

```

-----OUTPUT-----
False      SumPrint      - Print summary data to "<RootName>.fsm" (flag)
True       TabDelim      - Generate a tab-delimited tabular output file. (flag)
"ES10.3E2" OutFmt        - Format used for tabular output except time. Resulting field
should be 10 characters. (quoted string) [not checked for validity!]
    30.0    TStart        - Time to begin tabular output (s)
    1       DecFact       - Decimation factor for tabular output {1: output every time
step} (-)
    1.0     SttsTime      - Amount of time between screen status messages (sec)
-3.09528   NcIMUxn       - Downwind distance from the tower-top to the nacelle IMU
(meters)
    0.0     NcIMUyn       - Lateral distance from the tower-top to the nacelle IMU
(meters)
    2.23336 NcIMUzn       - Vertical distance from the tower-top to the nacelle IMU
(meters)
    1.912   ShftGagL      - Distance from rotor apex [3 blades] or teeter pin [2 blades]
to shaft strain gages [positive for upwind rotors] (meters)
    0       NTwGages      - Number of tower nodes that have strain gages for output [0
to 9] (-)
           TwrGagNd       - List of tower nodes that have strain gages [1 to TwrNodes]
(-) [unused if NTwGages=0]
    3       NBlGages      - Number of blade nodes that have strain gages for output [0
to 9] (-)
    5,9,13  BldGagNd      - List of blade nodes that have strain gages [1 to BldNodes]
(-) [unused if NBlGages=0]
           OutList        - The next line(s) contains a list of output parameters. See
OutList.txt for a listing of available output channels, (-)
"WindVxi, WindVyi, WindVzi" - Wind-speed components (m/s)
"Azimuth, RotSpeed"        - Rotor azimuth angle (deg) and angular speed (rpm)
"TSR"                      - Tip speed ratio (-)
"GenSpeed, GenAccel"        - Generator speed (rpm), and generator acceleration(deg/s^2)
"LSShftTq"                  - LSS torque (kNm)
"GenTq, GenPwr"             - Generator torque (kNm) and power (kW)
"TipDxb1, TipDyb1"          - Blade 1 flapwise and edgewise tip deflection (m)
"TipDxb2, TipDyb2"          - Blade 2 flapwise and edgewise tip deflection (m)
"TipDxb3, TipDyb3"          - Blade 3 flapwise and edgewise tip deflection (m)
"TipDxc1, TipDyc1"          - Blade 1 tip out-plane and in-plane defl (m)
"TipDxc2, TipDyc2"          - Blade 2 tip out-plane and in-plane defl (m)
"TipDxc3, TipDyc3"          - Blade 3 tip out-plane and in-plane defl (m)
"BldPitch1"                 - Blade 1 pitch angle (deg)
"BldPitch2"                 - Blade 2 pitch angle (deg)
"BldPitch3"                 - Blade 3 pitch angle (deg)
"YawBrTDxp"                 - Tower-top/yaw bearing fore-aft (translational) deflection (m)
"YawBrTDyp"                 - Tower-top/yaw bearing side-to-side (translational) deflection (m)
"YawBrTDzp"                 - Tower-top/yaw bearing axial (translational) deflection (m)
"RootMxb1, RootMyb1, RootMzb1" - Blade 1 root moments (kNm)
"RootMxb2, RootMyb2, RootMzb2" - Blade 2 root moments (kNm)
"RootMxb3, RootMyb3, RootMzb3" - Blade 3 root moments (kNm)
"TwrBsMyt"                  - Tower fore-aft moment.
END of FAST input file
-----

```