

```

87.6      TowerHt      - Height of tower above ground level [onshore] or MSL
[offshore] (meters)
1.96256   Twr2Shft    - Vertical distance from the tower-top to the rotor shaft (meters)
0.0       TwrRBHt     - Tower rigid base height (meters)
-5.0      ShftTilt    - Rotor shaft tilt angle (degrees)
0.0       Delta3      - Delta-3 angle for teetering rotors (degrees) [unused for 3 blades]
-2.5      PreCone(1)  - Blade 1 cone angle (degrees)
-2.5      PreCone(2)  - Blade 2 cone angle (degrees)
-2.5      PreCone(3)  - Blade 3 cone angle (degrees) [unused for 2 blades]
0.0       AzimBlUp    - Azimuth value to use for I/O when blade 1 points up (degrees)
-----
0.0       YawBrMass   - Yaw bearing mass (kg)
240.00E3  NacMass     - Nacelle mass (kg)
56.78E3   HubMass     - Hub mass (kg)
0.0       TipMass(1)  - Tip-brake mass, blade 1 (kg)
0.0       TipMass(2)  - Tip-brake mass, blade 2 (kg)
0.0       TipMass(3)  - Tip-brake mass, blade 3 (kg) [unused for 2 blades]
2607.89E3 NacYIner    - Nacelle inertia about yaw axis (kg m^2)
534.116   GenIner     - Generator inertia about HSS (kg m^2)
115.926E3 HubIner     - Hub inertia about rotor axis [3 blades] or teeter axis [2
blades] (kg m^2)
-----
100.0     GBoxEff     - Gearbox efficiency (%)
94.4      GenEff      - Generator efficiency [ignored by the Thevenin and
user-defined generator models] (%)
97.0      GBRatio     - Gearbox ratio (-)
False     GBRevers    - Gearbox reversal {T: if rotor and generator rotate in
opposite directions} (flag)
28.1162E3 HSSBrTqF    - Fully deployed HSS-brake torque (N-m)
0.6       HSSBrDT     - Time for HSS-brake to reach full deployment once initiated
(sec) [used only when HSSBrMode=1]
"Dummy"   DynBrkFi    - File containing a mech-gen-torque vs HSS-speed curve for a
dynamic brake [CURRENTLY IGNORED] (quoted string)
867.637E6 DTTorSpr    - Drivetrain torsional spring (N-m/rad)
6.215E6   DTTorDmp    - Drivetrain torsional damper (N-m/(rad/s))
-----
9999.9     SIG_SlPc    - Rated generator slip percentage (%) [used only when
VSContrl=0 and GenModel=1]
9999.9     SIG_SySp    - Synchronous (zero-torque) generator speed (rpm) [used only
when VSContrl=0 and GenModel=1]
9999.9     SIG_RtTq    - Rated torque (N-m) [used only when VSContrl=0 and
GenModel=1]
9999.9     SIG_PORT    - Pull-out ratio (Tpullout/Trated) (-) [used only when
VSContrl=0 and GenModel=1]
-----
9999.9     TEC_Freq    - Line frequency [50 or 60] (Hz) [used only when VSContrl=0
and GenModel=2]
9998       TEC_NPol    - Number of poles [even integer > 0] (-) [used only when
VSContrl=0 and GenModel=2]
9999.9     TEC_SRes    - Stator resistance (ohms) [used only when VSContrl=0 and
GenModel=2]
9999.9     TEC_RRes    - Rotor resistance (ohms) [used only when VSContrl=0 and
GenModel=2]
9999.9     TEC_VLL     - Line-to-line RMS voltage (volts) [used only when VSContrl=0
and GenModel=2]
9999.9     TEC_SLR     - Stator leakage reactance (ohms) [used only when VSContrl=0
and GenModel=2]
9999.9     TEC_RLR     - Rotor leakage reactance (ohms) [used only when VSContrl=0
and GenModel=2]
9999.9     TEC_MR      - Magnetizing reactance (ohms) [used only when VSContrl=0 and
GenModel=2]

```