

Mode	Button	Display						Display shows
		1	2	3	4	5	6	
AKT POS		D	D	M	M	X	Y	Lo/La of current position. TERNAV status and position error [km].
REF LOLA								Lo/La or Ref.# of current destination.
	LS/SKU	D	D	M	M	S	S	Lo/La or Ref.# of LS starting base.
	L/MÅL	9	X	X	X	0	0	Lo/La or Ref.# of L1/L2 landing base.
	B1-B9							Lo/La or Ref.# of depressed WP.
	BX + 1-9							Lo/La or Ref.# of Bx mark point.
BANA GRÄNS		X	X	X	X	X	X	Output depends on current destination.
	L/MÅL	D	D	D	D	X	X	RWY heading and TILS channel.
	B1-B9	D	D	D	D	D	D	First and second boundary line heading.
VIND RUTA MÅL		D	D	D	X	X	0	Doppler wind direction & speed [km/h].
	LS/SKU	D	D	D	X	X	□	Forecast wind direction & speed [km/h].
	1-9	D	D	M	M	S	S	Lo/La of SPA/MÅL target.
TID		X	H	M	M	S	S	Deviation of ETA with respect to ToT. X=□ ahead, X=9 behind schedule.
		7	H	M	M	S	S	Relative ETA – if no ToT was set.
	LS/SKU	H	H	M	M	S	S	Current time.
	B1-B9	H	H	M	M	S	S	ToT for target WP.
		X	Y	Y	0	0	0	Ingress speed M X.YY for WP.
	BX	H	H	M	M	S	S	ToT for RB 15 at Bx8.
TAKT		H	H	M	M	S	S	Timestamp of SPA/MÅL target.
TAKT		X ₇	X ₆	X ₅	X ₃	X ₂	X ₁	Weapon status on pylon <i>i</i> (X _i =0 empty).
	B1-B9	9	0	0	0	0	0	Depressed WP button is a target WP.