

VIZIO OS Menu Tree 2022 as of FUR5.4

		Main Menu	Settings	Sub Settings	Sub Sub settings	Options	Notes
1			Bluetooth Headphones				
2			TV Speakers			Checked (default) / Unchecked	
3			Paired Devices	PAIREDHEADPHONES			
4				PAIREDHEADPHONES			
5			Other Devices				
6			Forget Paired Devices				
7				UNPAIREDHEADPHONES			
8			Picture				
9			Picture Modes				
10				Vivid		default Store Demo	
11				Bright		default	
12				Calibrated			
13				Calibrated Dark			
14				Game			Applies to Computer in help text.
15				Sports			
16			Gaming				
17				Gaming/PC Mode		Auto (default), Off, On (default Game pic mode)	
18				Variable Refresh Rate		On (def), Off	DELETED?
19	V, M, P			Game HDR		Off (default), On	

20				HDMI Mode		Auto (default), Standard, Compatibility	D series: Auto, Standard
21				Current Gaming Mode			All status from TV system info
22					Resolution:		
23					Frame Rate:		
24					HDR:		
25					Variable Refrsh Rate:		
26					Audio Out:		
27	M/P		Ambient Light Sensor			Off (def), Low, Medium, High	If can tune light sensor to behave like a phone.
28			Backlight			slider	Help text describes range tone and mapping curve
29			Brightness			slider	
30			Contrast			slider	
31			Color			slider	
32			Tint			slider	
33			Sharpness			slider	
34			Color Temperature			Warm (default Calibrated, Cal. Dark,Game), Cool (default Vivid), Normal (default Bright,Sports)	
35			Aspect Ratio			Normal (default), Stretch OR Panoramic, Wide, Zoom	
36			Advanced Picture				
37				Black Detail		Off (def), Low, Medium, High	Black detail includes contrast enhancement
38				Super Resolution		Off, Low, Medium (def), High	
39				Edge Enhancement		Off (def Game), Low (def), Medium, High	
40				Active Pixel Tuning		Off, Low (def), Medium, High	Default by SDR or HDR &pic mode) Previously named Local Contrast

41	M7/8/QX, P9/X			Active Full Array		Off, Low, Medium, High	Default by SDR or HDR & pic mode
42	D, V, M6			OR Backlight Control		On (default), Off	
43	OLED			OR Peak Luminance (OLED)			
44	MQX, P9/X			Motion Control		0 (default) - 10	Default 5 for Vivid
45	MQX, P9/X				Judder Reduction	0 (default) - 10	Default 5 for Vivid
46	MQX, P9/X				Motion Blur Reduction	0 (default) - 10	Default 5 for Vivid
47	MQX, P9/X				Clear Action	Off (default), On	Off for Game also supports Computer
48	MQX, P9/X			Reduce Noise			
49					Signal Noise	Off (def Game), Low (def), Medium, High	
50					Block Noise	Off (def Game), Low (def), Medium, High	
51	V, M, P				Contour Smoothing	Off, Low (def), Medium, High	
52				Film Mode		On (default), Off	
53				Gamma		1.8, 2.0, 2.1 - Normal (default), 2.2 (Calibrated Dark default), 2.4	
54	M7, M8, P			Enhanced Viewing Angle		On (default), Off P9, PX only	also applies to V655-H9, V655x- H9, V505-H9 and M506x-H9
55				Color Calibration			
56					Picture Mode		Current setting displays
57					Color Temperature		Current setting displays
58					Dynamic Range		Current setting displays
59					Color Tuner		
60						Hue, Saturation, Brightness	Red, Green, Blue, Cyan, Magenta, Yellow

61					White Balance Tuner		
62						IRE% Red, Green, Blue	AKA 20-Point White Balance
63						RGB Offset Red, Green, Blue	AKA 2-Point White Balance
64					SMPTE Test Pattern	RGB Gain Red, Green, Blue	AKA 2-Point White Balance
65					Reset Color Temperature		
66				Calibration Test			
67					SMPTE Test Pattern		
68					Flat Test Pattern		
69					Ramp Test Pattern		21 bar
70					Uniformity Analyzer Test Pattern		
71			Input Picture Settings				
72				Picture Size and Position			Current source only
73					Picture Size		
74					Picture Position		
75				HDMI Mode (HDMI only)		Auto (default), 2.1, 1.4	Auto defaults to 2.1 (supercedes 2.0); if HDCP 2.2 NOT detected then 1.4
76	V, M, P			Full Color 4:4:4 (HDMI only)		Off (default), On	
77				Color Space Range (HDMI only)		Auto (default), YCbCr, RGB	
78			Picture Mode Edit				
79				Save Picture Mode			
80				Copy Picture mode			Deleted in FUR5.4
81				Lock Picture Mode			Deleted in FUR5.4

82				Reset OR Delete Picture Mode			
83							
84		Audio		Sound Bar control at bottom			
85			Audio Out			TV Speakers (default if no Sound bar) Auto (or sound bar name), Optical/	
86			Surround Sound			Virtual: X (default), On, Off	
87			Volume Leveling			Off (default), On	
88			Balance			slider	
89			Bass			slider	
90			Treble			slider	
91			Lip Sync			0 (default) - 5	
92			Digital Audio Out			Auto (default), PCM, Digital	
93			Analog Audio Out			Fixed (default), Variable (default models single jack)	
94			Dialogue Enhancer			Off (def), Low, Medium, High	
95	V, M, P		eARC mode			On (default), Off	
96							
97		Network					
98			My networks				Header - grayed out and not selectable
99			1. Ethernet Connected OR 2. WiFiName1 OR 3. Not Connected		display (ethernet and not connected) or action if WiFi	If Wi-Fi: Forget saved network	If WiFi include name, icons for selected AP, lock and signal strength.
100			WiFi Networks				5 AP passwords can be saved including above
101				Wi-Fi 1		Forget Saved Network	
102				Wi-Fi 2		Forget Saved Network	

103				Wi-Fi 3		Forget Saved Network	
104				Wi-Fi 4		Forget Saved Network	
105			More Wi-Fi Networks				
106			Test Connection				
107			Hidden Network				
108			Manual Setup			IPv4 only	
109			Network Information				
110							
111		Antenna Channels					
112			Find Channels				
113			Find More Channels				scans for new channels without deleting channels previously found
114			Skip Channels				
115			Digital Audio			English, Spanish/Video Description, French	
116			Parental Controls				
117				Enter Passcode			
118				Parental Locks		Off (default), On	
119				Lock by Channels			
120				Lock Shows by Rating		TV-Y, TV-Y7 +FV, TV-G, TV-PG + DLSV, TV-14 + DLSV, TV-MA + LSV	
121				USA Movie		G, PG, PG-13, R, NC-17	
122				Canadian English		C, C8+, G, PG, 14+, 18+	
123				Canadian French		G, 8 ans+, 13 ans+, 16 ans+, 18 ans+	
124				USA "System"			
125				Block Unrated Shows		Off (default), On	
126				Reset Locks			
127							
128		Accessibility					

129			Captions				
130				Closed Captions		Off (default), On	
131				Analog Closed Captions		CC1 (default), CC2, CC3, CC4	Only for models with composite
132				Digital Closed Captions		CS1 (default), CS2, CS3, CS4, CS5, CS6	
133				Digital Style			
134					Text Style	As Broadcast (default), Playbill, Newsprint, Computer, Modern, Casual, Script, Capitals	
135					Text Size	As Broadcast (default), Small, Medium, Large	
136					Text Color	As Broadcast (default), Black, White, Green, Blue, Red, Cyan, Yellow, Magenta	
137					Text Opacity	As Broadcast (default), Solid, Flashing, Translucen, Transparent	
138					Text Edges	As Broadcast (default), None, Raised, Depressed, Uniform, Drop Shadow	
139					Text Edges Color	As Broadcast (default), Black, White, Green, Blue, Red, Cyan, Yellow, Magenta	
140					Background Color	As Broadcast (default), Black, White, Green, Blue, Red, Cyan, Yellow, Magenta	
141					Background Opacity	As Broadcast (default), Solid, Flashing, Translucen, Transparent	
142					Window Color	As Broadcast (default), Black, White, Green, Blue, Red, Cyan, Yellow, Magenta	
143					Window Opacity	As Broadcast (default), Solid, Flashing, Translucen, Transparent	
144			Video Description			Off (default), On	Only displays if Tuner is source.
145			Talk Tack			Off (default), On	
146			Speech Rate			Slow, Normal (default), Fast	
147			Zoom Mode			Off (default), On	Arrow navigation
148							
149		System					
150			Menu Language			English, Español, Français	

151			Time				
152				Automatic Time			
153				Time Zone		Many ...	
154				Daylight Saving Time		Auto (default), On, Off	
155				Time Format		12 hour (default), 24 hour	
156			TV Name				
157			Input Name			HDMI 1-4, COMP	OR Blu-ray, Cable Box, Computer, DVD, DVR, Game, Satellite, Xbox
158			Hide From Input List			Visible (default), Hidden	Applies to TV, COMP, HDMI 1 - 4
159			Input at Power On			SmartCast, Last Used TV Input	
160			Power Mode			Eco Mode (default), Quick Start	
161			OLED				
162				Screen Refresher		Start at Power Off, Start Now	
163				Pixel Shift		On (default), Off	
164			USB Power			Always On (default), Off When TV Off	
165			Power Indicator			Off (default), On	
166			Timers				
167				Sleep Timer		Off (default), 30 minutes, 60 minutes, 90 minutes, 120 minutes, 180 minutes	
168				Auto Power Off		Off, 10 minutes (default)	
169				Blank Screen			
170			System PIN				
171			CEC				
172				CEC		Enabled (default), Disabled	
173				One Touch Play		Disabled (default), Enabled	
174				Device Discovery			
175			Mobile Devices			list paired devices	Feature deleted.
176			Voice Remote			Launch app	
177							
178		Admin & Privacy					

179			Reboot TV				
180			System Information				
181				TV Information			
182				Network Information			
183				Remote Information			
184				Application Information			
185				ULI Information			
186				Channel Information			
187			Support Code			App launched	
188			Check for Updates				
189			Reset to Factory Settings			Reset TV, Reset Apps, Reboot, Cancel	
190			Viewing Data			Off (default), On	
191			Advertising				
192				Limited Ad Tracking		On (default if Viewing Data is On), Off (default if Viewing Data is Off)	
193				Reset TV Advertiser ID			
194			VIZIO Privacy Policy				
195			Store Demo			Off (default), Demo 1, Demo 2	
196			User Manual				
197							
198			Audio with supported sound bar				
199			"VIZIO simplified sound bar" Settings (Audio out)			Examples: V51 Settings (PCM) P-Elevate Settings (Dolby Atmos - Dolby MAT)	Header with grayed text, not selectable
200				Bass			

201				Treble			
202				Dialogue			
203				Subwoofer			
204				Night Mode			
205				Virtual:X			
206				Speaker Test			
207				Info			
208					Model Name		
209					Serial Number		
210					Firmware		
211					Audio Out		
212			TV Audio Settings				Header with grayed text, not selectable
213				TV Speakers			
214				Digital Audio Out			
215				eARC Mode			