
Icom IC-706 MkIIG

Out of Band MARS Modification

Written in L^AT_EX



Figure 1: The Icom IC-706 MkIIG. [Image Credit](#)

Joel Brigida, BSCE
R & D, Engineering.
[GitHub](#) [LinkedIn](#)

Table of Contents

1	Disclaimer	2
2	Description of the Modification	2
3	Modification Procedure	3
3.1	Preliminary Procedure	3
3.2	Step One	5
3.3	Step Two	6
3.4	Step Three	7

1 Disclaimer

Please note that none of the information in this manual is meant to be legal advice in any way. The author of this document does not assume any responsibility for the accuracy of the information in this document. This document should be regarded as the author's own opinion, and nothing more for legal reasons even though this is a well researched subject in the author's own expertise. Do your own research, make sure you have the proper equipment, licenses and know the rules for the appropriate RF bands you are operating on. If any of this goes over your head, please stop and have someone with the proper knowledge educate you first.

Do not use this modification for anything else, like illegally transmitting on the GMRS band or the CB band. I do not recommend operating there on a Part 97 Radio. The radio's VCO was not designed to operate in these ranges, which results in lower power output even if the antenna is tuned for these ranges. For Example: GMRS is FCC Part 95 and as such must use either dedicated FCC Part 95 radios for GMRS, or FCC Part 90 radios that are bandsplit appropriately, like a 400 MHz to 470 MHz or a 450 MHz to 512 MHz band split, either of which will cover the 462 MHz and 467MHz GMRS channels and can properly operate there.

This modification is meant for MARS operators, who operate on bands which are adjacent or nearly adjacent to the ham bands. On the IC-706 MkIIG, this will also allow for operation in the 60 meter ham band (5.3 MHz), which was allocated after the production of the radio. Also note that at the time of this writing, the FCC has now allocated new spectrum in the 60 meter ham band which was approved for worldwide use at the WRC-15 conference. A link to this new information is on the [ARRL site here](#).

2 Description of the Modification

This modification allows the radio to transmit out-of-band. Such a modification is necessary if, for example, you are a member of the Military Auxiliary Radio System (MARS), in which out-of-band operation is permitted legally on an FCC Part 97 radio meant for the ham bands. This modification is colloquially referred to as a "MARS Mod". This will also open up the radio transmitter so it will operate on the 60 meter amateur radio band, which was not allocated at the time of the IC-706 MkIIG production.

3 Modification Procedure

3.1 Preliminary Procedure

In order to prevent any Electrostatic Discharge (ESD), an anti-static ESD mat should be used as shown in Figure 3. Be sure the mat is grounded properly. An excellent ground source is the ground lug on a household 120VAC NEMA 5-15 or 5-20 outlet. There are some cheap ground lug outlet adapters as seen [here \[Amazon link\]](#) which convert the ground lug into a banana jack.



Figure 2: An example of an outlet ground lug to banana jack adapter.

Before working on the radio, be sure that it is disconnected from all power sources. Only the radio body needs to be worked on for this repair, so the head should be removed for that purpose. Using the ground lug adapter and an ESD mat kit, ground the mat to the outlet ground, preferably with the side facing away from the technician. At the side facing towards the technician, clip the wrist strap to the other side of the ESD mat and put the wrist strap on the non-dominant hand so it does not get in the way. Now the ESD mat and the technician are all grounded and at equal potential. If you need to purchase an ESD mat kit, there are some kits [here \[Amazon Link\]](#). Note in Figure 3 the alligator clips pull off to reveal banana jacks. The top lead needs to be connected to the ground lug adapter, and the bottom lead with the wrist strap can be alligator clipped to the mat for a proper connection.



Figure 3: Proper setup of an ESD mat with the radio body.

If the ESD mat does not have buttons to snap the leads onto (most do), then just use alligator clips to make the connection to the mat. This still provides the proper electrical connection needed for equal potential.

3.2 Step One

Starting this modification requires removing the top cover of the radio. The top cover is the cover with the speaker, and the speaker can be left attached to the cover during the procedure. There are 5 Phillips style screws: 3 in the middle of the top panel, and one on each side at the rear. The cover then flips up toward the front of the radio. The speaker wire lead can be disconnected as shown by pulling the two connector halves apart with the technicians fingers. No pliers or picks are needed here and will only damage the connector. Refer to Figure 4 showing the cover removed with the area of interest circled.




Figure 4: Removal of the top cover [5 screws] and speaker connection.

3.3 Step Two

Left of center on the front board is a row of jumper pads. Refer to figure 5 for the jumper/resistor location. The only resistor in the row of jumper pads is the one that must be removed. In Figure 5, the pad with the resistor is circled and already removed. This modification requires proficiency with a [hot air rework station](#). In the author's experience, the "Yihua" brand of rework stations has proved very reliable. This also requires use of [SMD tweezers](#) to remove the surface mount jumper after heated, and a [magnifier headset](#). Heat up the jumper with moderate heat, set the blower to a very low speed so the component does not unsolder then blow across the board and get lost. Care must be taken since heating up the jumper with the blower may cause adjacent components to heat up and melt their solder. This is only a problem if they are moved while the solder is melted. In the case of an accidentally moved component, make sure the jumper is already removed, then go back after the solder hardens in a minute or so, reheat the component and carefully move it back into place with the tweezers.




Figure 5: Location of the resistor that must be removed for the MARS mod to work.

Image Credit: [KK4ICE](#)

3.4 Step Three

The modification is now complete. Set aside the removed jumper so it does not fall loose into the radio, and reassemble in reverse order. Install the top cover, do not forget to reconnect the speaker connector, then reinstall the five screws. Now the faceplate can be reinstalled, the radio plugged in, and the radio can be tested on the 60 meter band (5.3 MHz) with a dummy load and a wattmeter as shown below. For effective full scale power output, be sure the RF power is set to maximum in the IC-706 MkiIG internal menu. If you are unsure how to do this, the author has archived the *IC-706 MkiIG Operating Guide* [here on GitHub](#). Whistle loudly close to the mic with the transmitter keyed in SSB mode, and this should output maximum power, since SSB is suppressed carrier.



Figure 6: A proper test setup using a Bird 43 wattmeter and a 100 watt dummy load in VHF 2m band.