


# Klayout: Parameterized Cells Scripting

2020 SiEPIC Passive Silicon Photonics Workshop, Vancouver, Canada



**Mustafa Hammood,**  
The University of British Columbia, Vancouver, Canada



a place of mind  
THE UNIVERSITY OF BRITISH COLUMBIA

**MiNa** Microsystems and  
Nanotechnology Group  
Photonics Research Group



Electrical and  
Computer  
Engineering


# Outline

---

- **SiEPIC EPDA Flow**
- **What is a parameterized cell?**
- **How to setup and start creating scripts**
- **Define components library**
- **Make your first parameterized cell**




# SiEPIC EPDA



# Pcell?

- A method to generate the layout of a parameterized device, contains:
  - Physical device parameters
  - Ports definitions
  - Device region definition
  - Compact models (?)



## Instance Properties

Cell hi?

Cell  Library 


Geometry

PCell parameters



Si Layer	Si - 1/0
Si Gratings Layer	Si - 1/0
Radius (um)	5
Width (um)	0.5
Gratings Period (nm)	318
Corrugation Width (um)	0.04
N (number of corrugations)	30
Bus-to-straight bend radius	5
PinRec Layer	PinRec - 1/10
DevRec Layer	DevRec - 68/0

# Setup

- Open Macro Development



- Create a new Python script in your local directory
- Copy content of my\_first\_script.py



# Define components library

- Call it SiEPIC\_Demo
- Built on a technology
  - 'EBeam'
- Register all PCells in the script
  - 'Ebeam\_Bent\_Bragg'


```

157 class SiEPIC_Demo(Library):
158     """
159     The library where we will put the PCells and GDS into
160     """
161
162     def __init__(self):
163
164         tech_name = 'EBeam_Personal'
165         library = tech_name
166
167         print("Initializing '%s' Library." % library)
168
169         # Set the description
170         # windows only allows for a fixed width, short description
171         self.description = ""
172         # OSX does a resizing:
173         self.description = "This is my first library!"
174
175         # Create the PCell declarations
176         self.layout().register_pcell("ebeam_Bent_Bragg", ebeam_Bent_Bragg())
177
178         # Register the library with the technology name
179         # If a library with that name already existed, it will be replaced then.
180         self.register(library)
181
182         self.technology='EBeam'
183
184         # Instantiate and register the library
185         SiEPIC_Demo()

```





# Define components library



# Pcell: Objective

- We want to turn Bragg gratings from straight to bent over an Arc
- Parameters:
  - Radius
  - Waveguide width
  - Bragg period
  - Bragg corrugation width
  - Number of Bragg periods
  - Layers





# Pcell: Format

- `__init__`: initialize technology and GUI Pcell parameters
- `Display_text_impl`: Description of the Pcell, appears when selected
- `produce`: Actual implementation of the Pcell (polygon drawing definition) and ports definition, and device recognition

```

16 class ebeam_Bent_Bragg(PCellDeclarationHelper):
17
18     def __init__(self):
19         # initialize the super class and technology
20         super(ebeam_Bent_Bragg, self).__init__()
21         TECHNOLOGY = get_technology_by_name('EBeam')
22
23         # declare the PCell parameters
24         self.param("silayer", self.TypeLayer, "Si Layer", default = TECHNOLOGY["Waveguide"])
25         self.param("width", self.TypeDouble, "Width (um)", default = 0.5)
26
27     def display_text_impl(self):
28         # Provide a descriptive text for the cell
29         return "Description"
30
31     def produce(self, layout, layers, parameters, cell):
32
33         # Draw the PCell polygons
34
35         # Create the device pins, as short paths:
36
37         # Create the device recognition layer -- make it 1 * wg_width away from the waveguides.
38

```

# Pcell: Objective

---

- We want to turn Bragg gratings from straight to bent over an Arc
- Parameters:
  - Radius
  - Waveguide width
  - Bragg period
  - Bragg corrugation width
  - Number of Bragg periods
  - Layers



# Pcell: Script Parameters GUI and tech

- Method: `__init__`

```
def __init__(self):
```

```
    # Important: initialize the super class
```

```
    super(ebeam_Bent_Bragg, self).__init__()
```

```
    TECHNOLOGY = get_technology_by_name('EBeam')
```

```
    # declare the parameters
```

```
    self.param("silayer", self.TypeLayer, "Si Layer", default = TECHNOLOGY['Waveguide'])
```

```
    self.param("silayer_gratings", self.TypeLayer, "Si Gratings Layer", default = TECHNOLOGY['31_Si_p6nm'])
```

```
    self.param("radius", self.TypeDouble, "Radius (um)", default = 25)
```

```
    self.param("width", self.TypeDouble, "Width (um)", default = 0.5)
```

```
    self.param("period", self.TypeDouble, "Gratings Period (nm)", default = 318)
```

```
    self.param("deltaW", self.TypeDouble, "Corrugation Width (um)", default = 0.04)
```

```
    self.param("gamma", self.TypeDouble, "N (number of corrugations)", default = 135)
```


```
    self.param("pinrec", self.TypeLayer, "PinRec Layer", default = TECHNOLOGY['PinRec'])
```

```
    self.param("devrec", self.TypeLayer, "DevRec Layer", default = TECHNOLOGY['DevRec'])
```

# Pcell: Description

- Method: `display_text_impl`

```
def display_text_impl(self):
    # Provide a descriptive text for the cell
    return "Bent_Bragg(R=" + ('%.3f' % self.radius) + ")"
```



# Pcell: Produce: fetch layout parameters

- Method: Produce

```
def produce(self, layout, layers, parameters, cell):
```

```
#coerce parameters (make consistent)
```

```
self._layers = layers
```

```
self.cell = cell
```

```
self._param_values = parameters
```

```
self.layout = layout
```

```
# cell: layout cell to place the layout
```

```
# LayerSiN: which layer to use
```

```
# r: radius
```

```
# w: waveguide width
```

```
# length units in dbu
```

```
from math import pi, cos, sin
```

```
from SiEPIC.utils import arc_wg, arc_wg_xy
```

```
from SiEPIC._globals import PIN_LENGTH
```

```
# fetch the parameters
```

```
dbu = self.layout.dbu
```

```
ly = self.layout
```

```
LayerSi = self.silayer
```

```
LayerSiN_gratings = self.silayer_gratings_layer
```

```
LayerSiN = self.silayer_layer
```

```
LayerPinRecN = ly.layer(self.pinrec)
```

```
LayerDevRecN = ly.layer(self.devrec)
```

```
from SiEPIC.extend import to_itype
```

```
w = to_itype(self.width,dbu)
```

```
r = to_itype(self.radius,dbu)
```

```
period = self.period
```

```
deltaW = to_itype(self.deltaW,dbu)
```

```
N = int(self.gamma)
```

# Pcell: Produce: Draw layout!

- Method: Produce

*# Center of everything*

$x = 0$


$y = 0$

*# Angle of Bragg corrugated portion, also bend angle!*

$\text{periodAngle} = (180/\pi) * (\text{period}/2) / r$

*# Bend angle*


$\text{bendAngle} = (180/\pi) * (N * \text{period}/2) / r$





# Pcell: Produce: Draw layout!

- **Method: Produce**
- **Draw corrugations (wide)**
- **Use an arc function (arg\_wg\_xy)**
  - skip every other period
- **Draw corrugations (narrow)**
- **Use an arc function (arg\_wg\_xy)**
  - skip every other period




```
# Bragg wide
ii = periodAngle*2
while ii < N+periodAngle*1.5:
    self.cell.shapes(LayerSiN_gratings).insert(arc_wg_xy(x,y, r, w+deltaW, 90+bendAngle-ii, 90+bendAngle-ii-periodAngle))
    ii = ii+periodAngle
    ii = ii+periodAngle
```

```
# Bragg narrow
ii = periodAngle
while ii < N:
    self.cell.shapes(LayerSiN_gratings).insert(arc_wg_xy(x,y, r, w-deltaW, 90+bendAngle-ii, 90+bendAngle-ii-periodAngle))
    ii = ii+periodAngle
    ii = ii+periodAngle
```

# Pcell: Produce: Draw layout!

- Method: Produce
- Draw bend sections (uncorrugated)
- Use an arc function (arg\_wg\_xy)



*# bend non-corrugated left*


```
self.cell.shapes(LayerSiN).insert(arc_wg_xy(x,y, r, w, 180-(90-bendAngle), 180))
```

*# bend non-corrugated right*

```
self.cell.shapes(LayerSiN).insert(arc_wg_xy(x,y, r, w, 0, 90-bendAngle))
```

# Pcell: Produce: Draw layout!

- **Method: Produce**
- **Draw optical input pins**
- **As wide as waveguides width**
- **Be aware of orientation!**
- **This enables component snapping**
- **Used for connectivity/netlist**



*# Pin on the bottom left side:*


```
p1 = [Point(x-r, pin_length/2 + y), Point(x-r, -pin_length/2 + y)]
p1c = Point(x-r, y)
self.set_p1 = p1c
self.p1 = p1c
pin = Path(p1, w)
self.cell.shapes(LayerPinRecN).insert(pin)
t = Trans(Trans.R0, x-r, y)
text = Text("opt1", t)
shape = self.cell.shapes(LayerPinRecN).insert(text)
shape.text_size = 0.4/dbu
```

*# Pin on the bottom right side:*

```
p2 = [Point(x+r, y+pin_length/2), Point(x+r, y-pin_length/2)]
p2c = Point(x+r, y)
self.set_p2 = p2c
self.p2 = p2c
pin = Path(p2, w)
self.cell.shapes(LayerPinRecN).insert(pin)
t = Trans(Trans.R0, x+r, y)
text = Text("opt2", t)
shape = self.cell.shapes(LayerPinRecN).insert(text)
shape.text_size = 0.4/dbu
```

# Pcell: Produce: Draw layout!

- **Method: Produce**
- **Draw device recognition (bounding) box**
- **Used for device area recognition, prevents from overlapping with other components**



*# Create the device recognition layer -- make it 1 \* wg\_width away from the waveguides.*  
`self.cell.shapes(LayerDevRecN).insert(arc_wg_xy(x ,y, r, w*5, 0, 180))`

# Pcell examples:

---

- **MMI**
- **Ring Resonator**
- **Bragg Grating**
- **Directional Coupler**
- **Taper**

