

# FEM/BEM NOTES

<http://www.cmiss.org/>

Bioengineering Institute  
The University of Auckland  
New Zealand

September 26, 2013

© Copyright 1997-  
Bioengineering Institute  
The University of Auckland



# Contents

<b>1</b>	<b>Finite Element Basis Functions</b>	<b>1</b>
1.1	Representing a One-Dimensional Field . . . . .	1
1.2	Linear Basis Functions . . . . .	1
1.3	Basis Functions as Weighting Functions . . . . .	3
1.4	Quadratic Basis Functions . . . . .	4
1.5	Two- and Three-Dimensional Elements . . . . .	5
1.6	Higher Order Continuity . . . . .	6
1.7	Triangular Elements . . . . .	9
1.8	Curvilinear Coordinate Systems . . . . .	10
1.9	CMISS Examples . . . . .	13
<b>2</b>	<b>Steady-State Heat Conduction</b>	<b>15</b>
2.1	One-Dimensional Steady-State Heat Conduction . . . . .	15
2.1.1	Integral equation . . . . .	16
2.1.2	Integration by parts . . . . .	16
2.1.3	Finite element approximation . . . . .	17
2.1.4	Element integrals . . . . .	18
2.1.5	Assembly . . . . .	19
2.1.6	Boundary conditions . . . . .	20
2.1.7	Solution . . . . .	21
2.1.8	Fluxes . . . . .	21
2.2	An $x$ -Dependent Source Term . . . . .	21
2.3	The Galerkin Weight Function Revisited . . . . .	22
2.4	Two and Three-Dimensional Steady-State Heat Conduction . . . . .	23
2.5	Basis Functions - Element Discretisation . . . . .	25
2.6	Integration . . . . .	25
2.7	Assemble Global Equations . . . . .	26
2.8	Gaussian Quadrature . . . . .	28
2.9	CMISS Examples . . . . .	30
<b>3</b>	<b>The Boundary Element Method</b>	<b>31</b>
3.1	Introduction . . . . .	31
3.2	The Dirac-Delta Function and Fundamental Solutions . . . . .	31
3.2.1	Dirac-Delta function . . . . .	31
3.2.2	Fundamental solutions . . . . .	33

3.3	The Two-Dimensional Boundary Element Method . . . . .	35
3.4	Numerical Solution Procedures for the Boundary Integral Equation . . . . .	39
3.5	Numerical Evaluation of Coefficient Integrals . . . . .	41
3.6	The Three-Dimensional Boundary Element Method . . . . .	43
3.7	A Comparison of the FE and BE Methods . . . . .	44
3.8	More on Numerical Integration . . . . .	45
3.8.1	Logarithmic quadrature and other special schemes . . . . .	46
3.8.2	Special solutions . . . . .	47
3.9	The Boundary Element Method Applied to other Elliptic PDEs . . . . .	47
3.10	Solution of Matrix Equations . . . . .	47
3.11	Coupling the FE and BE techniques . . . . .	47
3.12	Other BEM techniques . . . . .	49
3.12.1	Trefftz method . . . . .	49
3.12.2	Regular BEM . . . . .	50
3.13	Symmetry . . . . .	51
3.14	Axisymmetric Problems . . . . .	52
3.15	Infinite Regions . . . . .	54
3.16	Appendix: Common Fundamental Solutions . . . . .	55
3.16.1	Two-Dimensional equations . . . . .	55
3.16.2	Three-Dimensional equations . . . . .	55
3.16.3	Axisymmetric problems . . . . .	56
3.17	CMISS Examples . . . . .	56
<b>4</b>	<b>Transient Heat Conduction</b>	<b>57</b>
4.1	Introduction . . . . .	57
4.2	Finite Differences . . . . .	57
4.2.1	Explicit Transient Finite Differences . . . . .	57
4.2.2	Von Neumann Stability Analysis . . . . .	59
4.2.3	Higher Order Approximations . . . . .	60
4.3	The Transient Advection-Diffusion Equation . . . . .	61
4.4	Mass lumping . . . . .	64
4.5	CMISS Examples . . . . .	65
<b>5</b>	<b>Linear Elasticity</b>	<b>67</b>
5.1	Introduction . . . . .	67
5.2	Truss Elements . . . . .	68
5.3	Beam Elements . . . . .	70
5.4	Plane Stress Elements . . . . .	72
5.4.1	Notes on calculating nodal loads . . . . .	74
5.5	Three-Dimensional Elasticity . . . . .	75
5.5.1	Weighted Residual Integral Equation . . . . .	76
5.5.2	The Principle of Virtual Work . . . . .	77
5.5.3	The Finite Element Approximation . . . . .	78
5.6	Linear Elasticity with Boundary Elements . . . . .	79
5.7	Fundamental Solutions . . . . .	81

5.8	Boundary Integral Equation . . . . .	83
5.9	Body Forces (and Domain Integrals in General) . . . . .	86
5.10	CMISS Examples . . . . .	88
<b>6</b>	<b>Modal Analysis</b>	<b>89</b>
6.1	Introduction . . . . .	89
6.2	Free Vibration Modes . . . . .	89
6.3	An Analytic Example . . . . .	91
6.4	Proportional Damping . . . . .	92
6.5	CMISS Examples . . . . .	93
<b>7</b>	<b>Constitutive Laws</b>	<b>95</b>
7.1	Introduction . . . . .	95
7.2	Kinematic Relations . . . . .	95
7.2.1	Coordinate systems and metric tensors . . . . .	96
7.2.2	Strain measures . . . . .	97
<b>8</b>	<b>Data fitting with finite elements</b>	<b>99</b>
8.1	Introduction . . . . .	99
8.2	Linear field fitting . . . . .	99
8.2.1	The linear field fitting problem . . . . .	99
8.2.2	Calculation of data point projections . . . . .	100
8.2.3	Least squares field fitting . . . . .	100
8.2.4	Gauss point fitting . . . . .	101
8.3	Linear geometric fitting . . . . .	101
8.3.1	Introduction . . . . .	101
8.3.2	Fitting with one geometric variable . . . . .	102
8.3.3	Linear geometric fitting with fixed $\xi_d$ locations . . . . .	102
8.4	Geometric fitting with Hermite elements . . . . .	104
8.4.1	Review of cubic Hermite interpolation . . . . .	104
8.4.2	Least squares fitting with cubic Hermite interpolation . . . . .	107
8.4.3	Non-linear geometric fitting with Hermite elements . . . . .	109
<b>9</b>	<b>Derivative BIE</b>	<b>113</b>
9.1	Boundary Element Formulation . . . . .	113
9.1.1	Discretisation . . . . .	115
9.2	Three-dimensional element splitting . . . . .	117
9.2.1	$P_o$ at local node 1 . . . . .	117
9.2.2	$P_o$ at local node 2 . . . . .	118
9.2.3	$P_o$ at local node 3 . . . . .	118
9.2.4	$P_o$ at local node 4 . . . . .	118
9.3	Hermite “Simplexes” . . . . .	118
9.3.1	Apex at local node 3 . . . . .	119
9.3.2	Apex at local node 1 . . . . .	119

---

<b>10 Domain Integrals in the BEM</b>	<b>121</b>
10.1 Achieving a Boundary Integral Formulation . . . . .	121
10.2 Removing Domain Integrals due to Inhomogeneous Terms . . . . .	122
10.2.1 The Galerkin Vector technique . . . . .	122
10.2.2 The Monte Carlo method . . . . .	123
10.2.3 Complementary Function-Particular Integral method . . . . .	124
10.3 Domain Integrals Involving the Dependent Variable . . . . .	124
10.3.1 The Perturbation Boundary Element Method . . . . .	125
10.3.2 The Multiple Reciprocity Method . . . . .	126
10.3.3 The Dual Reciprocity Boundary Element Method . . . . .	128
<b>11 The BEM for Parabolic PDES</b>	<b>137</b>
11.1 Time-Stepping Methods . . . . .	137
11.1.1 Coupled Finite Difference - Boundary Element Method . . . . .	137
11.1.2 Direct Time-Integration Method . . . . .	139
11.2 Laplace Transform Method . . . . .	140
11.3 The DR-BEM For Transient Problems . . . . .	141
11.4 The MRM for Transient Problems . . . . .	142

# Chapter 1

## Finite Element Basis Functions

### 1.1 Representing a One-Dimensional Field

Consider the problem of finding a mathematical expression  $u(x)$  to represent a one-dimensional field *e.g.*, measurements of temperature  $u$  against distance  $x$  along a bar, as shown in Figure 1.1a.

FIGURE 1.1: (a) Temperature distribution  $u(x)$  along a bar. The points are the measured temperatures. (b) A least-squares polynomial fit to the data, showing the unacceptable oscillation between data points.

One approach would be to use a polynomial expression  $u(x) = a + bx + cx^2 + dx^3 + \dots$  and to estimate the values of the parameters  $a$ ,  $b$ ,  $c$  and  $d$  from a least-squares fit to the data. As the degree of the polynomial is increased the data points are fitted with increasing accuracy and polynomials provide a very convenient form of expression because they can be differentiated and integrated readily. For low degree polynomials this is a satisfactory approach, but if the polynomial order is increased further to improve the accuracy of fit a problem arises: the polynomial can be made to fit the data accurately, but it oscillates unacceptably between the data points, as shown in Figure 1.1b.

To circumvent this, while retaining the advantages of low degree polynomials, we divide the bar into three subregions and use low order polynomials over each subregion - called *elements*. For later generality we also introduce a parameter  $s$  which is a measure of distance along the bar.  $u$  is plotted as a function of this arclength in Figure 1.2a. Figure 1.2b shows three linear polynomials in  $s$  fitted by least-squares separately to the data in each element.

FIGURE 1.2: (a) Temperature measurements replotted against arclength parameter  $s$ . (b) The  $s$  domain is divided into three subdomains, *elements*, and linear polynomials are independently fitted to the data in each subdomain.

### 1.2 Linear Basis Functions

A new problem has now arisen in Figure 1.2b: the piecewise linear polynomials are not continuous in  $u$  across the boundaries between elements. One solution would be to constrain the parameters  $a$ ,

$b, c$  etc. to ensure continuity of  $u$  across the element boundaries, but a better solution is to replace the parameters  $a$  and  $b$  in the first element with parameters  $u_1$  and  $u_2$ , which are the values of  $u$  at the two ends of that element. We then define a linear variation between these two values by

$$u(\xi) = (1 - \xi)u_1 + \xi u_2$$

where  $\xi(0 \leq \xi \leq 1)$  is a normalized measure of distance along the curve.

We define

$$\begin{aligned}\varphi_1(\xi) &= 1 - \xi \\ \varphi_2(\xi) &= \xi\end{aligned}$$

such that

$$u(\xi) = \varphi_1(\xi)u_1 + \varphi_2(\xi)u_2$$

and refer to these expressions as the *basis* functions associated with the *nodal* parameters  $u_1$  and  $u_2$ . The basis functions  $\varphi_1(\xi)$  and  $\varphi_2(\xi)$  are straight lines varying between 0 and 1 as shown in Figure 1.3.

FIGURE 1.3: Linear basis functions  $\varphi_1(\xi) = 1 - \xi$  and  $\varphi_2(\xi) = \xi$ .

It is convenient always to associate the nodal quantity  $u_n$  with *element node*  $n$  and to map the temperature  $U_\Delta$  defined at *global node*  $\Delta$  onto local node  $n$  of element  $e$  by using a connectivity matrix  $\Delta(n, e)$  i.e.,

$$u_n = U_{\Delta(n, e)}$$

where  $\Delta(n, e)$  = global node number of local node  $n$  of element  $e$ . This has the advantage that the interpolation

$$u(\xi) = \varphi_1(\xi)u_1 + \varphi_2(\xi)u_2$$

holds for any element provided that  $u_1$  and  $u_2$  are correctly identified with their global counterparts, as shown in Figure 1.4. Thus, in the first element

FIGURE 1.4: The relationship between global nodes and element nodes.

$$u(\xi) = \varphi_1(\xi)u_1 + \varphi_2(\xi)u_2 \tag{1.1}$$

with  $u_1 = U_1$  and  $u_2 = U_2$ .

In the second element  $u$  is interpolated by

$$u(\xi) = \varphi_1(\xi)u_1 + \varphi_2(\xi)u_2 \tag{1.2}$$

with  $u_1 = U_2$  and  $u_2 = U_3$ , since the parameter  $U_2$  is shared between the first and second elements the temperature field  $u$  is implicitly continuous. Similarly, in the third element  $u$  is interpolated by

$$u(\xi) = \varphi_1(\xi)u_1 + \varphi_2(\xi)u_2 \tag{1.3}$$



with  $u_1 = U_3$  and  $u_2 = U_4$ , with the parameter  $U_3$  being shared between the second and third elements. Figure 1.6 shows the temperature field defined by the three interpolations (1.1)–(1.3).

FIGURE 1.5: Temperature measurements fitted with nodal parameters and linear basis functions. The fitted temperature field is now continuous across element boundaries.

### 1.3 Basis Functions as Weighting Functions

It is useful to think of the basis functions as weighting functions on the nodal parameters. Thus, in element 1

$$\text{at } \xi = 0 \quad u(0) = (1 - 0)u_1 + 0u_2 = u_1$$

which is the value of  $u$  at the left hand end of the element and has no dependence on  $u_2$

$$\text{at } \xi = \frac{1}{4} \quad u\left(\frac{1}{4}\right) = \left(1 - \frac{1}{4}\right)u_1 + \frac{1}{4}u_2 = \frac{3}{4}u_1 + \frac{1}{4}u_2$$

which depends on  $u_1$  and  $u_2$ , but is weighted more towards  $u_1$  than  $u_2$

$$\text{at } \xi = \frac{1}{2} \quad u\left(\frac{1}{2}\right) = \left(1 - \frac{1}{2}\right)u_1 + \frac{1}{2}u_2 = \frac{1}{2}u_1 + \frac{1}{2}u_2$$

which depends equally on  $u_1$  and  $u_2$

$$\text{at } \xi = \frac{3}{4} \quad u\left(\frac{3}{4}\right) = \left(1 - \frac{3}{4}\right)u_1 + \frac{3}{4}u_2 = \frac{1}{4}u_1 + \frac{3}{4}u_2$$

which depends on  $u_1$  and  $u_2$  but is weighted more towards  $u_2$  than  $u_1$

$$\text{at } \xi = 1 \quad u(1) = (1 - 1)u_1 + 1u_2 = u_2$$

which is the value of  $u$  at the right hand end of the region and has no dependence on  $u_1$ .

Moreover, these weighting functions can be considered as *global* functions, as shown in Figure 1.6, where the weighting function  $w_n$  associated with global node  $n$  is constructed from the basis functions in the elements adjacent to that node.

FIGURE 1.6: (a) ... (d) The weighting functions  $w_n$  associated with the global nodes  $n = 1 \dots 4$ , respectively. Notice the linear fall off in the elements adjacent to a node. Outside the immediately adjacent elements, the weighting functions are defined to be zero.

For example,  $w_2$  weights the global parameter  $U_2$  and the influence of  $U_2$  falls off linearly in the elements on either side of node 2.

We now have a continuous piecewise parametric description of the temperature field  $u(\xi)$  but in order to define  $u(x)$  we need to define the relationship between  $x$  and  $\xi$  for each element. A convenient way to do this is to define  $x$  as an interpolation of the nodal values of  $x$ .

For example, in element 1

$$x(\xi) = \varphi_1(\xi) x_1 + \varphi_2(\xi) x_2 \quad (1.4)$$

and similarly for the other two elements. The dependence of temperature on  $x$ ,  $u(x)$ , is therefore defined by the parametric expressions

$$u(\xi) = \sum_n \varphi_n(\xi) u_n$$

$$x(\xi) = \sum_n \varphi_n(\xi) x_n$$

where summation is taken over all element nodes (in this case only 2) and the parameter  $\xi$  (the “element coordinate”) links temperature  $u$  to physical position  $x$ .  $x(\xi)$  provides the mapping between the mathematical space  $0 \leq \xi \leq 1$  and the physical space  $x_1 \leq x \leq x_2$ , as illustrated in Figure 1.7.

FIGURE 1.7: Illustrating how  $x$  and  $u$  are related through the normalized element coordinate  $\xi$ . The values of  $x(\xi)$  and  $u(\xi)$  are obtained from a linear interpolation of the nodal variables and then plotted as  $u(x)$ . The points at  $\xi = 0.2$  are emphasized.

## 1.4 Quadratic Basis Functions

The essential property of the basis functions defined above is that the basis function associated with a particular node takes the value of 1 when evaluated at that node and is zero at every other node in the element (only one other in the case of linear basis functions). This ensures the linear independence of the basis functions. It is also the key to establishing the form of the basis functions for higher order interpolation. For example, a quadratic variation of  $u$  over an element requires three nodal parameters  $u_1$ ,  $u_2$  and  $u_3$

$$u(\xi) = \varphi_1(\xi) u_1 + \varphi_2(\xi) u_2 + \varphi_3(\xi) u_3 \quad (1.5)$$

The quadratic basis functions are shown, with their mathematical expressions, in Figure 1.8. Notice that since  $\varphi_1(\xi)$  must be zero at  $\xi = 0.5$  (node 2),  $\varphi_1(\xi)$  must have a factor  $(\xi - 0.5)$  and since it is also zero at  $\xi = 1$  (node 3), another factor is  $(\xi - 1)$ . Finally, since  $\varphi_1(\xi)$  is 1 at  $\xi = 0$  (node 1) we have  $\varphi_1(\xi) = 2(\xi - 1)(\xi - 0.5)$ . Similarly for the other two basis functions.

FIGURE 1.8: One-dimensional quadratic basis functions.

## 1.5 Two- and Three-Dimensional Elements

Two-dimensional bilinear basis functions are constructed from the products of the above one-dimensional linear functions as follows

Let

$$u(\xi_1, \xi_2) = \varphi_1(\xi_1, \xi_2) u_1 + \varphi_2(\xi_1, \xi_2) u_2 + \varphi_3(\xi_1, \xi_2) u_3 + \varphi_4(\xi_1, \xi_2) u_4$$

where

$$\begin{aligned}\varphi_1(\xi_1, \xi_2) &= (1 - \xi_1)(1 - \xi_2) \\ \varphi_2(\xi_1, \xi_2) &= \xi_1(1 - \xi_2) \\ \varphi_3(\xi_1, \xi_2) &= (1 - \xi_1)\xi_2 \\ \varphi_4(\xi_1, \xi_2) &= \xi_1\xi_2\end{aligned}\tag{1.6}$$

Note that  $\varphi_1(\xi_1, \xi_2) = \varphi_1(\xi_1)\varphi_1(\xi_2)$  where  $\varphi_1(\xi_1)$  and  $\varphi_1(\xi_2)$  are the one-dimensional linear basis functions. Similarly,  $\varphi_2(\xi_1, \xi_2) = \varphi_2(\xi_1)\varphi_1(\xi_2) \dots etc.$

These four bilinear basis functions are illustrated in Figure 1.9.

FIGURE 1.9: Two-dimensional bilinear basis functions.

Notice that  $\varphi_n(\xi_1, \xi_2)$  is 1 at node  $n$  and zero at the other three nodes. This ensures that the temperature  $u(\xi_1, \xi_2)$  receives a contribution from each nodal parameter  $u_n$  weighted by  $\varphi_n(\xi_1, \xi_2)$  and that when  $u(\xi_1, \xi_2)$  is evaluated at node  $n$  it takes on the value  $u_n$ .

As before the geometry of the element is defined in terms of the node positions  $(x_n, y_n)$ ,  $n = 1, \dots, 4$  by

$$\begin{aligned}x &= \sum_n \varphi_n(\xi_1, \xi_2) x_n \\ y &= \sum_n \varphi_n(\xi_1, \xi_2) y_n\end{aligned}$$

which provide the mapping between the mathematical space  $(\xi_1, \xi_2)$  (where  $0 \leq \xi_1, \xi_2 \leq 1$ ) and the physical space  $(x, y)$ .

Higher order 2D basis functions can be similarly constructed from products of the appropriate 1D basis functions. For example, a six-noded (see Figure 1.10) quadratic-linear element (quadratic in  $\xi_1$  and linear in  $\xi_2$ ) would have

$$u = \sum_{n=1}^6 \varphi_n(\xi_1, \xi_2) u_n$$

where

$$\varphi_1(\xi_1, \xi_2) = 2(\xi_1 - 1)(\xi_1 - 0.5)(1 - \xi_2) \quad \varphi_2(\xi_1, \xi_2) = 4\xi_1(1 - \xi_1)(1 - \xi_2) \tag{1.7}$$

$$\varphi_3(\xi_1, \xi_2) = 2\xi_1(\xi_1 - 0.5)(1 - \xi_2) \quad \varphi_4(\xi_1, \xi_2) = 2(\xi_1 - 1)(\xi_1 - 0.5)\xi_2 \tag{1.8}$$

$$\varphi_5(\xi_1, \xi_2) = 4\xi_1(1 - \xi_1)\xi_2 \quad \varphi_6(\xi_1, \xi_2) = 2\xi_1(\xi_1 - 0.5)\xi_2 \tag{1.9}$$

FIGURE 1.10: A 6-node quadratic-linear element (node numbers circled).

Three-dimensional basis functions are formed similarly, *e.g.*, a trilinear element basis has eight nodes (see Figure 1.11) with basis functions

$$\varphi_1(\xi_1, \xi_2, \xi_3) = (1 - \xi_1)(1 - \xi_2)(1 - \xi_3) \quad \varphi_2(\xi_1, \xi_2, \xi_3) = \xi_1(1 - \xi_2)(1 - \xi_3) \quad (1.10)$$

$$\varphi_3(\xi_1, \xi_2, \xi_3) = (1 - \xi_1)\xi_2(1 - \xi_3) \quad \varphi_4(\xi_1, \xi_2, \xi_3) = \xi_1\xi_2(1 - \xi_3) \quad (1.11)$$

$$\varphi_5(\xi_1, \xi_2, \xi_3) = (1 - \xi_1)(1 - \xi_2)\xi_3 \quad \varphi_6(\xi_1, \xi_2, \xi_3) = \xi_1(1 - \xi_2)\xi_3 \quad (1.12)$$

$$\varphi_7(\xi_1, \xi_2, \xi_3) = (1 - \xi_1)\xi_2\xi_3 \quad \varphi_8(\xi_1, \xi_2, \xi_3) = \xi_1\xi_2\xi_3 \quad (1.13)$$

FIGURE 1.11: An 8-node trilinear element.

## 1.6 Higher Order Continuity

All the basis functions mentioned so far are *Lagrange*<sup>1</sup> basis functions and provide continuity of  $u$  across element boundaries but not higher order continuity. Sometimes it is desirable to use basis functions which also preserve continuity of the derivative of  $u$  with respect to  $\xi$  across element boundaries. A convenient way to achieve this is by defining two additional nodal parameters  $\left(\frac{du}{d\xi}\right)_n$ . The basis functions are chosen to ensure that

$$\left.\frac{du}{d\xi}\right|_{\xi=0} = \left(\frac{du}{d\xi}\right)_1 = u'_1 \text{ and } \left.\frac{du}{d\xi}\right|_{\xi=1} = \left(\frac{du}{d\xi}\right)_2 = u'_2$$

and since  $u_n$  is shared between adjacent elements derivative continuity is ensured. Since the number of element parameters is 4 the basis functions must be cubic in  $\xi$ . To derive these cubic *Hermite*<sup>2</sup> basis functions let

$$u(\xi) = a + b\xi + c\xi^2 + d\xi^3,$$

$$\frac{du}{d\xi} = b + 2c\xi + 3d\xi^2,$$

---

<sup>1</sup>Joseph-Louis Lagrange (1736-1813).

<sup>2</sup>Charles Hermite (1822-1901).

and impose the constraints

$$\begin{aligned} u(0) &= a & &= u_1 \\ u(1) &= a + b + c + d & &= u_2 \\ \frac{du}{d\xi}(0) &= b & &= u'_1 \\ \frac{du}{d\xi}(1) &= b + 2c + 3d & &= u'_2 \end{aligned}$$

These four equations in the four unknowns  $a$ ,  $b$ ,  $c$  and  $d$  are solved to give

$$\begin{aligned} a &= u_1 \\ b &= u'_1 \\ c &= 3u_2 - 3u_1 - 2u'_1 - u'_2 \\ d &= u'_1 + u'_2 + 2u_1 - 2u_2 \end{aligned}$$

Substituting  $a$ ,  $b$ ,  $c$  and  $d$  back into the original cubic then gives

$$u(\xi) = u_1 + u'_1 \xi + (3u_2 - 3u_1 - 2u'_1 - u'_2) \xi^2 + (u'_1 + u'_2 + 2u_1 - 2u_2) \xi^3$$

or, rearranging,

$$u(\xi) = \Psi_1^0(\xi) u_1 + \Psi_1^1(\xi) u'_1 + \Psi_2^0(\xi) u_2 + \Psi_2^1(\xi) u'_2 \quad (1.14)$$

where the four cubic Hermite basis functions are drawn in Figure 1.12.

FIGURE 1.12: Cubic Hermite basis functions.

One further step is required to make cubic Hermite basis functions useful in practice. The derivative  $\left(\frac{du}{d\xi}\right)_n$  defined at node  $n$  is dependent upon the element  $\xi$ -coordinate in the two adjacent elements. It is much more useful to define a global node derivative  $\left(\frac{du}{ds}\right)_n$  where  $s$  is arclength and then use

$$\left(\frac{du}{d\xi}\right)_n = \left(\frac{du}{ds}\right)_{\Delta(n,e)} \cdot \left(\frac{ds}{d\xi}\right)_n \quad (1.15)$$

where  $\left(\frac{ds}{d\xi}\right)_n$  is an element *scale factor* which scales the arclength derivative of global node  $\Delta$  to the  $\xi$ -coordinate derivative of element node  $n$ . Thus  $\frac{du}{ds}$  is constrained to be continuous across element boundaries rather than  $\frac{du}{d\xi}$ . A two-dimensional bicubic Hermite basis requires four derivatives per node

$$u, \frac{\partial u}{\partial \xi_1}, \frac{\partial u}{\partial \xi_2} \text{ and } \frac{\partial^2 u}{\partial \xi_1 \partial \xi_2}$$

The need for the second-order cross-derivative term can be explained as follows; If  $u$  is cubic in  $\xi_1$

and cubic in  $\xi_2$ , then  $\frac{\partial u}{\partial \xi_1}$  is quadratic in  $\xi_1$  and cubic in  $\xi_2$ , and  $\frac{\partial u}{\partial \xi_2}$  is cubic in  $\xi_1$  and quadratic in  $\xi_2$ . Now consider the side 1–3 in Figure 1.13. The cubic variation of  $u$  with  $\xi_2$  is specified by the four nodal parameters  $u_1$ ,  $\left(\frac{\partial u}{\partial \xi_2}\right)_1$ ,  $u_3$  and  $\left(\frac{\partial u}{\partial \xi_2}\right)_3$ . But since  $\frac{\partial u}{\partial \xi_1}$  (the normal derivative) is also cubic in  $\xi_2$  along that side and is entirely independent of these four parameters, four additional parameters are required to specify this cubic. Two of these are specified by  $\left(\frac{\partial u}{\partial \xi_1}\right)_1$  and  $\left(\frac{\partial u}{\partial \xi_1}\right)_3$ , and the remaining two by  $\left(\frac{\partial^2 u}{\partial \xi_1 \partial \xi_2}\right)_1$  and  $\left(\frac{\partial^2 u}{\partial \xi_1 \partial \xi_2}\right)_3$ .

FIGURE 1.13: Interpolation of nodal derivative  $\frac{\partial u}{\partial \xi_1}$  along side 1–3.

The bicubic interpolation of these nodal parameters is given by

$$\begin{aligned}
 u(\xi_1, \xi_2) = & \Psi_1^0(\xi_1) \Psi_1^0(\xi_2) u_1 + \Psi_2^0(\xi_1) \Psi_1^0(\xi_2) u_2 \\
 & + \Psi_1^0(\xi_1) \Psi_2^0(\xi_2) u_3 + \Psi_2^0(\xi_1) \Psi_2^0(\xi_2) u_4 \\
 & + \Psi_1^1(\xi_1) \Psi_1^0(\xi_2) \left(\frac{\partial u}{\partial \xi_1}\right)_1 + \Psi_2^1(\xi_1) \Psi_1^0(\xi_2) \left(\frac{\partial u}{\partial \xi_1}\right)_2 \\
 & + \Psi_1^1(\xi_1) \Psi_2^0(\xi_2) \left(\frac{\partial u}{\partial \xi_1}\right)_3 + \Psi_2^1(\xi_1) \Psi_2^0(\xi_2) \left(\frac{\partial u}{\partial \xi_1}\right)_4 \\
 & + \Psi_1^0(\xi_1) \Psi_1^1(\xi_2) \left(\frac{\partial u}{\partial \xi_2}\right)_1 + \Psi_2^0(\xi_1) \Psi_1^1(\xi_2) \left(\frac{\partial u}{\partial \xi_2}\right)_2 \\
 & + \Psi_1^0(\xi_1) \Psi_2^1(\xi_2) \left(\frac{\partial u}{\partial \xi_2}\right)_3 + \Psi_2^0(\xi_1) \Psi_2^1(\xi_2) \left(\frac{\partial u}{\partial \xi_2}\right)_4 \\
 & + \Psi_1^1(\xi_1) \Psi_1^1(\xi_2) \left(\frac{\partial^2 u}{\partial \xi_1 \partial \xi_2}\right)_1 + \Psi_2^1(\xi_1) \Psi_1^1(\xi_2) \left(\frac{\partial^2 u}{\partial \xi_1 \partial \xi_2}\right)_2 \\
 & + \Psi_1^1(\xi_1) \Psi_2^1(\xi_2) \left(\frac{\partial^2 u}{\partial \xi_1 \partial \xi_2}\right)_3 + \Psi_2^1(\xi_1) \Psi_2^1(\xi_2) \left(\frac{\partial^2 u}{\partial \xi_1 \partial \xi_2}\right)_4
 \end{aligned} \tag{1.16}$$

where

$$\begin{aligned}
 \Psi_1^0(\xi) &= 1 - 3\xi^2 + 2\xi^3 \\
 \Psi_1^1(\xi) &= \xi(\xi - 1)^2 \\
 \Psi_2^0(\xi) &= \xi^2(3 - 2\xi) \\
 \Psi_2^1(\xi) &= \xi^2(\xi - 1)
 \end{aligned} \tag{1.17}$$

are the one-dimensional cubic Hermite basis functions (see Figure 1.12).

As in the one-dimensional case above, to preserve derivative continuity in physical  $x$ -coordinate space as well as in  $\xi$ -coordinate space the global node derivatives need to be specified with respect to physical arclength. There are now two arclengths to consider:  $s_1$ , measuring arclength along the

$\xi_1$ -coordinate, and  $s_2$ , measuring arclength along the  $\xi_2$ -coordinate. Thus

$$\begin{aligned} \left( \frac{\partial u}{\partial \xi_1} \right)_n &= \left( \frac{\partial u}{\partial s_1} \right)_{\Delta(n,e)} \cdot \left( \frac{\partial s_1}{\partial \xi_1} \right)_n \\ \left( \frac{\partial u}{\partial \xi_2} \right)_n &= \left( \frac{\partial u}{\partial s_2} \right)_{\Delta(n,e)} \cdot \left( \frac{\partial s_2}{\partial \xi_2} \right)_n \\ \left( \frac{\partial^2 u}{\partial \xi_1 \partial \xi_2} \right)_n &= \left( \frac{\partial^2 u}{\partial s_1 \partial s_2} \right)_{\Delta(n,e)} \cdot \left( \frac{ds_1}{d\xi_1} \right)_n \cdot \left( \frac{ds_2}{d\xi_2} \right)_n \end{aligned} \quad (1.18)$$

where  $\left( \frac{ds_1}{d\xi_1} \right)_n$  and  $\left( \frac{ds_2}{d\xi_2} \right)_n$  are element *scale factors* which scale the arclength derivatives of global node  $\Delta$  to the  $\xi$ -coordinate derivatives of element node  $n$ .

The bicubic Hermite basis is a powerful shape descriptor for curvilinear surfaces. Figure 1.14 shows a four element bicubic Hermite surface in 3D space where each node has the following twelve parameters

$$x, \frac{\partial x}{\partial s_1}, \frac{\partial x}{\partial s_2}, \frac{\partial^2 x}{\partial s_1 \partial s_2}, y, \frac{\partial y}{\partial s_1}, \frac{\partial y}{\partial s_2}, \frac{\partial^2 y}{\partial s_1 \partial s_2}, z, \frac{\partial z}{\partial s_1}, \frac{\partial z}{\partial s_2} \text{ and } \frac{\partial^2 z}{\partial s_1 \partial s_2}$$

FIGURE 1.14: A surface formed by four bicubic Hermite elements.

## 1.7 Triangular Elements

Triangular elements cannot use the  $\xi_1$  and  $\xi_2$  coordinates defined above for *tensor product* elements (*i.e.*, two- and three- dimensional elements whose basis functions are formed as the product of one-dimensional basis functions). The natural coordinates for triangles are based on area ratios and are called *Area Coordinates*. Consider the ratio of the area formed from the points 2, 3 and  $P(x, y)$  in Figure 1.15 to the total area of the triangle

FIGURE 1.15: Area coordinates for a triangular element.

$$L_1 = \frac{\text{Area} \langle P23 \rangle}{\text{Area} \langle 123 \rangle} = \frac{1}{2} \begin{vmatrix} 1 & x & y \\ 1 & x_2 & y_2 \\ 1 & x_3 & y_3 \end{vmatrix} / \Delta = (a_1 + b_1 x + c_1 y) / (2\Delta)$$

where  $\Delta = \frac{1}{2} \begin{vmatrix} 1 & x_1 & y_1 \\ 1 & x_2 & y_2 \\ 1 & x_3 & y_3 \end{vmatrix}$  is the area of the triangle with vertices 123, and  $a_1 = x_2 y_3 - x_3 y_2$ ,  $b_1 = y_2 - y_3$ ,  $c_1 = x_3 - x_2$ .

Notice that  $L_1$  is linear in  $x$  and  $y$ . Similarly, area coordinates for the other two triangles

containing  $P$  and two of the element vertices are

$$L_2 = \frac{\text{Area} \langle P13 \rangle}{\text{Area} \langle 123 \rangle} = \frac{1}{2} \begin{vmatrix} 1 & x & y \\ 1 & x_3 & y_3 \\ 1 & x_1 & y_1 \end{vmatrix} / \Delta = (a_2 + b_2x + c_2y) / (2\Delta)$$

$$L_3 = \frac{\text{Area} \langle P12 \rangle}{\text{Area} \langle 123 \rangle} = \frac{1}{2} \begin{vmatrix} 1 & x & y \\ 1 & x_1 & y_1 \\ 1 & x_2 & y_2 \end{vmatrix} / \Delta = (a_3 + b_3x + c_3y) / (2\Delta)$$

where  $a_2 = x_3y_1 - x_1y_3$ ,  $b_2 = y_3 - y_1$ ,  $c_2 = x_1 - x_3$  and  $a_3 = x_1y_2 - x_2y_1$ ,  $b_3 = y_1 - y_2$ ,  $c_3 = x_2 - x_1$ .

Notice that  $L_1 + L_2 + L_3 = 1$ .

Area coordinate  $L_1$  varies linearly from  $L_1 = 0$  when  $P$  lies at node 2 or 3 to  $L_1 = 1$  when  $P$  lies at node 1 and can therefore be used directly as the basis function for node 1 for a three node triangle. Thus, interpolation over the triangle is given by

$$u(x, y) = \varphi_1(x, y) u_1 + \varphi_2(x, y) u_2 + \varphi_3(x, y) u_3$$

where  $\varphi_1 = L_1$ ,  $\varphi_2 = L_2$  and  $\varphi_3 = L_3 = 1 - L_1 - L_2$ .

Six node quadratic triangular elements are constructed as shown in Figure 1.16.

FIGURE 1.16: Basis functions for a six node quadratic triangular element.

## 1.8 Curvilinear Coordinate Systems

It is sometimes convenient to model the geometry of the region (over which a finite element solution is sought) using an orthogonal curvilinear coordinate system. A 2D circular annulus, for example, can be modelled geometrically using one element with cylindrical polar  $(r, \theta)$ -coordinates, *e.g.*, the annular plate in Figure 1.17a has two global nodes, the first with  $r = r_1$  and the second with  $r = r_2$ .

FIGURE 1.17: Defining a circular annulus with one cylindrical polar element. Notice that element vertices 1 and 2 in  $(r, \theta)$ -space or  $(\xi_1, \xi_2)$ -space, as shown in (b) and (c), respectively, map onto the single global node 1 in  $(x, y)$ -space in (a). Similarly, element vertices 3 and 4 map onto global node 2.

Global nodes 1 and 2, shown in  $(x, y)$ -space in Figure 1.17a, each map to two element vertices in  $(r, \theta)$ -space, as shown in Figure 1.17b, and in  $(\xi_1, \xi_2)$ -space, as shown in Figure 1.17c. The  $(r, \theta)$  coordinates at any  $(\xi_1, \xi_2)$  point are given by a bilinear interpolation of the nodal coordinates  $r_n$  and  $\theta_n$  as

$$\begin{aligned} r &= \varphi_n(\xi_1, \xi_2) \cdot r_n \\ \theta &= \varphi_n(\xi_1, \xi_2) \cdot \theta_n \end{aligned}$$



where the basis functions  $\varphi_n(\xi_1, \xi_2)$  are given by (1.6).

Three orthogonal curvilinear coordinate systems are defined here for use in later sections.

**Cylindrical polar**  $(r, \theta, z)$  :

$$\begin{aligned} x &= r \cos \theta \\ y &= r \sin \theta \\ z &= z \end{aligned} \tag{1.19}$$

**Spherical polar**  $(r, \theta, \phi)$  :

$$\begin{aligned} x &= r \cos \theta \cos \phi \\ y &= r \sin \theta \cos \phi \\ z &= r \sin \phi \end{aligned} \tag{1.20}$$

**Prolate spheroidal**  $(\lambda, \mu, \theta)$  :

$$\begin{aligned} x &= d \cosh \lambda \cos \mu \\ y &= d \sinh \lambda \sin \mu \cos \theta \\ z &= d \sinh \lambda \sin \mu \sin \theta \end{aligned} \tag{1.21}$$

FIGURE 1.18: Prolate spheroidal coordinates.

The prolate spheroidal coordinates are illustrated in Figure 1.18 and a single prolate spheroidal element is shown in Figure 1.19. The coordinates  $(\lambda, \mu, \theta)$  are all trilinear in  $(\xi_1, \xi_2, \xi_3)$ . Only four global nodes are required provided the four global nodes map to eight element nodes as shown in Figure 1.19.

FIGURE 1.19: A single prolate spheroidal element, shown (a) in  $(x, y, z)$ -coordinates, (c) in  $(\lambda, \mu, \theta)$ -coordinates and (d) in  $(\xi_1, \xi_2, \xi_3)$ -coordinates, (b) shows the orientation of the  $\xi_i$ -coordinates on the prolate spheroid.

## 1.9 CMISS Examples

1. To define a 2D bilinear finite element mesh run the CMISS example number 111. The nodes should be positioned as shown in Figure 1.20. After defining elements the mesh should appear like the one shown in Figure 1.21.

FIGURE 1.20: Node positions for example 111.

FIGURE 1.21: 2D bilinear finite element mesh for example 111.

2. To refine a mesh run the CMISS example 113. After the first refine the mesh should appear like the one shown in Figure 1.22.

FIGURE 1.22: First refined mesh for example 113

3. To define a quadratic-linear element run the cmiss example 115.
4. To define a 3D trilinear element run CMISS example 121.
5. To define a 2D cubic Hermite-linear finite element mesh run example 114.
6. To define a triangular element mesh run CMISS example 116 (see Figure 1.24).
7. To define a bilinear mesh in cylindrical polar coordinates run CMISS example 122.

FIGURE 1.23: Second refined mesh for example 113

FIGURE 1.24: Defining a triangular mesh for example 116

# Chapter 2

## Steady-State Heat Conduction

### 2.1 One-Dimensional Steady-State Heat Conduction

Our first example of solving a partial differential equation by finite elements is the one-dimensional steady-state heat equation. The equation arises from a simple heat balance over a region of conducting material:

Rate of change of heat flux = heat source per unit volume

or

$$\frac{d}{dx} (\text{heat flux}) + \text{heat sink per unit volume} = 0$$

or

$$\frac{d}{dx} \left( -k \frac{du}{dx} \right) + q(u, x) = 0$$

where  $u$  is temperature,  $q(u, x)$  the heat sink and  $k$  the thermal conductivity (Watts/m/°C).

Consider the case where  $q = u$

$$-\frac{d}{dx} \left( k \frac{du}{dx} \right) + u = 0 \quad 0 < x < 1 \quad (2.1)$$

subject to boundary conditions:  $u(0) = 0$  and  $u(1) = 1$ .

This equation (with  $k = 1$ ) has an exact solution

$$u(x) = \frac{e}{e^2 - 1} (e^x - e^{-x}) \quad (2.2)$$

with which we can compare the approximate finite element solutions.

To solve Equation (2.1) by the finite element method requires the following steps:

1. Write down the integral equation form of the heat equation.
2. Integrate by parts (in 1D) or use Green's Theorem (in 2D or 3D) to reduce the order of derivatives.

3. Introduce the finite element approximation for the temperature field with nodal parameters and element basis functions.
4. Integrate over the elements to calculate the element stiffness matrices and RHS vectors.
5. Assemble the global equations.
6. Apply the boundary conditions.
7. Solve the global equations.
8. Evaluate the fluxes.

### 2.1.1 Integral equation

Rather than solving Equation (2.1) directly, we form the weighted residual

$$\int R\omega \cdot dx = 0 \quad (2.3)$$

where  $R$  is the residual

$$R = -\frac{d}{dx} \left( k \frac{du}{dx} \right) + u \quad (2.4)$$

for an approximate solution  $u$  and  $\omega$  is a weighting function to be chosen below. If  $u$  were an exact solution over the whole domain, the residual  $R$  would be zero everywhere. But, given that in real engineering problems this will not be the case, we try to obtain an approximate solution  $u$  for which the residual or error (*i.e.*, the amount by which the differential equation is not satisfied exactly at a point) is distributed evenly over the domain. Substituting Equation (2.4) into Equation (2.3) gives

$$\int_0^1 \left\{ -\frac{d}{dx} \left( k \frac{du}{dx} \right) \omega + u\omega \right\} dx = 0 \quad (2.5)$$

This formulation of the governing equation can be thought of as forcing the residual or error to be zero in a spatially averaged sense. More precisely,  $\omega$  is chosen such that the residual is kept orthogonal to the space of functions used in the approximation of  $u$  (see step 3 below).

### 2.1.2 Integration by parts

A major advantage of the integral equation is that the order of the derivatives inside the integral can be reduced from two to one by integrating by parts (or, equivalently for 2D problems, by applying Green's theorem - see later). Thus, substituting  $f = \omega$  and  $g = -k \frac{du}{dx}$  into the *integration by parts* formula

$$\int_0^1 f \frac{dg}{dx} dx = [f \cdot g]_0^1 - \int_0^1 g \frac{df}{dx} dx$$

gives

$$\int_0^1 \omega \frac{d}{dx} \left( -k \frac{du}{dx} \right) dx = \left[ \omega \left( -k \frac{du}{dx} \right) \right]_0^1 - \int_0^1 \left( -k \frac{du}{dx} \frac{d\omega}{dx} \right) dx$$

and Equation (2.5) becomes

$$\int_0^1 \left( k \frac{du}{dx} \frac{d\omega}{dx} + u\omega \right) dx = \left[ k \frac{du}{dx} \omega \right]_0^1 \quad (2.6)$$

### 2.1.3 Finite element approximation

We divide the domain  $0 < x < 1$  into 3 equal length elements and replace the continuous field variable  $u(x)$  within each element by the parametric finite element approximation

$$\begin{aligned} u(\xi) &= \varphi_1(\xi) u_1 + \varphi_2(\xi) u_2 = \varphi_n(\xi) u_n \\ x(\xi) &= \varphi_1(\xi) x_1 + \varphi_2(\xi) x_2 = \varphi_n(\xi) x_n \end{aligned}$$

(summation implied by repeated index) where  $\varphi_1(\xi) = 1 - \xi$  and  $\varphi_2(\xi) = \xi$  are the linear basis functions for both  $u$  and  $x$ .

We also choose  $\omega = \varphi_m$  (called the *Galerkin*<sup>1</sup> assumption). This forces the residual  $R$  to be orthogonal to the space of functions used to represent the dependent variable  $u$ , thereby ensuring that the residual, or error, is monotonically reduced as the finite element mesh is refined (see later for a more complete justification of this very important step).

The domain integral in Equation (2.6) can now be replaced by the sum of integrals taken separately over the three elements

$$\int_0^1 \cdot dx = \int_0^{\frac{1}{3}} \cdot dx + \int_{\frac{1}{3}}^{\frac{2}{3}} \cdot dx + \int_{\frac{2}{3}}^1 \cdot dx$$

and each element integral is then taken over  $\xi$ -space

$$\int_{x_1}^{x_2} \cdot dx = \int_0^1 \cdot J d\xi$$

where  $J = \left| \frac{dx}{d\xi} \right|$  is the Jacobian of the transformation from  $x$  coordinates to  $\xi$  coordinates.

---

<sup>1</sup>Boris G. Galerkin (1871-1945). Galerkin was a Russian engineer who published his first technical paper on the buckling of bars while imprisoned in 1906 by the Tzar in pre-revolutionary Russia. In many Russian texts the Galerkin finite element method is known as the Bubnov-Galerkin method. He published a paper using this idea in 1915. The method was also attributed to I.G. Bubnov in 1913.

### 2.1.4 Element integrals

The element integrals arising from the LHS of Equation (2.6) have the form

$$\int_0^1 \left( k \frac{du}{dx} \frac{d\omega}{dx} + u\omega \right) J d\xi \quad (2.7)$$

where  $u = \varphi_n u_n$  and  $\omega = \varphi_m$ . Since  $\varphi_n$  and  $\varphi_m$  are both functions of  $\xi$  the derivatives with respect to  $x$  need to be converted to derivatives with respect to  $\xi$ . Thus Equation (2.7) becomes

$$u_n \int_0^1 \left( k \frac{d\varphi_n}{d\xi} \frac{d\xi}{dx} \frac{d\varphi_m}{d\xi} \frac{d\xi}{dx} + \varphi_n \varphi_m \right) J d\xi \quad (2.8)$$

Notice that  $u_n$  has been taken outside the integral because it is not a function of  $\xi$ . The term  $\frac{d\xi}{dx}$  is evaluated by substituting the finite element approximation  $x(\xi) = \varphi_n x_n$ . In this case  $x = \frac{1}{3}\xi$  or  $\frac{d\xi}{dx} = 3$  and the Jacobian is  $J = \frac{dx}{d\xi} = \frac{1}{3}$ . The term multiplying the nodal parameters  $u_n$  is called the element stiffness matrix,  $E_{mn}$

$$E_{mn} = \int_0^1 \left( k \frac{d\varphi_m}{d\xi} \frac{d\xi}{dx} \frac{d\varphi_n}{d\xi} \frac{d\xi}{dx} + \varphi_m \varphi_n \right) J d\xi = \int_0^1 \left( k \frac{d\varphi_m}{d\xi} 3 \frac{d\varphi_n}{d\xi} 3 + \varphi_m \varphi_n \right) \frac{1}{3} d\xi$$

where the indices  $m$  and  $n$  are 1 or 2. To evaluate  $E_{mn}$  we substitute the basis functions

$$\begin{aligned} \varphi_1(\xi) &= 1 - \xi & \text{or } \frac{d\varphi_1}{d\xi} &= -1 \\ \varphi_2(\xi) &= \xi & \text{or } \frac{d\varphi_2}{d\xi} &= 1 \end{aligned}$$

Thus,

$$E_{11} = \frac{1}{3} \int_0^1 \left( 9k \left( \frac{d\varphi_1}{d\xi} \right)^2 + (\varphi_1)^2 \right) d\xi = \frac{1}{3} \int_0^1 (9k(-1)^2 + (1-\xi)^2) d\xi = \frac{1}{3} \left( 9k + \frac{1}{3} \right)$$



FIGURE 2.1: The rows of the global stiffness matrix are generated from the global weight functions. The bar is shown at the top divided into three elements.

and, similarly,

$$\begin{aligned} E_{12} &= E_{21} = \frac{1}{3} \left( -9k + \frac{1}{6} \right) \\ E_{22} &= \frac{1}{3} \left( 9k + \frac{1}{3} \right) \\ E_{mn} &= \begin{bmatrix} \frac{1}{3} \left( 9k + \frac{1}{3} \right) & \frac{1}{3} \left( -9k + \frac{1}{6} \right) \\ \frac{1}{3} \left( -9k + \frac{1}{6} \right) & \frac{1}{3} \left( 9k + \frac{1}{3} \right) \end{bmatrix} \end{aligned}$$

Notice that the element stiffness matrix is symmetric. Notice also that the stiffness matrix, in this particular case, is the same for all elements. For simplicity we put  $k = 1$  in the following steps.

### 2.1.5 Assembly

The three element stiffness matrices (with  $k = 1$ ) are assembled into one global stiffness matrix. This process is illustrated in Figure 2.1 where rows 1, ..., 4 of the global stiffness matrix (shown here multiplied by the vector of global unknowns) are generalised from the weight function associated with nodes 1, ..., 4.

Note how each element stiffness matrix (the smaller square brackets in Figure 2.1) overlaps with its neighbour because they share a common global node. The assembly process gives

$$\begin{bmatrix} \frac{28}{9} & -\frac{53}{18} & 0 & 0 \\ -\frac{53}{18} & \frac{28}{9} + \frac{28}{9} & -\frac{53}{18} & 0 \\ 0 & -\frac{53}{18} & \frac{28}{9} + \frac{28}{9} & -\frac{53}{18} \\ 0 & 0 & -\frac{53}{18} & \frac{28}{9} \end{bmatrix} \begin{bmatrix} U_1 \\ U_2 \\ U_3 \\ U_4 \end{bmatrix}$$

Notice that the first row (generating heat flux at node 1) has zeros multiplying  $U_3$  and  $U_4$  since nodes 3 and 4 have no direct connection through the basis functions to node 1. Finite element matrices are always *sparse* matrices - containing many zeros - since the basis functions are local to elements.

The RHS of Equation (2.6) is

$$\left[ k \frac{du}{dx} \omega \right]_{x=0}^{x=1} = \left( k \frac{du}{dx} \omega \right) \Big|_{x=1} - \left( k \frac{du}{dx} \omega \right) \Big|_{x=0} \quad (2.9)$$

To evaluate these expressions consider the weighting function  $\omega$  corresponding to each global node (see Fig.1.6). For node 1  $\omega_1$  is obtained from the basis function  $\varphi_1$  associated with the first node of element 1 and therefore  $\omega_1|_{x=0} = 1$ . Also, since  $\omega_1$  is identically zero outside element 1,  $\omega_1|_{x=1} = 0$ . Thus Equation (2.9) for node 1 reduces to

$$\left[ k \frac{du}{dx} \omega_1 \right]_{x=0}^{x=1} = - \left( k \frac{du}{dx} \right) \Big|_{x=0} = \text{flux entering node 1.}$$

Similarly,

$$\left[ k \frac{du}{dx} \omega_n \right]_{x=0}^{x=1} = 0 \quad (\text{nodes 2 and 3})$$

and

$$\left[ k \frac{du}{dx} \omega_4 \right]_{x=0}^{x=1} = \left( k \frac{du}{dx} \right) \Big|_{x=1} = \text{flux entering node 4.}$$

Note:  $k$  has been left in these expressions to emphasise that they are heat fluxes.

Putting these global equations together we get

$$\begin{bmatrix} \frac{28}{9} & -\frac{53}{18} & 0 & 0 \\ -\frac{53}{18} & \frac{28}{9} + \frac{28}{9} & -\frac{53}{18} & 0 \\ 0 & -\frac{53}{18} & \frac{28}{9} + \frac{28}{9} & -\frac{53}{18} \\ 0 & 0 & -\frac{53}{18} & \frac{28}{9} \end{bmatrix} \begin{bmatrix} U_1 \\ U_2 \\ U_3 \\ U_4 \end{bmatrix} = \begin{bmatrix} - \left( k \frac{du}{dx} \right) \Big|_{x=0} \\ 0 \\ 0 \\ \left( k \frac{du}{dx} \right) \Big|_{x=1} \end{bmatrix} \quad (2.10)$$

or

$$\mathbf{K} \mathbf{u} = \mathbf{f}$$

where  $\mathbf{K}$  is the global “stiffness” matrix,  $\mathbf{u}$  the vector of unknowns and  $\mathbf{f}$  the global “load” vector.

Note that if the governing differential equation had included a distributed source term that was independent of  $u$ , this term would appear - via its weighted integral - on the RHS of Equation (2.10) rather than on the LHS as here. Moreover, if the source term was a function of  $x$ , the contribution from each element would be different - as shown in the next section.

### 2.1.6 Boundary conditions

The boundary conditions  $u(0) = 0$  and  $u(1) = 1$  are applied directly to the first and last nodal values: *i.e.*,  $U_1 = 0$  and  $U_4 = 1$ . These so-called *essential* boundary conditions then replace the first and last rows in the global Equation (2.10), where the flux terms on the RHS are at present unknown

$$\begin{array}{llll} \text{1st equation} & U_1 & & = 0 \\ \text{2nd equation} & -\frac{53}{18}U_1 & +\frac{56}{9}U_2 & -\frac{53}{18}U_3 = 0 \\ \text{3rd equation} & & -\frac{53}{18}U_2 & +\frac{56}{9}U_3 -\frac{53}{18}U_4 = 0 \\ \text{4th equation} & & & U_4 = 1 \end{array}$$

Note that, if a flux boundary condition had been applied, rather than an essential boundary condition, the known value of flux would enter the appropriate RHS term and the value of  $U$  at that node would remain an unknown in the system of equations. An applied boundary flux of zero, corresponding to an insulated boundary, is termed a *natural* boundary condition, since effectively no additional constraint is applied to the global equation. At least one essential boundary condition must be applied.

FIGURE 2.2: Finite element solution of one-dimensional heat equation.

### 2.1.7 Solution

Solving these equations gives:  $U_2 = 0.2885$  and  $U_3 = 0.6098$ . From Equation (2.2) the exact solutions at these points are 0.2889 and 0.6102, respectively. The finite element solution is shown in Figure 2.2.

### 2.1.8 Fluxes

The fluxes at nodes 1 and 4 are evaluated by substituting the nodal solutions  $U_1 = 0$ ,  $U_2 = 0.2885$ ,  $U_3 = 0.6098$  and  $U_4 = 1$  into Equation (2.10)

$$\begin{aligned} \text{flux entering node 1} &= - \left( k \frac{du}{dx} \right) \Big|_{x=0} = -0.8496 \quad (k = 1; \text{exact solution } 0.8509) \\ \text{flux entering node 4} &= \left( k \frac{du}{dx} \right) \Big|_{x=1} = 1.3157 \quad (k = 1; \text{exact solution } 1.3131) \end{aligned}$$

These fluxes are shown in Figure 2.2 as heat entering node 4 and leaving node 1, consistent with heat flow down the temperature gradient.

## 2.2 An $x$ -Dependent Source Term

Consider the addition of a source term dependent on  $x$  in Equation (2.1):

$$-\frac{d}{dx} \left( k \frac{du}{dx} \right) + u - x = 0 \quad 0 < x < 1$$

Equation (2.6) now becomes

$$\int_0^1 \left( k \frac{du}{dx} \frac{d\omega}{dx} + u\omega \right) dx = \left[ k \frac{du}{dx} \omega \right]_0^1 + \int_0^1 x\omega dx \quad (2.11)$$

where the  $x$ -dependent source term appears on the RHS because it is not dependent on  $u$ . Replacing the domain integral for this source term by the sum of three element integrals

$$\int_0^1 x\omega dx = \int_0^{\frac{1}{3}} x\omega dx + \int_{\frac{1}{3}}^{\frac{2}{3}} x\omega dx + \int_{\frac{2}{3}}^1 x\omega dx$$

and putting  $x$  in terms of  $\xi$  gives (with  $\frac{dx}{d\xi} = \frac{1}{3}$  for all three elements)

$$\int_0^1 x\omega dx = \frac{1}{3} \int_0^1 \frac{\xi}{3} \omega d\xi + \frac{1}{3} \int_0^1 \frac{(1+\xi)}{3} \omega d\xi + \frac{1}{3} \int_0^1 \frac{(2+\xi)}{3} \omega d\xi \quad (2.12)$$

where  $\omega$  is chosen to be the appropriate basis function within each element. For example, the first term on the RHS of (2.12) corresponding to element 1 is  $\frac{1}{9} \int_0^1 \xi \varphi_m d\xi$ , where  $\varphi_1 = 1 - \xi$  and  $\varphi_2 = \xi$ . Evaluating these expressions,

$$\int_0^1 \frac{1}{9} \xi (1 - \xi) d\xi = \frac{1}{54}$$

and

$$\int_0^1 \frac{1}{9} \xi^2 d\xi = \frac{1}{27}$$

Thus, the contribution to the element 1 RHS vector from the source term is  $\begin{bmatrix} \frac{1}{54} \\ \frac{1}{27} \end{bmatrix}$ .

Similarly, for element 2,

$$\int_0^1 \frac{1}{9} (1 + \xi) (1 - \xi) d\xi = \frac{2}{27} \text{ and } \int_0^1 \frac{1}{9} (1 + \xi) \xi d\xi = \frac{5}{54} \text{ gives } \begin{bmatrix} \frac{2}{27} \\ \frac{5}{54} \end{bmatrix}$$

and for element 3,

$$\int_0^1 \frac{1}{9} (2 + \xi) (1 - \xi) d\xi = \frac{7}{54} \text{ and } \int_0^1 \frac{1}{9} (2 + \xi) \xi d\xi = \frac{5}{54} \text{ gives } \begin{bmatrix} \frac{7}{54} \\ \frac{5}{54} \end{bmatrix}$$

Assembling these into the global RHS vector, Equation (2.10) becomes

$$\begin{bmatrix} \frac{28}{9} & -\frac{53}{18} & 0 & 0 \\ -\frac{53}{18} & \frac{56}{9} & -\frac{53}{18} & 0 \\ 0 & -\frac{53}{18} & \frac{56}{9} & -\frac{53}{18} \\ 0 & 0 & -\frac{53}{18} & \frac{28}{9} \end{bmatrix} \begin{bmatrix} U_1 \\ U_2 \\ U_3 \\ U_4 \end{bmatrix} = \begin{bmatrix} -\left(k \frac{du}{dx}\right) \Big|_{x=0} \\ 0 \\ 0 \\ \left(k \frac{du}{dx}\right) \Big|_{x=1} \end{bmatrix} + \begin{bmatrix} \frac{1}{54} \\ \frac{1}{27} + \frac{2}{27} \\ \frac{5}{54} + \frac{7}{54} \\ \frac{5}{54} \end{bmatrix}$$

FIGURE 2.3: Showing how the Galerkin method maintains orthogonality between the residual vector  $\mathbf{r}$  and the set of basis vectors  $\varphi_i$  as  $i$  is increased from (a) 1 to (b) 2 to (c) 3.

## 2.3 The Galerkin Weight Function Revisited

A key idea in the Galerkin finite element method is the choice of weighting functions which are orthogonal to the equation residual (thought of here as the error or amount by which the equation fails to be exactly zero). This idea is illustrated in Figure 2.3.

In Figure 2.3a an exact vector  $\mathbf{u}_e$  (lying in 3D space) is approximated by a vector  $\mathbf{u} = u_1\varphi_1$  where  $\varphi_1$  is a basis vector along the first coordinate axis (representing one degree of freedom in the system). The difference between the exact vector  $\mathbf{u}_e$  and the approximate vector  $\mathbf{u}$  is the error or residual  $\mathbf{r} = \mathbf{u}_e - \mathbf{u}$  (shown by the broken line in Figure 2.3a). The Galerkin technique minimises this residual by making it orthogonal to  $\varphi_1$  and hence to the approximating vector  $\mathbf{u}$ . If a second degree of freedom (in the form of another coordinate axis in Figure 2.3b) is added, the approximating vector is  $\mathbf{u} = u_1\varphi_1 + u_2\varphi_2$  and the residual is now *also* made orthogonal to  $\varphi_2$  and hence to  $\mathbf{u}$ . Finally, in Figure 2.3c, a third degree of freedom (a third axis in Figure 2.3c) is permitted in the approximation  $\mathbf{u} = u_1\varphi_1 + u_2\varphi_2 + u_3\varphi_3$  with the result that the residual (now also orthogonal to  $\varphi_3$ ) is reduced to zero and  $\mathbf{u} = \mathbf{u}_e$ . For a 3D vector space we only need three axes or basis vectors to represent the true vector  $\mathbf{u}$ , but in the infinite dimensional vector space associated with a spatially continuous field  $u(x)$  we need to impose the equivalent orthogonality condition  $\left( \int R\varphi dx = 0 \right)$  for every basis function  $\varphi$  used in the approximate representation of  $u(x)$ . The key point is that in this analogy the residual is made orthogonal to the current set of basis vectors - or, equivalently, in finite element analysis, to the set of basis functions used to represent the dependent variable. This ensures that the error or residual is minimal (in a least-squares sense) for the current number of degrees of freedom and that as the number of degrees of freedom is increased (or the mesh refined) the error decreases monotonically.

## 2.4 Two and Three-Dimensional Steady-State Heat Conduction

Extending Equation (2.1) to two or three spatial dimensions introduces some additional complexity which we examine here. Consider the three-dimensional steady-state heat equation with no source terms:

$$-\frac{\partial}{\partial x} \left( k_x \frac{\partial u}{\partial x} \right) - \frac{\partial}{\partial y} \left( k_y \frac{\partial u}{\partial y} \right) - \frac{\partial}{\partial z} \left( k_z \frac{\partial u}{\partial z} \right) = 0$$

where  $k_x, k_y$  and  $k_z$  are the thermal diffusivities along the  $x, y$  and  $z$  axes respectively. If the material is assumed to be isotropic,  $k_x = k_y = k_z = k$ , and the above equation can be written as

$$-\nabla \cdot (k \nabla u) = 0 \quad (2.13)$$

and, if  $k$  is spatially constant (in the case of a homogeneous material), this reduces to Laplace's equation  $k \nabla^2 u = 0$ . Here we consider the solution of Equation (2.13) over the region  $\Omega$ , subject to boundary conditions on  $\Gamma$  (see Figure 2.4).

FIGURE 2.4: The region  $\Omega$  and the boundary  $\Gamma$ .

The weighted integral equation, corresponding to Equation (2.13), is

$$\int_{\Omega} -\nabla \cdot (k \nabla u) \omega \, d\Omega = 0 \quad (2.14)$$

The multi-dimensional equivalent of integration by parts is the Green-Gauss theorem:

$$\int_{\Omega} (f \nabla \cdot \nabla g + \nabla f \cdot \nabla g) \, d\Omega = \int_{\Gamma} f \frac{\partial g}{\partial n} \, d\Gamma \quad (2.15)$$

(see p553 in "Advanced Engineering Mathematics" by E. Kreysig, 7th edition, Wiley, 1993).

This is used (with  $f = \omega$ ,  $g = -ku$  and assuming that  $k$  is constant) to reduce the derivative order from two to one as follows:

$$\int_{\Omega} -\nabla \cdot (k \nabla u) \omega \, d\Omega = \int_{\Omega} k \nabla u \cdot \nabla \omega \, d\Omega - \int_{\Gamma} k \frac{\partial u}{\partial n} \omega \, d\Gamma \quad (2.16)$$

*cf.* Integration by parts is  $\int_x -\frac{d}{dx} \left( k \frac{du}{dx} \right) \omega \, dx = \int_x k \frac{du}{dx} \frac{d\omega}{dx} \, dx - \left[ k \frac{du}{dx} \omega \right]_{x_1}^{x_2}$ .

Using Equation (2.16) in Equation (2.14) gives the two-dimensional equivalent of Equation (2.6) (but with no source term):

$$\int_{\Omega} k \nabla u \cdot \nabla \omega \, d\Omega = \int_{\Gamma} k \frac{\partial u}{\partial n} \omega \, d\Gamma \quad (2.17)$$

subject to  $u$  being given on one part of the boundary and  $\frac{\partial u}{\partial n}$  being given on another part of the boundary.

The integrand on the LHS of (2.17) is evaluated using

$$\nabla u \cdot \nabla \omega = \frac{\partial u}{\partial x_k} \cdot \frac{\partial \omega}{\partial x_k} = \frac{\partial u}{\partial \xi_i} \frac{\partial \xi_i}{\partial x_k} \cdot \frac{\partial \omega}{\partial \xi_j} \frac{\partial \xi_j}{\partial x_k} \quad (2.18)$$

where  $u = \varphi_n u_n$  and  $\omega = \varphi_m$ , as before, and the geometric terms  $\frac{\partial \xi_i}{\partial x_k}$  are found from the inverse matrix

$$\left[ \frac{\partial \xi_i}{\partial x_k} \right] = \left[ \frac{\partial x_k}{\partial \xi_i} \right]^{-1}$$

or, for a two-dimensional element,

$$\begin{bmatrix} \frac{\partial \xi_1}{\partial x} & \frac{\partial \xi_1}{\partial y} \\ \frac{\partial \xi_2}{\partial x} & \frac{\partial \xi_2}{\partial y} \end{bmatrix} = \begin{bmatrix} \frac{\partial x}{\partial \xi_1} & \frac{\partial x}{\partial \xi_2} \\ \frac{\partial y}{\partial \xi_1} & \frac{\partial y}{\partial \xi_2} \end{bmatrix}^{-1} = \frac{1}{\frac{\partial x}{\partial \xi_1} \frac{\partial y}{\partial \xi_2} - \frac{\partial x}{\partial \xi_2} \frac{\partial y}{\partial \xi_1}} \begin{bmatrix} \frac{\partial y}{\partial \xi_2} & -\frac{\partial x}{\partial \xi_2} \\ -\frac{\partial y}{\partial \xi_1} & \frac{\partial x}{\partial \xi_1} \end{bmatrix}$$

## 2.5 Basis Functions - Element Discretisation

Let  $\Omega = \bigcup_{i=1}^I \Omega_i$ , i.e., the solution region is the union of the individual elements. In each  $\Omega_i$  let  $u = \varphi_n u_n = \varphi_1 u_1 + \varphi_2 u_2 + \dots + \varphi_N u_N$  and map each  $\Omega_i$  to the  $\xi_1, \xi_2$  plane. Figure 2.5 shows an example of this mapping.

FIGURE 2.5: Mapping each  $\Omega$  to the  $\xi_1, \xi_2$  plane in a  $2 \times 2$  element plane.

For each element, the basis functions and their derivatives are:

$$\varphi_1 = (1 - \xi_1)(1 - \xi_2) \quad \frac{\partial \varphi_1}{\partial \xi_1} = -(1 - \xi_2) \quad (2.19)$$

$$\frac{\partial \varphi_1}{\partial \xi_2} = -(1 - \xi_1) \quad (2.20)$$

$$(2.21)$$

$$\varphi_2 = \xi_1(1 - \xi_2) \quad \frac{\partial \varphi_2}{\partial \xi_1} = 1 - \xi_2 \quad (2.22)$$

$$\frac{\partial \varphi_2}{\partial \xi_2} = -\xi_1 \quad (2.23)$$

$$(2.24)$$

$$\varphi_3 = (1 - \xi_1)\xi_2 \quad \frac{\partial \varphi_3}{\partial \xi_1} = -\xi_2 \quad (2.25)$$

$$\frac{\partial \varphi_3}{\partial \xi_2} = 1 - \xi_1 \quad (2.26)$$

$$(2.27)$$

$$\varphi_4 = \xi_1 \xi_2 \quad \frac{\partial \varphi_4}{\partial \xi_1} = \xi_2 \quad (2.28)$$

$$\frac{\partial \varphi_4}{\partial \xi_2} = \xi_1 \quad (2.29)$$

## 2.6 Integration

The equation is

$$\int_{\Omega} k \nabla u \cdot \nabla \omega \, d\Omega = \int_{\Gamma} k \frac{\partial u}{\partial n} \omega \, d\Gamma \quad (2.30)$$

i.e.,

$$\int_{\Omega} k \left( \frac{\partial u}{\partial x} \frac{\partial \omega}{\partial x} + \frac{\partial u}{\partial y} \frac{\partial \omega}{\partial y} \right) d\Omega = \int_{\Gamma} k \frac{\partial u}{\partial n} \omega \, d\Gamma \quad (2.31)$$

$u$  has already been approximated by  $\varphi_n u_n$  and  $\omega$  is a weight function but what should this be chosen to be? For a *Galerkin* formulation choose  $\omega = \varphi_m$  i.e., weight function is one of the basis functions used to approximate the dependent variable.

This gives

$$\sum_i u_n \int_{\Omega} k \left( \frac{\partial \varphi_n}{\partial x} \frac{\partial \varphi_m}{\partial x} + \frac{\partial \varphi_n}{\partial y} \frac{\partial \varphi_m}{\partial y} \right) d\Omega = \int_{\Gamma} k \frac{\partial u}{\partial n} \varphi_m \, d\Gamma \quad (2.32)$$

where the stiffness matrix is  $E_{mn}$  where  $m = 1, \dots, 4$  and  $n = 1, \dots, 4$  and  $F_m$  is the (element) load vector.

The names originated from earlier finite element applications and extension of spring systems, i.e.,  $F = kx$  where  $k$  is the stiffness of spring and  $F$  is the force/load.

This yields the system of equations  $E_{mn} u_n = F_m$ . e.g., heat flow in a unit square (see Figure 2.6).

FIGURE 2.6: Considering heat flow in a unit square.

The first component  $E_{11}$  is calculated as

$$\begin{aligned} E_{11} &= k \int_0^1 \int_0^1 (1-y)^2 + (1-x)^2 \, dx dy \\ &= \frac{2}{3} k \end{aligned}$$

and similarly for the other components of the matrix.

Note that if the element was not the unit square we would need to transform from  $(x, y)$  to  $(\xi_1, \xi_2)$  coordinates. In this case we would have to include the Jacobian of the transformation and also use the chain rule to calculate  $\frac{\partial \varphi_i}{\partial x_j}$ . e.g.,  $\frac{\partial \varphi_n}{\partial x} = \frac{\partial \varphi_n}{\partial \xi_1} \frac{\partial \xi_1}{\partial x} + \frac{\partial \varphi_n}{\partial \xi_2} \frac{\partial \xi_2}{\partial x} = \frac{\partial \varphi_n}{\partial \xi_i} \frac{\partial \xi_i}{\partial x}$ .

The system of  $E_{mn} u_n = F_m$  becomes

$$k \begin{bmatrix} \frac{2}{3} & -\frac{1}{6} & -\frac{1}{6} & -\frac{1}{3} \\ -\frac{1}{6} & \frac{2}{3} & -\frac{1}{6} & -\frac{1}{3} \\ -\frac{1}{6} & -\frac{1}{6} & \frac{2}{3} & -\frac{1}{3} \\ -\frac{1}{3} & -\frac{1}{6} & -\frac{1}{6} & \frac{2}{3} \end{bmatrix} \begin{bmatrix} u_1 \\ u_2 \\ u_3 \\ u_4 \end{bmatrix} = RHS \quad (\text{Right Hand Side}) \quad (2.33)$$



Note that the Galerkin formulation generates a symmetric stiffness matrix (this is true for self adjoint operators which are the most common).

Given that boundary conditions can be applied and it is possible to solve for unknown nodal temperatures or fluxes. However, typically there is more than one element and so the next step is required.

## 2.7 Assemble Global Equations

Each element stiffness matrix must be assembled into a global stiffness matrix. For example, consider 4 elements (each of unit size) and nine nodes. Each element has the same element stiffness matrix as that given above. This is because each element is the same size, shape and interpolation.

FIGURE 2.7: Assembling 4 unit sized elements into a global stiffness matrix.

$$\begin{bmatrix} \frac{2}{3} & -\frac{1}{6} & & -\frac{1}{6} & & -\frac{1}{3} & & & \\ -\frac{1}{6} & \frac{2}{3} + \frac{2}{3} & -\frac{1}{6} & & -\frac{1}{6} & -\frac{1}{3} & & & \\ & -\frac{1}{6} & \frac{2}{3} & & -\frac{1}{6} & -\frac{1}{3} & & & \\ -\frac{1}{6} & -\frac{1}{6} & -\frac{1}{6} & \frac{2}{3} + \frac{2}{3} & -\frac{1}{6} & -\frac{1}{3} & & & \\ -\frac{1}{3} & -\frac{1}{6} & -\frac{1}{6} & -\frac{1}{6} & \frac{2}{3} + \frac{2}{3} & -\frac{1}{3} & & & \\ & & -\frac{1}{6} & -\frac{1}{6} & -\frac{1}{6} & -\frac{1}{3} & & & \\ & & & \frac{2}{3} + \frac{2}{3} & -\frac{1}{6} & -\frac{1}{3} & & & \\ & & & -\frac{1}{6} & -\frac{1}{6} & -\frac{1}{6} & \frac{2}{3} + \frac{2}{3} & & \\ & & & & -\frac{1}{6} & -\frac{1}{6} & -\frac{1}{6} & \frac{2}{3} + \frac{2}{3} & \\ & & & & & -\frac{1}{6} & -\frac{1}{6} & -\frac{1}{6} & \frac{2}{3} + \frac{2}{3} \end{bmatrix} \begin{bmatrix} U_1 \\ U_2 \\ U_3 \\ U_4 \\ U_5 \\ U_6 \\ U_7 \\ U_8 \\ U_9 \end{bmatrix} = RHS \quad (2.34)$$

This yields the system of equations

$$\begin{bmatrix} \frac{2}{3} & -\frac{1}{6} & & -\frac{1}{6} & & -\frac{1}{3} & & & \\ -\frac{1}{6} & \frac{4}{3} & -\frac{1}{6} & & -\frac{1}{6} & -\frac{1}{3} & & & \\ & -\frac{1}{6} & \frac{4}{3} & & -\frac{1}{6} & -\frac{1}{3} & & & \\ -\frac{1}{6} & -\frac{1}{6} & -\frac{1}{6} & \frac{4}{3} & -\frac{1}{6} & -\frac{1}{3} & & & \\ -\frac{1}{3} & -\frac{1}{6} & -\frac{1}{6} & -\frac{1}{6} & \frac{4}{3} & -\frac{1}{3} & & & \\ & & -\frac{1}{6} & -\frac{1}{6} & -\frac{1}{6} & -\frac{1}{3} & & & \\ & & & \frac{4}{3} & -\frac{1}{6} & -\frac{1}{3} & & & \\ & & & -\frac{1}{6} & -\frac{1}{6} & -\frac{1}{6} & \frac{4}{3} & & \\ & & & & -\frac{1}{6} & -\frac{1}{6} & -\frac{1}{6} & \frac{4}{3} & \\ & & & & & -\frac{1}{6} & -\frac{1}{6} & -\frac{1}{6} & \frac{4}{3} \end{bmatrix} \begin{bmatrix} U_1 \\ U_2 \\ U_3 \\ U_4 \\ U_5 \\ U_6 \\ U_7 \\ U_8 \\ U_9 \end{bmatrix} = RHS$$

Note that the matrix is symmetric. It should also be clear that the matrix will be sparse (i.e. contains many zeros) if there is a large number of elements.

From this system of equations, boundary conditions can be applied and the equations solved. To solve, firstly boundary conditions are applied to reduce the size of the system.

If at global node  $i$ ,  $U_i$  is known, we can remove the  $i^{\text{th}}$  equation and replace it with the known value of  $U_i$ . This is because the RHS at node  $i$  is unknown, but the RHS equation is uncoupled from

other equations so these equation can be removed. Therefore the size of the system is reduced. The final system to solve is only as big as the number of unknown values of  $U$ .

As an example to illustrate this consider fixing the temperature ( $U$ ) at the left and right sides of the plate in Figure 2.7 and insulating the top (node 8) and the bottom (node 2). This means that there are only 3 unknown values of  $U$  at nodes (2,5 and 8), therefore there is a  $3 \times 3$  matrix to solve. The RHS is known at these three nodes (see below). We can then solve the  $3 \times 3$  matrix and then multiply out the original matrix to find the unknown RHS values.

The RHS is 0 at nodes 2 and 8 because it is insulated. To find out what the RHS is at node 5 we need to examine the RHS expression  $\int_{\Gamma} \frac{\partial u}{\partial n} \omega d\Gamma = 0$  at node 5. This is zero as flux is always 0 at internal nodes. This can be explained in two ways.

FIGURE 2.8: “Cancelling” of flux in internal nodes.

**Correct way:**  $\Gamma$  does not pass through node 5 and each basis function that is not zero at 5 is zero on  $\Gamma$

**Other way:**  $\frac{\partial u}{\partial n}$  is opposite in neighbouring elements so it cancels (see Figure 2.8).

## 2.8 Gaussian Quadrature

The element integrals arising from two- or three-dimensional problems can seldom be evaluated analytically. Numerical integration or *quadrature* is therefore required and the most efficient scheme for integrating the expressions that arise in the finite element method is Gauss-Legendre quadrature.

Consider first the problem of integrating  $f(\xi)$  between the limits 0 and 1 by the sum of weighted samples of  $f(\xi)$  taken at points  $\xi_1, \xi_2, \dots, \xi_I$  (see Figure 2.3):

$$\int_0^1 f(\xi) d\xi = \sum_{i=1}^I W_i f(\xi_i) + E$$

Here  $W_i$  are the weights associated with sample points  $\xi_i$  - called *Gauss points* - and  $E$  is the error in the approximation of the integral. We now choose the Gauss points and weights to exactly integrate a polynomial of degree  $2I - 1$  (since a general polynomial of degree  $2I - 1$  has  $2I$  arbitrary coefficients and there are  $2I$  unknown Gauss points and weights).

For example, with  $I = 2$  we can exactly integrate a polynomial of degree 3:

$$\text{Let } \int_0^1 f(\xi) d\xi = W_1 f(\xi_1) + W_2 f(\xi_2)$$

FIGURE 2.9: Gaussian quadrature.  $f(\xi)$  is sampled at  $I$  Gauss points  $\xi_1, \xi_2 \dots \xi_I$ .

and choose  $f(\xi) = a + b\xi + c\xi^2 + d\xi^3$ . Then

$$\int_0^1 f(\xi) d\xi = a \int_0^1 d\xi + b \int_0^1 \xi d\xi + c \int_0^1 \xi^2 d\xi + d \int_0^1 \xi^3 d\xi \quad (2.35)$$

Since  $a$ ,  $b$ ,  $c$  and  $d$  are arbitrary coefficients, each integral on the RHS of 2.35 must be integrated exactly. Thus,

$$\int_0^1 d\xi = 1 = W_1 \cdot 1 + W_2 \cdot 1 \quad (2.36)$$

$$\int_0^1 \xi d\xi = \frac{1}{2} = W_1 \cdot \xi_1 + W_2 \cdot \xi_2 \quad (2.37)$$

$$\int_0^1 \xi^2 d\xi = \frac{1}{3} = W_1 \cdot \xi_1^2 + W_2 \cdot \xi_2^2 \quad (2.38)$$

$$\int_0^1 \xi^3 d\xi = \frac{1}{4} = W_1 \cdot \xi_1^3 + W_2 \cdot \xi_2^3 \quad (2.39)$$

These four equations yield the solution for the two Gauss points and weights as follows:  
From symmetry and Equation (2.36),

$$W_1 = W_2 = \frac{1}{2}.$$

Then, from (2.37),

$$\xi_2 = 1 - \xi_1$$

and, substituting in (2.38),

$$\xi_1^2 + (1 - \xi_1)^2 = \frac{2}{3}$$

$$2\xi_1^2 - 2\xi_1 + \frac{1}{3} = 0,$$

giving

$$\xi_1 = \frac{1}{2} \pm \frac{1}{2\sqrt{3}}.$$

Equation (2.39) is satisfied identically. Thus, the two Gauss points are given by

$$\begin{aligned}\xi_1 &= \frac{1}{2} - \frac{1}{2\sqrt{3}}, \\ \xi_2 &= \frac{1}{2} + \frac{1}{2\sqrt{3}}, \\ W_1 &= W_2 = \frac{1}{2}\end{aligned}\tag{2.40}$$

A similar calculation for a 5<sup>th</sup> degree polynomial using three Gauss points gives

$$\begin{aligned}\xi_1 &= \frac{1}{2} - \frac{1}{2}\sqrt{\frac{3}{5}}, & W_1 &= \frac{5}{18} \\ \xi_2 &= \frac{1}{2}, & W_2 &= \frac{4}{9} \\ \xi_3 &= \frac{1}{2} + \frac{1}{2}\sqrt{\frac{3}{5}}, & W_3 &= \frac{5}{18}\end{aligned}\tag{2.41}$$

For two- or three-dimensional Gaussian quadrature the Gauss point positions are simply the values given above along each  $\xi_i$ -coordinate with the weights scaled to sum to 1 *e.g.*, for 2x2 Gauss quadrature the 4 weights are all  $\frac{1}{4}$ . The number of Gauss points chosen for each  $\xi_i$ -direction is governed by the complexity of the integrand in the element integral (2.8). In general two- and three-dimensional problems the integral is not polynomial (owing to the  $\frac{\partial \xi_i}{\partial x_j}$  terms which come from the

inverse of the matrix  $\left[ \frac{\partial x_i}{\partial \xi_j} \right]$ ) and no attempt is made to achieve exact integration. The quadrature error must be balanced against the discretization error. For example, if the two-dimensional basis is cubic in the  $\xi_1$ -direction and linear in the  $\xi_2$ -direction, three Gauss points would be used in the  $\xi_1$ -direction and two in the  $\xi_2$ -direction.

## 2.9 CMISS Examples

1. To solve for the steady state temperature distribution inside a plate run CMISS example 311
2. To solve for the steady state temperature distribution inside an annulus run CMISS example 312
3. To investigate the convergence of the steady state temperature distribution with mesh refinement run CMISS examples 3141, 3142, 3143 and 3144.

# Chapter 3

## The Boundary Element Method

### 3.1 Introduction

Having developed the basic ideas behind the finite element method, we now develop the basic ideas of the boundary element method. There are several key differences between these two methods, one of which involves the choice of weighting function (recall the Galerkin finite element method used as a weighting function one of the basis functions used to approximate the solution variable). Before launching into the boundary element method we must briefly develop some ideas that are central to the weighting function used in the boundary element method.

### 3.2 The Dirac-Delta Function and Fundamental Solutions

Before one applies the boundary element method to a particular problem one must obtain a *fundamental solution* (which is similar to the idea of a particular solution in ordinary differential equations and is the weighting function). Fundamental solutions are tied to the Dirac<sup>1</sup> Delta function and we deal with both here.

#### 3.2.1 Dirac-Delta function

What we do here is very non-rigorous. To gain an intuitive feel for this unusual function, consider the following sequence of force distributions applied to a large plate as shown in Figure 3.1

$$w_n(x) = \begin{cases} \frac{n}{2} & |x| < \frac{1}{n} \\ 0 & |x| > \frac{1}{n} \end{cases}$$

---

<sup>1</sup>Paul A.M. Dirac (1902-1994) was awarded the Nobel Prize (with Erwin Schrodinger) in 1933 for his work in quantum mechanics. Dirac introduced the idea of the “Dirac Delta” intuitively, as we will do here, around 1926-27. It was rigorously defined as a so-called generalised function by Schwartz in 1950-51, and strictly speaking we should talk about the “Dirac Delta Distribution”.

Each has the property that

$$\int_{-\infty}^{\infty} w_n(x) dx = 1 \quad (\text{i.e., the total force applied is unity})$$

but as  $n$  increases the area of force application decreases and the force/unit area increases.

FIGURE 3.1: Illustrations of unit force distributions  $w_n$ .

As  $n$  gets larger we can easily see that the area of application of the force becomes smaller and smaller, the magnitude of the force increases but the total force applied remains unity. If we imagine letting  $n \rightarrow \infty$  we obtain an idealised “point” force of unit strength, given the symbol  $\delta(x)$ , acting at  $x = 0$ . Thus, in a nonrigorous sense we have

$$\delta(x) = \lim_{n \rightarrow \infty} w_n(x) \quad \text{the Dirac Delta “function”}.$$

This is not a function that we are used to dealing with because we have  $\delta(x) = 0$  if  $x \neq 0$  and “ $\delta(0) = \infty$ ” i.e., the “function” is zero everywhere except at the origin, where it is infinite.

However, we have  $\int_{-\infty}^{\infty} \delta(x) dx = 1$  since each  $\int_{-\infty}^{\infty} w_n(x) dx = 1$ .

The Dirac delta “function” is not a function in the usual sense, and it is more correctly referred to as the Dirac delta distribution. It also has the property that for any continuous function  $h(x)$

$$\int_{-\infty}^{\infty} \delta(x) h(x) dx = h(0) \quad (3.1)$$

A rough proof of this is as follows

$$\begin{aligned} \int_{-\infty}^{\infty} \delta(x) h(x) dx &= \lim_{n \rightarrow \infty} \int_{-\infty}^{\infty} w_n(x) h(x) dx && \text{by definition of } \delta(x) \\ &= \lim_{n \rightarrow \infty} \frac{n}{2} \int_{-\frac{1}{n}}^{\frac{1}{n}} h(x) dx && \text{by definition of } w_n(x) \\ &= \lim_{n \rightarrow \infty} \frac{n}{2} h(\xi) \frac{2}{n} && \text{by the Mean Value Theorem, where } \xi \in \left(-\frac{1}{n}, \frac{1}{n}\right) \\ &= h(0) && \text{since } \xi \in \left(-\frac{1}{n}, \frac{1}{n}\right) \text{ and as } n \rightarrow \infty, \xi \rightarrow 0 \end{aligned}$$

The above result (Equation (3.1)) is often used as the defining property of the Dirac delta in more rigorous derivations. One does not usually talk about the values of the Dirac delta at a particular point, but rather its integral behaviour. Some properties of the Dirac delta are listed

below

$$\int_{-\infty}^{\infty} \delta(\xi - x) h(x) dx = h(\xi) \quad (3.2)$$

(Note:  $\delta(\xi - x)$  is the Dirac delta distribution centred at  $x = \xi$  instead of  $x = 0$ )

$$\delta(\xi - x) = H'(\xi - t) \quad (3.3)$$

where  $H(\xi - t) = \begin{cases} 0 & \text{if } \xi < t \\ 1 & \text{if } \xi > t \end{cases}$  (*i.e.*, the Dirac Delta function is the slope of the Heaviside<sup>2</sup> step function.)

$$\delta(\xi - x, \eta - y) = \delta(\xi - x) \delta(\eta - y) \quad (3.4)$$

(*i.e.*, the two dimensional Dirac delta is just a product of two one-dimensional Dirac deltas.)

### 3.2.2 Fundamental solutions

We develop here the fundamental solution (also called the freespace Green's<sup>3</sup> function) for Laplace's Equation in two variables. The fundamental solution of a particular equation is the weighting function that is used in the boundary element formulation of that equation. It is therefore important to be able to find the fundamental solution for a particular equation. Most of the common equations have well-known fundamental solutions (see Appendix 3.16). We briefly illustrate here how to find a simple fundamental solution.

Consider solving the Laplace Equation  $\frac{\partial^2 u}{\partial x^2} + \frac{\partial^2 u}{\partial y^2} = 0$  in some domain  $\Omega \in \mathbb{R}^2$ .

The fundamental solution for this equation (analogous to a particular solution in ODE work) is a solution of

$$\frac{\partial^2 \omega}{\partial x^2} + \frac{\partial^2 \omega}{\partial y^2} + \delta(\xi - x, \eta - y) = 0 \quad (3.5)$$

in  $\mathbb{R}^2$  (*i.e.*, we solve the above without reference to the original domain  $\Omega$  or original boundary conditions). The method is to try and find solution to  $\nabla^2 \omega = 0$  in  $\mathbb{R}^2$  which contains a singularity at the point  $(\xi, \eta)$ . This is not as difficult as it sounds. We expect the solution to be symmetric about the point  $(\xi, \eta)$  since  $\delta(\xi - x, \eta - y)$  is symmetric about this point. So we adopt a local polar coordinate system about the *singular point*  $(\xi, \eta)$ .

Let

$$r = \sqrt{(\xi - x)^2 + (\eta - y)^2}$$

Then, from Section 1.8 we have

$$\nabla^2 \omega = \frac{1}{r} \frac{\partial}{\partial r} \left( r \frac{\partial \omega}{\partial r} \right) + \frac{1}{r^2} \frac{\partial^2 \omega}{\partial \theta^2} \quad (3.6)$$

<sup>2</sup>Oliver Heaviside (1850-1925) was a British physicist, who pioneered the mathematical study of electrical circuits and helped develop vector analysis.

<sup>3</sup>George Green (1793-1841) was a self-educated miller's son. Most widely known for his integral theorem (the Green-Gauss theorem).

For  $r > 0$ ,  $\delta(\xi - x, \eta - y) = 0$  and owing to symmetry,  $\frac{\partial^2 \omega}{\partial \theta^2}$  is zero. Thus Equation (3.6) becomes

$$\frac{1}{r} \frac{\partial}{\partial r} \left( r \frac{\partial \omega}{\partial r} \right) = 0$$

This can be solved by straight (one-dimensional) integration. The solution is

$$\omega = A \log r + B \quad (3.7)$$

Note that this function is singular at  $r = 0$  as required.

To find  $A$  and  $B$  we make use of the integral property of the Delta function. From Equation (3.5) we must have

$$\int_D \nabla^2 \omega \, dD = - \int_D \delta \, dD = -1 \quad (3.8)$$

where  $D$  is any domain containing  $r = 0$ .

FIGURE 3.2: Domain used to evaluate fundamental solution coefficients.

We choose a simple domain to allow us to evaluate the above integrals. If  $D$  is a small disk of radius  $\varepsilon > 0$  centred at  $r = 0$  (Figure 3.2) then from the Green-Gauss theorem

$$\begin{aligned} \int_D \nabla^2 \omega \, dD &= \int_{\partial D} \frac{\partial \omega}{\partial n} \, dS && \partial D \text{ is the surface of the disk } D \\ &= \int_{\partial D} \frac{\partial \omega}{\partial r} \, dS && \text{since } D \text{ is a disk centred at } r = 0 \text{ so } n \text{ and } r \text{ are in the same direction} \\ &= \frac{A}{\varepsilon} 2\pi\varepsilon && \text{from Equation (3.7), and the fact that } D \text{ is a disc of radius } \varepsilon \\ &= 2\pi A \end{aligned}$$

Therefore, from Equation (3.8)

$$A = -\frac{1}{2\pi}.$$

So we have

$$\omega = -\frac{1}{2\pi} \log r + B$$

$B$  remains arbitrary but usually put equal to zero, so that the fundamental solution for the two-dimensional Laplace Equation is

$$\omega = -\frac{1}{2\pi} \log r \quad \left( = \frac{1}{2\pi} \log \frac{1}{r} \right) \quad (3.9)$$

where  $r = \sqrt{(\xi - x)^2 + (\eta - y)^2}$  (singular at the point  $(\xi, \eta)$ ).



The fundamental solution for the three-dimensional Laplace Equation can be found by a similar technique. The result is

$$\omega = \frac{1}{4\pi r}$$

where  $r$  is now a distance measured in three-dimensions.

### 3.3 The Two-Dimensional Boundary Element Method

We are now at a point where we can develop the boundary element method for the solution of  $\nabla^2 u = 0$  in a two-dimensional domain  $\Omega$ . The basic steps are in fact quite similar to those used for the finite element method (refer Section 2.1). We firstly must form an integral equation from the Laplace Equation by using a weighted integral equation and then use the Green-Gauss theorem. From Section 2.4 we have seen that

$$0 = \int_{\Omega} \nabla^2 u \cdot \omega \, d\Omega = \int_{\partial\Omega} \frac{\partial u}{\partial n} \omega \, d\Gamma - \int_{\Omega} \nabla u \cdot \nabla \omega \, d\Omega \quad (3.10)$$

This was the starting point for the finite element method. To derive the starting equation for the boundary element method we use the Green-Gauss theorem again on the second integral. This gives

$$\begin{aligned} 0 &= \int_{\partial\Omega} \frac{\partial u}{\partial n} \omega \, d\Gamma - \int_{\Omega} \nabla u \cdot \nabla \omega \, d\Omega \\ &= \int_{\partial\Omega} \frac{\partial u}{\partial n} \omega \, d\Gamma - \int_{\partial\Omega} u \frac{\partial \omega}{\partial n} \, d\Gamma + \int_{\Omega} u \nabla^2 \omega \, d\Omega \end{aligned} \quad (3.11)$$

For the Galerkin FEM we chose  $\omega$ , the weighting function, to be  $\varphi_m$ , one of the basis functions used to approximate  $u$ . For the boundary element method we choose  $\omega$  to be the fundamental solution of Laplace's Equation derived in the previous section *i.e.*,

$$\omega = -\frac{1}{2\pi} \log r$$

where  $r = \sqrt{(\xi - x)^2 + (\eta - y)^2}$  (singular at the point  $(\xi, \eta) \in \Omega$ ).

Then from Equation (3.11), using the property of the Dirac delta

$$\int_{\Omega} u \nabla^2 \omega \, d\Omega = - \int_{\Omega} u \delta(\xi - x, \eta - y) \, d\Omega = -u(\xi, \eta) \quad (\xi, \eta) \in \Omega \quad (3.12)$$

*i.e.*, the domain integral has been replaced by a point value.

Thus Equation (3.11) becomes

$$u(\xi, \eta) + \int_{\partial\Omega} u \frac{\partial\omega}{\partial n} d\Gamma = \int_{\partial\Omega} \frac{\partial u}{\partial n} \omega d\Gamma \quad (\xi, \eta) \in \Omega \quad (3.13)$$

This equation contains only boundary integrals (and no domain integrals as in Finite Elements) and is referred to as a boundary integral equation. It relates the value of  $u$  at some point inside the solution domain to integral expressions involving  $u$  and  $\frac{\partial u}{\partial n}$  over the boundary of the solution domain. Rather than having an expression relating the value of  $u$  at some point inside the domain to boundary integrals, a more useful expression would be one relating the value of  $u$  at some point *on the boundary* to boundary integrals. We derive such an expression below.

The previous equation (Equation (3.13)) holds if  $(\xi, \eta) \in \Omega$  (*i.e.*, the singularity of Dirac Delta function is inside the domain). If  $(\xi, \eta)$  is outside  $\Omega$  then

$$\int_{\Omega} u \nabla^2 \omega d\Omega = - \int_{\Omega} u \delta(\xi - x, \eta - y) d\Omega = 0$$

since the integrand of the second integral is zero at every point except  $(\xi, \eta)$  and this point is outside the region of integration. The case which needs special consideration is when the singular point  $(\xi, \eta)$  is on the boundary of the domain  $\Omega$ . This case also happens to be the most important for numerical work as we shall see. The integral expression we will ultimately obtain is simply Equation (3.13) with  $u(\xi, \eta)$  replaced by  $\frac{1}{2}u(\xi, \eta)$ . We can see this in a non-rigorous way as follows. When  $(\xi, \eta)$  was inside the domain, we integrated around the entire singularity of the Dirac Delta to get  $u(\xi, \eta)$  in Equation (3.13). When  $(\xi, \eta)$  is on the boundary we only have half of the singularity contained inside the domain, so we integrate around one-half of the singularity to get  $\frac{1}{2}u(\xi, \eta)$ . Rigorous details of where this coefficient  $\frac{1}{2}$  comes from are given below.

Let  $P$  denote the point  $(\xi, \eta) \in \Omega$ . In order to be able to evaluate  $\int_{\Omega} u \nabla^2 \omega d\Omega$  in this case we enlarge  $\Omega$  to include a disk of radius  $\varepsilon$  about  $P$  (Figure 3.3). We call this enlarged region  $\Omega'$  and let  $\Gamma' = \Gamma_{-\varepsilon} \cup \Gamma_{\varepsilon}$ .

FIGURE 3.3: Illustration of enlarged domain when singular point is on the boundary.

Now, since  $P$  is inside the enlarged region  $\Omega'$ , Equation (3.13) holds for this enlarged domain *i.e.*,

$$u(P) + \int_{\Gamma_{-\varepsilon} \cup \Gamma_{\varepsilon}} u \frac{\partial\omega}{\partial n} d\Gamma = \int_{\Gamma_{-\varepsilon} \cup \Gamma_{\varepsilon}} \frac{\partial u}{\partial n} \omega d\Gamma \quad (3.14)$$

We must now investigate this equation as  $\lim_{\varepsilon \downarrow 0}$ . There are 4 integrals to consider, and we look at each of these in turn.

Firstly consider

$$\begin{aligned}
 \int_{\Gamma_\varepsilon} u \frac{\partial \omega}{\partial n} d\Gamma &= \int_{\Gamma_\varepsilon} u \frac{\partial}{\partial n} \left( -\frac{1}{2\pi} \log r \right) d\Gamma && \text{by definition of } \omega \\
 &= \int_{\Gamma_\varepsilon} u \frac{\partial}{\partial r} \left( -\frac{1}{2\pi} \log r \right) d\Gamma && \text{since } \frac{\partial}{\partial n} \equiv \frac{\partial}{\partial r} \text{ on } \Gamma_\varepsilon \\
 &= -\frac{1}{2\pi} \int_{\Gamma_\varepsilon} \frac{u}{r} d\Gamma \\
 &= -\frac{1}{2\pi} \frac{1}{\varepsilon} \int_{\Gamma_\varepsilon} u d\Gamma && \text{since } r = \varepsilon \text{ on } \Gamma_\varepsilon \\
 &\rightarrow -\frac{1}{2\pi} \frac{1}{\varepsilon} u(P) \pi \varepsilon
 \end{aligned}$$

by the mean value theorem for a surface with a unique tangent at  $P$ .

Thus

$$\lim_{\varepsilon \downarrow 0} \int_{\Gamma_\varepsilon} u \frac{\partial \omega}{\partial n} d\Gamma = \lim_{\varepsilon \downarrow 0} \left( -\frac{1}{2\pi} \frac{u(P)}{\varepsilon} \pi \varepsilon \right) = -\frac{u(P)}{2} \quad (3.15)$$

By a similar process we obtain

$$\lim_{\varepsilon \downarrow 0} \int_{\Gamma_\varepsilon} \omega \frac{\partial u}{\partial n} d\Gamma = \lim_{\varepsilon \downarrow 0} \left( -\frac{1}{2\pi} \frac{\partial u}{\partial n}(P) \pi \varepsilon \log \varepsilon \right) = 0 \quad (3.16)$$

since  $\lim_{\varepsilon \log \varepsilon \downarrow 0}$  as  $\lim_{\varepsilon \downarrow 0}$ .

It only remains to consider the integrand over  $\Gamma_{-\varepsilon}$ . For “nice” integrals (which includes the integrals we are dealing with here) we have

$$\lim_{\varepsilon \downarrow 0} \left( \int_{\Gamma_{-\varepsilon}} (\text{nice integrand}) d\Gamma \right) = \int_{\Gamma} (\text{nice integrand}) d\Gamma$$

since  $\Gamma_{-\varepsilon} \rightarrow \Gamma$  as  $\lim_{\varepsilon \downarrow 0}$ .

**Note:** If the integrand is too badly behaved we cannot always replace  $\Gamma_{-\varepsilon}$  by  $\Gamma$  in the limit and one must deal with Cauchy Principal Values. (refer Section 5.8)

Thus we have

$$\lim_{\varepsilon \rightarrow 0} \left( \int_{\Gamma_{-\varepsilon}} \frac{\partial u}{\partial n} \omega \, d\Gamma \right) = \int_{\Gamma} \frac{\partial u}{\partial n} \omega \, d\Gamma \quad (3.17)$$

$$\lim_{\varepsilon \rightarrow 0} \left( \int_{\Gamma_{-\varepsilon}} \frac{\partial \omega}{\partial n} u \, d\Gamma \right) = \int_{\Gamma} \frac{\partial \omega}{\partial n} u \, d\Gamma \quad (3.18)$$

Combining Equations (3.14)–(3.18) we get

$$u(P) + \int_{\Gamma} u \frac{\partial \omega}{\partial n} \, d\Gamma = \frac{1}{2} u(P) + \int_{\Gamma} \frac{\partial u}{\partial n} \omega \, d\Gamma$$

or

$$\frac{1}{2} u(P) + \int_{\Gamma} u \frac{\partial \omega}{\partial n} \, d\Gamma = \int_{\Gamma} \frac{\partial u}{\partial n} \omega \, d\Gamma$$

where  $P = (\xi, \eta) \in \partial\Omega$  (i.e., singular point is on the boundary of the region).

**Note:** The above is true if the point  $P$  is at a smooth point (i.e., a point with a unique tangent) on the boundary of  $\Omega$ . If  $P$  happens to lie at some nonsmooth point e.g. a corner, then the coefficient  $\frac{1}{2}$  is replaced by  $\frac{\alpha}{2\pi}$  where  $\alpha$  is the internal angle at  $P$  (Figure 3.4).

FIGURE 3.4: Illustration of internal angle  $\alpha$ .

Thus we get the boundary integral equation.

$$c(P) u(P) + \int_{\Gamma} u \frac{\partial \omega}{\partial n} \, d\Gamma = \int_{\Gamma} \frac{\partial u}{\partial n} \omega \, d\Gamma \quad (3.19)$$

where

$$\begin{aligned} \omega &= -\frac{1}{2\pi} \log r \\ r &= \sqrt{(\xi - x)^2 + (\eta - y)^2} \\ c(P) &= \begin{cases} 1 & \text{if } P \in \Omega \\ \frac{1}{2} & \text{if } P \in \Gamma \text{ and } \Gamma \text{ smooth at } P \\ \frac{\text{internal angle}}{2\pi} & \text{if } P \in \Gamma \text{ and } \Gamma \text{ not smooth at } P \end{cases} \end{aligned}$$

For three-dimensional problems, the boundary integral equation expression above is the same,

with

$$\begin{aligned}\omega &= \frac{1}{4\pi r} \\ r &= \sqrt{(\xi - x)^2 + (\eta - y)^2 + (\gamma - z)^2} \\ c(P) &= \begin{cases} 1 & \text{if } P \in \Omega \\ \frac{1}{2} & \text{if } P \in \Gamma \text{ and } \Gamma \text{ smooth at } P \\ \frac{\text{inner solid angle}}{4\pi} & \text{if } P \in \Gamma \text{ and } \Gamma \text{ not smooth at } P \end{cases}\end{aligned}$$

Equation (3.19) involves only the surface distributions of  $u$  and  $\frac{\partial u}{\partial n}$  and the value of  $u$  at a point  $P$ . Once the surface distributions of  $u$  and  $\frac{\partial u}{\partial n}$  are known, the value of  $u$  at any point  $P$  inside  $\Omega$  can be found since all surface integrals in Equation (3.19) are then known. The procedure is thus to use Equation (3.19) to find the surface distributions of  $u$  and  $\frac{\partial u}{\partial n}$  and then (if required) use Equation (3.19) to find the solution at any point  $P \in \Omega$ . Thus we solve for the boundary data first, and find the volume data as a separate step.

Since Equation (3.19) only involves surface integrals, as opposed to volume integrals in a finite element formulation, the overall size of the problem has been reduced by one dimension (from volumes to surfaces). This can result in huge savings for problems with large volume to surface ratios (*i.e.*, problems with large domains). Also the effort required to produce a volume mesh of a complex three-dimensional object is far greater than that required to produce a mesh of the surface. Thus the boundary element method offers some distinct advantages over the finite element method in certain situations. It also has some disadvantages when compared to the finite element method and these will be discussed in Section 3.6. We now turn our attention to solving the boundary integral equation given in Equation (3.19).

### 3.4 Numerical Solution Procedures for the Boundary Integral Equation

The first step is to discretise the surface  $\Gamma$  into some set of elements (hence the name boundary elements).

$$\Gamma = \bigcup_{j=1}^N \Gamma_j \quad (3.20)$$

FIGURE 3.5: Schematic illustration of a boundary element mesh (a) and a finite element mesh (b).

Then Equation (3.19) becomes

$$c(P)u(P) + \sum_{j=1}^N \int_{\Gamma_j} u \frac{\partial \omega}{\partial n} d\Gamma = \sum_{j=1}^N \int_{\Gamma_j} \frac{\partial u}{\partial n} \omega d\Gamma \quad (3.21)$$

Over each element  $\Gamma_j$  we introduce standard (finite element) basis functions

$$u_j = \sum_{\alpha} \varphi_{\alpha} u_{j\alpha} \quad \text{and} \quad q_j \equiv \frac{\partial u_j}{\partial n} = \sum_{\alpha} \varphi_{\alpha} q_{j\alpha} \quad (3.22)$$

where  $u_j, q_j$  are values of  $u$  and  $q$  on element  $\Gamma_j$  and  $u_{j\alpha}, q_{j\alpha}$  are values of  $u$  and  $q$  at node  $\alpha$  on element  $\Gamma_j$ .

These basis functions for  $u$  and  $q$  can be any of the standard one-dimensional finite element basis functions (although we are dealing with a two-dimensional problem, we only have to interpolate the functions over a one-dimensional element). In general the basis functions used for  $u$  and  $q$  do not have to be the same (typically they are) and these basis functions can even be different to the basis functions used for the geometry, but are generally taken to be the same (this is termed an isoparametric formulation).

This gives

$$c(P) u(P) + \sum_{j=1}^N \sum_{\alpha} u_{j\alpha} \int_{\Gamma_j} \varphi_{\alpha} \frac{\partial \omega}{\partial n} d\Gamma = \sum_{j=1}^N \sum_{\alpha} q_{j\alpha} \int_{\Gamma_j} \varphi_{\alpha} \omega d\Gamma \quad (3.23)$$

This equation holds for any point  $P$  on the surface  $\Gamma$ . We now generate one equation per node by putting the point  $P$  to be at each node in turn. If  $P$  is at node  $i$ , say, then we have

$$c_i u_i + \sum_{j=1}^N \sum_{\alpha} u_{j\alpha} \int_{\Gamma_j} \varphi_{\alpha} \frac{\partial \omega_i}{\partial n} d\Gamma = \sum_{j=1}^N \sum_{\alpha} q_{j\alpha} \int_{\Gamma_j} \varphi_{\alpha} \omega_i d\Gamma \quad (3.24)$$

where  $\omega_i$  is the fundamental solution with the singularity at node  $i$  (recall  $\omega$  is  $-\frac{1}{2\pi} \log r$ , where  $r$  is the distance from the singularity point). We can write Equation (3.24) in a more abbreviated form as

$$c_i u_i + \sum_{j=1}^N \sum_{\alpha} u_{j\alpha} a_{ij}^{\alpha} = \sum_{j=1}^N \sum_{\alpha} q_{j\alpha} b_{ij}^{\alpha} \quad (3.25)$$

where

$$a_{ij}^{\alpha} = \int_{\Gamma_j} \varphi_{\alpha} \frac{\partial \omega_i}{\partial n} d\Gamma \quad \text{and} \quad b_{ij}^{\alpha} = \int_{\Gamma_j} \varphi_{\alpha} \omega_i d\Gamma \quad (3.26)$$

Equation (3.25) is for node  $i$  and if we have  $L$  nodes, then we can generate  $L$  equations.

We can assemble these equations into the matrix system

$$\mathbf{A} \mathbf{u} = \mathbf{B} \mathbf{q} \quad (3.27)$$

(compare to the global finite element equations  $\mathbf{K} \mathbf{u} = \mathbf{f}$ ) where the vectors  $\mathbf{u}$  and  $\mathbf{q}$  are the vectors of nodal values of  $u$  and  $q$ . Note that the  $ij^{\text{th}}$  component of the  $\mathbf{A}$  matrix in general is *not*  $a_{ij}^{\alpha}$  and similarly for  $\mathbf{B}$ .

At each node, we must specify either a value of  $u$  or  $q$  (or some combination of these) to have a well-defined problem. We therefore have  $L$  equations (the number of nodes) and have  $L$  unknowns

to find. We need to rearrange the above system of equations to get

$$C\mathbf{x} = \mathbf{f} \quad (3.28)$$

where  $\mathbf{x}$  is the vector of unknowns. This can be solved using standard linear equation solvers, although specialist solvers are required if the problem is large (refer [todo : Section ???]).

The matrices  $\mathbf{A}$  and  $\mathbf{B}$  (and hence  $\mathbf{C}$ ) are fully populated and not symmetric (compare to the finite element formulation where the global stiffness matrix  $\mathbf{K}$  is sparse and symmetric). The size of the  $\mathbf{A}$  and  $\mathbf{B}$  matrices are dependent on the number of surface nodes, while the matrix  $\mathbf{K}$  is dependent on the number of finite element nodes (which include nodes in the domain). As mentioned earlier, it depends on the surface to volume ratio as to which method will generate the smallest and quickest solution.

The use of the fundamental solution as a weight function ensures that the  $\mathbf{A}$  and  $\mathbf{B}$  matrices are generally well conditioned (see Section 3.5 for more on this). In fact the  $\mathbf{A}$  matrix is diagonally dominant (at least for Laplace's equation). The matrix  $\mathbf{C}$  is therefore also well conditioned and Equation (3.28) can be solved reasonably easily.

The vector  $\mathbf{x}$  contains the unknown values of  $u$  and  $q$  on the boundary. Once this has been found, all boundary values of  $u$  and  $q$  are known. If a solution is then required at a point inside the domain, then we can use Equation (3.25) with the singular point  $P$  located at the required solution point *i.e.*,

$$u(P) = \sum_{j=1}^N \sum_{\alpha} q_{j\alpha} b_{Pj}^{\alpha} - \sum_{j=1}^N \sum_{\alpha} u_{j\alpha} a_{Pj}^{\alpha} \quad (3.29)$$

The right hand side of Equation (3.29) contains no unknowns and only involves evaluating the surface integrals using the fundamental solution with the singular point located at  $P$ .

### 3.5 Numerical Evaluation of Coefficient Integrals

We consider in detail here how one evaluates the  $a_{ij}^{\alpha}$  and  $b_{ij}^{\alpha}$  integrals for two-dimensional problems. These integrals typically must be evaluated numerically, and require far more work and effort than the analogous finite element integrals.

Recall that

$$a_{ij}^{\alpha} = \int_{\Gamma_j} \varphi_{\alpha} \frac{\partial \omega_i}{\partial n} d\Gamma \quad \text{and} \quad b_{ij}^{\alpha} = \int_{\Gamma_j} \varphi_{\alpha} \omega_i d\Gamma$$

where

$$\omega_i = -\frac{1}{2\pi} \log r_i$$

$r_i$  = distance measured from node  $i$

In terms of a local  $\xi$  coordinate we have

$$b_{ij}^\alpha = \int_0^1 \varphi_\alpha(\xi) \omega_i(\xi) |J(\xi)| d\xi \quad (3.30)$$

$$a_{ij}^\alpha = \int_{\Gamma_j} \varphi_\alpha(\xi) \frac{\partial \omega_i(\xi)}{\partial n} |J(\xi)| d\xi = \int_0^1 \varphi_\alpha(\xi) \frac{\partial \omega_i(\xi)}{\partial r_i} \frac{dr_i}{dn} |J(\xi)| d\xi \quad (3.31)$$

The Jacobian  $J(\xi)$  can be found by

$$J(\xi) = \frac{d\Gamma}{d\xi} = \frac{ds}{d\xi} = \sqrt{\left(\frac{dx}{d\xi}\right)^2 + \left(\frac{dy}{d\xi}\right)^2} \quad (3.32)$$

where  $s$  represents the arclength and  $\frac{dx}{d\xi}$  and  $\frac{dy}{d\xi}$  can be found by straight differentiation of the interpolation expression for  $x(\xi)$  and  $y(\xi)$ .

The fundamental solution is

$$\omega_i = -\frac{1}{2\pi} \log(r_i(\xi))$$

$$r_i(\xi) = \sqrt{(x(\xi) - x_i)^2 + (y(\xi) - y_i)^2}$$

where  $(x_i, y_i)$  are the coordinates of node  $i$ .

To find  $\frac{dr_i}{dn}$  we note that

$$\frac{dr_i}{dn} = \nabla r_i \cdot \hat{n} \quad (3.33)$$

where  $\hat{n}$  is a unit outward normal vector. To find a unit normal vector, we simply rotate the tangent vector (given by  $(x'(\xi), y'(\xi))$ ) by  $\frac{\pi}{2}$  in the appropriate direction and then normalise.

Thus every expression in the integrands of the  $a_{ij}^\alpha$  and  $b_{ij}^\alpha$  integrals can be found at any value of  $\xi$ , and the integrals can therefore be evaluated numerically using some suitable quadrature schemes.

If node  $i$  is well removed from element  $\Gamma_j$  then standard Gaussian quadrature can be used to evaluate these integrals. However, if node  $i$  is in  $\Gamma_j$  (or close to it) we see that  $r_i$  approaches 0 and the fundamental solution  $\omega_i$  tends to  $\infty$ . The integral still exists, but the integrand becomes singular. In such cases special care must be taken - either by using special quadrature schemes, large numbers of Gauss points or other special treatment.

FIGURE 3.6: Illustration of the decrease in  $r_i$  as node  $i$  approaches element  $\Gamma_j$ .

The integrals for which node  $i$  lies in element  $\Gamma_j$  are in general the largest in magnitude and lead to the diagonally dominant matrix equation. It is therefore important to ensure that these integrals are calculated as accurately as possible since these terms will have most influence on the solution. This is one of the disadvantages of the BEM - the fact that singular integrands must be



accurately integrated.

A relatively straightforward way to evaluate all the integrals is simply to use Gaussian quadrature with varying number of quadrature points, depending on how close or far the singular point is from the current element. This is not very elegant or efficient, but has the benefit that it is relatively easy to implement. For the case when node  $i$  is contained in the current element one can use special quadrature schemes which are designed to integrate log-type functions. These are to be preferred when one is dealing with Laplace's equation. However, these special log-type schemes cannot be so readily used on other types of fundamental solution so for a general purpose implementation, Gaussian quadrature is still the norm. It is possible to incorporate adaptive integration schemes that keep adding more quadrature points until some error estimate is small enough, or also to subdivide the current element into two or more smaller elements and evaluate the integral over each subelement. It is also possible to evaluate the "worst" integrals by using simple solutions to the governing equation, and this technique is the norm for elasticity problems (Section 5.8). Details on each of these methods is given in Section 3.8. It should be noted that research still continues in an attempt to find more efficient ways of evaluating the boundary element integrals.

### 3.6 The Three-Dimensional Boundary Element Method

The three-dimensional boundary element method is very similar to the two-dimensional boundary element method discussed above. As noted above, the three-dimensional boundary integral equation is the same as the two-dimensional equation (3.19), with  $\omega$  and  $c(P)$  being defined as in Section 3.3. The numerical solution procedure also parallels that given in Section 3.4, and the expressions given for  $a_{ij}^\alpha$  and  $b_{ij}^\alpha$  apply equally well to the three-dimensional case. The only real difference between the two procedures is how to numerically evaluate the terms in each integrand of these coefficient integrals.

As in Section 3.5 we illustrate how to evaluate each of the terms in the integrand of  $a_{ij}^\alpha$  and  $b_{ij}^\alpha$ . The relevant expressions are

$$\begin{aligned} a_{ij}^\alpha &= \int_{\Gamma_j} \varphi_\alpha \frac{\partial \omega_i}{\partial n} d\Gamma \\ &= \int_0^1 \int_0^1 \varphi_\alpha(\xi_1, \xi_2) \frac{\partial \omega_i}{\partial r_i}(\xi_1, \xi_2) \frac{dr_i}{dn} |J(\xi_1, \xi_2)| d\xi_1 d\xi_2 \end{aligned} \quad (3.34)$$

$$\begin{aligned} b_{ij}^\alpha &= \int_{\Gamma_j} \varphi_\alpha \omega_i d\Gamma \\ &= \int_0^1 \int_0^1 \varphi_\alpha(\xi_1, \xi_2) \omega_i(\xi_1, \xi_2) |J(\xi_1, \xi_2)| d\xi_1 d\xi_2 \end{aligned} \quad (3.35)$$

The fundamental solution is

$$\omega_i(\xi_1, \xi_2) = \frac{1}{4\pi r_i(\xi_1, \xi_2)}$$

$$\text{where } r_i(\xi_1, \xi_2) = \sqrt{(x(\xi_1, \xi_2) - x_i)^2 + (y(\xi_1, \xi_2) - y_i)^2 + (z(\xi_1, \xi_2) - z_i)^2}$$

where  $(x_i, y_i, z_i)$  are the coordinates of node  $i$ . As before we use  $\frac{dr_i}{dn} = \nabla r_i \cdot \hat{n}$  to find  $\frac{dr_i}{dn}$ . The unit outward normal  $\hat{n}$  is found by normalising the cross product of the two tangent vectors  $\mathbf{t}_1 = \left( \frac{\partial x}{\partial \xi_1}, \frac{\partial y}{\partial \xi_1}, \frac{\partial z}{\partial \xi_1} \right)$  and  $\mathbf{t}_2 = \left( \frac{\partial x}{\partial \xi_2}, \frac{\partial y}{\partial \xi_2}, \frac{\partial z}{\partial \xi_2} \right)$  (it relies on the user of any BEM code to ensure that the elements have been defined with a consistent set of element coordinates  $\xi_1$  and  $\xi_2$ ).

The Jacobian  $J(\xi_1, \xi_2)$  is given by  $\|\mathbf{t}_1 \times \mathbf{t}_2\|$  (where  $\mathbf{t}_1$  and  $\mathbf{t}_2$  are the two tangent vectors). Note that this is different for the determinant in a two-dimensional finite element code - in that case we are dealing with a two-dimensional surface in two-dimensional space, whereas here we have a (possibly curved) two-dimensional surface in three-dimensional space.

The integrals are evaluated numerically using some suitable quadrature schemes (see Section 3.8) (typically a Gauss-type scheme in both the  $\xi_1$  and  $\xi_2$  directions).

### 3.7 A Comparison of the FE and BE Methods

We comment here on some of the major differences between the two methods. Depending on the application some of these differences can either be considered as advantageous or disadvantageous to a particular scheme.

1. **FEM:** An entire domain mesh is required.

**BEM:** A mesh of the boundary only is required.

**Comment:** Because of the reduction in size of the mesh, one often hears of people saying that the problem size has been reduced by one dimension. This is one of the major pluses of the BEM - construction of meshes for complicated objects, particularly in 3D, is a very time consuming exercise.

2. **FEM:** Entire domain solution is calculated as part of the solution.

**BEM:** Solution on the boundary is calculated first, and then the solution at domain points (if required) are found as a separate step.

**Comment:** There are many problems where the details of interest occur on the boundary, or are localised to a particular part of the domain, and hence an entire domain solution is not required.

3. **FEM:** Reactions on the boundary typically less accurate than the dependent variables.

**BEM:** Both  $\mathbf{u}$  and  $\mathbf{q}$  of the same accuracy.

4. **FEM:** Differential Equation is being approximated.

**BEM:** Only boundary conditions are being approximated.

**Comment:** The use of the Green-Gauss theorem and a fundamental solution in the formulation means that the BEM involves no approximations of the differential Equation in the domain - only in its approximations of the boundary conditions.

5. **FEM:** Sparse symmetric matrix generated.

**BEM:** Fully populated nonsymmetric matrices generated.

**Comment:** The matrices are generally of different sizes due to the differences in size of the domain mesh compared to the surface mesh. There are problems where either method can give rise to the smaller system and quickest solution - it depends partly on the volume to surface ratio. For problems involving infinite or semi-infinite domains, BEM is to be favoured.

6. **FEM:** Element integrals easy to evaluate.

**BEM:** Integrals are more difficult to evaluate, and some contain integrands that become singular.

**Comment:** BEM integrals are far harder to evaluate. Also the integrals that are the most difficult (those containing singular integrands) have a significant effect on the accuracy of the solution, so these integrals need to be evaluated accurately.

7. **FEM:** Widely applicable. Handles nonlinear problems well.

**BEM:** Cannot even handle all linear problems.

**Comment:** A fundamental solution must be found (or at least an approximate one) before the BEM can be applied. There are many linear problems (*e.g.*, virtually any nonhomogeneous equation) for which fundamental solutions are not known. There are certain areas in which the BEM is clearly superior, but it can be rather restrictive in its applicability.

8. **FEM:** Relatively easy to implement.

**BEM:** Much more difficult to implement.

**Comment:** The need to evaluate integrals involving singular integrands makes the BEM at least an order of magnitude more difficult to implement than a corresponding finite element procedure.

## 3.8 More on Numerical Integration

The BEM involves integrals whose integrands in generally become singular when the source point is contained in the element of integration. If one uses constant or linear interpolation for the geometry and dependent variable, then it is possible to obtain analytic expressions to most (if not all) of the integrals that will appear in the BEM (at least for two-dimensional problems). The expressions can become quite lengthy to write down and evaluate, but benefit from the fact that they will be exact. However, when one begins to use general curved elements and/or solve three-dimensional problems then the integrals will not be available as analytic expressions. The basic tool for evaluation of these integrals is quadrature. As discussed in Section 2.8 a one-dimensional integral is approximated by a sum in which the integrand is evaluated at certain discrete points or

$$\int_0^1 f(\xi) d\xi \approx \sum_{i=1}^N f(\xi_i) w_i$$

The weights and abscissa for the Gaussian quadrature scheme of order  $N$  are chosen so that the above expression will exactly integrate any polynomial of degree  $2N - 1$  or less. For the numerical evaluation of two or three-dimensional integrals, a Gaussian scheme can be used of each variable of integration if the region of integration is rectangular. This is generally not the optimal choice for the weights and abscissae but it allows easy extension to higher order integration.

Low order Gaussian schemes are generally sufficient for all FEM integrals, but that is not the case for BEM. For a two-dimensional BEM solution of Laplace's equation, integrals of the form  $\int_0^1 \log(\xi) f(\xi) d\xi$  will be required. It is relatively common to use logarithmic schemes for this. These are obtained by approximating the integral as

$$\int_0^1 \log(\xi) f(\xi) d\xi \approx \sum_{i=1}^N f(\xi_i) w_i$$

In the same way as Gaussian quadrature schemes were developed in Section 2.8, log quadrature schemes can be developed which will exactly integrate polynomial functions  $f(\xi)$ . Tables of these are given below

Abscissas = $r_i$			Weight Factors = $w_i$		
$n$	$\xi_i$	$-w_i$	$n$	$\xi_i$	$-w_i$
2	0.112009	0.718539	3	0.063891	0.513405
	0.602277	0.281461		0.368997	0.391980
				0.766880	0.094615
			4	0.041448	0.848982
				0.245275	0.039225
				0.556165	
				0.190435	

It is possible to develop similar quadrature schemes for use in the BEM solution of other PDEs, which use different fundamental solutions to the log function. The problem with this approach is the lack of generality - each new equation to be used requires its own special quadrature scheme.

### 3.8.2 Special solutions

Another approach, particularly useful if Cauchy principal values are to be found (see Section 5.8) is to use special solutions of the governing equation to find one or more of the more difficult integrals.

For example  $u = x$  is a solution to Laplace's equation (assuming the boundary conditions are set correctly). Thus if one sets both  $u$  and  $q$  in Equation (3.27) at every node according to the solution  $u = x$ , one can then use this to solve for some entry in either the  $A$  or  $B$  matrix (typically the diagonal entry since this is the most important and difficult to find). Further solutions to Laplace's equation (*e.g.*,  $u = x^2 - y^2$ ) can be used to find the other matrix entries (or just used to check the accuracy of the matrices).

## 3.9 The Boundary Element Method Applied to other Elliptic PDEs

Helmholtz, modified Helmholtz (CMISS example) Poisson Equation (domain integral and MRM, DRM, Monte-carlo integration).

### 3.10 Solution of Matrix Equations

The standard BEM approach results in a system of equations of the form  $Cx = f$  (refer (3.28)). As mentioned above the matrix  $C$  is generally well conditioned, fully populated and nonsymmetric. For small problems, direct solution methods, based on LU factorisations, can be used. As the problem size increases, the time taken for the matrix solution begins to dominate the matrix assembly stage. This usually occurs when there is between 500 and 1000 degrees of freedom, although it is very dependent on the implementation of the BE method. The current technique of favour in the BE community for solution of large BEM matrix equations is a preconditioned Conjugate Gradient solver. Preconditioners are generally problem dependent - what works well for one problem may not be so good for another problem. The conjugate gradient technique is generally regarded as a solution technique for (sparse) symmetric matrix equations.

### 3.11 Coupling the FE and BE techniques

There are undoubtedly situations which favour FEM over BEM and vice versa. Often one problem can give rise to a model favouring one method in one region and the other method in another region, *e.g.*, in a detailed analysis of stresses around a foundation one needs FEM close to the foundation to handle nonlinearities, but to handle the semi-infinite domain (well removed from the foundation), BEM is better. There has been a lot of research on coupling FE and BE procedures - we will only talk about the basic ideas and use Laplace's Equation to illustrate this. There are at least two possible methods.

1. Treat the BEM region as a finite element and combine with FEM
2. Treat the FEM region as an equivalent boundary element and combine with BEM

FIGURE 3.7: Coupled finite element/boundary element solution domain.

Note that these are essentially equivalent - the use of one or the other depends on the problem, in the sense of which part is more dominant FEM or BEM)

Consider the region shown in Figure 3.7, where

$$\begin{aligned}\Omega_f &= \text{FEM region} \\ \Omega_B &= \text{BEM region} \\ \Gamma_f &= \text{FEM boundary} \\ \Gamma_B &= \text{BEM boundary} \\ \Gamma_I &= \text{interface boundary}\end{aligned}$$

The BEM matrices for  $\Omega_B$  can be written as

$$\mathbf{A}\mathbf{u} = \mathbf{B}\mathbf{q} \quad (3.36)$$

where  $\mathbf{u}$  is a vector of the nodal values of  $u$  and  $\mathbf{q}$  is a vector of the nodal values of  $\frac{\partial u}{\partial n}$

The FEM matrices for  $\Omega_F$  can be written as

$$\mathbf{K}\mathbf{u} = \mathbf{f} \quad (3.37)$$

where  $\mathbf{K}$  is the stiffness matrix and  $\mathbf{f}$  is the load vector.

To apply method 1 (*i.e.*, treating BEM as an equivalent FEM region) we get (from Equation (3.36))

$$\mathbf{B}^{-1}\mathbf{A}\mathbf{u} = \mathbf{q} \quad (3.38)$$

If we recall what the elements of  $\mathbf{f}$  in Equation (3.37) contained, then we can convert  $\mathbf{q}$  in Equation (3.38) to an equivalent load vector by weighting the nodal values of  $\mathbf{q}$  by the appropriate basis functions, producing a matrix  $\mathbf{M}$  *i.e.*,  $\mathbf{f}_B = \mathbf{M}\mathbf{q}$

Therefore Equation (3.38) becomes

$$\mathbf{M}(\mathbf{B}^{-1}\mathbf{A})\mathbf{u} = \mathbf{M}\mathbf{q} = \mathbf{f}_B$$

*i.e.*,

$$\begin{aligned}\mathbf{K}_B\mathbf{u} &= \mathbf{f}_B \\ \text{where } \mathbf{K}_B &= \mathbf{M}\mathbf{B}^{-1}\mathbf{A}\end{aligned}$$

an equivalent stiffness matrix obtain from BEM.

Therefore we can assemble this together with original FEM matrix to produce an FEM-type system for the entire region  $\Omega_B$ .

**Notes:**

1.  $\mathbf{K}_B$  is in general not symmetric and not sparse. This means that different matrix equation solvers must be used for solving the new combined FEM-type system (most solvers in FEM

codes assume sparse and symmetric). Attempts have been made to “symmetricise” the  $\mathbf{K}_B$  matrix - of doubtful quality. (e.g., replace  $\mathbf{K}_B$  by  $\frac{1}{2}(\mathbf{K}_B - \mathbf{K}_B^T)$  - often yields inaccurate results).

2. On  $\Gamma_I$  nodal values of  $\mathbf{u}$  and  $\mathbf{q}$  are unknown. One must make use of the following

$$\begin{aligned}\mathbf{u}_B^I &= \mathbf{u}_F^I \quad (\mathbf{u} \text{ is continuous}) \\ \frac{\partial \mathbf{u}_B^I}{\partial \mathbf{n}_B} &= -\frac{\partial \mathbf{u}_F^I}{\partial \mathbf{n}_F} \quad (\mathbf{q} \text{ is continuous, but } \Gamma_B = -\Gamma_F)\end{aligned}$$

To apply method 2 (i.e., to treat the FEM region as an equivalent BEM region) we firstly note that, as before,  $\mathbf{f} = \mathbf{M}\mathbf{q}$ . Applying this to (3.37) yields  $\mathbf{K}\mathbf{u} = \mathbf{M}\mathbf{q}$  an equivalent BEM system. This can be assembled into the existing BEM system (using compatibility conditions) and use existing BEM matrix solvers.

**Notes:**

1. This approach does not require any matrix inversion and is hence easier (cheaper) to implement
2. Existing BEM solvers will not assume symmetric or sparse matrices therefore no new matrix solvers to be implemented

## 3.12 Other BEM techniques

What we have mentioned to date is the so-called singular (direct) BEM. Given a BIE there are other ways of solving the Equation although these are not so widely used.

### 3.12.1 Trefftz method

Trefftz was the first person to perform a BEM calculation (in 1917 - calculated the value (numerical) of the contraction coefficient of a round jet issuing from an infinite tank - a nonlinear free surface problem). This method basically uses a “complete” set of solutions instead of a Fundamental Solution. e.g., Consider Laplace's Equation in a (bounded) domain  $\Omega$

$$\text{weighted residuals} \Rightarrow \int_{\partial\Omega} \omega \frac{\partial u}{\partial n} d\Gamma = \int_{\partial\Omega} u \frac{\partial \omega}{\partial n} d\Gamma \quad \text{if } \nabla^2 \omega = 0$$

The procedure is to express  $u$  as a series of (complete) functions satisfying Laplace's equation with coefficients which need to be numerically determined through utilisation of the boundary conditions.

**Notes:**

1. Doesn't introduce singular functions so integrals are easy to evaluate

2. Must find a (complete) set of functions (If you just use usual approximations for  $u$  matrix system is not diagonally dominant so not so good)
3. Method is not so popular - Green's functions more widely available than complete systems

### 3.12.2 Regular BEM

Consider the BIE for Laplace's equation

$$c(P)u(P) + \int_{\partial\Omega} u \frac{\partial\omega}{\partial n} d\Gamma = \int_{\partial\Omega} \frac{\partial u}{\partial n} \omega d\Gamma$$

with  $\omega = -\frac{1}{2\pi} \log r$

The usual procedure is to put point  $P$  at each solution variable node - creating an equation for each node. This leads to singular integrands.

Another possibility is to put point  $P$  outside of the domain  $\Omega$  - this yields

$$\int_{\partial\Omega} u \frac{\partial\omega_p}{\partial n} d\Gamma = \int_{\partial\Omega} \frac{\partial u}{\partial n_p} d\Gamma$$

Following discretisation as before gives

$$\sum_{j=1}^N \sum_{\alpha} u_{j\alpha} \int_{\Gamma_j} \varphi_{\alpha} \frac{\partial\omega_p}{\partial n} d\Gamma = \sum_{j=1}^N \sum_{\alpha} q_{j\alpha} \int_{\Gamma_j} \varphi_{\alpha} \omega_p d\Gamma$$

- an equation involving  $u$  and  $q$  at each surface node.

By placing the point  $P$  (the singular point) at other distinct points outside  $\Omega$  one can generate as many equations as there are unknowns (or more if required).

**Notes:**

1. This method does not involve singular integrands, so that integrals are inexpensive to calculate.
2. There is considerable choice for the location of the point  $P$ . Often the set of Equations generated are ill-conditioned unless  $P$  chosen carefully. In practice  $P$  is chosen along the unit outward normal of the surface at each solution variable node. The distance along each node is often found by experimentation - various research papers suggesting "ideal" distances (Patterson & Shiekh).
3. This method is not very popular.
4. The idea of placing the singularity point  $P$  away from the solution variable node is often of use in other situations *e.g.*, *Exterior Acoustic Problems*. For an acoustic problem (governed by Helmholtz Equation  $\nabla^2 u + k^2 u = 0$ ) in an unbounded region the system of Equations produced by the usual (singular) BEM approach is singular for certain "fictitious" frequencies



FIGURE 3.8: A problem exhibiting symmetry.

FIGURE 3.9: Illustration of a symmetric mesh.

(*i.e.*, certain values of  $k$ ). To overcome this further equations are generated (by placing the singular point  $P$  at various locations outside  $\Omega$ ). The system of equations are then over-determined and are solved in a least squares sense.

### 3.13 Symmetry

Consider the problem given in Figure 3.8 (the domain is *outside* the circle). Both the boundary conditions and the governing Equation exhibit symmetry about the vertical axis. *i.e.*, putting  $x$  to  $-x$  makes no difference to the problem formulation. Thus the solution  $H(x, z)$  has the property that  $H(x, z) = H(-x, z) \forall x$ . This behaviour can be found in many problems and we can make use of this as follows. The Boundary Element Equation is (with  $N = 2M$  (*i.e.*,  $N$  is even) *constant* elements)

$$\frac{1}{2}u_i + \sum_{j=1}^N u_j \int_{\Gamma_j} \frac{\partial \omega_i}{\partial n} d\Gamma = \sum_{j=1}^N q_j \int_{\Gamma_j} \omega_i d\Gamma \quad i = 1, \dots, N \quad (3.39)$$

We have  $N$  Equations and  $N$  unknowns (allowing for the boundary conditions). From symmetry we know that (refer to Figure 3.9).

$$u_i = u_{n+1-i} \quad i = 1, \dots, M \quad (3.40)$$

So we can write

$$\frac{1}{2}u_i + \sum_{j=1}^M u_j \left\{ \int_{\Gamma_j} \frac{\partial \omega_i}{\partial n} d\Gamma + \int_{\Gamma_{N+1-j}} \frac{\partial \omega_i}{\partial n} d\Gamma \right\} = \sum_{j=1}^M q_j \left\{ \int_{\Gamma_j} \omega_i d\Gamma + \int_{\Gamma_{N+1-j}} \omega_i d\Gamma \right\} \quad (3.41)$$

for nodes  $i = 1, \dots, M$ . (The Equations for nodes  $i = M+1, \dots, N$  are the same as the Equations for nodes  $i = 1, \dots, M$ ). The above  $M$  Equations have only  $M$  unknowns.

If we define

$$a_{ij} = \int_{\Gamma_j} \frac{\partial \omega_i}{\partial n} d\Gamma + \int_{\Gamma_{N+1-j}} \frac{\partial \omega_i}{\partial n} d\Gamma \quad (3.42)$$

$$b_{ij} = \int_{\Gamma_j} \omega_i d\Gamma + \int_{\Gamma_{N+1-j}} \omega_i^* d\Gamma \quad (3.43)$$

FIGURE 3.10: Illustration of surface  $\bar{\Gamma}$  for an axisymmetric problem.FIGURE 3.11: The distance from the source point ( $P$ ) to the point of interest ( $Q$ ) in terms of cylindrical polar coordinates.

then we can write Equation (3.41) as

$$\frac{1}{2}u_i + \sum_{j=1}^M a_{ij}u_j = \sum_{j=1}^M b_{ij}q_j \quad i = 1, \dots, M \quad (3.44)$$

and solve as before. (This procedure has halved the number of unknowns.)

Note: Since  $i = 1, \dots, M$  this means that the integrals over the elements  $\Gamma_{M+1}$  to  $\Gamma_N$  will never contain a singularity arising from the fundamental solution, except possibly on the axis of symmetry if linear or higher order elements are used.

An alternative approach to the method above arises from the implied no flux across the  $z$  axis. This approach ignores the negative  $x$  axis and considers the half plane problem shown.

However now the surface to be discretised extends to infinity in the positive and negative  $z$  directions and the resulting systems of equations produced is much larger.

Further examples of how symmetry can be used (*e.g.*, radial symmetry) are given in the next section.

### 3.14 Axisymmetric Problems

If a three-dimensional problem exhibits radial or axial symmetry (*i.e.*,  $u(r, \theta_1, z) = u(r, \theta_2, z)$ ) it is possible to reduce the two-dimensional integrals appearing in the standard boundary Equation to one-dimensional line integrals and thus substantially reduce the amount of computer time that would otherwise be required to solve the fully three-dimensional problem. The first step in such a procedure is to write the standard boundary integral equation in terms of cylindrical polars  $(r, \theta, z)$  *i.e.*,

$$c(P)u(P) + \int_{\bar{\Gamma}} u \left( \int_0^{2\pi} \frac{\partial \omega_p}{\partial n} d\theta_q \right) r_q d\bar{\Gamma} = \int_{\bar{\Gamma}} q \left( \int_0^{2\pi} \omega_p d\theta_q \right) r_q d\bar{\Gamma} \quad (3.45)$$

where  $(r_p, \theta_p, z_p)$  and  $(r_q, \theta_q, z_q)$  are the polar coordinates of  $P$  and  $Q$  respectively, and  $\bar{\Gamma}$  is the intersection of  $\Gamma$  and  $\theta = 0$  semi-plane (Refer Figure 3.10). (*n.b.*  $Q$  is a point on the surface being integrated over.)

For three-dimensional problems governed by Laplace's equation

$$\omega_p = \frac{1}{4\pi r}$$

where  $r_p$  is the distance from  $P$  to  $Q$ . From Figure 3.11

$$\begin{aligned}
r_1^2 &= r_p^2 + r_q^2 - 2r_p r_q \cos(\theta_p - \theta_q) \\
r^2 &= \sqrt{r_1^2 + r_2^2} \\
r &= \sqrt{r_p^2 + r_q^2 - 2r_p r_q \cos(\theta_p - \theta_q) + (z_p - z_q)^2} \\
&= \sqrt{a - b \cos(\theta_p - \theta_q) + (z_p - z_q)^2}
\end{aligned} \tag{3.46}$$

We define

$$\bar{\omega}_p = \frac{1}{4\pi} \int_0^{2\pi} \omega_p d\theta_q \equiv \frac{K(m)}{\pi\sqrt{a+b}} \quad \text{where } m = \frac{2b}{a+b} \tag{3.47}$$

and  $K(m)$  is the complete elliptic integral of the first kind.

$\bar{\omega}_p$  is called the axisymmetric fundamental solution and is the Green's function for a ring source as opposed to a point source. *i.e.*,  $\bar{\omega}_p$  is a solution of

$$\nabla^2 \omega + \delta(r - r_p) = 0 \tag{3.48}$$

instead of

$$\nabla^2 \omega + \delta_p = 0 \tag{3.49}$$

where  $\delta_p$  is the dirac delta centered at the point  $P$  and  $\delta(r - r_p)$  is the dirac delta centered on the ring  $r = r_p$ .

Unlike the two- and three-dimensional cases, the axisymmetric fundamental solution cannot be written as simply a function of the distance between two points  $P$  and  $Q$ , but it also depends upon the distance of these points to the axis of revolution.

We also define

$$\bar{q}_p^* = \frac{1}{4\pi} \int_0^{2\pi} \frac{\partial \omega_p}{\partial n} d\theta_q \equiv \frac{\partial \bar{\omega}_p}{\partial n} \tag{3.50}$$

For Laplace's equation Equation (3.50) becomes

$$\bar{q}_p^* = \frac{1}{\pi\sqrt{a+b}} \left[ \frac{1}{2r_q} \left\{ \frac{r_p^2 - r_q^2 + (z_p - z_q)^2}{a - b} E(m) - K(m) \right\} n_r(Q) + \frac{z_p - z_q}{a - b} E(m) n_z(Q) \right] \tag{3.51}$$

where  $E(m)$  is the complete elliptic integral of the second kind.

Using Equation (3.47) and Equation (3.50) we can write Equation (3.45) as

$$c(P) u(P) + \int_{\bar{\Gamma}} u \frac{\partial \bar{\omega}_p}{\partial n} d\bar{\Gamma} = \int_{\bar{\Gamma}} q \bar{\omega}_p d\bar{\Gamma} \tag{3.52}$$

and the solution procedure for this Equation follows the same lines as the solution procedure given previously for the two-dimensional version of boundary element method.

FIGURE 3.12: Derivation of infinite domain boundary integral equations.

### 3.15 Infinite Regions

The boundary integral equations we have been using have been derived assuming the domain  $\Omega$  is bounded (although this was never stated). However all concepts presented thus far are also valid for infinite regular (*i.e.*, nice) regions provided the solution and its normal derivative behave appropriately as  $\Gamma \rightarrow \infty$ .

Consider the problem of solving  $\nabla^2 u = 0$  outside some surface  $\Gamma$ .

$\bar{\Gamma}$  is the centre of a circle (or sphere in three dimensions) of radius centred at some point  $x_0$  on  $\Gamma$  and surrounding  $\Gamma$  (see Figure 3.12). The boundary integral equations for the bounded domain  $\Omega_R$  can be written as

$$c(P)u(P) + \int_{\Gamma} u \frac{\partial \omega_P}{\partial n} d\Gamma + \int_{\bar{\Gamma}} u \frac{\partial \omega_P}{\partial n} d\Gamma = \int_{\Gamma} q \omega_P d\Gamma + \int_{\bar{\Gamma}} q \omega_P d\Gamma \quad (3.53)$$

If we let the radius  $R \rightarrow \infty$  Equation (3.53) will only be valid for the points on  $\Gamma$  if

$$\lim_{R \rightarrow \infty} \int_{\bar{\Gamma}} \left( u \frac{\partial \omega_P}{\partial n} - q \omega_P \right) d\Gamma = 0 \quad (3.54)$$

If this is satisfied, the boundary integral Equation for  $\Omega$  will be as expected *i.e.*,

$$c(P)u(P) + \int_{\Gamma} u \frac{\partial \omega_P}{\partial n} d\Gamma = \int_{\Gamma} q \omega_P d\Gamma \quad (3.55)$$

For three-dimensional problems with  $\omega^* = \frac{1}{4\pi r}$

$$\begin{aligned} d\Gamma &= |J| d\theta d\phi & \text{where } |J| &= O(R^2) \\ \omega^* &= O(R^{-1}) \\ \frac{\partial \omega^*}{\partial n} &= O(R^{-2}) \end{aligned}$$

where  $|J|$  is the Jacobian and  $O()$  represents the asymptotic behaviour of the function as  $R \rightarrow \infty$ . In this case Equation (3.53) will be satisfied if  $u$  behaves at most as  $O(R^{-1})$  so that  $q = O(R^{-2})$ . These are the regularity conditions at infinity and these ensure that each term in the integral Equation (3.53) behaves at most as  $O(R^{-1})$  (*i.e.*, each term will  $\rightarrow 0$  as  $R \rightarrow \infty$ )

For two-dimensional problems with  $\omega^* = O(\log(R))$  we require  $u$  to behave as  $\log(R)$  so that  $q = O(R^{-1})$ . For almost all well posed infinite domain problems the solution behaves appropriately at infinity.

## 3.16 Appendix: Common Fundamental Solutions

### 3.16.1 Two-Dimensional equations

Here  $r = \sqrt{(x_1^2 + x_2^2)}$ .

Laplace	Equation	$\frac{\partial^2 u^*}{\partial x_1^2} + \frac{\partial^2 u^*}{\partial x_2^2} + \delta_0 = 0$
---------	----------	--

	Solution	$u^* = \frac{1}{2\pi} \log \left( \frac{1}{r} \right)$
--	----------	--

Helmholtz	Equation	$\frac{\partial^2 u^*}{\partial x_1^2} + \frac{\partial^2 u^*}{\partial x_2^2} + \lambda^2 u^* + \delta_0 = 0$
-----------	----------	--

	Solution	$u^* = \frac{1}{4i} H_0^{(2)}(\lambda r)$ where $H$ is the Hankel function.
--	----------	--

Wave	Equation	$c^2 \left( \frac{\partial^2 u^*}{\partial x_1^2} + \frac{\partial^2 u^*}{\partial x_2^2} \right) - \frac{\partial^2 u^*}{\partial t^2} + \delta_0(t) = 0$ where $c$ is the wave speed.
------	----------	--

	Solution	$u^* = -\frac{H(ct - r)}{2\pi c(c^2 t^2 - r^2)}$
--	----------	--

Diffusion	Equation	$\frac{\partial^2 u^*}{\partial x_1^2} + \frac{\partial^2 u^*}{\partial x_2^2} - \frac{1}{k} \frac{\partial u^*}{\partial t} = 0$ where $k$ is the diffusivity.
-----------	----------	--

	Solution	$u^* = -\frac{1}{(4\pi kt)^{\frac{3}{2}}} \exp \left( -\frac{r^2}{4kt} \right)$
--	----------	---

Navier's	Equation	$\frac{\partial \sigma_{jk}^*}{\partial x_j} + \delta_l = 0$ for a point load in direction $l$ .
----------	----------	--

	Solution	$p_i^* = p_{ji}^* e_j$ $p_{ji}^* = -\frac{1}{8\pi(1-\nu^2)r^2}$ $\left( \frac{\partial r}{\partial n} [(1-2\nu)\delta_{ij} + 3r_{,i}r_{,j}] + (1-2\nu)(n_j r_{,i} - n_i r_{,j}) \right) e_j$ for a traction in direction $k$ where $\nu$ is Poisson's ratio.
--	----------	---

### 3.16.2 Three-Dimensional equations

Here  $r = \sqrt{(x_1^2 + x_2^2 + x_3^2)}$ .

Laplace	Equation	$\frac{\partial^2 u^*}{\partial x_1^2} + \frac{\partial^2 u^*}{\partial x_2^2} + \frac{\partial^2 u^*}{\partial x_3^2} + \delta_0 = 0$
	Solution	$u^* = \frac{1}{4\pi r}$
Helmholtz	Equation	$\frac{\partial^2 u^*}{\partial x_1^2} + \frac{\partial^2 u^*}{\partial x_2^2} + \frac{\partial^2 u^*}{\partial x_3^2} + \lambda^2 u^* + \delta_0 = 0$
	Solution	$u^* = \frac{1}{4\pi r} \exp(-i\lambda r)$
Wave	Equation	$c^2 \left( \frac{\partial^2 u^*}{\partial x_1^2} + \frac{\partial^2 u^*}{\partial x_2^2} + \frac{\partial^2 u^*}{\partial x_3^2} \right) - \frac{\partial^2 u^*}{\partial t^2} + \delta_t = 0$ where $c$ is the wave speed.
	Solution	$u^* = \frac{\delta \left( t - \frac{r}{c} \right)}{4\pi r}$
Navier's	Equation	$\frac{\partial \sigma_{jk}^*}{\partial x_j} + \delta_l = 0$ for a isotropic homogenous Kelvin solution for a point load in direction $l$ .
	Solution	$u_k^* = u_{lk}^* e_l$ $u_{lk}^* = \frac{1}{16\pi G (1 - \nu)} \left( \frac{3 - 4\nu}{r} \delta_{lk} + \frac{\partial r}{\partial x_1} \frac{\partial r}{\partial x_2} \right)$ for a displacement in direction $k$ where $\nu$ is Poisson's ratio and $G$ is the shear modulus.

### 3.16.3 Axisymmetric problems

Laplace For  $u^*$  see Equation (3.47) and for  $q^*$  see Equation (3.51)

## 3.17 CMISS Examples

1. 2D steady-state heat conduction inside an annulus To determine the steady-state heat conduction inside an annulus run the CMISS example 324.
2. 3D steady-state heat conduction inside a sphere. To determine the steady-state heat conduction inside a sphere run the CMISS example 328.
3. CMISS comparison of 2-D FEM and BEM calculations To determine the CMISS comparison of 2-D FEM and BEM calculations run examples 324 and 312.
4. CMISS biopotential problems C4 and C5.

# Chapter 4

## Transient Heat Conduction

### 4.1 Introduction

In the previous discussion of steady state boundary value problems the principal advantage of the finite element method over the finite difference method has been the greater ease with which complex boundary shapes can be modelled. In time-dependent problems the solution proceeds from an initial solution at  $t = 0$  and it is almost always convenient to calculate each new solution at a constant time ( $t > 0$ ) throughout the entire spatial domain  $\Omega$ . There is, therefore, no need to use the greater flexibility (and cost) of finite elements to subdivide the time domain: finite difference approximations of the time derivatives are usually preferred. Finite difference techniques are introduced in Section 4.2 to solve the transient one dimensional heat equation. A combination of finite elements for the spatial domain and finite differences for the time domain is used in Section 4.3 to solve the transient advection-diffusion equation - a slight generalization of the heat equation.

### 4.2 Finite Differences

#### 4.2.1 Explicit Transient Finite Differences

Consider the transient one-dimensional heat equation

$$\frac{\partial u}{\partial t} = D \frac{\partial^2 u}{\partial x^2}, \quad (0 < x < L, t > 0) \quad (4.1)$$

where  $D$  is the conductivity and  $u = u(x, t)$  is the temperature, subject to the boundary conditions  $u(0, t) = u_0$  and  $u(L, t) = u_1$  and the initial conditions  $u(x, 0) = 0$ . A finite difference approximation of this equation is obtained by defining a grid with spacing  $\Delta x$  in the  $x$ -domain and  $\Delta t$  in the time domain, as shown in Figure 4.1.

Grid points are labelled by the indices  $i = 0, 1, \dots, I$  (for the  $x$ -direction) and  $n = 0, 1, \dots, N$  (for the  $t$ -direction). The temperature at the grid point  $(i, n)$  is therefore labelled as

$$u(x, t) = u(i\Delta x, n\Delta t) = u_i^n. \quad (4.2)$$

Finite difference equations are derived by writing Taylor Series expansions for  $u_{i+1}^n, u_{i-1}^n, u_i^{n+1}$

FIGURE 4.1: A finite difference grid for the solution of the transient 1D heat equation. The equation is centred at grid point  $(i, n)$  shown by the **O**. The lightly shaded region shows where the solution is known at time step  $n$ . With central differences in  $x$  and a forward difference in  $t$  an explicit finite difference formula gives the solution at time step  $n + 1$  explicitly in terms of the solution at the three points below it at step  $n$ , as indicated by the dark shading.

about the grid point  $(i, n)$

$$u_{i+1}^n = u_i^n + \Delta x \cdot \left( \frac{\partial u}{\partial x} \right)_i^n + \frac{1}{2} \Delta x^2 \cdot \left( \frac{\partial^2 u}{\partial x^2} \right)_i^n + \frac{1}{6} \Delta x^3 \cdot \left( \frac{\partial^3 u}{\partial x^3} \right)_i^n + O(\Delta x^4) \quad (4.3)$$

$$u_{i-1}^n = u_i^n - \Delta x \cdot \left( \frac{\partial u}{\partial x} \right)_i^n + \frac{1}{2} \Delta x^2 \cdot \left( \frac{\partial^2 u}{\partial x^2} \right)_i^n - \frac{1}{6} \Delta x^3 \cdot \left( \frac{\partial^3 u}{\partial x^3} \right)_i^n + O(\Delta x^4) \quad (4.4)$$

$$u_i^{n+1} = u_i^n + \Delta t \cdot \left( \frac{\partial u}{\partial t} \right)_i^n + O(\Delta t^2) \quad (4.5)$$

where  $O(\Delta x^4)$  and  $O(\Delta t^2)$  represent all the remaining terms in the Taylor Series expansions.

Adding Equations (4.3) and (4.4) gives

$$u_{i+1}^n + u_{i-1}^n = 2u_i^n + \Delta x^2 \cdot \left( \frac{\partial^2 u}{\partial x^2} \right)_i^n + O(\Delta x^4)$$

or

$$\left( \frac{\partial^2 u}{\partial x^2} \right)_i^n = \frac{u_{i+1}^n - 2u_i^n + u_{i-1}^n}{\Delta x^2} + O(\Delta x^2), \quad (4.6)$$

which is a “central difference” approximation of the second order spatial derivative.

Rearranging Equation (4.5) gives a “difference” approximation of the first order time derivative

$$\left( \frac{\partial u}{\partial t} \right)_i^n = \frac{u_i^{n+1} - u_i^n}{\Delta t} + O(\Delta t). \quad (4.7)$$

Substituting Equation (4.6) and Equation (4.7) into the transient heat equation Equation (4.1) gives the finite difference approximation

$$\frac{u_i^{n+1} - u_i^n}{\Delta t} + O(\Delta t) = D \frac{u_{i+1}^n - 2u_i^n + u_{i-1}^n}{\Delta x^2} + O(\Delta x^2)$$

which is rearranged to give an expression for  $u_i^{n+1}$  in terms of the values of  $u$  at the  $n^{\text{th}}$  time step

$$u_i^{n+1} = u_i^n + D \frac{\Delta t}{\Delta x^2} (u_{i+1}^n - 2u_i^n + u_{i-1}^n) + O(\Delta t^2, \Delta x^2). \quad (4.8)$$

Given the initial values of  $u_i^n$  at  $n = 0$  (*i.e.*,  $t = 0$ ), the values of  $u_i^{n+1}$  for the next time step are found from Equation (4.8) with  $i = 1, 2, \dots, I$ . Applying Equation (4.8) iteratively for time steps  $n = 1, 2, \dots$  *etc.* yields the time dependent temperatures at the grid points (see Figure 4.1). This is an *explicit* finite difference formula because the value of  $u_i^n$  depends only on the values of



$u_i^n$  ( $i = 1, 2, \dots, I$ ) at the previous time step and not on the neighbouring terms  $u_{i+1}^{n+1}$  and  $u_{i-1}^{n+1}$  at the latest time step. The accuracy of the solution depends on the chosen values of  $\Delta x$  and  $\Delta t$  and in fact the stability of the scheme depends on these satisfying the *Courant* condition:

$$D \frac{\Delta t}{\Delta x^2} \leq \frac{1}{2}. \quad (4.9)$$

### 4.2.2 Von Neumann Stability Analysis

The concept behind the Von Neumann analysis is that all Fourier components decay as time advances or as they are processed by an iterative solver. Considering Equation (4.8), we can rearrange this to be of the form,

$$u_i^{n+1} = \Upsilon u_{i+1}^n + (1 - 2\Upsilon)u_i^n + \Upsilon u_{i-1}^n \quad (4.10)$$

where  $\Upsilon = D \frac{\Delta t}{\Delta x^2}$ . By substituting the general Fourier component  $u_j^n = A_k^n e^{i(\frac{\pi k j \Delta x}{L})}$ , we obtain,

$$A_k^{n+1} e^{i(\frac{\pi k j \Delta x}{L})} = A_k^n \left[ \Upsilon e^{i(\frac{\pi k (j+1) \Delta x}{L})} + (1 - 2\Upsilon) e^{i(\frac{\pi k j \Delta x}{L})} + \Upsilon e^{i(\frac{\pi k (j-1) \Delta x}{L})} \right] \quad (4.11)$$

If divide Equation (4.11) by,  $A_k^n e^{i(\frac{\pi k j \Delta x}{L})}$  we obtain (no sum on  $k$ ),

$$\begin{aligned} \frac{A_k^{n+1}}{A_k^n} &= (1 - 2\Upsilon) + \Upsilon e^{i(\frac{\pi k \Delta x}{L})} + \Upsilon e^{-i(\frac{\pi k \Delta x}{L})} \\ &= 1 - 2\Upsilon + 2\Upsilon \cos\left(\frac{\pi k \Delta x}{L}\right) \quad \text{using} \quad \cos(x) = \frac{e^{ix} + e^{-ix}}{2} \\ &= 1 - 4\Upsilon \sin^2\left(\frac{\pi k \Delta x}{2L}\right) \quad \text{using} \quad \cos(2x) = 1 - 2\sin^2(x) \end{aligned} \quad (4.12)$$

Equation (4.12) predicts the growth of any component (specified by  $k$ ) admitted by the system. If all components are to decay,

$$\left| \frac{A_k^{n+1}}{A_k^n} \right| \leq 1 \quad \text{for stability (no sum on } k) \quad (4.13)$$

Since the  $\sin^2$  term in Equation (4.12) is always between 0 and 1, we effectively have the stability criteria that

$$1 - 4\Upsilon \leq 1 \quad \text{and} \quad 1 - 4\Upsilon \geq -1 \quad (4.14)$$

The first inequality is trivially satisfied, since  $\Upsilon \geq 0$  for positive values of  $\Delta t$  and  $D$ , and the second condition will always hold if

$$\Upsilon = D \frac{\Delta t}{\Delta x^2} \leq \frac{1}{2} \quad (4.15)$$

Thus, to ensure stability, the time step should be chosen such that

$$\Delta t \leq \frac{\Delta x^2}{2D} \quad \text{The Courant condition} \quad (4.16)$$

FIGURE 4.2: An implicit finite difference scheme based on central differences in  $t$ , as well as  $x$ , which tie together the 6 points shown by  $\times$ . The equation is centred at the point  $(i, n + \frac{1}{2})$  shown by the  $\circ$ . The lightly shaded region shows where the solution is known at time step  $n$ . The dark shading shows the region of the coupled equations.

### 4.2.3 Higher Order Approximations

An improvement in accuracy and stability can be obtained by using a higher order approximation for the time derivative. For example, if a central difference approximation is used for  $\frac{\partial u}{\partial t}$  by centering the equation at  $(i\Delta x, (n + \frac{1}{2})\Delta t)$  rather than  $(i\Delta x, n\Delta t)$  we get

$$\left(\frac{\partial u}{\partial t}\right)_i^{n+\frac{1}{2}} = \frac{u_i^{n+1} - u_i^n}{\Delta t} + O(\Delta t^2) \quad (4.17)$$

in place of Equation (4.7) and Equation (4.1) is approximated with the ‘‘Crank-Nicolson’’ formula

$$\frac{u_i^{n+1} - u_i^n}{\Delta t} = D \left\{ \frac{1}{2} \left(\frac{\partial^2 u}{\partial x^2}\right)_i^{n+1} + \frac{1}{2} \left(\frac{\partial^2 u}{\partial x^2}\right)_i^n \right\} \quad (4.18)$$

in which the spatial second derivative term is weighted by  $\frac{1}{2}$  at the old time step  $n$  and by  $\frac{1}{2}$  at the new time step  $n + 1$ . Notice that the finite difference time derivative has not changed - only the time position at which it is centred. The price paid for the better accuracy (for a given  $\Delta t$ ) and unconditional stability (*i.e.*, stable for **any**  $\Delta t$ ) is that Equation (4.18) is an *implicit* scheme - the equations for the new time step are now coupled in that  $u_i^{n+1}$  depends on the neighbouring terms  $u_{i+1}^{n+1}$  and  $u_{i-1}^{n+1}$ . Thus each new time step requires the solution of a system of coupled equations.

A generalization of (4.18) is

$$\frac{u_i^{n+1} - u_i^n}{\Delta t} = D \left\{ \theta \left(\frac{\partial^2 u}{\partial x^2}\right)_i^{n+1} + (1 - \theta) \left(\frac{\partial^2 u}{\partial x^2}\right)_i^n \right\} \quad (4.19)$$

in which the spatial second derivative of Equation (4.1) has been weighted by  $\theta$  at the new time step and by  $(1 - \theta)$  at the old time step. The original explicit forward difference scheme Equation (4.8) is recovered when  $\theta = 0$  and the implicit central difference (Crank-Nicolson) scheme (4.19) when  $\theta = \frac{1}{2}$ . An implicit backward difference scheme is obtained when  $\theta = 1$ .

In the following section the transient heat equation is approximated for numerical analysis by using finite differences in time and finite elements in space. We also generalize the partial differential equation to include an advection term and a source term.

### 4.3 The Transient Advection-Diffusion Equation

Consider a linear parabolic equation

$$\frac{\partial u}{\partial t} + \mathbf{v} \cdot \nabla u = D \nabla^2 u + f \quad (4.20)$$

where  $u$  is a scalar variable (e.g., the advection-diffusion equation, where  $u$  is concentration or temperature;  $\mathbf{v} \cdot \nabla u$  then represents advective transport by a velocity field  $\mathbf{v}$ ,  $D$  is the diffusivity and  $f$  is source term. The ratio of advective to diffusive transport is characterised by the *Peclet number*  $VL/D$  where  $V = \|\mathbf{v}\|_2$  and  $L$  is a characteristic length).

Applying the Galerkin weighted residual method to Equation (4.20) with weight  $\omega$  gives

$$\int_{\Omega} \left( \frac{\partial u}{\partial t} + \mathbf{v} \cdot \nabla u - D \nabla^2 u - f \right) \omega d\Omega = 0$$

or

$$\int_{\Omega} \left[ \left( \frac{\partial u}{\partial t} + \mathbf{v} \cdot \nabla u \right) \omega + D \nabla u \cdot \nabla \omega \right] d\Omega = \int_{\Omega} f \omega d\Omega + D \int_{\partial\Omega} \frac{\partial u}{\partial n} \omega d\Gamma \quad (4.21)$$

where  $\frac{\partial}{\partial n}$  is the normal derivative to the boundary  $\partial\Omega$ .

Putting  $u = \varphi_n u_n$  and  $\omega = \varphi_m$  and summing the element contributions to the global equations, Equation (4.21) can be represented by a system of first order ordinary differential equations,

$$\mathbf{M} \frac{d\mathbf{u}}{dt} + \mathbf{K} \mathbf{u} = \mathbf{K} \mathbf{u}_{\infty} \quad (4.22)$$

where  $\mathbf{M}$  is the global mass matrix,  $\mathbf{K}$  the global stiffness matrix and  $\mathbf{u}$  a vector of global nodal unknowns with steady state values ( $t \rightarrow \infty$ )  $\mathbf{u}_{\infty}$ . The element contributions to  $\mathbf{M}$  and  $\mathbf{K}$  are given by

$$M_{mne} = \int_0^1 \varphi_m \varphi_n J d\xi \quad (4.23)$$

and

$$K_{mne} = \int_0^1 D \frac{\partial \varphi_m}{\partial \xi_i} \frac{\partial \varphi_n}{\partial \xi_j} \cdot \frac{\partial \xi_i}{\partial x_k} \frac{\partial \xi_j}{\partial x_k} J d\xi + \int_0^1 v_j \varphi_m \frac{\partial \varphi_n}{\partial \xi_i} \frac{\partial \xi_i}{\partial x_j} J d\xi \quad (4.24)$$

If the time domain is now discretized ( $t = n\Delta t, n = 0, 1, 2, \dots$ ) Equation (4.22) can be replaced by

$$\mathbf{M} \frac{\mathbf{u}^{n+1} - \mathbf{u}^n}{\Delta t} + \mathbf{K} [\theta \mathbf{u}^{n+1} + (1 - \theta) \mathbf{u}^n] = \mathbf{K} \mathbf{u}_{\infty} \quad 0 \leq \theta \leq 1 \quad (4.25)$$

where  $\theta$  is a weighting factor discussed in Section 4.2. Note that for  $\theta = \frac{1}{2}$  the method is known as the *Crank-Nicolson-Galerkin* method and errors arising from the time domain discretization are

$O(\Delta t^2)$ . Rearranging Equation (4.25) as

$$[\mathbf{M} + \theta \Delta t \mathbf{K}] \mathbf{u}^{n+1} = [\mathbf{M} - (1 - \theta) \Delta t \mathbf{K}] \mathbf{u}^n + \Delta t \mathbf{K} \mathbf{u}_\infty \quad (4.26)$$

gives a set of linear algebraic equations to solve at the new time step  $(n + 1) \Delta t$  from the known solution  $\mathbf{u}^n$  at the previous time step  $n \Delta t$ .

The stability of the above scheme can be examined by expanding  $\mathbf{u}$  (assumed to be smoothly continuous in time) in terms of the eigenvectors  $\mathbf{s}_i$  (with associated eigenvalues  $\lambda_i$ ) of the matrix  $\mathbf{A} = \mathbf{M}^{-1} \mathbf{K}$ . Writing the initial conditions  $\mathbf{u}(0) = \sum_i a_i \mathbf{s}_i$  and steady state solution  $\mathbf{u}_\infty = \sum_i b_i \mathbf{s}_i$ , the set of ordinary differential equations Equation (4.22) has solution

$$\mathbf{u} = \sum_i [b_i + (a_i - b_i) e^{-\lambda_i t}] \mathbf{s}_i \quad (4.27)$$

The time-difference scheme Equation (4.26) on the other hand, with  $\mathbf{u}$  now replaced by a set of discrete values  $\mathbf{u}^n$  at each time step  $n \Delta t$ , can be written as the recursion formula

$$[\mathbf{I} + \theta \Delta t \mathbf{A}] \mathbf{u}^{n+1} = [\mathbf{I} - (1 - \theta) \Delta t \mathbf{A}] \mathbf{u}^n + \Delta t \mathbf{A} \mathbf{u}_\infty \quad (4.28)$$

with solution

$$\mathbf{u} = \sum_i \left\{ b_i + (a_i - b_i) \left[ \frac{1 - \Delta t (1 - \theta) \lambda_i}{1 + \Delta t \theta \lambda_i} \right]^n \right\} \mathbf{s}_i \quad (4.29)$$

(You can verify that Equation (4.27) and Equation (4.29) are indeed the solutions of Equation (4.22) and Equation (4.25), respectively, by substituting and using  $\mathbf{A} \mathbf{s}_i = \lambda_i \mathbf{s}_i$ .)

Comparing Equation (4.27) and Equation (4.29) shows that replacing the ordinary differential equations (4.22) by the finite difference approximation Equation (4.25) is equivalent to replacing the exponential  $e^{-\lambda_i t}$  in Equation (4.27) by the approximation

$$e^{-\lambda_i t} \sim \left[ \frac{1 - \Delta t (1 - \theta) \lambda_i}{1 + \Delta t \theta \lambda_i} \right]^n \quad (4.30)$$

or, with  $t = n \Delta t$ ,

$$e^{-\lambda_i t} \sim \frac{1 - \Delta t (1 - \theta) \lambda_i}{1 + \Delta t \theta \lambda_i} = 1 - \frac{\Delta t \lambda_i}{1 + \Delta t \theta \lambda_i} \quad (4.31)$$

The stability of the numerical time integration scheme can now be investigated by examining the behaviour of this approximation to the exponential. For stability we require

$$-1 \leq 1 - \frac{\Delta t \lambda_i}{1 + \Delta t \theta \lambda_i} \leq 1 \quad (4.32)$$

since this term appears in Equation (4.29) raised to the power  $n$ . The right hand inequality in Equation (4.32) is trivially satisfied, since  $\Delta t$ ,  $\lambda_i$  and  $\theta$  are all positive, and the left hand inequality

FIGURE 4.3: Analytical and numerical solutions of the transient 1D heat equation showing the effects of element size  $\Delta x$  and time step size  $\Delta t$ . The top graph shows the exact and approximate solutions as functions of  $x$  at various times. The lower graphs show the solution through time at the specified  $x$  positions and with various choices of  $\Delta x$  and  $\Delta t$  as indicated.

gives

$$\frac{\Delta t \lambda_i}{1 + \Delta t \theta \lambda_i} \leq 2 \quad \text{or} \quad \Delta t \lambda_i (1 - 2\theta) \leq 2 \quad (4.33)$$

A consequence of Equation (4.33) is that the scheme is *unconditionally stable* if  $\frac{1}{2} \leq \theta \leq 1$ . For  $\theta < \frac{1}{2}$  the *stability criterion* is

$$\Delta t \lambda_i < \frac{2}{1 - 2\theta} \quad (4.34)$$

If the exponential approximation given by Equation (4.31) is negative for any  $\lambda_i$  the solution will contain components which change sign with each time step  $n$ . This *oscillatory noise* can be avoided by choosing

$$\Delta t < \frac{1}{(1 - \theta) \lambda_{\max}}, \quad (4.35)$$

where  $\lambda_{\max}$  is the largest eigenvalue in the matrix  $\mathbf{A}$ , but in practice this imposes a limit which is too severe for  $\Delta t$  and a small amount of oscillatory noise, associated with the high frequency vibration modes of the system, is tolerated. Alternatively the oscillatory noise can be filtered out by averaging.

These theoretical results are explored numerically with a Crank-Nicolson-Galerkin scheme ( $\theta = \frac{1}{2}$ ) in Figure 4.3, where the one-dimensional diffusion equation

$$\frac{\partial u}{\partial t} = D \frac{\partial^2 u}{\partial x^2} \quad \text{on} \quad 0 \leq x \leq 1 \quad (4.36)$$

$$\begin{array}{ll} \text{subject to initial conditions} & u(x, 0) = 0 \\ \text{and boundary conditions} & u(0, t) = 0, u(1, t) = 1 \end{array}$$

is solved for various time increments ( $\Delta t$ ) and element lengths ( $\Delta x$ ) for both linear and cubic Hermite elements.

Decreasing  $\Delta x$  from 0.25 to 0.1 with linear elements produces more oscillation because the system has more degrees of freedom and leads to greater oscillation. At a sufficiently small  $\Delta t$  the oscillations are negligible (bottom right, Figure 4.3). With this value of  $\Delta t$  (0.01 s) the numerical results agree well with the exact solution (top, Figure 4.3) given by

$$u(x, t) = x + \frac{2}{\pi} \sum_{n=1}^{\infty} \frac{(-1)^n}{n} e^{-n^2 \pi^2 t} \sin(n\pi x) \quad (4.37)$$

FIGURE 4.4: Advection-diffusion of a unit mass pulse. The finite element solutions (at  $t=0.01$  s,  $0.05$  s,  $0.2$  s and  $0.4$  s) and finite difference solutions (at  $t=0.4$  s only) are compared with the exact solution.  $\Delta x=0.1$ ,  $\Delta t=0.001$  s for  $0 < t < 0.01$  s and  $\Delta t=0.01$  for  $t \geq 0.01$  s.

## 4.4 Mass lumping

A technique known as *mass lumping* is sometimes used in which the mass matrix  $\mathbf{M}$  is replaced by a diagonal matrix having diagonal terms equal to the row sums. For example, consider the mass matrix (Equation (4.23)) for a bilinear element (see Figure 1.9 and Equation (1.6)).

$$\begin{aligned}
 M_{11} &= \iint (1 - \xi_1)^2 (1 - \xi_2)^2 \xi_1 \xi_2 \, d\xi_1 d\xi_2 = -\frac{(1 - \xi_1)^3}{3} \Big|_0^1 \left( 1 - \frac{(1 - \xi_2)^3}{3} \right) \Big|_0^1 = \frac{1}{3} \cdot \frac{1}{3} = \frac{1}{9} \\
 M_{22} &= \iint \xi_1^2 (1 - \xi_2)^2 \xi_1 \xi_2 \, d\xi_1 d\xi_2 = \frac{1}{3} \cdot \frac{1}{3} = \frac{1}{9} \text{ and similarly } M_{33} \text{ and } M_{44}. \\
 M_{12} &= \iint \xi_1 (1 - \xi_1) (1 - \xi_2)^2 \xi_1 \xi_2 \, d\xi_1 d\xi_2 = \left( -\frac{1}{2} - \frac{1}{3} \right) \cdot \frac{1}{3} = -\frac{1}{18} \\
 M_{13} &= \iint (1 - \xi_1)^2 \xi_2 (1 - \xi_2) \xi_1 \xi_2 \, d\xi_1 d\xi_2 = \frac{1}{18} \text{ and similarly } M_{34} \text{ and } M_{24}. \\
 M_{14} &= \iint \xi_1 (1 - \xi_1) \xi_2 (1 - \xi_2) \xi_1 \xi_2 \, d\xi_1 d\xi_2 = \frac{1}{36} \text{ and similarly } M_{23}.
 \end{aligned}$$

$$\text{therefore } \mathbf{M} = \begin{bmatrix} \frac{1}{9} & \frac{1}{18} & \frac{1}{18} & \frac{1}{36} \\ \frac{1}{18} & \frac{1}{9} & \frac{1}{36} & \frac{1}{18} \\ \frac{1}{18} & \frac{1}{36} & \frac{1}{9} & \frac{1}{18} \\ \frac{1}{36} & \frac{1}{18} & \frac{1}{18} & \frac{1}{9} \end{bmatrix} \xrightarrow{\text{mass lumping}} \begin{bmatrix} \frac{1}{4} & 0 & 0 & 0 \\ 0 & \frac{1}{4} & 0 & 0 \\ 0 & 0 & \frac{1}{4} & 0 \\ 0 & 0 & 0 & \frac{1}{4} \end{bmatrix}$$

The element mass is effectively lumped at the element vertices. Such a scheme has computational advantages when  $\theta = 0$  in Equation (4.26) because each component of the vector  $\mathbf{u}^{n+1}$  is obtained directly without the need to solve a set of coupled equations. This *explicit* time integration scheme, however, is only conditionally stable (see (4.34)) and suffers from *phase lag errors* - see below. For evenly spaced elements the finite element scheme with mass lumping is equivalent to finite differences with central spatial differences.

In Figure 4.4, the finite element and finite differences (lumped f.e. mass matrix) solutions of the one-dimensional advection-diffusion equation (4.20) with  $V = 5 \text{ m s}^{-1}$ ,  $D = 0.1 \text{ m}^2 \text{ s}^{-1}$ ,  $f = 0$  are compared for the propagation and dispersion of an initial unit mass pulse at  $x = 0$ . The length of the solution domain is sufficient to avoid reflected end effects.

The exact solution is a Gaussian distribution whose variance increases with time:

$$u(x, t) = \frac{M}{\sqrt{4\pi Dt}} e^{-\frac{(x - Vt)^2}{4Dt}} \quad (4.38)$$

The finite element solution, using the Crank-Nicolson-Galerkin technique, shows excellent amplitude and phase characteristics when compared with the exact solution. The finite difference,

or lumped mass, solution also using centered time differences, reproduces the amplitude of the pulse very well but shows a slight phase lag.

## 4.5 CMISS Examples

1. To solve for the transient heat flow in a plate run CMISS example 331
2. To investigate the stability of time integration schemes run CMISS examples 3321 and 3322.





# Chapter 5

## Linear Elasticity

### 5.1 Introduction

To analyse the stress in various elastic bodies we calculate the strain energy of the body in terms of nodal displacements and then minimize the strain energy with respect to these parameters - a technique known as the Rayleigh-Ritz. In fact, as we will show later, this leads to the same algebraic equations as would be obtained by the Galerkin method (now equivalent to virtual work) but the physical assumptions made (in neglecting certain strain energy terms) are exposed more clearly in the Rayleigh-Ritz method. We will first consider one-dimensional truss and beam elements, then two-dimensional plane stress and plane strain elements, and finally three-dimensional elasticity.

In all cases the steps are:

1. Evaluate the components of strain in terms of nodal displacements,
2. Evaluate the components of stress from strain using the elastic material constants,
3. Evaluate the strain energy for each element by integrating the products of stress and strain components over the element volume,
4. Evaluate the potential energy from the sum of total strain energy for all elements together with the work done by applied boundary forces,
5. Apply the boundary conditions, *e.g.*, by fixing nodal displacements,
6. Minimize the potential energy with respect to the unconstrained nodal displacements,
7. Solve the resulting system of equations for the unconstrained nodal displacements,
8. Evaluate the stresses and strains using the nodal displacements and element basis functions,
9. Evaluate the boundary reaction forces (or moments) at the nodes where displacement is constrained.

## 5.2 Truss Elements

Consider the one-dimensional truss of undeformed length  $L$  in Figure 3.1 with end points  $(0, 0)$  and  $(x, y)$  and making an angle  $\theta$  with the  $x$ -axis. Under the action of forces in the  $x$ - and  $y$ -directions the right hand end of the truss displaces by  $u$  in the  $x$ -direction and  $v$  in the  $y$ -direction, relative to the left hand end.

FIGURE 5.1: A truss of initial length  $L$  is stretched to a new length  $l$ . Displacements of the right hand end relative to the left hand end are  $u$  and  $v$  in the  $x$ - and  $y$ -directions, respectively.

The new length is  $l$  with axial strain

$$\begin{aligned} e &= \frac{l}{L} - 1 = \frac{\sqrt{(X+u)^2 + (Y+v)^2}}{\sqrt{X^2 + Y^2}} - 1 \\ &= \frac{\sqrt{L^2 + 2(Xu + Yv) + u^2 + v^2}}{L} - 1 \\ &= \sqrt{1 + 2\left(\cos\theta \cdot \frac{u}{L} + \sin\theta \cdot \frac{v}{L}\right) + \frac{u^2 + v^2}{L^2}} - 1 \end{aligned}$$

using  $\frac{X}{L} = \cos\theta$  and  $\frac{Y}{L} = \sin\theta$ , where  $\theta$  is defined to be positive in the anticlockwise direction.

Neglecting second order terms in the binomial expansion  $\sqrt{1 + \varepsilon} = 1 + \frac{1}{2}\varepsilon + O(\varepsilon^2)$ , the strain for small displacements  $u$  and  $v$  is

$$e \cong \cos\theta \cdot \frac{u}{L} + \sin\theta \cdot \frac{v}{L} \quad (5.1)$$

The strain energy associated with this uniaxial stretch is

$$SE = \frac{1}{2} \int \sigma e dV = \frac{1}{2} A \int_0^L \sigma e dx = \frac{1}{2} \int_0^L EAe^2 dx = \frac{1}{2} ALEe^2 \quad (5.2)$$

where  $\sigma = Ee$  is the stress in the truss (of cross-sectional area  $A$ ), linearly related to the strain  $e$  via Young's modulus  $E$ . We now substitute for  $e$  from Equation (5.1) into Equation (5.2) and put  $u = u_2 - u_1$  and  $v = v_2 - v_1$ , where  $(u_1, v_1)$  and  $(u_2, v_2)$  are the nodal displacements of the two ends of the truss

$$SE = \frac{1}{2} ALE \left( \cos\theta \cdot \frac{u_2 - u_1}{L} + \sin\theta \cdot \frac{v_2 - v_1}{L} \right)^2 \quad (5.3)$$

The potential energy is the combined strain energy from all trusses in the structure minus the work done on the structure by external forces. The Rayleigh-Ritz approach is to minimize this potential energy with respect to the nodal displacements once all displacement boundary conditions have been applied.

For example, consider the system of three trusses shown in Figure 5.2. A force of 100 kN is applied in the  $x$ -direction at node 1. Node 2 is a sliding joint and has zero displacement in the

y-direction only. Node 3 is a pivot and therefore has zero displacement in both  $x$ - and  $y$ - directions. The problem is to find all nodal displacements and the stress in the three trusses.

FIGURE 5.2: A system of three trusses.

The strain in truss 1 (joining nodes 1 and 3) is

$$\frac{u_1}{L} \cos 30 + \frac{v_1}{L} \sin 30 = \frac{\sqrt{3}}{2} \frac{u_1}{L} + \frac{1}{2} \frac{v_1}{L}$$

The strain in truss 2 (joining nodes 1 and 2) is

$$\frac{(u_1 - u_2)}{L} \cos 90 + \frac{v_1}{L} \sin 90 = \frac{v_1}{L}$$

The strain in truss 3 (joining nodes 2 and 3) is

$$\frac{u_2}{L} \cos(-30) = \frac{\sqrt{3}}{2} \frac{u_2}{L}$$

Since a force of 100 kN acts at node 1 in the  $x$ -direction, the potential energy is

$$\text{PE} = \sum_{\text{trusses}} \frac{1}{2} A L E e^2 - 100 u_1 = \frac{1}{2} \frac{A E}{L} \left[ \left( \frac{\sqrt{3}}{2} u_1 + \frac{1}{2} v_1 \right)^2 + \left( \frac{\sqrt{3}}{2} u_2 \right)^2 + (v_1)^2 \right] - 100 u_1$$

[Note that if the force was applied in the negative  $x$ -direction, the final term would be  $+100 u_1$ ]

Minimizing the potential energy with respect to the three unknowns  $u_1$ ,  $v_1$  and  $u_2$  gives

$$\frac{\partial \text{PE}}{\partial u_1} = \frac{A E}{L} \left( \frac{\sqrt{3}}{2} u_1 + \frac{1}{2} v_1 \right) \frac{\sqrt{3}}{2} - 100 = 0 \quad (5.4)$$

$$\frac{\partial \text{PE}}{\partial v_1} = \frac{A E}{L} \left[ \left( \frac{\sqrt{3}}{2} u_1 + \frac{1}{2} v_1 \right) \frac{1}{2} + v_1 \right] = 0 \quad (5.5)$$

$$\frac{\partial \text{PE}}{\partial u_2} = \frac{A E}{L} \left( \frac{\sqrt{3}}{2} u_2 \right) \frac{\sqrt{3}}{2} = 0 \quad (5.6)$$

If we choose  $A = 5 \times 10^{-3} \text{ m}^2$ ,  $E = 10 \text{ GPa}$  and  $L = 1 \text{ m}$  (e.g., 100 mm  $\times$  50 mm timber truss) then  $\frac{A E}{L} = 5 \times 10^{-3} \text{ m}^2 \times 10^7 \text{ kPa/m} = 5 \times 10^4 \text{ kN m}^{-1}$ .

Equation (5.6) gives

$$u_2 = 0$$

Equation (5.4) gives

$$3u_1 + \sqrt{3}v_1 = 4 \times 10^2 / (5 \times 10^4)$$

Equation (5.5) gives for two dimensions

$$v_1 = -\frac{\sqrt{3}}{5}u_1$$

Solving these last two equations gives  $u_1 = 3.34$  mm and  $v_1 = -1.15$  mm. Thus the strain in truss 1 is  $(\frac{\sqrt{3}}{2}3.34 - \frac{1}{2}1.15) \times 10^{-3} = 0.232\%$ , in truss 2 is  $-0.115\%$  and in truss 3 is zero.

The tension in truss 1 is  $A\sigma = AEe = 5 \times 10^{-3} \text{ m}^2 10^7 \text{ kPa} \times 0.232 \times 10^{-2} = 116$  kN (tensile), in truss 2 is  $-57.5$  kN (compressive) and in truss 3 is zero. The nodal reaction forces are shown in Figure 5.3.

FIGURE 5.3: Reaction forces for the truss system of Figure 5.2.

### 5.3 Beam Elements

Simple beam theory ignores all but axial strain  $e_x$  and stress  $\sigma_x = Ee_x$  ( $E$  = Young's modulus) along the beam (assumed here to be in the  $x$ -direction). The axial strain is given by  $e_x = \frac{z}{R}$ , where  $z$  is the lateral distance from the neutral axis in the plane of the bending and  $R$  is the radius of curvature in that plane. The bending moment is given by  $M = \int \sigma_x z dA$ , where  $A$  is the beam crosssectional area. Thus

$$\sigma_x = Ee_x = E\frac{z}{R} \quad (5.7)$$

$$M = \int \sigma_x z dA = \frac{E}{R} \int z^2 dA = \frac{EI}{R} \quad (5.8)$$

where  $I = \int z^2 dA$  is the second moment of area of the beam cross-section. Thus,  $\frac{E}{R} = \frac{M}{I}$  and

Equation (5.7) becomes

$$\sigma_x = \frac{Mz}{I} \quad (5.9)$$

The slope of the beam is  $\frac{dw}{dx} = \theta$  and the rate of change of slope is the curvature

$$K = \frac{d\theta}{dx} = \frac{d^2w}{dx^2} = \frac{1}{R} \quad (5.10)$$

Thus the bending moment is

$$M = EI \frac{d^2w}{dx^2} = EIw'' \quad (5.11)$$

and a force balance gives the shear force

$$V = -\frac{dM}{dx} = -\frac{d}{dx} (EIw'') \quad (5.12)$$

and the normal force (per unit length of beam)

$$p = \frac{dV}{dx} = -\frac{d^2}{dx^2} (EIw'') \quad (5.13)$$

This last equation is the equilibrium equation for the beam, balancing the loading forces  $p$  with the axial stresses associated with beam flexure

$$-\frac{d^2}{dx^2} \left( EI \frac{d^2 w}{dx^2} \right) = p \quad (5.14)$$

The elastic strain energy stored in a bent beam is the sum of flexural strain energy and shear strain energy, but this latter is ignored in the simple beam theory considered here. Thus, the (flexural) strain energy is

$$\begin{aligned} \text{SE} &= \frac{1}{2} \int_{x=0}^L \int_A \sigma_x e_x dA dx = \frac{1}{2} \int_{x=0}^L E \int_A e_x^2 dA dx \\ &= \frac{1}{2} \int_{x=0}^L E \int_A \left( \frac{z}{R} \right)^2 dA dx = \frac{1}{2} \int_{x=0}^L EI (w'')^2 dx \end{aligned}$$

where  $x$  is taken along the beam and  $A$  is the cross-sectional area of the beam.

The external work associated with forces  $p$  acting normal to the beam and moving through a transverse displacement  $w$  is  $\int_0^L pw dx$ . The potential energy is therefore

$$\text{PE} = \frac{1}{2} \int_0^L EI (w'')^2 dx - \int_0^L pw dx. \quad (5.15)$$

The finite element approximation for the transverse displacement  $w$  must be able to represent the second derivative  $w''$ . A linear basis function has a zero second derivative and therefore cannot represent the flexural strain. The natural choice of basis function for beam deflection is in fact cubic Hermite because the inter-element slope continuity of this basis ensures transmission of bending moment as well as shear force across element boundaries.

The boundary conditions associated with the 4<sup>th</sup> order equilibrium Equation (5.14) or the equations arising from minimum potential energy Equation (5.15) (which contain the square of 2<sup>nd</sup> derivative terms) are more complex than the simple temperature or flux boundary conditions for the (second order) heat equation. Three possible combinations of boundary condition with their associated reactions are

	<i>Boundary conditions</i>	<i>Reactions</i>
(i) Simply supported	zero displacement $w = 0$ zero moment $M = EIw'' = 0$	shear force $V$ slope $\theta (= w')$
(ii) Cantilever	zero displacement $w = 0$ zero slope $\theta = w' = 0$	shear force $V$ moment $M$
(iii) Free end	zero shear force $V = -\frac{d}{dx}(EIw'') = 0$ zero moment $M = EI'' = 0$	displacement $w$ slope $\theta$

## 5.4 Plane Stress Elements

For two-dimensional problems, we define the displacement vector  $\mathbf{u} = \begin{bmatrix} u \\ v \end{bmatrix}$ , strain vector  $\mathbf{e} =$

$\begin{bmatrix} e_x \\ e_y \\ e_{xy} \end{bmatrix}$  and stress vector  $\boldsymbol{\sigma} = \begin{bmatrix} \sigma_x \\ \sigma_y \\ \sigma_{xy} \end{bmatrix}$ . The stress-strain relation for two-dimensional plane stress:

$$\begin{aligned}\sigma_x &= \frac{E}{1-\nu^2} (e_x + \nu e_y) \\ \sigma_y &= \frac{E}{1-\nu^2} (e_y + \nu e_x) \\ \sigma_{xy} &= \frac{E}{1+\nu} (e_{xy})\end{aligned}\tag{5.16}$$

can be written in matrix form

$$\boldsymbol{\sigma} = \mathbf{E}\mathbf{e}$$

where  $\mathbf{E} = \frac{E}{1-\nu^2} \begin{bmatrix} 1 & \nu & 0 \\ \nu & 1 & 0 \\ 0 & 0 & 1-\nu \end{bmatrix}$ . The strain components are given in terms of displacement gradients by

$$\begin{aligned}e_x &= \frac{\partial u}{\partial x} \\ e_y &= \frac{\partial v}{\partial y} \\ e_{xy} &= \frac{1}{2} \left( \frac{\partial u}{\partial y} + \frac{\partial v}{\partial x} \right)\end{aligned}\tag{5.17}$$

The strain energy is

$$\begin{aligned}\text{SE} &= \frac{1}{2} \int_V \boldsymbol{\sigma}^T \mathbf{e} \, dV = \frac{1}{2} \int_V (e_x \sigma_x + e_y \sigma_y + e_{xy} \sigma_{xy}) \, dV \\ &= \frac{1}{2} \int_V \mathbf{e}^T \mathbf{E} \mathbf{e} \, dV = \frac{1}{2} \int_V \frac{E}{1-\nu^2} [e_x^2 + e_y^2 + 2\nu e_x e_y + (1-\nu) e_{xy}^2] \, dV\end{aligned}$$

The potential energy is

$$\text{PE} = \text{SE} - \text{external work} = \frac{1}{2} \int_V \mathbf{e}^T \mathbf{E} \mathbf{e} dV - \int_A \mathbf{u}^T \mathbf{l} dA \quad (5.18)$$

where  $\mathbf{l}$  represents the external loads (forces) acting on the elastic body.

Following the steps outlined in Section 5.1 we approximate the displacement field  $\mathbf{u}$  with a finite element basis  $u = \varphi_n u_n$ ,  $v = \varphi_n v_n$  and calculate the strains

$$\begin{aligned} e_x &= \frac{\partial u}{\partial x} = \frac{\partial \varphi_n}{\partial x} u_n \\ e_y &= \frac{\partial v}{\partial y} = \frac{\partial \varphi_n}{\partial y} v_n \\ e_{xy} &= \frac{1}{2} \left( \frac{\partial u}{\partial y} + \frac{\partial v}{\partial x} \right) = \frac{1}{2} \left( \frac{\partial \varphi_n}{\partial y} u_n + \frac{\partial \varphi_n}{\partial x} v_n \right) \end{aligned} \quad (5.19)$$

or

$$\mathbf{e} = \begin{bmatrix} e_x \\ e_y \\ e_{xy} \end{bmatrix} = \begin{bmatrix} \frac{\partial \varphi_n}{\partial x} & 0 \\ 0 & \frac{\partial \varphi_n}{\partial y} \\ \frac{1}{2} \frac{\partial \varphi_n}{\partial y} & \frac{1}{2} \frac{\partial \varphi_n}{\partial x} \end{bmatrix} \begin{bmatrix} u_n \\ v_n \end{bmatrix} = \mathbf{B} \mathbf{u} \quad (5.20)$$

From Equation (5.18) the potential energy is therefore

$$\begin{aligned} \text{PE} &= \frac{1}{2} \int_V (\mathbf{B} \mathbf{u})^T \mathbf{E} (\mathbf{B} \mathbf{u}) dV - \int_A \mathbf{u}^T \mathbf{l} dA \\ &= \frac{1}{2} \mathbf{u}^T \left[ \int_V \mathbf{B}^T \mathbf{E} \mathbf{B} dV \right] \mathbf{u} - \int_A \mathbf{u}^T \mathbf{l} dA \\ &= \frac{1}{2} \mathbf{u}^T \mathbf{K} \mathbf{u} - \int_A \mathbf{u}^T \mathbf{l} dA \end{aligned}$$

where  $\mathbf{K} = \int_V \mathbf{B}^T \mathbf{E} \mathbf{B} dV$  is the element stiffness matrix.

We next minimize the potential energy with respect to the nodal parameters  $u_n$  and  $v_n$  giving

$$\mathbf{K} \mathbf{u} = \mathbf{f} \quad (5.21)$$

where  $\mathbf{f} = \int_A \mathbf{l} dA$  is a vector of nodal forces.

### 5.4.1 Notes on calculating nodal loads

If a known stress acts normal to a given surface (*e.g.*, a surface pressure), it may be applied by calculating equivalent nodal forces. For example, consider a uniform load  $p \text{ kN m}^{-1}$  applied to the edge of the plane stress element in Figure 5.4a.

The nodal load vector  $\mathbf{f}$  in Equation (5.21) has components

$$f_n = \int_x p \varphi_n dx = pL \int_0^1 \varphi_n d\xi \quad (5.22)$$

where  $\xi$  is the normalized element coordinate along the side of length  $L$  loaded by the constant stress  $p \text{ kN m}^{-1}$ . If the element side has a linear basis, Equation (5.22) gives

$$\begin{aligned} f_1 &= pL \int_0^1 \varphi_1 d\xi = pL \int_0^1 (1 - \xi) d\xi = \frac{1}{2}pL \\ f_2 &= pL \int_0^1 \varphi_2 d\xi = pL \int_0^1 \xi d\xi = \frac{1}{2}pL \end{aligned}$$

as shown in Figure 5.4b. If the element side has a quadratic basis, Equation (5.22) gives

$$\begin{aligned} f_1 &= pL \int_0^1 \varphi_1 d\xi = pL \int_0^1 2 \left( \frac{1}{2} - \xi \right) (1 - \xi) d\xi = \frac{1}{6}pL \\ f_2 &= pL \int_0^1 \varphi_2 d\xi = pL \int_0^1 4\xi (1 - \xi) d\xi = \frac{2}{3}pL \\ f_3 &= pL \int_0^1 \varphi_3 d\xi = pL \int_0^1 2\xi \left( \xi - \frac{1}{2} \right) d\xi = \frac{1}{6}pL \end{aligned}$$

as shown in Figure 5.4c. A node common to two elements will receive contributions from both elements, as shown in Figure 5.4d.

FIGURE 5.4: A uniform boundary stress applied to the element side in (a) is equivalent to nodal loads of  $\frac{1}{2}pL$  and  $\frac{1}{2}pL$  for the linear basis used in (b) and to  $\frac{1}{6}pL$ ,  $\frac{2}{3}pL$  and  $\frac{1}{6}pL$  for the quadratic basis used in (c). Two adjacent quadratic elements both contribute to a common node in (d), where the element length is now  $\frac{L}{2}$ .



## 5.5 Three-Dimensional Elasticity

Consider a surface  $\Gamma$  enclosing a volume  $\Omega$  of material of mass density  $\rho$ . Conservation of linear momentum over the domain  $\Omega$  results in the governing stress equilibrium equations

$$\sigma_{ij,j} + b_i = 0 \quad i, j = 1, 2, 3 \quad (5.23)$$

where  $\sigma_{ij}$  are the components of the stress tensor ( $\sigma_{ij}$  is the component of the traction or stress vector in the  $i^{\text{th}}$  direction which is acting on the face of a rectangle whose normal is in the  $j^{\text{th}}$  direction), and  $b_i$  is the body force/unit volume (*e.g.*,  $\mathbf{b} = \rho\mathbf{g}$ ). Note that the notation  $\sigma_{ij,j} = \frac{\partial \sigma_{ij}}{\partial x_j}$  has been introduced to represent the derivative.

Recall that the components of the linear (or small) strain tensor are

$$e_{ij} = \frac{1}{2} (u_{i,j} + u_{j,i}) \quad i, j = 1, 2, 3 \quad (5.24)$$

where  $\mathbf{u}$  is the displacement vector (*i.e.*,  $\mathbf{u}$  is the difference between the final and initial positions of a material point in question). Note: we are assuming here that the displacement gradients are small compared to unity, which is appropriate for many materials in solid mechanics. However, for soft materials, such as rubber or biological tissue, then we need to use the exact finite strain tensor.

The object of solving an elasticity problem is to find the distributions of stress and displacement in an elastic body, subject to a known set of body forces and prescribed stresses or displacements at the boundaries. In the general three-dimensional case, this means finding 6 stress components  $\sigma_{ij}$  ( $= \sigma_{ji}$  which arises from the conservation of angular momentum) and 3 displacements  $u_i$  each as a function of position in the body. Currently we have 15 unknowns (6 stresses, 6 strains and 3 displacements), but only 9 equations (3 equilibrium equations and 6 strain-displacement relations).

To progress, we require an equation of state, *i.e.*, a stress-strain relation or constitutive law. For a linear elastic material we may propose that the components of stress  $\sigma_{ij}$  depend linearly on  $e_{ij}$ . *i.e.*,

$$\sigma_{ij} = c_{ijkl} e_{kl}$$

where  $c_{ijkl}$  are the 81 components of a 4<sup>th</sup> order tensor, although symmetry of the strain and stress tensors reduces the number of independent components to 21.

If the material is assumed to be isotropic (*i.e.*, the material response is independent of orientation of the material element), then we end up with the generalized Hooke's Law.

$$\sigma_{ij} = \lambda e_{kk} \delta_{ij} + 2\mu e_{ij} \quad (5.25)$$

or inversely

$$e_{ij} = \frac{1}{2\mu} \sigma_{ij} - \frac{\lambda}{2\mu(3\lambda + 2\mu)} \sigma_{kk} \delta_{ij}$$

where  $\lambda, \mu$  are Lamé's constants.

Note:  $\lambda, \mu$  are related to Young's modulus  $E$  and Poisson's ratio  $\nu$  by

$$E = \frac{\mu(3\lambda + 2\mu)}{\lambda + \mu}$$

$$\nu = \frac{\lambda}{2(\lambda + \mu)}$$

Providing that the displacements are continuous functions of position, then Equation (5.23), Equation (5.24) and Equation (5.25) are sufficient to determine the 15 unknown quantities. This can often work with some smaller grouping or simplification of these equations, *e.g.*, if all boundary conditions are expressed in terms of displacements, substituting Equation (5.24) into Equation (5.25) then into Equation (5.23) yields Navier's equation of motion.

$$\mu u_{i,kk} + (\lambda + \mu) u_{k,ki} + b_i = 0 \quad i, k = 1, 2, 3$$

These 3 equations can be solved for the unknown displacements. Then Equation (5.24) can be used to determine the strains and Equation (5.25) to calculate the stresses.

### 5.5.1 Weighted Residual Integral Equation

Using weighted residuals as before we can write

$$\int_{\Omega} (\sigma_{ij,j} + b_i) u_i^* d\Omega = 0 \quad (5.26)$$

where  $\mathbf{u}^* = (u_i^*)$  is a (vector) weighting field. The  $u_i^*$  are usually interpreted as a consistent set of virtual displacements (hence we use the notation  $u$  instead of  $w$ ).

By the chain-rule

$$(\sigma_{ij} u_i^*)_{,j} = \sigma_{ij,j} u_i^* + \sigma_{ij} u_{i,j}^*$$

Therefore, the first term in the integrand of Equation (5.26) can be re-written

$$\begin{aligned} \int_{\Omega} \sigma_{ij,j} u_i^* d\Omega &= \int_{\Omega} (\sigma_{ij} u_i^*)_{,j} d\Omega - \int_{\Omega} \sigma_{ij} u_{i,j}^* d\Omega \\ &= \int_{\Omega} \nabla \cdot (\sigma_{ij} u_i^*) d\Omega - \int_{\Omega} \sigma_{ij} u_{i,j}^* d\Omega \\ &= \int_{\partial\Omega} \sigma_{ij} u_i^* n_j d\Gamma - \int_{\Omega} \sigma_{ij} u_{i,j}^* d\Omega \end{aligned} \quad (5.27)$$

where the domain integral involving “ $\nabla \cdot = \frac{\partial}{\partial x_j}$ ” has been transformed into a surface integral using the divergence theorem

$$\int_{\Omega} \nabla \cdot \mathbf{g} d\Omega = \int_{\partial\Omega} \mathbf{g} \cdot \mathbf{n} d\Gamma \quad \text{or} \quad \int_{\Omega} g_{j,j} d\Omega = \int_{\partial\Omega} g_j n_j d\Gamma$$

where  $\mathbf{n} = n_j \mathbf{i}_j$  is the outward normal vector to the surface  $\Gamma$ .

Thus, combining Equation (5.26) and Equation (5.27) we have

$$\begin{aligned} \int_{\Omega} \sigma_{ij} u_{i,j}^* d\Omega &= \int_{\Omega} b_i u_i^* d\Omega + \int_{\partial\Omega} \sigma_{ij} n_j u_i^* d\Gamma \\ &= \int_{\Omega} b_i u_i^* d\Omega + \int_{\partial\Omega} t_i u_i^* d\Gamma \end{aligned} \quad (5.28)$$

where  $t_i$  are the components of the internal stress vector ( $\mathbf{t}$ ) and are related to the components of the stress tensor ( $\sigma_{ij}$ ) by Cauchy's formula

$$\mathbf{t} = \sigma_{ij} n_j \mathbf{i}_i \quad (5.29)$$

To arrive at this point, we have used weighted residuals to tie in with Chapter 2, however Equation (5.28) is more usually derived using the principle of virtual work (below). Note that the weighted integral Equation (5.28) is independent of the constitutive law of the material.

### 5.5.2 The Principle of Virtual Work

The governing equations for elastostatics can also be derived from a physically appealing argument. Let  $\mathbf{s}$  be the external traction vector (*i.e.*, force per unit surface area). For equilibrium, the work done by the external surface forces  $\mathbf{s} = s_i \mathbf{i}_i$ , in moving through a virtual displacement  $\mathbf{u}^* = u_i^* \mathbf{i}_i$  is equal to the work done by the stress vector  $\mathbf{t} = t_i \mathbf{i}_i$  in moving through a compatible set of virtual displacements  $\mathbf{u}^*$ . In mathematical terms, the principle of virtual work can be written

$$\int_{\partial\Omega} s_i u_i^* d\Gamma = \int_{\partial\Omega} t_i u_i^* d\Gamma = \int_{\partial\Omega} \sigma_{ij} n_j u_i^* d\Gamma \quad (5.30)$$

using Cauchy's formula (Equation (5.29)).

The Green-Gauss theorem (Equation (2.15)) is now used to replace the right hand surface integral in Equation (5.30) by a volume integral, giving

$$\int_{\partial\Omega} s_i u_i^* d\Gamma = \int_{\Omega} (\sigma_{ij,j} u_i^* + \sigma_{ij} u_{i,j}^*) d\Omega \quad (5.31)$$

Substituting the equilibrium relation (Equation (5.23)) into the first integrand on the right hand side, yields the *virtual work* equation

$$\int_{\Omega} \sigma_{ij} u_{i,j}^* d\Omega = \int_{\Omega} b_i u_i^* d\Omega + \int_{\partial\Omega} s_i u_i^* d\Gamma \quad (5.32)$$

where the internal work done due to the stress field is equated to the work due to internal body forces and external surface forces. Note that Equation (5.32) is equivalent to Equation (5.28) via Equation (5.30). In practice, Equation (5.32) is in a more useful form than Equation (5.28), because

the right hand side integrals can be expressed in terms of the known body forces and the applied boundary conditions (surface traction forces or stresses).

### 5.5.3 The Finite Element Approximation

Let  $\Omega = \bigcup \Omega_e$  and interpolate the virtual displacements  $u_i^*$  from their nodal values. *i.e.*,

$$\begin{aligned} u_i^* &= \varphi_m (\dot{u}_i^m)^* \\ \text{so } u_{i,j}^* &= \frac{\partial \varphi_m}{\partial x_j} (\dot{u}_i^m)^* \\ &= \varphi_{m,k} \frac{\partial \xi_k}{\partial x_j} (\dot{u}_i^m)^* \end{aligned} \quad (5.33)$$

where  $(u_i^m)^* = (U_i^{\Delta(m,e)})^*$ ,  $\Delta(m,e)$  is the global node number of local node  $m$  on element  $e$ , and the shorthand  $\varphi_{m,k} = \frac{\partial \varphi_m}{\partial \xi_k}$  has been introduced.

Substituting this into Equation (5.32) gives

$$\sum_e \left( \int_{\Omega_e} \sigma_{ij} \varphi_{m,k} \frac{\partial \xi_k}{\partial x_j} d\Omega \right) (U_i^{\Delta(m,e)})^* = \sum_e \left( \int_{\Omega_e} b_i \varphi_m d\Omega + \int_{\partial\Omega_e} s_i \varphi_m d\Gamma \right) (U_i^{\Delta(m,e)})^*$$

and since the virtual displacements are arbitrary we get

$$\sum_e \int_{\Omega_e} \sigma_{ij} \varphi_{m,k} \frac{\partial \xi_k}{\partial x_j} d\Omega = \sum_e \left( \int_{\Omega_e} b_i \varphi_m d\Omega + \int_{\partial\Omega_e} s_i \varphi_m d\Gamma \right) \quad (5.34)$$

The next step is to express the stress components  $\sigma_{ij}$  in terms of the virtual displacements and their finite element approximation by substituting Equation (5.33) into Equation (5.24) (the strain-displacement relation) and in turn into Equation (5.25) (the generalized Hooke's law).

We first introduce the finite element approximation for the displacement field  $u_j = \varphi_n u_j^n$  which gives

$$e_{ij} = \frac{1}{2} \left( \frac{\partial}{\partial x_j} (\varphi_n u_i^n) + \frac{\partial}{\partial x_i} (\varphi_n u_j^n) \right) = \frac{1}{2} \left( \frac{\partial \varphi_n}{\partial \xi_l} \frac{\partial \xi_l}{\partial x_j} u_i^n + \frac{\partial \varphi_n}{\partial \xi_l} \frac{\partial \xi_l}{\partial x_i} u_j^n \right) \quad (5.35)$$

and

$$e_{kk} = u_{k,k} = \frac{\partial \varphi_n}{\partial \xi_l} \frac{\partial \xi_l}{\partial x_k} u_k^n$$

Thus

$$\sigma_{ij} = \lambda \delta_{ij} \frac{\partial \varphi_n}{\partial \xi_l} \frac{\partial \xi_l}{\partial x_k} u_k^n + 2\mu \left( \frac{1}{2} \frac{\partial \varphi_n}{\partial \xi_l} \frac{\partial \xi_l}{\partial x_j} u_i^n + \frac{1}{2} \frac{\partial \varphi_n}{\partial \xi_l} \frac{\partial \xi_l}{\partial x_i} u_j^n \right)$$

which, due to symmetry of the stress tensor, simplifies to

$$\begin{aligned}\sigma_{ij} &= \lambda \delta_{ij} \frac{\partial \varphi_n}{\partial \xi_l} \frac{\partial \xi_l}{\partial x_k} u_k^n + 2\mu \frac{\partial \varphi_n}{\partial \xi_l} \frac{\partial \xi_l}{\partial x_i} u_j^n \\ &= \left( \lambda \delta_{i(j)} \varphi_{n,l} \frac{\partial \xi_l}{\partial x_j} + 2\mu \varphi_{n,l} \frac{\partial \xi_l}{\partial x_i} \right) u_j^n\end{aligned}\quad (5.36)$$

where the summation index  $k$  has been replaced with  $j$ , but the parenthesis in  $\delta_{i(j)}$  implies that there is no sum with respect to that particular index.

Substituting this expression into Equation (5.34) and simplifying, we get for each element

$$u_j^n \int_{\Omega_e} \left( \lambda \varphi_{n,l} \frac{\partial \xi_l}{\partial x_j} \varphi_{m,k} \frac{\partial \xi_k}{\partial x_i} + 2\mu \varphi_{n,l} \frac{\partial \xi_l}{\partial x_i} \varphi_{m,k} \frac{\partial \xi_k}{\partial x_j} \right) d\Omega = f_{im} \quad (5.37)$$

where  $f_{im}$  denotes the right hand side terms in Equation (5.34). (Note that there has been some careful manipulation of summation indices with the substitution of Equation (5.36) to arrive at Equation (5.37).)

So for each element

$$E_{imjn} u_j^n = f_{im}$$

where

$$\begin{aligned}E_{imjn} &= \int_0^1 \int_0^1 \int_0^1 \left( \lambda \frac{\partial \xi_l}{\partial x_j} \frac{\partial \xi_k}{\partial x_i} + 2\mu \frac{\partial \xi_l}{\partial x_i} \frac{\partial \xi_k}{\partial x_j} \right) \varphi_{n,l} \varphi_{m,k} J(\xi_1, \xi_2, \xi_3) d\xi_1 d\xi_2 d\xi_3 \\ f_{im} &= \int_0^1 \int_0^1 \int_0^1 b_i \varphi_m J(\xi_1, \xi_2, \xi_3) d\xi_1 d\xi_2 d\xi_3 + \int_0^1 \int_0^1 s_i \varphi_m J_{2D}(\xi_1, \xi_2) d\xi_1 d\xi_2\end{aligned}\quad (5.38)$$

where the Jacobians  $J(\xi_1, \xi_2, \xi_3)$  and  $J_{2D}(\xi_1, \xi_2)$  have been used to transform volume and surface integrals so that they can be calculated using  $\xi$ -coordinates. (Note: without loss of generality, the above definition of  $f_{im}$  assumes that  $(\xi_1, \xi_2)$  are defined to lie in the surface  $\Gamma$ .)

So in summary, the finite element approximation leads to element stiffness matrix components that can be calculated from the known material parameters, the chosen interpolation functions, and the geometry of the material (note that the element stiffness components are independent of the unknown displacement parameters). Element stiffness components are then assembled into the global stiffness matrix in the usual manner (as described previously). Note that this is implicitly a Galerkin formulation, since the unknown displacement fields are interpolated using the same basis functions as those used to weight the integral equations.

## 5.6 Linear Elasticity with Boundary Elements

Equation (5.28) is the starting point for the general finite element formulation (Section 5.5). In the above derivation, we have essentially used the Green-Gauss theorem once to move from Equation (5.26) to Equation (5.28) (as was done for the derivation of the FEM equation for Laplace's

equation). To continue, we firstly note that

$$\begin{aligned}
 \sigma_{ij}e_{ij}^* &= \frac{1}{2}\sigma_{ij}u_{i,j}^* + \frac{1}{2}\sigma_{ij}u_{j,i}^* \\
 &= \frac{1}{2}\sigma_{ij}u_{i,j}^* + \frac{1}{2}\sigma_{ji}u_{j,i}^* \\
 &= \frac{1}{2}\sigma_{ij}u_{i,j}^* + \frac{1}{2}\sigma_{ij}u_{i,j}^* \\
 &= \sigma_{ij}u_{i,j}^*
 \end{aligned}$$

where  $e_{ij}^*$  are the virtual strains corresponding to the virtual displacements.

Using the constitutive law for linearly elastic materials (Equation (5.25)) we have

$$\begin{aligned}
 \int_{\Omega} \sigma_{ij}u_{i,j}^* d\Omega &= \int_{\Omega} \sigma_{ij}e_{ij}^* d\Omega \\
 &= \lambda \int_{\Omega} e_{kk}e_{ij}^*\delta_{ij} d\Omega + 2\mu \int_{\Omega} e_{ij}e_{ij}^* d\Omega \\
 &= \lambda \int_{\Omega} e_{kk}e_{kk}^* d\Omega + 2\mu \int_{\Omega} e_{ij}e_{ij}^* d\Omega \\
 &= \int_{\Omega} e_{ij}\sigma_{ij}^* d\Omega
 \end{aligned}$$

due to symmetry.

Thus from the virtual work statement, Equation (5.28) and the above symmetry we have

$$\int_{\Omega} b_i u_i^* d\Omega + \int_{\partial\Omega} t_i u_i^* d\Gamma = \int_{\Omega} b_i^* u_i d\Omega + \int_{\partial\Omega} t_i^* u_i d\Gamma \quad (5.39)$$

This is known as Betti's second reciprocal work theorem or the Maxwell-Betti reciprocity relationship between two different elastic problems (the starred and unstarred variables) established on the same domain.

Note that  $b_i^* = -\sigma_{ij,j}^*$  (i.e.,  $\sigma_{ij,j}^* + b_i^* = 0$ ). Therefore Equation (5.39) can be written as

$$\int_{\Omega} (\sigma_{ij,j}^*) u_i d\Omega + \int_{\Omega} b_i u_i^* d\Omega = \int_{\partial\Omega} t_i^* u_i d\Gamma - \int_{\partial\Omega} t_i u_i^* d\Gamma \quad (5.40)$$

( $\sigma_{ij}^*, e_{ij}^*, t_i^*$  represents the equilibrium state corresponding to the virtual displacements  $u_i^*$ ).

Note: What we have essentially done is use integration of parts to get Equation (5.28), then use it again to get Equation (5.39) above (after noting the reciprocity between  $\sigma_{ij}$  and  $e_{ij}$ ).

Since the body forces,  $b_i$ , are known functions, the second domain integral on the left hand side of Equation (5.40) does not introduce any unknowns into the problem (more about this later).

The first domain integral contains unknown displacements in  $\Omega$  and it is this integral we wish to remove.

We choose the virtual displacements such that

$$\sigma_{ij,j}^* + e_i \delta = 0 \quad (5.41)$$

(or equivalently  $-b_i^* + e_i \delta = 0$ ), where  $e_i$  is the  $i^{\text{th}}$  component of a unit vector in the  $i^{\text{th}}$  direction and  $e_i \delta = e_i \delta(\mathbf{x} - P)$ . We can interpret this as the body force components which correspond to a positive unit point load applied at a point  $P \in \Omega$  in each of the three orthogonal directions.

Therefore

$$\int_{\Omega} \sigma_{ij,j}^* u_i d\Omega = - \int_{\Omega} \delta(\mathbf{x} - P) e_i u_i d\Omega = -u_i(P) e_i$$

i.e., the volume integral is replaced with a point value (as for Laplace's equation).

Therefore, Equation (5.40) becomes

$$u_i(P) e_i = \int_{\partial\Omega} t_j u_j^* d\Gamma - \int_{\partial\Omega} t_j^* u_j d\Gamma + \int_{\Omega} b_j u_j^* d\Omega \quad P \in \Omega \quad (5.42)$$

If each point load is taken to be independent then  $u_j^*$  and  $t_j^*$  can be written as

$$u_j^* = u_{ij}^*(P, x) e_i \quad (5.43)$$

$$t_j^* = t_{ij}^*(P, x) e_i \quad (5.44)$$

where  $u_{ij}^*(P, x)$  and  $t_{ij}^*(P, x)$  represent the displacements and tractions in the  $j^{\text{th}}$  direction at  $x$  corresponding to a unit point force acting in the  $i^{\text{th}}$  direction ( $e_i$ ) applied at  $P$ . Substituting these into Equation (5.42) (and equating components in each  $e_i$  direction) yields

$$u_i(P) = \int_{\partial\Omega} u_{ij}^*(P, x) t_j(x) d\Gamma(x) - \int_{\partial\Omega} t_{ij}^*(P, x) u_j(x) d\Gamma(x) + \int_{\Omega} u_{ij}^*(P, x) b_j(x) d\Omega(x) \quad (5.45)$$

where  $P \in \Omega$  (see later for  $P \in \partial\Omega$ ).

This is known as Somigliana's <sup>1</sup> identity for displacement.

## 5.7 Fundamental Solutions

Recall from Equation (5.41) that  $\sigma_{ij}^*$  satisfied

$$\sigma_{ij,j}^* + \delta(\mathbf{x} - P) e_i = 0 \quad (5.46)$$

<sup>1</sup>Somigliana was an Italian Mathematician who published this result around 1894-1902.

or equivalently

$$b_i^* = e_i \delta (\mathbf{x} - P)$$

Navier's equation for the displacements  $u_i^*$  is

$$G u_{i,kk}^* + \frac{G}{1-2\nu} u_{k,ki}^* + b_i^* = 0$$

where  $G$  = shear Modulus.

Thus  $u_i^*$  satisfy

$$G u_{i,kk}^* + \frac{G}{1-2\nu} u_{k,ki}^* + \delta (\mathbf{x} - P) e_i = 0 \quad (5.47)$$

The solutions to the above equation in either two or three dimensions are known as Kelvin<sup>2</sup>'s fundamental solutions and are given by

$$u_{ij}^* (P, \mathbf{x}) = \frac{1}{16\pi (1-\nu) G r} \{ (3-4\nu) \delta_{ij} + r_{,i} r_{,j} \} \quad (5.48)$$

for three-dimensions and for two-dimensional plane strain problems,

$$u_{ij}^* (P, \mathbf{x}) = \frac{-1}{8\pi (1-\nu) G} \{ (3-4\nu) \delta_{ij} \log r - r_{,i} r_{,j} \} \quad (5.49)$$

and

$$t_{ij}^* (P, \mathbf{x}) = \frac{-1}{4\alpha\pi (1-\nu) r^\alpha} \left\{ ((1-2\nu) \delta_{ij} + \beta r_{,i} r_{,j}) \frac{\partial r}{\partial n} - (1-2\nu) (r_{,i} n_j - r_{,j} n_i) \right\} \quad (5.50)$$

where  $\alpha = 1, 2; \beta = 2, 3$  for two-dimensional plane strain and three-dimensional problems respectively.

Here  $r \equiv r(P, \mathbf{x})$ , the distance between load point ( $P$ ) and field point ( $\mathbf{x}$ ),  $r_i = x_i(\mathbf{x}) - x_i(P)$  and  $r_{,i} = \frac{\partial r}{\partial x_i} = \frac{r_i}{r}$ .

In addition the strains at an point  $\mathbf{x}$  due to a unit point load applied at  $P$  in the  $i^{\text{th}}$  direction are given by

$$e_{jki}^* (P, \mathbf{x}) = \frac{-1}{8\alpha\pi (1-\nu) G r^\alpha} \{ (1-2\nu) (r_{,k} \delta_{ij} + r_{,j} \delta_{ik}) - r_{,i} \delta_{jk} + \beta r_{,i} r_{,j} r_{,k} \}$$

and the stresses are given by

$$\sigma_{ijk}^* (P, \mathbf{x}) = \frac{-1}{4\alpha\pi (1-\nu) r^\alpha} \{ (1-2\nu) (r_{,k} \delta_{ij} + r_{,j} \delta_{ki} - r_{,i} \delta_{jk}) + \beta r_{,i} r_{,j} r_{,k} \}$$

where  $\alpha$  and  $\beta$  are defined above.

The plane strain expressions are valid for plane stress if  $\nu$  is replaced by  $\bar{\nu} = \frac{\nu}{1+\nu}$  (This is a mathematical equivalence of plane stress and plane strain - there are obviously physical differences.

<sup>2</sup>Lord Kelvin (1824-1907) Scottish physicist who made great contributions to the science of thermodynamics



What the mathematical equivalence allows us to do is to use one program to solve both types of problems - all we have to do is modify the values of the elastic constants).

Note that in three dimensions

$$u_{ij}^* = O\left(\frac{1}{r}\right) \quad t_{ij}^* = O\left(\frac{1}{r^2}\right)$$

and for two dimensions

$$u_{ij}^* = O(\log r) \quad t_{ij}^* = O\left(\frac{1}{r}\right).$$

Somigliana's identity (Equation (5.45)) is a continuous representation of displacements at any point  $P \in \Omega$ . Consequently, one can find the stress at any  $P \in \Omega$  firstly by combining derivatives of (5.45) to produce the strains and then substituting into Hooke's law. Details can be found in Brebbia:1984 pp 190–191, 255–258.

This yields

$$\begin{aligned} \sigma_{ij}(P) = & \int_{\Gamma} u_{ijk}^*(P, \mathbf{x}) t_k(\mathbf{x}) d\Gamma(\mathbf{x}) - \int_{\Gamma} t_{ijk}^*(P, \mathbf{x}) u_k(\mathbf{x}) d\Gamma(\mathbf{x}) \\ & + \int_{\Omega} u_{ijk}^*(P, \mathbf{x}) b_k(\mathbf{x}) d\Omega(\mathbf{x}) \end{aligned}$$

Note: One can find internal stress via numerical differentiation as in FE/FD but these are not as accurate as the above expressions.

Expressions for the new tensors  $u_{ijk}^*$  and  $t_{ijk}^*$  are on page 191 in [?].

## 5.8 Boundary Integral Equation

Just as we did for Laplace's equation we need to consider the limiting case of Equation (5.45) as  $P$  is moved to  $\partial\Omega$ . (*i.e.*, we need to find the equivalent of  $c(P)$  (in section 3) - called here  $c_{ij}(P)$ .) We use the same procedure as for Laplace's equation but here things are not so easy.

If  $P \in \partial\Omega$  we enlarge  $\Omega$  to  $\Omega'$  as shown.

FIGURE 5.5: Illustration of enlarged domain when singular point is on the boundary.

Then Equation (5.45) can be written as

$$\begin{aligned} u_i(P) = & \int_{\Gamma_{-\varepsilon} + \Gamma_{\varepsilon}} u_{ij}^*(P, \mathbf{x}) t_j(\mathbf{x}) d\Gamma(\mathbf{x}) - \int_{\Gamma_{-\varepsilon} + \Gamma_{\varepsilon}} t_{ij}^*(P, \mathbf{x}) u_j(\mathbf{x}) d\Gamma(\mathbf{x}) \\ & + \int_{\Omega'} u_{ij}^*(P, \mathbf{x}) b_j(\mathbf{x}) d\Omega(\mathbf{x}) \quad (5.51) \end{aligned}$$

We need to look at each integral in turn as  $\varepsilon \downarrow 0$  (i.e.,  $\varepsilon \rightarrow 0$  from above). The only integral that presents a problem is the second integral. This can be written as

$$\int_{\Gamma_{-\varepsilon} + \Gamma_{\varepsilon}} t_{ij}^*(P, \mathbf{x}) u_j(\mathbf{x}) d\Gamma(\mathbf{x}) = \int_{\Gamma_{\varepsilon}} t_{ij}^*(P, \mathbf{x}) u_j(\mathbf{x}) d\Gamma(\mathbf{x}) + \int_{\Gamma_{-\varepsilon}} t_{ij}^*(P, \mathbf{x}) u_j(\mathbf{x}) d\Gamma(\mathbf{x}) \quad (5.52)$$

The first integral on the right hand side can be written as

$$\int_{\Gamma_{\varepsilon}} t_{ij}^*(P, \mathbf{x}) u_j(\mathbf{x}) d\Gamma(\mathbf{x}) = \underbrace{\int_{\Gamma_{\varepsilon}} t_{ij}^*(P, \mathbf{x}) [u_j(\mathbf{x}) - u_j(P)] d\Gamma(\mathbf{x})}_{0 \text{ by continuity of } u_j(\mathbf{x})} + u_j(P) \int_{\Gamma_{\varepsilon}} t_{ij}^*(P, \mathbf{x}) d\Gamma(\mathbf{x}) \quad (5.53)$$

Let

$$c_{ij}(P) = \delta_{ij} + \lim_{\varepsilon \downarrow 0} \int_{\Gamma_{\varepsilon}} t_{ij}^*(P, \mathbf{x}) d\Gamma(\mathbf{x}) \quad (5.54)$$

As  $\varepsilon \downarrow 0$ ,  $\Gamma_{-\varepsilon} \rightarrow \Gamma$  and we write the second integral of Equation (5.52) as  $\int_{\Gamma} t_{ij}^*(P, \mathbf{x}) u_j(\mathbf{x}) d\Gamma(\mathbf{x})$

where we interpret this in the Cauchy Principal Value<sup>3</sup>sense.

---

<sup>3</sup>What is a Cauchy Principle Value?

Consider  $f(x) = \frac{1}{x}$  on  $\Gamma_{-\varepsilon} = [-2, -\varepsilon] \cup (\varepsilon, 2]$

Then

$$\begin{aligned} \int_{\Gamma_{-\varepsilon}} f(x) dx &= \int_{-2}^{-\varepsilon} \frac{1}{x} dx + \int_{\varepsilon}^2 \frac{1}{x} dx = \ln|x| \Big|_{-2}^{-\varepsilon} + \ln|x| \Big|_{\varepsilon}^2 \\ &= \ln \varepsilon - \ln 2 + \ln 2 - \ln \varepsilon = 0 \quad \forall \varepsilon > 0 \end{aligned}$$

$$\Rightarrow \lim_{\varepsilon \rightarrow 0} \int_{\Gamma_{-\varepsilon}} f(x) dx = 0$$

This is the Cauchy Principle Value of  $\int_{\Gamma} f(x) dx$

But if we replace  $\Gamma_{-\varepsilon}$  by  $\lim_{\varepsilon \rightarrow 0} \Gamma_{-\varepsilon} = [-2, 2] = \Gamma$  then

$$\int_{\Gamma} \frac{1}{x} dx = \int_{-2}^2 \frac{1}{x} dx = \left( \lim_{\varepsilon_1 \rightarrow 0} \int_{-2}^{\varepsilon_1} \frac{1}{x} dx \right) + \left( \lim_{\varepsilon_2 \rightarrow 0} \int_{-\varepsilon_2}^2 \frac{1}{x} dx \right) \text{ (by definition of improper integration)}$$

which does NOT exist. i.e., the integral does not exist in the proper sense, but it does in the Cauchy Principal Value

Thus as  $\varepsilon \downarrow 0$  we get the boundary integral equation

$$\begin{aligned} c_{ij}(P) u_j(P) + \int_{\Gamma} t_{ij}^*(P, \mathbf{x}) u_j(\mathbf{x}) d\Gamma(\mathbf{x}) \\ = \int_{\Gamma} u_{ij}^*(P, \mathbf{x}) t_j(\mathbf{x}) d\Gamma(\mathbf{x}) + \int_{\Omega} u_{ij}^*(P, \mathbf{x}) b_j(\mathbf{x}) d\Omega \end{aligned} \quad (5.55)$$

(or, in brief (no body force),  $c_{ij}u_j + \int_{\Gamma} t_{ij}^*u_j d\Gamma = \int_{\Gamma} u_{ij}^*t_j d\Gamma$ ) where the integral on the left hand side is interpreted in the Cauchy Principal sense. In practical applications  $c_{ij}$  and the principal value integral can be found indirectly from using Equation (5.55) to represent rigid-body movements.

The numerical implementation of Equation (5.55) is similar to the numerical implementation of an elliptic equation (e.g., Laplace's Equation). However, whereas with Laplace's equation the unknowns were  $u$  and  $\frac{\partial u}{\partial n}$  (scalar quantities) here the unknowns are vector quantities. Thus it is more convenient to work with matrices instead of indicial notation.  
i.e., use

$$\begin{aligned} \mathbf{u} &= \begin{bmatrix} u_1 \\ u_2 \\ u_3 \end{bmatrix}, \quad \mathbf{t} = \begin{bmatrix} t_1 \\ t_2 \\ t_3 \end{bmatrix} \\ \mathbf{u}^* &= \begin{bmatrix} u_{11}^* & u_{12}^* & u_{13}^* \\ u_{21}^* & u_{22}^* & u_{23}^* \\ u_{31}^* & u_{32}^* & u_{33}^* \end{bmatrix}, \quad \mathbf{t}^* = \begin{bmatrix} t_{11}^* & t_{12}^* & t_{13}^* \\ t_{21}^* & t_{22}^* & t_{23}^* \\ t_{31}^* & t_{32}^* & t_{33}^* \end{bmatrix} \end{aligned}$$

Then (in absence of a body force) we can write Equation (5.55) as

$$\mathbf{C}\mathbf{u} + \int_{\Gamma} \mathbf{t}^* \mathbf{u} d\Gamma = \int_{\Gamma} \mathbf{u}^* \mathbf{t} d\Gamma \quad (5.56)$$

We can discretise the boundary as before and put  $P$ , the singular point, at each node (each node has 6 unknowns - 3 displacements and 3 tractions - we get 3 equations per node). The overall matrix equation

$$\mathbf{A}\mathbf{u} = \mathbf{B}\mathbf{t} \quad (5.57)$$

where  $\mathbf{u} = \begin{bmatrix} u_1 \\ u_2 \\ \vdots \\ u_n \end{bmatrix}$  and  $\mathbf{t} = \begin{bmatrix} t_1 \\ t_2 \\ \vdots \\ t_n \end{bmatrix}$  where  $n$  is the number nodes.

The diagonal elements of the  $\mathbf{A}$  matrix in Equation (5.57) (for three-dimensions, a 3 x 3 matrix) contains principal value components. If we have a rigid-body displacement of a *finite* body in any

---

sense. However, if an integral exists in the proper sense, then it exists in the Cauchy Principal Value sense and the two values are the same.

one direction then we get

$$\mathbf{A}\mathbf{i}_l = \mathbf{0}$$

( $\mathbf{i}_l$  = vector defining a rigid body displacement in direction  $l$ )

$$\Rightarrow a_{ii} = - \sum_{i \neq j} a_{ij} \quad (\text{no sum on } i)$$

*i.e.*, the diagonal entries of  $\mathbf{A}$  (the  $c_{ij}$ 's) do not need to be determined explicitly. There is a similar result for an infinite body.

## 5.9 Body Forces (and Domain Integrals in General)

The body force gives rise to a domain integral although it does not give rise to any further unknowns in the system of equations. (This is because the body force is known - the fundamental solution was chosen so that it removed all unknowns appearing in domain integrals).

Thus Equation (5.55) is still classed as a Boundary Integral Equation. Integrals over the domain containing known functions (eg body force integral) appear in many situations *e.g.*, the Poisson equation  $\nabla^2 u = f$  yields a domain integral involving  $f$ .

The question is how do we evaluate domain integrals such as those appearing in the boundary integral formulation of such equations? Since the functions are known a *coarse* domain mesh may work. (*n.b.* Since the integral also contains the fundamental solution and  $\Omega$  may not be a "nice" region it is unlikely that it can be evaluated analytically). However, a domain mesh nullifies one of the advantages of BEM - that of having to prepare only a boundary mesh.

In some cases domain integrals must be used but there are techniques developing to avoid many of them. In some standard situations a domain integral can be transformed to a boundary integral. *e.g.*, a body force arising from a constant gravitational load, or a centrifugal load due to rotation about a fixed axis or the effect of a steady state thermal load can all be transformed to a boundary integral.

Firstly, let  $G_{ij}^*$  (the Galerkin tension) be related to  $u_{ij}^*$  by

$$u_{ij}^* = G_{ij,kk}^* - \frac{1}{2(1-\nu)} G_{ik,kj}^* \quad (3D)$$

$$\Rightarrow G_{ij} = \begin{cases} \frac{1}{8\pi G} r \delta_{ij} & (3D) \\ \frac{1}{8\pi G} r^2 \log\left(\frac{1}{r}\right) \delta_{ij} & (2D) \end{cases}$$

Then

$$B_i = \int_{\Omega} u_{ij}^* b_j d\Omega = \int_{\Omega} \left( G_{ij,kk}^* - \frac{1}{2(1-\nu)} G_{ik,kj}^* \right) b_j d\Omega$$

Under a constant gravitational load  $\mathbf{g} = (g_j)$

$$\begin{aligned}
 b_j &= \rho g_j \\
 \Rightarrow B_i &= \rho g_j \int_{\Omega} \left( G_{ik,j}^* - \frac{1}{2(1-\nu)} G_{ik,kj}^* \right) d\Omega \\
 &= \rho g_j \int_{\Gamma} \left\{ G_{ij,k}^* - \frac{1}{2(1-\nu)} G_{ik,j}^* \right\} n_k d\Gamma
 \end{aligned}$$

which is a boundary integral.

Unless the domain integrand is “nice” the above simple application of Green’s theorem won’t work in general. There has been a considerable amount of research on domain integrals in BEM which has produced techniques for overcoming some domain methods. The two integrals of note are the DRM, dual reciprocity method, developed around 1982 and the MRM, multiple reciprocity method, developed around 1988.

## 5.10 CMISS Examples

1. To solve a truss system run CMISS example 411 This solves the simple three truss system shown in Figure 5.2.
2. To solve stresses in a bicycle frame modelled with truss elements run CMISS example 412.

# Chapter 6

## Modal Analysis

### 6.1 Introduction

The system of ordinary differential equations which results from the application of the Galerkin finite element (or other) discretization of the spatial domain to linear parabolic or hyperbolic equations can either be integrated directly - as in the last section for parabolic equations - or analysed by *mode superposition*. That is, the time-dependent solution is expressed as the superposition of the natural (or resonant) modes of the system. To find these modes requires the solution of an eigenvalue problem.

### 6.2 Free Vibration Modes

Consider an extension of Equation (4.22) which includes second order time derivatives (*e.g.*, nodal point accelerations)

$$M\ddot{\mathbf{u}}(t) + C\dot{\mathbf{u}}(t) + K\mathbf{u}(t) = \mathbf{f}(t) \quad (6.1)$$

$M$ ,  $C$  and  $K$  are the mass, damping and stiffness matrices, respectively,  $\mathbf{f}(t)$  is the external load vector and  $\mathbf{u}(t)$  is the vector of  $n$  nodal unknowns. In direct time integration methods  $\ddot{\mathbf{u}}(t)$  and  $\dot{\mathbf{u}}(t)$  are replaced by finite differences and the resulting system of algebraic equations is solved at successive time steps. For a small number of steps this is the most economical method of solution but, if a solution is required over a long time period, or for a large number of different load vectors  $\mathbf{f}(t)$ , a suitable transformation

$$\mathbf{u}(t) = \mathbf{P}\mathbf{x}(t) \quad (6.2)$$

applied to Equation (6.1) can result in the matrices of the transformed system

$$\mathbf{P}^T M \mathbf{P} \ddot{\mathbf{x}}(t) + \mathbf{P}^T C \mathbf{P} \dot{\mathbf{x}}(t) + \mathbf{P}^T K \mathbf{P} \mathbf{x}(t) = \mathbf{P}^T \mathbf{f} \quad (6.3)$$

having a much smaller bandwidth than in the original system and hence being more economical to solve. In fact, if damping is neglected,  $\mathbf{P}$  can be chosen to diagonalize  $M$  and  $K$  and thereby uncouple the equations entirely. This transformation (which is still applicable when damping is included but does not then result in an uncoupled system unless further simplifications are made) is

found by solving the free vibration problem

$$M\ddot{\mathbf{u}}(t) + \mathbf{K}\mathbf{u}(t) = \mathbf{0} \quad (6.4)$$

**Proof:** Consider a solution to Equation (6.4) of the form

$$\mathbf{u}(t) = \mathbf{s} \sin \omega(t - t_0), \quad (6.5)$$

where  $\omega$  and  $t_0$  are constants and  $\mathbf{s}$  is a vector of order  $n$ . Substituting Equation (6.5) into Equation (6.4) gives the *generalized eigenproblem*

$$\mathbf{K}\mathbf{s} = \omega^2 \mathbf{M}\mathbf{s} \quad (6.6)$$

having  $n$  *eigensolutions*  $(\omega_1^2 \mathbf{s}_1), (\omega_2^2 \mathbf{s}_2), \dots, (\omega_n^2 \mathbf{s}_n)$ . If  $\mathbf{K}$  is a symmetric matrix (as is the case when the original partial differential operator is self-adjoint) the eigenvectors are orthogonal and can be “normalized” such that

$$\mathbf{s}_i^T \mathbf{M} \mathbf{s}_j = \begin{cases} 1 & i = j \\ 0 & i \neq j \end{cases} \quad (6.7)$$

(the eigenvectors are said to be *M-orthonormalised*). Combining the  $n$  eigenvectors into a matrix  $\mathbf{S} = [\mathbf{s}_1, \mathbf{s}_2, \dots, \mathbf{s}_n]$  - the *modal matrix* - rewriting Equation (6.7) as

$$\mathbf{S}^T \mathbf{M} \mathbf{S} = \mathbf{I} \quad (6.8)$$

where  $\mathbf{I}$  is the identity matrix, (6.6) becomes

$$\mathbf{K}\mathbf{S} = \mathbf{M}\mathbf{S}\mathbf{\Lambda} \quad (6.9)$$

where

$$\mathbf{\Lambda} = \begin{bmatrix} \omega_1^2 & & & 0 \\ & \omega_2^2 & & \\ & & \ddots & \\ 0 & & & \omega_n^2 \end{bmatrix} \quad (6.10)$$

or

$$\mathbf{S}^T \mathbf{K} \mathbf{S} = \mathbf{S}^T \mathbf{M} \mathbf{S} \mathbf{\Lambda} = \mathbf{I} \mathbf{\Lambda} = \mathbf{\Lambda} \quad (6.11)$$

Thus the modal matrix - whose columns are the *M-orthonormalised* eigenvectors of  $\mathbf{K}$  (*i.e.*, satisfying Equation (6.6)) - can be used as the transformation matrix  $\mathbf{P}$  in Equation (6.2) required to reduce the original system of equations (6.1) to the *canonical* form

$$\ddot{\mathbf{x}}(t) + \mathbf{S}^T \mathbf{C} \mathbf{S} \dot{\mathbf{x}}(t) + \mathbf{\Lambda} \mathbf{x}(t) = \mathbf{S}^T \mathbf{f}(t) \quad (6.12)$$

With damping neglected equation (6.12) becomes a system of uncoupled equations

$$\ddot{x}_i(t) + \omega_i^2 x_i(t) = r_i(t) \quad i = 1, 2, \dots, n \quad (6.13)$$

where  $x_i$  is the  $i^{\text{th}}$  component of  $\mathbf{x}$  and  $r_i$  is the  $i^{\text{th}}$  component of the vector  $\mathbf{S}^T \mathbf{f}$ . The solution of



this system is given by the Duhamel integral

$$x_i(t) = \frac{1}{\omega_i} \int_0^t r_i(\tau) \sin \omega_i(t - \tau) d\tau + \alpha_i \sin \omega_i t + \beta_i \cos \omega_i t \quad (6.14)$$

where the constants  $\alpha_i$  and  $\beta_i$  are determined from the initial conditions

$$\begin{aligned} x_i(0)|_{t=0} &= s_i^T \mathbf{M} \mathbf{u}(0)|_{t=0} \\ \dot{x}_i(0)|_{t=0} &= \dot{x}_i(0)|_{t=0} = s_i^T \mathbf{M} \dot{\mathbf{u}}(0)|_{t=0} \end{aligned} \quad (6.15)$$

### 6.3 An Analytic Example

As an example, consider the equilibrium equations  $\mathbf{M}\ddot{\mathbf{u}} + \mathbf{K}\mathbf{u} = \mathbf{f}$  where

$$\mathbf{M} = \begin{bmatrix} 2 & 0 \\ 0 & 1 \end{bmatrix}, \quad \mathbf{K} = \begin{bmatrix} 6 & -2 \\ -2 & 4 \end{bmatrix} \quad \text{and} \quad \mathbf{f} = \begin{bmatrix} 0 \\ 10 \end{bmatrix}$$

To find the solution by modal analysis we first solve the generalised eigenproblem  $\mathbf{K}\mathbf{s} = \omega^2 \mathbf{M}\mathbf{s}$  i.e.,

$$\begin{bmatrix} 6 - 2\omega^2 & -2 \\ -2 & 4 - \omega^2 \end{bmatrix} \mathbf{s} = 0$$

has a solution when  $\det[\mathbf{K} - \omega^2 \mathbf{M}] = 0$  or  $\omega^4 - 7\omega^2 + 10 = 0$ . This *characteristic polynomial* has solutions  $\omega^2 = 2, 5$  with corresponding eigenvectors  $\mathbf{s}_1^T = a \begin{bmatrix} 1 & 1 \end{bmatrix}$ ,  $\mathbf{s}_2^T = b \begin{bmatrix} -1 & 2 \end{bmatrix}$ . To find the magnitude of the eigenvectors we use Equation (6.7), i.e.,

$$a^2 \begin{bmatrix} 1 & 1 \end{bmatrix} \begin{bmatrix} 2 & 0 \\ 0 & 1 \end{bmatrix} \begin{bmatrix} 1 \\ 1 \end{bmatrix} = 1 \Rightarrow a = \frac{1}{\sqrt{3}} \quad b^2 \begin{bmatrix} -1 & 2 \end{bmatrix} \begin{bmatrix} 2 & 0 \\ 0 & 1 \end{bmatrix} \begin{bmatrix} -1 \\ 2 \end{bmatrix} = 1 \Rightarrow b = \frac{1}{\sqrt{3}}$$

(Notice that the orthogonality condition is satisfied:  $ab \begin{bmatrix} 1 & 1 \end{bmatrix} \begin{bmatrix} 2 & 0 \\ 0 & 1 \end{bmatrix} \begin{bmatrix} -1 \\ 2 \end{bmatrix} = 0$ ).

The  $M$ -orthonormalised eigenvectors are now  $\mathbf{s}_1^T = \begin{bmatrix} \frac{1}{\sqrt{3}} & \frac{1}{\sqrt{3}} \end{bmatrix}$  and  $\mathbf{s}_2^T = \begin{bmatrix} -\frac{1}{\sqrt{6}} & \frac{2}{\sqrt{6}} \end{bmatrix}$ ,

giving the modal matrix  $\mathbf{S} = \begin{bmatrix} \frac{1}{\sqrt{3}} & -\frac{1}{\sqrt{6}} \\ \frac{1}{\sqrt{3}} & \frac{2}{\sqrt{6}} \end{bmatrix}$  which, when used as the transformation matrix,

reduces the stiffness matrix to

$$\mathbf{S}^T \mathbf{K} \mathbf{S} = \begin{bmatrix} \frac{1}{\sqrt{3}} & \frac{1}{\sqrt{3}} \\ -\frac{1}{\sqrt{6}} & \frac{2}{\sqrt{6}} \end{bmatrix} \begin{bmatrix} 6 & -2 \\ -2 & 4 \end{bmatrix} \begin{bmatrix} \frac{1}{\sqrt{3}} & -\frac{1}{\sqrt{6}} \\ \frac{1}{\sqrt{3}} & \frac{2}{\sqrt{6}} \end{bmatrix} = \begin{bmatrix} 2 & 0 \\ 0 & 5 \end{bmatrix} = \mathbf{\Lambda}$$

and the mass matrix to

$$\mathbf{S}^T \mathbf{M} \mathbf{S} = \begin{bmatrix} \frac{1}{\sqrt{3}} & \frac{1}{\sqrt{3}} \\ -\frac{1}{\sqrt{6}} & \frac{1}{\sqrt{6}} \end{bmatrix} \begin{bmatrix} 2 & 0 \\ 0 & 1 \end{bmatrix} \begin{bmatrix} \frac{1}{\sqrt{3}} & -\frac{1}{\sqrt{6}} \\ \frac{1}{\sqrt{3}} & \frac{1}{\sqrt{6}} \end{bmatrix} = \begin{bmatrix} 1 & 0 \\ 0 & 1 \end{bmatrix} = \mathbf{I}$$

Thus the natural modes of the system are given by

$$\mathbf{u}_1(t) = \begin{bmatrix} \frac{1}{\sqrt{3}} \\ 1 \\ \frac{1}{\sqrt{3}} \end{bmatrix} \sin \sqrt{2}(t - t_0) \quad \text{and} \quad \mathbf{u}_2(t) = \begin{bmatrix} -\frac{1}{\sqrt{6}} \\ 2 \\ \frac{1}{\sqrt{6}} \end{bmatrix} \sin \sqrt{5}(t - t'_0).$$

The solution of the non-homogeneous system, subject to given initial conditions, is found by solving the uncoupled equations

$$\ddot{\mathbf{x}}(t) + \begin{bmatrix} 2 & 0 \\ 0 & 5 \end{bmatrix} \mathbf{x}(t) = \begin{bmatrix} \frac{1}{\sqrt{3}} & \frac{1}{\sqrt{3}} \\ -\frac{1}{\sqrt{6}} & \frac{1}{\sqrt{6}} \end{bmatrix} \begin{bmatrix} 0 \\ 10 \end{bmatrix} = \begin{bmatrix} \frac{10}{\sqrt{3}} \\ \frac{20}{\sqrt{6}} \end{bmatrix}$$

by means of the Duhamel integral (6.14) (in this case with  $\mathbf{r}$  constant) and then, from Equation (6.2) with  $\mathbf{P} \equiv \mathbf{S} = [\mathbf{s}_1, \mathbf{s}_2, \dots, \mathbf{s}_n]$

$$\mathbf{u}(t) = \mathbf{S} \mathbf{x}(t) = \sum_{i=1}^n \mathbf{s}_i x_i(t) \quad (6.16)$$

Notice that the solution is expressed in Equation (6.16) as the superposition of the natural modes (eigenvectors) of the homogeneous equations. If the forcing function (load vector) is close to one of these modes the corresponding coefficient  $x_i$  will be large and will dominate the response - if it coincides then resonance will occur. Very often it is unnecessary to evaluate all  $n$  eigenvectors of the system; the higher frequency modes can be ignored and the solution adequately represented by superposition of the  $p$  eigenvectors associated with the  $p$  lowest eigenvalues, where  $p < n$ .

## 6.4 Proportional Damping

When element damping terms are included in the original dynamic equations (6.1) the transformation to a lower bandwidth system is still based on the model matrix  $\mathbf{S}$  but Equation (6.12) is then not a system of uncoupled equations. One simplification often made in order to retain the diagonal nature of Equation (6.12) is to approximate the overall energy dissipation of the finite element system with *proportional damping*

$$\mathbf{s}_i^T \mathbf{C} \mathbf{s}_j = 2\omega_i \xi_i \delta_{ij}, \quad (6.17)$$

where  $\xi_i$  is a modal damping parameter and  $\delta_{ij}$  is the Kronecker delta. Equation (6.12) now reduces to  $n$  equations of the form

$$\ddot{x}_i(t) + 2\omega_i\xi_i\dot{x}_i(t) + \omega_i^2x_i(t) = r_i(t) \quad (6.18)$$

with solution (the Duhamel integral)

$$x_i(t) = \frac{1}{\bar{\omega}_i} \int_0^t r_i(\tau) \cdot e^{\xi_i\omega_i(t-\tau)} \cdot \sin \bar{\omega}_i(t-\tau) dt + e^{-\xi_i\omega_i t} \{\alpha_i \sin \bar{\omega}_i t + \beta_i \cos \bar{\omega}_i t\} \quad (6.19)$$

where  $\bar{\omega}_i = \omega_i \sqrt{1 - \xi_i^2}$ .  $\alpha_i$  and  $\beta_i$  are calculated from the initial conditions Equation (6.15). Once the components  $x_i(t)$  have been found from Equation (6.19) (or alternative time integration methods applied to (6.18)), the solution  $\mathbf{u}(t)$  is expressed as a superposition of the mode shapes  $\mathbf{s}_i$  by Equation (6.16).

## 6.5 CMISS Examples

1. To analyse a plane stress modal analysis run CMISS example 451
2. To analyse a clamped beam modal analysis run CMISS example 452
3. To analyse a steel-framed building modal analysis run CMISS example 453



# Chapter 7

## Constitutive Laws

### 7.1 Introduction

Continuum Mechanics deals with the movement of materials under the action of applied forces where the materials are continuous and deformable (we will only consider solid mechanics here). The result of a set of forces acting on a deformable material is a (possibly time-varying) displacement field: each material point moves a certain amount dependent both on its position relative to the applied forces and on the mechanical properties of the material. A displacement “field” implies a continuous variation of displacement with position. The concepts of strain, a measure of length change or displacement gradient, and stress, the force per unit area acting on an infinitesimally small plane surface within the material, are of fundamental importance.

We derive the equations governing the motion of deformable materials in the following four steps:

1. **Kinematic Relations**, which define the components of strain in terms of displacement gradients and, in the case of incompressible materials, define the incompressibility constraint.
2. **Stress Equilibrium**, or equations of motion, derived from the laws of conservation of linear momentum and conservation of angular momentum.
3. **Constitutive Relations**, which express the relationship between stress and strain and must be established from experimental measurement, subject to certain theoretical restrictions.
4. **Boundary Conditions**, which specify the external loads or displacement constraints acting on the deforming body.

The first two steps are concerned with relationships which hold for all materials and will be considered in detail in Section 7.2 and 7.4; the third step is concerned with relations determined experimentally for a particular material and is treated more fully in 7.5. **[Remark: fix up section references no 7.5]**

### 7.2 Kinematic Relations

The key to analyzing strain in a material undergoing large displacements and deformation is to establish two types of coordinate system and the relationship between them. The first are fixed

FIGURE 7.1: Coordinate systems used in the kinematic analysis of large deformation.  $(X_1, X_2, X_3)$  are the rectangular cartesian coordinates of the point  $P$  (position vector  $R$ ) in the undeformed body.  $(x_1, x_2, x_3)$  are the rectangular cartesian coordinates of the same material point  $p$  (position vector  $r$ ) in the deformed body after a displacement  $u$ .  $(x_1, x_2, x_3)$  are material coordinates.

reference coordinates and the second (material coordinates) are embedded in the deforming body. From the base vectors of the material coordinates we define metric tensors - measures of the physical lengths of coordinate increments - and thence strain tensors.

### 7.2.1 Coordinate systems and metric tensors

The coordinates  $(X_1, X_2, X_3)$  define the position of a material point in the undeformed tissue (see Fig.2.1) **[Remark: fix up figure reference]** with respect to a fixed reference rectangular cartesian coordinate system. The same material point in the deformed tissue has rectangular cartesian coordinates  $(x_1, x_2, x_3)$ . Another system of material coordinates  $(x_1, x_2, x_3)$  is defined in which the coordinate lines can be thought of as being attached to material particles and so move with the deforming body. During the deformation the initially straight and orthogonal  $X_M$ -coordinate axes remain “attached” to material particles and therefore become distorted and non-orthogonal in the deformed configuration.  $\{X_M\}$  are called material coordinates or convected coordinates. On the other hand the  $x_i$ -coordinate axes are fixed throughout the deformation and  $\{x_i\}$  are called spatial coordinates (see Figure 3.1). **[Remark: fix reference]** **[Remark: missing figure]**

The base vectors for the  $x_i$ -coordinates in the undeformed reference state are found by differentiating the position vector  $\mathbf{r} = X_k \mathbf{i}_k$

$$\mathbf{g}_i = \frac{\delta X_k}{\delta x_i} \mathbf{i}_k \quad (7.1)$$

The covariant components  $G_{ij}$  of the undeformed metric tensor are obtained from the inner products of the base vectors

$$G_{ij} = \mathbf{g}_i \mathbf{g}_j = \frac{\delta X_k}{\delta x_i} \frac{\delta X_k}{\delta x_j} \quad (7.2)$$

Similarly, derivatives of the position vector  $\mathbf{r}$  of a material point in the deformed body (see Figure 7.1) with respect to the same material coordinates yield base vectors

$$\mathbf{g}_i = \frac{\delta x_k}{\delta x_i} \mathbf{i}_k \quad (7.3)$$

and metric tensors

$$g_{ij} = \mathbf{g}_i \mathbf{g}_j = \frac{\delta x_k}{\delta x_i} \frac{\delta x_k}{\delta x_j} \quad (7.4)$$

FIGURE 7.2: Coordinate systems used in the kinematic analysis of large deformation.  $(X_1, X_2, X_3)$  are the rectangular cartesian coordinates of the point  $P$  (position vector  $\mathbf{r}$ ) in the undeformed body.  $(x_1, x_2, x_3)$  are the rectangular cartesian coordinates of the same material point  $p$  (position vector  $\mathbf{r}$ ) in the deformed body after a displacement  $\mathbf{u}$ .  $(x_1, x_2, x_3)$  are material coordinates.

### 7.2.2 Strain measures

An initially undeformed line segment vector  $d\mathbf{x}$  with components  $dX^1, dX^2, dX^3$  (expressed more succinctly as  $d\mathbf{x} = \{dX^M\}$ ) deforms into the line segment  $d\mathbf{x} = \{dx^i\}$ . The deformation field is defined by expressing  $\mathbf{x}$  as a function of  $\mathbf{X}$  and the components of deformation gradient,  $\frac{\delta x_i}{\delta X_M}$ , collectively give the deformation gradient tensor  $\mathbf{F} = \left\{ \frac{\delta x_i}{\delta X_M} \right\}$ . Thus, the line segment  $d\mathbf{x}$  is carried by the deformation into  $d\mathbf{x} = \mathbf{F}d\mathbf{X}$ , or, in component form,  $dx^i = F_M^i dX^M$ , where summation is implied ( $M = 1, 2, 3$ ) over the repeated index  $M$  and

$$F_M^i = \frac{\delta x_i}{\delta X_M} \quad (7.5)$$

**[Remark: missing figure]**

A very important concept is that of “polar decomposition”. The deformation gradient tensor  $\mathbf{F}$  can be considered as the product  $\mathbf{F} = \mathbf{R}\mathbf{U}$  of an orthogonal rotation tensor  $\mathbf{R}$  and a symmetric positive stretch tensor  $\mathbf{U}$ . Equivalently, the line segment components  $dX^M$  are stretched into components  $dy^L = U_M^L dX^M$  before being rotated into the components  $dx^i = R_L^i dy^L$ . An equally valid interpretation of the deformation would be to consider the rigid body rotation before the stretching but for the present purpose it is more convenient to interpret “stretch” in terms of material coordinates and then use the rotation tensor  $\mathbf{R}$  to relate the stretched material lines to the spatial coordinates (for further details and a full justification of the polar decomposition theorem see Atkin and Fox (1980) or Spencer (1980)). The main point here is that the stretch tensor  $\mathbf{U}$  contains a complete description of the material strain, independent of rigid body motion (see also Figure 4.4).

The length of the line segments  $d\mathbf{x}$  and  $d\mathbf{X}$  are denoted by  $dS$  and  $d\mathbf{x}$ , respectively, where, from Pythagoras,  $dS^2 = dX^M dX^M$  and  $ds^2 = dx^i dx^i$

Strain is a measure of relative length change and the so-called “Right Cauchy-Green” strain tensor

$$\mathbf{C} = \mathbf{F}^T \mathbf{F} = \frac{\delta x_k}{\delta X_M} \frac{\delta x_k}{\delta X_N}$$

with components  $C_{MN}$ , indicates how each component of undeformed line segment  $d\mathbf{x}$  contributes to the squared length of the deformed line segment  $d\mathbf{x}$

$$ds^2 = dx^k dx^k = \frac{\delta x_k}{\delta X_M} dX^M \frac{\delta x_k}{\delta X_N} dX^N = C_{MN} dX^M dX^N = dX^T \mathbf{C} d\mathbf{X}$$

Using polar decomposition  $\mathbf{F} = \mathbf{R}\mathbf{U}$ , gives

$$\mathbf{C} = \mathbf{F}^T \mathbf{F} = (\mathbf{R}\mathbf{U})^T \mathbf{R}\mathbf{U} = \mathbf{U}^T \mathbf{R}^T \mathbf{R}\mathbf{U} = \mathbf{U}^T \mathbf{U} = \mathbf{U}^2$$

since  $\mathbf{R}$  is orthogonal ( $\mathbf{R}^T = \mathbf{R}^{-1}$ ) and  $\mathbf{U}$  is symmetric ( $\mathbf{U}^T = \mathbf{U}$ ).

Thus the stretch tensor  $\mathbf{U}$  can be obtained by taking the positive square-root of the strain tensor (see below). Both  $\mathbf{U}$  and  $\mathbf{C}$  are expressed in terms of material coordinates.



# Chapter 8

## Data fitting with finite elements

### 8.1 Introduction

We show here how finite elements can be used for fitting one, two or three-dimensional fields. The data could, for examples, be a series of temperature measurements (as in figure \*\*\*) and there is a need to find the finite element nodal parameters which, together with the chosen basis functions, 'fit' the data in a least-squares sense. This linear least-squares problem is considered in Section ?? Another common requirement is to fit nodal geometric parameters describing a finite element surface in 3D space to a set of non-uniformly spaced coordinates defining the original surface. Geometric fitting problems are nonlinear when the  $\xi_i$  -coordinates found at the orthogonal projection of the data onto the finite element mesh are changed by the fitting process. A judicious choice of coordinate system can sometimes avoid the problem and keep the geometric fitting linear, (this situation is considered in \*\*Section ??). Full nonlinear geometric fitting is considered in Section ??

### 8.2 Linear field fitting

#### 8.2.1 The linear field fitting problem

Consider the two-dimensional bilinear element shown in Figure 8.1. The element surrounds a set of data points (shown by the x's in Figure 8.1) which consist of measured values  $u_d$ ,  $d = 1..D$ , of some field (such as temperature) at specified locations  $(x_d, y_d)$ . The field fitting problem is to find the values of the finite element nodal parameters  $u_n$ ,  $n = 1..4$ , which minimise the sum of squared differences  $(u(\xi_d) - u_d)^2$  between  $u_d$  and the finite element field  $u$  evaluated at the  $(\xi_1, \xi_2)$  coordinates of data point  $d$  ( $u(\xi_d)$ ).

FIGURE 8.1: Least-squares fitting of finite element nodal parameters  $u_n$ ,  $n = 1..4$ , to measured data values  $u_d$ ,  $d = 1..D$ , at point locations  $(x_d, y_d)$ .

### 8.2.2 Calculation of data point projections

The first requirement, therefore, is to find the  $\xi_i$  coordinates of each data point  $(x_d, y_d)$ . For a bilinear element (with the basis functions given by (1.6)) this is a straightforward inversion of the following relations for each data point:

$$\begin{aligned} x_d &= (1 - \xi_1^d)(1 - \xi_2^d)x_1 + \xi_1^d(1 - \xi_2^d)x_2 + (1 - \xi_1^d)\xi_2^d x_3 + \xi_1^d \xi_2^d x_4 \\ y_d &= (1 - \xi_1^d)(1 - \xi_2^d)y_1 + \xi_1^d(1 - \xi_2^d)y_2 + (1 - \xi_1^d)\xi_2^d y_3 + \xi_1^d \xi_2^d y_4 \end{aligned} \quad (8.1)$$

where  $(x_n, y_n), n = 1..4$ , are the specified node positions and  $(x_d, y_d), d = 1..D$ , are the specified data point positions. To solve (8.1) for  $\xi_1^d$  and  $\xi_2^d$  we rearrange (8.1) as

$$\begin{aligned} a\xi_1^d + b\xi_2^d + c\xi_1^d \xi_2^d &= d \\ A\xi_1^d + B\xi_2^d + C\xi_1^d \xi_2^d &= D \end{aligned} \quad (8.2)$$

where

$$a = x_2 - x_1, \quad b = x_3 - x_1, \quad c = x_1 - x_2 - x_3 + x_4, \quad \text{and} \quad d = x_d - x_1$$

and

$$A = y_2 - y_1, \quad B = y_3 - y_1, \quad C = y_1 - y_2 - y_3 + y_4, \quad \text{and} \quad D = y_d - y_1$$

then

$$\xi_2^d = \frac{d - a\xi_1^d}{b + c\xi_1^d} = \frac{D - A\xi_1^d}{B + C\xi_1^d} \quad (8.3)$$

or

$$\alpha(\xi_1^d)^2 + \beta(\xi_1^d) + \gamma = 0 \quad (8.4)$$

where

$$\alpha = Ac - aC, \quad \beta = dC - Dc + Ab - aB, \quad \text{and} \quad \gamma = Bd - bD$$

Solving (8.4) gives

$$\xi_1^d = \begin{cases} \frac{-\beta \pm \sqrt{\beta^2 - 4\alpha\gamma}}{2\alpha} & \text{when } \alpha \neq 0 \\ -\frac{\gamma}{\beta} & \text{when } \alpha = 0 \end{cases} \quad (8.5)$$

and then  $\xi_2^d$  is recovered from (8.3).

### 8.2.3 Least squares field fitting

Once the  $\xi_i$  coordinate positions of each data point  $\xi_d = (\xi_1^d, \xi_2^d)$  is known, and interpolation of the (unknown) nodal values of  $u_n$  ( $n = 1..4$ ) gives

$$u(\xi_d) = \Psi_n u_n$$

where there is an implied sum over  $n = 1..4$ . Now the weighted sum of squared differences between this value and the measured value  $u_d$  for  $d = 1..D$ , is

$$\text{eqnhere} \quad (8.6)$$

where  $w_d$  is the weight for data point  $d$ . For measured data a good choice for  $w_d$  is one over the variance of the error for data point  $d$ .

Minimising (8.6) with respect to the nodal parameters  $u_m$  gives

$$\frac{\partial \mathcal{F}}{\partial u_m} = 2 \sum_{d=1}^D w_d (\Psi_n(\xi_d) u_n - u_d) \Psi_m(\xi_d) = 0 \quad (8.7)$$

or

$$\left[ \sum_{d=1}^D w_d \Psi_m(\xi_d) \Psi_n(\xi_d) \right] u_n = \sum_{d=1}^D w_d \Psi_m(\xi_d) u_d \quad m = 1..4 \quad (8.8)$$

Note that there is an implied sum over  $n = 1..4$  on the left hand side of (8.8). For the single 4-node element shown in Figure 8.1. **[check capital?]** (8.8) gives four unknowns  $u_1, u_2, u_3$  and  $u_4$ . If more than one element is used in the fitting, the matrix and vector on the left and right hand sides, respectively, of (8.8) are

$$E_{mn} = \sum_{d=1}^D w_d \Psi_m(\xi_d) \Psi_n(\xi_d) \quad \text{and} \quad f_m = \sum_{d=1}^D w_d \Psi_m(\xi_d) u_d \quad (8.9)$$

which can then be assembled into a global system of equations in exactly the same fashion as occurs in the finite element solution of a boundary value problem (see Section 2.1).

### 8.2.4 Gauss point fitting

An extension to linear field fitting is Gauss point fitting. Consider the problem of finding the nodal stress field from a finite element analysis. The finite element formulation for a stress analysis typically solves for displacements, not stresses (see Chapter 5). Stresses are a derived quantity and are calculated from the constitutive law from the strains which are calculated (in terms of nodal displacements) at the Gauss points. The result of the analysis is that it is only possible to obtain a Gauss point based description of the stresses. To obtain a nodal field based description of the stress field we can use a fitting approach very similar to the one described above for field fitting. The only difference in this case is that our 'data points' are located at the Gauss points and hence the  $\xi_d$  location is just the Gauss point location  $\xi_g$ . The values of the field  $u_d$  are just the values of stress calculated at the Gauss points and the weights for each data point  $w_d$  are 1.

## 8.3 Linear geometric fitting

### 8.3.1 Introduction

Another common requirement is to fit nodal geometric parameters describing a finite element geometry to a set of non-uniformly spaced coordinates defining the original geometry. Geometric fitting differs from field fitting in that when fitting with more than one geometric variable we have a non-linear problem since the mesh data projection is no longer orthogonal.

Geometric fitting problems can be turned into a linear problem in two ways. The first is to only fit geometries where there is one geometric variable. The second is to keep the data projections

constant throughout the fit. Both options will now be considered.

### 8.3.2 Fitting with one geometric variable

A Geometric fitting problem with one variable is linear hence it is desirable to try and arrange a geometric fitting problem so that only one variable is being fitted. This can often be achieved by adopting a non-rectangular cartesian coordinate system. For example consider a fitting problem in polar coordinates as shown in Figure ??

[missing figure]

In this case the orthogonal data point projections  $\xi_d$  are independent of the radius and can be easily found from the theta coordinate of the data point  $\theta_d$ . This independence from radius means we can formulate the geometric fitting problem with only one geometric variable,  $r$  being fitted. As with the linear field fitting case we can formulate an error function as the weighted sum of squares of the individual errors, that is

$$\mathcal{F}(r) = \sum_{d=1}^D w_d (\Psi_n(\xi_d) r_n - r_d)^2 \quad (8.10)$$

Minimising this error function with respect to the nodal radii  $r_n$  we obtain

$$\frac{\partial \mathcal{F}}{\partial r_m} = 2 \sum_{d=1}^D w_d (\Psi_n(\xi_d) r_n - r_d) \Psi_m(\xi_d) = 0 \quad (8.11)$$

or in terms of element stiffness matrices

$$E_{mn} r_n = f_m \quad (8.12)$$

where

$$E_{mn} = \sum_{d=1}^D w_d \Psi_m(\xi_d) \Psi_n(\xi_d) \quad \text{and} \quad f_m = \sum_{d=1}^D w_d \Psi_m(\xi_d) u_d \quad (8.13)$$

Another example of a change of coordinate systems is a prolate spheroidal coordinates for fitting a heart geometry.

### 8.3.3 Linear geometric fitting with fixed $\xi_d$ locations

In some geometric fitting problems there is no appropriate change of coordinates and a rectangular cartesian system must be used. This means that, in general, we require both x and y (and z) in the fit at the same time. This results in a non-linear problem as the data point projection  $\xi_d$  will now, in general, change as we change any geometric variable during the fit. Hence in order to obtain a linear problem the data point projections must remain fixed during the fit. To see how this works consider the geometric fitting problem as shown in Figure 8.2.

FIGURE 8.2: Geometric fitting problem. The three nodal y-coordinates  $y_1, y_2$  and  $y_3$  of a two linear element basis function mesh are fitted to five data points. The initial locations of the nodes are  $(x_1, y_1) = (0, 0)$ ,  $(x_2, y_2) = (1, 0)$  and  $(x_3, y_3) = (2, 0)$ . The location of the data points are  $(x^1, y^1) = (0.2, 1.2)$ ,  $(x^2, y^2) = (0.8, 1.5)$ ,  $(x^3, y^3) = (1.3, 1.5)$ ,  $(x^4, y^4) = (1.5, 1.1)$  and  $(x^5, y^5) = (1.7, 0.8)$ . The initial  $\xi$  projections are  $\xi^1 = 0.2$  and  $\xi^2 = 0.8$  in element 1 and  $\xi^3 = 0.3$ ,  $\xi^4 = 0.5$  and  $\xi^5 = 0.7$  in element 2.

Now computing the error functions as a weighted sum of squares we obtain

$$\mathcal{F}(\mathbf{r}) = \sum_{d=1}^D w_d (\Psi_n(\xi_d) y_n - y_d)^2 \quad (8.14)$$

Minimising this error function with respect to the nodal parameters  $y_n$  we obtain the element matrix equation

$$E_{mn} y_n = f_m \quad (8.15)$$

where, as before,

$$E_{mn} = \sum_{d=1}^D w_d \Psi_m(\xi_d) \Psi_n(\xi_d) \quad \text{and} \quad f_m = \sum_{d=1}^D w_d \Psi_m(\xi_d) y_d \quad (8.16)$$

Now for element 1

$$\begin{aligned} E_{11} &= (1 - \xi^1)(1 - \xi^1) + (1 - \xi^2)(1 - \xi^2) \\ &= (1 - 0.2)(1 - 0.2) + (1 - 0.8)(1 - 0.8) = 0.68 \\ E_{12} &= E_{21} = (1 - \xi^1)\xi^1 + (1 - \xi^2)\xi^2 \\ &= (1 - 0.2)(0.2) + (1 - 0.8)(0.8) = 0.32 \\ E_{22} &= \xi^1\xi^1 + \xi^2\xi^2 \\ &= (0.2)(0.2) + (0.8)(0.8) = 0.68 \\ f_1 &= (1 - \xi^1)y^1 + (1 - \xi^2)y^2 \\ &= (1 - 0.2)(1.2) + (1 - 0.8)(1.5) = 1.26 \\ f_2 &= \xi^1y^1 + \xi^2y^2 \\ &= (0.2)(1.2) + (0.8)(1.5) = 1.44 \end{aligned} \quad (8.17)$$

and for element 2

$$\begin{aligned}
E_{11} &= (1 - \xi^3)(1 - \xi^3) + (1 - \xi^4)(1 - \xi^4) + (1 - \xi^5)(1 - \xi^5) \\
&= (1 - 0.3)(1 - 0.3) + (1 - 0.5)(1 - 0.5) + (1 - 0.7)(1 - 0.7) = 0.83 \\
E_{12} &= E_{21} = (1 - \xi^3)\xi^3 + (1 - \xi^4)\xi^4 + (1 - \xi^5)\xi^5 \\
&= (1 - 0.3)(0.3) + (1 - 0.5)(0.5) + (1 - 0.7)(0.7) = 0.67 \\
E_{22} &= \xi^3\xi^3 + \xi^4\xi^4 + \xi^5\xi^5 \\
&= (0.3)(0.3) + (0.5)(0.5) + (0.7)(0.7) = 0.83 \\
f_1 &= (1 - \xi^3)y^3 + (1 - \xi^4)y^4 + (1 - \xi^5)y^5 \\
&= (1 - 0.3)(1.5) + (1 - 0.5)(1.1) + (1 - 0.7)(0.8) = 1.84 \\
f_2 &= \xi^3y^3 + \xi^4y^4 + \xi^5y^5 \\
&= (0.3)(1.5) + (0.5)(1.1) + (0.7)(0.8) = 1.56
\end{aligned} \tag{8.18}$$

Assembling these element matrices and vectors into a global system of equations we get

$$\begin{bmatrix} 0.68 & 0.32 & 0.00 \\ 0.32 & 1.51 & 0.67 \\ 0.00 & 0.67 & 0.83 \end{bmatrix} \begin{bmatrix} y_1 \\ y_2 \\ y_3 \end{bmatrix} = \begin{bmatrix} 1.26 \\ 3.28 \\ 1.56 \end{bmatrix} \tag{8.19}$$

Solving these gives

$$\begin{bmatrix} y_1 \\ y_2 \\ y_3 \end{bmatrix} = \begin{bmatrix} 1.03210 \\ 1.74420 \\ 0.47152 \end{bmatrix} \tag{8.20}$$

The fitted solution is shown in Figure 8.3. It should be noted that after the fit the new data point

FIGURE 8.3: Fitted mesh. The  $\xi_d$  locations on the fitted mesh are  $\xi^1 = 0.212$  and  $\xi^2 = 0.752$  in element 1 and  $\xi^3 = 0.233$ ,  $\xi^4 = 0.504$  and  $\xi^5 = 0.726$  in element 2.

projections have changed after the fit. Hence it general there maybe some benefit from reapplying the fitting procedure to the new data point projection i.e. iterating on the fit.

## 8.4 Geometric fitting with Hermite elements

### 8.4.1 Review of cubic Hermite interpolation

#### Cubic Hermite basis functions

One of the most commonly used basis functions in finite elements are Lagrange basis functions which preserve continuity of the geometric coordinates across element boundaries by interpolating nodal coordinates which are shared by adjacent elements i.e.  $C^0$  continuity. The interpolation formula for linear Lagrange interpolation is given in (8.21).

$$\mathbf{x}(\xi) = \varphi_1(\xi)\mathbf{x}_1 + \varphi_2(\xi)\mathbf{x}_2 \tag{8.21}$$

where  $x_n$  is the geometric position of local node  $n$  and the two one-dimensional linear Lagrange basis functions are given in (8.22).

$$\varphi_1(\xi) = 1 - \xi \quad \varphi_2(\xi) = \xi \quad (8.22)$$

Cubic Hermite functions, on the other hand, also preserve continuity of the derivative of these coordinates with respect to  $\xi$  across element boundaries by defining additional nodal parameters **[here]** i.e.  $C^1$  continuity. The interpolation formula within an element is given by

$$\textbf{[eqn]} \quad (8.23)$$

where the four one-dimensional cubic Hermite basis functions are given in (8.24).

$$\begin{aligned} \Psi_1^0(\xi) &= 1 - 3\xi^2 + 2\xi^3 & \Psi_1^1(\xi) &= \xi(\xi - 1)^2 \\ \Psi_2^0(\xi) &= \xi^2(3 - 2\xi) & \Psi_2^1(\xi) &= \xi^2(\xi - 1) \end{aligned} \quad (8.24)$$

One further step is required to make cubic Hermite basis functions useful in practice. Consider now the two cubic Hermite elements as shown in Figure 8.4.

FIGURE 8.4: Two cubic Hermite elements (denoted by **1** and **2**) formed from three nodes (shown as a  $\bullet$  and denoted by 1, 2 and 3) and having arc-lengths  $s_1$  and  $s_2$ .

The derivative **[here]** the local element  $\xi$ -coordinate and is therefore, in general, different in the two adjacent elements. Therefore we carry a physical derivative

$$(8.25)$$

length derivative,  $\Delta(n, e)$  is the global node number of local node  $n$   $S_e$ , which scales the arc-length derivative to the  $\xi$ -coordinate derivative. Thus  $\frac{d\mathbf{x}}{ds}$  is constrained to be continuous across element boundaries rather than  $\frac{d\mathbf{x}}{d\xi}$ .

There is one condition that must be placed on the  $\xi$  to arc-length transformation to ensure that we have arc-length derivatives. This condition is that the arc-length derivative vector at a node must have unit magnitude, that is

$$(8.26)$$

This ensures that we have continuity with respect to a physical parameter rather than with respect to a mathematical parameter  $\xi$ . The set of mesh parameters,  $\mathbf{u}$ , for cubic Hermite interpolation hence contains the set of nodal values (or positions), the set of nodal arc-length derivatives and the set of scale factors.

### Bicubic Hermite basis functions

Bicubic Hermite basis functions are the two-dimensional extension of the one-dimensional cubic Hermite basis functions. They are formed from the tensor (or outer) product of two one-dimensional basis functions as defined in (8.24). The interpolation formula for a point  $(\xi_1, \xi_2)$

within an element is obtained from the bicubic Hermite interpolation formula,

(8.27)

As with the one-dimensional cubic Hermite elements, the derivatives with respect to  $\xi$  in the two-dimensional interpolation formula above are expressed as the product of a nodal arc-length derivative and a nodal scale factor. This is, however, complicated by the fact that there are now scale factors for each  $\xi$  direction at each node. For node  $n$  we have

(8.28)

and for the cross-derivative

(8.29)

As with the one-dimensional cubic Hermite case conditions must be placed on this transformation in order to maintain  $C^1$  continuity. A sufficient condition is that the scale factor at a node in one element must be the same as the scale factor at the same node in an adjacent element. That is, the elemental scale factor should be nodally based so that the same scale factor is used at a given node regardless of the current element. With this condition satisfied any choice of scale factor will give  $C^1$  continuity across element boundaries. The choice of the scale factor will, however, affect the spacing of  $\xi$  with arc-length. It is often computationally desirable to have a uniform spacing of  $\xi$  with respect to arc-length (for example, not biasing the Gaussian quadrature scheme to one end of the element). To achieve this uniform spacing a good choice of the nodal scale factor (denoted from now on as  $\mathcal{S}_n$  for node  $n$ ) is the average of the two arc-lengths on either side of the node. This condition must also be applied together with arc-length derivatives for each  $\xi$  direction as defined by (8.26).

If  $n_{\ominus}$  is the node or line immediately before node  $n$  (in the sense of increasing  $\xi$ ) and  $n_{\oplus}$  is the node or line immediately after node  $n$ , the nodal scale factor is given by

$$\mathcal{S}_n = \frac{s_{n_{\ominus}} + s_{n_{\oplus}}}{2} \quad (8.30)$$

This is termed average arc-length scaling. For example consider node 2 in Figure 8.4 then

$$\mathcal{S}_2 = \frac{s_1 + s_2}{2}$$

Thus, for an element  $e$ , the one-dimensional cubic Hermite interpolation formula in (8.23) becomes

(8.31)

To calculate the arc-length for a particular element an iterative process is needed. The arc-length for an one-dimensional element is defined as

(8.32)

However, since the interpolation of  $x(\xi)$ , as defined in (8.31), uses the arc-length in the calculation of the scaling factor, an iterative root finding technique is needed to obtain the arc-length.



FIGURE 8.5: Definition of a data point projection into an element. The data point at geometric location  $z_d$  is projected into an element at a geometric position  $z$  and element co-ordinate  $\xi_d$ .

With nodal based scale factors and arc-length derivatives we achieve a good arc-length to  $\xi$  spacing, continuity is maintained with respect to a physically meaningful parameter and the numerical results when using the mesh are more accurate.

### 8.4.2 Least squares fitting with cubic Hermite interpolation

#### Problem formulation

Consider a set of rectangular cartesian data with geometric positions  $z_d, d = 1..D$ . For each data point we can find the position on the mesh which has the smallest distance to that data point. This point is the orthogonal projection of the data point onto the mesh and has geometric position  $z$ . The point  $z$  is also given by the local element co-ordinate  $\xi_d$  as is shown in Figure 8.5.

To calculate  $\xi_d$  a non-linear iterative procedure is required. Given a  $\xi$  position for the data point projection within an element the geometric position of this projection is given by the standard interpolation formula ((8.23) or (8.27)). An error function can then be set up as the Euclidean distance between this position and the actual position of the data point. The  $\xi$  position which minimises this function can be found by using the Newton-Rhapson root finding method on the derivative of this function. This  $\xi$  position is the orthogonal projection of the data point.

For simplicity only two-dimensional fitting (i.e. cubic Hermite elements) will be covered in this section. Hence, given  $\xi_d$ ,  $z$  can be found from interpolation i.e.

(8.33)

The measure of error for each data point is defined as the Euclidean distance between the data point and its closest projection onto the current mesh:

(8.34)

For a given projection of the data points onto the mesh (i.e.  $\xi_d$  is held constant) the objective function to be minimised in the fit is then formed as the sum-of-squares of the individual errors.

(8.35)

where  $\gamma_d$  is a weight for each data point and  $u$  is a vector of mesh parameters.

The fitting problem is to find the set of mesh parameters that minimises this objective function. Substituting (8.33) into (8.35) and differentiating we obtain

(8.36)

(8.37)

A minimum can thus be found to the objective function by setting both Equations (8.36) and (8.37) to zero. This will result in a linear system only if the scale factors are kept constant

FIGURE 8.6: Geometric data fitting with cubic Hermite elements. (a) The data points (+) are shown projected onto the two element mesh at some intermediate stage in the fitting procedure. (b) The final fitted mesh.

during the fit. That is the vector  $\mathbf{u}$  will contain the nodal positions and the nodal arc-length derivatives. With this restriction we can obtain

This is a linear system of equations for the element of the form

$$K_{mn}u_n = f_m \quad (8.38)$$

A linear system of equations governing the entire mesh can then be found by assembling a global stiffness matrix from all the individual element matrices. This can then be solved to yield the nodal positions and derivatives which minimises the error in the mesh. An example of fitting is shown in Figure 8.6.

### Sobolev Smoothing

With an insufficient number of data points, fitting 'noisy' data or fitting data that has an uneven spread, a smoothness constraint [?] can be introduced by adding a second term to the objective function:

The first term measures the error in the surface from the data and the second term measures deformation of the surface. To measure the deformation of the surface a  $p^{th}$  order weighted Sobolev norm [?, ?] is used, defined by

$$(8.39)$$

where  $w_{ij}$  are the weights for the norm. The addition to the objective function, called the Sobolev value, is defined as

$$(8.40)$$

where  $\Omega$  is the mesh domain.

For the case of two-dimensional fitting (i.e. cubic Hermite elements)  $j = 0$  (as there is no  $\xi_2$  direction) and for the case of three-dimensional fitting (i.e. bicubic Hermite elements)  $j = 0..2$ . Consider the case for  $p = 2$ , and for 2D:  $w_0 = 0, w_1 = \alpha, w_2 = \beta$ , and for 3D:  $w_{00} = 0, w_{01} = w_{10} = \alpha, w_{20} = w_{02} = \beta, w_{11} = 2\beta$ . The Sobolev value now becomes

$$(8.41)$$

The parameter  $\alpha$  controls the tension of the surface and the parameter  $\beta$  controls the degree of surface curvature [?].

### 8.4.3 Non-linear geometric fitting with Hermite elements

#### Problem formulation

One problem that arises when using linear fitting with cubic Hermite elements is that arc-length derivatives and average arc-length scaling are not maintained during the fit. In linear fitting there is no information supplied in the linear fitting model that enforces arc-length derivatives and the scale factors are held constant during the fit. Here we consider how to fit the data whilst maintaining arc-length derivatives and an even spacing of arc-length with  $\xi$ . Because both the value of the arc-length for the element and the relationship between the derivatives in the various spatial directions depend upon the mesh parameters in a non-linear fashion, the only way to ensure arc-length derivatives are maintained during fitting is to use a non-linear fitting procedure.

Consider the following: Let  $\mathbf{u}$  be the vector of mesh parameters,  $\mathbf{z}_d$  the vector of the location of the data points in space and the vector of the location of the closest projection (at the points given by the  $d^{th}$  data point can be expressed by an error vector

(8.42)

and by a residual,

(8.43)

as the sum of squares of the individual residuals for the mesh  $\mathbf{u}$  and projections  $\xi_d$

(8.44)

In order to maintain arc-length derivatives a non-linear constraint is needed. This constraint comes from the geometric properties of arc-length derivatives. For a node  $n$  and  $\xi$ -direction  $i$  the magnitude of the vector of arc-length derivatives in the various spatial directions must be 1 as detailed in (8.26). Hence the constraint is

(8.45)

This also implies simple bounds on the derivative variables:

Thus the fitting problem can be written in terms of a non-linearly constrained, non-linear optimisation problem

(8.46)

(8.47)

where  $\mathbf{a}$  is a vector of lower bounds,  $\mathbf{b}$  a vector of upper bounds problem can be solved with readily available non-linear optimisation packages such as NPSOL [?].

In order to ensure that there is an approximately uniform spacing of  $\xi$  with arc-length two approaches can be used. The first approach is to use an iterative technique for the scale factors and is detailed here. The second approach is to include the scale factors in the optimisation problem and is detailed in the next section.

The constraint on the nodal scale factors (being the average of the line lengths either side of

the node) is placed upon the problem to ensure that the arc-length to  $\xi$  spacing is approximately uniform. As we are only getting approximately uniform arc-length to  $\xi$  spacing we can relax the constraint on nodal scale factors. If the nodal scale factors are held fixed during the fit we will not have average arc-length scaling throughout the fitting process but we will have a reasonable approximation. With the nodal scale factors fixed the variables  $\mathcal{S}_n$  can be removed from the vector of mesh

The approach is to hold the scale factors constant, fit the mesh with these scale factors, and then update the scale factors (based on the new mesh) to be average arc-length. This process can be repeated iteratively until the desired fit has been achieved. It should also be noted that (8.46) is defined only for a constant data point projection. With this iterative approach the data point projections are also updated at the same time as the scale factors.

The convergence of the fitting problem can be measured in two ways. The first is the convergence of the RMS error in the data and second is the convergence in the magnitude of the nodal scale factors.

The algorithm is therefore:

1. Define initial mesh (and calculate initial nodal scale factors)
2. Calculate the initial data point projections
3. Repeat until converged or the maximum number of iterations is exceeded
  - (a) Fit the mesh to the data by solving (8.46)
  - (b) Update the scale factors to be average arc-lengths based on the new mesh
  - (c) Recalculate the data point projections on the new mesh

### Alternative formulation

An alternative approach to ensuring average arc-length scale factors can be formulated by including the scale factors in the optimisation problem as optimisation variables. The vector of mesh parameters,  $\mathbf{u}$ , is hence extended to include the nodal scale factors. With this a new constraint can be introduced to (8.46) to ensure that there is an approximately uniform spacing of  $\xi$  with arc-length. This can be achieved if the nodal scale factor is the average on the arc-lengths on either side of that node. If  $(\mathcal{S}_i)_n$  is the average arc-length for node  $n$  in the  $\xi_i$  direction as given by (8.30) then the constraint that the nodal scale factor equals the average arc-length is given by

$$(8.48)$$

or

$$(8.49)$$

Note that no summation over  $\xi_i$  is implied.

This also generates a simple bound on the scale-factors:

This formulation of the non-linear fitting problem does have one practical limitation. With average arc-length scaling the interpolation within an element depends on the arc-length on the neighbouring elements, and the arc-length of the neighbouring elements depends on their neighbouring elements and so on. This results in a 'global mesh' in that every part of the mesh is

dependent on every other part of the mesh. The implication of this is that the entire mesh must be included in the fit otherwise average arc-length scaling cannot be achieved. This is not a desirable feature for very large problems or for problems where only a small part of the mesh is in error and needs to be fitted. The formulation still requires iteration for the data point projections but does have the advantage that the number of iterations required is reduced as the scale factors are found during the fit. This is at the expense of having to solve a much larger non-linear optimisation problem with more variables and, more importantly, more non-linear constraints.

The fit can be considered converged when either the data point projections or the RMS error in the fit does not change significantly between iterations. The algorithm for the non-linear data fitting procedure is as follows:

1. Define the initial mesh (and calculate the initial nodal scale factors)
2. Calculate the initial data point projections
3. Repeat until converged or the maximum number of iterations is exceeded
  - (a) Fit the mesh to the data by solving (8.46) (with the new constraints)
  - (b) Recalculate the data point projections on the new mesh

### Residual and constraint Jacobians

Solution of the non-linear problem given by (8.46) will generally require the evaluation of objective gradient (or residual vector Jacobian) and the constraint Jacobian with respect to the optimisation (mesh) parameters. For simplicity in this section we will be concerned with two-dimensions only (i.e. one-dimensional cubic Hermite elements). The residual and constraint Jacobians will be given for the alternative formulation as this covers all cases. If the scale factors are found by iteration (i.e. the problem as described in Section ??) the Jacobians with respect to the nodal scale factors can be ignored, as can the second constraint ((8.49)) which ensures average arc-length scale factors. In this case there are three basic types of variable within an element: the nodal variables  $(x_j)_n$ , the derivative The residual and constraint Jacobians are given below for each of these three variable types.

(8.42), and its corresponding residual  $f_d$ , defined in (8.43). The position of the projection of data point  $d$  within the element is given by (8.33). Substituting (8.33) into Equations (8.42) and (8.43) and differentiating with respect to the various optimisation variables we can obtain the Jacobian of the residual vector:

$$(8.50)$$

Note that if the data residual was (??) would become numerical problems the residual is therefore defined by (8.43).

Now consider the constraint Jacobians. Differentiating constraint (8.45) with respect to the mesh parameters gives constraint gradients:

$$(8.51)$$

To calculate the gradients for constraint (8.49) we first compute the rate of change of  $x$  with respect to  $\xi$  within an element by differentiating (8.31):

$$(8.52)$$

Substituting (8.52) into (8.49) and differentiating with respect to the optimisation variables gives the constraint gradients:

$$(8.53)$$

Note that when the integrand in these formula contains  $n_{\ominus}$  ( $n_{\oplus}$ ) the  $\xi$  variable is assumed to be taken over the previous (next) element.

Similar results can be found for three-dimensions (i.e. bicubic Hermite elements).

### Sobolov smoothing

In order to implement Sobolov smoothing in the form of the non-linear optimisation problem given in (8.46) we need to modify the residual vector by defining an additional residual as the Sobolov value for the mesh being fitted, that is

$$(8.54)$$

The objective function to minimise now becomes

The gradients of this additional residual can then be found by differentiating (8.41) with respect to the mesh parameters. Considering the case of two-dimensional fitting and breaking the domain up into elements we obtain Interpolating within the element using cubic Hermite elements and differentiating with respect to the three different mesh parameters within an element we obtain the additional residual gradients given in equations (??–??).

$$(8.55)$$

Note that all the above integrals are with respect to one element. All the contributions from each element need to be included to obtain the complete residual gradients for the optimisation parameters.

# Chapter 9

## Derivative BIE

### 9.1 Boundary Element Formulation

The BEM will be used in any region of the torso in which the conductivity can be reasonably taken to be constant (e.g. the lungs). Thus the equation to be solved in such a region is simply the Laplace equation. The conventional boundary integral equation for Laplace's equation,  $\nabla\phi = 0$  in a (closed) domain  $\Omega \subset \mathbb{R}^m$  ( $m = 2$  or  $3$ ) can be written as

$$C(P_0)\phi(P_0) = \left( G(P, P_0) \frac{\partial\phi(P)}{\partial n} - \frac{\partial G(P, P_0)}{\partial n} \phi(P) \right) d\Gamma(P) \quad (9.1)$$

where  $C(P_0) = 1$  if  $P_0 \in \Omega^0$ , and  $G(P, P_0)$  is the fundamental solution for the Laplace equation in either two or three dimensions (i.e.  $G(P, P_0) = -\frac{1}{2\pi} \log \|P - P_0\|$  or  $\frac{1}{4\pi} \|P - P_0\|^{-1}$ ).

The standard procedure in a boundary element formulation is to take the point  $P_0$  to be one of the nodes used to approximate the dependent variable  $\phi$ , and this generates one integral equation for each node. When Lagrange interpolation is used for  $\phi$  there is only one unknown per node (allowing for boundary conditions and assuming no free surfaces). This means that a square system of equations is produced and a unique solution can be found. However, when using cubic Hermite interpolation there is always more than one unknown per node - in two-dimensions there are 2 (with Neuman boundary conditions these are  $\phi$  and  $\frac{\partial\phi}{\partial s}$ ) and in three-dimensions there are 4 (with Neuman boundary conditions these are  $\phi$ ,  $\frac{\partial\phi}{\partial s_1}$ ,  $\frac{\partial\phi}{\partial s_2}$  and  $\frac{\partial^2\phi}{\partial s_1\partial s_2}$ ). Thus one needs to generate extra linearly independent equations. This is achieved by differentiating (9.1) in various directions [?], yielding a hypersingular integral formulation.

Taking the directional derivative of (9.1) at  $P_0$  in an (initially) arbitrary direction  $n_0$  ( $\|n_0\| = 1$ ) gives

$$\frac{\partial\phi(P_0)}{\partial n_0} = \int_{\partial\Gamma} \left( \frac{\partial G(P, P_0)}{\partial n} \frac{\partial\phi(P)}{\partial n} - \frac{\partial^2 G(P, P_0)}{\partial n \partial n_0} \phi(P) \right) d\Gamma(P) \quad (9.2)$$

valid  $\forall P_0 \in \Omega^0$ . The hypersingular fundamental solution  $\frac{\partial^2 G(P, P_0)}{\partial n \partial n_0}$  is given by either

$$\begin{aligned} & \frac{1}{2\pi} \left[ \frac{\mathbf{n} \cdot \mathbf{n}_0}{r^2} - \frac{2(\mathbf{r} \cdot \mathbf{n}_0)(\mathbf{r} \cdot \mathbf{n})}{r^4} \right] \quad (\text{two-dimensions}) \\ \text{or} \quad & \frac{1}{4\pi} \left[ \frac{\mathbf{n} \cdot \mathbf{n}_0}{r^3} - \frac{3(\mathbf{r} \cdot \mathbf{n}_0)(\mathbf{r} \cdot \mathbf{n})}{r^5} \right] \quad (\text{three-dimensions}) \end{aligned}$$

Here  $\mathbf{r}$  is the vector of modulus  $r = \|P - P_0\|$  from  $P_0$  to  $P$ ,  $\mathbf{n}$  is the unit outward normal vector and  $n_0$  is the unit vector in the direction of differentiation.

At this stage the integral expression (9.2) is well defined. With  $P_0$  placed on the boundary of  $\Omega$  the second integrand is termed hypersingular and it is the interpretation of this term and the procedure used to take  $P_0$  to the boundary that gives rise to the variety of integral expressions currently in use in hypersingular boundary integral formulations. To obtain a weakly-singular form of the derivative equation, one requires the following identities

$$\int_{\partial\Omega} \frac{\partial G(P, P_0)}{\partial n} d\Gamma(P) = -1 \quad \forall P_0 \in \Omega^0 \quad (9.3)$$

$$\int_{\partial\Omega} \frac{\partial^2 G(P, P_0)}{\partial n \partial n_0} d\Gamma(P) = 0 \quad \forall P_0 \in \Omega^0 \quad (9.4)$$

$$\int_{\partial\Omega} \left( n_k \frac{\partial G(P, P_0)}{\partial n_0} - (x_k - x_{0k}) \frac{\partial^2 G(P, P_0)}{\partial n \partial n_0} \right) d\Gamma(P) = n_{0k}(P_0) \quad \forall P_0 \in \Omega^0 \quad (9.5)$$

The first two of these identities are obtained from (9.1) and (9.2) respectively by putting  $\phi \equiv 1$ . The third identity is also obtained from (9.2) by substitution of  $x_k - x_{0k}$  (where  $x_k, x_{0k}, n_k, n_{0k}$  are the  $k$ th cartesian components of  $P, P_0, n$ , and  $n_0$  respectively).

The derivation of the weakly singular form of the derivative equation follows the traditional derivation of the conventional boundary integral equation. The point  $P_0$  is placed on the boundary of the domain  $\Omega$  and the domain is enlarged about this point to include a semicircular or hemispherical region of some small radius  $\varepsilon > 0$ . The limits of the integral expression (9.2) over each part of the enlarged domain are then considered in detail as  $\varepsilon \rightarrow 0$ , with judicious application of the above identities [?, ?]. The result is

$$\begin{aligned} & \int_{\partial\Omega} \frac{\partial^2 G(P, P_0)}{\partial n \partial n_0} \left( \phi(P) - \phi(P_0) - \frac{\partial \phi(P_0)}{\partial x_k} \right) d\Gamma(P) \\ & = \int_{\partial\Omega} n_k \frac{\partial G(P, P_0)}{\partial n_0} \left( \frac{\partial \phi(P)}{\partial n} - \frac{\partial \phi(P_0)}{\partial x_k} n_k(P) \right) d\Gamma(P) \end{aligned} \quad (9.6)$$

where now  $P_0 \in \partial\Omega$  (the singular point),  $n$  is a unit outward normal on  $\partial\Omega$ ,  $n_0$  is an arbitrary unit vector at  $P_0$  (the direction in which (??) was differentiated) and a sum over  $k$  is implied.



### 9.1.1 Discretisation

The surface is discretised into “boundary elements” i.e.  $\Omega = \bigcup_{m=1}^M \Omega_m$ . Introducing cubic Hermite interpolation for  $\phi$ , and, as above, approximating  $\frac{\partial \phi(P)}{\partial n}$  by  $N_\alpha \left( \frac{\partial \phi(P)}{\partial n} \right)_\alpha$  and also interpolating the geometry as  $x_k = M_\alpha x_k^\alpha$  for some set of basis functions  $\{M_\alpha\}$  (these will be taken to be cubic Hermite, but for now we leave these general), Equation (9.6) becomes

$$\begin{aligned} \sum_{m=1}^M \int_{\Gamma_m} \frac{\partial^2 G(P, P_0)}{\partial n \partial n_0} & \left( \Psi_\alpha^i \phi_i^\alpha - \phi(P_0) - \frac{\partial \phi(P_0)}{\partial x_k} (M_\alpha x_k^\alpha - x_{0k}) \right) d\Gamma(P) \\ & = \sum_{m=1}^M \int_{\Gamma_m} \frac{\partial G(P, P_0)}{\partial n_0} \left( N_\alpha \frac{\partial \phi^\alpha}{\partial n} - \frac{\partial \phi(P_0)}{\partial x_k} n_k(P) \right) d\Gamma(P) \quad (9.7) \end{aligned}$$

or, in terms of the local  $\xi$  coordinate

$$\begin{aligned} \sum_{m=1}^M \int_0^1 \frac{\partial^2 G(\xi, P_0)}{\partial n \partial n_0} & \left( \Psi_\alpha^i(\xi) \phi_i^\alpha - \phi(P_0) - \frac{\partial \phi(P_0)}{\partial x_k} (M_\alpha(\xi) x_k^\alpha - x_{0k}) \right) |J(\xi) d\xi \\ & = \sum_{m=1}^M \int_0^1 \frac{\partial G(\xi, P_0)}{\partial n_0} \left( N_\alpha(\xi) \frac{\partial \phi^\alpha}{\partial n} - \frac{\partial \phi(P_0)}{\partial x_k} n_k(\xi) \right) |J(\xi) d\xi \quad (9.8) \end{aligned}$$

As with the conventional boundary integral equation,  $P_0$  is located at each of the solution variable nodes in turn.

The global unknowns we are dealing with are nodal values of  $\phi$ ,  $\frac{\partial \phi}{\partial s}$  and  $\phi$ ,  $\frac{\partial \phi}{\partial n}$  (and also  $\frac{\partial^2 \phi}{\partial s \partial n}$  if cubic Hermite interpolation is used for the normal derivative). By adopting a local coordinate system  $(s, n)$  [or  $(\xi, n)$ ] one has, by the chain rule,

$$\frac{\partial \phi}{\partial x_k} = \left( \frac{\partial \phi}{\partial \sigma_l} \frac{\partial \sigma_l}{\partial x_k} \right) \quad (l = 1, 2) \quad (9.9)$$

where  $(\sigma_1, \sigma_2) = (s, n)$  [or  $(s_1, s_2, n)$  in three dimensions].  $\frac{\partial \sigma_l}{\partial x_k}$  can either be obtained exactly (as in some of the test problems) or, more generally, by inverting the matrix  $\left[ \frac{\partial x_k}{\partial \sigma_l} \right]$ . For a cubic

Hermite geometric mesh,  $\frac{\partial x_k}{\partial s}$  are known nodal values (either entered or calculated as part of the mesh fitting) so the matrix entries are all known. The use of (9.9) in (9.8) yields an integral expression, which, with the application of element scale factors (if required), involves only the required nodal unknowns as coefficients. We concentrate now on obtaining expressions suitable for numerical computation for these coefficients. As in [?] two separate cases must be considered - that for which  $P_0$  is contained in the element  $\Gamma_m$  being considered, and that for which  $P_0$  is removed from the current element  $\Gamma_m$ . For each case, we investigate both integrals of (9.8).

### Case 1: $P_0 \in \Gamma_m$ SHOULD BE NOT AN ELEMENT

In this case the integrands of both integrals in (9.8) are nonsingular and both integrals exist. The first integral can be written as

$$\begin{aligned} \phi_{,i}^\alpha \int_0^1 \frac{\partial^2 G(\xi, P_0)}{\partial n \partial n_0} \Psi_\alpha^i(\xi) |J(\xi)| d\xi &= \phi(P_0) \int_0^1 \frac{\partial^2 G(\xi, P_0)}{\partial n \partial n_0} |J(\xi)| d\xi \\ &- \frac{\partial \phi}{\partial \sigma_l}(P_0) \frac{\partial \sigma_l}{\partial x_k}(P_0) \int_0^1 \frac{\partial^2 G(\xi, P_0)}{\partial n \partial n_0} (M_\alpha(\xi) x_k^\alpha - x_{0k}) |J(\xi)| d\xi \end{aligned}$$

Since  $\phi_{,i}^\alpha$  is either a nodal value of  $\phi$  or  $\frac{\partial \phi}{\partial \xi}$ , multiplication of the appropriate first integrals by element scale factors generates coefficients of nodal values of  $\frac{\partial \phi}{\partial s}$ . Each integral expression is (9.10) is regular and standard Gaussian quadrature can be used to evaluate these.

The second integral can be written as

$$\frac{\partial \phi^\alpha}{\partial n} \int_0^1 \frac{\partial^2 G(\xi, P_0)}{\partial n \partial n_0} N_\alpha(\xi) |J(\xi)| d\xi - \frac{\partial \phi}{\partial \sigma_l}(P_0) \frac{\partial \sigma_l}{\partial x_k}(P_0) \int_0^1 \frac{\partial G(\xi, P_0)}{\partial n \partial n_0} n_k(\xi) |J(\xi)| d\xi \quad (9.11)$$

and again each integral can be evaluated by standard Gaussian quadrature. A more efficient grouping of the integrals in (9.10) and (9.11) can be obtained by grouping like coefficients, resulting in some computational saving.

### Case 2: $P_0 \in \Gamma_m$

In this case special care must be exercised to retain the weakly singular nature of the integral expressions in (9.8). A straightforward application of either (9.10) or (9.11) will result in divergent integrals. We identify with  $\beta$  the local node on element  $\Gamma_m$  corresponding to  $P_0$ . Keeping the appropriate coefficients grouped, we have from the first integral of (9.8)

$$\begin{aligned} &\phi(P_0) \int_0^1 \frac{\partial^2 G(\xi, P_0)}{\partial n \partial n_0} (\Psi_\beta^0(\xi) - 1) |J(\xi)| d\xi + \phi_{,i}^{\alpha \{ \alpha \neq \beta \}} \int_0^1 \frac{\partial^2 G(\xi, P_0)}{\partial n \partial n_0} (\Psi_\alpha^i(\xi) - 1) |J(\xi)| d\xi \\ &+ \frac{\partial \phi}{\partial s}(P_0) \int_0^1 \frac{\partial^2 G(\xi, P_0)}{\partial n \partial n_0} \left[ \frac{\partial s}{\partial \xi}(P_0) \Psi_\beta^1(\xi) - \frac{\partial s}{\partial x_k}(P_0) (M_\alpha(\xi) x_k^\alpha - x_{0k}) \right] |J(\xi)| d\xi \\ &- \frac{\partial \phi}{\partial n}(P_0) \int_0^1 \frac{\partial^2 G(\xi, P_0)}{\partial n \partial n_0} \frac{\partial n}{\partial x_k}(P_0) (M_\alpha(\xi) x_k^\alpha - x_{0k}) |J(\xi)| d\xi \end{aligned} \quad (9.12)$$

Here we have explicitly included the element scale factors, and the second integral involves a sum over  $\alpha$  with  $\alpha \neq \beta$ . With this grouping, all integrals are at most weakly singular and amenable to numerical integration. The second integral of (9.8) is more straightforward, although certain

FIGURE 9.1: The element splitting used when  $P_0$  is at local node 1. The individual transformations yield Jacobians that reduce the order of the singularity in the otherwise singular boundary element integrals.

groupings must still be retained. The appropriate expression for numerical integration is

$$\begin{aligned} \frac{\partial \phi}{\partial n}(P_0) &= \int_0^1 \frac{\partial G(\xi, P_0)}{\partial n_0} \left[ N_\beta(\xi) - \frac{\partial n}{\partial x_k}(P_0) n_k(\xi) \right] |J(\xi)| d\xi \\ &- \frac{\partial \phi}{\partial n} \int_0^1 \frac{\partial G(\xi, P_0)}{\partial n_0} N_\alpha(\xi) |J(\xi)| d\xi \\ &- \frac{\partial \phi}{\partial s}(P_0) \int_0^1 \frac{\partial G(\xi, P_0)}{\partial n_0} \frac{\partial s}{\partial x_k}(P_0) n_k(\xi) |J(\xi)| d\xi \end{aligned}$$

The above equations provide numerically well-behaved expressions for the coefficients of the discretised derivative boundary integral equation. It only remains to specify the direction(s) of  $n_0$ . After extensive testing [?] we concluded that the direction of differentiation should be that of  $s$  (i.e. tangential) for two-dimensional problems (where one extra equation is required) and for three-dimensional problems, one should differentiate in both the  $s_1$  and  $s_2$  directions (and set the cross derivative coefficients to zero).

## 9.2 Three-dimensional element splitting

If the singular point  $P_0$  is contained in the current element then the element is sub-divided in local  $(\xi_1, \xi_2)$  space according to the location of  $P_0$ . Each of these triangular elements is then transformed to a regular four-noded element in another space [say  $(s, t)$  space] in such a way that the Jacobian of this last transformation cancels the dominant singularity in the integrand (which is  $O(\frac{1}{r})$  in the original space, where  $r$  is the distance from the singular point  $P_0$ ). The numerical integrations are then performed over the elements in the  $(s, t)$  space. We use the following subdivisions and transformations. In each case the absolute value of the Jacobian of the transformation for element  $A$  is  $s$  and for element  $B$  is  $t$ .

### 9.2.1 $P_0$ at local node 1

Sub-divide from local node 1 to 4, giving two elements  $A$  and  $B$ .

Transformation for element  $A$ :

$$s = \xi_1 \quad t = \frac{\xi_2}{\xi_1} \quad (\text{inverse mapping is } \xi_1 = s \quad \xi_2 = st)$$

Transformation for element  $B$ :

$$s = \frac{\xi_2}{\xi_1} \quad t = \xi_2 \quad (\text{inverse mapping is } \xi_1 = st \quad \xi_2 = t)$$

FIGURE 9.2: The two Hermite “simplexes” and their connection to standard cubic Hermite elements.

### 9.2.2 $P_o$ at local node 2

Sub-divide from local node 2 to 3. Element  $A$  contains local nodes 1, 2 and 3.

Transformation for element  $A$ :

$$s = 1 - \xi_1 \quad t = \frac{1-\xi_1-\xi_2}{1-\xi_1} \quad (\text{inverse mapping is } \xi_1 = 1 - s \quad \xi_2 = s(1 - t))$$

Transformation for element  $B$ :

$$s = \frac{1-\xi_1}{\xi_2} \quad t = \xi_2 \quad (\text{inverse mapping is } \xi_1 = 1 - st \quad \xi_2 = t)$$

### 9.2.3 $P_o$ at local node 3

Sub-divide from local node 2 to 3. Element  $A$  contains local nodes 2,3 and 4.

Transformation for element  $A$ :

$$s = \xi_1 \quad t = \frac{1-\xi_2}{\xi_1} \quad (\text{inverse mapping is } \xi_1 = s \quad \xi_2 = 1 - st)$$

Transformation for element  $B$ :

$$s = \frac{1-\xi_1-\xi_2}{1-\xi_2} \quad t = 1 - \xi_2 \quad (\text{inverse mapping is } \xi_1 = t(1 - s) \quad \xi_2 = 1 - t)$$

### 9.2.4 $P_o$ at local node 4

Sub-divide from local node 1 to 4. Element  $A$  contains local nodes 1,3 and 4.

Transformation for element  $A$ :

$$s = 1 - \xi_1 \quad t = \frac{1-\xi_2}{1-\xi_1} \quad (\text{inverse mapping is } \xi_1 = 1 - s \quad \xi_2 = 1 - st)$$

Transformation for element  $B$ :

$$s = \frac{1-\xi_1}{1-\xi_2} \quad t = 1 - \xi_2 \quad (\text{inverse mapping is } \xi_1 = 1 - st \quad \xi_2 = 1 - t)$$

## 9.3 Hermite “Simplexes”

We describe here the special three-noded Hermite elements that have been used to close a cubic Hermite surface in three-dimensional space. The need for such elements was illustrated in Figure ?? . We describe the two special elements that were used - one in which the derivatives come to a point at local node 3 (the top), and one in which the derivatives come together at local node 1 (the bottom).

### 9.3.1 Apex at local node 3

With reference to Figure 9.2 a, we construct the appropriate two-dimensional interpolation functions via a tensor product (instead of using area functions, which are commonly used in three-noded elements). The tensor product formulation requires a description of the basis functions to be used in each direction. We use standard Hermite interlotion in the  $\xi_1$  direction, so that any standard cubic Hermite element sharing this edge maintains consistent interpolation. In the  $\xi_2$  direction we require the interpolation function to interpolate nodal values of function and derivative at the first node, and only the value of the function at the second node (i.e. we have dropped the arclength derivative at the second node since it is no longer uniquely defined). Thus we require

$$\mathbf{x}(\xi_2) = \Psi_1(\xi_2)\mathbf{x}_1 + \Psi_2(\xi_2)\frac{\partial \mathbf{x}_1}{\partial \xi_2} + \Psi_3(\xi_2)\mathbf{x}_3$$

where

$$\Psi_1(0) = 1, \quad \Psi_1(1) = 0, \quad \frac{\partial \Psi_1}{\partial \xi_2}(0) = 0$$

$$\Psi_2(0) = 0, \quad \Psi_2(1) = 0, \quad \frac{\partial \Psi_2}{\partial \xi_2}(0) = 1$$

$$\Psi_3(0) = 0, \quad \Psi_3(1) = 1, \quad \frac{\partial \Psi_3}{\partial \xi_2}(0) = 0$$

These conditions yield

$$\begin{aligned} \Psi_1(\xi) &= 1 - \xi^2 \\ \Psi_2(\xi) &= \xi - \xi^2 \\ \Psi_3(\xi) &= \xi^2 \end{aligned}$$

and the appropriate two-dimensional basis function is obtained from a tensor product of the standard Hermite basis function and the family given above.

### 9.3.2 Apex at local node 1

Again, with reference to Figure 9.2 b, we construct the appropriate two-dimensional interpolation functions via a tensor product with standard Hermite interpolation in the  $\xi_1$  direction. In the  $\xi_2$  direction we require the interpolation function to interpolate nodal values of function at the first node, and the value of the function and derivative at the second node. Thus we require

$$\mathbf{x}(\xi_2) = \zeta_1(\xi_2)\mathbf{x}_1 + \zeta_2(\xi_2)\frac{\partial \mathbf{x}_3}{\partial \xi_2} + \zeta_3(\xi_2)\mathbf{x}_3$$

where

$$\zeta_1(0) = 1, \quad \zeta_1(1) = 0, \quad \frac{\partial \zeta_1}{\partial \xi_2}(1) = 0$$

$$\zeta_2(0) = 0, \quad \zeta_2(1) = 0, \quad \frac{\partial \zeta_2}{\partial \xi_2}(1) = 1$$

$$\zeta_3(0) = 0, \quad \zeta_3(1) = 1, \quad \frac{\partial \zeta_3}{\partial \xi_2}(1) = 0$$

These conditions yield

$$\begin{aligned} \zeta_1(\xi) &= (\xi - 1)^2 \\ \zeta_2(\xi) &= \xi^2 - \xi \\ \zeta_3(\xi) &= 2\xi - \xi^2 \end{aligned}$$

and the appropriate two-dimensional basis function are obtained as above.

# Chapter 10

## Domain Integrals in the BEM

### 10.1 Achieving a Boundary Integral Formulation

The principal advantage of the BEM over other numerical methods is the ability to reduce the problem dimension by one. This property is advantageous as it reduces the size of the solution system leading to improved computational efficiency. This reduction of dimension also eases the burden on the engineer as it is only necessary to construct a boundary mesh to implement the BEM.

To achieve this reduction of dimension it is necessary to formulate the governing equation as a boundary integral equation. To achieve a boundary integral formulation it is necessary to find an appropriate reciprocity relationship for the problem and to determine an appropriate fundamental solution. If either of these requirements cannot be satisfied then a boundary integral formulation cannot be achieved. The most common difficulty in applying the BEM is in determining an appropriate fundamental solution.

A linear differential equation can be expressed in operator form as  $Lu = \gamma$  where  $L$  is a linear operator,  $\gamma$  is an inhomogeneous source term and  $u$  is the dependent variable. The fundamental solution for this equation is a solution of

$$L^*\omega(\mathbf{x}, \boldsymbol{\xi}) + \delta(\boldsymbol{\xi}) = 0 \quad (10.1)$$

where  $*$  indicates the adjoint of the operator  $L$  and  $\delta$  is the Dirac delta function. No specific boundary conditions are prescribed but in some cases regularity conditions at infinity need to be satisfied. The fundamental solution is a Green's function which is not required to satisfy any boundary conditions and is therefore also commonly termed the free-space Green's function.

The mathematical theory required to determine the fundamental solution of a constant coefficient PDE is well-developed and has been used successfully to determine the fundamental solutions for a wide range of constant coefficient equations [?] [?] [?]. Fundamental solutions are known and have been published for many of the most important equations in engineering such as Laplace's equation, the diffusion equation and the wave equation [?]. However, by no means can it be guaranteed that the fundamental solution to a specific differential equation is known. In particular, PDEs with variable coefficients do not, in general, have known fundamental solutions. If the fundamental solution to an operator cannot be found then domain integrals cannot be completely removed from the integral formulation. Domain integrals will also arise for inhomogeneous equations.

wu:1985 argued that the BEM has several advantages over other numerical methods which

justify its use for many practical problems - even in cases where domain integration is required. He argued that for problems such as flow problems a wide range of phenomena are described by the same governing equations. What distinguishes these phenomena is the boundary conditions of the problem. For this reason accurate description of the boundary conditions is vital for solution accuracy. The BEM generates a formulation involving both the dependent variable  $u$  and the flux  $q$ . This allows flux boundary conditions to be applied directly which cannot be achieved in either the finite element or finite difference methods.

Another advantage of the BEM over other numerical methods is that it allows an explicit expression for the solution at an internal point. This allows a problem to be subdivided into a number of zones for which the BEM can be applied individually. This zoning approach is suited to problems with significantly different length scales or different properties in different areas.

Domain integration can be simply and accurately performed in the BEM. However, the presence of domain integrals in the BEM formulation negates one of the principal advantages of the BEM in that the problem dimension is no longer reduced by one. Several methods have been developed which allow domain integrals to be expressed as equivalent boundary integrals. In this section these methods will be discussed.

## 10.2 Removing Domain Integrals due to Inhomogeneous Terms

Inhomogeneous PDEs occur for a large number of physical problems. An inhomogeneous term may arise due to a number of factors including a source term, a body force term, or due to initial conditions in time-dependent problems. An inhomogeneous linear PDE can be expressed in operator form as  $Lu = \gamma$  where  $\gamma$  is a known function of position or a non-zero constant. If the fundamental solution is known for the operator  $L$ , the resulting BEM formulation will be

$$Hu - Gq = - \int_{\Omega} \gamma \omega d\Omega \quad (10.2)$$

The domain integral in this formulation does not involve any unknowns so domain integration can be used directly to solve this equation. This requires discretising the domain into internal cells in much the same way as for the finite element method. As the domain integral does not involve any unknown values accurate results can generally be achieved using a fairly coarse mesh. This method is simple and has been shown to produce accurate results [?]. This approach, however, requires a domain discretisation and a numerical domain integration procedure which reduces the attraction of the BEM over domain-based numerical methods.

### 10.2.1 The Galerkin Vector technique

For some particular forms of the inhomogeneous function  $\gamma$  the domain integral can be transformed directly into boundary integrals.

Consider the Poisson equation  $\nabla^2 u = \gamma$ . Applying the BEM gives an equation of the form of



Equation (10.2). Using Green's second identity

$$\int_{\Omega} (\gamma \nabla^2 v - v \nabla^2 \gamma) d\Omega = \int_{\Gamma} \left( \gamma \frac{\partial v}{\partial n} - v \frac{\partial \gamma}{\partial n} \right) d\Gamma \quad (10.3)$$

domain integration can be avoided for certain forms of  $\gamma$ . If a  $v$  can be found which satisfies  $\nabla^2 v = \omega$ , where  $\omega$  is the fundamental solution of Laplace's equation, then for the specific case of  $\gamma$  being harmonic ( $\nabla^2 \gamma = 0$ ) Green's second identity can be reduced to

$$\int_{\Omega} \gamma \omega d\Omega = \int_{\Gamma} \left( \gamma \frac{\partial v}{\partial n} - v \frac{\partial \gamma}{\partial n} \right) d\Gamma \quad (10.4)$$

Therefore if a Galerkin vector can be found and  $\gamma$  is harmonic the domain integral in Equation (10.2) can be expressed as equivalent boundary integrals.

fairweather:1979 determined the Galerkin vector for the two-dimensional Poisson equation and rangogni:1982 determined the Galerkin vector for the three-dimensional Poisson equation. dan-son:1981 showed how this method can be applied successfully for a number of physical problems involving linear isotropic problems with body forces. He considered the practical cases where the body force term arose due to either a constant gravitational load, rotation about a fixed axis or steady-state thermal loading. In each of these cases the domain integral can be expressed as equivalent boundary integrals.

This Galerkin vector approach provides a simple method of expressing domain integrals as equivalent boundary integrals. Unfortunately, it only applies to specific forms of the inhomogeneous term  $\gamma$  (*i.e.*,  $\gamma$  is required to be harmonic).

### 10.2.2 The Monte Carlo method

Domain discretisation could be avoided by using a Monte Carlo technique. This technique approximates a domain integral as a sum of the integrand at a number of random points. Specifically, in two dimensions, a domain integral  $I$  is approximated as

$$I \approx \frac{A}{N} \sum_{i=1}^N f(x_i, y_i) \quad (10.5)$$

where  $f(x_i, y_i)$  is the value of the integrand at random point  $(x_i, y_i)$ ,  $N$  is the number of random points used and  $A$  is the area of the region over which the integration is performed. This approximation allows a domain integral to be approximated by a summation over a set of random points so domain integration can be performed without requiring a domain mesh. This method has the secondary advantage of allowing the integration to be performed over a simple geometry enclosing the problem domain - if a random point is not in the problem domain its contribution is ignored.

The method was proposed by gipson:1987. Gipson has successfully applied this method to a number of Poisson-type problems. Unfortunately this method often proves to be computationally expensive as a large number of integration points are needed for accurate domain integration. Gipson argues however that, as this method removes the burden of preparing a domain mesh,

the extra computational expense is justified.

### 10.2.3 Complementary Function-Particular Integral method

A more general approach can be developed using particular solutions. Consider the linear problem  $Lu = \gamma$ .  $u$  can be considered as the sum of the complementary function  $u_c$ , which is a solution of the homogeneous equation  $Lu_c = 0$ , and a particular solution  $u_p$  which satisfies  $Lu_p = \gamma$  but is not required to satisfy the boundary conditions of the problem. Applying BEM to the governing equation using the expansion  $u = u_c + u_p$  gives

$$Hu - Gq = Hu_p - Gq_p \quad (10.6)$$

If a particular solution  $u_p$  can be found, all values on the right-hand-side of Equation (10.6) are known - reducing the problem to

$$Hu - Gq = d \quad (10.7)$$

where  $d$  is a vector of known values. This linear system can be solved by applying boundary conditions.

This approach can be applied in a situation where an analytic expression for a particular solution can be found. Unfortunately particular solutions are generally only known for simple operators and for simple forms of  $\gamma$ . Alternatively an approximate particular solution could be calculated numerically. zheng:1991 proposed a method where a particular solution is determined by approximating the inhomogeneous source term using a global interpolation function. This approach is a special case of a more general method known as the dual reciprocity boundary element method.

## 10.3 Domain Integrals Involving the Dependent Variable

Consider the linear homogeneous PDE  $Lu = 0$ . For many operators the fundamental solution to the operator  $L$  may be unobtainable or may be in an unusable form. This is especially likely if  $L$  involves variable coefficients for which case it has been shown that it is particularly difficult to find a fundamental solution. Instead, a BEM formulation can be derived based on a related operator  $\hat{L}$  with known fundamental solution. A BEM formulation for  $Lu = 0$  based on the operator  $\hat{L}$  will be of the form

$$Hu - Gq = - \int_{\Omega} (\hat{L} - L) u \omega d\Omega \quad (10.8)$$

where  $\omega$  is the fundamental solution corresponding to the operator  $\hat{L}$ . This integral equation is similar to Equation (10.2). However in this case the domain integral term involves the dependent variable  $u$ . This problem could be solved using domain integration where the internal nodes are treated as formal problem unknowns.

### 10.3.1 The Perturbation Boundary Element Method

rangogni:1986 proposed solving variable coefficient PDEs by coupling the boundary element method with a perturbation method. He considered the two-dimensional generalised Laplace equation

$$\nabla \cdot (\kappa(x, y) \nabla V(x, y)) = 0 \quad (10.9)$$

Using the substitution  $V(x, y) = \frac{1}{\kappa} \frac{1}{2} u(x, y)$  Equation (10.9) can be recast as a heterogeneous Helmholtz equation

$$\nabla^2 u + f(x, y) u = 0 \quad (10.10)$$

where  $f$  is a known function of position.

rangogni:1986 treated this equation as a perturbation about Laplace's equation. He considered the class of equations

$$\nabla^2 u + \varepsilon f(x, y) u = 0 \quad \text{where } 0 \leq \varepsilon \leq 1 \quad (10.11)$$

for which he sought a solution of the form

$$u = u_0 + \varepsilon u_1 + \varepsilon^2 u_2 + \dots = \sum_{j=0}^{\infty} u_j \varepsilon^j \quad (10.12)$$

Substituting Equation (10.12) into Equation (10.11) and grouping powers of  $\varepsilon$  gives

$$\nabla^2 u_0 + \varepsilon (\nabla^2 u_1 + f u_0) + \varepsilon^2 (\nabla^2 u_2 + f u_1) + \dots = 0 \quad (10.13)$$

A solution will only exist for all values of  $\varepsilon$  if the terms at each power of  $\varepsilon$  equal zero. This allows Equation (10.13) to be treated as an infinite series of distinct problems which can be solved using the boundary element method.  $u_0$  can be found by solving  $\nabla^2 u_0 = 0$  which Rangogni assumes will satisfy the boundary conditions of the original problem. Each successive  $u_j$  can then be found by solving a Poisson equation with homogeneous boundary conditions as  $u_{j-1}$  has been previously determined. Rangogni used a domain discretisation to solve these Poisson problems.

Equation (10.10) is a particular member of this family of equations for which  $\varepsilon = 1$ . The solution to Equation (10.10) is therefore given by  $\sum_{j=0}^{\infty} u_j$ . Rangogni reported that in practice this series converged rapidly and in his numerical examples he achieved accurate results using only  $u_0$  and  $u_1$ .

rangogni:1991 extended this coupled perturbation - boundary element method to the general second-order variable coefficient PDE

$$\nabla^2 u + f(x, y) \frac{\partial u}{\partial x} + g(x, y) \frac{\partial u}{\partial y} = h(x, y) \quad (10.14)$$

He considered the family of equations

$$\nabla^2 u + \varepsilon \left[ f(x, y) \frac{\partial u}{\partial x} + g(x, y) \frac{\partial u}{\partial y} \right] = h(x, y) \quad (0 \leq \varepsilon \leq 1) \quad (10.15)$$

Applying the perturbation method to this family of equations allows Equation (10.15) to be expressed as an infinite series of distinct Poisson equations which can be solved using the boundary element method. Again Rangogni used an domain mesh to solve these Poisson equations. Rangogni found that in practice convergence was rapid and accurate results were produced.

gipson:1987b considered a class of hyperbolic and elliptic problems which can be transformed into an inhomogeneous Helmholtz equation. They used the perturbation method to recast this as an infinite sequence of Poisson equations. They avoided domain discretisation by using a Monte Carlo integration technique [?] to evaluate the required domain integrals.

lafe:1987 used the perturbation method to solve steady-state groundwater flow problems in heterogeneous aquifers. They showed the method produced accurate results for simply varying hydraulic conductivities with convergence after two or three terms. lafe:1987 investigated the convergence of the perturbation method. They found that for rapidly varying hydraulic conductivity convergence is not guaranteed. From this investigation they concluded that accurate results can be obtained so long as the hydraulic conductivity does not vary by more than one order of magnitude within the solution domain. If the hydraulic conductivity variation is more significant they recommend using the perturbation method in conjunction with a subregion technique so that the variation of conductivity within each subregion satisfies their requirements. This process could become computationally expensive, particularly if convergence is not rapid, as the solution of multiple subproblems will be required within each subregion.

### 10.3.2 The Multiple Reciprocity Method

The multiple reciprocity method (MRM) was initially proposed by nowak:1987 for the solution of transient heat conduction problems. Since then the method has been successfully applied to a wide range of problems. The MRM can be viewed as a generalisation of the Galerkin vector approach. Instead of using one higher-order fundamental solution, the Galerkin vector, to convert the remaining domain integrals to equivalent boundary integrals a series of higher-order fundamental solutions is used.

Consider the Poisson equation

$$\nabla^2 u = b_0 \quad (10.16)$$

where  $b_0 = b_0(\mathbf{x})$  is a known function of position. Applying BEM to this equation, using the fundamental solution to the Laplace operator, gives

$$c(\boldsymbol{\xi}) u(\boldsymbol{\xi}) + \int_{\Gamma} u \frac{\partial \omega_0}{\partial n} d\Gamma + \int_{\Omega} b_0 \omega_0 d\Omega = \int_{\Gamma} \omega_0 \frac{\partial u}{\partial n} d\Gamma \quad (10.17)$$

where  $\omega_0$  is the known fundamental solution to Laplace's equation applied at point  $\boldsymbol{\xi}$ . To avoid domain discretisation the domain integral in Equation (10.17) needs to be expressed as equivalent boundary integrals. Using MRM this is achieved by defining a higher-order fundamental solution  $\omega_1$  such that

$$\nabla^2 \omega_1 = \omega_0 \quad (10.18)$$

Using this higher-order fundamental solution the domain integral in Equation (10.17) can be writ-

ten as

$$\int_{\Omega} b_0 \omega_0 d\Omega = \int_{\Omega} b_0 \nabla^2 \omega_1 d\Omega \quad (10.19)$$

or

$$\int_{\Omega} b_0 \omega_0 d\Omega = \int_{\Gamma} \left( u \frac{\partial \omega_1}{\partial n} - \omega_1 \frac{\partial u}{\partial n} \right) d\Gamma + \int_{\Omega} \omega_1 \nabla^2 b_0 d\Omega \quad (10.20)$$

This formulation has generated a new domain integral.  $b_0$  is a known function so we can introduce a new function  $b_1$  which can be determined analytically from the relationship

$$b_1 = \nabla^2 b_0 \quad (10.21)$$

giving

$$\int_{\Omega} \omega_1 \nabla^2 b_0 d\Omega = \int_{\Omega} \omega_1 b_1 d\Omega \quad (10.22)$$

This process can be repeated by introducing a new higher-order fundamental solution  $\omega_2$  such that

$$\nabla^2 \omega_2 = \omega_1 \quad (10.23)$$

and continuing until convergence is reached.

This procedure is based on the recurrence relationships

$$b_{j+1} = \nabla^2 b_j \quad \text{for } j = 0, 1, 2, \dots \quad (10.24)$$

$$\nabla^2 \omega_{j+1} = \omega_j \quad \text{for } j = 0, 1, 2, \dots \quad (10.25)$$

Using these recurrence relationships gives the boundary integral formulation

$$c(\boldsymbol{\xi}) u(\boldsymbol{\xi}) + \int_{\Gamma} \left( u \frac{\partial \omega_0}{\partial n} - \omega_0 \frac{\partial u}{\partial n} \right) d\Gamma + \sum_{j=0}^{\infty} \int_{\Gamma} \left( b_j \frac{\partial \omega_{j+1}}{\partial n} - \omega_{j+1} \frac{\partial b_j}{\partial n} \right) d\Gamma = 0 \quad (10.26)$$

which is an exact formulation if the infinite series converges. Errors are only introduced at the stage of boundary discretisation.

Introducing interpolation functions and discretising the boundary gives the matrix system

$$\mathbf{H}_0 \mathbf{u} - \mathbf{G}_0 \mathbf{q} = \sum_{j=0}^{\infty} (\mathbf{H}_{J+1} \mathbf{p}_j - \mathbf{G}_{J+1} \mathbf{r}_j) \quad (10.27)$$

where  $\mathbf{H}_{J+1}$  and  $\mathbf{G}_{J+1}$  are influence coefficient matrices corresponding to the higher-order fundamental solutions and  $\mathbf{p}_j$  and  $\mathbf{r}_j$  contain the nodal values of  $b_j$  and its normal derivative.

The MRM can be applied based on operators other than the Laplace operator. This approach relies on knowledge of the higher-order fundamental solutions necessary for application of the method. These solutions have been determined and successfully used for the Laplace operator in both two and three dimensions but the extension of the method to other equation types needs

further research. itagaki:1993 have determined the higher order fundamental solutions for the two-dimensional modified Helmholtz equation.

The MRM can be extended to other equations by allowing the forcing function  $b_0$  to be a general function such that  $b_0 = b_0(\mathbf{x}, u, t)$ . The MRM will be restricted to cases where the recurrence relationships - Equations (10.24) and (10.25) - can be employed. brebbia:1989 have applied the MRM to the Helmholtz equation  $\nabla^2 u + \kappa^2 u = 0$  where  $b_0 = -\kappa^2 u$  and the recurrence relationship defined by Equation (10.24) becomes simply

$$u_{j+1} = \nabla^2 u_j = -\kappa^2 u \quad (10.28)$$

In this case the boundary integral formulation will be

$$c(\boldsymbol{\xi}) u(\boldsymbol{\xi}) + \sum_{j=0}^{\infty} \int_{\Gamma} \kappa^{2j} \left( u \frac{\partial \omega_j}{\partial n} - \omega_j \frac{\partial u}{\partial n} \right) d\Gamma = 0 \quad (10.29)$$

### 10.3.3 The Dual Reciprocity Boundary Element Method

#### Equation Derivation

The dual reciprocity boundary element method (DR-BEM) was developed to avoid the need for domain integration in cases where the fundamental solution of the governing differential equation is unknown or is impractical to apply. Instead the DR-BEM is applied using an appropriate related operator with known fundamental solution. The most common choice is the Laplace operator [?] and in this chapter the DR-BEM will be illustrated for this choice.

Consider a second-order PDE which can be expressed in the form

$$\nabla^2 u = b \quad (10.30)$$

The forcing function  $b$  can be completely general. If  $b = b(\mathbf{x})$  then  $b$  is a known function of position and the differential equation described is simply the Poisson equation. For potential problems  $b = b(\mathbf{x}, u)$  and for transient problems  $b = b(\mathbf{x}, u, t)$ . Applying the BEM to Equation (10.30) will give

$$\mathbf{H}\mathbf{u} - \mathbf{G}\mathbf{q} = - \int_{\Omega} b\omega d\Omega \quad (10.31)$$

where  $\omega$  is the known fundamental solution to Laplace's equation. The aim of the DR-BEM is to express the domain integral due to the forcing function  $b$  as equivalent boundary integrals.

The DR-BEM uses the idea of approximating  $b$  using interpolation functions. A global approximation to  $b$  of the form

$$b = \sum_{j=1}^M \alpha_j f_j \quad (10.32)$$

is proposed.  $\alpha_j$  are unknown coefficients and  $f_j$  are approximating functions used in the interpolation and are generally chosen to be functions of the source point and the field point of the fun-

damental solution. The approximating functions  $f_j$  are applied at  $M$  different collocation points - called poles - generally most, but not all, of which are located on the boundary of the problem domain.

As discussed in the previous chapter the solution to a linear PDE  $Lu = \gamma$  can be constructed as the sum of a complimentary function  $u_c$  (which satisfies the homogeneous equation  $Lu_c = 0$ ) and a particular solution  $u_p$  to the equation  $Lu_p = \gamma$ . Instead of using a single particular solution, which may be difficult to determine, the DR-BEM employs a series of particular solutions  $\hat{u}_j$  which are related to the approximating functions  $f_j$  as shown in Equation (10.33).

$$\nabla^2 \hat{u}_j = f_j \quad j = 1, \dots, M \quad (10.33)$$

By substituting Equations (10.32) and (10.33) into Equation (10.30) the forcing function  $b$  is approximated by a weighted summation of particular solutions to the Poisson equation.

$$\nabla^2 u = \sum_{j=1}^M \alpha_j \nabla^2 \hat{u}_j \quad (10.34)$$

The DR-BEM essentially constructs an approximate particular solution to the governing PDE as a summation of localised particular solutions.

With the governing equation rewritten in the form of Equation (10.34) the standard boundary element approach can be applied. Equation (10.34) is multiplied by a weighting function  $\omega$  and integrated over the domain. Green's theorem is applied twice and the fundamental solution of the Laplacian is used to remove the remaining domain integrals. The name dual reciprocity BEM is derived from the application of reciprocity relationships to both sides of Equation (10.34). After applying these steps Equation (10.35) is obtained, where the fundamental solution pole is applied at point  $\xi$ .

$$\begin{aligned} c(\xi) u(\xi) + \int_{\Gamma} \left( u \frac{\partial \omega}{\partial n} - \omega \frac{\partial u}{\partial n} \right) d\Gamma \\ = \sum_{j=1}^M \alpha_j \left( c(\xi) u_j(\xi) + \int_{\Gamma} \left( \hat{u}_j \frac{\partial \omega}{\partial n} - \omega \frac{\partial \hat{u}_j}{\partial n} \right) d\Gamma \right) \end{aligned} \quad (10.35)$$

In implementing a numerical solution of this equation similar steps are taken as for the standard BEM. The boundary is discretised into elements and interpolation functions are introduced to approximate the dependent variable within each element.

The form of each  $\hat{u}_j$  is known from Equation (10.33) once the approximating functions  $f_j$  have been defined. It is not necessary to use interpolation functions to approximate each  $\hat{u}_j$ . However by using the same interpolation functions to approximate  $u$  and  $\hat{u}_j$  the numerical implementation will generate the same matrices  $\mathbf{H}$  and  $\mathbf{G}$  on both sides of Equation (10.35). The error generated by approximating each  $\hat{u}_j$  in this manner has been found to be small and can be justified by the improved computational efficiency of the method [?].

The application of this method results in the system

$$\mathbf{H}\mathbf{u} - \mathbf{G}\mathbf{q} = \sum_{j=1}^{N+I} \alpha_j (\mathbf{H}\hat{\mathbf{u}}_j - \mathbf{G}\hat{\mathbf{q}}_j) \quad (10.36)$$

where the  $M$  poles were chosen to be the  $N$  boundary nodes plus  $I$  internal points so that  $M = N + I$ . Although it is not generally necessary to include poles at internal points it has been found that in general improved accuracy is achieved by doing so [?]. It has been shown that for many problems [?] [?] using boundary points only in this procedure is insufficient to define the problem. In general using internal points is likely to improve the solution accuracy as it increases the number of degrees of freedom. No theory has been developed of how many internal collocation points should be used for optimal accuracy, or where these points should be positioned within the problem domain. Using internal poles in this interpolation does not require domain discretisation - it is only necessary to specify the coordinates of the internal collocation points. The internal points can be chosen to be locations where the solution is of interest.

The  $\hat{\mathbf{u}}_j$  and  $\hat{\mathbf{q}}_j$  vectors can be treated as columns of the matrices  $\hat{\mathbf{U}}$  and  $\hat{\mathbf{Q}}$  respectively. This allows Equation (10.36) to be rewritten as

$$\mathbf{H}\mathbf{u} - \mathbf{G}\mathbf{q} = (\mathbf{H}\hat{\mathbf{U}} - \mathbf{G}\hat{\mathbf{Q}}) \boldsymbol{\alpha} \quad (10.37)$$

where  $\boldsymbol{\alpha}$  is a vector containing the nodal values of  $\alpha$ . To solve this system it is necessary to evaluate  $\boldsymbol{\alpha}$ .  $\boldsymbol{\alpha}$  is defined by Equation (10.32) which, for the nodal values, can be expressed in matrix form as  $\mathbf{b} = \mathbf{F}\boldsymbol{\alpha}$ . If the  $\mathbf{F}$  matrix is nonsingular this expression can be rearranged to give Equation (10.38) which provides an explicit expression for  $\boldsymbol{\alpha}$ .

$$\boldsymbol{\alpha} = \mathbf{F}^{-1}\mathbf{b} \quad (10.38)$$

Including this explicit expression for  $\boldsymbol{\alpha}$  in Equation (10.37) gives

$$\mathbf{H}\mathbf{u} - \mathbf{G}\mathbf{q} = (\mathbf{H}\hat{\mathbf{U}} - \mathbf{G}\hat{\mathbf{Q}}) \mathbf{F}^{-1}\mathbf{b} \quad (10.39)$$

The approach taken to solve this equation will depend on the form of  $\mathbf{b}$ .

### The Approximating Function $f$

The accuracy of the DR-BEM hinges on the accuracy of the global approximation to the forcing function  $b$  (defined by Equation (10.32)). Therefore the choice of the approximating functions  $f_j$  is a key consideration when implementing the DR-BEM. The only requirement so far prescribed on the form of the approximating functions  $f_j$  is that the  $\mathbf{F}$  matrix generated should be nonsingular and that the related particular solutions  $\hat{\mathbf{u}}_j$  can be determined and can be expressed in a practical closed form. Some work has been conducted into investigating what form of  $f_j$  should be used in a given situation to provide the highest accuracy and computational efficiency.

Usually a form of  $f_j$  is defined and this can be used, applying Equation (10.33), to specify  $\hat{\mathbf{u}}$  and  $\hat{\mathbf{q}}$ . The fundamental solution of Laplace's equation is  $\omega(\mathbf{x}, \boldsymbol{\xi}) = -\frac{1}{2\pi} \ln r$  in two-dimensional



space and  $\omega(\mathbf{x}, \boldsymbol{\xi}) = \frac{1}{4\pi r}$  in three-dimensional space - where  $r$  is the Euclidean distance between the field point  $\mathbf{x}$  and the source point  $\boldsymbol{\xi}$  of the fundamental solution. Due to the dependence of this fundamental solution only on  $r$  the approximating function is generally chosen to be some radial function *i.e.*,  $f_j = f_j(r)$ . Several other options for  $f_j$  have been tried [?] but it has been found that in general the most accurate results were generated using some radial function. For both two and three-dimensional problems wrobel:1986 recommended choosing  $f_j$  from the series

$$f_j = 1 + r_j + r_j^2 + \dots + r_j^m \quad (10.40)$$

where  $r_j$  is the distance between the field point (node  $j$ ) and the DR-BEM collocation point (node  $i$ ). They showed that accurate results can be achieved using some combination of terms from this series. Generally the same approximating function  $f_j$  is used at all the collocation points so in this thesis, for simplicity, the form of approximating functions  $f_j$  will be referred to by a single  $f$ .

Choosing  $f$  to be a function of only one variable simplifies the process of determining  $\hat{u}$  and  $\hat{q}$ . For two-dimensional problems, if  $f = f(r)$  then the relationship

$$\nabla^2 \hat{u} = f(r) \quad (10.41)$$

can be reduced to the ordinary differential equation

$$\frac{d^2 \hat{u}}{dr^2} + \frac{1}{r} \frac{d\hat{u}}{dr} = f \quad (10.42)$$

Using  $f$  defined by Equation (10.40) the corresponding forms of  $\hat{u}$  and  $\hat{q}$ , for two-dimensional problems, can be shown to be

$$\hat{u} = \frac{r^2}{4} + \frac{r^3}{9} + \dots + \frac{r^{m+2}}{(m+2)^2} \quad (10.43)$$

$$\hat{q} = \left( r_x \frac{\partial x}{\partial n} + r_y \frac{\partial y}{\partial n} \right) \left( \frac{1}{2} + \frac{r}{3} + \dots + \frac{r^m}{m+2} \right) \quad (10.44)$$

where  $r_x = x_j - x_i$  and  $r_y = y_j - y_i$ .

Any combination of terms from Equation (10.40) can be used for specifying  $f$ . It has been found that in general including higher-order terms leads to little improvement in accuracy [?]. The most commonly used form is  $f = 1 + r$  as this approximation will generally give accurate results with greater computational efficiency than other choices.

Equation (10.40) was recommended as a basis for the approximating function  $f$  due to the particular form of the fundamental solution of Laplace's equation and its dependence on  $r$  only. If a different operator is used as the basis of the DR-BEM then it is likely a different form of  $f$  will be more appropriate. The choice of  $f$  in this case will be discussed in Section 10.3.3.

The performance of the DR-BEM hinges on the choice of the approximating function  $f$ . The theory of how to determine the best approximating function is therefore a vital component of the DR-BEM. Unfortunately the approximating function has generally been chosen and used in a rather ad-hoc manner. Recently some more formal analysis of the use of approximating functions has been undertaken.

golberg:1994 argued that a formal analysis of the approximating function  $f$  can be undertaken

using the theory of radial basis functions. Radial basis functions are a generalisation of cubic splines in multi-dimensions. Cubic splines are known to be optimal for one-dimensional interpolation. Therefore, rather than being an arbitrary choice, it seems that choosing  $f$  to be a radial function is a logical extension for two or three-dimensional problems. golberg:1994 showed that, for the Poisson equation, choosing  $f$  to be a radial basis function ensures convergence of the DR-BEM.

They also demonstrated that  $f = 1 + r$  is a specific member of the group of radial basis functions. The theory of using radial basis functions for multi-dimensional approximation is fairly advanced. It has been shown that  $f = r$  is optimal for three-dimensional problems which justifies the use of  $f = 1 + r$  when applying the DR-BEM to three-dimensional problems - the constant is included to ensure a non-zero diagonal for  $F$ . However for two-dimensional problems it has been shown that optimal approximation is attained using the thin plate spline  $f = r^2 \log r$ . This observation lead golberg:1994 to suggest that choosing  $f$  to be a thin plate spline may improve the accuracy of the DR-BEM in two dimensions. Recently golberg:1995 has published a review of the DR-BEM concentrating on developments since 1990 concerning the numerical evaluation of particular solutions.

### Inhomogeneous Equations

If the forcing function  $b$  is a function of position only then the differential equation under consideration is simply Poisson's equation. In this case it is not necessary to invert the  $F$  matrix as  $\alpha$  can simply be calculated from  $b = F\alpha$  using Gaussian elimination. Equation (10.39) can be rewritten as

$$Hu - Gq = d \quad \text{where } d = (H\hat{U} - G\hat{Q})\alpha \quad (10.45)$$

By applying boundary conditions Equation (10.45) can be reduced to a linear system  $Ax = \tau$  which can be solved to give the unknown nodal values of  $u$  and  $q$ .

zheng:1991 and coleman:1991 have proposed a method which uses a global shape function to construct an approximate particular solution. As discussed by polyzos:1994 this method is essentially equivalent to the DR-BEM. However, zheng:1991 and coleman:1991 suggested several alternative ways of determining the unknown coefficients  $\alpha_j$  for inhomogeneous equations. zheng:1991 used a least-squares method where they minimised the sum of squares

$$S = \sum_{m=1}^M \left( b(r_m) - \sum_{j=1}^N \alpha_j f_j(r_m) \right)^2 \quad (10.46)$$

using singular value decomposition. For large systems they found the computational efficiency could be improved by employing the conjugate gradient method. coleman:1991 successfully solved inhomogeneous potential and elasticity problems which are governed by operators other than the Laplacian.

### Elliptic Problems

If  $b$  is a function of the dependent variable then  $\alpha$  will also be a function of the dependent variable. Consider, for example, the linear second-order differential equation

$$\nabla^2 u + u = 0 \quad (10.47)$$

In this case  $b = -u$  so  $\alpha = F^{-1} - u$ . Applying the DR-BEM to Equation (10.47), based on the fundamental solution to Laplace's equation, gives

$$Hu - Gq = - \left( H\hat{U} - G\hat{Q} \right) F^{-1}u \quad (10.48)$$

which can be rearranged to give

$$(H + S)u = Gq \quad \text{where } S = \left( H\hat{U} - G\hat{Q} \right) F^{-1} \quad (10.49)$$

Again, by applying boundary conditions Equation (10.49) can be reduced to a linear system  $AX = \tau$  which can be solved to determine the unknown nodal values.

Due to the presence of the fully-populated  $F^{-1}$  matrix in Equation (10.49) it is not possible to solve the boundary problem and internal problem separately. Instead the solution can be treated as a coupled problem and the solutions at boundary and internal nodes are generated simultaneously.

**Derivative Terms** The DR-BEM can also be applied for elliptic problems where  $b$  involves derivatives of the dependent variable [?]. Consider, for example, the differential equation

$$\nabla^2 u + \frac{\partial u}{\partial x} = 0 \quad (10.50)$$

In this case applying DR-BEM, using the Laplace fundamental solution, gives

$$Hu - Gq = - \left( H\hat{U} - G\hat{Q} \right) F^{-1} \frac{\partial u}{\partial x} \quad (10.51)$$

To solve this problem it is necessary to relate the nodal values of  $u$  to the nodal values of  $\frac{\partial u}{\partial x}$ . This is achieved by using interpolation functions to approximate  $u$  in a similar manner as was used to approximate  $b$  in Equation (10.32). A global approximation function of the form

$$u = \sum_{j=1}^M \phi_j(x, y) \beta_j \quad (10.52)$$

can be used to approximate  $u$  where  $\phi_j$  are the chosen interpolation functions and  $\beta_j$  are the unknown coefficients. In system form this can be expressed as

$$u = \Phi\beta \quad (10.53)$$

Although it is not necessary, equating  $\Phi$  to  $F$  improves the computational efficiency of the method as only one matrix inversion procedure is required. Differentiating Equation (10.53) gives

$$\frac{\partial u}{\partial x} = \frac{\partial \Phi}{\partial X} \beta \quad (10.54)$$

Choosing  $\Phi = F$  and inverting Equation (10.53) to give an explicit expression for  $\beta$  allows Equation (10.54) to be rewritten as

$$\frac{\partial u}{\partial x} = \frac{\partial F}{\partial X} F^{-1} u \quad (10.55)$$

Equation (10.39) can now be rewritten as

$$(H + R) u = Gq \quad \text{where } R = \left( H\hat{U} - G\hat{Q} \right) F^{-1} \frac{\partial F}{\partial X} F^{-1} \quad (10.56)$$

By applying boundary conditions Equation (10.56) can be reduced to a linear system which can be solved to give the unknown nodal values.

As mentioned earlier, the approximating function  $f$  is generally chosen to be  $f = 1 + r$ . This can lead to numerical problems if derivative terms are included in the forcing function  $b$ . As shown in Equation (10.55) derivative terms require derivatives of  $f$  to be evaluated. For example, evaluating the  $\frac{\partial F}{\partial X}$  matrix requires calculation of  $\frac{\partial f}{\partial x}$ . Using the approximating function  $f = 1 + r$  gives

$$\frac{\partial f}{\partial x} = \frac{\partial f}{\partial r} \frac{\partial r}{\partial x} = \frac{\partial f}{\partial r} \frac{r_x}{r} \quad (10.57)$$

This derivative function can become singular, so - as shown by zhang:1993 - significant numerical error may result. This will especially be the case in problems where collocation points are located close together.

zhang:1993 suggested two possibilities for avoiding this problem. The first suggestion involved using a mapping procedure to map the governing equation to an equation without convective terms. This method was shown to produce accurate results but is somewhat cumbersome and can only be applied to linear problems. A simpler approach is to choose an approximating function which does not lead to singularities for convective terms. zhang:1993 recommended use of either  $f = 1 + r^3$  or  $f = 1 + r^2 + r^3$ . These approximating functions produce accurate results and can be simply applied for both linear and nonlinear problems. zhang:1993 recommended the adoption of these approximating functions for all use of the DR-BEM.

The same idea of using Equation (10.53) to allow nodal values of  $u$  to be associated to its derivatives can be applied to extend the DR-BEM to cases involving higher-order derivatives or cross derivatives of the dependent variable. Appropriate approximating functions need to be chosen to avoid the problem of singularities.

**Variable Coefficients** The DR-BEM can be readily extended to equations with variable coefficients. Consider the variable coefficient Helmholtz equation

$$\nabla^2 u + \kappa(\mathbf{x}) u = 0 \quad (10.58)$$

where  $\kappa$  is a function of position -  $\kappa = \kappa(x, y)$  in two dimensions. If the DR-BEM is applied using the known fundamental solution to the Laplace operator then the forcing function is  $b = -\kappa u$ . Applying the DR-BEM gives

$$Hu - Gq = (H\hat{U} - G\hat{Q}) F^{-1}b \quad (10.59)$$

where  $b$  is a vector of the nodal values of the forcing function  $b$ . The relationship  $b = -\kappa u$  can be written in matrix form as  $b = -Ku$  where  $K$  is a diagonal matrix containing the nodal values of  $\kappa(x, y)$  i.e.,

$$K = \begin{bmatrix} \kappa(x_1, y_1) & 0 & \cdots & 0 \\ 0 & \kappa(x_2, y_2) & \cdots & 0 \\ \vdots & \vdots & \ddots & \vdots \\ 0 & 0 & \cdots & \kappa(x_M, y_M) \end{bmatrix} \quad (10.60)$$

where  $M$  is the number of collocation points used in applying the DR-BEM.

Using this matrix expression for  $b$  Equation (10.59) can be rearranged to give

$$(H + SK)u = Gq \quad \text{where } S = (H\hat{U} - G\hat{Q}) F^{-1} \quad (10.61)$$

which is a boundary-only expression for the variable coefficient Helmholtz equation. This method is general and can easily be extended to accommodate variable coefficient derivative terms and a sum of variable coefficient terms.

**Formulating the DR-BEM for a General Elliptic Problem** In this section it has been shown how the DR-BEM can be applied for elliptic problems with varying forms of  $b$ . The DR-BEM can be applied in cases where  $b$  involves a sum of terms due to the basic property

$$\int_{\Omega} (b_1 + b_2) d\Omega = \int_{\Omega} b_1 d\Omega + \int_{\Omega} b_2 d\Omega \quad (10.62)$$

Consider a two-dimensional equation of the form

$$\nabla^2 u(x, y) = k(x, y)u + l(x, y) \frac{\partial u}{\partial x} + m(x, y) \frac{\partial u}{\partial y} + n(x, y) \quad (10.63)$$

Applying the DR-BEM to this equation gives a matrix system of the form

$$(H - R)u = Gq + Sn \quad (10.64)$$

where

$$S = (H\hat{U} - G\hat{Q}) F^{-1} \quad (10.65)$$

$$R = S \left[ K + \left( L \frac{\partial F}{\partial X} + M \frac{\partial F}{\partial Y} \right) F^{-1} \right] \quad (10.66)$$

$K$ ,  $L$  and  $M$  are diagonal matrices where the diagonals contain the nodal values of  $k$ ,  $l$  and  $m$  respectively.  $n$  is a vector containing the nodal values of  $n$ .

### The DR-BEM Using Other Operators

The DR-BEM has been presented in this chapter based on the Laplace operator. However the DR-BEM can be applied using essentially any operator of appropriate order with known fundamental solution. If an appropriate operator can be found the complexity of the forcing function  $b$  can be reduced. This should improve the accuracy of the method. The problem with applying the DR-BEM based on another operator is in choosing the approximating function  $f$ . A choice of  $f$  which produces accurate results is required but it is also necessary to choose an  $f$  for which a particular solution  $\hat{u}$  can be determined.

zhu:1993 has determined the particular solutions necessary for applying the DR-BEM based on the two-dimensional Helmholtz operator.

$$\nabla^2 u + \kappa^2 u = b(x, y, u, t) \quad (10.67)$$

Radial functions have generally been used when applying the DR-BEM. Along the lines of wrobel:1986, zhu:1993 chose an approximating function of the form  $f = r^m$  where  $m$  is a positive integer. Determining the particular solution  $\hat{u}$  requires solving the ordinary differential equation

$$\frac{d^2 \hat{u}}{dr^2} + \frac{1}{r} \frac{d\hat{u}}{dr} + \kappa^2 \hat{u} = r^m \quad (10.68)$$

which can be achieved using a variation of coefficients method.

partridge:1992 applied the DR-BEM to the transient convection diffusion equation

$$D\nabla^2 u - v_x \frac{\partial u}{\partial x} - v_y \frac{\partial u}{\partial y} - ku = \frac{\partial u}{\partial t} \quad (10.69)$$

where the material parameters  $D$ ,  $v_x$ ,  $v_y$  and  $k$  are all assumed to be homogeneous. They applied the DR-BEM based on the steady-state convection-diffusion operator

$$D\nabla^2 u - v_x \frac{\partial u}{\partial x} - v_y \frac{\partial u}{\partial y} - ku = 0 \quad (10.70)$$

which has a known fundamental solution.

This analysis requires the determination of a particular solution  $\hat{u}$  which satisfies

$$D\nabla^2 \hat{u} - v_x \frac{\partial \hat{u}}{\partial x} - v_y \frac{\partial \hat{u}}{\partial y} - k\hat{u} = f \quad (10.71)$$

Instead of defining a form of the approximating function  $f$  and solving for  $\hat{u}$  partridge:1992 chose to define  $\hat{u}$  and use Equation (10.71) to determine the corresponding approximating function. Although somewhat ad-hoc this approach was found to produce accurate results.

# Chapter 11

## The BEM for Parabolic PDES

### 11.1 Time-Stepping Methods

Several approaches have been proposed for applying the BEM to parabolic problems. These methods can be broadly classified into two main approaches. Either some form of time-stepping procedure is used to advance the solution in time, or a semi-analytic technique is used which can directly calculate a solution at a specified time. In this section time-stepping procedures will be considered.

Time-stepping approaches discretise the time domain in some manner and use some form of time marching scheme to advance the solution from one discrete time to the next. The two most commonly used time-stepping methods are the coupled finite difference - BEM and the direct time integration method. These two methods will be outlined in this section for the diffusion equation

$$\nabla^2 u(\mathbf{x}, t) = \frac{1}{\kappa} \frac{\partial u(\mathbf{x}, t)}{\partial t} \quad (11.1)$$

where the diffusivity  $\kappa$  is a material parameter which can be a constant or a function of position.

#### 11.1.1 Coupled Finite Difference - Boundary Element Method

This approach discretises the time-domain in a finite difference form. Consider the variation between a time  $t^m$  and a time  $t^{m+1} = t^m + \Delta t$ . The most common approach [?] is to assume that, for sufficiently small  $\Delta t$ , the time derivative can be approximated using a first-order fully implicit finite difference scheme

$$\frac{\partial u(\mathbf{x}, t^{m+1})}{\partial t} = \frac{u(\mathbf{x}, t^{m+1}) - u(\mathbf{x}, t^m)}{\Delta t} \quad (11.2)$$

which allows the diffusion equation in this time-range to be approximated as

$$\nabla^2 u(\mathbf{x}, t^{m+1}) - \frac{1}{\kappa \Delta t} u(\mathbf{x}, t^{m+1}) + \frac{1}{\kappa \Delta t} u(\mathbf{x}, t^m) = 0 \quad (11.3)$$

Using this finite difference approximation the original parabolic equation has been reduced to an elliptic equation. Using the weighted residuals method an integral equation can be generated from

Equation (11.3).

$$c(\boldsymbol{\xi}) u^{m+1} + \int_{\Gamma} u^{m+1} \frac{\partial \omega}{\partial n} d\Gamma = \int_{\Omega} q^{m+1} \omega d\Gamma + \frac{1}{\kappa \Delta t} \int_{\Omega} u^m \omega d\Omega \quad (11.4)$$

where  $u^{m+1} = u(\boldsymbol{x}, t^{m+1})$  and  $u^m = u(\boldsymbol{x}, t^m)$ . The fundamental solution  $\omega$  is a solution of the modified Helmholtz equation

$$\nabla^2 \omega(\boldsymbol{x}, \boldsymbol{\xi}) - \frac{1}{\kappa \Delta t} \omega(\boldsymbol{x}, \boldsymbol{\xi}) + \delta(\boldsymbol{\xi}) = 0 \quad (11.5)$$

applied at some source point  $\boldsymbol{\xi}$ . The fundamental solution of the modified Helmholtz equation is known in both two and three dimensions. If an internal solution is required at a specific time this can be determined explicitly from Equation (11.4) where the fundamental solution is applied at internal point  $\boldsymbol{\xi}$  and  $c(\boldsymbol{\xi}) = 1$ .

Unfortunately Equation (11.4) contains a domain integral. This integral is generally evaluated by using a domain mesh [?]. The domain integral does not include any problem unknowns so a fairly coarse domain mesh will generally suffice. Applying the BEM to Equation (11.4) gives

$$\boldsymbol{H} \boldsymbol{u}^{m+1} - \boldsymbol{G} \boldsymbol{q}^{m+1} = \boldsymbol{B} \boldsymbol{u}^m \quad (11.6)$$

where  $\boldsymbol{B}$  is a matrix containing the influence coefficients due to the domain integral. Using Equation (11.6) the solution can be advanced in time.  $\boldsymbol{U}^0$  is known from the initial conditions so a solution can be calculated at  $t = t_0 + \Delta t$ . A solution at internal nodes can then be calculated. The time-stepping procedure can be repeated using the internal solution at  $t = t_0 + \Delta t$  as pseudo-initial conditions for the next time-step.

If a constant time-step is used the matrices  $\boldsymbol{H}$ ,  $\boldsymbol{G}$  and  $\boldsymbol{B}$  can be calculated once and stored. The boundary conditions can be applied to form a solution system of the form  $\boldsymbol{A} \boldsymbol{x}^{m+1} = \boldsymbol{\tau}$  where  $\boldsymbol{x}^{m+1}$  is the vector of unknown nodal values at time  $t^{m+1}$  and  $\boldsymbol{\tau}$  is a vector constructed from known nodal values from the previous time-step. For a problem with time-independent boundary conditions at each time-step it is only necessary to update  $\boldsymbol{\tau}$  and solve the system for  $\boldsymbol{x}^{m+1}$ . If a problem has time-dependent boundary conditions the solution system needs to be reformed at each time-step.

This coupled finite difference - boundary element method (FD-BEM) was first proposed by walker:1980 for the diffusion equation. It was implemented and investigated by curran:1980. They found that this method will only produce accurate results if Equation (11.2) accurately approximates the time derivative. This will generally require small time-steps to be adopted. curran:1980 investigated the use of a higher-order approximation to the time-derivative. They found that this improved the accuracy of the method. Unfortunately it lead to a deterioration in convergence behaviour.

tanaka:1994 proposed a generalised version of this time-stepping scheme. They approximated the time variation within an interval as

$$u(\boldsymbol{x}, t) = \phi u(\boldsymbol{x}, t^{m+1}) + (1 - \phi) u(\boldsymbol{x}, t^m) \quad (11.7)$$

where  $\phi$ , termed the time-scheme parameter, is a constant in the range  $0 < \phi \leq 1$ . Substituting



this approximation and a first-order finite difference approximation of the time derivative into the diffusion equation gives

$$\phi \nabla^2 u^{m+1} + (1 - \phi) \nabla^2 u^m = \frac{u^{m+1} - u^m}{\kappa \Delta t} \quad (11.8)$$

If  $\phi = 1$  this approximation of the diffusion equation is equivalent to the standard FD-BEM discussed earlier. An integral equation can be derived from Equation (11.8). tanaka:1994 implemented this method and found it gave accurate results for a range of diffusion problems. They tested the accuracy for a Crank-Nicolson scheme ( $\phi = \frac{1}{2}$ ), a Galerkin scheme ( $\phi = \frac{2}{3}$ ) and a fully implicit scheme ( $\phi = 1$ ). They found that the best results were achieved using a Crank-Nicolson scheme.

### 11.1.2 Direct Time-Integration Method

Instead of converting the original parabolic equation to an elliptic equation the problem can be treated directly in the time domain by directly integrating over both time and space. The weighted residual statement using this approach is

$$\int_{t_0}^{t_F} \int_{\Omega} \left[ \nabla^2 u(\mathbf{x}, t) - \frac{1}{\kappa} \frac{\partial u(\mathbf{x}, t)}{\partial t} \right] \omega(\xi, \mathbf{x}, t_F, t) d\Omega dt = 0 \quad (11.9)$$

Integrating in time once and in space twice gives

$$c(\xi) u(\xi, t_F) + \kappa \int_{t_0}^{t_F} \int_{\Gamma} u \frac{\partial \omega}{\partial n} d\Gamma dt = \kappa \int_{t_0}^{t_F} \int_{\Gamma} q \omega d\Gamma dt + \int_{\Omega} u(\mathbf{x}, t_0) \omega d\Omega \quad (11.10)$$

where the fundamental solution  $\omega$  satisfies

$$\kappa \nabla^2 \omega(\xi, \mathbf{x}, t_F, t) + \frac{\partial \omega(\xi, \mathbf{x}, t_F, t)}{\partial t} + \delta(\xi) \delta(t_F) = 0 \quad (11.11)$$

This time dependent fundamental solution is known in two and three dimensions. Physically this fundamental solution represents the effect at a field point  $\mathbf{x}$  at time  $t$  of a unit point source applied at a point  $\xi$  at time  $t_F$ . If an internal solution is required at a specific time this can be determined from Equation (11.10) with  $c(\xi) = 1$ .

The variation of  $u$  and  $q$  with time is unknown so it is still necessary to step in time. However, as the time dependence is included in the fundamental solution, accurate results can be achieved using larger time-steps than with the FD-BEM. Two different time-stepping schemes can be used. Similarly to the FD-BEM, each time-step can be treated as a new problem so that an internal solution is constructed at the end of each time-step to be used as pseudo-initial conditions for the next time-step. Alternatively the time integration process can be restarted at  $t_0$  with increasing numbers of intermediate steps used. These two time-stepping approaches are discussed in detail in brebbia:1984.

The first method requires a new domain integral to be calculated after each time-step due to

the updated pseudo-initial conditions. The second time-stepping procedure involves only a domain integral at  $t_0$  so, ideally, a domain integral only needs to be calculated once. This, however, will still require the user to create a domain mesh. As mentioned by brebbia:1984, in many practical cases the domain integral can be avoided. If the initial conditions are  $u_0 = 0$  throughout the body the domain integral equals zero. If the initial conditions satisfy Laplace's equation  $\nabla^2 u_0 = 0$  then a Galerkin vector can be found and the domain integral can be expressed as equivalent boundary integrals. This includes many practical cases such as constant initial temperature or an initial linear temperature profile.

Unfortunately, in practice it is not always feasible to restart the integration process at  $t_0$ . At each time-step new  $\mathbf{H}$  and  $\mathbf{G}$  matrices are required so if many time-steps are required the storage capacity of the computer is likely to be exceeded. This requires the procedure to be restarted at some time where an internal solution is constructed and used as pseudo-initial conditions to repeat the process. Therefore, in practice, both time-stepping methods are likely to require domain integration.

## 11.2 Laplace Transform Method

An alternative approach which avoids time-stepping is to solve the problem in a transform domain which removes the time dependence of the problem. The parabolic PDE is thus converted to an elliptic problem for which the boundary element method has been shown to generally produce accurate results. Once the solution to the elliptic problem is determined in the transform space a solution in the original space can be attained using an inverse transform procedure. The most appropriate transform approach for parabolic problems is the Laplace transform.

Consider the diffusion equation

$$\nabla^2 u(\mathbf{x}, t) = \frac{1}{\kappa} \frac{\partial u(\mathbf{x}, t)}{\partial t} \quad (11.12)$$

with appropriate boundary and initial conditions. The Laplace transform of  $u(\mathbf{x}, t)$  will be symbolised as  $U(\mathbf{x}, \lambda)$  and is defined as

$$U(\mathbf{x}, \lambda) = \int_0^\infty e^{-\lambda t} u(\mathbf{x}, t) dt \quad (11.13)$$

Applying Laplace transforms to Equation (11.12) gives

$$\nabla^2 U(\mathbf{x}, \lambda) = \frac{1}{\kappa} (\lambda U(\mathbf{x}, \lambda) - u_0(\mathbf{x})) \quad (11.14)$$

with transformed boundary conditions.  $u_0(\mathbf{x})$  is the initial conditions of  $u$ . Equation (11.14) is an elliptic PDE which can be readily solved using the boundary element method. Once the solution is determined in Laplace transform space this solution can be inverted to give a solution in the time-domain. This inversion procedure requires solutions to be generated for several values of the transform parameter  $\lambda$ .

This method was first proposed by rizzo:1970 and has since been successfully used by other

practitioners [?] [?]. liggett:1979 compared the Laplace transform method with the time-dependent Green's function method. They noted that the direct method is simpler to apply. However, due to its greater efficiency, they recommended the Laplace transform method for solving diffusion problems.

One limitation of the Laplace transform method is that Equation (11.14) is inhomogeneous so that applying the standard BEM will generate a domain integral involving the initial conditions. Traditionally this domain integral has been calculated by using a domain discretisation [?]. However, recently zhu:1994 proposed using the DR-BEM to convert this domain integral term to equivalent boundary integrals. They chose to apply the DR-BEM based on the known fundamental solution to the Laplace operator. Considering Equation (11.14) this means that the DR-BEM will be used to convert the right-hand-side to equivalent domain integrals. Therefore the required DR-BEM approximation is

$$\frac{1}{\kappa} (\lambda U(\mathbf{x}, \lambda) - u_0(\mathbf{x})) = \sum_{j=1}^{N+L} f_j \alpha_j \quad (11.15)$$

The DR-BEM can now be applied to Equation (11.14), giving a matrix system of the form

$$\left( \mathbf{H} - \frac{\lambda}{\kappa} \mathbf{S} \right) \mathbf{u} - \mathbf{G} \mathbf{q} = -\frac{1}{\kappa} \mathbf{S} \mathbf{u}_0 \quad (11.16)$$

which can be reduced to a square system by applying boundary conditions. Once the solution is determined for this elliptic equation in the transform space a solution at a given time can be constructed using an inversion process.

This Laplace transform dual reciprocity method (LT-DRM) can easily be extended to equations of the form

$$\nabla^2 u(\mathbf{x}, t) = \frac{1}{\kappa} \frac{\partial u(\mathbf{x}, t)}{\partial t} + b(\mathbf{x}, u) \quad (11.17)$$

in which case a matrix expression of the form

$$\left( \mathbf{H} - \mathbf{R} - \frac{\lambda}{\kappa} \mathbf{S} \right) \mathbf{u} - \mathbf{G} \mathbf{q} = -\frac{1}{\kappa} \mathbf{S} \mathbf{u}_0 \quad (11.18)$$

is generated. Zhu and his colleagues have successfully extended the LT-DRM to solve diffusion problems with nonlinear source terms.

## 11.3 The DR-BEM For Transient Problems

The DR-BEM can also be applied to parabolic problems. Consider, for example, the diffusion equation

$$\nabla^2 u = \frac{1}{\kappa} \frac{\partial u}{\partial t} \quad (11.19)$$

where the thermal diffusivity,  $\kappa$ , is a constant. In this case the global approximation of  $b$  implies a separation of variables such that

$$\frac{\partial u}{\partial t} = \sum_{j=1}^M f_j(\mathbf{x}) \alpha_j(t) \quad (11.20)$$

Using Equation (11.20), Equation (10.39) becomes

$$\mathbf{H}\mathbf{u} - \mathbf{G}\mathbf{q} = \frac{1}{\kappa} \left( \mathbf{H}\hat{\mathbf{U}} - \mathbf{G}\hat{\mathbf{Q}} \right) \mathbf{F}^{-1} \frac{\partial \mathbf{u}}{\partial t} \quad (11.21)$$

or

$$\mathbf{C} \frac{\partial \mathbf{u}}{\partial t} + \mathbf{H}\mathbf{u} = \mathbf{G}\mathbf{q} \quad \text{where } \mathbf{C} = -\frac{1}{\kappa} \left( \mathbf{H}\hat{\mathbf{U}} - \mathbf{G}\hat{\mathbf{Q}} \right) \mathbf{F}^{-1} \quad (11.22)$$

Equation (11.22) can be solved using a standard direct time-integration method.

partridge:1990 recommended using a first-order finite difference approximation to the time derivative

$$\frac{\partial u}{\partial t} = \frac{u^{m+1} - u^m}{\Delta t} \quad (11.23)$$

and linear approximations to  $u$  and  $q$  within a time-step.

$$u = (1 - \phi_u) u^m + \phi_u u^{m+1} \quad (11.24)$$

$$q = (1 - \phi_q) q^m + \phi_q q^{m+1} \quad (11.25)$$

where  $\phi_u$  and  $\phi_q$  are weighting parameters with values in the range  $(0, 1]$  and the time-step is between times  $t^m$  and  $t^{m+1} = t^m + \Delta t$ . Substituting these approximations into Equation (11.22) an expression at  $t^{m+1}$  can be derived in terms of values at  $t^m$ .

$$\left[ \frac{1}{\Delta t} \mathbf{C} + \phi_u \mathbf{H} \right] \mathbf{u}^{m+1} - \phi_q \mathbf{G}\mathbf{q}^{m+1} = \left[ \frac{\mathbf{c}}{\Delta t} - (1 - \phi_u) \mathbf{H} \right] \mathbf{u}^m + (1 - \phi_q) \mathbf{G}\mathbf{q}^m \quad (11.26)$$

The values of  $u^0$  and  $q^0$  are known from the initial conditions so a time-stepping procedure can be used. If a constant time-step is used the matrices  $\mathbf{C}$ ,  $\mathbf{H}$  and  $\mathbf{G}$  only need to be constructed once. Using this two-level time-integration scheme the most common choice of time-scheme parameters is  $\phi_u = 0.5$ ,  $\phi_q = 1.0$ .

## 11.4 The MRM for Transient Problems

The MRM can be applied to the diffusion equation  $\nabla^2 u = \frac{1}{\kappa} \frac{\partial u}{\partial t}$  using the fundamental solution of Laplace's equation. In this case the forcing function becomes  $b_0 = \frac{1}{\kappa} \frac{\partial u}{\partial t}$  and the recurrence relationship defined by Equation (10.24) becomes

$$u_{j+1} = \nabla^2 u_j = \frac{\partial^j u}{\partial t^j} \quad (11.27)$$

The higher-order fundamental solutions are known for Laplace's equation. In this case the MRM formulation becomes

$$c(\xi) u(\xi) + \sum_{j=0}^{\infty} \int_{\Gamma} \frac{\partial \omega}{\partial n} \frac{\partial^j u}{\partial t^j} d\Gamma = \sum_{j=0}^{\infty} \int_{\Gamma} \omega \frac{\partial^j q}{\partial t^j} d\Gamma \quad (11.28)$$

The standard BEM numerical procedure can be applied to this boundary integral equation. This gives the matrix system

$$\mathbf{H}_0 \mathbf{u} + \mathbf{H}_1 \dot{\mathbf{u}} + \mathbf{H}_2 \ddot{\mathbf{u}} + \dots = \mathbf{G}_0 \mathbf{q} + \mathbf{G}_1 \dot{\mathbf{q}} + \mathbf{G}_2 \ddot{\mathbf{q}} + \dots \quad (11.29)$$

where the matrices  $\mathbf{H}_1, \mathbf{G}_1$  etc are the influence coefficient matrices relating to the higher-order fundamental solutions. This equation can be solved using a time-integration procedure.

The most common approach is to solve this system numerically by discretising the time domain and using a time-stepping procedure. This requires some interpolation between the two time-levels marked by  $m$  and  $m+1$ . This most common approach is to use a linear approximation to  $u$  and  $q$  in this time-range

$$u = (1 - \phi) u^m + \phi u^{m+1} \quad (11.30)$$

$$q = (1 - \phi) q^m + \phi q^{m+1} \quad (11.31)$$

where  $\phi$  has a value in the range 0 to 1. Differentiating these linear approximations gives

$$\dot{u} = \frac{u^{m+1} - u^m}{\Delta t^m} \quad (11.32)$$

$$\dot{q} = \frac{q^{m+1} - q^m}{\Delta t^m} \quad (11.33)$$

and all the other derivatives vanish.

This allows Equation (11.29) to be simplified to

$$\mathbf{H}_L \mathbf{u}^{m+1} - \mathbf{G}_L \mathbf{q}^{m+1} = -\mathbf{H}_R \mathbf{u}^m + \mathbf{G}_R \mathbf{q}^m \quad (11.34)$$

where  $\mathbf{H}_L = \frac{1}{\Delta t^m} \mathbf{H}_1 + \phi \mathbf{H}_0$ ,  $\mathbf{H}_R = -\frac{1}{\Delta t^m} \mathbf{H}_1 + (1 - \phi) \mathbf{H}_0$ ,  $\mathbf{G}_L = \frac{1}{\Delta t^m} \mathbf{G}_1 + \phi \mathbf{G}_0$ ,  $\mathbf{G}_R = -\frac{1}{\Delta t^m} \mathbf{G}_1 + (1 - \phi) \mathbf{G}_0$ . This approach is termed a first-order approach as it removes all but the first derivatives. A second order approach can be formulated by using quadratic interpolation of  $u$  and  $q$  within the time-range.

Using Equation (11.34) the solution can be advanced in time. If a constant time-step is used the matrices  $\mathbf{H}_L, \mathbf{H}_R, \mathbf{G}_L$  and  $\mathbf{G}_R$  only need to be constructed once outside the time-stepping loop. If the boundary conditions are not time-dependent the boundary conditions only need to be applied once.

