


BIM ingame tutorial

This documentation is not finished. Please help and contribute documentation.

Gui Command explains how tools should be documented. See Draft ShapeString for an example of a well documented tool. Browse Category:UnfinishedDocu to see incomplete pages like this one. See Category:Command Reference for all commands.

See WikiPages to learn about editing the wiki pages, and go to Help FreeCAD to learn about other ways in which you can contribute.



Tutorial steps


This is the in-game tutorial of the BIM Workbench. It is not meant to be read here on the wiki, but rather to be started from inside FreeCAD, in the BIM workbench, under menu **Help -> BIM tutorial**. It includes a series of steps to be completed by the user. Each step is terminated by an instance of the `{{BIMTutorialAction|descr|goal1|test1|goal2|test2}}` template, which informs of the condition that need to be met

Contents

- 1 Welcome to the BIM workbench!
- 2 Set FreeCAD up
- 3 Create a new document
- 4 Find your marks in the 3D view
- 5 Reorganize the interface
- 6 The BIM workbench tools
 - 6.1 2D Drafting
 - 6.2 3D Modeling

- 6.3 BIM
- 6.4 Annotation
- 6.5 Snapping
- 6.6 Modify
- 6.7 Manage
- 7 Prepare your working space
- 8 Draw a first wall
- 9 Draw a second wall
 - 9.1 Important note
- 10 Don't forget to save the file regularly!
- 11 Draw a roof slab
 - 11.1 Method 1: Draw the slab on the ground, then move it into position
 - 11.2 Method 2: Draw the slab directly in the correct plane
- 12 Create a metallic column
 - 12.1 Add a support plate
- 13 Add windows and doors
- 14 To be continued...

Welcome to the BIM workbench!



This tutorial will walk you through the different functionalities of the BIM Workbench and help you to get on tracks by modeling a very simple pavilion building. It should take between one and two hours to complete entirely, depending on your previous experience with 3D applications.

You can interrupt it anytime and resume it later, by selecting menu **Help -> Welcome screen**, and clicking the **BIM Tutorial** item again.

Some steps of this tutorial require you to take actions. Those will be indicated below this text box, with an icon showing if the task has been completed or not. But since we are good people here at FreeCAD, it is not mandatory to complete the actions in order to advance through these pages. You can just browse through the tutorial and skip actions at your convenience.

Note: This tutorial is still being written, and is therefore **incomplete**! If you have suggestions or things you find unclear, why not help us to make it better on the FreeCAD forum (<https://forum.freecadweb.org/viewforum.php?f=23>)!


Tutorial steps

No action to perform for this step

Set FreeCAD up


FreeCAD has a large preferences system with many options to set, located under menu **Edit->Preferences**. Each additional workbench can add more preferences pages, which makes it very complex.

The BIM workbench provides a simplified setup screen, which allows to quickly set some of the most useful preferences for BIM work. The BIM preferences screen is located under menu **Manage -> BIM Setup** (you can also click the corresponding button on the Manage toolbar):




Open the simplified BIM preferences screen now, and set the different options to your liking.

In case of need, hover the mouse over any option or setting to see a description of what it is used for:



In this tutorial, we will work in centimeters. We therefore suggest you to set preferred units as **centimeters**, and the default grid square size to **10 cm**. After you left this screen, these two settings can be changed anytime from the units indicator located on the status bar and from the working plane button on the main toolbars:



Tutorial steps

Open the BIM setup screen

```
True if hasattr(FreeCADGui,"BIMSetupDialog") else False
```

Set units to centimeters and grid size to 10cm


```
True if ((FreeCAD.ParamGet("User parameter:BaseApp/Preferences/Units").GetInt("UserSchema",0) == 4) a
```

Create a new document


If you just installed FreeCAD, you are probably currently looking at the **FreeCAD Start Page**:



The start page lists the latest documents you have been working with, and, on its different tabs, explains how to get help. But in order to start working, we need to create a new, empty **document**. If you haven't done it yet, create now a new document by using the "Create new..." item of the start page, or by navigating to menu **File** -> **New**:



You will then find yourself in the 3D space of FreeCAD, ready to work:



Tutorial steps

Create a new document


True if FreeCAD.ActiveDocument else False

Find your marks in the 3D view

There are several ways to interact with the mouse in FreeCAD. These are called navigation styles. You can change the current navigation style anytime by clicking on the navigation style button in the status bar. Hovering the mouse over that button will also show you what each mouse button does. Several of them are made to match other well-known applications. Choose one you are comfortable with.



Controlling how you look at your model in the 3D view can be done in multiple ways: Using the **mouse** (depending on the navigation style you chose), the **keyboard** (explore the contents of the **View** menu to find out more), or the Navigation Cube (click the different arrows and faces of the cube to align the view).



Tutorial steps

Choose a navigation style


True

Set yourself in Top view

```
True if FreeCADGui.ActiveDocument.ActiveView.getViewDirection().getAngle(FreeCAD.Vector(0,0,-1)) < 0.
```


Reorganize the interface

All panels and toolbars in FreeCAD can be moved and reorganized. Larger panels can also be joined by dragging and dropping them on another one. If your screen is too small to display all the toolbars and their contents (truncated toolbars will appear with a >> sign), it might be a good idea to move them to a better position.



Right-clicking on an empty area of the toolbars space also allows you to turn on and off individual toolbars and panels.

The BIM workbench also features switch buttons in the status bar, that turns additional panels like selection view, report view and python console on and off. These panels are often useful while working with FreeCAD, but they use precious screen space. You can usually turn everything off until you need them. Remember that error messages are printed in the report window, so in case anything goes wrong, be sure to have a look there.



Tutorial steps

No action to perform for this step

The BIM workbench tools

The BIM Workbench contains tools borrowed from other workbenches such as Arch, Draft or Part, as well as a couple of its own tools. These are organized in several categories. Each category has a menu and a toolbar. Take a moment to explore the contents of the menus described below.

2D Drafting

These tools allow you to draw flat objects, such as lines, polylines, rectangles, arcs, etc... that will become the bases of your BIM objects. For example, you can use a polyline to define the base trace a wall, or a rectangle as a profile for a beam. All 2D objects are created in the current working plane.

3D Modeling

This category contains tools that create non-BIM 3D objects from scratch, such as boxes, or by using other objects as a base, such as extrusions or boolean operations (union, subtraction, intersection). The resulting objects, although they don't have BIM properties themselves, are easy to turn into BIM objects by using any of the tools from the next category.

BIM

These tools can be used to create BIM objects from scratch, or based on other objects. The result is different if you use the tool with an object selected or not. If not, you will be presented with a creation interface. If you have selected an object before running the tool, an object of the corresponding type will be created using the selected object as a base.

The way the base object will be used also depends on its type. If a line is selected when building a wall, for example, the new wall will use the line as its base alignment. If a rectangle is selected when using the structure tool, the new structural object will use the rectangle as its profile.

If the selected object is already a 3D object, such as obtained from the **3D Modeling** tools, then that object simply becomes a BIM object, and gains BIM properties.

Annotation

These tools produce annotative objects such as dimensions, texts, labels or grids, that are not used for modeling but to annotate your models and produce understandable drawings.

Snapping

These tools turn snapping positions on/off. Like in most BIM applications, each additional snapping position adds calculation time when drawing, so it is best to only keep the ones you need turned on.

Modify

These tools modify existing objects. They contain usual transformation tools such as Move or Rotate, plus a series of others that only work for specific object types.

Manage

This category contains general management tools. Most of them allow you to edit BIM properties of a large group of objects simultaneously, without the need to select them.

Each tool contained in these menus has its own documentation page that describes in detail how it works and what options are available. They are listed on the BIM Workbench documentation page, which is also accessible from the **Help** menu, or by using menu **Help -> What's this?** and clicking on any toolbar button.

Tutorial steps


No action to perform for this step

Prepare your working space


There are many ways to create BIM objects in FreeCAD. You can use the native BIM tools from this workbench, or use any other FreeCAD tool from other workbenches. Both the 2D drawing tools and the 3D BIM tools from this workbench, unlike other workbenches such as Part Design, make extensive use of **working planes** and **snapping**.

The working plane is where your next objects will be created. You can set it to one of the basic orthogonal planes (ground, front, side), or use any selected face to define the current working plane. You can also use Working Plane Proxies from menu **Utils** to store a specific working plane position inside your model. Building Parts also contain an implicit working plane. Changing the current working plane is done by pressing the working plane button on the BIM toolbar. The **grid** always reflects where the working plane is.

Set the working plane in "Top" mode now:



The snapping tools allow you to place new objects and points precisely according to existing geometry. However, enabling many snapping locations might slow down the drawing operations, so it is wise to only enable the snapping tools you intent to use. Take a moment to review what each of them does, so when needed you will know which can be disabled.



Take special notice of the last one, the **working plane snapping** tool, as it will force any snapped point to lie on the working plane, thus preventing you to snap above or under the working plane. You will often need to turn it on or off, depending on the operation you are performing.

Tutorial steps

Set the working plane in "Top" (XY) mode

```
True if ((FreeCAD.DraftWorkingPlane.axis.getAngle(FreeCAD.Vector(0,0,1)) < 0.01) and (FreeCAD.DraftTwo
```


Review the different snapping tools


```
True
```


Draw a first wall

Let's start building our pavilion by creating some walls. Walls can be drawn either directly with the wall tool, or by first drawing 2D objects such as lines, wires (polylines) or sketches, that will define the baseline of our walls. When you have such a baseline object selected, pressing the Wall tool will automatically convert it into a wall.

First, zoom out until a good part or all of the grid is seen. This will make it much easier to see what we are doing:



Then, press the  **Wall** button from the toolbar (or choose menu item **3D/BIM -> Wall**). Click two points on the grid, vertically aligned, distant by **300 cm**. Pressing SHIFT after the first point has been clicked will help you to keep your wall horizontal or vertical. The side panel will inform you of the length of wall while drawing.



If you created a wrong wall, no worries! Simply delete it or undo it (menu **Edit** -> **Undo**) and try again.


Tutorial steps

Create a wall


```
bool(len([o for o in FreeCAD.ActiveDocument.Objects if "MakeBlocks" in o.PropertiesList]) == 1)
```

Draw a second wall


Make a second, horizontal wall of 4 meters (or 400 centimeters) long. Select the **Wall tool** again, pan and zoom out until you see a good area of the grid, and pick two points from the grid to define the start and end points of the new wall:



After they are created, select both walls by pressing CTRL and clicking them both in the 3D view or in the tree view, and adjust their **height** property to 2.5 meters and their **width** to 20 centimeters (or any other measurement you are comfortable with, if working in another unit), so they look like this (Use the mouse to rotate the view, according to the navigation style you chose):




You can always correct or change properties after a wall or any other BIM object has been created. By expanding the wall object in the tree view, then double-clicking the baseline of the wall, you can also modify its base 2D object. Most BIM objects in FreeCAD are based on another object, such as a baseline or a profile.



Important note

You will notice that some property changes, in FreeCAD, don't reflect immediately on the object in the 3D view. Instead, the object is marked with a "to be recomputed" blue mark in the tree:



The reason for this is that a FreeCAD document can be a very complex chain of inter-dependent objects. Updating one can trigger an update on many others, and therefore take a long time. To avoid this, some operations simply mark the object to be recomputed, and you trigger the recomputation yourself by using menu **Edit -> Refresh** or pressing **Ctrl+R**.

Tutorial steps

Create two orthogonal wall objects

```
bool(len([o for o in FreeCAD.ActiveDocument.Objects if "MakeBlocks" in o.PropertiesList]) == 2)
```

Set their height to 2.50 meters and width to 20 centimeters

```
bool(len([o for o in FreeCAD.ActiveDocument.Objects if "MakeBlocks" in o.PropertiesList and o.Height.
```

Don't forget to save the file regularly!

Like any other computer application, FreeCAD is subject to failing or crashing, specially when we have little experience with it. Saving your file often is a very good habit to take in these early moments.

Save your file now by using menu **File -> Save**.

Tutorial steps

Save your file


```
bool(FreeCAD.ActiveDocument.FileName)
```


Draw a roof slab

We will now place a roof slab on top of our walls. Instead of drawing the slab directly, like we did with the walls, we will here first draw a rectangle, then turn the rectangle into a slab. We will now explore two methods to do so, both are useful to know, so we suggest you to try one first, then undo it (or reload the file), and try the other method.


Method 1: Draw the slab on the ground, then move it into position

It is often convenient to consider the top XY plane (the ground plane) as a kind of "drawing board", where we will be building our objects, and move then next to their correct position. There is an additional advantage here, our working plane is already in "Top" mode, so we don't need to change it.


Set yourself in top view, zoom out a bit until you see both walls, and draw a rectangle encompassing them both. Press the  **Rectangle** button from the toolbar (or choose menu item **2D Drafting -> Rectangle**):



Rotate your view to inspect the results. By default, the rectangle is filled with a face. This can be changed by changing the **Make Face** property of our rectangle to False. For the slab we are going to build, this has no impact, for other types of objects, however, the base object being a polyline or a face can make a difference.







The next step is to build a slab using our rectangle as its base, or extrusion profile. In FreeCAD, structural objects such as columns, beams or slabs are all made with a same tool, called **Structure**. After a structural object is created, setting its **IFC Role** property to the desired type (column, slab, etc...) is all that is needed to turn it into that type.


Make sure our rectangle is selected, then press the  **Structure** button from the toolbar (or choose menu item **3D/BIM -> Structure**). After your structural object is created, we need to make the following changes to its properties:

- Set its **Height** to **20 cm**
- Set its **IFC Role** to **Slab**


Now we need to move our new roof slab to its correct position, that is, above the walls. So we need to move it upwards, in the Z direction, by a distance of 250 cm, which is the height of our walls. We can simply edit the **Placement** property of our slab, expand its **Position** attribute, and set the value of **z** to 250 cm. Our slab is now well in place:




Another way to move our slab to its correct position, is to use the  **Move** tool from the **Modify** menu. For that, we need to set our working plane in a vertical plane first, by pressing the  **working plane** button (make sure you don't have any face selected), and setting it to **XY (Front)**. By setting ourselves in front view (press key **1**), we can now select the slab, press the  **Move** button, and move our slab by clicking one of its base points, and, with **Shift** pressed to restrict the movement vertically, click one point on top of the walls:



Method 2: Draw the slab directly in the correct plane

Another useful method is to directly draw our rectangle in the correct plane. We can easily set the working plane to the top surface of the walls, which is where we want our slab, by selecting one of these faces, and pressing the  **working plane** button:



Everything we draw from now on will happen in that plane. If you like, you can now set yourself in top view, but this is not necessary. Once your working plane is set, and provided **working plane snapping** is enabled, you can draw directly in any 3D view, being orthogonal or perspective.

Once our rectangle is drawn, we can just follow the same method as in method 1 to turn it into a slab (select it, press the **Structure** button, adjust its properties).

Tutorial steps

Create a rectangle

```
bool(len([o for o in FreeCAD.ActiveDocument.Objects if "Rectangle" in o.Name])) == 1)
```

Create a 20cm thick slab


```
bool(len([o for o in FreeCAD.ActiveDocument.Objects if "IfcRole" in o.PropertiesList and o.IfRole ==
```

Create a metallic column


Let's add a metallic column to give better support to our slab. Make sure the working plane is in Top mode, let's start by putting ourselves in top view (press key **2**), and turn the slab off, so we see better what's underneath. Select the slab, and press the **Space** key to turn its display off.

In FreeCAD, it is very easy to turn objects or groups on and off, and the tree shows you clearly what is shown and what is hidden. Be sure to use that often!

The **Structure** tool has some built-in profiles that we will use now. Make sure nothing is selected, then press the Structure button. In the **Structure options**, select **CTH**:



And click a point to place your column, more or less at this position. Give the new column an IFC Role of "Column" and a Height of 250cm.




Unfortunately, the CTH preset has only one diameter option of 42mm, which is very thin to support our concrete roof slab. Fortunately, as everything is parametric, it is easy to change the diameter. Expand the new structural object in the tree view, and you will find its profile object, named CTH423. Change its diameter to 12cm and its thickness to 8mm. Now we have a strong enough column.

Add a support plate


However, in the real world, it will be difficult to attach our metal column to the concrete slab. So let's add a plate to its top, which can be bolted to a corresponding plate molded inside the concrete. This will illustrate how you can easily modify BIM objects and create the very precise ones you need.

Let's start by changing the height of our column from 250cm to 249cm, to give it a space for a 1cm-thick plate. Then draw a 20cm x 20cm rectangle, either on the ground plane or on the top of the column, as we learned in the previous step. Use the **Move** tool, with midpoint and center snaps turned on, if needed, to center the rectangle over the column center.


Using the Structure tool again, create a structural object from the rectangle, give it a height of 1cm, and move it to a height of 249cm:



Now let's add our plate to the column. BIM objects in FreeCAD have two properties named **Additions** and **Subtractions** that can receive objects that need to be unioned or subtracted to/from them. To add the plate to the column, select the plate, then, with **Ctrl** pressed, select the column and use the **+** **Add** tool the **Modify** menu. Our plate is now part of the column:



By starting from simple shapes, and adding or subtracting objects, we can quickly create very complex BIM objects.



Tutorial steps

Create a CTH tubular column

```
bool(len([o for o in FreeCAD.ActiveDocument.Objects if "CTH" in o.Label]) == 1)
```


Add a 20cm x 20cm plate to the column

```
bool(len([o for o in FreeCAD.ActiveDocument.Objects if "Shape" in o.PropertiesList and (abs(o.Shape.V
```


Add windows and doors

Doors and windows are created with the same Window tool in FreeCAD. They can be independent or, if an object is selected when running the tool, inserted in another BIM object, in which case they will automatically create a hole through it.


Let's insert a 80cm x 210cm glass door in one of our walls. Start by placing the working plane on a face of a wall, which will make it easier to precisely place our window:



Then, with the wall selected, select **Window** from the **BIM** menu. Select the **Glass door** preset, and set the **Width** to 80cm and **Height** to 210cm. You can set the other values as you like:




Click a point on the base of the wall where you wish to place the window. This can be difficult, as the grid lines don't necessarily correspond to the wall edges. Pressing the **Q** key while drawing will create temporary snap points, and new snap points will become available at the horizontal/vertical intersections of these temporary snap points. Use this to find a suitable point:



If your window didn't get placed correctly, if the error seems fixable, use the **Move** tool to move it to its correct position. If not, it might be simpler to simply undo the operation and try again.

When everything is done, you should obtain a door properly inserted into its wall:



Tutorial steps

Create a glass door

```
bool(len([o for o in FreeCAD.ActiveDocument.Objects if "Window" in o.Name]) == 1)
```

To be continued...

The writing of this tutorial is not finished, be sure to check back soon!

Tutorial steps

No action to perform for this step

Retrieved from "http://www.freecadweb.org/wiki/index.php?title=BIM_ingame_tutorial&oldid=435315"

-
- This page was last edited on 5 March 2019, at 00:20.
 - Content is available under Creative Commons Attribution unless otherwise noted.