

Quarter Car Model with Single Mass

Justin Chin Cheong

May 2025

1 Problem Statement

The quarter car model is a well known and widely applied model used to investigate the vertical dynamics of a vehicle.

It simplifies the the investigation to just a single tire with suspension. The version discussed here is the most simple case where there is some excitation from the road and only the mass of the car body is considered. The most important parameter is the acceleration of the body as it influences the comfort characteristics of the vehicle.

Hence, the goal of this investigation is to:

1. Characterize the system using basic system types
2. Explore the frequency domain characteristics

1.1 Parameters

To evaluate our model, we can use the following parameter values.

$$\begin{aligned}m &= 400kg \\c &= 20000 \frac{N}{m} \\d &= 1500 \frac{Ns}{m}\end{aligned}$$

2 Formulation

2.1 Ordinary Differential Equation




Figure 1: System diagram of quarter car model

To begin, we must of course do a freebody diagram.




Figure 2: Free body diagram of quarter car model

From fig.2, we get the following equilibrium.

$$\sum F = m \cdot \ddot{z}_B = -mg - c(z_B - z_E) - d(\dot{z}_B - \dot{z}_E) \quad (1)$$

$$\ddot{z}_B = -g - \frac{c}{m}z_B - \frac{d}{m}\dot{z}_B + \frac{c}{m}z_E + \frac{d}{m}\dot{z}_E \quad (2)$$

This is our ordinary differential equation (ODE).

2.2 Transfer Function

We can perform a Laplace transform on (2) considering \ddot{z}_B as the output and z_E as the input. We also assume the initial conditions are zero and body starts from a neutral position such that the static term mg is of no consequence. (Alternatively we could have also excluded it from our free body diagram)

$$\begin{aligned}
L\{\ddot{z}_B(t) &= -\frac{c}{m}z_B(t) - \frac{d}{m}\dot{z}_B(t) + \frac{c}{m}z_E(t) + \frac{d}{m}\dot{z}_E(t)\} \\
\Rightarrow \ddot{Z}_B(s) &= -\frac{c}{ms^2}\ddot{Z}_B(s) - \frac{d}{ms}\ddot{Z}_B(s) + \frac{c}{m}Z_E(s) + \frac{ds}{m}Z_E(s) \\
\Leftrightarrow \ddot{Z}_B(s) \cdot (ms^2 + ds + c) &= Z_E(s) \cdot (ds^3 + cs^2) \\
\Leftrightarrow \ddot{Z}_B(s) &= Z_E(s) \cdot \frac{s^2(ds + c)}{ms^2 + ds + c}
\end{aligned}$$

Hence, we get a transfer function of

$$G_B(s) = \frac{s^2(ds + c)}{ms^2 + ds + c} \quad (3)$$

3 Analysis

3.1 System Characterization

Using our transfer function (3), we can find the poles and zeros to characterise it.

For the zeros:

$$\begin{aligned}
z_{1,2} &= 0 \\
z_3 &= -\frac{c}{d} \approx 13.333
\end{aligned}$$

For the poles:

$$\begin{aligned}
p_{1,2} &= \frac{-d \pm \sqrt{d^2 - 4mc}}{2m} \\
\Rightarrow p_1 &= \frac{-15 + 5\sqrt{119}\mathbf{i}}{8} \\
\Rightarrow p_2 &= \frac{-15 - 5\sqrt{119}\mathbf{i}}{8}
\end{aligned}$$

Having a zero at the origin tells us that the system is differential while z_3 suggest proportionality. The presence of two poles also implies 2nd order delay.

As such we can characterise the system as a PDT2 system.

Additionally, we see that the real parts of both poles are less than zero and hence the system is stable. It can also be noted that the system is not causal, but for our purposes, that is fine.

3.2 Frequency Domain Characteristics

Using our transfer function, we can plot a bode diagram to illustrate the frequency domain characteristics.

We can actually do this quite easily using MATLAB.

```
1 %% Programm
2
3 close all
4 clear all
5 m = 400; % mass
6 c = 20000; % stiffness
7 d = 1500; % damping
8 F = 1000; % external load
9 g = 981/100; % gravity
10 z0 = m*g/c; % initial displacement
11 freq={0,50*(2*pi)};
12
13 %% Bode Plot
14 sys = tf([d,c,0,0],[m,d,c]);
15
16 bode(sys,freq)
17 xlabel('Frequency [rad/s]')
18 title('Bode Plot of Body Acceleration Transfer Function due to Road Excitation')
    
```

Listing 1: Script to Plot Bode Diagrams

This code gives us the following plot




Figure 3: Bode Plot of $G_B(s)$

With MATLAB, we can even go a bit further and investigate how different parameters change the bode plot.

```

1 %% Variation of Mass
2 % Initialisation of parameters done in previous listing
3 mass=100:100:1000;
4
5 for h=1:length(mass)
6     m = mass(h); % update the mass
7     leg(h)= mass(h) + " kg"; % storing mass for legend
8     sys_acc(h)=tf([d,c,0,0],[m,d,c]); % finding transfer function
9 end
10
11 bode(sys_acc(1),sys_acc(2),sys_acc(3),sys_acc(4),sys_acc(5),sys_acc(6),sys_acc(7),sys_acc(8),sys_acc(9),sys_acc(10),freq)
12 acc_leg = legend(leg);
13 acc_leg.Location = 'southeast';
14 title('Bode Plot of Body Acceleration as body mass varies')

```

Listing 2: Script to Plot Bode Diagram Varying Mass




Figure 4: Bode Plot of $G_B(s)$ while varying mass m

To accomplish the same plots manually, we must consider the transfer function as

$$s \rightarrow \omega \mathbf{i}$$

$$G(j\omega) = \frac{-d\omega^3 \mathbf{i} - c\omega^2}{-m\omega^2 + d\omega \mathbf{i} + c} \quad (4)$$

For the magnitude:

$$\begin{aligned}
 A(w) &:= |G(w\mathbf{i})| \\
 &= \left| \frac{-d\omega^3\mathbf{i} - c\omega^2}{-m\omega^2 + d\omega\mathbf{i} + c} \right| \\
 &= \frac{\sqrt{(c\omega^2)^2 + (d\omega^3)^2}}{\sqrt{(c - m\omega^2)^2 + (d\omega)^2}} \\
 A(w) &= \sqrt{\frac{(c\omega^2)^2 + (d\omega^3)^2}{(c - m\omega^2)^2 + (d\omega)^2}}
 \end{aligned}$$

For the phase:

$$\begin{aligned}
 \phi(\omega) &:= \angle G_B(\omega\mathbf{i}) \\
 &= \arg\left(\frac{-d\omega^3\mathbf{i} - c\omega^2}{-m\omega^2 + d\omega\mathbf{i} + c}\right) \\
 &= \arg(-d\omega^3\mathbf{i} - c\omega^2) - \arg(-m\omega^2 + d\omega\mathbf{i} + c) \\
 \phi(\omega) &= \arctan\left(\frac{d\omega}{c}\right) - \arctan\left(\frac{d\omega}{c - m\omega^2}\right)
 \end{aligned}$$

Now, in MATLAB.

```

1 %% Manual Bode
2 A = @(w)(sqrt(((c*w^2)^2+(d*w^3)^2)/((c-m*w^2)^2+(d*w)^2)));
3 % Using angle since arctan doesn't work well
4 phi = @(w)(angle((-c*w^2-d*(w^3)*1i)/(c-m*w^2+d*w*1i)));
5
6 w = linspace(1,50*2*pi,1000);
7
8 for k=1:length(w)
9     A_val(k) = feval(A,w(k)); phi_val(k) = phi(w(k));
10 end
11
12 subplot(2,1,1)
13 loglog(w,A_val)
14 xlabel('Frequency [rad/s]')
15 ylabel('Amplitude')
16 title('Bodeplot')
17
18 subplot(2,1,2)
19 loglog(w,phi_val)
20 xlabel('Frequency [rad/s]')
21 ylabel('Phase')

```

Listing 3: Script to Plot Bode Diagram Manually




Figure 5: Bode Plot of $G_B(s)$ using manual method