The background of the cover is a blurred, close-up photograph of a robotic arm, likely a FIRST Robotics Competition robot. The arm is dark blue and grey, with various mechanical components and joints visible. The lighting is dramatic, with strong highlights and deep shadows, creating a sense of depth and complexity. The overall color palette is dominated by dark blues and greys, with a lighter, semi-transparent white band across the middle where the text is located.

# **Controls Engineering in the FIRST Robotics Competition**

**Graduate-level control theory for high schoolers**

**Tyler Veness**

# **Controls Engineering in the FIRST Robotics Competition**

**Graduate-level control theory for high schoolers**

**Tyler Veness**

Copyright © 2017-2020 Tyler Veness

[HTTPS://GITHUB.COM/CALCMOGUL/CONTROLS-ENGINEERING-IN-FRC](https://github.com/calcmogul/controls-engineering-in-frc)

Licensed under the Creative Commons Attribution-ShareAlike 4.0 International License (the “License”). You may not use this file except in compliance with the License. You may obtain a copy of the License at <https://creativecommons.org/licenses/by-sa/4.0/>. Unless required by applicable law or agreed to in writing, software distributed under the License is distributed on an “AS IS” BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied. See the License for the specific language governing permissions and limitations under the License.

Generated from commit b7a029b made on October 24, 2020. The latest version can be downloaded from <https://file.tavsys.net/control/controls-engineering-in-frc.pdf>.

# Contents

	<b>Preface</b> .....	<b>xi</b>
<b>0</b>	<b>Notes to the reader</b> .....	<b>1</b>
<b>0.1</b>	<b>Prerequisites</b>	<b>1</b>
<b>0.2</b>	<b>Structure of this book</b>	<b>1</b>
<b>0.3</b>	<b>Ethos of this book</b>	<b>2</b>
0.3.1	Role of classical control theory .....	2
0.3.2	An integrated approach to nonlinear control theory .....	3
<b>0.4</b>	<b>Mindset of an egoless engineer</b>	<b>3</b>
<b>0.5</b>	<b>Request for feedback</b>	<b>3</b>
<b>I</b>	<b>Fundamentals of control theory</b>	
<b>1</b>	<b>Control system basics</b> .....	<b>7</b>
<b>1.1</b>	<b>Nomenclature</b>	<b>7</b>
<b>1.2</b>	<b>What is gain?</b>	<b>8</b>
<b>1.3</b>	<b>Block diagrams</b>	<b>8</b>
<b>1.4</b>	<b>Why feedback control?</b>	<b>9</b>
<b>2</b>	<b>PID controllers</b> .....	<b>11</b>
<b>2.1</b>	<b>Proportional term</b>	<b>11</b>
<b>2.2</b>	<b>Derivative term</b>	<b>12</b>
<b>2.3</b>	<b>Integral term</b>	<b>14</b>



2.4	<b>PID controller definition</b>	16
2.5	<b>Response types</b>	16
2.6	<b>Manual tuning</b>	17
2.7	<b>Limitations</b>	17
<b>3</b>	<b>Application advice</b> .....	<b>19</b>
3.1	<b>Actuator saturation</b>	19

## II

## Modern control theory

<b>4</b>	<b>Linear algebra</b> .....	<b>23</b>
4.1	<b>Vectors</b>	23
4.2	<b>Linear combinations, span, and basis vectors</b>	23
4.3	<b>Linear transformations and matrices</b>	23
4.4	<b>Matrix multiplication as composition</b>	23
4.5	<b>The determinant</b>	24
4.6	<b>Inverse matrices, column space, and null space</b>	24
4.7	<b>Nonsquare matrices as transformations between dimensions</b>	24
4.8	<b>Eigenvectors and eigenvalues</b>	24
4.9	<b>Miscellaneous notation</b>	24
<b>5</b>	<b>State-space controllers</b> .....	<b>25</b>
5.1	<b>From PID control to model-based control</b>	25
5.2	<b>What is a dynamical system?</b>	26
5.3	<b>State-space notation</b>	26
5.3.1	What is state-space? .....	26
5.3.2	Definition .....	26
5.4	<b>Eigenvalues and stability</b>	27
5.5	<b>Controllability</b>	28
5.6	<b>Observability</b>	28
5.7	<b>Closed-loop controller</b>	29
5.8	<b>Pole placement</b>	30
5.9	<b>Linear-quadratic regulator</b>	31
5.9.1	The intuition .....	31
5.9.2	The mathematical definition .....	31
5.9.3	Bryson's rule .....	33
5.9.4	Pole placement vs LQR .....	33
5.10	<b>Model augmentation</b>	34
5.10.1	Plant augmentation .....	34
5.10.2	Controller augmentation .....	34
5.10.3	Observer augmentation .....	35
5.10.4	Output augmentation .....	35
5.10.5	Examples .....	35

<b>5.11</b>	<b>Feedforward</b>	<b>37</b>
5.11.1	Plant inversion . . . . .	37
5.11.2	Unmodeled dynamics . . . . .	39
<b>5.12</b>	<b>Integral control</b>	<b>40</b>
5.12.1	Plant augmentation . . . . .	40
5.12.2	Input error estimation . . . . .	40
<b>6</b>	<b>Digital control</b> . . . . .	<b>43</b>
<b>6.1</b>	<b>Phase loss</b>	<b>43</b>
<b>6.2</b>	<b>s-plane to z-plane</b>	<b>44</b>
6.2.1	z-plane stability . . . . .	44
6.2.2	z-plane behavior . . . . .	45
6.2.3	Nyquist frequency . . . . .	45
<b>6.3</b>	<b>Discretization methods</b>	<b>46</b>
<b>6.4</b>	<b>Effects of discretization on controller performance</b>	<b>48</b>
<b>6.5</b>	<b>Matrix exponential</b>	<b>50</b>
<b>6.6</b>	<b>Taylor series</b>	<b>51</b>
<b>6.7</b>	<b>Zero-order hold for state-space</b>	<b>52</b>
<b>7</b>	<b>Nonlinear control</b> . . . . .	<b>55</b>
<b>7.1</b>	<b>Introduction</b>	<b>55</b>
<b>7.2</b>	<b>Linearization</b>	<b>55</b>
<b>7.3</b>	<b>Lyapunov stability</b>	<b>56</b>
<b>7.4</b>	<b>Affine systems</b>	<b>57</b>
7.4.1	Feedback linearization for reference tracking . . . . .	57
<b>7.5</b>	<b>Further reading</b>	<b>58</b>
<b>8</b>	<b>State-space applications</b> . . . . .	<b>59</b>
<b>8.1</b>	<b>Elevator</b>	<b>59</b>
8.1.1	Continuous state-space model . . . . .	59
8.1.2	Model augmentation . . . . .	60
8.1.3	Gravity feedforward . . . . .	60
8.1.4	Simulation . . . . .	61
8.1.5	Implementation . . . . .	61
<b>8.2</b>	<b>Flywheel</b>	<b>61</b>
8.2.1	Continuous state-space model . . . . .	61
8.2.2	Model augmentation . . . . .	62
8.2.3	Simulation . . . . .	62
8.2.4	Implementation . . . . .	62
8.2.5	Flywheel model without encoder . . . . .	62
8.2.6	Voltage compensation . . . . .	64
<b>8.3</b>	<b>Single-jointed arm</b>	<b>64</b>
8.3.1	Continuous state-space model . . . . .	64
8.3.2	Model augmentation . . . . .	65
8.3.3	Gravity feedforward . . . . .	65
8.3.4	Simulation . . . . .	66

8.3.5	Implementation . . . . .	66
<b>8.4</b>	<b>Pendulum</b>	<b>67</b>
8.4.1	State-space model . . . . .	67
<b>8.5</b>	<b>Holonomic drivetrains</b>	<b>68</b>
8.5.1	Model . . . . .	68
8.5.2	Control . . . . .	69
8.5.3	Holonomic vs nonholonomic control . . . . .	69
<b>8.6</b>	<b>Differential drive</b>	<b>69</b>
8.6.1	Velocity subspace state-space model . . . . .	69
8.6.2	Linear time-varying model . . . . .	70
8.6.3	Improving model accuracy . . . . .	72
8.6.4	Cross track error controller . . . . .	73
8.6.5	Nonlinear observer design . . . . .	76
<b>8.7</b>	<b>Ramsete unicycle controller</b>	<b>77</b>
8.7.1	Velocity and turning rate command derivation . . . . .	78
8.7.2	Nonlinear controller equations . . . . .	79
8.7.3	Linear reference tracker . . . . .	80
<b>8.8</b>	<b>Linear time-varying unicycle controller</b>	<b>83</b>

### III

## Estimation and localization

<b>9</b>	<b>Stochastic control theory</b> . . . . .	<b>89</b>
<b>9.1</b>	<b>Terminology</b>	<b>89</b>
<b>9.2</b>	<b>State observers</b>	<b>89</b>
9.2.1	Luenberger observer . . . . .	90
<b>9.3</b>	<b>Introduction to probability</b>	<b>92</b>
9.3.1	Random variables . . . . .	92
9.3.2	Expected value . . . . .	93
9.3.3	Variance . . . . .	93
9.3.4	Joint probability density functions . . . . .	94
9.3.5	Covariance . . . . .	95
9.3.6	Correlation . . . . .	95
9.3.7	Independence . . . . .	95
9.3.8	Marginal probability density functions . . . . .	96
9.3.9	Conditional probability density functions . . . . .	96
9.3.10	Bayes's rule . . . . .	96
9.3.11	Conditional expectation . . . . .	96
9.3.12	Conditional variances . . . . .	96
9.3.13	Random vectors . . . . .	96
9.3.14	Covariance matrix . . . . .	97
9.3.15	Relations for independent random vectors . . . . .	97
9.3.16	Gaussian random variables . . . . .	98
<b>9.4</b>	<b>Linear stochastic systems</b>	<b>99</b>
9.4.1	State vector expectation evolution . . . . .	99
9.4.2	Error covariance matrix evolution . . . . .	99
9.4.3	Measurement vector expectation . . . . .	100
9.4.4	Measurement covariance matrix . . . . .	100

<b>9.5</b>	<b>Two-sensor problem</b>	<b>101</b>
<b>9.6</b>	<b>Kalman filter</b>	<b>101</b>
9.6.1	Derivations . . . . .	101
9.6.2	Predict and update equations . . . . .	104
9.6.3	Setup . . . . .	106
9.6.4	Simulation . . . . .	107
9.6.5	Kalman filter as Luenberger observer . . . . .	108
<b>9.7</b>	<b>Kalman smoother</b>	<b>110</b>
9.7.1	Derivations . . . . .	110
9.7.2	State update equation . . . . .	110
9.7.3	Error covariance equation . . . . .	111
9.7.4	Optimal estimate . . . . .	112
9.7.5	Predict and update equations . . . . .	113
9.7.6	Example . . . . .	114
<b>9.8</b>	<b>Extended Kalman filter</b>	<b>116</b>
<b>9.9</b>	<b>Unscented Kalman filter</b>	<b>116</b>
<b>9.10</b>	<b>Multiple model adaptive estimation</b>	<b>117</b>
<b>10</b>	<b>Pose estimation . . . . .</b>	<b>119</b>
<b>10.1</b>	<b>Euler integration</b>	<b>119</b>
<b>10.2</b>	<b>Pose exponential</b>	<b>119</b>
10.2.1	What is a group? . . . . .	119
10.2.2	What is a pose? . . . . .	120
10.2.3	What is a twist? . . . . .	120
10.2.4	Derivation . . . . .	120
10.2.5	Lie groups . . . . .	123
<b>10.3</b>	<b>Pose correction</b>	<b>124</b>

## IV

## System modeling

<b>11</b>	<b>Calculus . . . . .</b>	<b>127</b>
<b>11.1</b>	<b>Derivatives</b>	<b>127</b>
11.1.1	Power rule . . . . .	128
11.1.2	Product rule . . . . .	128
11.1.3	Chain rule . . . . .	128
<b>11.2</b>	<b>Integrals</b>	<b>128</b>
11.2.1	Change of variables . . . . .	129
<b>11.3</b>	<b>Tables</b>	<b>129</b>
11.3.1	Common derivatives and integrals . . . . .	129
<b>12</b>	<b>Dynamics . . . . .</b>	<b>131</b>
<b>12.1</b>	<b>Linear motion</b>	<b>131</b>
<b>12.2</b>	<b>Angular motion</b>	<b>131</b>
<b>12.3</b>	<b>Vectors</b>	<b>132</b>
12.3.1	Basic vector operations . . . . .	132



12.3.2	Cross product . . . . .	132
<b>12.4</b>	<b>Curvilinear motion</b>	<b>133</b>
12.4.1	Differential drive . . . . .	133
12.4.2	Mecanum drive . . . . .	135
12.4.3	Swerve drive . . . . .	138
<b>13</b>	<b>Newtonian mechanics examples</b> . . . . .	<b>141</b>
<b>13.1</b>	<b>DC brushed motor</b>	<b>141</b>
13.1.1	Equations of motion . . . . .	142
13.1.2	Calculating constants . . . . .	142
13.1.3	Current limiting . . . . .	144
<b>13.2</b>	<b>Elevator</b>	<b>144</b>
13.2.1	Equations of motion . . . . .	144
<b>13.3</b>	<b>Flywheel</b>	<b>146</b>
13.3.1	Equations of motion . . . . .	146
13.3.2	Calculating constants . . . . .	147
<b>13.4</b>	<b>Single-jointed arm</b>	<b>148</b>
13.4.1	Equations of motion . . . . .	148
13.4.2	Calculating constants . . . . .	149
<b>13.5</b>	<b>Pendulum</b>	<b>150</b>
13.5.1	Force derivation . . . . .	150
13.5.2	Torque derivation . . . . .	151
13.5.3	Energy derivation . . . . .	152
<b>13.6</b>	<b>Differential drive</b>	<b>153</b>
13.6.1	Equations of motion . . . . .	153
13.6.2	Calculating constants . . . . .	156
<b>14</b>	<b>Lagrangian mechanics examples</b> . . . . .	<b>157</b>
<b>14.1</b>	<b>DC brushed motor</b>	<b>158</b>
<b>14.2</b>	<b>Elevator</b>	<b>158</b>
<b>14.3</b>	<b>Flywheel</b>	<b>158</b>
<b>14.4</b>	<b>Single-jointed arm</b>	<b>158</b>
<b>14.5</b>	<b>Pendulum</b>	<b>158</b>
<b>14.6</b>	<b>Differential drive</b>	<b>158</b>
<b>15</b>	<b>System identification</b> . . . . .	<b>159</b>
<b>15.1</b>	<b>1-DOF mechanism model</b>	<b>160</b>
<b>15.2</b>	<b>Drivetrain velocity model</b>	<b>162</b>

**V**

**Motion planning**

<b>16</b>	<b>Motion profiles</b> . . . . .	<b>169</b>
<b>16.1</b>	<b>1-DOF motion profiles</b>	<b>169</b>
16.1.1	Jerk . . . . .	170

16.1.2	Profile selection	170
16.1.3	Profile equations	171
16.1.4	Other profile types	171
16.1.5	Further reading	172
<b>16.2</b>	<b>2-DOF motion profiles</b>	<b>172</b>
<b>17</b>	<b>Configuration spaces</b>	<b>173</b>
<b>17.1</b>	<b>Introduction</b>	<b>173</b>
<b>17.2</b>	<b>Waypoint planning</b>	<b>174</b>
<b>17.3</b>	<b>Waypoint traversal</b>	<b>176</b>
<b>17.4</b>	<b>State machine validation with safe sets</b>	<b>176</b>
<b>18</b>	<b>Trajectory optimization</b>	<b>177</b>

## VI Classical control theory

<b>19</b>	<b>Transfer functions</b>	<b>181</b>
<b>19.1</b>	<b>Laplace transform</b>	<b>181</b>
<b>19.2</b>	<b>Parts of a transfer function</b>	<b>181</b>
19.2.1	Poles and zeroes	181
19.2.2	Nonminimum phase zeroes	183
19.2.3	Pole-zero cancellation	183
<b>19.3</b>	<b>Transfer functions in feedback</b>	<b>184</b>
19.3.1	Root locus	184
<b>19.4</b>	<b>Classical vs modern control</b>	<b>186</b>
<b>20</b>	<b>Laplace domain analysis</b>	<b>189</b>
<b>20.1</b>	<b>Projections</b>	<b>189</b>
<b>20.2</b>	<b>Fourier transform</b>	<b>192</b>
<b>20.3</b>	<b>Laplace transform</b>	<b>194</b>
<b>20.4</b>	<b>Laplace transform definition</b>	<b>196</b>
<b>20.5</b>	<b>Case study: steady-state error</b>	<b>196</b>
<b>20.6</b>	<b>Case study: flywheel PID control</b>	<b>198</b>
<b>20.7</b>	<b>Gain margin and phase margin</b>	<b>201</b>

## VII Appendices

<b>A</b>	<b>Simplifying block diagrams</b>	<b>205</b>
<b>A.1</b>	<b>Cascaded blocks</b>	<b>205</b>
<b>A.2</b>	<b>Combining blocks in parallel</b>	<b>205</b>
<b>A.3</b>	<b>Removing a block from a feedforward loop</b>	<b>206</b>
<b>A.4</b>	<b>Eliminating a feedback loop</b>	<b>206</b>

A.5	Removing a block from a feedback loop	207
<b>B</b>	<b>Installing Python packages</b> .....	<b>209</b>
B.1	Windows instructions	209
B.2	Linux instructions	209
<b>C</b>	<b>Linear-quadratic regulator</b> .....	<b>211</b>
C.1	Derivation	211
C.2	Output feedback	214
C.3	Implicit model following	215
C.4	Time delay compensation	217
C.4.1	Continuous case .....	218
C.4.2	Discrete case .....	219
<b>D</b>	<b>QR-weighted linear plant inversion</b> .....	<b>221</b>
D.1	Necessary theorems	221
D.2	Setup	222
D.3	Minimization	222
<b>E</b>	<b>Steady-state feedforward</b> .....	<b>225</b>
E.1	Continuous case	225
E.2	Discrete case	226
E.3	Deriving steady-state input	227
E.3.1	Case study: second-order CIM motor model .....	227
<b>F</b>	<b>Derivations</b> .....	<b>229</b>
F.1	Transfer function in feedback	229
F.2	Zero-order hold for state-space	230
F.3	Kalman filter as Luenberger observer	231
F.3.1	Luenberger observer with separate prediction and update .....	232
F.4	Trapezoidal motion profile	232
	<b>Glossary</b> .....	<b>234</b>
	<b>Bibliography</b> .....	<b>235</b>
	Online	235
	Miscellaneous	236
	<b>Index</b> .....	<b>239</b>



## Preface

### Motivation

I am the software mentor for a FIRST Robotics Competition (FRC) team. My responsibilities for that include teaching programming, software engineering practices, and applications of control theory. The curriculum I developed as of the spring of 2017 (located at <https://frc3512.github.io/ci/>) taught rookies enough to be minimally competitive, but it provided no formal avenues of growth for veteran students.

Also, out of a six week build season, the software team usually only got a few days with the completed robot due to poor build schedule management. This led to two problems. First, two days is only enough time to verify basic software functionality, not test and tune feedback controllers. Second, this was also the first time the robot's electromechanical systems have been tested after integration, so any issues that arose consumed valuable software integration time while the team traced the problem to a mechanical, electrical, or software cause.

This book expands my curriculum to cover control theory topics I learned in my graduate-level engineering classes at University of California, Santa Cruz. It introduces state-space controllers and serves as a practical guide for formulating and implementing them. Since state-space control utilizes a system model, both problems mentioned earlier can be addressed. Basic software functionality can be tested against it and feedback controllers can be tuned automatically based on system constraints. This allows software teams to test their work much earlier in the build season in a controlled environment as well as save time during feedback controller design, implementation, and testing.

I originally started writing this book because I felt that the topic wasn't difficult, but the information for it wasn't easily accessible. When I was a high school robotics team member, I had to learn everything from scratch through various internet sources and eventually from college courses as part of my bachelor's degree. Control theory has a certain beauty to it, and I want more people to appreciate it the way I do. Therefore, my goal is to make the learning process quicker and easier for future team members by collating all the relevant information.

## **Intended audience**

This guide is intended to make an advanced engineering topic approachable so it can be applied by those who aren't experts in control theory. My intended audience is high school students who are members of a FIRST Robotics Competition team. As such, they will likely have passing knowledge of PID control and have basic proficiency in programming. This guide will expand their incomplete understanding of control theory to include the fundamentals of classical control theory, enough linear algebra to understand the notation and mechanics of modern control, and finally how to apply modern control to design challenges they regularly see in their FRC robots from year to year.

## **Acknowledgements**

I would like to thank my controls engineering instructors Dejan Milutinović and Gabriel Elkaim of University of California, Santa Cruz. They taught their classes from a pragmatic perspective focused on application and intuition that I appreciated. I would also like to thank Dejan Milutinović for introducing me to the field of control theory and both of my instructors for teaching me what it means to be a controls engineer.

Thanks to Austin Schuh from FRC team 971 for providing the final continuous state-space models used in the examples section.



## 0. Notes to the reader

### 0.1 Prerequisites

Knowledge of basic algebra and complex numbers is assumed. Some introductory physics and calculus will be taught as necessary.

### 0.2 Structure of this book

This book consists of five parts and a collection of appendices that address the four tasks a controls engineer carries out: derive a model of the system (kinematics), design a controller for the model (control theory), design an observer to estimate the current state of the model (localization), and plan how the controller is going to drive the model to a desired state (motion planning).

Part I, “Fundamentals of control theory,” introduces the basics of control theory, teaches the fundamentals of PID controller design, describes what a transfer function is, and shows how they can be used to analyze dynamical systems. Emphasis is placed on the geometric intuition of this analysis rather than the math.

Part II, “Modern control theory,” first provides a crash course in the geometric intuition behind linear algebra and covers enough of the mechanics of evaluating matrix algebra for the reader to follow along in later chapters. It covers state-space representation, controllability, and observability. The intuition gained in part I and the notation of linear algebra are used to model and control linear multiple-input, multiple-output (MIMO) systems and covers discretization, LQR controller design, LQE observer design, and feedforwards. Then, these concepts are applied to design and implement controllers for real systems. The examples from part IV are converted to state-space representation, implemented, and tested with a discrete controller.

Part II also introduces the basics of nonlinear control system analysis with Lyapunov functions. It presents an example of a nonlinear controller for a unicycle-like vehicle as well as how to apply it to a two-wheeled vehicle. Since nonlinear control isn't the focus of this book, we mention other books and resources for further reading.



Part III, “Estimation and localization,” introduces the field of stochastic control theory. The Luenberger observer and the probability theory behind the Kalman filter is taught with several examples of creative applications of Kalman filter theory.

Part IV, “System modeling,” introduces the basic calculus and physics concepts required to derive the models used in the previous chapters. It walks through the derivations for several common FRC subsystems. Then, methods for system identification are discussed for empirically measuring model parameters.

Part V, “Motion planning,” covers planning how the robot will get from its current state to some desired state in a manner achievable by its dynamics. It introduces motion profiles with one degree of freedom for simple maneuvers. Trajectory optimization methods are presented for generating profiles with higher degrees of freedom.

Part VI, “Classical control theory,” describes what a transfer function is, and shows how they can be used to analyze dynamical systems. Emphasis is placed on the geometric intuition of this analysis rather than the frequency domain math. This part is provided for those who are curious about a lower-level interpretation of control systems.

The appendices provide further enrichment that isn’t required for a passing understanding of the material. This includes derivations for many of the results presented and used in the mainmatter of the book.

The Python scripts used to generate the plots in the case studies double as reference implementations of the techniques discussed in their respective chapters. They are available in this book’s Git repository. Its location is listed on the copyright page.

### 0.3 Ethos of this book

This book is intended as both a tutorial for new students and as a reference manual for more experienced readers who need to review a thing or two. While it isn’t comprehensive, the reader will hopefully learn enough to either implement the concepts presented themselves or know where to look for more information.

Some parts are mathematically rigorous, but I believe in giving students a solid theoretical foundation with emphasis on intuition so they can apply it to new problems. To achieve deep understanding of the topics in this book, math is unavoidable. With that said, I try to provide practical and intuitive explanations whenever possible.

#### 0.3.1 Role of classical control theory

The sections on classical control theory are only included to develop geometric intuition for the mathematical machinery of modern control theory. Many tools exclusive to classical control theory (root locus, Bode plots, Nyquist plots, etc.) aren’t useful for or relevant to the examples presented, so they serve only to complicate the learning process.

Classical control theory is interesting in that one can perform stability and robustness analyses and design reasonable controllers for systems on the back of a napkin. It’s also useful for controlling systems which don’t have a model. One can generate a Bode plot of a system by feeding in sine waves of increasing frequency and recording the amplitude of the output oscillations. This data can be used to create a transfer function or lead and lag compensators can be applied directly based on the Bode plot. However, computing power is much more plentiful nowadays; we should take advantage of this in the design phase and use the more modern tools that enables when it makes sense.

This book uses LQR and modern control over, say, loop shaping with Bode and Nyquist plots because we have accurate dynamical models to leverage, and LQR allows directly expressing what the author is concerned with optimizing: state excursion relative to control effort. Applying lead and lag compensators, while effective for robust controller design, doesn't provide the same expressive power.

### 0.3.2 An integrated approach to nonlinear control theory

Most teaching resources separate linear and nonlinear control with the latter being reserved for a different course. Here, they are introduced together because the concepts of nonlinear control apply often, and it isn't that much of a leap (if Lyapunov stability isn't included). The control and estimation chapters cover relevant tools for dealing with nonlinearities like linearization when appropriate.

## 0.4 Mindset of an egoless engineer

Engineering has a mindset, not just a skillset. Engineers have a unique way of approaching problems, and the following maxim summarizes what I hope to teach my robotics students (with examples drawn from controls engineering).

“Engineer based on requirements, not an ideology.”

Engineering is filled with trade-offs. The tools should fit the job, and not every problem is a nail waiting to be struck by a hammer. Instead, assess the minimum requirements (min specs) for a solution to the task at hand and do only enough work to satisfy them; exceeding your specifications is a waste of time and money. If you require performance or maintainability above the min specs, your min specs were chosen incorrectly by definition.

Controls engineering is pragmatic in a similar respect: *solve. the. problem.* For control of nonlinear systems, plant inversion is elegant on paper but doesn't work with an inaccurate model, yet using a theoretically incorrect solution like linear approximations of the nonlinear system works well enough to be used industry-wide. There are more sophisticated controllers than PID, but we use PID anyway for its versatility and simplicity. Sometimes the inferior solutions are more effective or have a more desirable cost-benefit ratio than what the control system designer considers ideal or clean. Choose the tool that is most effective.

Solutions need to be good enough, but do not need to be perfect. We want to avoid integrators as they introduce instability, but we use them anyway because they work well for meeting tracking specifications. One should not blindly defend a design or follow an ideology, because there is always a case where its antithesis is a better option. The engineer should be able to determine when this is the case, set aside their ego, and do what will meet the specifications of their client (e.g., system response characteristics, maintainability, usability). Preferring one solution over another for pragmatic or technical reasons is fine, but the engineer should not care on a personal level which sufficient solution is chosen.

## 0.5 Request for feedback

While we have tried to write a book that makes the topics of control theory approachable, it still may be dense or fast-paced for some readers (it covers three classes of feedback control, two of which are for graduate students, in one short book). Please send us feedback, corrections, or suggestions through the GitHub link listed on the copyright page. New examples that demonstrate key concepts and make them more accessible are also appreciated.

*This page intentionally left blank*



# Fundamentals of control theory

<b>1</b>	<b>Control system basics</b> .....	<b>7</b>
1.1	Nomenclature	
1.2	What is gain?	
1.3	Block diagrams	
1.4	Why feedback control?	
<b>2</b>	<b>PID controllers</b> .....	<b>11</b>
2.1	Proportional term	
2.2	Derivative term	
2.3	Integral term	
2.4	PID controller definition	
2.5	Response types	
2.6	Manual tuning	
2.7	Limitations	
<b>3</b>	<b>Application advice</b> .....	<b>19</b>
3.1	Actuator saturation	

*This page intentionally left blank*

# 1. Control system basics

Control systems are all around us and we interact with them daily. A small list of ones you may have seen includes heaters and air conditioners with thermostats, cruise control and the anti-lock braking system (ABS) on automobiles, and fan speed modulation on modern laptops. **Control systems** monitor or control the behavior of **systems** like these and may consist of humans controlling them directly (manual control), or of only machines (automatic control).

How can we prove closed-loop **controllers** on an autonomous car, for example, will behave safely and meet the desired performance specifications in the presence of uncertainty? Control theory is an application of algebra and geometry used to analyze and predict the behavior of **systems**, make them respond how we want them to, and make them **robust** to **disturbances** and uncertainty.

Controls engineering is, put simply, the engineering process applied to control theory. As such, it's more than just applied math. While control theory has some beautiful math behind it, controls engineering is an engineering discipline like any other that is filled with trade-offs. The solutions control theory gives should always be sanity checked and informed by our performance specifications. We don't need to be perfect; we just need to be good enough to meet our specifications (see section 0.4 for more on engineering).

## 1.1 Nomenclature

Most resources for advanced engineering topics assume a level of knowledge well above that which is necessary. Part of the problem is the use of jargon. While it efficiently communicates ideas to those within the field, new people who aren't familiar with it are lost. See the glossary for a list of words and phrases commonly used in control theory, their origins, and their meaning. Links to the glossary are provided for certain words throughout the book and will use [this color](#).

The **system** or collection of actuators being controlled by a **control system** is called the **plant**. A **controller** is used to drive the **plant** from its current state to some desired state (the **reference**). **Controllers** which don't include information measured from the **plant's** **output** are called open-loop **controllers**.



Controllers which incorporate information fed back from the plant's output are called closed-loop controllers or feedback controllers. Figure 1.1 shows a plant in feedback with a controller.




Figure 1.1: Control system nomenclature for a closed-loop system

$r(t)$	reference	$u(t)$	control input
$e(t)$	error	$y(t)$	output

Note that the input and output of a system are defined from the plant's point of view. The negative feedback controller shown is driving the difference between the reference and output, also known as the error, to zero.

## 1.2 What is gain?

Gain is a proportional value that shows the relationship between the magnitude of an input signal to the magnitude of an output signal at steady-state. Many systems contain a method by which the gain can be altered, providing more or less "power" to the system.

Figure 1.2 shows a system with a hypothetical input and output. Since the output is twice the amplitude of the input, the system has a gain of 2.




Figure 1.2: Demonstration of system with a gain of  $K = 2$

## 1.3 Block diagrams

When designing or analyzing a control system, it is useful to model it graphically. Block diagrams are used for this purpose. They can be manipulated and simplified systematically (see appendix A). Figure 1.3 is an example of one.




Figure 1.3: Block diagram with nomenclature

The open-loop gain is the total gain from the sum node at the input (the circle) to the output branch.

This would be the **system's** gain if the feedback loop was disconnected. The **feedback gain** is the total gain from the output back to the input sum node. A sum node's output is the sum of its inputs.

Figure 1.4 is a block diagram with more formal notation in a feedback configuration.




Figure 1.4: Feedback block diagram

⊖ means “minus or plus” where a minus represents negative feedback.

## 1.4 Why feedback control?

Let's say we are controlling a DC brushed motor. With just a **mathematical model** and knowledge of all current **states** of the **system** (i.e., angular velocity), we can predict all future **states** given the future voltage **inputs**. Why then do we need feedback control? If the **system** is **disturbed** in any way that isn't modeled by our equations, like a load was applied to the armature, or voltage sag in the rest of the circuit caused the commanded voltage to not match the actual applied voltage, the angular velocity of the motor will deviate from the **model** over time.

To combat this, we can take measurements of the **system** and the environment to detect this deviation and account for it. For example, we could measure the current position and estimate an angular velocity from it. We can then give the motor corrective commands as well as steer our **model** back to reality. This feedback allows us to account for uncertainty and be **robust** to it.

*This page intentionally left blank*

## 2. PID controllers

The PID controller is a commonly used feedback controller consisting of proportional, integral, and derivative terms, hence the name. This chapter will build up the definition of a PID controller term by term while trying to provide intuition for how each of them behaves.

First, we'll get some nomenclature for PID controllers out of the way. The **reference** is called the **setpoint** (the desired position) and the **output** is called the **process variable** (the measured position). Below are some common variable naming conventions for relevant quantities.

$$\begin{array}{llll} r(t) & \text{setpoint} & u(t) & \text{control input} \\ e(t) & \text{error} & y(t) & \text{output} \end{array}$$

The **error**  $e(t)$  is  $r(t) - y(t)$ .

For those already familiar with PID control, this book's interpretation won't be consistent with the classical intuition of "past", "present", and "future" error. We will be approaching it from the viewpoint of modern control theory with proportional controllers applied to different physical quantities we care about. This will provide a more complete explanation of the derivative term's behavior for constant and moving **setpoints**, and this intuition will carry over to the modern control methods covered later in this book.

The proportional term drives the position error to zero, the derivative term drives the velocity error to zero, and the integral term accumulates the area between the **setpoint** and **output** plots over time (the integral of position **error**) and adds the current total to the **control input**. We'll go into more detail on each of these.

### 2.1 Proportional term

The *Proportional* term drives the position error to zero.

**Definition 2.1.1 — Proportional controller.**

$$u(t) = K_p e(t) \quad (2.1)$$

where  $K_p$  is the proportional gain and  $e(t)$  is the error at the current time  $t$ .

Figure 2.1 shows a block diagram for a system controlled by a P controller.




Figure 2.1: P controller block diagram

Proportional gains act like “software-defined springs” that pull the system toward the desired position. Recall from physics that we model springs as  $F = -kx$  where  $F$  is the force applied,  $k$  is a proportional constant, and  $x$  is the displacement from the equilibrium point. This can be written another way as  $F = k(0 - x)$  where 0 is the equilibrium point. If we let the equilibrium point be our feedback controller’s setpoint, the equations have a one-to-one correspondence.

$$F = k(r - x)$$

$$u(t) = K_p e(t) = K_p (r(t) - y(t))$$

so the “force” with which the proportional controller pulls the system’s output toward the setpoint is proportional to the error, just like a spring.

## 2.2 Derivative term

The *Derivative* term drives the velocity error to zero.

**Definition 2.2.1 — PD controller.**

$$u(t) = K_p e(t) + K_d \frac{de}{dt} \quad (2.2)$$

where  $K_p$  is the proportional gain,  $K_d$  is the derivative gain, and  $e(t)$  is the error at the current time  $t$ .

Figure 2.2 shows a block diagram for a system controlled by a PD controller.




Figure 2.2: PD controller block diagram






Figure 2.3: PD controller on an elevator

A PD controller has a proportional controller for position ( $K_p$ ) and a proportional controller for velocity ( $K_d$ ). The velocity **setpoint** is implicitly provided by how the position **setpoint** changes over time. Figure 2.3 shows an example for an elevator.

To prove a PD controller is just two proportional controllers, we will rearrange the equation for a PD controller.

$$u_k = K_p e_k + K_d \frac{e_k - e_{k-1}}{dt}$$

where  $u_k$  is the **control input** at timestep  $k$  and  $e_k$  is the **error** at timestep  $k$ .  $e_k$  is defined as  $e_k = r_k - x_k$  where  $r_k$  is the **setpoint** and  $x_k$  is the current **state** at timestep  $k$ .

$$u_k = K_p(r_k - x_k) + K_d \frac{(r_k - x_k) - (r_{k-1} - x_{k-1})}{dt}$$

$$u_k = K_p(r_k - x_k) + K_d \frac{r_k - x_k - r_{k-1} + x_{k-1}}{dt}$$

$$u_k = K_p(r_k - x_k) + K_d \frac{r_k - r_{k-1} - x_k + x_{k-1}}{dt}$$

$$u_k = K_p(r_k - x_k) + K_d \frac{(r_k - r_{k-1}) - (x_k - x_{k-1})}{dt}$$

$$u_k = K_p(r_k - x_k) + K_d \left( \frac{r_k - r_{k-1}}{dt} - \frac{x_k - x_{k-1}}{dt} \right)$$

Notice how  $\frac{r_k - r_{k-1}}{dt}$  is the velocity of the **setpoint**. By the same reasoning,  $\frac{x_k - x_{k-1}}{dt}$  is the **system's** velocity at a given timestep. That means the  $K_d$  term of the PD controller is driving the estimated velocity to the **setpoint** velocity.

If the **setpoint** is constant, the implicit velocity **setpoint** is zero, so the  $K_d$  term slows the **system** down if it's moving. This acts like a “software-defined damper”. These are commonly seen on door closers, and their damping force increases linearly with velocity.



## 2.3 Integral term

The *Integral* term accumulates the area between the **setpoint** and **output** plots over time (i.e., the integral of position **error**) and adds the current total to the **control input**. Accumulating the area between two curves is called integration.

**Definition 2.3.1 — PI controller.**

$$u(t) = K_p e(t) + K_i \int_0^t e(\tau) d\tau \quad (2.3)$$

where  $K_p$  is the proportional gain,  $K_i$  is the integral gain,  $e(t)$  is the error at the current time  $t$ , and  $\tau$  is the integration variable.

The integral integrates from time 0 to the current time  $t$ . We use  $\tau$  for the integration because we need a variable to take on multiple values throughout the integral, but we can't use  $t$  because we already defined that as the current time.

Figure 2.4 shows a block diagram for a **system** controlled by a PI controller.




Figure 2.4: PI controller block diagram

When the **system** is close to the **setpoint** in steady-state, the proportional term may be too small to pull the **output** all the way to the **setpoint**, and the derivative term is zero. This can result in **steady-state error**, as shown in figure 2.5.

A common way of eliminating **steady-state error** is to integrate the **error** and add it to the **control input**. This increases the **control effort** until the **system** converges. Figure 2.5 shows an example of **steady-state error** for a flywheel, and figure 2.6 shows how an integrator added to the flywheel controller eliminates it. However, too high of an integral gain can lead to overshoot, as shown in figure 2.7.

- R** There are better approaches to fix **steady-state error** like using feedforwards or constraining when the integral control acts using other knowledge of the **system**. We will discuss these in more detail when we get to modern control theory.




Figure 2.5: P controller on a flywheel with steady-state error





Figure 2.6: PI controller on a flywheel without steady-state error

Figure 2.7: PI controller on a flywheel with overshoot from large  $K_i$  gain

## 2.4 PID controller definition

When these three terms are combined, one gets the typical definition for a PID controller.

**Definition 2.4.1 — PID controller.**

$$u(t) = K_p e(t) + K_i \int_0^t e(\tau) d\tau + K_d \frac{de}{dt} \quad (2.4)$$

where  $K_p$  is the proportional gain,  $K_i$  is the integral gain,  $K_d$  is the derivative gain,  $e(t)$  is the error at the current time  $t$ , and  $\tau$  is the integration variable.

Figure 2.8 shows a block diagram for a [system](#) controlled by a PID controller.




Figure 2.8: PID controller block diagram

## 2.5 Response types

A [system](#) driven by a PID controller generally has three types of responses: underdamped, overdamped, and critically damped. These are shown in figure 2.9.

For the [step responses](#) in figure 2.9, [rise time](#) is the time the [system](#) takes to initially reach the [reference](#) after applying the [step input](#). [Settling time](#) is the time the [system](#) takes to settle at the [reference](#) after the [step input](#) is applied.

An *underdamped* response oscillates around the [reference](#) before settling. An *overdamped* response is slow to rise and does not overshoot the [reference](#). A *critically damped* response has the fastest [rise time](#) without overshooting the [reference](#).




Figure 2.9: PID controller response types

## 2.6 Manual tuning

These steps apply to position PID controllers. Velocity PID controllers typically don't need  $K_d$ .

1. Set  $K_p$ ,  $K_i$ , and  $K_d$  to zero.
2. Increase  $K_p$  until the **output** starts to oscillate around the **setpoint**.
3. Increase  $K_d$  as much as possible without introducing jittering in the **system response**.

If the **setpoint** follows a trapezoidal motion profile (see section 16.1), tuning becomes a lot easier. Plot the position **setpoint**, velocity **setpoint**, measured position, and measured velocity. The velocity **setpoint** can be obtained via numerical differentiation of the position **setpoint** (i.e.,  $v_{desired,k} = \frac{r_k - r_{k-1}}{\Delta t}$ ). Increase  $K_p$  until the position tracks well, then increase  $K_d$  until the velocity tracks well.

If the **controller** settles at an **output** above or below the **setpoint**, one can increase  $K_i$  such that the **controller** reaches the **setpoint** in a reasonable amount of time. However, a steady-state feedforward is strongly preferred over integral control (especially for velocity PID control).

**R** *Note:* Adding an integral gain to the **controller** is an incorrect way to eliminate **steady-state error**. A better approach would be to tune it with an integrator added to the **plant**, but this requires a **model**. Since we are doing output-based rather than model-based control, our only option is to add an integrator to the **controller**.

Beware that if  $K_i$  is too large, integral windup can occur. Following a large change in **setpoint**, the integral term can accumulate an error larger than the maximal **control input**. As a result, the system overshoots and continues to increase until this accumulated error is unwound.

## 2.7 Limitations

PID's heuristic method of tuning is a reasonable choice when there is no *a priori* knowledge of the **system dynamics**. However, controllers with much better response can be developed if a **dynamical model** of the **system** is known. Furthermore, PID only applies to single-input, single-output (SISO)

systems; we'll cover methods for multiple-input, multiple-output (MIMO) control in part II of this book.

## 3. Application advice

### 3.1 Actuator saturation

A controller calculates its output based on the error between the **reference** and the current **state**. **Plant** in the real world don't have unlimited control authority available for the controller to apply. When the actuator limits are reached, the controller acts as if the gain has been temporarily reduced.

We'll try to explain this through a bit of math. Let's say we have a controller  $u = k(r - x)$  where  $u$  is the **control effort**,  $k$  is the gain,  $r$  is the **reference**, and  $x$  is the current **state**. Let  $u_{max}$  be the limit of the actuator's output which is less than the uncapped value of  $u$  and  $k_{max}$  be the associated maximum gain. We will now compare the capped and uncapped controllers for the same **reference** and current **state**.

$$\begin{aligned}u_{max} &< u \\k_{max}(r - x) &< k(r - x) \\k_{max} &< k\end{aligned}$$

For the inequality to hold,  $k_{max}$  must be less than the original value for  $k$ . This reduced gain is evident in a **system response** when there is a linear change in state instead of an exponential one as it approaches the **reference**. This is due to the **control effort** no longer following a decaying exponential plot. Once the **system** is closer to the **reference**, the controller will stop saturating and produce realistic controller values again.



*This page intentionally left blank*

# Modern control theory

<b>4</b>	<b>Linear algebra</b> .....	<b>23</b>
4.1	Vectors	
4.2	Linear combinations, span, and basis vectors	
4.3	Linear transformations and matrices	
4.4	Matrix multiplication as composition	
4.5	The determinant	
4.6	Inverse matrices, column space, and null space	
4.7	Nonsquare matrices as transformations between dimensions	
4.8	Eigenvectors and eigenvalues	
4.9	Miscellaneous notation	
<b>5</b>	<b>State-space controllers</b> .....	<b>25</b>
5.1	From PID control to model-based control	
5.2	What is a dynamical system?	
5.3	State-space notation	
5.4	Eigenvalues and stability	
5.5	Controllability	
5.6	Observability	
5.7	Closed-loop controller	
5.8	Pole placement	
5.9	Linear-quadratic regulator	
5.10	Model augmentation	
5.11	Feedforward	
5.12	Integral control	
<b>6</b>	<b>Digital control</b> .....	<b>43</b>
6.1	Phase loss	
6.2	s-plane to z-plane	
6.3	Discretization methods	
6.4	Effects of discretization on controller performance	
6.5	Matrix exponential	
6.6	Taylor series	
6.7	Zero-order hold for state-space	
<b>7</b>	<b>Nonlinear control</b> .....	<b>55</b>
7.1	Introduction	
7.2	Linearization	
7.3	Lyapunov stability	
7.4	Affine systems	
7.5	Further reading	
<b>8</b>	<b>State-space applications</b> .....	<b>59</b>
8.1	Elevator	
8.2	Flywheel	
8.3	Single-jointed arm	
8.4	Pendulum	
8.5	Holonomic drivetrains	
8.6	Differential drive	
8.7	Ramsete unicycle controller	
8.8	Linear time-varying unicycle controller	

*This page intentionally left blank*

## 4. Linear algebra

Modern control theory borrows concepts from linear algebra. At first, linear algebra may appear very abstract, but there are simple geometric intuitions underlying it. First, watch 3Blue1Brown's preview video for the *Essence of linear algebra* video series (5 minutes) [4]. The goal here is to provide an intuitive, geometric understanding of linear algebra as a method of linear transformations.

We would normally include written material here for learning linear algebra, but 3Blue1Brown's animated videos are better at conveying the geometric intuition involved than anything we could write here with static text. Instead of making an inferior copy of his work, we'll provide bibliography entries for a selection of his videos.

### 4.1 Vectors

Watch the "Vectors, what even are they?" video from 3Blue1Brown's *Essence of linear algebra* series (5 minutes) [11].

### 4.2 Linear combinations, span, and basis vectors

Watch the "Linear combination, span, and basis vectors" video from 3Blue1Brown's *Essence of linear algebra* series (10 minutes) [6].

### 4.3 Linear transformations and matrices

Watch the "Linear transformations and matrices" video from 3Blue1Brown's *Essence of linear algebra* series (11 minutes) [7].

### 4.4 Matrix multiplication as composition

Watch the "Matrix multiplication as composition" video from 3Blue1Brown's *Essence of linear algebra* series (10 minutes) [8].

## 4.5 The determinant

Watch the “The determinant” video from 3Blue1Brown’s *Essence of linear algebra* series (10 minutes) [10].

## 4.6 Inverse matrices, column space, and null space

Watch the “Inverse matrices, column space, and null space” video from 3Blue1Brown’s *Essence of linear algebra* series (12 minutes) [5].

## 4.7 Nonsquare matrices as transformations between dimensions

Watch the “Nonsquare matrices as transformations between dimensions” video from 3Blue1Brown’s *Essence of linear algebra* series (4 minutes) [9].

## 4.8 Eigenvectors and eigenvalues

Watch the “Eigenvectors and eigenvalues” video from 3Blue1Brown’s *Essence of linear algebra* series (17 minutes) [3].

## 4.9 Miscellaneous notation

This book works with two-dimensional matrices in the sense that they only have rows and columns. The dimensionality of these matrices is specified by row first, then column. For example, a matrix with two rows and three columns would be a two-by-three matrix. A square matrix has the same number of rows as columns. Matrices commonly use capital letters while vectors use lowercase letters.

The matrix  $\mathbf{I}$  is known as the identity matrix, which is a square matrix with ones along its diagonal and zeroes elsewhere. For example

$$\begin{bmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix}$$

The matrix denoted by  $\mathbf{0}_{m \times n}$  is a matrix filled with zeroes with  $m$  rows and  $n$  columns.

The  $T$  in  $\mathbf{A}^T$  denotes transpose, which flips the matrix across its diagonal such that the rows become columns and vice versa.

The  $\dagger$  in  $\mathbf{B}^\dagger$  denotes the Moore-Penrose pseudoinverse given by  $\mathbf{B}^\dagger = (\mathbf{B}^T \mathbf{B})^{-1} \mathbf{B}^T$ . The pseudoinverse is used when the matrix is nonsquare and thus not invertible to produce a close approximation of an inverse in the least squares sense.



## 5. State-space controllers

**R** Chapters from here on use the `frcontrol` Python package to demonstrate the concepts discussed and perform the complex math required. See appendix B for how to install it.

When we want to command a **system** to a set of **states**, we design a controller with certain **control laws** to do it. PID controllers use the system **outputs** with proportional, integral, and derivative **control laws**. In state-space, we also have knowledge of the system **states** so we can do better.

Modern control theory uses state-space representation to model and control systems. State-space representation models **systems** as a set of **state**, **input**, and **output** variables related by first-order differential equations that describe how the **system's state** changes over time given the current **states** and **inputs**.

### 5.1 From PID control to model-based control

As mentioned before, controls engineers have a more general framework to describe control theory than just PID control. PID controller designers are focused on fiddling with controller parameters relating to the current, past, and future **error** rather than the underlying system **states**. Integral control is a commonly used tool, and some people use integral action as the majority of the control action. While this approach works in a lot of situations, it is an incomplete view of the world.

Model-based control has a completely different mindset. Controls designers using model-based control care about developing an accurate **model** of the **system**, then driving the **states** they care about to zero (or to a **reference**). Integral control is added with  $u_{error}$  estimation if needed to handle **model** uncertainty, but we prefer not to use it because its response is hard to tune and some of its destabilizing dynamics aren't visible during simulation.



## 5.2 What is a dynamical system?

A dynamical system is a **system** whose motion varies according to a set of differential equations. A dynamical system is considered *linear* if the differential equations describing its dynamics consist only of linear operators. Linear operators are things like constant gain multiplications, derivatives, and integrals. You can define reasonably accurate linear **models** for pretty much everything you'll see in FRC with just those relations.

But let's say you have a DC brushed motor hooked up to a power supply and you applied a constant voltage to it from rest. The motor approaches a steady-state angular velocity, but the shape of the angular velocity curve over time isn't a line. In fact, it's a decaying exponential curve akin to

$$\omega = \omega_{max} (1 - e^{-t})$$

where  $\omega$  is the angular velocity and  $\omega_{max}$  is the maximum angular velocity. If DC brushed motors are said to behave linearly, then why is this?

Linearity refers to a **system's** equations of motion, not its time domain response. The equation defining the motor's change in angular velocity over time looks like

$$\dot{\omega} = -a\omega + bV$$

where  $\dot{\omega}$  is the derivative of  $\omega$  with respect to time,  $V$  is the input voltage, and  $a$  and  $b$  are constants specific to the motor. This equation, unlike the one shown before, is actually linear because it only consists of multiplications and additions relating the **input**  $V$  and current **state**  $\omega$ .

Also of note is that the relation between the input voltage and the angular velocity of the output shaft is a linear regression. You'll see why if you model a DC brushed motor as a voltage source and generator producing back-EMF (in the equation above,  $bV$  corresponds to the voltage source and  $-a\omega$  corresponds to the back-EMF). As you increase the input voltage, the back-EMF increases linearly with the motor's angular velocity. If there was a friction term that varied with the angular velocity squared (air resistance is one example), the relation from input to output would be a curve. Friction that scales with just the angular velocity would result in a lower maximum angular velocity, but because that term can be lumped into the back-EMF term, the response is still linear.

## 5.3 State-space notation

### 5.3.1 What is state-space?

Recall from last chapter that 2D space has two axes:  $x$  and  $y$ . We represent locations within this space as a pair of numbers packaged in a vector, and each coordinate is a measure of how far to move along the corresponding axis. State-space is a Cartesian coordinate system with an axis for each **state** variable, and we represent locations within it the same way we do for 2D space: with a list of numbers in a vector. Each element in the vector corresponds to a **state** of the **system**.

In addition to the **state**, **inputs** and **outputs** are represented as vectors. Since the mapping from the current **states** and **inputs** to the change in **state** is a system of equations, it's natural to write it in matrix form.

### 5.3.2 Definition

Below are the continuous and discrete versions of state-space notation.

**Definition 5.3.1 — State-space notation.**

$$\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u} \quad (5.1)$$

$$\mathbf{y} = \mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u} \quad (5.2)$$

$$\mathbf{x}_{k+1} = \mathbf{A}\mathbf{x}_k + \mathbf{B}\mathbf{u}_k \quad (5.3)$$

$$\mathbf{y}_k = \mathbf{C}\mathbf{x}_k + \mathbf{D}\mathbf{u}_k \quad (5.4)$$

<b>A</b>	system matrix	<b>x</b>	state vector
<b>B</b>	input matrix	<b>u</b>	input vector
<b>C</b>	output matrix	<b>y</b>	output vector
<b>D</b>	feedthrough matrix		

Matrix	Rows × Columns	Matrix	Rows × Columns
<b>A</b>	states × states	<b>x</b>	states × 1
<b>B</b>	states × inputs	<b>u</b>	inputs × 1
<b>C</b>	outputs × states	<b>y</b>	outputs × 1
<b>D</b>	outputs × inputs		

Table 5.1: State-space matrix dimensions

In the continuous case, the change in **state** and the **output** are linear combinations of the **state** vector and the **input** vector. The **A** and **B** matrices are used to map the **state** vector **x** and the **input** vector **u** to a change in the **state** vector  $\dot{\mathbf{x}}$ . The **C** and **D** matrices are used to map the **state** vector **x** and the **input** vector **u** to an **output** vector **y**.

## 5.4 Eigenvalues and stability

The eigenvalues of **A** are called *poles*. The locations of the closed-loop poles in the complex plane determine the stability of the **system**. Each pole represents a frequency mode of the **system**, and their location determines how much of each response is induced for a given input frequency. Figure 5.1 shows the **impulse responses** in the time domain for **systems** with various pole locations. They all have an initial condition of 1.

Location	Stability
Left Half-plane (LHP)	Stable
Imaginary axis	Marginally stable
Right Half-plane (RHP)	Unstable

Table 5.2: Pole location and stability

When a **system** is stable, its output may oscillate but it converges to steady-state. When a **system** is




Figure 5.1: Impulse response vs pole location

marginally stable, its output oscillates at a constant amplitude forever. When a system is unstable, its output grows without bound.

**R** Imaginary poles always come in complex conjugate pairs (e.g.,  $-2 + 3i$ ,  $-2 - 3i$ ).

## 5.5 Controllability

State controllability implies that it is possible – by admissible inputs – to steer the states from any initial value to any final value within some finite time window.

**Theorem 5.5.1 — Controllability.** A continuous time-invariant linear state-space model is controllable if and only if

$$\text{rank} \left( \begin{bmatrix} \mathbf{B} & \mathbf{A}\mathbf{B} & \mathbf{A}^2\mathbf{B} & \dots & \mathbf{A}^{n-1}\mathbf{B} \end{bmatrix} \right) = n \quad (5.5)$$

where rank is the number of linearly independent rows in a matrix and  $n$  is the number of state variables.

The matrix in equation (5.5) being rank-deficient means the inputs cannot apply transforms along all axes in the state-space; the transformation the matrix represents is collapsed into a lower dimension.

The condition number of the controllability matrix  $\mathbb{C}$  is defined as  $\frac{\sigma_{max}(\mathbb{C})}{\sigma_{min}(\mathbb{C})}$  where  $\sigma_{max}$  is the maximum singular value<sup>1</sup> and  $\sigma_{min}$  is the minimum singular value. As this number approaches infinity, one or more of the states becomes uncontrollable. This number can also be used to tell us which actuators are better than others for the given system; a lower condition number means that the actuators have more control authority.

## 5.6 Observability

Observability is a measure for how well internal states of a system can be inferred by knowledge of its external outputs. The observability and controllability of a system are mathematical duals (i.e., as

<sup>1</sup>Singular values are a generalization of eigenvalues for nonsquare matrices.

controllability proves that an **input** is available that brings any initial **state** to any desired final **state**, observability proves that knowing enough **output** values provides enough information to predict the initial **state** of the system).

**Theorem 5.6.1 — Observability.** A continuous **time-invariant** linear state-space **model** is observable if and only if

$$\text{rank} \left( \begin{bmatrix} C \\ CA \\ \vdots \\ CA^{n-1} \end{bmatrix} \right) = n \quad (5.6)$$

where rank is the number of linearly independent rows in a matrix and  $n$  is the number of **state** variables.

The matrix in equation (5.6) being rank-deficient means the **outputs** do not contain contributions from every **state**. That is, not all **states** are mapped to a linear combination in the **output**. Therefore, the **outputs** alone are insufficient to estimate all the **states**.

The condition number of the observability matrix  $\mathbb{O}$  is defined as  $\frac{\sigma_{max}(\mathbb{O})}{\sigma_{min}(\mathbb{O})}$  where  $\sigma_{max}$  is the maximum singular value<sup>1</sup> and  $\sigma_{min}$  is the minimum singular value. As this number approaches infinity, one or more of the **states** becomes unobservable. This number can also be used to tell us which sensors are better than others for the given **system**; a lower condition number means the **outputs** produced by the sensors are better indicators of the **system state**.

## 5.7 Closed-loop controller

With the **control law**  $\mathbf{u} = \mathbf{K}(\mathbf{r} - \mathbf{x})$ , we can derive the closed-loop state-space equations. We'll discuss where this **control law** comes from in subsection 5.9.

First is the **state** update equation. Substitute the **control law** into equation (5.1).

$$\begin{aligned} \dot{\mathbf{x}} &= \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{K}(\mathbf{r} - \mathbf{x}) \\ \dot{\mathbf{x}} &= \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{K}\mathbf{r} - \mathbf{B}\mathbf{K}\mathbf{x} \\ \dot{\mathbf{x}} &= (\mathbf{A} - \mathbf{B}\mathbf{K})\mathbf{x} + \mathbf{B}\mathbf{K}\mathbf{r} \end{aligned} \quad (5.7)$$

Now for the **output** equation. Substitute the **control law** into equation (5.2).

$$\begin{aligned} \mathbf{y} &= \mathbf{C}\mathbf{x} + \mathbf{D}(\mathbf{K}(\mathbf{r} - \mathbf{x})) \\ \mathbf{y} &= \mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{K}\mathbf{r} - \mathbf{D}\mathbf{K}\mathbf{x} \\ \mathbf{y} &= (\mathbf{C} - \mathbf{D}\mathbf{K})\mathbf{x} + \mathbf{D}\mathbf{K}\mathbf{r} \end{aligned} \quad (5.8)$$

Now, we'll do the same for the discrete **system**. We'd like to know whether the **system** defined by equation (5.3) operating with the **control law**  $\mathbf{u}_k = \mathbf{K}(\mathbf{r}_k - \mathbf{x}_k)$  converges to the **reference**  $\mathbf{r}_k$ .

$$\begin{aligned} \mathbf{x}_{k+1} &= \mathbf{A}\mathbf{x}_k + \mathbf{B}\mathbf{u}_k \\ \mathbf{x}_{k+1} &= \mathbf{A}\mathbf{x}_k + \mathbf{B}(\mathbf{K}(\mathbf{r}_k - \mathbf{x}_k)) \\ \mathbf{x}_{k+1} &= \mathbf{A}\mathbf{x}_k + \mathbf{B}\mathbf{K}\mathbf{r}_k - \mathbf{B}\mathbf{K}\mathbf{x}_k \\ \mathbf{x}_{k+1} &= \mathbf{A}\mathbf{x}_k - \mathbf{B}\mathbf{K}\mathbf{x}_k + \mathbf{B}\mathbf{K}\mathbf{r}_k \end{aligned}$$

$$\mathbf{x}_{k+1} = (\mathbf{A} - \mathbf{BK})\mathbf{x}_k + \mathbf{BKr}_k$$

**Theorem 5.7.1** — Closed-loop state-space controller.

$$\dot{\mathbf{x}} = (\mathbf{A} - \mathbf{BK})\mathbf{x} + \mathbf{BKr} \quad (5.9)$$

$$\mathbf{y} = (\mathbf{C} - \mathbf{DK})\mathbf{x} + \mathbf{DKr} \quad (5.10)$$

$$\mathbf{x}_{k+1} = (\mathbf{A} - \mathbf{BK})\mathbf{x}_k + \mathbf{BKr}_k \quad (5.11)$$

$$\mathbf{y}_k = (\mathbf{C} - \mathbf{DK})\mathbf{x}_k + \mathbf{DKr}_k \quad (5.12)$$

<b>A</b>	system matrix	<b>K</b>	controller gain matrix
<b>B</b>	input matrix	<b>x</b>	state vector
<b>C</b>	output matrix	<b>r</b>	reference vector
<b>D</b>	feedthrough matrix	<b>y</b>	output vector

Matrix	Rows × Columns	Matrix	Rows × Columns
<b>A</b>	states × states	<b>x</b>	states × 1
<b>B</b>	states × inputs	<b>u</b>	inputs × 1
<b>C</b>	outputs × states	<b>y</b>	outputs × 1
<b>D</b>	outputs × inputs	<b>r</b>	states × 1
<b>K</b>	inputs × states		

Table 5.3: Controller matrix dimensions

Instead of commanding the **system** to a **state** using the vector **u** directly, we can now specify a vector of desired **states** through **r** and the **controller** will choose values of **u** for us over time to make the **system** converge to the **reference**. For equation (5.9) to reach steady-state, the eigenvalues of **A – BK** must be in the left-half plane. For equation (5.11) to have a bounded output, the eigenvalues of **A – BK** must be within the unit circle.

The eigenvalues of **A – BK** are the poles of the closed-loop **system**. Therefore, the rate of convergence and stability of the closed-loop **system** can be changed by moving the poles via the eigenvalues of **A – BK**. **A** and **B** are inherent to the **system**, but **K** can be chosen arbitrarily by the controller designer.

## 5.8 Pole placement

This is the practice of placing the poles of a closed-loop **system** directly to produce a desired response. Python Control offers several pole placement algorithms for generating controller or observer gains from a set of poles. In general, pole placement should only be used if you know what you're doing. It's much easier to let LQR place the poles for you, which we'll discuss next.



## 5.9 Linear-quadratic regulator

### 5.9.1 The intuition

We can demonstrate the basic idea behind the linear-quadratic regulator with the following flywheel model:

$$\dot{x} = ax + bu$$

where  $a$  is a negative constant representing the back-EMF of the motor,  $x$  is the angular velocity,  $b$  is a positive constant that maps the input voltage to some change in angular velocity (angular acceleration),  $u$  is the voltage applied to the motor, and  $\dot{x}$  is the angular acceleration.

If the angular velocity starts from zero and we apply a positive voltage, we'd see the motor spin up to some constant speed following an exponential decay, then stay at that speed. If we throw in the control law  $u = k(r - x)$ , we can make the system converge to a desired state  $r$  through proportional feedback. In what manner can we pick the constant  $k$  that balances getting to the target angular velocity quickly with getting there efficiently (minimal oscillations or excessive voltage)?

We can solve this problem with something called the linear-quadratic regulator. We'll define the following cost function that includes the states and inputs:

$$J = \int_0^{\infty} (Q(r - x)^2 + Ru^2) dt$$

We want to minimize this while obeying the constraint that the system follow our flywheel dynamics  $\dot{x} = ax + bu$ .

The cost is the sum of the squares of the error and the input for all time. If the controller gain  $k$  we pick in the control law  $u = k(r - x)$  is stable, the error  $r - x$  and the input  $u$  will both go to zero and give us a finite cost.  $Q$  and  $R$  let us decide how much the error and input contribute to the cost (we will require that  $Q \geq 0$  and  $R > 0$  for reasons that will be clear shortly<sup>2</sup>). Penalizing error more will make the controller more aggressive, while penalizing the input more will make the controller less aggressive. We want to pick a  $k$  that minimizes the cost.

There's a common trick for finding the value of a variable that minimizes a function of that variable. We'll take the derivative (the slope) of the cost function with respect to the input  $u$ , set the derivative to zero, then solve for  $u$ . When the slope is zero, the function is at a minimum or maximum. Now, the cost function we picked is quadratic. All the terms are strictly positive on account of the squared variables and nonnegative weights, so our cost is strictly positive and the quadratic function is concave up. The  $u$  we found is therefore a minimum.

The actual process of solving for  $u$  is mathematically intensive and outside the scope of this explanation (appendix C references a derivation for those curious). The rest of this section will describe the more general form of the linear-quadratic regulator and how to use it.

### 5.9.2 The mathematical definition

Instead of placing the poles of a closed-loop system manually, the linear-quadratic regulator (LQR) places the poles for us based on acceptable relative error and control effort costs. This method of

<sup>2</sup>Lets consider the boundary conditions on the weights  $Q$  and  $R$ . If we set  $Q$  to zero, error doesn't contribute to the cost, so the optimal solution is to not move. This minimizes the sum of the inputs over time. If we let  $R$  be zero, the input doesn't contribute to the cost, so infinite inputs are allowed as they minimize the sum of the errors over time. This isn't useful, so we require that the input be penalized with a nonzero  $R$ .




Figure 5.2: Pareto boundary for LQR

controller design uses a quadratic function for the cost-to-go defined as the sum of the **error** and **control effort** over time for the linear system  $\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u}$ .

$$J = \int_0^{\infty} (\mathbf{x}^T \mathbf{Q} \mathbf{x} + \mathbf{u}^T \mathbf{R} \mathbf{u}) dt$$

where  $J$  represents a trade-off between **state excursion** and **control effort** with the weighting factors  $\mathbf{Q}$  and  $\mathbf{R}$ . LQR is a **control law**  $\mathbf{u}$  that minimizes the cost function.  $\mathbf{Q}$  and  $\mathbf{R}$  slide the cost along a Pareto boundary between state tracking and **control effort** (see figure 5.2). Pareto optimality for this problem means that an improvement in state **tracking** cannot be obtained without using more **control effort** to do so. Also, a reduction in **control effort** cannot be obtained without sacrificing state **tracking** performance. Pole placement, on the other hand, will have a cost anywhere on, above, or to the right of the Pareto boundary (no cost can be inside the boundary).

The minimum of LQR's cost function is found by setting the derivative of the cost function to zero and solving for the **control law**  $\mathbf{u}$ . However, matrix calculus is used instead of normal calculus to take the derivative.

The feedback **control law** that minimizes  $J$  is shown in theorem 5.9.1.

**Theorem 5.9.1 — Linear-quadratic regulator.**

$$\min_{\mathbf{u}} \int_0^{\infty} (\mathbf{x}^T \mathbf{Q} \mathbf{x} + \mathbf{u}^T \mathbf{R} \mathbf{u}) dt$$

subject to  $\dot{\mathbf{x}} = \mathbf{A} \mathbf{x} + \mathbf{B} \mathbf{u}$  (5.13)

If the system is controllable, the optimal control policy  $\mathbf{u}^*$  that drives all the states to zero is  $-\mathbf{K} \mathbf{x}$ . To converge to nonzero states, a reference vector  $\mathbf{r}$  can be added to the state  $\mathbf{x}$ .

$$\mathbf{u} = \mathbf{K}(\mathbf{r} - \mathbf{x}) \quad (5.14)$$

This means that optimal control can be achieved with simply a set of proportional gains on all the states. To use the control law, we need knowledge of the full state of the system. That means we either have to measure all our states directly or estimate those we do not measure.

See appendix C for how  $\mathbf{K}$  is calculated. If the result is finite, the controller is guaranteed to be stable and robust with a phase margin of 60 degrees [28].

- R** LQR design's  $\mathbf{Q}$  and  $\mathbf{R}$  matrices don't need discretization, but the  $\mathbf{K}$  calculated for continuous time and discrete time systems will be different. The discrete time gains approach the continuous time gains as the sample period tends to zero.

**5.9.3 Bryson's rule**

The next obvious question is what values to choose for  $\mathbf{Q}$  and  $\mathbf{R}$ . While this can be more of an art than a science, Bryson's rule provides a good starting point. With Bryson's rule, the diagonals of the  $\mathbf{Q}$  and  $\mathbf{R}$  matrices are chosen based on the maximum acceptable value for each state and actuator. The nondiagonal elements are zero. The balance between  $\mathbf{Q}$  and  $\mathbf{R}$  can be slid along the Pareto boundary using a weighting factor  $\rho$ .

$$J = \int_0^{\infty} \left( \rho \left[ \left( \frac{x_1}{x_{1,max}} \right)^2 + \dots + \left( \frac{x_m}{x_{m,max}} \right)^2 \right] + \left[ \left( \frac{u_1}{u_{1,max}} \right)^2 + \dots + \left( \frac{u_n}{u_{n,max}} \right)^2 \right] \right) dt$$

$$\mathbf{Q} = \begin{bmatrix} \frac{\rho}{x_{1,max}^2} & 0 & \dots & 0 \\ 0 & \frac{\rho}{x_{2,max}^2} & & \vdots \\ \vdots & & \ddots & 0 \\ 0 & \dots & 0 & \frac{\rho}{x_{m,max}^2} \end{bmatrix} \quad \mathbf{R} = \begin{bmatrix} \frac{1}{u_{1,max}^2} & 0 & \dots & 0 \\ 0 & \frac{1}{u_{2,max}^2} & & \vdots \\ \vdots & & \ddots & 0 \\ 0 & \dots & 0 & \frac{1}{u_{n,max}^2} \end{bmatrix}$$

Small values of  $\rho$  penalize control effort while large values of  $\rho$  penalize state excursions. Large values would be chosen in applications like fighter jets where performance is necessary. Spacecrafts would use small values to conserve their limited fuel supply.

**5.9.4 Pole placement vs LQR**

This example uses the following second-order model for a CIM motor (a DC brushed motor).

$$\mathbf{A} = \begin{bmatrix} -\frac{b}{J} & \frac{K_t}{J} \\ -\frac{K_e}{L} & -\frac{R}{L} \end{bmatrix} \quad \mathbf{B} = \begin{bmatrix} 0 \\ \frac{1}{L} \end{bmatrix} \quad \mathbf{C} = [1 \quad 0] \quad \mathbf{D} = [0]$$




Figure 5.3: Second-order CIM motor response with pole placement and LQR

Figure 5.3 shows the response using discrete poles<sup>3</sup> placed at  $(0.1, 0)$  and  $(0.9, 0)$  and LQR with the following cost matrices.

$$\mathbf{Q} = \begin{bmatrix} \frac{1}{20^2} & 0 \\ 0 & \frac{1}{40^2} \end{bmatrix} \quad \mathbf{R} = \begin{bmatrix} \frac{1}{12^2} \end{bmatrix}$$

LQR selected poles at  $(0.593, 0)$  and  $(0.955, 0)$ . Notice with pole placement that as the current pole moves left, the **control effort** becomes more aggressive.

## 5.10 Model augmentation

This section will teach various tricks for manipulating state-space **models** with the goal of demystifying the matrix algebra at play. We will use the augmentation techniques discussed here in the section on integral control.

Matrix augmentation is the process of appending rows or columns to a matrix. In state-space, there are several common types of augmentation used: **plant** augmentation, **controller** augmentation, and **observer** augmentation.

### 5.10.1 Plant augmentation

Plant augmentation is the process of adding a state to a model's state vector and adding a corresponding row to the **A** and **B** matrices.

### 5.10.2 Controller augmentation

Controller augmentation is the process of adding a column to a controller's **K** matrix. This is often done in combination with **plant** augmentation to add controller dynamics relating to a newly added **state**.

<sup>3</sup>See section 6.2 for pole mappings of discrete systems (inside unit circle is stable). The pole mappings mentioned so far (LHP is stable) only apply to continuous systems.

### 5.10.3 Observer augmentation

Observer augmentation is closely related to [plant](#) augmentation. In addition to adding entries to the [observer](#) matrix **L**, the [observer](#) is using this augmented [plant](#) for estimation purposes. This is better explained with an example.

By augmenting the [plant](#) with a bias term with no dynamics (represented by zeroes in its rows in **A** and **B**), the [observer](#) will attempt to estimate a value for this bias term that makes the [model](#) best reflect the measurements taken of the real [system](#). Note that we're not collecting any data on this bias term directly; it's what's known as a hidden [state](#). Rather than our [inputs](#) and other [states](#) affecting it directly, the [observer](#) determines a value for it based on what is most likely given the [model](#) and current measurements. We just tell the [plant](#) what kind of dynamics the term has and the [observer](#) will estimate it for us.

### 5.10.4 Output augmentation

Output augmentation is the process of adding rows to the **C** matrix. This is done to help the controls designer visualize the behavior of internal states or other aspects of the [system](#) in MATLAB or Python Control. **C** matrix augmentation doesn't affect [state](#) feedback, so the designer has a lot of freedom here. Noting that the [output](#) is defined as  $y = \mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u}$ , the following row augmentations of **C** may prove useful. Of course, **D** needs to be augmented with zeroes as well in these cases to maintain the correct matrix dimensionality.

Since  $\mathbf{u} = -\mathbf{K}\mathbf{x}$ , augmenting **C** with  $-\mathbf{K}$  makes the [observer](#) estimate the [control input](#) **u** applied.

$$y = \mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u}$$

$$\begin{bmatrix} \mathbf{y} \\ \mathbf{u} \end{bmatrix} = \begin{bmatrix} \mathbf{C} \\ -\mathbf{K} \end{bmatrix} \mathbf{x} + \begin{bmatrix} \mathbf{D} \\ \mathbf{0} \end{bmatrix} \mathbf{u}$$

This works because **K** has the same number of columns as [states](#).

Various [states](#) can also be produced in the [output](#) with **I** matrix augmentation.

### 5.10.5 Examples

Snippet 5.1 shows how one packs together the following augmented matrix in Python using concatenation.

$$\begin{bmatrix} \mathbf{A} & \mathbf{B} \\ \mathbf{C} & \mathbf{D} \end{bmatrix}$$

```
#!/usr/bin/env python3

import numpy as np

def main():
    A = np.array([[1, 2], [3, 4]])
    B = np.array([[5], [6]])
    C = np.array([[7, 8]])
    D = np.array([[9]])

    tmp = np.concatenate(
        (np.concatenate((A, B), axis=1), np.concatenate((C, D), axis=1)),
        axis=0
    )

    print("A =")
```



```

print(A)
print("B =")
print(B)
print("C =")
print(C)
print("D =")
print(D)
print("[A, B; C, D] =")
print(tmp)

if __name__ == "__main__":
    main()

```

Snippet 5.1. Matrix augmentation example: concatenation

Snippet 5.2 shows how one packs together the same augmented matrix in Python using array slices.

```

#!/usr/bin/env python3

import numpy as np

def main():
    A = np.array([[1, 2], [3, 4]])
    B = np.array([[5], [6]])
    C = np.array([[7, 8]])
    D = np.array([[9]])

    tmp = np.zeros((3, 3))
    tmp[:2, :2] = A # tmp[0:2, 0:2] = A
    tmp[:2, 2:] = B # tmp[0:2, 2:3] = B
    tmp[2:, :2] = C # tmp[2:3, 0:2] = C
    tmp[2:, 2:] = D # tmp[2:3, 2:3] = D

    print("A =")
    print(A)
    print("B =")
    print(B)
    print("C =")
    print(C)
    print("D =")
    print(D)
    print("[A, B; C, D] =")
    print(tmp)

if __name__ == "__main__":
    main()

```

Snippet 5.2. Matrix augmentation example: array slices

Section 5.12 demonstrates `model` augmentation for different types of integral control.

## 5.11 Feedforward

So far, we've used feedback control for [reference tracking](#) (making a [system](#)'s output follow a desired [reference](#) signal). While this is effective, it's a reactionary measure; the [system](#) won't start applying [control effort](#) until the [system](#) is already behind. If we could tell the [controller](#) about the desired movement and required input beforehand, the [system](#) could react quicker and the feedback [controller](#) could do less work. A [controller](#) that feeds information forward into the [plant](#) like this is called a [feedforward controller](#).

A [feedforward controller](#) injects information about the [system](#)'s dynamics (like a [model](#) does) or the desired movement. The feedforward handles parts of the control actions we already know must be applied to make a [system](#) track a [reference](#), then feedback compensates for what we do not or cannot know about the [system](#)'s behavior at runtime.

There are two types of feedforwards: model-based feedforward and feedforward for unmodeled dynamics. The first solves a mathematical model of the system for the inputs required to meet desired velocities and accelerations. The second compensates for unmodeled forces or behaviors directly so the feedback controller doesn't have to. Both types can facilitate simpler feedback controllers; we'll cover examples of each.

### 5.11.1 Plant inversion

[Plant inversion](#) is a method of model-based feedforward for [state](#) feedback. It solves the [plant](#) for the input that will make the [plant](#) track a desired state. This is called inversion because in a block diagram, the inverted [plant](#) feedforward and [plant](#) cancel out to produce a unity system from input to output.

While it can be an effective tool, the following should be kept in mind.

1. Don't invert an unstable [plant](#). If the expected [plant](#) doesn't match the real [plant](#) exactly, the [plant](#) inversion will still result in an unstable [system](#). Stabilize the [plant](#) first with feedback, then inject an inversion.
2. Don't invert a nonminimum phase system. The advice for pole-zero cancellation in subsection 19.2.3 applies here.

#### Necessary theorems

The following theorem will be needed to derive the linear plant inversion equation.

**Theorem 5.11.1**  $\frac{\partial \mathbf{x}^T \mathbf{A} \mathbf{x}}{\partial \mathbf{x}} = 2\mathbf{A} \mathbf{x}$  where  $\mathbf{A}$  is symmetric.

#### Setup

Let's start with the equation for the [reference](#) dynamics

$$\mathbf{r}_{k+1} = \mathbf{A} \mathbf{r}_k + \mathbf{B} \mathbf{u}_k$$

where  $\mathbf{u}_k$  is the feedforward input. Note that this feedforward equation does not and should not take into account any feedback terms. We want to find the optimal  $\mathbf{u}_k$  such that we minimize the [tracking error](#) between  $\mathbf{r}_{k+1}$  and  $\mathbf{r}_k$ .

$$\mathbf{r}_{k+1} - \mathbf{A} \mathbf{r}_k = \mathbf{B} \mathbf{u}_k$$

To solve for  $\mathbf{u}_k$ , we need to take the inverse of the nonsquare matrix  $\mathbf{B}$ . This isn't possible, but we can find the pseudoinverse given some constraints on the [state tracking error](#) and [control effort](#). To

find the optimal solution for these sorts of trade-offs, one can define a cost function and attempt to minimize it. To do this, we'll first solve the expression for  $\mathbf{0}$ .

$$\mathbf{0} = \mathbf{B}\mathbf{u}_k - (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k)$$

This expression will be the *state tracking* cost we use in the following cost function as an  $H_2$  norm.

$$\mathbf{J} = (\mathbf{B}\mathbf{u}_k - (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k))^T (\mathbf{B}\mathbf{u}_k - (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k))$$

### Minimization

Given theorem 5.11.1, find the minimum of  $\mathbf{J}$  by taking the partial derivative with respect to  $\mathbf{u}_k$  and setting the result to  $\mathbf{0}$ .

$$\begin{aligned} \frac{\partial \mathbf{J}}{\partial \mathbf{u}_k} &= 2\mathbf{B}^T (\mathbf{B}\mathbf{u}_k - (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k)) \\ \mathbf{0} &= 2\mathbf{B}^T (\mathbf{B}\mathbf{u}_k - (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k)) \\ \mathbf{0} &= 2\mathbf{B}^T \mathbf{B}\mathbf{u}_k - 2\mathbf{B}^T (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k) \\ 2\mathbf{B}^T \mathbf{B}\mathbf{u}_k &= 2\mathbf{B}^T (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k) \\ \mathbf{B}^T \mathbf{B}\mathbf{u}_k &= \mathbf{B}^T (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k) \\ \mathbf{u}_k &= (\mathbf{B}^T \mathbf{B})^{-1} \mathbf{B}^T (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k) \end{aligned}$$

$(\mathbf{B}^T \mathbf{B})^{-1} \mathbf{B}^T$  is the Moore-Penrose pseudoinverse of  $\mathbf{B}$  denoted by  $\mathbf{B}^\dagger$ .

**Theorem 5.11.2 — Linear plant inversion.** Given the discrete model  $\mathbf{x}_{k+1} = \mathbf{A}\mathbf{x}_k + \mathbf{B}\mathbf{u}_k$ , the plant inversion feedforward is

$$\mathbf{u}_k = \mathbf{B}^\dagger (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k) \quad (5.15)$$

where  $\mathbf{B}^\dagger$  is the Moore-Penrose pseudoinverse of  $\mathbf{B}$ ,  $\mathbf{r}_{k+1}$  is the reference at the next timestep, and  $\mathbf{r}_k$  is the reference at the current timestep.

### Discussion

Linear *plant inversion* in theorem 5.11.2 compensates for *reference* dynamics that don't follow how the *model* inherently behaves. If they do follow the *model*, the feedforward has nothing to do as the *model* already behaves in the desired manner. When this occurs,  $\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k$  will return a zero vector.

For example, a constant *reference* requires a feedforward that opposes *system* dynamics that would change the *state* over time. If the *system* has no dynamics, then  $\mathbf{A} = \mathbf{I}$  and thus

$$\begin{aligned} \mathbf{u}_k &= \mathbf{B}^\dagger (\mathbf{r}_{k+1} - \mathbf{I}\mathbf{r}_k) \\ \mathbf{u}_k &= \mathbf{B}^\dagger (\mathbf{r}_{k+1} - \mathbf{r}_k) \end{aligned}$$

For a constant *reference*,  $\mathbf{r}_{k+1} = \mathbf{r}_k$ .

$$\begin{aligned} \mathbf{u}_k &= \mathbf{B}^\dagger (\mathbf{r}_k - \mathbf{r}_k) \\ \mathbf{u}_k &= \mathbf{B}^\dagger (\mathbf{0}) \end{aligned}$$




Figure 5.4: Second-order CIM motor response with plant inversion

$$\mathbf{u}_k = \mathbf{0}$$

so no feedforward is required to hold a **system** with no dynamics at a constant **reference**, as expected.

Figure 5.4 shows **plant** inversion applied to a second-order CIM motor model. **Plant** inversion accounts for the motor back-EMF and eliminates steady-state error.

### 5.11.2 Unmodeled dynamics

In addition to **plant** inversion, one can include feedforwards for unmodeled dynamics. Consider an elevator model which doesn't include gravity. A constant voltage offset can be used compensate for this. The feedforward takes the form of a voltage constant because voltage is proportional to force applied, and the force is acting in only one direction at all times.

$$u_k = V_{app} \quad (5.16)$$

where  $V_{app}$  is a constant. Another feedforward holds a single-jointed arm steady in the presence of gravity. It has the following form.

$$u_k = V_{app} \cos \theta \quad (5.17)$$

where  $V_{app}$  is the voltage required to keep the single-jointed arm level with the ground, and  $\theta$  is the angle of the arm relative to the ground. Therefore, the force applied is greatest when the arm is parallel with the ground and zero when the arm is perpendicular to the ground (at that point, the joint supports all the weight).

Note that the elevator model could be augmented easily enough to include gravity and still be linear, but this wouldn't work for the single-jointed arm since a trigonometric function is required to model the gravitational force in the arm's rotating reference frame<sup>4</sup>.

<sup>4</sup>While the applied torque of the motor is constant throughout the arm's range of motion, the torque caused by gravity in the opposite direction varies according to the arm's angle.

## 5.12 Integral control

A common way of implementing integral control is to add an additional **state** that is the integral of the **error** of the variable intended to have zero **steady-state error**.

There are two drawbacks to this method. First, there is integral windup on a unit **step input**. That is, the integrator accumulates even if the **system** is **tracking** the **model** correctly. The second is demonstrated by an example from Jared Russell of FRC team 254. Say there is a position/velocity trajectory for some **plant** to follow. Without integral control, one can calculate a desired  $\mathbf{K}\mathbf{x}$  to use as the **control input**. As a result of using both desired position and velocity, **reference tracking** is good. With integral control added, the **reference** is always the desired position, but there is no way to tell the controller the desired velocity.

Consider carefully whether integral control is necessary. One can get relatively close without integral control, and integral adds all the issues listed above. Below, it is assumed that the controls designer has determined that integral control will be worth the inconvenience.

We'll present two methods:

1. Augment the **plant** as described earlier. For an arm, one would add an “integral of position” state.
2. Estimate the “error” in the **control input** (the difference between what was applied versus what was observed to happen) via the **observer** and compensate for it. We'll call this “input error estimation”.

### 5.12.1 Plant augmentation

We want to augment the **system** with an integral term that integrates the **error**  $\mathbf{e} = \mathbf{r} - \mathbf{y} = \mathbf{r} - \mathbf{C}\mathbf{x}$ .

$$\begin{aligned}\mathbf{x}_I &= \int \mathbf{e} dt \\ \dot{\mathbf{x}}_I &= \mathbf{e} = \mathbf{r} - \mathbf{C}\mathbf{x}\end{aligned}$$

The **plant** is augmented as

$$\begin{aligned}\begin{bmatrix} \dot{\mathbf{x}} \\ \dot{\mathbf{x}}_I \end{bmatrix} &= \begin{bmatrix} \mathbf{A} & \mathbf{0} \\ -\mathbf{C} & \mathbf{0} \end{bmatrix} \begin{bmatrix} \mathbf{x} \\ \mathbf{x}_I \end{bmatrix} + \begin{bmatrix} \mathbf{B} \\ \mathbf{0} \end{bmatrix} \mathbf{u} + \begin{bmatrix} \mathbf{0} \\ \mathbf{I} \end{bmatrix} \mathbf{r} \\ \begin{bmatrix} \dot{\mathbf{x}} \\ \dot{\mathbf{x}}_I \end{bmatrix} &= \begin{bmatrix} \mathbf{A} & \mathbf{0} \\ -\mathbf{C} & \mathbf{0} \end{bmatrix} \begin{bmatrix} \mathbf{x} \\ \mathbf{x}_I \end{bmatrix} + \begin{bmatrix} \mathbf{B} & \mathbf{0} \\ \mathbf{0} & \mathbf{I} \end{bmatrix} \begin{bmatrix} \mathbf{u} \\ \mathbf{r} \end{bmatrix}\end{aligned}$$

The controller is augmented as

$$\begin{aligned}\mathbf{u} &= \mathbf{K}(\mathbf{r} - \mathbf{x}) - \mathbf{K}_I \mathbf{x}_I \\ \mathbf{u} &= [\mathbf{K} \quad \mathbf{K}_I] \left( \begin{bmatrix} \mathbf{r} \\ \mathbf{0} \end{bmatrix} - \begin{bmatrix} \mathbf{x} \\ \mathbf{x}_I \end{bmatrix} \right)\end{aligned}$$

### 5.12.2 Input error estimation

Given the desired **input** produced by a **controller**, unmodeled **disturbances** may cause the observed behavior of a **system** to deviate from its **model**. Input error estimation estimates the difference between the desired **input** and a hypothetical **input** that makes the **model** match the observed behavior. This value can be added to the **control input** to make the **controller** compensate for unmodeled **disturbances** and make the **model** better predict the **system's** future behavior.



First, we'll consider the one-dimensional case. Let  $u_{error}$  be the difference between the **input** actually applied to a **system** and the desired **input**. The  $u_{error}$  term is then added to the **system** as follows.

$$\dot{x} = Ax + B(u + u_{error})$$

$u + u_{error}$  is the hypothetical **input** actually applied to the **system**.

$$\dot{x} = Ax + Bu + Bu_{error}$$

The following equation generalizes this to a multiple-input **system**.

$$\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u} + \mathbf{B}_{error}u_{error}$$

where  $\mathbf{B}_{error}$  is a column vector that maps  $u_{error}$  to changes in the rest of the **state** the same way  $\mathbf{B}$  does for  $\mathbf{u}$ .  $\mathbf{B}_{error}$  is only a column of  $\mathbf{B}$  if  $u_{error}$  corresponds to an existing **input** within  $\mathbf{u}$ .

Given the above equation, we'll augment the **plant** as

$$\begin{bmatrix} \dot{\mathbf{x}} \\ u_{error} \end{bmatrix} = \begin{bmatrix} \mathbf{A} & \mathbf{B}_{error} \\ \mathbf{0} & \mathbf{0} \end{bmatrix} \begin{bmatrix} \mathbf{x} \\ u_{error} \end{bmatrix} + \begin{bmatrix} \mathbf{B} \\ \mathbf{0} \end{bmatrix} \mathbf{u}$$

$$\mathbf{y} = \begin{bmatrix} \mathbf{C} & 0 \end{bmatrix} \begin{bmatrix} \mathbf{x} \\ u_{error} \end{bmatrix} + \mathbf{D}\mathbf{u}$$

Notice how the **state** is augmented with  $u_{error}$ . With this **model**, the **observer** will estimate both the **state** and the  $u_{error}$  term. The controller is augmented similarly.  $\mathbf{r}$  is augmented with a zero for the goal  $u_{error}$  term.

$$\mathbf{u} = \mathbf{K}(\mathbf{r} - \mathbf{x}) - \mathbf{k}_{error}u_{error}$$

$$\mathbf{u} = \begin{bmatrix} \mathbf{K} & \mathbf{k}_{error} \end{bmatrix} \left( \begin{bmatrix} \mathbf{r} \\ 0 \end{bmatrix} - \begin{bmatrix} \mathbf{x} \\ u_{error} \end{bmatrix} \right)$$

where  $\mathbf{k}_{error}$  is a column vector with a 1 in a given row if  $u_{error}$  should be applied to that **input** or a 0 otherwise.

This process can be repeated for an arbitrary **error** which can be corrected via some linear combination of the **inputs**.

*This page intentionally left blank*

## 6. Digital control

The complex plane discussed so far deals with continuous **systems**. In decades past, **plants** and controllers were implemented using analog electronics, which are continuous in nature. Nowadays, microprocessors can be used to achieve cheaper, less complex controller designs. **Discretization** converts the continuous **model** we've worked with so far from a differential equation like

$$\dot{x} = x - 3 \quad (6.1)$$

to a difference equation like

$$\begin{aligned} \frac{x_{k+1} - x_k}{\Delta T} &= x_k - 3 \\ x_{k+1} - x_k &= (x_k - 3)\Delta T \\ x_{k+1} &= x_k + (x_k - 3)\Delta T \end{aligned} \quad (6.2)$$

where  $x_k$  refers to the value of  $x$  at the  $k^{th}$  timestep. The difference equation is run with some update period denoted by  $T$ , by  $\Delta T$ , or sometimes sloppily by  $dt$ <sup>1</sup>.

While higher order terms of a differential equation are derivatives of the **state** variable (e.g.,  $\ddot{x}$  in relation to equation (6.1)), higher order terms of a difference equation are delayed copies of the **state** variable (e.g.,  $x_{k-1}$  with respect to  $x_k$  in equation (6.2)).

### 6.1 Phase loss

However, **discretization** has drawbacks. Since a microcontroller performs discrete steps, there is a sample delay that introduces phase loss in the controller. Phase loss is the reduction of **phase margin**<sup>2</sup> that occurs in digital implementations of feedback controllers from sampling the continuous **system**

<sup>1</sup>The discretization of equation (6.1) to equation (6.2) uses the forward Euler discretization method.

<sup>2</sup>See section 20.7 for an explanation of phase margin.

at discrete time intervals. As the sample rate of the controller decreases, the **phase margin** decreases according to  $-\frac{T}{2}\omega$  where  $T$  is the sample period and  $\omega$  is the frequency of the **system** dynamics. Instability occurs if the **phase margin** of the **system** reaches zero. Large amounts of phase loss can make a stable controller in the continuous domain become unstable in the discrete domain. Here are a few ways to combat this.

- Run the controller with a high sample rate.
- Designing the controller in the analog domain with enough **phase margin** to compensate for any phase loss that occurs as part of **discretization**.
- Convert the **plant** to the digital domain and design the controller completely in the digital domain.

## 6.2 s-plane to z-plane

Transfer functions are converted to impulse responses using the Z-transform. The s-plane's LHP maps to the inside of a unit circle in the z-plane. Table 6.1 contains a few common points and figure 6.1 shows the mapping visually.

s-plane	z-plane
(0, 0)	(1, 0)
imaginary axis	edge of unit circle
$(-\infty, 0)$	(0, 0)

Table 6.1: Mapping from s-plane to z-plane




Figure 6.1: Mapping of axes from s-plane (left) to z-plane (right)

### 6.2.1 z-plane stability

Eigenvalues of a **system** that are within the unit circle are stable, but why is that? Let's consider a scalar equation  $x_{k+1} = ax_k$ .  $a < 1$  makes  $x_{k+1}$  converge to zero. The same applies to a complex number like  $z = x + yi$  for  $x_{k+1} = zx_k$ . If the magnitude of the complex number  $z$  is less than one,  $x_{k+1}$  will converge to zero. Values with a magnitude of 1 oscillate forever because  $x_{k+1}$  never decays.



### 6.2.2 z-plane behavior

As  $\omega$  increases in  $s = j\omega$ , a pole in the z-plane moves around the perimeter of the unit circle. Once it hits  $\frac{\omega_s}{2}$  (half the sampling frequency) at  $(-1, 0)$ , the pole wraps around. This is due to poles faster than the sample frequency folding down to below the sample frequency (that is, higher frequency signals *alias* to lower frequency ones).

You may notice that poles can be placed at  $(0, 0)$  in the z-plane. This is known as a deadbeat controller. An  $N^{\text{th}}$ -order deadbeat controller decays to the reference in  $N$  timesteps. While this sounds great, there are other considerations like **control effort**, **robustness**, and **noise immunity**. These will be discussed in more detail with LQR and LQE.

If poles from  $(1, 0)$  to  $(0, 0)$  on the x-axis approach infinity, then what do poles from  $(-1, 0)$  to  $(0, 0)$  represent? Them being faster than infinity doesn't make sense. Poles in this location exhibit oscillatory behavior similar to complex conjugate pairs. See figures 6.2 and 6.3. The jaggedness of these signals is due to the frequency of the **system** dynamics being above the Nyquist frequency (twice the sample frequency). The **discretized** signal doesn't have enough samples to reconstruct the continuous **system's** dynamics.




Figure 6.2: Single poles in various locations in z-plane




Figure 6.3: Complex conjugate poles in various locations in z-plane

### 6.2.3 Nyquist frequency

To completely reconstruct a signal, the Nyquist-Shannon sampling theorem states that it must be sampled at a frequency at least twice the maximum frequency it contains. The highest frequency a given sample rate can capture is called the Nyquist frequency, which is half the sample frequency. This is why recorded audio is sampled at  $44.1\text{ kHz}$ . The maximum frequency a typical human can hear is about  $20\text{ kHz}$ , so the Nyquist frequency is  $40\text{ kHz}$ . ( $44.1\text{ kHz}$  in particular was chosen for unrelated historical reasons.)

Frequencies above the Nyquist frequency are folded down across it. The higher frequency and the folded down lower frequency are said to alias each other<sup>3</sup>. Figure 6.4 demonstrates aliasing.

The effect of these high-frequency aliases can be reduced with a low-pass filter (called an anti-aliasing filter in this application).

<sup>3</sup>The aliases of a frequency  $f$  can be expressed as  $f_{alias}(N) \stackrel{def}{=} |f - Nf_s|$ . For example, if a  $200\text{ Hz}$  sine wave is sampled at  $150\text{ Hz}$ , the **observer** will see a  $50\text{ Hz}$  signal instead of a  $200\text{ Hz}$  one.




Figure 6.4: The samples of two sine waves can be identical when at least one of them is at a frequency above half the sample rate. In this case, the  $2\text{ Hz}$  sine wave is above the Nyquist frequency  $1.5\text{ Hz}$ .

### 6.3 Discretization methods

Discretization is done using a zero-order hold. That is, the **system state** is only updated at discrete intervals and it's held constant between samples (see figure 6.5). The exact method of applying this uses the matrix exponential, but this can be computationally expensive. Instead, approximations such as the following are used.

1. Forward Euler method. This is defined as  $y_{n+1} = y_n + f(t_n, y_n)\Delta t$ .
2. Backward Euler method. This is defined as  $y_{n+1} = y_n + f(t_{n+1}, y_{n+1})\Delta t$ .
3. Bilinear transform. The first-order bilinear approximation is  $s = \frac{2}{T} \frac{1-z^{-1}}{1+z^{-1}}$ .

where the function  $f(t_n, y_n)$  is the slope of  $y$  at  $n$  and  $T$  is the sample period for the discrete **system**. Each of these methods is essentially finding the area underneath a curve. The forward and backward Euler methods use rectangles to approximate that area while the bilinear transform uses trapezoids (see figures 6.6 and 6.7). Since these are approximations, there is distortion between the real discrete **system's** poles and the approximate poles. This is in addition to the phase loss introduced by discretizing at a given sample rate in the first place. For fast-changing **systems**, this distortion can quickly lead to instability.






Figure 6.5: Zero-order hold of a system response




Figure 6.6: Discretization methods applied to velocity data




Figure 6.7: Position plot of discretization methods applied to velocity data

## 6.4 Effects of discretization on controller performance

Running a feedback controller at a faster update rate doesn't always mean better control. In fact, you may be using more computational resources than you need. However, here are some reasons for running at a faster update rate.

Firstly, if you have a discrete **model** of the **system**, that **model** can more accurately approximate the underlying continuous **system**. Not all controllers use a **model** though.



Secondly, the controller can better handle fast **system** dynamics. If the **system** can move from its initial state to the desired one in under 250ms, you obviously want to run the controller with a period less than 250ms. When you reduce the sample period, you're making the discrete controller more accurately reflect what the equivalent continuous controller would do (controllers built from analog circuit components like op-amps are continuous).

Running at a lower sample rate only causes problems if you don't take into account the response time of your **system**. Some **systems** like heaters have **outputs** that change on the order of minutes. Running a control loop at 1kHz doesn't make sense for this because the **plant input** the controller computes won't change much, if at all, in 1ms.

Figures 6.8, 6.9, and 6.10 show simulations of the same controller for different sampling methods and sample rates, which have varying levels of fidelity to the real **system**.

Forward Euler is numerically unstable for low sample rates. The bilinear transform is a significant improvement due to it being a second-order approximation, but zero-order hold performs best due to the matrix exponential including much higher orders (we'll cover the matrix exponential in the next section).

Table 6.2 compares the Taylor series expansions of the discretization methods presented so far (these are found using polynomial division). The bilinear transform does best with accuracy trailing off after the third-order term. Forward Euler has no second-order or higher terms, so it undershoots. Backward Euler has twice the second-order term and overshoots the remaining higher order terms as

Figure 6.8: Sampling methods for system simulation with  $T = 0.1s$ Figure 6.9: Sampling methods for system simulation with  $T = 0.05s$




Figure 6.10: Sampling methods for system simulation with  $T = 0.01s$

well.

Method	Conversion	Taylor series expansion
Zero-order hold	$z = e^{Ts}$	$z = 1 + Ts + \frac{1}{2}T^2s^2 + \frac{1}{6}T^3s^3 + \dots$
Bilinear	$z = \frac{1 + \frac{1}{2}Ts}{1 - \frac{1}{2}Ts}$	$z = 1 + Ts + \frac{1}{2}T^2s^2 + \frac{1}{4}T^3s^3 + \dots$
Forward Euler	$z = 1 + Ts$	$z = 1 + Ts$
Reverse Euler	$z = \frac{1}{1 - Ts}$	$z = 1 + Ts + T^2s^2 + T^3s^3 + \dots$

Table 6.2: Taylor series expansions of discretization methods (scalar case). The zero-order hold discretization method is exact.

## 6.5 Matrix exponential

The matrix exponential (and [system discretization](#) in general) is typically solved with a computer. Python Control's `StateSpace.sample()` with the “zoh” method (the default) does this.

**Definition 6.5.1 — Matrix exponential.** Let  $\mathbf{X}$  be an  $n \times n$  matrix. The exponential of  $\mathbf{X}$  denoted by  $e^{\mathbf{X}}$  is the  $n \times n$  matrix given by the following power series.

$$e^{\mathbf{X}} = \sum_{k=0}^{\infty} \frac{1}{k!} \mathbf{X}^k \quad (6.3)$$

where  $\mathbf{X}^0$  is defined to be the identity matrix  $\mathbf{I}$  with the same dimensions as  $\mathbf{X}$ .

To understand why the matrix exponential is used in the [discretization](#) process, consider the set of

differential equations  $\dot{\mathbf{x}} = \mathbf{A}\mathbf{x}$  we use to describe **systems** (**systems** also have a  $\mathbf{B}\mathbf{u}$  term, but we'll ignore it for clarity). The solution to this type of differential equation uses an exponential. Since we are using matrices and vectors here, we use the matrix exponential.

$$\mathbf{x}(t) = e^{\mathbf{A}t} \mathbf{x}_0$$

where  $\mathbf{x}_0$  contains the initial conditions. If the initial **state** is the current system **state**, then we can describe the **system's state** over time as

$$\mathbf{x}_{k+1} = e^{\mathbf{A}T} \mathbf{x}_k$$

where  $T$  is the time between samples  $\mathbf{x}_k$  and  $\mathbf{x}_{k+1}$ .

## 6.6 Taylor series

**R** Watch the “Taylor series” video from 3Blue1Brown’s *Essence of calculus* series (22 minutes) [13] for an explanation of how the Taylor series expansion works.

The definition for the matrix exponential and the approximations below all use the *Taylor series expansion*. The Taylor series is a method of approximating a function like  $e^t$  via the summation of weighted polynomial terms like  $t^k$ .  $e^t$  has the following Taylor series around  $t = 0$ .

$$e^t = \sum_{n=0}^{\infty} \frac{t^n}{n!}$$

where a finite upper bound on the number of terms produces an approximation of  $e^t$ . As  $n$  increases, the polynomial terms increase in power and the weights by which they are multiplied decrease. For  $e^t$  and some other functions, the Taylor series expansion equals the original function for all values of  $t$  as the number of terms approaches infinity<sup>4</sup>. Figure 6.11 shows the Taylor series expansion of  $e^t$  around  $t = 0$  for a varying number of terms.


We’ll expand the first few terms of the Taylor series expansion in equation (6.3) for  $\mathbf{X} = \mathbf{A}T$  so we can compare it with other methods.

$$\sum_{k=0}^3 \frac{1}{k!} (\mathbf{A}T)^k = \mathbf{I} + \mathbf{A}T + \frac{1}{2} \mathbf{A}^2 T^2 + \frac{1}{6} \mathbf{A}^3 T^3$$

Table 6.3 compares the Taylor series expansions of the **discretization** methods for the matrix case. These use a more complex formula which we won’t present here.

Each of them has different stability properties. The bilinear transform preserves the (in)stability of the continuous time **system**.

<sup>4</sup>Functions for which their Taylor series expansion converges to and also equals it are called analytic functions.

Figure 6.11: Taylor series expansions of  $e^t$  around  $t = 0$  for  $n$  terms

Method	Conversion	Taylor series expansion
Zero-order hold	$\mathbf{A}_d = e^{\mathbf{A}_c T}$	$\mathbf{A}_d = \mathbf{I} + \mathbf{A}_c T + \frac{1}{2} \mathbf{A}_c^2 T^2 + \frac{1}{6} \mathbf{A}_c^3 T^3 + \dots$
Bilinear	$\mathbf{A}_d = (\mathbf{I} + \frac{1}{2} \mathbf{A}_c T) (\mathbf{I} - \frac{1}{2} \mathbf{A}_c T)^{-1}$	$\mathbf{A}_d = \mathbf{I} + \mathbf{A}_c T + \frac{1}{2} \mathbf{A}_c^2 T^2 + \frac{1}{4} \mathbf{A}_c^3 T^3 + \dots$
Forward Euler	$\mathbf{A}_d = \mathbf{I} + \mathbf{A}_c T$	$\mathbf{A}_d = \mathbf{I} + \mathbf{A}_c T$
Reverse Euler	$\mathbf{A}_d = (\mathbf{I} - \mathbf{A}_c T)^{-1}$	$\mathbf{A}_d = \mathbf{I} + \mathbf{A}_c T + \mathbf{A}_c^2 T^2 + \mathbf{A}_c^3 T^3 + \dots$

Table 6.3: Taylor series expansions of discretization methods (matrix case). The zero-order hold discretization method is exact.

## 6.7 Zero-order hold for state-space

Given the following continuous time state space model

$$\begin{aligned}\dot{\mathbf{x}} &= \mathbf{A}_c \mathbf{x} + \mathbf{B}_c \mathbf{u} + \mathbf{w} \\ \mathbf{y} &= \mathbf{C}_c \mathbf{x} + \mathbf{D}_c \mathbf{u} + \mathbf{v}\end{aligned}$$

where  $\mathbf{w}$  is the process noise,  $\mathbf{v}$  is the measurement noise, and both are zero-mean white noise sources with covariances of  $\mathbf{Q}_c$  and  $\mathbf{R}_c$  respectively.  $\mathbf{w}$  and  $\mathbf{v}$  are defined as normally distributed random variables.

$$\begin{aligned}\mathbf{w} &\sim N(0, \mathbf{Q}_c) \\ \mathbf{v} &\sim N(0, \mathbf{R}_c)\end{aligned}$$

The model can be discretized as follows

$$\begin{aligned}\mathbf{x}_{k+1} &= \mathbf{A}_d \mathbf{x}_k + \mathbf{B}_d \mathbf{u}_k + \mathbf{w}_k \\ \mathbf{y}_k &= \mathbf{C}_d \mathbf{x}_k + \mathbf{D}_d \mathbf{u}_k + \mathbf{v}_k\end{aligned}$$



with covariances

$$\mathbf{w}_k \sim N(0, \mathbf{Q}_d)$$

$$\mathbf{v}_k \sim N(0, \mathbf{R}_d)$$

**Theorem 6.7.1 — Zero-order hold for state-space.**

$$\mathbf{A}_d = e^{\mathbf{A}_c T} \quad (6.4)$$

$$\mathbf{B}_d = \int_0^T e^{\mathbf{A}_c \tau} d\tau \mathbf{B}_c = \mathbf{A}_c^{-1} (\mathbf{A}_d - \mathbf{I}) \mathbf{B}_c \quad (6.5)$$

$$\mathbf{C}_d = \mathbf{C}_c \quad (6.6)$$

$$\mathbf{D}_d = \mathbf{D}_c \quad (6.7)$$

$$\mathbf{Q}_d = \int_{\tau=0}^T e^{\mathbf{A}_c \tau} \mathbf{Q}_c e^{\mathbf{A}_c^T \tau} d\tau \quad (6.8)$$

$$\mathbf{R}_d = \frac{1}{T} \mathbf{R}_c \quad (6.9)$$

where a subscript of  $d$  denotes discrete, a subscript of  $c$  denotes the continuous version of the corresponding matrix,  $T$  is the sample period for the discrete system, and  $e^{\mathbf{A}_c T}$  is the matrix exponential of  $\mathbf{A}_c$ .

See appendix F.2 for derivations.

To compute  $\mathbf{A}_d$  and  $\mathbf{B}_d$  in one step, one can utilize the following property.

$$e^{\begin{bmatrix} \mathbf{A}_c & \mathbf{B}_c \\ \mathbf{0} & \mathbf{0} \end{bmatrix} T} = \begin{bmatrix} \mathbf{A}_d & \mathbf{B}_d \\ \mathbf{0} & \mathbf{I} \end{bmatrix}$$

$\mathbf{Q}_d$  can be computed as

$$\Phi = e^{\begin{bmatrix} -\mathbf{A}_c & \mathbf{Q}_c \\ \mathbf{0} & \mathbf{A}_c^T \end{bmatrix} T} = \begin{bmatrix} -\mathbf{A}_d & \mathbf{A}_d^{-1} \mathbf{Q}_d \\ \mathbf{0} & \mathbf{A}_d^T \end{bmatrix}$$

where  $\mathbf{Q}_d = \Phi_{2,2}^T \Phi_{1,2}$  [24].

To see why  $\mathbf{R}_c$  is being divided by  $T$ , consider the discrete white noise sequence  $\mathbf{v}_k$  and the (non-physically realizable) continuous white noise process  $\mathbf{v}$ . Whereas  $\mathbf{R}_{d,k} = E[\mathbf{v}_k \mathbf{v}_k^T]$  is a covariance matrix,  $\mathbf{R}_c(t)$  defined by  $E[\mathbf{v}(t) \mathbf{v}^T(\tau)] = \mathbf{R}_c(t) \delta(t - \tau)$  is a spectral density matrix (the Dirac function  $\delta(t - \tau)$  has units of 1/sec). The covariance matrix  $\mathbf{R}_c(t) \delta(t - \tau)$  has infinite-valued elements. The discrete white noise sequence can be made to approximate the continuous white noise process by shrinking the pulse lengths ( $T$ ) and increasing their amplitude, such that  $\mathbf{R}_d \rightarrow \frac{1}{T} \mathbf{R}_c$ .

That is, in the limit as  $T \rightarrow 0$ , the discrete noise sequence tends to one of infinite-valued pulses of zero duration such that the area under the “impulse” autocorrelation function is  $\mathbf{R}_d T$ . This is equal to the area  $\mathbf{R}_c$  under the continuous white noise impulse autocorrelation function.

*This page intentionally left blank*

## 7. Nonlinear control

While many tools exist for designing controllers for linear **systems**, all **systems** in reality are inherently nonlinear. We'll briefly mention some considerations for nonlinear **systems**.

### 7.1 Introduction

Recall from linear **system** theory that we defined **systems** as having the following form:

$$\begin{aligned}\dot{\mathbf{x}} &= \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u} + \mathbf{\Gamma}\mathbf{w} \\ \mathbf{y} &= \mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u} + \mathbf{v}\end{aligned}$$

In this equation, **A** and **B** are constant matrices, which means they are both time-invariant and linear (all transformations on the **system state** are linear ones, and those transformations remain the same for all time). In nonlinear and time-variant **systems**, the **state** evolution and **output** are defined by arbitrary functions of the current **states** and **inputs**.

$$\begin{aligned}\dot{\mathbf{x}} &= f(\mathbf{x}, \mathbf{u}, \mathbf{w}) \\ \mathbf{y} &= h(\mathbf{x}, \mathbf{u}, \mathbf{v})\end{aligned}$$

Nonlinear functions come up regularly when attempting to control the **pose** of a vehicle in the global coordinate frame instead of the vehicle's rotating local coordinate frame. Converting from one to the other requires applying a rotation matrix, which consists of sine and cosine operations. These functions are nonlinear.

### 7.2 Linearization

One way to control nonlinear **systems** is to **linearize** the **model** around a reference point. Then, all the powerful tools that exist for linear controls can be applied. This is done by taking the Jacobians of  $f$  and  $h$ .

$$\mathbf{A} = \frac{\partial f(\mathbf{x}, \mathbf{u}, \mathbf{w})}{\partial \mathbf{x}} \quad \mathbf{B} = \frac{\partial f(\mathbf{x}, \mathbf{u}, \mathbf{w})}{\partial \mathbf{u}} \quad \mathbf{C} = \frac{\partial h(\mathbf{x}, \mathbf{u}, \mathbf{v})}{\partial \mathbf{x}} \quad \mathbf{D} = \frac{\partial h(\mathbf{x}, \mathbf{u}, \mathbf{v})}{\partial \mathbf{u}}$$

Let  $f(\mathbf{x}, \mathbf{u})$  be defined as

$$\dot{\mathbf{x}} = f(\mathbf{x}, \mathbf{u}) = \begin{bmatrix} f_1(\mathbf{x}, \mathbf{u}) \\ f_2(\mathbf{x}, \mathbf{u}) \\ \vdots \\ f_m(\mathbf{x}, \mathbf{u}) \end{bmatrix}$$

The subscript denotes a row of  $f$ , where each row represents the dynamics of a state.

The Jacobian is the partial derivative of a vector-valued function with respect to one of the vector arguments. The Jacobian of  $f$  has as many rows as  $f$ , and the columns are filled with partial derivatives of  $f$ 's rows with respect to each of the argument's elements. For example, the Jacobian of  $f$  with respect to  $\mathbf{x}$  is

$$\mathbf{A} = \frac{\partial f(\mathbf{x}, \mathbf{u})}{\partial \mathbf{x}} = \begin{bmatrix} \frac{\partial f_1}{\partial x_1} & \frac{\partial f_1}{\partial x_2} & \cdots & \frac{\partial f_1}{\partial x_m} \\ \frac{\partial f_2}{\partial x_1} & \frac{\partial f_2}{\partial x_2} & \cdots & \frac{\partial f_2}{\partial x_m} \\ \vdots & \vdots & \ddots & \vdots \\ \frac{\partial f_m}{\partial x_1} & \frac{\partial f_m}{\partial x_2} & \cdots & \frac{\partial f_m}{\partial x_m} \end{bmatrix}$$

$\frac{\partial f_1}{\partial x_1}$  is the partial derivative of the first row of  $f$  with respect to the first state, and so on for all rows of  $f$  and states. This has  $n^2$  permutations and thus produces a square matrix.

The Jacobian of  $f$  with respect to  $\mathbf{u}$  is

$$\mathbf{B} = \frac{\partial f(\mathbf{x}, \mathbf{u})}{\partial \mathbf{u}} = \begin{bmatrix} \frac{\partial f_1}{\partial u_1} & \frac{\partial f_1}{\partial u_2} & \cdots & \frac{\partial f_1}{\partial u_n} \\ \frac{\partial f_2}{\partial u_1} & \frac{\partial f_2}{\partial u_2} & \cdots & \frac{\partial f_2}{\partial u_n} \\ \vdots & \vdots & \ddots & \vdots \\ \frac{\partial f_m}{\partial u_1} & \frac{\partial f_m}{\partial u_2} & \cdots & \frac{\partial f_m}{\partial u_n} \end{bmatrix}$$

$\frac{\partial f_1}{\partial u_1}$  is the partial derivative of the first row of  $f$  with respect to the first input, and so on for all rows of  $f$  and inputs. This has  $m \times n$  permutations and can produce a nonsquare matrix if  $m \neq n$ .

Linearization of a nonlinear equation is a Taylor series expansion to only the first-order terms (that is, terms whose variables have exponents on the order of  $x^1$ ). This is where the small angle approximations for  $\sin \theta$  and  $\cos \theta$  ( $\theta$  and 1 respectively) come from.

Higher order partial derivatives can be added to better approximate the nonlinear dynamics. We typically only **linearize** around equilibrium points<sup>1</sup> because we are interested in how the **system** behaves when perturbed from equilibrium. An FAQ on this goes into more detail [18]. To be clear though, **linearizing the system** around the current **state** as the **system** evolves does give a closer approximation over time.

Note that linearization with static matrices (that is, with a time-invariant linear **system**) only works if the original **system** in question is feedback linearizable.

### 7.3 Lyapunov stability

Lyapunov stability is a fundamental concept in nonlinear control, so we're going to give a brief overview of what it is so students can research it further.

<sup>1</sup>Equilibrium points are points where  $\dot{\mathbf{x}} = \mathbf{0}$ . At these points, the system is in steady-state.



Since the **state** evolution in nonlinear **systems** is defined by a function rather than a constant matrix, the **system's** poles as determined by **linearization** move around. Nonlinear control uses Lyapunov stability to determine if nonlinear **systems** are stable. From a linear control theory point of view, Lyapunov stability says the **system** is stable if, for a given initial condition, all possible eigenvalues of **A** from that point on remain in the left-half plane. However, nonlinear control uses a different definition.

Lyapunov stability means that the **system** trajectory can be kept arbitrarily close to the origin by starting sufficiently close to it. Lyapunov's direct method uses a function consisting of the energy in a **system** or derivatives of the **system's state** to prove stability around an equilibrium point. This is done by showing that the function, and thus its inputs, decay to some ground state.

More than one Lyapunov function can prove stability, and if one function doesn't prove it, another candidate should be tried. For this reason, we refer to these functions as *Lyapunov candidate functions*.

## 7.4 Affine systems

Let  $\mathbf{x} = \mathbf{x}_0 + \delta\mathbf{x}$  and  $\mathbf{u} = \mathbf{u}_0 + \delta\mathbf{u}$  where  $\delta\mathbf{x}$  and  $\delta\mathbf{u}$  are perturbations from  $(\mathbf{x}_0, \mathbf{u}_0)$ . A first-order linearization of  $\dot{\mathbf{x}} = f(\mathbf{x}, \mathbf{u})$  around  $(\mathbf{x}_0, \mathbf{u}_0)$  gives

$$\begin{aligned}\dot{\mathbf{x}} &\approx f(\mathbf{x}_0, \mathbf{u}_0) + \left. \frac{\partial f(\mathbf{x}, \mathbf{u})}{\partial \mathbf{x}} \right|_{\mathbf{x}_0, \mathbf{u}_0} \delta\mathbf{x} + \left. \frac{\partial f(\mathbf{x}, \mathbf{u})}{\partial \mathbf{u}} \right|_{\mathbf{x}_0, \mathbf{u}_0} \delta\mathbf{u} \\ \dot{\mathbf{x}} &= f(\mathbf{x}_0, \mathbf{u}_0) + \left. \frac{\partial f(\mathbf{x}, \mathbf{u})}{\partial \mathbf{x}} \right|_{\mathbf{x}_0, \mathbf{u}_0} \delta\mathbf{x} + \left. \frac{\partial f(\mathbf{x}, \mathbf{u})}{\partial \mathbf{u}} \right|_{\mathbf{x}_0, \mathbf{u}_0} \delta\mathbf{u}\end{aligned}$$

An affine system is a linear system with a constant offset in the dynamics. If  $(\mathbf{x}_0, \mathbf{u}_0)$  is an equilibrium point,  $f(\mathbf{x}_0, \mathbf{u}_0) = \mathbf{0}$ , the resulting **model** is linear, and LQR works as usual. If  $(\mathbf{x}_0, \mathbf{u}_0)$  is, say, the current operating point rather than an equilibrium point, the easiest way to correctly apply LQR is

1. Find a control input  $\mathbf{u}_0$  that makes  $(\mathbf{x}_0, \mathbf{u}_0)$  an equilibrium point.
2. Obtain an LQR for the linearized system.
3. Add  $\mathbf{u}_0$  to the LQR's control input.

For a control-affine **system** (a nonlinear **system** with linear control inputs)  $\dot{\mathbf{x}} = f(\mathbf{x}) + \mathbf{B}\mathbf{u}$ ,  $\mathbf{u}_0$  can be derived via plant inversion as follows.

$$\begin{aligned}\dot{\mathbf{x}} &= f(\mathbf{x}_0) + \mathbf{B}\mathbf{u}_0 \\ \mathbf{0} &= f(\mathbf{x}_0) + \mathbf{B}\mathbf{u}_0 \\ \mathbf{B}\mathbf{u}_0 &= -f(\mathbf{x}_0) \\ \mathbf{u}_0 &= -\mathbf{B}^\dagger f(\mathbf{x}_0)\end{aligned}\tag{7.1}$$

### 7.4.1 Feedback linearization for reference tracking

Feedback linearization lets us erase the nonlinear dynamics of a system so we can apply our own (usually linear) dynamics for **reference** tracking. To do this, we will perform a similar procedure as in subsection 5.11.1 and solve for  $\mathbf{u}$  given the **reference** dynamics in  $\dot{\mathbf{r}}$ .

$$\begin{aligned}\dot{\mathbf{r}} &= f(\mathbf{x}) + \mathbf{B}\mathbf{u} \\ \mathbf{B}\mathbf{u} &= \dot{\mathbf{r}} - f(\mathbf{x})\end{aligned}$$

$$\mathbf{u} = \mathbf{B}^\dagger(\dot{\mathbf{r}} - f(\mathbf{x})) \quad (7.2)$$

**R** To use equation (7.2) in a discrete controller, one can approximate  $\dot{\mathbf{r}}$  with  $\frac{\mathbf{r}_{k+1} - \mathbf{r}_k}{T}$  where  $T$  is the time period between the two [references](#).

## 7.5 Further reading

For a more complex type of trajectory tracking, read *A guiding vector field algorithm for path following control of nonholonomic mobile robots* [20].

To learn more about nonlinear control, we recommend watching the underactuated robotics lectures by MIT [31]. Links to it and the associated lecture note [32] are in the bibliography. The books *Nonlinear Dynamics and Chaos* by Steven Strogatz and *Applied Nonlinear Control* by Jean-Jacques Slotine are also good references.



## 8. State-space applications

Up to now, we've just been teaching what tools are available. Now, we'll go into specifics on how to apply them and provide advice on certain applications.

The code shown in each example can be obtained from frcontrol's Git repository at <https://github.com/calcmogul/frcontrol/tree/master/examples>. See appendix B for setup instructions.

### 8.1 Elevator

#### 8.1.1 Continuous state-space model

The position and velocity derivatives of the elevator can be written as

$$\dot{x} = v \quad (8.1)$$

$$\dot{v} = a \quad (8.2)$$

where by equation (13.15),

$$a = \frac{GK_t}{Rrm}V - \frac{G^2K_t}{Rr^2mK_v}v$$

Substitute this into equation (8.2).

$$\begin{aligned} \dot{v} &= \frac{GK_t}{Rrm}V - \frac{G^2K_t}{Rr^2mK_v}v \\ \dot{v} &= -\frac{G^2K_t}{Rr^2mK_v}v + \frac{GK_t}{Rrm}V \end{aligned} \quad (8.3)$$

Factor out  $v$  and  $V$  into column vectors.

$$\begin{bmatrix} \dot{v} \end{bmatrix} = \begin{bmatrix} -\frac{G^2K_t}{Rr^2mK_v} \end{bmatrix} \begin{bmatrix} v \end{bmatrix} + \begin{bmatrix} \frac{GK_t}{Rrm} \end{bmatrix} \begin{bmatrix} V \end{bmatrix}$$

Augment the matrix equation with the position state  $x$ , which has the model equation  $\dot{x} = v$ . The matrix elements corresponding to  $v$  will be 1, and the others will be 0 since they don't appear, so  $\dot{x} = 0x + 1v + 0V$ . The existing rows will have zeroes inserted where  $x$  is multiplied in.

$$\begin{bmatrix} \dot{x} \\ v \end{bmatrix} = \begin{bmatrix} 0 & 1 \\ 0 & -\frac{G^2 K_t}{Rr^2 m K_v} \end{bmatrix} \begin{bmatrix} x \\ v \end{bmatrix} + \begin{bmatrix} 0 \\ \frac{GK_t}{Rrm} \end{bmatrix} [V]$$

**Theorem 8.1.1 — Elevator state-space model.**

$$\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u}$$

$$\mathbf{y} = \mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u}$$

$$\mathbf{x} = \begin{bmatrix} x \\ v \end{bmatrix} \quad \mathbf{y} = x \quad \mathbf{u} = V$$

$$\mathbf{A} = \begin{bmatrix} 0 & 1 \\ 0 & -\frac{G^2 K_t}{Rr^2 m K_v} \end{bmatrix} \quad \mathbf{B} = \begin{bmatrix} 0 \\ \frac{GK_t}{Rrm} \end{bmatrix} \quad \mathbf{C} = [1 \quad 0] \quad \mathbf{D} = 0 \quad (8.4)$$

### 8.1.2 Model augmentation

As per subsection 5.12.2, we will now augment the model so a  $u_{error}$  state is added to the control input.

The plant and observer augmentations should be performed before the model is discretized. After the controller gain is computed with the unaugmented discrete model, the controller may be augmented. Therefore, the plant and observer augmentations assume a continuous model and the controller augmentation assumes a discrete controller.

$$\mathbf{x}_{aug} = \begin{bmatrix} x \\ v \\ u_{error} \end{bmatrix} \quad \mathbf{y} = x \quad \mathbf{u} = V$$

$$\mathbf{A}_{aug} = \begin{bmatrix} \mathbf{A} & \mathbf{B} \\ \mathbf{0}_{1 \times 2} & 0 \end{bmatrix} \quad \mathbf{B}_{aug} = \begin{bmatrix} \mathbf{B} \\ 0 \end{bmatrix} \quad \mathbf{C}_{aug} = [\mathbf{C} \quad 0] \quad \mathbf{D}_{aug} = \mathbf{D} \quad (8.5)$$

$$\mathbf{K}_{aug} = [\mathbf{K} \quad 1] \quad \mathbf{r}_{aug} = \begin{bmatrix} \mathbf{r} \\ 0 \end{bmatrix} \quad (8.6)$$

This will compensate for unmodeled dynamics such as gravity. However, using a constant voltage feedforward to counteract gravity is preferred over  $u_{error}$  estimation in this case because it results in a simpler controller with similar performance.

### 8.1.3 Gravity feedforward

Input voltage is proportional to force and gravity is a constant force, so a constant voltage feedforward can compensate for gravity. We'll model gravity as a disturbance described by  $-mg$ . To compensate for it, we want to find a voltage that is equal and opposite to it. The bottom row of the continuous elevator model contains the acceleration terms.

$$Bu_{ff} = -(\text{unmodeled dynamics})$$

where  $B$  is the motor acceleration term from  $\mathbf{B}$  and  $u_{ff}$  is the voltage feedforward.

$$Bu_{ff} = -(-mg)$$




Figure 8.1: Elevator response

$$\begin{aligned}
 Bu_{ff} &= mg \\
 \frac{GK_t}{Rrm}u_{ff} &= mg \\
 u_{ff} &= \frac{Rrm^2g}{GK_t}
 \end{aligned}$$

### 8.1.4 Simulation

Python Control will be used to discretize the model and simulate it. One of the frcontrol examples<sup>1</sup> creates and tests a controller for it. Figure 8.1 shows the closed-loop system response.

### 8.1.5 Implementation

C++ and Java implementations of this elevator controller are available online<sup>2 3</sup>.

## 8.2 Flywheel

### 8.2.1 Continuous state-space model

By equation (13.18)

$$\dot{\omega} = -\frac{G^2K_t}{K_vRJ}\omega + \frac{GK_t}{RJ}V$$

Factor out  $\omega$  and  $V$  into column vectors.

$$\begin{bmatrix} \dot{\omega} \end{bmatrix} = \begin{bmatrix} -\frac{G^2K_t}{K_vRJ} \end{bmatrix} \begin{bmatrix} \omega \end{bmatrix} + \begin{bmatrix} \frac{GK_t}{RJ} \end{bmatrix} \begin{bmatrix} V \end{bmatrix}$$

<sup>1</sup><https://github.com/calcmogul/frcontrol/blob/master/examples/elevator.py>

<sup>2</sup><https://github.com/wpilibsuite/allwpilib/blob/master/wpilibcExamples/src/main/cpp/examples/StateSpaceElevator/cpp/Robot.cpp>

<sup>3</sup><https://github.com/wpilibsuite/allwpilib/blob/master/wpilibjExamples/src/main/java/edu/wpi/first/wpilibj/examples/statepacelevator/Robot.java>

**Theorem 8.2.1 — Flywheel state-space model.**

$$\begin{aligned}\dot{\mathbf{x}} &= \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u} \\ \mathbf{y} &= \mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u} \\ \mathbf{x} &= \omega \quad \mathbf{y} = \omega \quad \mathbf{u} = V \\ \mathbf{A} &= -\frac{G^2 K_t}{K_v R J} \quad \mathbf{B} = \frac{G K_t}{R J} \quad \mathbf{C} = 1 \quad \mathbf{D} = 0\end{aligned}\tag{8.7}$$

**8.2.2 Model augmentation**

As per subsection 5.12.2, we will now augment the **model** so a  $u_{error}$  state is added to the **control** input.

The **plant** and **observer** augmentations should be performed before the **model** is **discretized**. After the **controller** gain is computed with the unaugmented discrete **model**, the controller may be augmented. Therefore, the **plant** and **observer** augmentations assume a continuous **model** and the **controller** augmentation assumes a discrete **controller**.

$$\mathbf{x} = \begin{bmatrix} \omega \\ u_{error} \end{bmatrix} \quad \mathbf{y} = \omega \quad \mathbf{u} = V$$

$$\mathbf{A}_{aug} = \begin{bmatrix} \mathbf{A} & \mathbf{B} \\ 0 & 0 \end{bmatrix} \quad \mathbf{B}_{aug} = \begin{bmatrix} \mathbf{B} \\ 0 \end{bmatrix} \quad \mathbf{C}_{aug} = [\mathbf{C} \quad 0] \quad \mathbf{D}_{aug} = \mathbf{D}\tag{8.8}$$

$$\mathbf{K}_{aug} = [\mathbf{K} \quad 1] \quad \mathbf{r}_{aug} = \begin{bmatrix} \mathbf{r} \\ 0 \end{bmatrix}\tag{8.9}$$

This will compensate for unmodeled dynamics such as projectiles slowing down the flywheel.

**8.2.3 Simulation**

Python Control will be used to **discretize** the **model** and simulate it. One of the `frcontrol` examples<sup>4</sup> creates and tests a controller for it. Figure 8.2 shows the closed-loop **system** response.

Notice how the **control effort** when the **reference** is reached is nonzero. This is a plant inversion feedforward compensating for the **system** dynamics attempting to slow the flywheel down when no voltage is applied.

**8.2.4 Implementation**

C++ and Java implementations of this flywheel controller are available online<sup>5 6</sup>.

**8.2.5 Flywheel model without encoder**

In the FIRST Robotics Competition, we can get the current drawn for specific channels on the power distribution panel. We can theoretically use this to estimate the angular velocity of a DC motor without an encoder. We'll start with the flywheel model derived earlier as equation (13.18).

$$\dot{\omega} = \frac{G K_t}{R J} V - \frac{G^2 K_t}{K_v R J} \omega$$

<sup>4</sup><https://github.com/calcmogul/frcontrol/blob/master/examples/flywheel.py>

<sup>5</sup><https://github.com/wpilibsuite/allwpilib/blob/master/wpilibcExamples/src/main/cpp/examples/StateSpaceFlywheel/cpp/Robot.cpp>

<sup>6</sup><https://github.com/wpilibsuite/allwpilib/blob/master/wpilibjExamples/src/main/java/edu/wpi/first/wpilibj/examples/statepaceflywheel/Robot.java>




Figure 8.2: Flywheel response

$$\dot{\omega} = -\frac{G^2 K_t}{K_v R J} \omega + \frac{G K_t}{R J} V$$

Next, we'll derive the current  $I$  as an output.

$$\begin{aligned} V &= IR + \frac{\omega}{K_v} \\ IR &= V - \frac{\omega}{K_v} \\ I &= -\frac{1}{K_v R} \omega + \frac{1}{R} V \end{aligned}$$

Therefore,

**Theorem 8.2.2 — Flywheel state-space model without encoder.**

$$\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u}$$

$$\mathbf{y} = \mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u}$$

$$\mathbf{x} = \omega \quad \mathbf{y} = I \quad \mathbf{u} = V$$

$$\mathbf{A} = -\frac{G^2 K_t}{K_v R J} \quad \mathbf{B} = \frac{G K_t}{R J} \quad \mathbf{C} = -\frac{1}{K_v R} \quad \mathbf{D} = \frac{1}{R} \quad (8.10)$$

Notice that in this model, the output doesn't provide any direct measurements of the state. To estimate the full state (also known as full observability), we only need the outputs to collectively include linear combinations of every state<sup>7</sup>. We'll revisit this in chapter 9 with an example that uses range measurements to estimate an object's orientation.

<sup>7</sup>While the flywheel model's outputs are a linear combination of both the states and inputs, inputs don't provide new information about the states. Therefore, they don't affect whether the system is observable.

The effectiveness of this model's observer is heavily dependent on the quality of the current sensor used. If the sensor's noise isn't zero-mean, the observer won't converge to the true state.

### 8.2.6 Voltage compensation

To improve controller tracking, one may want to use the voltage renormalized to the power rail voltage to compensate for voltage drop when current spikes occur. This can be done as follows.

$$V = V_{cmd} \frac{V_{nominal}}{V_{rail}} \quad (8.11)$$

where  $V$  is the controller's new input voltage,  $V_{cmd}$  is the old input voltage,  $V_{nominal}$  is the rail voltage when effects like voltage drop due to current draw are ignored, and  $V_{rail}$  is the real rail voltage.

To drive the model with a more accurate voltage that includes voltage drop, the reciprocal can be used.

$$V = V_{cmd} \frac{V_{rail}}{V_{nominal}} \quad (8.12)$$

where  $V$  is the model's new input voltage. Note that if both the controller compensation and model compensation equations are applied, the original voltage is obtained. The model input only drops from ideal if the compensated controller voltage saturates.

## 8.3 Single-jointed arm

### 8.3.1 Continuous state-space model

The angle and angular rate derivatives of the arm can be written as

$$\dot{\theta}_{arm} = \omega_{arm} \quad (8.13)$$

$$\dot{\omega}_{arm} = \dot{\omega}_{arm} \quad (8.14)$$

By equation (13.22)

$$\dot{\omega}_{arm} = -\frac{G^2 K_t}{K_v R J} \omega_{arm} + \frac{G K_t}{R J} V$$

Factor out  $\omega_{arm}$  and  $V$  into column vectors.

$$\begin{bmatrix} \dot{\omega}_{arm} \end{bmatrix} = \begin{bmatrix} -\frac{G^2 K_t}{K_v R J} \end{bmatrix} \begin{bmatrix} \omega_{arm} \end{bmatrix} + \begin{bmatrix} \frac{G K_t}{R J} \end{bmatrix} \begin{bmatrix} V \end{bmatrix}$$

Augment the matrix equation with the angle state  $\theta_{arm}$ , which has the model equation  $\dot{\theta}_{arm} = \omega_{arm}$ . The matrix elements corresponding to  $\omega_{arm}$  will be 1, and the others will be 0 since they don't appear, so  $\dot{\theta}_{arm} = 0\theta_{arm} + 1\omega_{arm} + 0V$ . The existing rows will have zeroes inserted where  $\theta_{arm}$  is multiplied in.

$$\begin{bmatrix} \dot{\theta}_{arm} \\ \dot{\omega}_{arm} \end{bmatrix} = \begin{bmatrix} 0 & 1 \\ 0 & -\frac{G^2 K_t}{K_v R J} \end{bmatrix} \begin{bmatrix} \theta_{arm} \\ \omega_{arm} \end{bmatrix} + \begin{bmatrix} 0 \\ \frac{G K_t}{R J} \end{bmatrix} \begin{bmatrix} V \end{bmatrix}$$



**Theorem 8.3.1 — Single-jointed arm state-space model.**

$$\begin{aligned}\dot{\mathbf{x}} &= \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u} \\ \mathbf{y} &= \mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u} \\ \mathbf{x} &= \begin{bmatrix} \theta_{arm} \\ \omega_{arm} \end{bmatrix} \quad \mathbf{y} = \theta_{arm} \quad \mathbf{u} = V \\ \mathbf{A} &= \begin{bmatrix} 0 & 1 \\ 0 & -\frac{G^2 K_t}{K_v R J} \end{bmatrix} \quad \mathbf{B} = \begin{bmatrix} 0 \\ \frac{G K_t}{R J} \end{bmatrix} \quad \mathbf{C} = [1 \quad 0] \quad \mathbf{D} = 0\end{aligned}\quad (8.15)$$

**8.3.2 Model augmentation**

As per subsection 5.12.2, we will now augment the **model** so a  $u_{error}$  state is added to the **control** input.

The **plant** and **observer** augmentations should be performed before the **model** is **discretized**. After the **controller** gain is computed with the unaugmented discrete **model**, the controller may be augmented. Therefore, the **plant** and **observer** augmentations assume a continuous **model** and the **controller** augmentation assumes a discrete **controller**.

$$\begin{aligned}\mathbf{x}_{aug} &= \begin{bmatrix} \mathbf{x} \\ u_{error} \end{bmatrix} \quad \mathbf{y} = \theta_{arm} \quad \mathbf{u} = V \\ \mathbf{A}_{aug} &= \begin{bmatrix} \mathbf{A} & \mathbf{B} \\ \mathbf{0}_{1 \times 2} & 0 \end{bmatrix} \quad \mathbf{B}_{aug} = \begin{bmatrix} \mathbf{B} \\ 0 \end{bmatrix} \quad \mathbf{C}_{aug} = [\mathbf{C} \quad 0] \quad \mathbf{D}_{aug} = \mathbf{D}\end{aligned}\quad (8.16)$$

$$\mathbf{K}_{aug} = [\mathbf{K} \quad 1] \quad \mathbf{r}_{aug} = \begin{bmatrix} \mathbf{r} \\ 0 \end{bmatrix}\quad (8.17)$$

This will compensate for unmodeled dynamics such as gravity or other external loading from lifted objects. However, if only gravity compensation is desired, a feedforward of the form  $u_{ff} = V_{gravity} \cos \theta$  is preferred where  $V_{gravity}$  is the voltage required to hold the arm level with the ground and  $\theta$  is the angle of the arm with the ground.

**8.3.3 Gravity feedforward**

Input voltage is proportional to torque and gravity is a constant force, but the torque applied against the motor varies according to the arm's angle. We'll use sum of torques to find a compensating torque.

We'll model gravity as a disturbance described by  $-mg$  where  $m$  is the arm's mass. To compensate for it, we want to find a torque that is equal and opposite to the torque applied to the arm by gravity. The bottom row of the continuous elevator model contains the angular acceleration terms, so  $Bu_{ff}$  is angular acceleration caused by the motor;  $JBu_{ff}$  is the torque.

$$\begin{aligned}JBu_{ff} &= -(\mathbf{r} \times \mathbf{F}) \\ JBu_{ff} &= -(rF \cos \theta)\end{aligned}$$

Torque is usually written as  $rF \sin \theta$  where  $\theta$  is the angle between the  $\mathbf{r}$  and  $\mathbf{F}$  vectors, but  $\theta$  in this case is being measured from the horizontal axis rather than the vertical one, so the force vector is  $\frac{\pi}{4}$  radians out of phase. Thus, an angle of 0 results in the maximum torque from gravity being applied rather than the minimum.




Figure 8.3: Single-jointed arm response

The force of gravity  $mg$  is applied at the center of the arm's mass. For a uniform beam, this is halfway down its length, or  $\frac{L}{2}$  where  $L$  is the length of the arm.

$$JBu_{ff} = - \left( \left( \frac{L}{2} \right) (-mg) \cos \theta \right)$$

$$JBu_{ff} = mg \frac{L}{2} \cos \theta$$

$B = \frac{GK_t}{RJ}$ , so

$$J \frac{GK_t}{RJ} u_{ff} = mg \frac{L}{2} \cos \theta$$

$$u_{ff} = \frac{RJ}{JGK_t} mg \frac{L}{2} \cos \theta$$

$$u_{ff} = \frac{L Rmg}{2 GK_t} \cos \theta$$

$\frac{L}{2}$  can be adjusted according to the location of the arm's center of mass.

### 8.3.4 Simulation

Python Control will be used to [discretize](#) the [model](#) and simulate it. One of the [frcontrol](#) examples<sup>8</sup> creates and tests a controller for it. Figure 8.3 shows the closed-loop [system](#) response.

### 8.3.5 Implementation

C++ and Java implementations of this single-jointed arm controller are available online<sup>9 10</sup>.

<sup>8</sup>[https://github.com/calcmogul/frcontrol/blob/master/examples/single\\_jointed\\_arm.py](https://github.com/calcmogul/frcontrol/blob/master/examples/single_jointed_arm.py)

<sup>9</sup><https://github.com/wpilibsuite/allwpilib/blob/master/wpilibcExamples/src/main/cpp/examples/StateSpaceArm/cpp/Robot.cpp>

<sup>10</sup><https://github.com/wpilibsuite/allwpilib/blob/master/wpilibjExamples/src/main/java/edu/wpi/first/wpilibj/examples/statepacearm/Robot.java>

## 8.4 Pendulum

### 8.4.1 State-space model

Below is the **model** for a pendulum

$$\ddot{\theta} = -\frac{g}{l} \sin \theta$$

where  $\theta$  is the angle of the pendulum and  $l$  is the length of the pendulum.

Since state-space representation requires that only single derivatives be used, they should be broken up as separate **states**. We'll reassign  $\dot{\theta}$  to be  $\omega$  so the derivatives are easier to keep straight for state-space representation.

$$\dot{\omega} = -\frac{g}{l} \sin \theta$$

Now separate the **states**.

$$\begin{aligned}\dot{\theta} &= \omega \\ \dot{\omega} &= -\frac{g}{l} \sin \theta\end{aligned}$$

This makes our state vector  $[\theta \ \omega]^T$  and our nonlinear model

$$f(\mathbf{x}, \mathbf{u}) = \begin{bmatrix} \omega \\ -\frac{g}{l} \sin \theta \end{bmatrix}$$

#### Linearization around $\theta = 0$

To apply our tools for linear control theory, the **model** must be a linear combination of the **states** and **inputs** (addition and multiplication by constants). Since this **model** is nonlinear on account of the sine function, we should **linearize** it.

Linearization finds a tangent line to the nonlinear dynamics at a desired point in the state-space. The Taylor series is a way to approximate arbitrary functions with polynomials, so we can use it for linearization.

The Taylor series expansion for  $\sin \theta$  around  $\theta = 0$  is  $\theta - \frac{1}{6}\theta^3 + \frac{1}{120}\theta^5 - \dots$ . We'll take just the first-order term  $\theta$  to obtain a linear function.

$$\begin{aligned}\dot{\theta} &= \omega \\ \dot{\omega} &= -\frac{g}{l}\theta\end{aligned}$$

Now write the **model** in state-space representation. We'll write out the system of equations with the zeroed variables included to assist with this.

$$\begin{aligned}\dot{\theta} &= 0\theta + 1\omega \\ \dot{\omega} &= -\frac{g}{l}\theta + 0\omega\end{aligned}$$

Factor out  $\theta$  and  $\omega$  into a column vector.

$$\begin{bmatrix} \dot{\theta} \\ \dot{\omega} \end{bmatrix} = \begin{bmatrix} 0 & 1 \\ -\frac{g}{l} & 0 \end{bmatrix} \begin{bmatrix} \theta \\ \omega \end{bmatrix} \quad (8.18)$$

### Linearization with the Jacobian

Here's the original nonlinear model in state-space representation.

$$f(\mathbf{x}, \mathbf{u}) = \begin{bmatrix} \omega \\ -\frac{g}{l} \sin \theta \end{bmatrix}$$

If we want to linearize around an arbitrary point, we can take the Jacobian with respect to  $\mathbf{x}$ .

$$\frac{\partial f(\mathbf{x}, \mathbf{u})}{\partial \mathbf{x}} = \begin{bmatrix} 0 & 1 \\ -\frac{g}{l} \cos \theta & 0 \end{bmatrix}$$

For full **state** feedback, knowledge of all **states** is required. If not all **states** are measured directly, an estimator can be used to supplement them.

We may only be measuring  $\theta$  in the pendulum example, not  $\dot{\theta}$ , so we'll need to estimate the latter. The **C** matrix the **observer** would use in this case is

$$\mathbf{C} = [1 \quad 0]$$

Therefore, the measurement vector is

$$\begin{aligned} \mathbf{y} &= \mathbf{C}\mathbf{x} \\ \mathbf{y} &= [1 \quad 0] \begin{bmatrix} \theta \\ \omega \end{bmatrix} \\ \mathbf{y} &= 1\theta + 0\omega \\ \mathbf{y} &= \theta \end{aligned}$$

#### Theorem 8.4.1 — Linear time-varying pendulum state-space model with no input.

$$\begin{aligned} \dot{\mathbf{x}} &= \mathbf{A}\mathbf{x} \\ \mathbf{y} &= \mathbf{C}\mathbf{x} \\ \mathbf{x} &= \begin{bmatrix} \theta \\ \omega \end{bmatrix} \quad \mathbf{y} = \theta \\ \mathbf{A} &= \begin{bmatrix} 0 & 1 \\ -\frac{g}{l} \cos \theta & 0 \end{bmatrix} \quad \mathbf{C} = [1 \quad 0] \end{aligned} \tag{8.19}$$

## 8.5 Holonomic drivetrains

### 8.5.1 Model

Holonomic drivetrains have three degrees of freedom:  $x$ ,  $y$ , and heading. They are described by the following kinematics.

$$\begin{bmatrix} \dot{x} \\ \dot{y} \\ \dot{\theta} \end{bmatrix} = \begin{bmatrix} \cos \theta & -\sin \theta & 0 \\ \sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} v_{x,chassis} \\ v_{y,chassis} \\ \omega_{chassis} \end{bmatrix}$$

where  $v_{x,chassis}$  is the velocity ahead in the chassis frame,  $v_{y,chassis}$  is the velocity to the left in the chassis frame, and  $\omega_{chassis}$  is the angular velocity in the chassis frame. This can be written in state-space notation as

$$\begin{bmatrix} \dot{x} \\ \dot{y} \\ \dot{\theta} \end{bmatrix} = \begin{bmatrix} 0 & 0 & 0 \\ 0 & 0 & 0 \\ 0 & 0 & 0 \end{bmatrix} \begin{bmatrix} x \\ y \\ \theta \end{bmatrix} + \begin{bmatrix} \cos \theta & -\sin \theta & 0 \\ \sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} v_{x,chassis} \\ v_{y,chassis} \\ \omega_{chassis} \end{bmatrix}$$

### 8.5.2 Control

This control-affine model is fully actuated but nonlinear in the chassis frame. However, we can apply linear control theory to the error dynamics in the global frame instead. Note how equation (8.20)'s state vector contains the global pose and its input vector contains the global linear and angular velocities.

$$\begin{bmatrix} \dot{x} \\ \dot{y} \\ \dot{\theta} \end{bmatrix} = \begin{bmatrix} 0 & 0 & 0 \\ 0 & 0 & 0 \\ 0 & 0 & 0 \end{bmatrix} \begin{bmatrix} x \\ y \\ \theta \end{bmatrix} + \begin{bmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} v_{x,global} \\ v_{y,global} \\ \omega_{global} \end{bmatrix} \quad (8.20)$$

$$\text{where } \begin{bmatrix} v_{x,global} \\ v_{y,global} \\ \omega_{global} \end{bmatrix} = \begin{bmatrix} \cos \theta & -\sin \theta & 0 \\ \sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} v_{x,chassis} \\ v_{y,chassis} \\ \omega_{chassis} \end{bmatrix} \quad (8.21)$$

We can control the model in equation (8.20) with an LQR, which will have three independent proportional controllers. Then, we can convert the global velocity commands to chassis velocity commands with equation (8.21) and convert the chassis velocity commands to wheel speed commands with inverse kinematics. LQRs on each wheel can track the wheel speed commands.

Note that the full control law is nonlinear because the kinematics contain a rotation matrix for transforming from the chassis frame to the global frame. However, the nonlinear part has been abstracted away from the tunable linear control laws.

### 8.5.3 Holonomic vs nonholonomic control

Drivetrains that are unable to exercise all possible degrees of freedom (e.g., moving sideways with respect to the chassis) are nonholonomic. An LQR on each degree of freedom is ideal for holonomic drivetrains, but not for nonholonomic. Section 8.6 will use the differential drive as a motivating example for various nonholonomic controllers.

**R** Nonholonomic controllers should not be used for holonomic drivetrains. They make different assumptions about the drivetrain dynamics that yield suboptimal results compared to holonomic controllers.

## 8.6 Differential drive

### 8.6.1 Velocity subspace state-space model

By equations (13.34) and (13.35)

$$\begin{aligned} \dot{v}_l &= \left( \frac{1}{m} + \frac{r_b^2}{J} \right) (C_1 v_l + C_2 V_l) + \left( \frac{1}{m} - \frac{r_b^2}{J} \right) (C_3 v_r + C_4 V_r) \\ \dot{v}_r &= \left( \frac{1}{m} - \frac{r_b^2}{J} \right) (C_1 v_l + C_2 V_l) + \left( \frac{1}{m} + \frac{r_b^2}{J} \right) (C_3 v_r + C_4 V_r) \end{aligned}$$

Regroup the terms into states  $v_l$  and  $v_r$  and inputs  $V_l$  and  $V_r$ .

$$\dot{v}_l = \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_1 v_l + \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_2 V_l + \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_3 v_r + \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_4 V_r$$

$$\dot{v}_r = \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_1 v_l + \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_2 V_l + \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_3 v_r + \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_4 V_r$$

$$\dot{v}_l = \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_1 v_l + \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_3 v_r + \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_2 V_l + \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_4 V_r$$

$$\dot{v}_r = \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_1 v_l + \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_3 v_r + \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_2 V_l + \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_4 V_r$$

Factor out  $v_l$  and  $v_r$  into a column vector and  $V_l$  and  $V_r$  into a column vector.

$$\begin{bmatrix} \dot{v}_l \\ \dot{v}_r \end{bmatrix} = \begin{bmatrix} \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_3 \\ \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_3 \end{bmatrix} \begin{bmatrix} v_l \\ v_r \end{bmatrix} + \begin{bmatrix} \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_2 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_4 \\ \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_2 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_4 \end{bmatrix} \begin{bmatrix} V_l \\ V_r \end{bmatrix}$$

#### Theorem 8.6.1 — Differential drive velocity state-space model.

$$\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u}$$

$$\mathbf{y} = \mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u}$$

$$\mathbf{x} = \begin{bmatrix} v_l \\ v_r \end{bmatrix} \quad \mathbf{y} = \begin{bmatrix} v_l \\ v_r \end{bmatrix} \quad \mathbf{u} = \begin{bmatrix} V_l \\ V_r \end{bmatrix}$$

$$\mathbf{A} = \begin{bmatrix} \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_3 \\ \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_3 \end{bmatrix} \quad \mathbf{B} = \begin{bmatrix} \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_2 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_4 \\ \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_2 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_4 \end{bmatrix} \quad (8.22)$$

$$\mathbf{C} = \begin{bmatrix} 1 & 0 \\ 0 & 1 \end{bmatrix} \quad \mathbf{D} = \mathbf{0}_{2 \times 2}$$

where  $C_1 = -\frac{G_l^2 K_t}{K_v R r^2}$ ,  $C_2 = \frac{G_l K_t}{R r}$ ,  $C_3 = -\frac{G_r^2 K_t}{K_v R r^2}$ , and  $C_4 = \frac{G_r K_t}{R r}$ .

#### Simulation

Python Control will be used to discretize the model and simulate it. One of the frcontrol examples<sup>11</sup> creates and tests a controller for it. Figure 8.4 shows the closed-loop system response.

Given the high inertia in drivetrains, it's better to drive the reference with a motion profile instead of a step input for reproducibility.

### 8.6.2 Linear time-varying model

The model in theorem 8.6.1 is linear, but only includes the velocity dynamics, not the dynamics of the drivetrain's global pose. The change in global pose is defined by these three equations.

$$\dot{x} = \frac{v_l + v_r}{2} \cos \theta = \frac{v_r}{2} \cos \theta + \frac{v_l}{2} \cos \theta$$

<sup>11</sup>[https://github.com/calcmogul/frcontrol/blob/master/examples/differential\\_drive.py](https://github.com/calcmogul/frcontrol/blob/master/examples/differential_drive.py)






Figure 8.4: Drivetrain response

$$\dot{y} = \frac{v_l + v_r}{2} \sin \theta = \frac{v_r}{2} \sin \theta + \frac{v_l}{2} \sin \theta$$

$$\dot{\theta} = \frac{v_r - v_l}{2r_b} = \frac{v_r}{2r_b} - \frac{v_l}{2r_b}$$

Next, we'll augment the linear subspace's state with the global pose  $x$ ,  $y$ , and  $\theta$ . Here's the model as a vector function where  $\mathbf{x} = [x \ y \ \theta \ v_l \ v_r]^T$  and  $\mathbf{u} = [V_l \ V_r]^T$ .

$$f(\mathbf{x}, \mathbf{u}) = \begin{bmatrix} \frac{v_r}{2} \cos \theta + \frac{v_l}{2} \cos \theta \\ \frac{v_r}{2} \sin \theta + \frac{v_l}{2} \sin \theta \\ \frac{v_r}{2r_b} - \frac{v_l}{2r_b} \\ \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_1 v_l + \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_3 v_r + \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_2 V_l + \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_4 V_r \\ \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_1 v_l + \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_3 v_r + \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_2 V_l + \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_4 V_r \end{bmatrix} \quad (8.23)$$

As mentioned in chapter 7, one can approximate a nonlinear system via linearizations around points of interest in the state-space and design controllers for those linearized subspaces. If we sample linearization points progressively closer together, we converge on a control policy for the original nonlinear system. Since the linear plant being controlled varies with time, its controller is called a linear time-varying (LTV) controller.

If we use LQRs for the linearized subspaces, the nonlinear control policy will also be locally optimal. We'll be taking this approach with a differential drive. To create an LQR, we need to linearize equation (8.23).

$$\frac{\partial f(\mathbf{x}, \mathbf{u})}{\partial \mathbf{x}} = \begin{bmatrix} 0 & 0 & -\frac{v_l + v_r}{2} \sin \theta & \frac{1}{2} \cos \theta & \frac{1}{2} \cos \theta \\ 0 & 0 & \frac{v_l + v_r}{2} \cos \theta & \frac{1}{2} \sin \theta & \frac{1}{2} \sin \theta \\ 0 & 0 & 0 & -\frac{1}{2r_b} & \frac{1}{2r_b} \\ 0 & 0 & 0 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_3 \\ 0 & 0 & 0 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_3 \end{bmatrix}$$

$$\frac{\partial f(\mathbf{x}, \mathbf{u})}{\partial \mathbf{u}} = \begin{bmatrix} 0 & 0 \\ 0 & 0 \\ 0 & 0 \\ \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_2 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_4 \\ \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_2 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_4 \end{bmatrix}$$

Therefore,

**Theorem 8.6.2 — Linear time-varying differential drive state-space model.**

$$\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u}$$

$$\mathbf{y} = \mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u}$$

$$\mathbf{x} = [x \ y \ \theta \ v_l \ v_r]^T \quad \mathbf{y} = [\theta \ v_l \ v_r]^T \quad \mathbf{u} = [V_l \ V_r]^T$$

$$\mathbf{A} = \begin{bmatrix} 0 & 0 & -vs & \frac{1}{2}c & \frac{1}{2}c \\ 0 & 0 & vc & \frac{1}{2}s & \frac{1}{2}s \\ 0 & 0 & 0 & -\frac{1}{2r_b} & \frac{1}{2r_b} \\ 0 & 0 & 0 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_3 \\ 0 & 0 & 0 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_3 \end{bmatrix} \quad \mathbf{B} = \begin{bmatrix} 0 & 0 \\ 0 & 0 \\ 0 & 0 \\ \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_2 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_4 \\ \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_2 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_4 \end{bmatrix}$$

$$\mathbf{C} = \begin{bmatrix} 0 & 0 & 1 & 0 & 0 \\ 0 & 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 0 & 1 \end{bmatrix} \quad \mathbf{D} = \mathbf{0}_{3 \times 2}$$

(8.24)

where  $v = \frac{v_l + v_r}{2}$ ,  $c = \cos \theta$ ,  $s = \sin \theta$ ,  $C_1 = -\frac{G_l^2 K_t}{K_v R r^2}$ ,  $C_2 = \frac{G_l K_t}{R r}$ ,  $C_3 = -\frac{G_r^2 K_t}{K_v R r^2}$ , and  $C_4 = \frac{G_r K_t}{R r}$ . The constants  $C_1$  through  $C_4$  are from the derivation in section 13.6.

We can also use this in an extended Kalman filter as is since the measurement model ( $\mathbf{y} = \mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u}$ ) is linear.

### 8.6.3 Improving model accuracy

Figures 8.5 and 8.6 demonstrate the tracking behavior of the linearized differential drive controller.

The linearized differential drive model doesn't track well because the first-order linearization of  $\mathbf{A}$  doesn't capture the full heading dynamics, making the **model** update inaccurate. This linearization inaccuracy is evident in the Hessian matrix (second partial derivative with respect to the state vector) being nonzero.

$$\frac{\partial^2 f(\mathbf{x}, \mathbf{u})}{\partial \mathbf{x}^2} = \begin{bmatrix} 0 & 0 & -\frac{v_l + v_r}{2} \cos \theta & 0 & 0 \\ 0 & 0 & -\frac{v_l + v_r}{2} \sin \theta & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0 \end{bmatrix}$$

The second-order Taylor series expansion of the **model** around  $\mathbf{x}_0$  would be

$$f(\mathbf{x}, \mathbf{u}_0) \approx f(\mathbf{x}_0, \mathbf{u}_0) + \frac{\partial f(\mathbf{x}, \mathbf{u})}{\partial \mathbf{x}}(\mathbf{x} - \mathbf{x}_0) + \frac{1}{2} \frac{\partial^2 f(\mathbf{x}, \mathbf{u})}{\partial \mathbf{x}^2}(\mathbf{x} - \mathbf{x}_0)^2$$




Figure 8.5: Linear time-varying differential drive controller x-y plot (first-order)




Figure 8.6: Linear time-varying differential drive controller response (first-order)

To include higher-order dynamics in the linearized differential drive model integration, we recommend using the fourth-order Runge-Kutta (RK4) integration method on equation (8.23).

**Theorem 8.6.3 — Fourth-order Runge-Kutta integration.** Given the differential equation  $\dot{\mathbf{x}} = f(\mathbf{x}_k, \mathbf{u}_k)$ , this method solves for  $\mathbf{x}_{k+1}$  at  $dt$  seconds in the future.  $\mathbf{u}$  is assumed to be held constant between timesteps.

$$\begin{aligned} \mathbf{k}_1 &= f(\mathbf{x}_k, \mathbf{u}_k) \\ \mathbf{k}_2 &= f\left(\mathbf{x}_k + \frac{1}{2}dt\mathbf{k}_1, \mathbf{u}_k\right) \\ \mathbf{k}_3 &= f\left(\mathbf{x}_k + \frac{1}{2}dt\mathbf{k}_2, \mathbf{u}_k\right) \\ \mathbf{k}_4 &= f\left(\mathbf{x}_k + dt\mathbf{k}_3, \mathbf{u}_k\right) \\ \mathbf{x}_{k+1} &= \mathbf{x}_k + \frac{1}{6}dt(\mathbf{k}_1 + 2\mathbf{k}_2 + 2\mathbf{k}_3 + \mathbf{k}_4) \end{aligned}$$

0				
$\frac{1}{2}$	$\frac{1}{2}$			
$\frac{1}{2}$	0	$\frac{1}{2}$		
1	0	0	1	
	$\frac{1}{6}$	$\frac{1}{3}$	$\frac{1}{3}$	$\frac{1}{6}$

The Butcher tableau on the right is a more succinct representation of the equations on the left. Each row in the tableau corresponds to one of the equations, and each column in the right half corresponds to a  $\mathbf{k}$  coefficient from  $\mathbf{k}_1$  to  $\mathbf{k}_4$ .

The top-left quadrant contains the sums of each row in the top-right quadrant. These sums are the  $\mathbf{k}$  coefficients in the first argument of  $f(\mathbf{x}, \mathbf{u})$ . The bottom row contains the  $\mathbf{k}$  coefficients for the  $\mathbf{x}_{k+1}$  equation.

Other methods of Runge-Kutta integration exist with various properties [14], but the one presented here is popular for its high accuracy relative to the amount of floating point operations (FLOPs) it requires.

Figures 8.7 and 8.8 show a simulation using RK4 instead of the first-order model.

### 8.6.4 Cross track error controller

Figures 8.7 and 8.8 show the tracking performance of the linearized differential drive controller for a given trajectory. The performance-effort trade-off can be tuned rather intuitively via the Q and R gains. However, if the  $x$  and  $y$  error cost are too high, the  $x$  and  $y$  components of the controller




Figure 8.7: Linear time-varying differential drive controller (global reference frame formulation) x-y plot




Figure 8.8: Linear time-varying differential drive controller (global reference frame formulation) response

will fight each other, and it will take longer to converge to the path. This can be fixed by applying a clockwise rotation matrix to the global tracking error to transform it into the robot's coordinate frame.

$${}^R \begin{bmatrix} e_x \\ e_y \\ e_\theta \end{bmatrix} = \begin{bmatrix} \cos \theta & \sin \theta & 0 \\ -\sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} {}^G \begin{bmatrix} e_x \\ e_y \\ e_\theta \end{bmatrix}$$

where the the superscript  $R$  represents the robot's coordinate frame and the superscript  $G$  represents the global coordinate frame.

With this transformation, the  $x$  and  $y$  error cost in LQR penalize the error ahead of the robot and cross-track error respectively instead of global pose error. Since the cross-track error is always measured from the robot's coordinate frame, the `model` used to compute the LQR should be linearized around  $\theta = 0$  at all times.

$$\mathbf{A} = \begin{bmatrix} 0 & 0 & -\frac{v_l+v_r}{2} \sin 0 & \frac{1}{2} \cos 0 & \frac{1}{2} \cos 0 \\ 0 & 0 & \frac{v_l+v_r}{2} \cos 0 & \frac{1}{2} \sin 0 & \frac{1}{2} \sin 0 \\ 0 & 0 & 0 & -\frac{1}{2r_b} & \frac{1}{2r_{b2}} \\ 0 & 0 & 0 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_3 \\ 0 & 0 & 0 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_3 \end{bmatrix}$$

$$\mathbf{A} = \begin{bmatrix} 0 & 0 & 0 & \frac{1}{2} & \frac{1}{2} \\ 0 & 0 & \frac{v_l+v_r}{2} & 0 & 0 \\ 0 & 0 & 0 & -\frac{1}{2r_b} & \frac{1}{2r_{b2}} \\ 0 & 0 & 0 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_3 \\ 0 & 0 & 0 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_3 \end{bmatrix}$$

**Theorem 8.6.4 — Linear time-varying differential drive controller.**

$$\mathbf{x} = [x \ y \ \theta \ v_l \ v_r]^T \quad \mathbf{y} = [\theta \ v_l \ v_r]^T \quad \mathbf{u} = [V_l \ V_r]^T$$

The following  $\mathbf{A}$  and  $\mathbf{B}$  matrices of a continuous system are used to compute the LQR.

$$\mathbf{A} = \begin{bmatrix} 0 & 0 & 0 & \frac{1}{2} & \frac{1}{2} \\ 0 & 0 & \frac{v_l+v_r}{2} & 0 & 0 \\ 0 & 0 & 0 & -\frac{1}{2r_b} & \frac{1}{2r_b} \\ 0 & 0 & 0 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_3 \\ 0 & 0 & 0 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_3 \end{bmatrix} \quad \mathbf{B} = \begin{bmatrix} 0 & 0 \\ 0 & 0 \\ 0 & 0 \\ \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_2 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_4 \\ \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_2 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_4 \end{bmatrix} \quad (8.25)$$

where  $v = \frac{v_l+v_r}{2}$ ,  $C_1 = -\frac{G_l^2 K_t}{K_v R r^2}$ ,  $C_2 = \frac{G_l K_t}{R r}$ ,  $C_3 = -\frac{G_r^2 K_t}{K_v R r^2}$ , and  $C_4 = \frac{G_r K_t}{R r}$ . The constants  $C_1$  through  $C_4$  are from the derivation in section 13.6.

$$\mathbf{u} = \mathbf{K} \begin{bmatrix} \cos \theta & \sin \theta & \mathbf{0}_{2 \times 3} \\ -\sin \theta & \cos \theta & \mathbf{0}_{3 \times 2} \\ \mathbf{0}_{3 \times 2} & \mathbf{I}_{3 \times 3} \end{bmatrix} (\mathbf{r} - \mathbf{x}) \quad (8.26)$$

The controller gain  $\mathbf{K}$  from LQR should be recomputed from the model linearized around the current state during every timestep.

With the model in theorem 8.6.4,  $y$  is uncontrollable at  $v = 0$  because nonholonomic drivetrains are unable to move sideways. Some DARE solvers throw errors in this case, but one can avoid it by linearizing the model around a slightly nonzero velocity instead.

The controller in theorem 8.6.4 results in figures 8.9 and 8.10, which show slightly better tracking performance than the previous formulation.




Figure 8.9: Linear time-varying differential drive controller x-y plot




Figure 8.10: Linear time-varying differential drive controller response

### 8.6.5 Nonlinear observer design

#### Encoder position augmentation

Estimation of the global pose can be significantly improved if encoder position measurements are used instead of velocity measurements. By augmenting the plant with the line integral of each wheel's velocity over time, we can provide a mapping from model states to position measurements. We can augment the linear subspace of the model as follows.

Augment the matrix equation with position states  $x_l$  and  $x_r$ , which have the model equations  $\dot{x}_l = v_l$  and  $\dot{x}_r = v_r$ . The matrix elements corresponding to  $v_l$  in the first equation and  $v_r$  in the second equation will be 1, and the others will be 0 since they don't appear, so  $\dot{x}_l = 1v_l + 0v_r + 0x_l + 0x_r + 0V_l + 0V_r$  and  $\dot{x}_r = 0v_l + 1v_r + 0x_l + 0x_r + 0V_l + 0V_r$ . The existing rows will have zeroes inserted where  $x_l$  and  $x_r$  are multiplied in.

$$\begin{bmatrix} \dot{x}_l \\ \dot{x}_r \end{bmatrix} = \begin{bmatrix} 1 & 0 \\ 0 & 1 \end{bmatrix} \begin{bmatrix} v_l \\ v_r \end{bmatrix} + \begin{bmatrix} 0 & 0 \\ 0 & 0 \end{bmatrix} \begin{bmatrix} V_l \\ V_r \end{bmatrix}$$

This produces the following linear subspace over  $\mathbf{x} = [v_l \ v_r \ x_l \ x_r]^T$ .

$$\mathbf{A} = \begin{bmatrix} \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_3 & 0 & 0 \\ \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_3 & 0 & 0 \\ 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \end{bmatrix} \quad \mathbf{B} = \begin{bmatrix} \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_2 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_4 \\ \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_2 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_4 \\ 0 & 0 \\ 0 & 0 \end{bmatrix} \quad (8.27)$$

The measurement model for the complete nonlinear model is now  $\mathbf{y} = [\theta \ x_l \ x_r]^T$  instead of  $\mathbf{y} = [\theta \ v_l \ v_r]^T$ .

#### U error estimation

As per subsection 5.12.2, we will now augment the **model** so  $u_{error}$  states are added to the **control inputs**.

The **plant** and **observer** augmentations should be performed before the **model** is **discretized**. After the **controller** gain is computed with the unaugmented discrete **model**, the controller may be augmented. Therefore, the **plant** and **observer** augmentations assume a continuous **model** and the **controller** augmentation assumes a discrete **controller**.

The three  $u_{error}$  states we'll be adding are  $u_{error,l}$ ,  $u_{error,r}$ , and  $u_{error,heading}$  for left voltage error, right voltage error, and heading error respectively. The left and right wheel positions are filtered encoder positions and are not adjusted for heading error. The turning angle computed from the left and right wheel positions is adjusted by the gyroscope heading. The heading  $u_{error}$  state is the heading error between what the wheel positions imply and the gyroscope measurement.

The full state is thus  $\mathbf{x} = [x \ y \ \theta \ v_l \ v_r \ x_l \ x_r \ u_{error,l} \ u_{error,r} \ u_{error,heading}]^T$ .

The complete nonlinear model is as follows. Let  $v = \frac{v_l + v_r}{2}$ . The three  $u_{error}$  states augment the linear subspace, so the nonlinear pose dynamics are the same.

$$\begin{bmatrix} \dot{x} \\ \dot{y} \\ \dot{\theta} \end{bmatrix} = \begin{bmatrix} v \cos \theta \\ v \sin \theta \\ \frac{v_r}{2r_b} - \frac{v_l}{2r_b} \end{bmatrix} \quad (8.28)$$



The left and right voltage error states should be mapped to the corresponding velocity states, so the system matrix should be augmented with  $\mathbf{B}$ .

The heading  $u_{error}$  is measuring counterclockwise encoder understeer relative to the gyroscope heading, so it should add to the left position and subtract from the right position for clockwise correction of encoder positions. That corresponds to the following input mapping vector.

$$\mathbf{B}_\theta = \begin{bmatrix} 0 \\ 0 \\ 1 \\ -1 \end{bmatrix}$$

Now we'll augment the linear system matrix horizontally to accommodate the  $u_{error}$  states.

$$\begin{bmatrix} \dot{v}_l \\ v_r \\ x_l \\ x_r \end{bmatrix} = [\mathbf{A} \quad \mathbf{B} \quad \mathbf{B}_\theta] \begin{bmatrix} v_l \\ v_r \\ x_l \\ x_r \\ u_{error,l} \\ u_{error,r} \\ u_{error,heading} \end{bmatrix} + \mathbf{B}\mathbf{u} \quad (8.29)$$

$\mathbf{A}$  and  $\mathbf{B}$  are the linear subspace from equation (8.27).

The  $u_{error}$  states have no dynamics. The observer selects them to minimize the difference between the expected and actual measurements.

$$\begin{bmatrix} \dot{u}_{error,l} \\ u_{error,r} \\ u_{error,heading} \end{bmatrix} = \mathbf{0}_{3 \times 1} \quad (8.30)$$

The controller is augmented as follows.

$$\mathbf{K}_{error} = \begin{bmatrix} 1 & 0 & 0 \\ 0 & 1 & 0 \end{bmatrix} \quad \mathbf{K}_{aug} = [\mathbf{K} \quad \mathbf{K}_{error}] \quad \mathbf{r}_{aug} = \begin{bmatrix} \mathbf{r} \\ 0 \\ 0 \\ 0 \end{bmatrix} \quad (8.31)$$

This controller augmentation compensates for unmodeled dynamics like:

1. Understeer caused by wheel friction inherent in skid-steer robots
2. Battery voltage drop under load, which reduces the available control authority

**R** The process noise for the voltage error states should be how much the voltage can be expected to drop. The heading error state should be the encoder [model](#) uncertainty.

## 8.7 Ramsete unicycle controller

Ramsete is a nonlinear time-varying feedback controller for unicycle [models](#) that drives the [model](#) to a desired [pose](#) along a two-dimensional trajectory. Why would we need a nonlinear control law in addition to the linear ones we have used so far? If we use the original approach with an LQR

controller for left and right position and velocity states, the controller only deals with the local pose. If the robot deviates from the path, there is no way for the controller to correct and the robot may not reach the desired global pose. This is due to multiple endpoints existing for the robot which have the same encoder path arc lengths.

Instead of using wheel path arc lengths (which are in the robot's local coordinate frame), nonlinear controllers like pure pursuit and Ramsete use global pose. The controller uses this extra information to guide a linear reference tracker like an LQR controller back in by adjusting the references of the LQR controller.

The paper *Control of Wheeled Mobile Robots: An Experimental Overview* describes a nonlinear controller for a wheeled vehicle with unicycle-like kinematics; a global pose consisting of  $x$ ,  $y$ , and  $\theta$ ; and a desired pose consisting of  $x_d$ ,  $y_d$ , and  $\theta_d$  [26]. We'll call it Ramsete because that's the acronym for the title of the book it came from in Italian ("Robotica Articolata e Mobile per i Servizi e le Tecnologie").

### 8.7.1 Velocity and turning rate command derivation

The state tracking error  $e$  in the vehicle's coordinate frame is defined as

$$\begin{bmatrix} e_x \\ e_y \\ e_\theta \end{bmatrix} = \begin{bmatrix} \cos \theta & \sin \theta & 0 \\ -\sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} x_d - x \\ y_d - y \\ \theta_d - \theta \end{bmatrix}$$

where  $e_x$  is the tracking error in  $x$ ,  $e_y$  is the tracking error in  $y$ , and  $e_\theta$  is the tracking error in  $\theta$ . The  $3 \times 3$  matrix is a rotation matrix that transforms the error in the pose (represented by  $x_d - x$ ,  $y_d - y$ , and  $\theta_d - \theta$ ) from the global coordinate frame into the vehicle's coordinate frame.

We will use the following control laws  $u_1$  and  $u_2$  for velocity and turning rate respectively.

$$\begin{aligned} u_1 &= -k_1 e_x \\ u_2 &= -k_3 e_\theta - k_2 v_d \operatorname{sinc}(e_\theta) e_y \end{aligned} \tag{8.32}$$

where  $k_1$ ,  $k_2$ , and  $k_3$  are time-varying gains and  $\operatorname{sinc}(e_\theta)$  is defined as  $\frac{\sin e_\theta}{e_\theta}$ . This choice of control law may seem arbitrary, and that's because it is. The only requirement on our choice is that there exist an associated Lyapunov candidate function that proves the control law is globally asymptotically stable. We'll provide a sketch of a proof in theorem 8.7.1.

Our velocity and turning rate commands for the vehicle will use the following nonlinear transformation of the inputs.

$$\begin{aligned} v &= v_d \cos e_\theta - u_1 \\ \omega &= \omega_d - u_2 \end{aligned}$$

Substituting the control laws  $u_1$  and  $u_2$  into these equations gives

$$\begin{aligned} v &= v_d \cos e_\theta + k_1 e_x \\ \omega &= k_3 e_\theta + \omega_d + k_2 v_d \operatorname{sinc}(e_\theta) e_y \end{aligned}$$

**Theorem 8.7.1** Assuming that  $v_d$  and  $\omega_d$  are bounded with bounded derivatives, and that  $v_d(t) \rightarrow 0$  or  $\omega_d(t) \rightarrow 0$  when  $t \rightarrow \infty$ , the control laws in equation (8.32) globally asymptotically stabilize the origin  $e = 0$ .

Proof:

To prove convergence, the paper previously mentioned uses the following Lyapunov function.

$$V = \frac{k_2}{2}(e_x^2 + e_y^2) + \frac{e_\theta^2}{2}$$

where  $k_2$  is a tuning constant,  $e_x$  is the tracking error in  $x$ ,  $e_y$  is the tracking error in  $y$ , and  $e_\theta$  is the tracking error in  $\theta$ .

The time derivative along the solutions of the closed-loop system is nonincreasing since

$$\dot{V} = -k_1 k_2 e_x^2 - k_3 e_\theta^2 \leq 0$$

Thus,  $\|e(t)\|$  is bounded,  $\dot{V}(t)$  is uniformly continuous, and  $V(t)$  tends to some limit value. Using the Barbalat lemma,  $\dot{V}(t)$  tends to zero [26].

### 8.7.2 Nonlinear controller equations

Let  $k_2 = b$  and  $k = k_1(v_d, \omega_d) = k_3(v_d, \omega_d) = 2\zeta\sqrt{\omega_d^2 + bv_d^2}$ .

**Theorem 8.7.2 — Ramsete unicycle controller.**

$$\begin{bmatrix} e_x \\ e_y \\ e_\theta \end{bmatrix} = \begin{bmatrix} \cos \theta & \sin \theta & 0 \\ -\sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} x_d - x \\ y_d - y \\ \theta_d - \theta \end{bmatrix} \quad (8.33)$$

$$v = v_d \cos e_\theta + k e_x \quad (8.34)$$

$$\omega = \omega_d + k e_\theta + b v_d \operatorname{sinc}(e_\theta) e_y \quad (8.35)$$

$$k = 2\zeta\sqrt{\omega_d^2 + bv_d^2} \quad (8.36)$$

$$\operatorname{sinc}(e_\theta) = \frac{\sin e_\theta}{e_\theta} \quad (8.37)$$

$v$	velocity command	$v_d$	desired velocity
$\omega$	turning rate command	$\omega_d$	desired turning rate
$x$	actual $x$ position in global coordinate frame	$x_d$	desired $x$ position
$y$	actual $y$ position in global coordinate frame	$y_d$	desired $y$ position
$\theta$	actual angle in global coordinate frame	$\theta_d$	desired angle

$b$  and  $\zeta$  are tuning parameters where  $b > 0$  and  $\zeta \in (0, 1)$ . Larger values of  $b$  make convergence more aggressive (like a proportional term), and larger values of  $\zeta$  provide more damping.

$v$  and  $\omega$  should be the references for a reference tracker for the drivetrain. This can be a linear controller (see subsection 8.7.3).  $x$ ,  $y$ , and  $\theta$  are obtained via a pose estimator (see chapter 10 for

how to implement one). The desired velocity, turning rate, and pose can be varied over time according to a desired trajectory.

Figures 8.11 and 8.12 show the tracking performance of Ramsete for a given trajectory.




Figure 8.11: Ramsete nonlinear controller x-y plot




Figure 8.12: Ramsete nonlinear controller response

### 8.7.3 Linear reference tracker

We need a velocity reference tracker for the nonlinear controller's commands. Starting from equation (8.22), we'll derive two models for this purpose and compare their responses with a straight profile and as part of a nonlinear trajectory follower.

#### Left/right velocity reference tracker

$$\mathbf{x} = \begin{bmatrix} x_l \\ v_l \\ x_r \\ v_r \end{bmatrix} \quad \mathbf{y} = \begin{bmatrix} x_l \\ x_r \end{bmatrix} \quad \mathbf{u} = \begin{bmatrix} V_l \\ V_r \end{bmatrix}$$

$$\mathbf{A} = \begin{bmatrix} 0 & 1 & 0 & 0 \\ 0 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_1 & 0 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_3 \\ 0 & 0 & 0 & 1 \\ 0 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_1 & 0 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_3 \end{bmatrix} \quad \mathbf{B} = \begin{bmatrix} 0 & 0 \\ \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_2 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_4 \\ 0 & 0 \\ \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_2 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_4 \end{bmatrix}$$

$$\mathbf{C} = \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & 0 & 1 & 0 \end{bmatrix} \quad \mathbf{D} = \mathbf{0}_{2 \times 2}$$

where  $C_1 = -\frac{G_l^2 K_t}{K_v R r^2}$ ,  $C_2 = \frac{G_l K_t}{R r}$ ,  $C_3 = -\frac{G_r^2 K_t}{K_v R r^2}$ , and  $C_4 = \frac{G_r K_t}{R r}$ .

To obtain a left/right velocity reference tracker, we can just remove the position states from the model.

**Theorem 8.7.3 — Left/right velocity reference tracker.**

$$\mathbf{x} = \begin{bmatrix} v_l \\ v_r \end{bmatrix} \quad \mathbf{y} = \begin{bmatrix} v_l \\ v_r \end{bmatrix} \quad \mathbf{u} = \begin{bmatrix} V_l \\ V_r \end{bmatrix}$$

$$\mathbf{A} = \begin{bmatrix} \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_3 \\ \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_1 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_3 \end{bmatrix} \quad \mathbf{B} = \begin{bmatrix} \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_2 & \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_4 \\ \left(\frac{1}{m} - \frac{r_b^2}{J}\right) C_2 & \left(\frac{1}{m} + \frac{r_b^2}{J}\right) C_4 \end{bmatrix} \quad (8.38)$$

$$\mathbf{C} = \begin{bmatrix} 1 & 0 \\ 0 & 1 \end{bmatrix} \quad \mathbf{D} = \mathbf{0}_{2 \times 2}$$

where  $C_1 = -\frac{G_l^2 K_t}{K_v R r^2}$ ,  $C_2 = \frac{G_l K_t}{R r}$ ,  $C_3 = -\frac{G_r^2 K_t}{K_v R r^2}$ , and  $C_4 = \frac{G_r K_t}{R r}$ .

See [https://github.com/calcmogul/controls-engineering-in-frc/blob/master/modern-control-theory/ss-applications/ramsete\\_decoupled.py](https://github.com/calcmogul/controls-engineering-in-frc/blob/master/modern-control-theory/ss-applications/ramsete_decoupled.py) for an implementation.

**Linear/angular velocity reference tracker**

Since the Ramsete controller produces velocity and turning rate commands, it would be more convenient if the **states** are velocity and turning rate instead of left and right wheel velocity. We'll create a second model that has velocity and angular velocity states and see how well it performs.

$$\dot{v}_l = \left(\frac{1}{m} + \frac{r_b^2}{J}\right) (C_1 v_l + C_2 V_l) + \left(\frac{1}{m} - \frac{r_b^2}{J}\right) (C_3 v_r + C_4 V_r)$$

$$\dot{v}_r = \left(\frac{1}{m} - \frac{r_b^2}{J}\right) (C_1 v_l + C_2 V_l) + \left(\frac{1}{m} + \frac{r_b^2}{J}\right) (C_3 v_r + C_4 V_r)$$

Substitute in equations (12.1) and (12.2).

$$\dot{v}_c + \dot{\omega} r_b = \left(\frac{1}{m} + \frac{r_b^2}{J}\right) (C_1 (v_c - \omega r_b) + C_2 V_l) + \left(\frac{1}{m} - \frac{r_b^2}{J}\right) (C_3 (v_c + \omega r_b) + C_4 V_r) \quad (8.39)$$

$$\dot{v}_c - \dot{\omega} r_b = \left(\frac{1}{m} - \frac{r_b^2}{J}\right) (C_1 (v_c - \omega r_b) + C_2 V_l) + \left(\frac{1}{m} + \frac{r_b^2}{J}\right) (C_3 (v_c + \omega r_b) + C_4 V_r) \quad (8.40)$$

Now, we need to solve for  $\dot{v}_c$  and  $\dot{\omega}$ . First, we'll add equation (8.39) to equation (8.40).

$$2\dot{v}_c = \frac{2}{m} (C_1 (v_c - \omega r_b) + C_2 V_l) + \frac{2}{m} (C_3 (v_c + \omega r_b) + C_4 V_r)$$

$$\dot{v}_c = \frac{1}{m} (C_1 (v_c - \omega r_b) + C_2 V_l) + \frac{1}{m} (C_3 (v_c + \omega r_b) + C_4 V_r)$$

$$\dot{v}_c = \frac{1}{m} (C_1 + C_3) v_c + \frac{1}{m} (-C_1 + C_3) \omega r_b + \frac{1}{m} C_2 V_l + \frac{1}{m} C_4 V_r$$

$$\dot{v}_c = \frac{1}{m} (C_1 + C_3) v_c + \frac{r_b}{m} (-C_1 + C_3) \omega + \frac{1}{m} C_2 V_l + \frac{1}{m} C_4 V_r$$

Next, we'll subtract equation (8.40) from equation (8.39).

$$2\dot{\omega} r_b = \frac{2r_b^2}{J} (C_1 (v_c - \omega r_b) + C_2 V_l) - \frac{2r_b^2}{J} (C_3 (v_c + \omega r_b) + C_4 V_r)$$

$$\begin{aligned}\dot{\omega} &= \frac{r_b}{J} (C_1(v_c - \omega r_b) + C_2 V_l) - \frac{r_b}{J} (C_3(v_c + \omega r_b) + C_4 V_r) \\ \dot{v} &= \frac{r_b}{J} (C_1 - C_3)v_c + \frac{r_b}{J} (-C_1 - C_3)\omega r_b + \frac{r_b}{J} C_2 V_l - \frac{r_b}{J} C_4 V_r \\ \dot{\omega} &= \frac{r_b}{J} (C_1 - C_3)v_c + \frac{r_b^2}{J} (-C_1 - C_3)\omega + \frac{r_b}{J} C_2 V_l - \frac{r_b}{J} C_4 V_r\end{aligned}$$

Now, just convert the two equations to state-space notation.

**Theorem 8.7.4 — Linear/angular velocity reference tracker.**

$$\mathbf{x} = \begin{bmatrix} v \\ \omega \end{bmatrix} \quad \mathbf{y} = \begin{bmatrix} v_l \\ v_r \end{bmatrix} \quad \mathbf{u} = \begin{bmatrix} V_l \\ V_r \end{bmatrix}$$

$$\begin{aligned}\mathbf{A} &= \begin{bmatrix} \frac{1}{m}(C_1 + C_3) & \frac{r_b}{m}(-C_1 + C_3) \\ \frac{r_b}{J}(C_1 - C_3) & \frac{r_b}{J}(-C_1 - C_3) \end{bmatrix} & \mathbf{B} &= \begin{bmatrix} \frac{1}{m}C_2 & \frac{1}{m}C_4 \\ \frac{r_b}{J}C_2 & -\frac{r_b}{J}C_4 \end{bmatrix} \\ \mathbf{C} &= \begin{bmatrix} 1 & -r_b \\ 1 & r_b \end{bmatrix} & \mathbf{D} &= \mathbf{0}_{2 \times 2}\end{aligned} \quad (8.41)$$

where  $C_1 = -\frac{G_l^2 K_t}{K_v R r^2}$ ,  $C_2 = \frac{G_l K_t}{R r}$ ,  $C_3 = -\frac{G_r^2 K_t}{K_v R r^2}$ , and  $C_4 = \frac{G_r K_t}{R r}$ .

See [https://github.com/calcmogul/controls-engineering-in-frc/blob/master/modern-control-theory/ss-applications/ramsete\\_coupled.py](https://github.com/calcmogul/controls-engineering-in-frc/blob/master/modern-control-theory/ss-applications/ramsete_coupled.py) for an implementation.

### Reference tracker comparison

Figures 8.13 and 8.14 shows how well each reference tracker performs.




Figure 8.13: Left/right velocity reference tracker response to a motion profile




Figure 8.14: Linear/angular velocity reference tracker response to a motion profile

For a simple s-curve motion profile, they behave similarly.

Figure 8.15 demonstrates the Ramsete controller with the left/right velocity reference tracker for a typical FRC drivetrain with the reference tracking behavior shown in figure 8.16 and figure 8.17 demonstrates the Ramsete controller with the velocity / angular velocity reference tracker for a typical FRC drivetrain with the reference tracking behavior shown in figure 8.18.

The Ramsete controller behaves relatively the same in each case, but the left/right velocity reference tracker tracks the references produced by the Ramsete controller better and with smaller control






Figure 8.15: Ramsete controller response with left/right velocity reference tracker ( $b = 2$ ,  $\zeta = 0.7$ )




Figure 8.16: Ramsete controller's left/right velocity reference tracker response




Figure 8.17: Ramsete controller response with velocity / angular velocity reference tracker ( $b = 2$ ,  $\zeta = 0.7$ )




Figure 8.18: Ramsete controller's velocity / angular velocity reference tracker response

efforts overall. This is likely due to the second controller having coupled dynamics. That is, the control inputs don't act independently on the system states. In the coupled controller,  $v$  and  $\omega$  require opposing control actions to reach their respective references, which results in them fighting each other. This hypothesis is supported by the condition number of the coupled controller's controllability matrix being larger (2.692 for coupled and 1.314 for decoupled).

Therefore, theorem 8.7.3 is a superior reference tracker to theorem 8.7.4 due to its decoupled dynamics, even though conversions are required between it and the Ramsete controller's commands.

## 8.8 Linear time-varying unicycle controller

One can also create a linear time-varying controller with a cascaded control architecture like Ramsete. This section will derive a locally optimal replacement for Ramsete.

The change in global pose for a unicycle is defined by the following three equations.

$$\begin{aligned}\dot{x} &= v \cos \theta \\ \dot{y} &= v \sin \theta \\ \dot{\theta} &= \omega\end{aligned}$$

Here's the model as a vector function where  $\mathbf{x} = [x \ y \ \theta]^T$  and  $\mathbf{u} = [v \ \omega]^T$ .

$$f(\mathbf{x}, \mathbf{u}) = \begin{bmatrix} v \cos \theta \\ v \sin \theta \\ \omega \end{bmatrix} \quad (8.42)$$

To create an LQR, we need to linearize this.

$$\frac{\partial f(\mathbf{x}, \mathbf{u})}{\partial \mathbf{x}} = \begin{bmatrix} 0 & 0 & -v \sin \theta \\ 0 & 0 & v \cos \theta \\ 0 & 0 & 0 \end{bmatrix} \quad \frac{\partial f(\mathbf{x}, \mathbf{u})}{\partial \mathbf{u}} = \begin{bmatrix} \cos \theta & 0 \\ \sin \theta & 0 \\ 0 & 1 \end{bmatrix}$$

We're going to make a cross-track error controller, so we'll apply a clockwise rotation matrix to the global tracking error to transform it into the robot's coordinate frame. Since the cross-track error is always measured from the robot's coordinate frame, the [model](#) used to compute the LQR should be linearized around  $\theta = 0$  at all times.

$$\mathbf{A} = \begin{bmatrix} 0 & 0 & -v \sin 0 \\ 0 & 0 & v \cos 0 \\ 0 & 0 & 0 \end{bmatrix} \quad \mathbf{B} = \begin{bmatrix} \cos 0 & 0 \\ \sin 0 & 0 \\ 0 & 1 \end{bmatrix}$$

$$\mathbf{A} = \begin{bmatrix} 0 & 0 & 0 \\ 0 & 0 & v \\ 0 & 0 & 0 \end{bmatrix} \quad \mathbf{B} = \begin{bmatrix} 1 & 0 \\ 0 & 0 \\ 0 & 1 \end{bmatrix}$$

Therefore,

**Theorem 8.8.1 — Linear time-varying unicycle controller.**

$$\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u}$$

$$\mathbf{y} = \mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u}$$

$$\mathbf{x} = [x \ y \ \theta]^T \quad \mathbf{y} = [\theta] \quad \mathbf{u} = [v \ \omega]^T$$

$$\mathbf{A} = \begin{bmatrix} 0 & 0 & 0 \\ 0 & 0 & v \\ 0 & 0 & 0 \end{bmatrix} \quad \mathbf{B} = \begin{bmatrix} 1 & 0 \\ 0 & 0 \\ 0 & 1 \end{bmatrix} \quad \mathbf{C} = [0 \ 0 \ 1] \quad \mathbf{D} = \mathbf{0}_{1 \times 2} \quad (8.43)$$

$$\mathbf{u} = \mathbf{K} \begin{bmatrix} \cos \theta & \sin \theta & 0 \\ -\sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} (\mathbf{r} - \mathbf{x}) \quad (8.44)$$

The controller gain  $\mathbf{K}$  from LQR should be recomputed from the model linearized around the current state during every timestep.

With the [model](#) in theorem 8.8.1,  $y$  is uncontrollable at  $v = 0$  because nonholonomic drivetrains are unable to move sideways. Some DARE solvers throw errors in this case, but one can avoid it by linearizing the model around a slightly nonzero velocity instead.

The controller in theorem 8.8.1 results in figures 8.19 and 8.20.




Figure 8.19: Linear time-varying unicycle controller x-y plot




Figure 8.20: Linear time-varying unicycle controller response

*This page intentionally left blank*



# Estimation and localization

<b>9</b>	<b>Stochastic control theory</b> .....	<b>89</b>
9.1	Terminology	
9.2	State observers	
9.3	Introduction to probability	
9.4	Linear stochastic systems	
9.5	Two-sensor problem	
9.6	Kalman filter	
9.7	Kalman smoother	
9.8	Extended Kalman filter	
9.9	Unscented Kalman filter	
9.10	Multiple model adaptive estimation	
<b>10</b>	<b>Pose estimation</b> .....	<b>119</b>
10.1	Euler integration	
10.2	Pose exponential	
10.3	Pose correction	

*This page intentionally left blank*





## 9. Stochastic control theory

Stochastic control theory is a subfield of control theory that deals with the existence of uncertainty either in observations or in noise that drives the evolution of a [system](#). We assign probability distributions to this random noise and aim to achieve a desired control task despite the presence of this uncertainty.

Stochastic optimal control is concerned with doing this with minimum cost defined by some cost functional, like we did with LQR earlier. First, we'll cover the basics of probability and how we represent linear stochastic [systems](#) in state-space representation. Then, we'll derive an optimal estimator using this knowledge, the Kalman filter, and demonstrate creative applications of the Kalman filter theory.

This will be a rather math-heavy introduction, so we recommend reading *Kalman and Bayesian Filters in Python* by Roger Labbe first [23].

### 9.1 Terminology

First, we should provide definitions for terms that have specific meanings in this field.

A causal system is one that uses only past information. A noncausal system also uses information from the future. A filter is a causal system that *filters* information through a probabilistic model to produce an estimate of a desired quantity that can't be measured directly. A smoother is a noncausal system, so it uses information from before and after the current state to produce a better estimate.

### 9.2 State observers

State [observers](#) are used to estimate [states](#) which cannot be measured directly. This can be due to noisy measurements or the [state](#) not being measurable (a hidden [state](#)). This information can be used for [localization](#), which is the process of using external measurements to determine an [agent's](#) pose<sup>1</sup>, or orientation in the world.

---

<sup>1</sup>An agent is a system-agnostic term for independent controlled actors like robots or aircraft.

One type of *state* estimator is LQE. “LQE” stands for “Linear-Quadratic Estimator”. Similar to LQR, it places the estimator poles such that it minimizes the sum of squares of the estimation *error*. The Luenberger *observer* and Kalman filter are examples of these, where the latter chooses the pole locations optimally based on the *model* and measurement uncertainties.

Computer vision can also be used for *localization*. By extracting features from an image taken by the *agent’s* camera, like a retroreflective target in FRC, and comparing them to known dimensions, one can determine where the *agent’s* camera would have to be to see that image. This can be used to correct our *state* estimate in the same way we do with an encoder or gyroscope.

### 9.2.1 Luenberger observer

We’ll introduce the Luenberger observer first to demonstrate the general form of a state estimator and some of their properties.

#### Theorem 9.2.1 — Luenberger observer.

$$\dot{\hat{\mathbf{x}}} = \mathbf{A}\hat{\mathbf{x}} + \mathbf{B}\mathbf{u} + \mathbf{L}(\mathbf{y} - \hat{\mathbf{y}}) \quad (9.1)$$

$$\hat{\mathbf{y}} = \mathbf{C}\hat{\mathbf{x}} + \mathbf{D}\mathbf{u} \quad (9.2)$$

$$\hat{\mathbf{x}}_{k+1} = \mathbf{A}\hat{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k + \mathbf{L}(\mathbf{y}_k - \hat{\mathbf{y}}_k) \quad (9.3)$$

$$\hat{\mathbf{y}}_k = \mathbf{C}\hat{\mathbf{x}}_k + \mathbf{D}\mathbf{u}_k \quad (9.4)$$

<b>A</b>	system matrix	$\hat{\mathbf{x}}$	state estimate vector
<b>B</b>	input matrix	$\mathbf{u}$	input vector
<b>C</b>	output matrix	$\mathbf{y}$	output vector
<b>D</b>	feedthrough matrix	$\hat{\mathbf{y}}$	output estimate vector
<b>L</b>	estimator gain matrix		

Matrix	Rows × Columns	Matrix	Rows × Columns
<b>A</b>	states × states	$\hat{\mathbf{x}}$	states × 1
<b>B</b>	states × inputs	$\mathbf{u}$	inputs × 1
<b>C</b>	outputs × states	$\mathbf{y}$	outputs × 1
<b>D</b>	outputs × inputs	$\hat{\mathbf{y}}$	outputs × 1
<b>L</b>	states × outputs		

Table 9.1: Luenberger observer matrix dimensions

Variables denoted with a hat are estimates of the corresponding variable. For example,  $\hat{\mathbf{x}}$  is the estimate of the true *state*  $\mathbf{x}$ .

Notice that a Luenberger *observer* has an extra term in the *state* evolution equation. This term uses the difference between the estimated *outputs* and measured *outputs* to steer the estimated *state* toward

the true *state*. Large values of  $\mathbf{L}$  trust the measurements more while small values trust the *model* more.

- R** Using an estimator forfeits the performance guarantees from earlier, but the responses are still generally very good if the process and measurement noises are small enough. See John Doyle's paper *Guaranteed Margins for LQG Regulators* for a proof.

A Luenberger *observer* combines the prediction and update steps of an estimator. To run them separately, use the equations in theorem 9.2.2 instead.

**Theorem 9.2.2 — Luenberger observer with separate predict/update.**

Predict step

$$\hat{\mathbf{x}}_{k+1}^- = \mathbf{A}\hat{\mathbf{x}}_k^- + \mathbf{B}\mathbf{u}_k \quad (9.5)$$

Update step

$$\hat{\mathbf{x}}_{k+1}^+ = \hat{\mathbf{x}}_{k+1}^- + \mathbf{A}^{-1}\mathbf{L}(\mathbf{y}_k - \hat{\mathbf{y}}_k) \quad (9.6)$$

$$\hat{\mathbf{y}}_k = \mathbf{C}\hat{\mathbf{x}}_k^- \quad (9.7)$$

See appendix F.3.1 for a derivation.

**Eigenvalues of closed-loop observer**

The eigenvalues of the system matrix can be used to determine whether a *state observer's* estimate will converge to the true *state*.

Plugging equation (9.4) into equation (9.3) gives

$$\begin{aligned} \hat{\mathbf{x}}_{k+1} &= \mathbf{A}\hat{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k + \mathbf{L}(\mathbf{y}_k - \hat{\mathbf{y}}_k) \\ \hat{\mathbf{x}}_{k+1} &= \mathbf{A}\hat{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k + \mathbf{L}(\mathbf{y}_k - (\mathbf{C}\hat{\mathbf{x}}_k + \mathbf{D}\mathbf{u}_k)) \\ \hat{\mathbf{x}}_{k+1} &= \mathbf{A}\hat{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k + \mathbf{L}(\mathbf{y}_k - \mathbf{C}\hat{\mathbf{x}}_k - \mathbf{D}\mathbf{u}_k) \end{aligned}$$

Plugging in equation (5.4) gives

$$\begin{aligned} \hat{\mathbf{x}}_{k+1} &= \mathbf{A}\hat{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k + \mathbf{L}((\mathbf{C}\mathbf{x}_k + \mathbf{D}\mathbf{u}_k) - \mathbf{C}\hat{\mathbf{x}}_k - \mathbf{D}\mathbf{u}_k) \\ \hat{\mathbf{x}}_{k+1} &= \mathbf{A}\hat{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k + \mathbf{L}(\mathbf{C}\mathbf{x}_k + \mathbf{D}\mathbf{u}_k - \mathbf{C}\hat{\mathbf{x}}_k - \mathbf{D}\mathbf{u}_k) \\ \hat{\mathbf{x}}_{k+1} &= \mathbf{A}\hat{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k + \mathbf{L}(\mathbf{C}\mathbf{x}_k - \mathbf{C}\hat{\mathbf{x}}_k) \\ \hat{\mathbf{x}}_{k+1} &= \mathbf{A}\hat{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k + \mathbf{L}\mathbf{C}(\mathbf{x}_k - \hat{\mathbf{x}}_k) \end{aligned}$$

Let  $\mathbf{E}_k = \mathbf{x}_k - \hat{\mathbf{x}}_k$  be the *error* in the estimate  $\hat{\mathbf{x}}_k$ .

$$\hat{\mathbf{x}}_{k+1} = \mathbf{A}\hat{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k + \mathbf{L}\mathbf{C}\mathbf{E}_k$$

Subtracting this from equation (5.3) gives

$$\begin{aligned} \mathbf{x}_{k+1} - \hat{\mathbf{x}}_{k+1} &= \mathbf{A}\mathbf{x}_k + \mathbf{B}\mathbf{u}_k - (\mathbf{A}\hat{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k + \mathbf{L}\mathbf{C}\mathbf{E}_k) \\ \mathbf{E}_{k+1} &= \mathbf{A}\mathbf{x}_k + \mathbf{B}\mathbf{u}_k - (\mathbf{A}\hat{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k + \mathbf{L}\mathbf{C}\mathbf{E}_k) \\ \mathbf{E}_{k+1} &= \mathbf{A}\mathbf{x}_k + \mathbf{B}\mathbf{u}_k - \mathbf{A}\hat{\mathbf{x}}_k - \mathbf{B}\mathbf{u}_k - \mathbf{L}\mathbf{C}\mathbf{E}_k \\ \mathbf{E}_{k+1} &= \mathbf{A}\mathbf{x}_k - \mathbf{A}\hat{\mathbf{x}}_k - \mathbf{L}\mathbf{C}\mathbf{E}_k \end{aligned}$$

$$\begin{aligned}
\mathbf{E}_{k+1} &= \mathbf{A}(\mathbf{x}_k - \hat{\mathbf{x}}_k) - \mathbf{LCE}_k \\
\mathbf{E}_{k+1} &= \mathbf{AE}_k - \mathbf{LCE}_k \\
\mathbf{E}_{k+1} &= (\mathbf{A} - \mathbf{LC})\mathbf{E}_k
\end{aligned} \tag{9.8}$$

For equation (9.8) to have a bounded output, the eigenvalues of  $\mathbf{A} - \mathbf{LC}$  must be within the unit circle. These eigenvalues represent how fast the estimator converges to the true state of the given model. A fast estimator converges quickly while a slow estimator avoids amplifying noise in the measurements used to produce a state estimate.

As stated before, the controller and estimator are dual problems. Controller gains can be found assuming perfect estimator (i.e., perfect knowledge of all states). Estimator gains can be found assuming an accurate model and a controller with perfect tracking.

The effect of noise can be seen if it is modeled stochastically as

$$\hat{\mathbf{x}}_{k+1} = \mathbf{A}\hat{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k + \mathbf{L}((\mathbf{y}_k + \nu_k) - \hat{\mathbf{y}}_k)$$

where  $\nu_k$  is the measurement noise. Rearranging this equation yields

$$\begin{aligned}
\hat{\mathbf{x}}_{k+1} &= \mathbf{A}\hat{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k + \mathbf{L}(\mathbf{y}_k - \hat{\mathbf{y}}_k + \nu_k) \\
\hat{\mathbf{x}}_{k+1} &= \mathbf{A}\hat{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k + \mathbf{L}(\mathbf{y}_k - \hat{\mathbf{y}}_k) + \mathbf{L}\nu_k
\end{aligned}$$

As  $\mathbf{L}$  increases, the measurement noise is amplified.

### 9.3 Introduction to probability

Now we'll begin establishing probability concepts we need to describe and manipulate stochastic systems.

#### 9.3.1 Random variables

A random variable is a variable whose values are the outcomes of a random phenomenon, like dice rolls or noisy process measurements. As such, a random variable is defined as a function that maps the outcomes of an unpredictable process to numerical quantities. A particular output of this function is called a sample. The sample space is the set of possible values taken by the random variable.

A probability density function (PDF) is a function of the random variable whose value at a given sample (measured value) in the sample space (the range of possible measured values) is the probability of that sample occurring. The area under the function over a range gives the probability that the sample falls within that range. Let  $x$  be a random variable, and let  $p(x)$  denote the probability density function of  $x$ . The probability that the value of  $x$  will be in the interval  $x \in [x_1, x_1 + dx]$  is  $p(x_1) dx$ . In other words, the probability is the area under the PDF within the region  $[x_1, x_1 + dx]$  (see figure 9.1).

A probability of zero means that the sample will not occur and a probability of one means that the sample will always occur. Probability density functions require that no probabilities are negative and that the sum of all probabilities is 1. If the probabilities sum to 1, that means one of those outcomes *must* happen. In other words,

$$p(x) \geq 0, \int_{-\infty}^{\infty} p(x) dx = 1$$

or given that the probability of a given sample is greater than or equal to zero, the sum of probabilities for all possible input values is equal to one.




Figure 9.1: Probability density function

### 9.3.2 Expected value

Expected value or expectation is a weighted average of the values the PDF can produce where the weight for each value is the probability of that value occurring. This can be written mathematically as

$$\bar{x} = E[x] = \int_{-\infty}^{\infty} x p(x) dx$$

The expectation can be applied to random functions as well as random variables.

$$E[f(x)] = \int_{-\infty}^{\infty} f(x) p(x) dx$$

The mean of a random variable is denoted by an overbar (e.g.,  $\bar{x}$ ) pronounced x-bar. The expectation of the difference between a random variable and its mean  $x - \bar{x}$  converges to zero. In other words, the expectation of a random variable is its mean. Here's a proof.

$$\begin{aligned} E[x - \bar{x}] &= \int_{-\infty}^{\infty} (x - \bar{x}) p(x) dx \\ E[x - \bar{x}] &= \int_{-\infty}^{\infty} x p(x) dx - \int_{-\infty}^{\infty} \bar{x} p(x) dx \\ E[x - \bar{x}] &= \int_{-\infty}^{\infty} x p(x) dx - \bar{x} \int_{-\infty}^{\infty} p(x) dx \\ E[x - \bar{x}] &= \bar{x} - \bar{x} \cdot 1 \\ E[x - \bar{x}] &= 0 \end{aligned}$$

### 9.3.3 Variance

Informally, variance is a measure of how far the outcome of a random variable deviates from its mean. Later, we will use variance to quantify how confident we are in the estimate of a random variable;




Figure 9.2: Joint probability density function

we can't know the true value of that variable without randomness, but we can give a bound on its randomness.

$$\text{var}(x) = \sigma^2 = E[(x - \bar{x})^2] = \int_{-\infty}^{\infty} (x - \bar{x})^2 p(x) dx$$

The standard deviation is the square root of the variance.

$$\text{std}[x] = \sigma = \sqrt{\text{var}(x)}$$

### 9.3.4 Joint probability density functions

Probability density functions can also include more than one variable. Let  $x$  and  $y$  are random variables. The joint probability density function  $p(x, y)$  defines the probability  $p(x, y) dx dy$ , so that  $x$  and  $y$  are in the intervals  $x \in [x, x + dx]$ ,  $y \in [y, y + dy]$ . In other words, the probability is the volume under a region of the PDF manifold (see figure 9.2 for an example of a joint PDF).

Joint probability density functions also require that no probabilities are negative and that the sum of all probabilities is 1.

$$p(x, y) \geq 0, \int_{-\infty}^{\infty} \int_{-\infty}^{\infty} p(x, y) dx dy = 1$$

The expected values for joint PDFs are as follows.

$$\begin{aligned} E[x] &= \int_{-\infty}^{\infty} \int_{-\infty}^{\infty} x dx dy \\ E[y] &= \int_{-\infty}^{\infty} \int_{-\infty}^{\infty} y dx dy \\ E[f(x, y)] &= \int_{-\infty}^{\infty} \int_{-\infty}^{\infty} f(x, y) dx dy \end{aligned}$$

The variance of a joint PDF measures how a variable correlates with itself (we'll cover variances with respect to other variables shortly).

$$\begin{aligned}\text{var}(x) &= \Sigma_{xx} = E[(x - \bar{x})^2] = \int_{-\infty}^{\infty} \int_{-\infty}^{\infty} (x - \bar{x})^2 p(x, y) dx dy \\ \text{var}(y) &= \Sigma_{yy} = E[(y - \bar{y})^2] = \int_{-\infty}^{\infty} \int_{-\infty}^{\infty} (y - \bar{y})^2 p(x, y) dx dy\end{aligned}$$

### 9.3.5 Covariance

A covariance is a measurement of how a variable correlates with another. If they vary in the same direction, the covariance increases. If they vary in opposite directions, the covariance decreases.

$$\text{cov}(x, y) = \Sigma_{xy} = E[(x - \bar{x})(y - \bar{y})] = \int_{-\infty}^{\infty} \int_{-\infty}^{\infty} (x - \bar{x})(y - \bar{y}) p(x, y) dx dy$$

### 9.3.6 Correlation

Two random variables are correlated if the result of one random variable affects the result of another. Correlation is defined as

$$\rho(x, y) = \frac{\Sigma_{xy}}{\sqrt{\Sigma_{xx}\Sigma_{yy}}}, |\rho(x, y)| \leq 1$$

So two variable's correlation is defined as their covariance over the geometric mean of their variances. Uncorrelated sources have a covariance of zero.

### 9.3.7 Independence

Two random variables are independent if the following relation is true.

$$p(x, y) = p(x)p(y)$$

This means that the values of  $x$  do not correlate with the values of  $y$ . That is, the outcome of one random variable does not affect another's outcome. If we assume independence,

$$\begin{aligned}E[xy] &= \int_{-\infty}^{\infty} \int_{-\infty}^{\infty} xy p(x, y) dx dy \\ E[xy] &= \int_{-\infty}^{\infty} \int_{-\infty}^{\infty} xy p(x) p(y) dx dy \\ E[xy] &= \int_{-\infty}^{\infty} x p(x) dx \int_{-\infty}^{\infty} y p(y) dy \\ E[xy] &= E[x]E[y] \\ E[xy] &= \bar{x}\bar{y}\end{aligned}$$

$$\begin{aligned}\text{cov}(x, y) &= E[(x - \bar{x})(y - \bar{y})] \\ \text{cov}(x, y) &= E[(x - \bar{x})]E[(y - \bar{y})] \\ \text{cov}(x, y) &= 0 \cdot 0\end{aligned}$$

Therefore, the covariance  $\Sigma_{xy}$  is zero, as expected. Furthermore,  $\rho(x, y) = 0$ , which means they are uncorrelated.



### 9.3.8 Marginal probability density functions

Given two random variables  $x$  and  $y$  whose joint distribution is known, the marginal PDF  $p(x)$  expresses the probability of  $x$  averaged over information about  $y$ . In other words, it's the PDF of  $x$  when  $y$  is unknown. This is calculated by integrating the joint PDF over  $y$ .

$$p(x) = \int_{-\infty}^{\infty} p(x, y) dy$$

### 9.3.9 Conditional probability density functions

Let us assume that we know the joint PDF  $p(x, y)$  and the exact value for  $y$ . The conditional PDF gives the probability of  $x$  in the interval  $[x, x + dx]$  for the given value  $y$ .

If  $p(x, y)$  is known, then we also know  $p(x, y = y^*)$ . However, note that the latter is not the conditional density  $p(x|y^*)$ , instead

$$C(y^*) = \int_{-\infty}^{\infty} p(x, y = y^*) dx$$

$$p(x|y^*) = \frac{1}{C(y^*)} p(x, y = y^*)$$

The scale factor  $\frac{1}{C(y^*)}$  is used to scale the area under the PDF to 1.

### 9.3.10 Bayes's rule

Bayes's rule is used to determine the probability of an event based on prior knowledge of conditions related to the event.

$$p(x, y) = p(x|y) p(y) = p(y|x) p(x)$$

If  $x$  and  $y$  are independent, then  $p(x|y) = p(x)$ ,  $p(y|x) = p(y)$ , and  $p(x, y) = p(x) p(y)$ .

### 9.3.11 Conditional expectation

The concept of expectation can also be applied to conditional PDFs. This allows us to determine what the mean of a variable is given prior knowledge of other variables.

$$E[x|y] = \int_{-\infty}^{\infty} x p(x|y) dx = f(y), E[x|y] \neq E[x]$$

$$E[y|x] = \int_{-\infty}^{\infty} y p(y|x) dy = f(x), E[y|x] \neq E[y]$$

### 9.3.12 Conditional variances

$$\text{var}(x|y) = E[(x - E[x|y])^2|y]$$

$$\text{var}(x|y) = \int_{-\infty}^{\infty} (x - E[x|y])^2 p(x|y) dx$$

### 9.3.13 Random vectors

Now we will extend the probability concepts discussed so far to vectors where each element has a PDF.

$$\mathbf{x} = \begin{bmatrix} x_1 \\ x_2 \\ \dots \\ x_n \end{bmatrix}$$

The elements of  $\mathbf{x}$  are scalar variables jointly distributed with a joint density  $p(x_1, x_2, \dots, x_n)$ . The expectation is

$$E[\mathbf{x}] = \bar{\mathbf{x}} = \int_{-\infty}^{\infty} \mathbf{x} p(\mathbf{x}) d\mathbf{x}$$

$$E[\mathbf{x}] = \begin{bmatrix} E[x_1] \\ E[x_2] \\ \vdots \\ E[x_n] \end{bmatrix}$$

$$E[x_i] = \int_{-\infty}^{\infty} \dots \int_{-\infty}^{\infty} x_i p(x_1, x_2, \dots, x_n) dx_1 \dots dx_n$$

$$E[f(\mathbf{x})] = \int_{-\infty}^{\infty} f(\mathbf{x}) p(\mathbf{x}) d\mathbf{x}$$

### 9.3.14 Covariance matrix

The covariance matrix for a random vector  $\mathbf{x} \in \mathbb{R}^n$  is

$$\Sigma = \text{cov}(\mathbf{x}, \mathbf{x}) = E[(\mathbf{x} - \bar{\mathbf{x}})(\mathbf{x} - \bar{\mathbf{x}})^T]$$

$$\Sigma = \begin{bmatrix} \text{cov}(x_1, x_1) & \text{cov}(x_1, x_2) & \dots & \text{cov}(x_1, x_n) \\ \text{cov}(x_2, x_1) & \text{cov}(x_2, x_2) & \dots & \text{cov}(x_2, x_n) \\ \vdots & \vdots & \ddots & \vdots \\ \text{cov}(x_n, x_1) & \text{cov}(x_n, x_2) & \dots & \text{cov}(x_n, x_n) \end{bmatrix}$$

This  $n \times n$  matrix is symmetric and positive semidefinite. A positive semidefinite matrix satisfies the relation that for any  $\mathbf{v} \in \mathbb{R}^n$  for which  $\mathbf{v} \neq 0$ ,  $\mathbf{v}^T \Sigma \mathbf{v} \geq 0$ . In other words, the eigenvalues of  $\Sigma$  are all greater than or equal to zero.

### 9.3.15 Relations for independent random vectors

First, independent vectors imply linearity from  $p(\mathbf{x}, \mathbf{y}) = p(\mathbf{x}) p(\mathbf{y})$ .

$$E[\mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{y}] = \mathbf{A}E[\mathbf{x}] + \mathbf{B}E[\mathbf{y}]$$

$$E[\mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{y}] = \mathbf{A}\bar{\mathbf{x}} + \mathbf{B}\bar{\mathbf{y}}$$

Second, independent vectors being uncorrelated means their covariance is zero.

$$\Sigma_{\mathbf{xy}} = \text{cov}(\mathbf{x}, \mathbf{y})$$

$$\Sigma_{\mathbf{xy}} = E[(\mathbf{x} - \bar{\mathbf{x}})(\mathbf{y} - \bar{\mathbf{y}})^T]$$

$$\Sigma_{\mathbf{xy}} = E[\mathbf{xy}^T] - E[\mathbf{x}\bar{\mathbf{y}}^T] - E[\bar{\mathbf{x}}\mathbf{y}^T] + E[\bar{\mathbf{x}}\bar{\mathbf{y}}^T]$$

$$\Sigma_{\mathbf{xy}} = E[\mathbf{xy}^T] - E[\mathbf{x}]\bar{\mathbf{y}}^T - \bar{\mathbf{x}}E[\mathbf{y}^T] + \bar{\mathbf{x}}\bar{\mathbf{y}}^T$$

$$\Sigma_{\mathbf{xy}} = E[\mathbf{xy}^T] - \bar{\mathbf{x}}\bar{\mathbf{y}}^T - \bar{\mathbf{x}}\bar{\mathbf{y}}^T + \bar{\mathbf{x}}\bar{\mathbf{y}}^T$$

$$\Sigma_{\mathbf{xy}} = E[\mathbf{xy}^T] - \bar{\mathbf{x}}\bar{\mathbf{y}}^T \tag{9.9}$$

Now, compute  $E[\mathbf{xy}^T]$ .

$$E[\mathbf{xy}^T] = \int_X \int_Y \mathbf{xy}^T p(\mathbf{x}) p(\mathbf{y}) d\mathbf{x} d\mathbf{y}^T$$

Factor out constants from the inner integral. This includes variables which are held constant for each inner integral evaluation.

$$E[\mathbf{xy}^T] = \int_X p(\mathbf{x}) \mathbf{x} d\mathbf{x} \int_Y p(\mathbf{y}) \mathbf{y}^T d\mathbf{y}^T$$

Each of these integrals is just the expected value of their respective integration variable.

$$E[\mathbf{xy}^T] = \overline{\mathbf{xy}^T} \quad (9.10)$$

Substitute equation (9.10) into equation (9.9).

$$\begin{aligned} \Sigma_{\mathbf{xy}} &= (\overline{\mathbf{xy}^T}) - \overline{\mathbf{xy}^T} \\ \Sigma_{\mathbf{xy}} &= 0 \end{aligned}$$

Using these results, we can compute the covariance of  $\mathbf{z} = \mathbf{Ax} + \mathbf{By}$ .

$$\begin{aligned} \Sigma_z &= \text{cov}(\mathbf{z}, \mathbf{z}) \\ \Sigma_z &= E[(\mathbf{z} - \bar{\mathbf{z}})(\mathbf{z} - \bar{\mathbf{z}})^T] \\ \Sigma_z &= E[(\mathbf{Ax} + \mathbf{By} - \mathbf{Ax} - \mathbf{By})(\mathbf{Ax} + \mathbf{By} - \mathbf{Ax} - \mathbf{By})^T] \\ \Sigma_z &= E[(\mathbf{A}(\mathbf{x} - \bar{\mathbf{x}}) + \mathbf{B}(\mathbf{y} - \bar{\mathbf{y}}))(\mathbf{A}(\mathbf{x} - \bar{\mathbf{x}}) + \mathbf{B}(\mathbf{y} - \bar{\mathbf{y}}))^T] \\ \Sigma_z &= E[(\mathbf{A}(\mathbf{x} - \bar{\mathbf{x}}) + \mathbf{B}(\mathbf{y} - \bar{\mathbf{y}}))((\mathbf{x} - \bar{\mathbf{x}})^T \mathbf{A}^T + (\mathbf{y} - \bar{\mathbf{y}})^T \mathbf{B}^T)] \\ \Sigma_z &= E[\mathbf{A}(\mathbf{x} - \bar{\mathbf{x}})(\mathbf{x} - \bar{\mathbf{x}})^T \mathbf{A}^T + \mathbf{A}(\mathbf{x} - \bar{\mathbf{x}})(\mathbf{y} - \bar{\mathbf{y}})^T \mathbf{B}^T \\ &\quad + \mathbf{B}(\mathbf{y} - \bar{\mathbf{y}})(\mathbf{x} - \bar{\mathbf{x}})^T \mathbf{A}^T + \mathbf{B}(\mathbf{y} - \bar{\mathbf{y}})(\mathbf{y} - \bar{\mathbf{y}})^T \mathbf{B}^T] \end{aligned}$$

Since  $\mathbf{x}$  and  $\mathbf{y}$  are independent,  $\Sigma_{xy} = 0$  and the cross terms cancel out.

$$\begin{aligned} \Sigma_z &= E[\mathbf{A}(\mathbf{x} - \bar{\mathbf{x}})(\mathbf{x} - \bar{\mathbf{x}})^T \mathbf{A}^T + 0 + 0 + \mathbf{B}(\mathbf{y} - \bar{\mathbf{y}})(\mathbf{y} - \bar{\mathbf{y}})^T \mathbf{B}^T] \\ \Sigma_z &= E[\mathbf{A}(\mathbf{x} - \bar{\mathbf{x}})(\mathbf{x} - \bar{\mathbf{x}})^T \mathbf{A}^T] + E[\mathbf{B}(\mathbf{y} - \bar{\mathbf{y}})(\mathbf{y} - \bar{\mathbf{y}})^T \mathbf{B}^T] \\ \Sigma_z &= \mathbf{A}E[(\mathbf{x} - \bar{\mathbf{x}})(\mathbf{x} - \bar{\mathbf{x}})^T] \mathbf{A}^T + \mathbf{B}E[(\mathbf{y} - \bar{\mathbf{y}})(\mathbf{y} - \bar{\mathbf{y}})^T] \mathbf{B}^T \end{aligned}$$

Recall that  $\Sigma_x = \text{cov}(\mathbf{x}, \mathbf{x})$  and  $\Sigma_y = \text{cov}(\mathbf{y}, \mathbf{y})$ .

$$\Sigma_z = \mathbf{A}\Sigma_x \mathbf{A}^T + \mathbf{B}\Sigma_y \mathbf{B}^T$$

### 9.3.16 Gaussian random variables

A Gaussian random variable has the following properties:

$$\begin{aligned} E[x] &= \bar{x} \\ \text{var}(x) &= \sigma^2 \\ p(x) &= \frac{1}{\sqrt{2\pi\sigma^2}} e^{-\frac{(x-\bar{x})^2}{2\sigma^2}} \end{aligned}$$

While we could use any random variable to represent a random process, we use the Gaussian random variable a lot in probability theory due to the central limit theorem.

**Definition 9.3.1 — Central limit theorem.** When independent random variables are added, their properly normalized sum tends toward a normal distribution (a Gaussian distribution or “bell curve”).

This is the case even if the original variables themselves are not normally distributed. The theorem is a key concept in probability theory because it implies that probabilistic and statistical methods that work for normal distributions can be applicable to many problems involving other types of distributions.

For example, suppose that a sample is obtained containing a large number of independent observations, and that the arithmetic mean of the observed values is computed. The central limit theorem says that the computed values of the mean will tend toward being distributed according to a normal distribution.

## 9.4 Linear stochastic systems

Given the following stochastic system

$$\begin{aligned}\mathbf{x}_{k+1} &= \mathbf{A}\mathbf{x}_k + \mathbf{B}\mathbf{u}_k + \mathbf{\Gamma}\mathbf{w}_k \\ \mathbf{y}_k &= \mathbf{C}\mathbf{x}_k + \mathbf{D}\mathbf{u}_k + \mathbf{v}_k\end{aligned}$$

where  $\mathbf{w}_k$  is the process noise and  $\mathbf{v}_k$  is the measurement noise,

$$\begin{aligned}E[\mathbf{w}_k] &= 0 \\ E[\mathbf{w}_k\mathbf{w}_k^T] &= \mathbf{Q}_k \\ E[\mathbf{v}_k] &= 0 \\ E[\mathbf{v}_k\mathbf{v}_k^T] &= \mathbf{R}_k\end{aligned}$$

where  $\mathbf{Q}_k$  is the process noise covariance matrix and  $\mathbf{R}_k$  is the measurement noise covariance matrix. We assume the noise samples are independent, so  $E[\mathbf{w}_k\mathbf{w}_j^T] = 0$  and  $E[\mathbf{v}_k\mathbf{v}_j^T] = 0$  where  $k \neq j$ . Furthermore, process noise samples are independent from measurement noise samples.

We’ll compute the expectation of these equations and their covariance matrices, which we’ll use later for deriving the Kalman filter.

### 9.4.1 State vector expectation evolution

First, we will compute how the expectation of the system state evolves.

$$\begin{aligned}E[\mathbf{x}_{k+1}] &= E[\mathbf{A}\mathbf{x}_k + \mathbf{B}\mathbf{u}_k + \mathbf{\Gamma}\mathbf{w}_k] \\ E[\mathbf{x}_{k+1}] &= E[\mathbf{A}\mathbf{x}_k] + E[\mathbf{B}\mathbf{u}_k] + E[\mathbf{\Gamma}\mathbf{w}_k] \\ E[\mathbf{x}_{k+1}] &= \mathbf{A}E[\mathbf{x}_k] + \mathbf{B}E[\mathbf{u}_k] + \mathbf{\Gamma}E[\mathbf{w}_k] \\ E[\mathbf{x}_{k+1}] &= \mathbf{A}E[\mathbf{x}_k] + \mathbf{B}\mathbf{u}_k + 0 \\ \bar{\mathbf{x}}_{k+1} &= \mathbf{A}\bar{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k\end{aligned}$$

### 9.4.2 Error covariance matrix evolution

Now, we will use this to compute how the error covariance matrix  $\mathbf{P}$  evolves.

$$\mathbf{x}_{k+1} - \bar{\mathbf{x}}_{k+1} = \mathbf{A}\mathbf{x}_k + \mathbf{B}\mathbf{u}_k + \mathbf{\Gamma}\mathbf{w}_k - (\mathbf{A}\bar{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k)$$

$$\begin{aligned}
\mathbf{x}_{k+1} - \bar{\mathbf{x}}_{k+1} &= \mathbf{A}(\mathbf{x}_k - \bar{\mathbf{x}}_k) + \mathbf{\Gamma}\mathbf{w}_k \\
E[(\mathbf{x}_{k+1} - \bar{\mathbf{x}}_{k+1})(\mathbf{x}_{k+1} - \bar{\mathbf{x}}_{k+1})^T] &= E[(\mathbf{A}(\mathbf{x}_k - \bar{\mathbf{x}}_k) + \mathbf{\Gamma}\mathbf{w}_k)(\mathbf{A}(\mathbf{x}_k - \bar{\mathbf{x}}_k) + \mathbf{\Gamma}\mathbf{w}_k)^T] \\
\mathbf{P}_{k+1} &= E[(\mathbf{A}(\mathbf{x}_k - \bar{\mathbf{x}}_k) + \mathbf{\Gamma}\mathbf{w}_k)(\mathbf{A}(\mathbf{x}_k - \bar{\mathbf{x}}_k) + \mathbf{\Gamma}\mathbf{w}_k)^T] \\
\mathbf{P}_{k+1} &= E[(\mathbf{A}(\mathbf{x}_k - \bar{\mathbf{x}}_k)(\mathbf{x}_k - \bar{\mathbf{x}}_k)^T \mathbf{A}^T] + E[\mathbf{A}(\mathbf{x}_k - \bar{\mathbf{x}}_k)\mathbf{w}_k^T \mathbf{\Gamma}^T] \\
&\quad + E[\mathbf{\Gamma}\mathbf{w}_k(\mathbf{x}_k - \bar{\mathbf{x}}_k)^T \mathbf{A}^T] + E[\mathbf{\Gamma}\mathbf{w}_k\mathbf{w}_k^T \mathbf{\Gamma}^T] \\
\mathbf{P}_{k+1} &= \mathbf{A}E[(\mathbf{x}_k - \bar{\mathbf{x}}_k)(\mathbf{x}_k - \bar{\mathbf{x}}_k)^T] \mathbf{A}^T + \mathbf{A}E[(\mathbf{x}_k - \bar{\mathbf{x}}_k)\mathbf{w}_k^T] \mathbf{\Gamma}^T \\
&\quad + \mathbf{\Gamma}E[\mathbf{w}_k(\mathbf{x}_k - \bar{\mathbf{x}}_k)^T] \mathbf{A}^T + \mathbf{\Gamma}E[\mathbf{w}_k\mathbf{w}_k^T] \mathbf{\Gamma}^T \\
\mathbf{P}_{k+1} &= \mathbf{A}\mathbf{P}_k\mathbf{A}^T + \mathbf{A}E[(\mathbf{x}_k - \bar{\mathbf{x}}_k)\mathbf{w}_k^T] \mathbf{\Gamma}^T + \mathbf{\Gamma}E[\mathbf{w}_k(\mathbf{x}_k - \bar{\mathbf{x}}_k)^T] \mathbf{A}^T + \mathbf{\Gamma}\mathbf{Q}_k\mathbf{\Gamma}^T
\end{aligned}$$

Since the error and noise are independent, the cross terms are zero.

$$\begin{aligned}
\mathbf{P}_{k+1} &= \mathbf{A}\mathbf{P}_k\mathbf{A}^T + \mathbf{A} \underbrace{E[(\mathbf{x}_k - \bar{\mathbf{x}}_k)\mathbf{w}_k^T]}_0 \mathbf{\Gamma}^T + \mathbf{\Gamma} \underbrace{E[\mathbf{w}_k(\mathbf{x}_k - \bar{\mathbf{x}}_k)^T]}_0 \mathbf{A}^T + \mathbf{\Gamma}\mathbf{Q}_k\mathbf{\Gamma}^T \\
\mathbf{P}_{k+1} &= \mathbf{A}\mathbf{P}_k\mathbf{A}^T + \mathbf{\Gamma}\mathbf{Q}_k\mathbf{\Gamma}^T
\end{aligned}$$

### 9.4.3 Measurement vector expectation

Next, we will compute the expectation of the output  $\mathbf{y}$ .

$$\begin{aligned}
E[\mathbf{y}_k] &= E[\mathbf{C}\mathbf{x}_k + \mathbf{D}\mathbf{u}_k + \mathbf{v}_k] \\
E[\mathbf{y}_k] &= \mathbf{C}E[\mathbf{x}_k] + \mathbf{D}\mathbf{u}_k + 0 \\
\bar{\mathbf{y}}_k &= \mathbf{C}\bar{\mathbf{x}}_k + \mathbf{D}\mathbf{u}_k
\end{aligned}$$

### 9.4.4 Measurement covariance matrix

Now, we will use this to compute how the measurement covariance matrix  $\mathbf{S}$  evolves.

$$\begin{aligned}
\mathbf{y}_k - \bar{\mathbf{y}}_k &= \mathbf{C}\mathbf{x}_k + \mathbf{D}\mathbf{u}_k + \mathbf{v}_k - (\mathbf{C}\bar{\mathbf{x}}_k + \mathbf{D}\mathbf{u}_k) \\
\mathbf{y}_k - \bar{\mathbf{y}}_k &= \mathbf{C}(\mathbf{x}_k - \bar{\mathbf{x}}_k) + \mathbf{v}_k \\
E[(\mathbf{y}_k - \bar{\mathbf{y}}_k)(\mathbf{y}_k - \bar{\mathbf{y}}_k)^T] &= E[(\mathbf{C}(\mathbf{x}_k - \bar{\mathbf{x}}_k) + \mathbf{v}_k)(\mathbf{C}(\mathbf{x}_k - \bar{\mathbf{x}}_k) + \mathbf{v}_k)^T] \\
\mathbf{S}_k &= E[(\mathbf{C}(\mathbf{x}_k - \bar{\mathbf{x}}_k) + \mathbf{v}_k)(\mathbf{C}(\mathbf{x}_k - \bar{\mathbf{x}}_k) + \mathbf{v}_k)^T] \\
\mathbf{S}_k &= E[(\mathbf{C}(\mathbf{x}_k - \bar{\mathbf{x}}_k) + \mathbf{v}_k)((\mathbf{x}_k - \bar{\mathbf{x}}_k)^T \mathbf{C}^T + \mathbf{v}_k^T)] \\
\mathbf{S}_k &= E[(\mathbf{C}(\mathbf{x}_k - \bar{\mathbf{x}}_k)(\mathbf{x}_k - \bar{\mathbf{x}}_k)^T \mathbf{C}^T] + E[\mathbf{C}(\mathbf{x}_k - \bar{\mathbf{x}}_k)\mathbf{v}_k^T] \\
&\quad + E[\mathbf{v}_k(\mathbf{x}_k - \bar{\mathbf{x}}_k)^T \mathbf{C}^T] + E[\mathbf{v}_k\mathbf{v}_k^T] \\
\mathbf{S}_k &= \mathbf{C}E[(\mathbf{x}_k - \bar{\mathbf{x}}_k)(\mathbf{x}_k - \bar{\mathbf{x}}_k)^T] \mathbf{C}^T + \mathbf{C}E[(\mathbf{x}_k - \bar{\mathbf{x}}_k)\mathbf{v}_k^T] \\
&\quad + E[\mathbf{v}_k(\mathbf{x}_k - \bar{\mathbf{x}}_k)^T] \mathbf{C}^T + E[\mathbf{v}_k\mathbf{v}_k^T] \\
\mathbf{S}_k &= \mathbf{C}\mathbf{P}_k\mathbf{C}^T + \mathbf{C}E[(\mathbf{x}_k - \bar{\mathbf{x}}_k)\mathbf{v}_k^T] + E[\mathbf{v}_k(\mathbf{x}_k - \bar{\mathbf{x}}_k)^T] \mathbf{C}^T + \mathbf{R}_k
\end{aligned}$$

Since the error and noise are independent, the cross terms are zero.

$$\begin{aligned}
\mathbf{S}_k &= \mathbf{C}\mathbf{P}_k\mathbf{C}^T + \mathbf{C} \underbrace{E[(\mathbf{x}_k - \bar{\mathbf{x}}_k)\mathbf{v}_k^T]}_0 + \underbrace{E[\mathbf{v}_k(\mathbf{x}_k - \bar{\mathbf{x}}_k)^T]}_0 \mathbf{C}^T + \mathbf{R}_k \\
\mathbf{S}_k &= \mathbf{C}\mathbf{P}_k\mathbf{C}^T + \mathbf{R}_k
\end{aligned}$$

## 9.5 Two-sensor problem

We'll skip the probability derivations here, but given two data points with associated variances represented by Gaussian distributions, the information can be optimally combined into a third Gaussian distribution with its own mean value and variance. The expected value of  $x$  given a measurement  $z_1$  is

$$E[x|z_1] = \mu = \frac{\sigma_0^2}{\sigma_0^2 + \sigma^2} z_1 + \frac{\sigma^2}{\sigma_0^2 + \sigma^2} x_0 \quad (9.11)$$

The variance of  $x$  given  $z_1$  is

$$E[(x - \mu)^2 | z_1] = \frac{\sigma^2 \sigma_0^2}{\sigma_0^2 + \sigma^2} \quad (9.12)$$

The expected value, which is also the maximum likelihood value, is the linear combination of the prior expected (maximum likelihood) value and the measurement. The expected value is a reasonable estimator of  $x$ .

$$\hat{x} = E[x|z_1] = \frac{\sigma_0^2}{\sigma_0^2 + \sigma^2} z_1 + \frac{\sigma^2}{\sigma_0^2 + \sigma^2} x_0 \quad (9.13)$$

$$\hat{x} = w_1 z_1 + w_2 x_0$$

Note that the weights  $w_1$  and  $w_2$  sum to 1. When the prior (i.e., prior knowledge of [state](#)) is uninformative (a large variance)

$$w_1 = \lim_{\sigma_0^2 \rightarrow 0} \frac{\sigma_0^2}{\sigma_0^2 + \sigma^2} = 0 \quad (9.14)$$

$$w_2 = \lim_{\sigma_0^2 \rightarrow 0} \frac{\sigma^2}{\sigma_0^2 + \sigma^2} = 1 \quad (9.15)$$

and  $\hat{x} = z_1$ . That is, the weight is on the observations and the estimate is equal to the measurement.

Let us assume we have a [model](#) providing an almost exact prior for  $x$ . In that case,  $\sigma_0^2$  approaches 0 and

$$w_1 = \lim_{\sigma_0^2 \rightarrow 0} \frac{\sigma_0^2}{\sigma_0^2 + \sigma^2} = 1 \quad (9.16)$$

$$w_2 = \lim_{\sigma_0^2 \rightarrow 0} \frac{\sigma^2}{\sigma_0^2 + \sigma^2} = 0 \quad (9.17)$$

The Kalman filter uses this optimal fusion as the basis for its operation.

## 9.6 Kalman filter

So far, we've derived equations for updating the expected value and state covariance without measurements and how to incorporate measurements into an initial [state](#) optimally. Now, we'll combine these concepts to produce an estimator which minimizes the error covariance for linear [systems](#).

### 9.6.1 Derivations

Given the *a posteriori* update equation  $\hat{\mathbf{x}}_{k+1}^+ = \hat{\mathbf{x}}_{k+1}^- + \mathbf{K}_{k+1}(\mathbf{y}_{k+1} - \hat{\mathbf{y}}_{k+1})$ , we want to find the value of  $\mathbf{K}_{k+1}$  that minimizes the *a posteriori* estimate covariance (the error covariance) because this minimizes the estimation error.

***a posteriori* estimate covariance update equation**

The following is the definition of the *a posteriori* estimate covariance matrix.

$$\mathbf{P}_{k+1}^+ = \text{cov}(\mathbf{x}_{k+1} - \hat{\mathbf{x}}_{k+1}^+)$$

Substitute in the *a posteriori* update equation and expand the measurement equations.

$$\begin{aligned}\mathbf{P}_{k+1}^+ &= \text{cov}(\mathbf{x}_{k+1} - (\hat{\mathbf{x}}_{k+1}^- + \mathbf{K}_{k+1}(\mathbf{y}_{k+1} - \hat{\mathbf{y}}_{k+1}))) \\ \mathbf{P}_{k+1}^+ &= \text{cov}(\mathbf{x}_{k+1} - \hat{\mathbf{x}}_{k+1}^- - \mathbf{K}_{k+1}(\mathbf{y}_{k+1} - \hat{\mathbf{y}}_{k+1})) \\ \mathbf{P}_{k+1}^+ &= \text{cov}(\mathbf{x}_{k+1} - \hat{\mathbf{x}}_{k+1}^- - \\ &\quad \mathbf{K}_{k+1}((\mathbf{C}_{k+1}\mathbf{x}_{k+1} + \mathbf{D}_{k+1}\mathbf{u}_{k+1} + \mathbf{v}_{k+1}) - (\mathbf{C}_{k+1}\hat{\mathbf{x}}_{k+1}^- + \mathbf{D}_{k+1}\mathbf{u}_{k+1}))) \\ \mathbf{P}_{k+1}^+ &= \text{cov}(\mathbf{x}_{k+1} - \hat{\mathbf{x}}_{k+1}^- - \\ &\quad \mathbf{K}_{k+1}(\mathbf{C}_{k+1}\mathbf{x}_{k+1} + \mathbf{D}_{k+1}\mathbf{u}_{k+1} + \mathbf{v}_{k+1} - \mathbf{C}_{k+1}\hat{\mathbf{x}}_{k+1}^- - \mathbf{D}_{k+1}\mathbf{u}_{k+1}))\end{aligned}$$

Reorder terms.

$$\begin{aligned}\mathbf{P}_{k+1}^+ &= \text{cov}(\mathbf{x}_{k+1} - \hat{\mathbf{x}}_{k+1}^- - \\ &\quad \mathbf{K}_{k+1}(\mathbf{C}_{k+1}\mathbf{x}_{k+1} - \mathbf{C}_{k+1}\hat{\mathbf{x}}_{k+1}^- + \mathbf{D}_{k+1}\mathbf{u}_{k+1} - \mathbf{D}_{k+1}\mathbf{u}_{k+1} + \mathbf{v}_{k+1}))\end{aligned}$$

The  $\mathbf{D}_{k+1}\mathbf{u}_{k+1}$  terms cancel.

$$\mathbf{P}_{k+1}^+ = \text{cov}(\mathbf{x}_{k+1} - \hat{\mathbf{x}}_{k+1}^- - \mathbf{K}_{k+1}(\mathbf{C}_{k+1}\mathbf{x}_{k+1} - \mathbf{C}_{k+1}\hat{\mathbf{x}}_{k+1}^- + \mathbf{v}_{k+1}))$$

Distribute  $\mathbf{K}_{k+1}$  to  $\mathbf{v}_{k+1}$ .

$$\mathbf{P}_{k+1}^+ = \text{cov}(\mathbf{x}_{k+1} - \hat{\mathbf{x}}_{k+1}^- - \mathbf{K}_{k+1}(\mathbf{C}_{k+1}\mathbf{x}_{k+1} - \mathbf{C}_{k+1}\hat{\mathbf{x}}_{k+1}^-) - \mathbf{K}_{k+1}\mathbf{v}_{k+1})$$

Factor out  $\mathbf{C}_{k+1}$ .

$$\mathbf{P}_{k+1}^+ = \text{cov}(\mathbf{x}_{k+1} - \hat{\mathbf{x}}_{k+1}^- - \mathbf{K}_{k+1}\mathbf{C}_{k+1}(\mathbf{x}_{k+1} - \hat{\mathbf{x}}_{k+1}^-) - \mathbf{K}_{k+1}\mathbf{v}_{k+1})$$

Factor out  $\mathbf{x}_{k+1} - \hat{\mathbf{x}}_{k+1}^-$  to the right.

$$\mathbf{P}_{k+1}^+ = \text{cov}((\mathbf{I} - \mathbf{K}_{k+1}\mathbf{C}_{k+1})(\mathbf{x}_{k+1} - \hat{\mathbf{x}}_{k+1}^-) - \mathbf{K}_{k+1}\mathbf{v}_{k+1})$$

Covariance is a linear operator, so it can be applied to each term separately. Covariance squares terms internally, so the negative sign on  $\mathbf{K}_{k+1}\mathbf{v}_{k+1}$  is removed.

$$\mathbf{P}_{k+1}^+ = \text{cov}((\mathbf{I} - \mathbf{K}_{k+1}\mathbf{C}_{k+1})(\mathbf{x}_{k+1} - \hat{\mathbf{x}}_{k+1}^-)) + \text{cov}(\mathbf{K}_{k+1}\mathbf{v}_{k+1})$$

Now just evaluate the covariances.

$$\begin{aligned}\mathbf{P}_{k+1}^+ &= (\mathbf{I} - \mathbf{K}_{k+1}\mathbf{C}_{k+1}) \text{cov}(\mathbf{x}_{k+1} - \hat{\mathbf{x}}_{k+1}^-)(\mathbf{I} - \mathbf{K}_{k+1}\mathbf{C}_{k+1})^T + \mathbf{K}_{k+1} \text{cov}(\mathbf{v}_{k+1})\mathbf{K}_{k+1}^T \\ \mathbf{P}_{k+1}^+ &= (\mathbf{I} - \mathbf{K}_{k+1}\mathbf{C}_{k+1})\mathbf{P}_{k+1}^-\mathbf{R}_{k+1} + \mathbf{K}_{k+1}\mathbf{R}_{k+1}\mathbf{K}_{k+1}^T\end{aligned}$$



### Finding the optimal Kalman gain

The error in the *a posteriori* state estimation is  $\mathbf{x}_{k+1} - \hat{\mathbf{x}}_{k+1}^-$ . We want to minimize the expected value of the square of the magnitude of this vector. This is equivalent to minimizing the trace of the a posteriori estimate covariance matrix  $\mathbf{P}_{k+1}^+$ .

We'll start with the equation for  $\mathbf{P}_{k+1}^+$ .

$$\mathbf{P}_{k+1}^+ = (\mathbf{I} - \mathbf{K}_{k+1} \mathbf{C}_{k+1}) \mathbf{P}_{k+1}^- (\mathbf{I} - \mathbf{K}_{k+1} \mathbf{C}_{k+1})^T + \mathbf{K}_{k+1} \mathbf{R}_{k+1} \mathbf{K}_{k+1}^T$$

We're going to expand the equation for  $\mathbf{P}_{k+1}^+$  and collect terms. First, multiply in  $\mathbf{P}_{k+1}^-$ .

$$\mathbf{P}_{k+1}^+ = (\mathbf{P}_{k+1}^- - \mathbf{K}_{k+1} \mathbf{C}_{k+1} \mathbf{P}_{k+1}^-) (\mathbf{I} - \mathbf{K}_{k+1} \mathbf{C}_{k+1})^T + \mathbf{K}_{k+1} \mathbf{R}_{k+1} \mathbf{K}_{k+1}^T$$

Transpose each term in  $\mathbf{I} - \mathbf{K}_{k+1} \mathbf{C}_{k+1}$ .  $\mathbf{I}$  is symmetric, so its transpose is dropped.

$$\mathbf{P}_{k+1}^+ = (\mathbf{P}_{k+1}^- - \mathbf{K}_{k+1} \mathbf{C}_{k+1} \mathbf{P}_{k+1}^-) (\mathbf{I} - \mathbf{C}_{k+1}^T \mathbf{K}_{k+1}^T) + \mathbf{K}_{k+1} \mathbf{R}_{k+1} \mathbf{K}_{k+1}^T$$

Multiply in  $\mathbf{I} - \mathbf{C}_{k+1}^T \mathbf{K}_{k+1}^T$ .

$$\mathbf{P}_{k+1}^+ = \mathbf{P}_{k+1}^- (\mathbf{I} - \mathbf{C}_{k+1}^T \mathbf{K}_{k+1}^T) - \mathbf{K}_{k+1} \mathbf{C}_{k+1} \mathbf{P}_{k+1}^- (\mathbf{I} - \mathbf{C}_{k+1}^T \mathbf{K}_{k+1}^T) + \mathbf{K}_{k+1} \mathbf{R}_{k+1} \mathbf{K}_{k+1}^T$$

Expand terms.

$$\begin{aligned} \mathbf{P}_{k+1}^+ &= \mathbf{P}_{k+1}^- - \mathbf{P}_{k+1}^- \mathbf{C}_{k+1}^T \mathbf{K}_{k+1}^T - \mathbf{K}_{k+1} \mathbf{C}_{k+1} \mathbf{P}_{k+1}^- + \mathbf{K}_{k+1} \mathbf{C}_{k+1} \mathbf{P}_{k+1}^- \mathbf{C}_{k+1}^T \mathbf{K}_{k+1}^T \\ &\quad + \mathbf{K}_{k+1} \mathbf{R}_{k+1} \mathbf{K}_{k+1}^T \end{aligned}$$

Factor out  $\mathbf{K}_{k+1}$  and  $\mathbf{K}_{k+1}^T$ .

$$\begin{aligned} \mathbf{P}_{k+1}^+ &= \mathbf{P}_{k+1}^- - \mathbf{P}_{k+1}^- \mathbf{C}_{k+1}^T \mathbf{K}_{k+1}^T - \mathbf{K}_{k+1} \mathbf{C}_{k+1} \mathbf{P}_{k+1}^- \\ &\quad + \mathbf{K}_{k+1} (\mathbf{C}_{k+1} \mathbf{P}_{k+1}^- \mathbf{C}_{k+1}^T + \mathbf{R}_{k+1}) \mathbf{K}_{k+1}^T \\ \mathbf{P}_{k+1}^+ &= \mathbf{P}_{k+1}^- - \mathbf{P}_{k+1}^- \mathbf{C}_{k+1}^T \mathbf{K}_{k+1}^T - \mathbf{K}_{k+1} \mathbf{C}_{k+1} \mathbf{P}_{k+1}^- + \mathbf{K}_{k+1} \mathbf{S}_{k+1} \mathbf{K}_{k+1}^T \end{aligned} \quad (9.18)$$

Now take the trace.

$$\text{tr}(\mathbf{P}_{k+1}^+) = \text{tr}(\mathbf{P}_{k+1}^-) - \text{tr}(\mathbf{P}_{k+1}^- \mathbf{C}_{k+1}^T \mathbf{K}_{k+1}^T) - \text{tr}(\mathbf{K}_{k+1} \mathbf{C}_{k+1} \mathbf{P}_{k+1}^-) + \text{tr}(\mathbf{K}_{k+1} \mathbf{S}_{k+1} \mathbf{K}_{k+1}^T)$$

Transpose one of the terms twice.

$$\text{tr}(\mathbf{P}_{k+1}^+) = \text{tr}(\mathbf{P}_{k+1}^-) - \text{tr}((\mathbf{K}_{k+1} \mathbf{C}_{k+1} \mathbf{P}_{k+1}^-)^T) - \text{tr}(\mathbf{K}_{k+1} \mathbf{C}_{k+1} \mathbf{P}_{k+1}^-) + \text{tr}(\mathbf{K}_{k+1} \mathbf{S}_{k+1} \mathbf{K}_{k+1}^T)$$

$\mathbf{P}_{k+1}^-$  is symmetric, so we can drop the transpose.

$$\text{tr}(\mathbf{P}_{k+1}^+) = \text{tr}(\mathbf{P}_{k+1}^-) - \text{tr}((\mathbf{K}_{k+1} \mathbf{C}_{k+1} \mathbf{P}_{k+1}^-)^T) - \text{tr}(\mathbf{K}_{k+1} \mathbf{C}_{k+1} \mathbf{P}_{k+1}^-) + \text{tr}(\mathbf{K}_{k+1} \mathbf{S}_{k+1} \mathbf{K}_{k+1}^T)$$

The trace of a matrix is equal to the trace of its transpose since the elements used in the trace are on the diagonal.

$$\begin{aligned} \text{tr}(\mathbf{P}_{k+1}^+) &= \text{tr}(\mathbf{P}_{k+1}^-) - \text{tr}(\mathbf{K}_{k+1} \mathbf{C}_{k+1} \mathbf{P}_{k+1}^-) - \text{tr}(\mathbf{K}_{k+1} \mathbf{C}_{k+1} \mathbf{P}_{k+1}^-) + \text{tr}(\mathbf{K}_{k+1} \mathbf{S}_{k+1} \mathbf{K}_{k+1}^T) \\ \text{tr}(\mathbf{P}_{k+1}^+) &= \text{tr}(\mathbf{P}_{k+1}^-) - 2 \text{tr}(\mathbf{K}_{k+1} \mathbf{C}_{k+1} \mathbf{P}_{k+1}^-) + \text{tr}(\mathbf{K}_{k+1} \mathbf{S}_{k+1} \mathbf{K}_{k+1}^T) \end{aligned}$$

Given theorems 9.6.1 and 9.6.2

**Theorem 9.6.1**  $\frac{\partial}{\partial \mathbf{A}} \text{tr}(\mathbf{A}\mathbf{B}\mathbf{A}^T) = 2\mathbf{A}\mathbf{B}$  where  $\mathbf{B}$  is symmetric.

**Theorem 9.6.2**  $\frac{\partial}{\partial \mathbf{A}} \text{tr}(\mathbf{A}\mathbf{C}) = \mathbf{C}^T$

find the minimum of the trace of  $\mathbf{P}_{k+1}^+$  by taking the partial derivative with respect to  $\mathbf{K}$  and setting the result to  $\mathbf{0}$ .

$$\begin{aligned}\frac{\partial \text{tr}(\mathbf{P}_{k+1}^+)}{\partial \mathbf{K}} &= \mathbf{0} - 2(\mathbf{C}_{k+1}\mathbf{P}_{k+1}^-)^T + 2\mathbf{K}_{k+1}\mathbf{S}_{k+1} \\ \frac{\partial \text{tr}(\mathbf{P}_{k+1}^+)}{\partial \mathbf{K}} &= -2\mathbf{P}_{k+1}^{-T}\mathbf{C}_{k+1}^T + 2\mathbf{K}_{k+1}\mathbf{S}_{k+1} \\ \frac{\partial \text{tr}(\mathbf{P}_{k+1}^+)}{\partial \mathbf{K}} &= -2\mathbf{P}_{k+1}^- \mathbf{C}_{k+1}^T + 2\mathbf{K}_{k+1}\mathbf{S}_{k+1} \\ \mathbf{0} &= -2\mathbf{P}_{k+1}^- \mathbf{C}_{k+1}^T + 2\mathbf{K}_{k+1}\mathbf{S}_{k+1} \\ 2\mathbf{K}_{k+1}\mathbf{S}_{k+1} &= 2\mathbf{P}_{k+1}^- \mathbf{C}_{k+1}^T \\ \mathbf{K}_{k+1}\mathbf{S}_{k+1} &= \mathbf{P}_{k+1}^- \mathbf{C}_{k+1}^T \\ \mathbf{K}_{k+1} &= \mathbf{P}_{k+1}^- \mathbf{C}_{k+1}^T \mathbf{S}_{k+1}^{-1}\end{aligned}$$

This is the optimal Kalman gain.

### Simplified *a priori* estimate covariance update equation

If the optimal Kalman gain is used, the *a posteriori* estimate covariance matrix update equation can be simplified. First, we'll manipulate the equation for the optimal Kalman gain.

$$\begin{aligned}\mathbf{K}_{k+1} &= \mathbf{P}_{k+1}^- \mathbf{C}_{k+1}^T \mathbf{S}_{k+1}^{-1} \\ \mathbf{K}_{k+1}\mathbf{S}_{k+1} &= \mathbf{P}_{k+1}^- \mathbf{C}_{k+1}^T \\ \mathbf{K}_{k+1}\mathbf{S}_{k+1}\mathbf{K}_{k+1}^T &= \mathbf{P}_{k+1}^- \mathbf{C}_{k+1}^T \mathbf{K}_{k+1}^T\end{aligned}$$

Now we'll substitute it into equation (9.18).

$$\begin{aligned}\mathbf{P}_{k+1}^+ &= \mathbf{P}_{k+1}^- - \mathbf{P}_{k+1}^- \mathbf{C}_{k+1}^T \mathbf{K}_{k+1}^T - \mathbf{K}_{k+1}\mathbf{C}_{k+1}\mathbf{P}_{k+1}^- + \mathbf{K}_{k+1}\mathbf{S}_{k+1}\mathbf{K}_{k+1}^T \\ \mathbf{P}_{k+1}^+ &= \mathbf{P}_{k+1}^- - \mathbf{P}_{k+1}^- \mathbf{C}_{k+1}^T \mathbf{K}_{k+1}^T - \mathbf{K}_{k+1}\mathbf{C}_{k+1}\mathbf{P}_{k+1}^- + (\mathbf{P}_{k+1}^- \mathbf{C}_{k+1}^T \mathbf{K}_{k+1}^T) \\ \mathbf{P}_{k+1}^+ &= \mathbf{P}_{k+1}^- - \mathbf{K}_{k+1}\mathbf{C}_{k+1}\mathbf{P}_{k+1}^-\end{aligned}$$

Factor out  $\mathbf{P}_{k+1}^-$  to the right.

$$\mathbf{P}_{k+1}^+ = (\mathbf{I} - \mathbf{K}_{k+1}\mathbf{C}_{k+1})\mathbf{P}_{k+1}^-$$

## 9.6.2 Predict and update equations

Now that we've derived all the pieces we need, we can finally write all the equations for a Kalman filter. Theorem 9.6.3 shows the predict and update steps for a Kalman filter at the  $k^{\text{th}}$  timestep.

**Theorem 9.6.3 — Kalman filter.**

Predict step

$$\hat{\mathbf{x}}_{k+1}^- = \mathbf{A}\hat{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k \quad (9.19)$$

$$\mathbf{P}_{k+1}^- = \mathbf{A}\mathbf{P}_k^- \mathbf{A}^T + \mathbf{\Gamma}\mathbf{Q}\mathbf{\Gamma}^T \quad (9.20)$$

Update step

$$\mathbf{K}_{k+1} = \mathbf{P}_{k+1}^- \mathbf{C}^T (\mathbf{C}\mathbf{P}_{k+1}^- \mathbf{C}^T + \mathbf{R})^{-1} \quad (9.21)$$

$$\hat{\mathbf{x}}_{k+1}^+ = \hat{\mathbf{x}}_{k+1}^- + \mathbf{K}_{k+1}(\mathbf{y}_{k+1} - \mathbf{C}\hat{\mathbf{x}}_{k+1}^- - \mathbf{D}\mathbf{u}_{k+1}) \quad (9.22)$$

$$\mathbf{P}_{k+1}^+ = (\mathbf{I} - \mathbf{K}_{k+1}\mathbf{C})\mathbf{P}_{k+1}^- \quad (9.23)$$

<b>A</b>	system matrix	$\hat{\mathbf{x}}$	state estimate vector
<b>B</b>	input matrix	$\mathbf{u}$	input vector
<b>C</b>	output matrix	$\mathbf{y}$	output vector
<b>D</b>	feedthrough matrix	$\mathbf{\Gamma}$	process noise intensity vector
<b>P</b>	error covariance matrix	$\mathbf{Q}$	process noise covariance matrix
<b>K</b>	Kalman gain matrix	$\mathbf{R}$	measurement noise covariance matrix

where a superscript of minus denotes *a priori* and plus denotes *a posteriori* estimate (before and after update respectively).

**C**, **D**, **Q**, and **R** from the equations derived earlier are made constants here.

- R** To implement a discrete time Kalman filter from a continuous model, the model and continuous time **Q** and **R** matrices can be *discretized* using theorem 6.7.1.

Matrix	Rows × Columns	Matrix	Rows × Columns
<b>A</b>	states × states	$\hat{\mathbf{x}}$	states × 1
<b>B</b>	states × inputs	$\mathbf{u}$	inputs × 1
<b>C</b>	outputs × states	$\mathbf{y}$	outputs × 1
<b>D</b>	outputs × inputs	$\mathbf{\Gamma}$	states × 1
<b>P</b>	states × states	<b>Q</b>	states × states
<b>K</b>	states × outputs	<b>R</b>	outputs × outputs

Table 9.2: Kalman filter matrix dimensions

Unknown *states* in a Kalman filter are generally represented by a Wiener (pronounced VEE-ner) process<sup>2</sup>. This process has the property that its variance increases linearly with time *t*.

<sup>2</sup>Explaining why we use the Wiener process would require going much more in depth into stochastic processes and Itô calculus, which is outside the scope of this book.

### 9.6.3 Setup

#### Equations to model

The following example [system](#) will be used to describe how to define and initialize the matrices for a Kalman filter.

A robot is between two parallel walls. It starts driving from one wall to the other at a velocity of  $0.8\text{cm/s}$  and uses ultrasonic sensors to provide noisy measurements of the distances to the walls in front of and behind it. To estimate the distance between the walls, we will define three [states](#): robot position, robot velocity, and distance between the walls.

$$x_{k+1} = x_k + v_k \Delta T \quad (9.24)$$

$$v_{k+1} = v_k \quad (9.25)$$

$$x_{k+1}^w = x_k^w \quad (9.26)$$

This can be converted to the following state-space [model](#).

$$\mathbf{x}_k = \begin{bmatrix} x_k \\ v_k \\ x_k^w \end{bmatrix} \quad (9.27)$$

$$\mathbf{x}_{k+1} = \begin{bmatrix} 1 & 1 & 0 \\ 0 & 0 & 0 \\ 0 & 0 & 1 \end{bmatrix} \mathbf{x}_k + \begin{bmatrix} 0 \\ 0.8 \\ 0 \end{bmatrix} + \begin{bmatrix} 0 \\ 0.1 \\ 0 \end{bmatrix} w_k \quad (9.28)$$

where the Gaussian random variable  $w_k$  has a mean of 0 and a variance of 1. The observation [model](#) is

$$\mathbf{y}_k = \begin{bmatrix} 1 & 0 & 0 \\ -1 & 0 & 1 \end{bmatrix} \mathbf{x}_k + \theta_k \quad (9.29)$$

where the covariance matrix of Gaussian measurement noise  $\theta$  is a  $2 \times 2$  matrix with both diagonals  $10\text{cm}^2$ .

The [state](#) vector is usually initialized using the first measurement or two. The covariance matrix entries are assigned by calculating the covariance of the expressions used when assigning the state vector. Let  $k = 2$ .

$$\mathbf{Q} = [1] \quad (9.30)$$

$$\mathbf{R} = \begin{bmatrix} 10 & 0 \\ 0 & 10 \end{bmatrix} \quad (9.31)$$

$$\hat{\mathbf{x}} = \begin{bmatrix} \mathbf{y}_{k,1} \\ (\mathbf{y}_{k,1} - \mathbf{y}_{k-1,1})/dt \\ \mathbf{y}_{k,1} + \mathbf{y}_{k,2} \end{bmatrix} \quad (9.32)$$

$$\mathbf{P} = \begin{bmatrix} 10 & 10/dt & 10 \\ 10/dt & 20/dt^2 & 10/dt \\ 10 & 10/dt & 20 \end{bmatrix} \quad (9.33)$$

#### Initial conditions

To fill in the  $\mathbf{P}$  matrix, we calculate the covariance of each combination of [state](#) variables. The resulting value is a measure of how much those variables are correlated. Due to how the covariance calculation works out, the covariance between two variables is the sum of the variance of matching

terms which aren't constants multiplied by any constants the two have. If no terms match, the variables are uncorrelated and the covariance is zero.

In  $\mathbf{P}_{11}$ , the terms in  $\mathbf{x}_1$  correlate with itself. Therefore,  $\mathbf{P}_{11}$  is  $\mathbf{x}_1$ 's variance, or  $\mathbf{P}_{11} = 10$ . For  $\mathbf{P}_{21}$ , One term correlates between  $\mathbf{x}_1$  and  $\mathbf{x}_2$ , so  $\mathbf{P}_{21} = \frac{10}{dt}$ . The constants from each are simply multiplied together. For  $\mathbf{P}_{22}$ , both measurements are correlated, so the variances add together. Therefore,  $\mathbf{P}_{22} = \frac{20}{dt^2}$ . It continues in this fashion until the matrix is filled up. Order doesn't matter for correlation, so the matrix is symmetric.

### Selection of priors

Choosing good priors is important for a well performing filter, even if little information is known. This applies to both the measurement noise and the noise **model**. The act of giving a **state** variable a large variance means you know something about the **system**. Namely, you aren't sure whether your initial guess is close to the true **state**. If you make a guess and specify a small variance, you are telling the filter that you are very confident in your guess. If that guess is incorrect, it will take the filter a long time to move away from your guess to the true value.

### Covariance selection

While one could assume no correlation between the **state** variables and set the covariance matrix entries to zero, this may not reflect reality. The Kalman filter is still guaranteed to converge to the steady-state covariance after an infinite time, but it will take longer than otherwise.

### Noise model selection

We typically use a Gaussian distribution for the noise **model** because the sum of many independent random variables produces a normal distribution by the central limit theorem. Kalman filters only require that the noise is zero-mean. If the true value has an equal probability of being anywhere within a certain range, use a uniform distribution instead. Each of these communicates information regarding what you know about a system in addition to what you do not.

### Process noise and measurement noise covariance selection

Recall that the process noise covariance is  $\mathbf{Q}$  and the measurement noise covariance is  $\mathbf{R}$ . To tune the elements of these, it can be helpful to take a collection of measurements, then run the Kalman filter on them offline to evaluate its performance.

The diagonal elements of  $\mathbf{R}$  are the variances of each measurement, which can be easily determined from the offline measurements. The diagonal elements of  $\mathbf{Q}$  are the variances of each **state**. They represent how much each **state** is expected to deviate from the **model**.

Selecting  $\mathbf{Q}$  is more difficult. If the data is trusted too much over the model, one risks overfitting the data. One should balance estimating any hidden **states** sufficiently with actually filtering out the noise.

### Modeling other noise colors

The Kalman filter assumes a **model** with zero-mean white noise. If the **model** is incomplete in some way, whether it's missing dynamics or assumes an incorrect noise **model**, the residual  $\tilde{\mathbf{y}} = \mathbf{y} - \mathbf{C}\hat{\mathbf{x}}$  over time will have probability characteristics not indicative of white noise (e.g., it isn't zero-mean).

To handle other colors of noise in a Kalman filter, define that color of noise in terms of white noise and augment the **model** with it.

## 9.6.4 Simulation

Figure 9.3 shows the **state** estimates and measurements of the Kalman filter over time. Figure 9.4 shows the position estimate and variance over time. Figure 9.5 shows the wall position estimate




Figure 9.3: State estimates and measurements with Kalman filter

and variance over time. Notice how the variances decrease over time as the filter gathers more measurements. This means that the filter becomes more confident in its `state` estimates.

The final precisions in estimating the position of the robot and the wall are the square roots of the corresponding elements in the covariance matrix. That is,  $0.5188\text{ m}$  and  $0.4491\text{ m}$  respectively. They are smaller than the precision of the raw measurements,  $\sqrt{10} = 3.1623\text{ m}$ . As expected, combining the information from several measurements produces a better estimate than any one measurement alone.

### 9.6.5 Kalman filter as Luenberger observer

A Kalman filter can be represented as a Luenberger `observer` by letting  $\mathbf{L} = \mathbf{A}\mathbf{K}_k$  (see appendix F.3). The Luenberger observer has a constant observer gain matrix  $\mathbf{L}$ , so the steady-state Kalman gain is used to calculate it. We will demonstrate how to find this shortly.

Kalman filter theory provides a way to place the poles of the Luenberger observer optimally in the same way we placed the poles of the controller optimally with LQR. The eigenvalues of the Kalman filter are

$$\text{eig}(\mathbf{A}(\mathbf{I} - \mathbf{K}_k\mathbf{C})) \quad (9.34)$$

#### Steady-state Kalman gain

One may have noticed that the error covariance matrix can be updated independently of the rest of the `model`. The error covariance matrix tends toward a steady-state value, and this matrix can be obtained via the discrete algebraic Riccati equation. This can then be used to compute a steady-state Kalman gain.

Snippet 9.1 computes the steady-state matrices for a Kalman filter.




Figure 9.4: Robot position estimate and variance with Kalman filter




Figure 9.5: Wall position estimate and variance with Kalman filter



```

import control as ct
import numpy as np
import scipy as sp

def kalmd(sys, Q, R):
    """Solves for the steady state kalman gain and error covariance matrices.

    Keyword arguments:
    sys -- discrete state-space model
    Q -- process noise covariance matrix
    R -- measurement noise covariance matrix

    Returns:
    Kalman gain, error covariance matrix.
    """
    m = sys.A.shape[0]

    observability_rank = np.linalg.matrix_rank(ct.obsv(sys.A, sys.C))
    if observability_rank != m:
        print(
            "Warning: Observability of %d != %d, unobservable state"
            % (observability_rank, m)
        )

    # Compute the steady state covariance matrix
    P_prior = sp.linalg.solve_discrete_are(a=sys.A.T, b=sys.C.T, q=Q, r=R)
    S = sys.C * P_prior * sys.C.T + R
    K = P_prior * sys.C.T * np.linalg.inv(S)
    P = (np.eye(m) - K * sys.C) * P_prior

    return K, P

```

Snippet 9.1. Steady-state Kalman gain and error covariance matrices calculation in Python

## 9.7 Kalman smoother

The Kalman filter uses the data up to the current time to produce an optimal estimate of the system *state*. If data beyond the current time is available, it can be ran through a Kalman smoother to produce a better estimate. This is done by recording measurements, then applying the smoother to it offline.

The Kalman smoother does a forward pass on the available data, then a backward pass through the system dynamics so it takes into account the data before and after the current time. This produces *state* variances that are lower than that of a Kalman filter.

### 9.7.1 Derivations

#### 9.7.2 State update equation

Let  $\hat{\mathbf{x}}(t)$  be the state estimate from the forward pass based on samples 0 to  $t$  and  $\hat{\mathbf{x}}_b(t)$  be the state estimate from the backward pass based on samples  $T$  to  $t$ .

$$\hat{\mathbf{x}}(t|T) = \mathbf{A}\hat{\mathbf{x}}(t) + \mathbf{A}'\hat{\mathbf{x}}_b(t) \quad (9.35)$$

where  $\mathbf{A}$  and  $\mathbf{A}'$  are weighting factors.

$$\hat{\mathbf{x}}(t|T) = \mathbf{A}\mathbf{x}(t) + \mathbf{A}\tilde{\mathbf{x}}(t) + \mathbf{A}'\mathbf{x}(t) + \mathbf{A}'\tilde{\mathbf{x}}_b(t)$$

where  $\tilde{\mathbf{x}}(t)$  represents the error in the forward state estimate and  $\tilde{\mathbf{x}}_b(t)$  represents the error in the backward state estimate.

$$\begin{aligned}\mathbf{x}(t) + \tilde{\mathbf{x}}(t|T) &= \mathbf{A}\mathbf{x}(t) + \mathbf{A}\tilde{\mathbf{x}}(t) + \mathbf{A}'\mathbf{x}(t) + \mathbf{A}'\tilde{\mathbf{x}}_b(t) \\ \tilde{\mathbf{x}}(t|T) &= \mathbf{A}\mathbf{x}(t) - \mathbf{x}(t) + \mathbf{A}\tilde{\mathbf{x}}(t) + \mathbf{A}'\mathbf{x}(t) + \mathbf{A}'\tilde{\mathbf{x}}_b(t)\end{aligned}$$

Factor out  $\mathbf{x}(t)$ .

$$\tilde{\mathbf{x}}(t|T) = (\mathbf{A} + \mathbf{A}' - \mathbf{I})\mathbf{x}(t) + \mathbf{A}\tilde{\mathbf{x}}(t) + \mathbf{A}'\tilde{\mathbf{x}}_b(t)$$

For unbiased filtering errors such as  $\tilde{\mathbf{x}}(t)$  and  $\tilde{\mathbf{x}}_b(t)$ , we want to have an unbiased smoothing error. Therefore, we set  $\mathbf{A} + \mathbf{A}' - \mathbf{I}$  to zero. This yields  $\mathbf{A}' = \mathbf{I} - \mathbf{A}$ , so

$$\tilde{\mathbf{x}}(t|T) = \mathbf{A}\tilde{\mathbf{x}}(t) + (\mathbf{I} - \mathbf{A})\tilde{\mathbf{x}}_b(t)$$

### 9.7.3 Error covariance equation

Next, find the error covariance.

$$\mathbf{P}(t|T) = \mathbf{A}\mathbf{P}(t)\mathbf{A}^T + (\mathbf{I} - \mathbf{A})\mathbf{P}_b(t)(\mathbf{I} - \mathbf{A})^T \quad (9.36)$$

Find the minimum of the trace of  $\mathbf{P}(t|T)$  by taking the partial derivative with respect to  $\mathbf{A}$  and setting the result to  $\mathbf{0}$  ( $t$  has been dropped from covariance matrices for clarity).

$$\begin{aligned}\mathbf{0} &= 2\mathbf{A}\mathbf{P} + 2(\mathbf{I} - \mathbf{A})\mathbf{P}_b(-\mathbf{I}) \\ \mathbf{0} &= 2\mathbf{A}\mathbf{P} - 2(\mathbf{I} - \mathbf{A})\mathbf{P}_b \\ \mathbf{0} &= \mathbf{A}\mathbf{P} - (\mathbf{I} - \mathbf{A})\mathbf{P}_b \\ \mathbf{0} &= \mathbf{A}\mathbf{P} - (\mathbf{P}_b - \mathbf{A}\mathbf{P}_b) \\ \mathbf{0} &= \mathbf{A}\mathbf{P} - \mathbf{P}_b + \mathbf{A}\mathbf{P}_b \\ \mathbf{0} &= \mathbf{A}(\mathbf{P} + \mathbf{P}_b) - \mathbf{P}_b \\ \mathbf{A}(\mathbf{P} + \mathbf{P}_b) &= \mathbf{P}_b \\ \mathbf{A} &= \mathbf{P}_b(\mathbf{P} + \mathbf{P}_b)^{-1}\end{aligned} \quad (9.37)$$

$$\begin{aligned}\mathbf{I} - \mathbf{A} &= \mathbf{I} - \mathbf{P}_b(\mathbf{P} + \mathbf{P}_b)^{-1} \\ \mathbf{I} - \mathbf{A} &= (\mathbf{P} + \mathbf{P}_b)(\mathbf{P} + \mathbf{P}_b)^{-1} - \mathbf{P}_b(\mathbf{P} + \mathbf{P}_b)^{-1} \\ \mathbf{I} - \mathbf{A} &= (\mathbf{P} + \mathbf{P}_b - \mathbf{P}_b)(\mathbf{P} + \mathbf{P}_b)^{-1} \\ \mathbf{I} - \mathbf{A} &= \mathbf{P}(\mathbf{P} + \mathbf{P}_b)^{-1}\end{aligned} \quad (9.38)$$

$$\begin{aligned}\mathbf{A}^T &= (\mathbf{P}_b(\mathbf{P} + \mathbf{P}_b)^{-1})^T \\ \mathbf{A}^T &= ((\mathbf{P} + \mathbf{P}_b)^{-1})^T \mathbf{P}_b^T \\ \mathbf{A}^T &= ((\mathbf{P} + \mathbf{P}_b)^T)^{-1} \mathbf{P}_b^T \\ \mathbf{A}^T &= (\mathbf{P}^T + \mathbf{P}_b^T)^{-1} \mathbf{P}_b^T\end{aligned}$$

Covariance matrices are symmetric, so

$$\mathbf{A}^T = (\mathbf{P} + \mathbf{P}_b)^{-1} \mathbf{P}_b \quad (9.39)$$

$$\begin{aligned}
(\mathbf{I} - \mathbf{A})^T &= (\mathbf{P}(\mathbf{P} + \mathbf{P}_b)^{-1})^T \\
(\mathbf{I} - \mathbf{A})^T &= ((\mathbf{P} + \mathbf{P}_b)^{-1})^T \mathbf{P}^T \\
(\mathbf{I} - \mathbf{A})^T &= ((\mathbf{P} + \mathbf{P}_b)^T)^{-1} \mathbf{P}^T \\
(\mathbf{I} - \mathbf{A})^T &= (\mathbf{P}^T + \mathbf{P}_b^T)^{-1} \mathbf{P}^T
\end{aligned}$$

Covariance matrices are symmetric, so

$$(\mathbf{I} - \mathbf{A})^T = (\mathbf{P} + \mathbf{P}_b)^{-1} \mathbf{P} \quad (9.40)$$

Now starting from equation (9.36), substitute in equations (9.37) through (9.40).

$$\begin{aligned}
\mathbf{P}(t|T) &= \mathbf{A} \mathbf{P} \mathbf{A}^T + (\mathbf{I} - \mathbf{A}) \mathbf{P}_b (\mathbf{I} - \mathbf{A})^T \\
\mathbf{P}(t|T) &= (\mathbf{P}_b (\mathbf{P} + \mathbf{P}_b)^{-1}) \mathbf{P} ((\mathbf{P} + \mathbf{P}_b)^{-1} \mathbf{P}_b) + (\mathbf{P} (\mathbf{P} + \mathbf{P}_b)^{-1}) \mathbf{P}_b ((\mathbf{P} + \mathbf{P}_b)^{-1} \mathbf{P}) \\
\mathbf{P}(t|T) &= \mathbf{P}_b (\mathbf{P} + \mathbf{P}_b)^{-1} \mathbf{P} (\mathbf{P} + \mathbf{P}_b)^{-1} \mathbf{P}_b + \mathbf{P} (\mathbf{P} + \mathbf{P}_b)^{-1} \mathbf{P}_b (\mathbf{P} + \mathbf{P}_b)^{-1} \mathbf{P}
\end{aligned}$$

Apply theorem 9.7.1 to the right sides of each term to combine them.

$$\text{Theorem 9.7.1} \quad \mathbf{A} \mathbf{B} = (\mathbf{B}^{-1} \mathbf{A}^{-1})^{-1}$$

$$\begin{aligned}
\mathbf{P}(t|T) &= \mathbf{P}_b (\mathbf{P} + \mathbf{P}_b)^{-1} \mathbf{P} (\mathbf{P}_b^{-1} (\mathbf{P} + \mathbf{P}_b))^{-1} + \mathbf{P} (\mathbf{P} + \mathbf{P}_b)^{-1} \mathbf{P}_b (\mathbf{P}^{-1} (\mathbf{P} + \mathbf{P}_b))^{-1} \\
\mathbf{P}(t|T) &= \mathbf{P}_b (\mathbf{P} + \mathbf{P}_b)^{-1} \mathbf{P} (\mathbf{P}_b^{-1} \mathbf{P} + \mathbf{I})^{-1} + \mathbf{P} (\mathbf{P} + \mathbf{P}_b)^{-1} \mathbf{P}_b (\mathbf{I} + \mathbf{P}^{-1} \mathbf{P}_b)^{-1}
\end{aligned}$$

Apply theorem 9.7.1 to the right sides of each term again.

$$\begin{aligned}
\mathbf{P}(t|T) &= \mathbf{P}_b (\mathbf{P} + \mathbf{P}_b)^{-1} ((\mathbf{P}_b^{-1} \mathbf{P} + \mathbf{I}) \mathbf{P}^{-1})^{-1} + \mathbf{P} (\mathbf{P} + \mathbf{P}_b)^{-1} ((\mathbf{I} + \mathbf{P}^{-1} \mathbf{P}_b) \mathbf{P}_b^{-1})^{-1} \\
\mathbf{P}(t|T) &= \mathbf{P}_b (\mathbf{P} + \mathbf{P}_b)^{-1} (\mathbf{P}_b^{-1} + \mathbf{P}^{-1})^{-1} + \mathbf{P} (\mathbf{P} + \mathbf{P}_b)^{-1} (\mathbf{P}_b^{-1} + \mathbf{P}^{-1})^{-1} \\
\mathbf{P}(t|T) &= \mathbf{P}_b (\mathbf{P} + \mathbf{P}_b)^{-1} (\mathbf{P}^{-1} + \mathbf{P}_b^{-1})^{-1} + \mathbf{P} (\mathbf{P} + \mathbf{P}_b)^{-1} (\mathbf{P}^{-1} + \mathbf{P}_b^{-1})^{-1}
\end{aligned}$$

Factor out  $(\mathbf{P}^{-1} + \mathbf{P}_b^{-1})^{-1}$  to the right.

$$\mathbf{P}(t|T) = (\mathbf{P}_b (\mathbf{P} + \mathbf{P}_b)^{-1} + \mathbf{P} (\mathbf{P} + \mathbf{P}_b)^{-1}) (\mathbf{P}^{-1} + \mathbf{P}_b^{-1})^{-1}$$

Factor out  $(\mathbf{P} + \mathbf{P}_b)^{-1}$  to the right.

$$\begin{aligned}
\mathbf{P}(t|T) &= (\mathbf{P}_b + \mathbf{P}) (\mathbf{P} + \mathbf{P}_b)^{-1} (\mathbf{P}^{-1} + \mathbf{P}_b^{-1})^{-1} \\
\mathbf{P}(t|T) &= (\mathbf{P} + \mathbf{P}_b) (\mathbf{P} + \mathbf{P}_b)^{-1} (\mathbf{P}^{-1} + \mathbf{P}_b^{-1})^{-1} \\
\mathbf{P}(t|T) &= \mathbf{I} (\mathbf{P}^{-1} + \mathbf{P}_b^{-1})^{-1} \\
\mathbf{P}(t|T) &= (\mathbf{P}(t)^{-1} + \mathbf{P}_b(t)^{-1})^{-1} \quad (9.41)
\end{aligned}$$

#### 9.7.4 Optimal estimate

Now find the optimal estimate  $\hat{\mathbf{x}}(t|T)$  starting from equation (9.35).

$$\begin{aligned}
\hat{\mathbf{x}}(t|T) &= \mathbf{A} \hat{\mathbf{x}}(t) + \mathbf{A}' \hat{\mathbf{x}}_b(t) \\
\hat{\mathbf{x}}(t|T) &= \mathbf{A} \hat{\mathbf{x}}(t) + (\mathbf{I} - \mathbf{A}) \hat{\mathbf{x}}_b(t)
\end{aligned}$$

$$\begin{aligned}\hat{\mathbf{x}}(t|T) &= \mathbf{P}_b(\mathbf{P} + \mathbf{P}_b)^{-1}\hat{\mathbf{x}}(t) + \mathbf{P}(\mathbf{P} + \mathbf{P}_b)^{-1}\hat{\mathbf{x}}_b(t) \\ \hat{\mathbf{x}}(t|T) &= \mathbf{P}_b(\mathbf{P} + \mathbf{P}_b)^{-1}\mathbf{P}\mathbf{P}^{-1}\hat{\mathbf{x}}(t) + \mathbf{P}(\mathbf{P} + \mathbf{P}_b)^{-1}\mathbf{P}_b\mathbf{P}_b^{-1}\hat{\mathbf{x}}_b(t)\end{aligned}$$

Apply theorem 9.7.1.

$$\begin{aligned}\hat{\mathbf{x}}(t|T) &= \mathbf{P}_b(\mathbf{P}^{-1}(\mathbf{P} + \mathbf{P}_b))^{-1}\mathbf{P}^{-1}\hat{\mathbf{x}}(t) + \mathbf{P}(\mathbf{P}_b^{-1}(\mathbf{P} + \mathbf{P}_b))^{-1}\mathbf{P}_b^{-1}\hat{\mathbf{x}}_b(t) \\ \hat{\mathbf{x}}(t|T) &= \mathbf{P}_b(\mathbf{I} + \mathbf{P}^{-1}\mathbf{P}_b)^{-1}\mathbf{P}^{-1}\hat{\mathbf{x}}(t) + \mathbf{P}(\mathbf{P}_b^{-1}\mathbf{P} + \mathbf{I})^{-1}\mathbf{P}_b^{-1}\hat{\mathbf{x}}_b(t)\end{aligned}$$

Apply theorem 9.7.1 again.

$$\begin{aligned}\hat{\mathbf{x}}(t|T) &= ((\mathbf{I} + \mathbf{P}^{-1}\mathbf{P}_b)\mathbf{P}_b^{-1})^{-1}\mathbf{P}^{-1}\hat{\mathbf{x}}(t) + ((\mathbf{P}_b^{-1}\mathbf{P} + \mathbf{I})\mathbf{P}^{-1})^{-1}\mathbf{P}_b^{-1}\hat{\mathbf{x}}_b(t) \\ \hat{\mathbf{x}}(t|T) &= (\mathbf{P}_b^{-1} + \mathbf{P}^{-1})^{-1}\mathbf{P}^{-1}\hat{\mathbf{x}}(t) + (\mathbf{P}_b^{-1} + \mathbf{P}^{-1})^{-1}\mathbf{P}_b^{-1}\hat{\mathbf{x}}_b(t)\end{aligned}$$

Factor out  $(\mathbf{P}_b^{-1} + \mathbf{P}^{-1})^{-1}$  to the left.

$$\hat{\mathbf{x}}(t|T) = (\mathbf{P}_b^{-1} + \mathbf{P}^{-1})^{-1}(\mathbf{P}^{-1}\hat{\mathbf{x}}(t) + \mathbf{P}_b^{-1}\hat{\mathbf{x}}_b(t))$$

Substitute in equation (9.41).

$$\begin{aligned}\hat{\mathbf{x}}(t|T) &= \mathbf{P}(t|T)(\mathbf{P}^{-1}\hat{\mathbf{x}}(t) + \mathbf{P}_b^{-1}\hat{\mathbf{x}}_b(t)) \\ \hat{\mathbf{x}}(t|T) &= \mathbf{P}(t|T)(\mathbf{P}^{-1}(t)\hat{\mathbf{x}}(t) + \mathbf{P}_b^{-1}(t)\hat{\mathbf{x}}_b(t))\end{aligned}\tag{9.42}$$

### 9.7.5 Predict and update equations

One first does a forward pass with the typical Kalman filter equations and stores the results. Then one can use the Rauch-Tung-Striebel (RTS) algorithm to do the backward pass (see theorem 9.7.2).

Theorem 9.7.2 shows the predict and update steps for the forward and backward passes for a Kalman smoother at the  $k^{\text{th}}$  timestep.

#### Theorem 9.7.2 — Kalman smoother.

Forward predict step

$$\hat{\mathbf{x}}_{k+1}^- = \mathbf{A}\hat{\mathbf{x}}_k + \mathbf{B}\mathbf{u}_k\tag{9.43}$$

$$\mathbf{P}_{k+1}^- = \mathbf{A}\mathbf{P}_k^- \mathbf{A}^T + \mathbf{\Gamma}\mathbf{Q}\mathbf{\Gamma}^T\tag{9.44}$$

Forward update step

$$\mathbf{K}_{k+1} = \mathbf{P}_{k+1}^- \mathbf{C}^T (\mathbf{C}\mathbf{P}_{k+1}^- \mathbf{C}^T + \mathbf{R})^{-1}\tag{9.45}$$

$$\hat{\mathbf{x}}_{k+1}^+ = \hat{\mathbf{x}}_{k+1}^- + \mathbf{K}_{k+1}(\mathbf{y}_{k+1} - \mathbf{C}\hat{\mathbf{x}}_{k+1}^- - \mathbf{D}\mathbf{u}_{k+1})\tag{9.46}$$

$$\mathbf{P}_{k+1}^+ = (\mathbf{I} - \mathbf{K}_{k+1}\mathbf{C})\mathbf{P}_{k+1}^-\tag{9.47}$$

Backward update step

$$\mathbf{K}_k = \mathbf{P}_k^+ \mathbf{A}_k^T (\mathbf{P}_{k+1}^-)^{-1}\tag{9.48}$$

$$\hat{\mathbf{x}}_{k|N} = \hat{\mathbf{x}}_k^+ + \mathbf{K}_k(\hat{\mathbf{x}}_{k+1|N} - \hat{\mathbf{x}}_{k+1}^-)\tag{9.49}$$

$$\mathbf{P}_{k|N} = \mathbf{P}_k^+ + \mathbf{K}_k(\mathbf{P}_{k+1|N} - \mathbf{P}_{k+1}^-)\mathbf{K}_k^T\tag{9.50}$$

Backward initial conditions

$$\hat{\mathbf{x}}_{N|N} = \hat{\mathbf{x}}_N^+\tag{9.51}$$

$$\mathbf{P}_{N|N} = \mathbf{P}_N^+\tag{9.52}$$




Figure 9.6: Robot position with Kalman smoother

### 9.7.6 Example

We will modify the robot model so that instead of a velocity of  $0.8\text{cm/s}$  with random noise, the velocity is modeled as a random walk from the current velocity.

$$\mathbf{x}_k = \begin{bmatrix} x_k \\ v_k \\ x_k^w \end{bmatrix} \quad (9.53)$$

$$\mathbf{x}_{k+1} = \begin{bmatrix} 1 & 1 & 0 \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix} \mathbf{x}_k + \begin{bmatrix} 0 \\ 0.1 \\ 0 \end{bmatrix} w_k \quad (9.54)$$

We will use the same observation model as before.

Using the same data from subsection 9.6.4, figures 9.6, 9.7, and 9.8 show the improved *state* estimates and figure 9.9 shows the improved robot position covariance with a Kalman smoother.

Notice how the wall position produced by the smoother is a constant. This is because that *state* has no dynamics, so the final estimate from the Kalman filter is already the best estimate.

See Roger Labbe's book *Kalman and Bayesian Filters in Python* for more on smoothing<sup>3</sup>.

<sup>3</sup><https://github.com/rllabbe/Kalman-and-Bayesian-Filters-in-Python/blob/master/13-Smoothing.ipynb>




Figure 9.7: Robot velocity with Kalman smoother




Figure 9.8: Wall position with Kalman smoother




Figure 9.9: Robot position variance with Kalman smoother

## 9.8 Extended Kalman filter

In this book, we have covered the Kalman filter, which is the optimal unbiased estimator for linear systems. It isn't optimal for nonlinear systems, but several extensions to it have been developed to make it more accurate.

The extended Kalman filter linearizes the matrices used during the prediction step.  $\mathbf{A}$ ,  $\mathbf{B}$ ,  $\mathbf{C}$ , and  $\mathbf{D}$  are linearized as follows:

$$\mathbf{A} \approx \frac{\partial f(\mathbf{x}, \mathbf{u})}{\partial \mathbf{x}} \quad \mathbf{B} \approx \frac{\partial f(\mathbf{x}, \mathbf{u})}{\partial \mathbf{u}} \quad \mathbf{C} \approx \frac{\partial h(\mathbf{x}, \mathbf{u})}{\partial \mathbf{x}} \quad \mathbf{D} \approx \frac{\partial h(\mathbf{x}, \mathbf{u})}{\partial \mathbf{u}}$$

From there, the continuous Kalman filter equations are used like normal to compute the error covariance matrix  $\mathbf{P}$  and Kalman gain matrix. The state estimate update can still use the function  $h(\mathbf{x})$  for accuracy.

$$\hat{\mathbf{x}}_{k+1}^+ = \hat{\mathbf{x}}_{k+1}^- + \mathbf{K}_{k+1}(\mathbf{y}_{k+1} - h(\hat{\mathbf{x}}_{k+1}^-))$$

## 9.9 Unscented Kalman filter

In this book, we have covered the Kalman filter, which is the optimal unbiased estimator for linear systems. It isn't optimal for nonlinear systems, but several extensions to it have been developed to make it more accurate.

The unscented Kalman filter propagates carefully chosen points called sigma points through the non-linear state and measurement models to obtain estimates of the true covariances (as opposed to linearized versions of them). We recommend reading Roger Labbe's book *Kalman and Bayesian Filters in Python* for more on unscented Kalman filters<sup>4</sup>.

<sup>4</sup><https://github.com/rlabbe/Kalman-and-Bayesian-Filters-in-Python/blob/master/10-Unscented-Kalman-Filter.ipynb>



The original paper on the unscented Kalman filter is also an option [19]. The equations for van der Merwe's sigma point algorithm are in [34]. Here's a paper on a quaternion-based Unscented Kalman filter for orientation tracking [22].

## 9.10 Multiple model adaptive estimation

Multiple model adaptive estimation (MMAE) runs multiple Kalman filters with different **models** on the same data. The Kalman filter with the lowest residual has the highest likelihood of accurately reflecting reality. This can be used to detect certain **system states** like an aircraft engine failing without needing to invest in costly sensors to determine this directly.

For example, say you have three Kalman filters: one for turning left, one for turning right, and one for going straight. If the **control input** is attempting to fly the plane straight and the Kalman filter for going left has the lowest residual, the aircraft's left engine probably failed.

See Roger Labbe's book *Kalman and Bayesian Filters in Python* for more on MMAE<sup>5</sup>.

---

<sup>5</sup>MMAE section of <https://github.com/rlabbe/Kalman-and-Bayesian-Filters-in-Python/blob/master/14-Adaptive-Filtering.ipynb>

*This page intentionally left blank*

## 10. Pose estimation

Pose is a term for the orientation of an **agent** (a system with a controller). The plant usually includes the pose in its state vector. We'll cover several methods for estimating an agent's pose from local measurements such as encoders and gyroscope heading.

### 10.1 Euler integration

The simplest way to perform pose estimation via dead reckoning (that is, no direct measurements of the pose are used) is to integrate the velocity in each orthogonal direction over time. In two dimensions, one could use

$$\begin{aligned}x_{k+1} &= x_k + v_k \cos \theta_k T \\y_{k+1} &= y_k + v_k \sin \theta_k T \\ \theta_{k+1} &= \theta_{gyro,k+1}\end{aligned}$$

where  $T$  is the sample period. This odometry approach assumes that the robot follows a straight path between samples (that is,  $\omega = 0$  at all but the sample times).

### 10.2 Pose exponential

We can obtain a more accurate approximation of the pose by including first-order dynamics for the heading  $\theta$ . To provide a rationale for the math we're about to do, we need to cover some aspects of group theory.

#### 10.2.1 What is a group?

In mathematics, a group is a set equipped with a binary operation (an operation with two arguments) that combines any two elements (of the set) to form a third element in such a way that four conditions called *group axioms* are satisfied: closure, associativity, identity, and invertibility.

*Closure* means that the result is in the same set as the arguments.

*Associativity* means that within an expression containing two or more occurrences in a row of the same associative operator, the order in which the operations are performed does not matter as long as the sequence of the operands is not changed. In other words, different groupings of the operations produces the same result.

*Identity*, or an identity element, is a special type of element of a set with respect to a binary operation on that set, which leaves any element of the set unchanged when combined with it. For example, the additive identity of the set of integers is zero, which means that any integer summed with zero produces that integer.

*Invertibility* means there is an element that can “undo” the effect of combination with another given element. For integers and the addition operator, the inverse element would be the negation.

### 10.2.2 What is a pose?

To develop what a pose is in group theory, we need to define a few key groups.  $SO(2)$  is the special orthogonal group in dimension 2. They represent a 2D rotation.

$SE(2)$  is the special euclidean group in dimension 2. They represent a 2D rotation and a 2D translation, which we call a 2D pose. In other words, pose is an element of  $SE(2)$ .

### 10.2.3 What is a twist?

A 2D twist is an element of the tangent space of  $SE(2)$  (like the tangential distance traveled by the robot along an arc in  $SE(2)$ ). We use the “pose exponential” to map a twist (an element of the tangent space) to an element of  $SE(2)$ . In other words, we map a twist to a pose.

We call it a pose exponential because it’s an exponential map onto a pose. The term exponential is used because the solution for integrating a change in something (like a slope or tangent) over time is usually an exponential. For example,  $\frac{dx}{dt} = ax$  has the solution  $x = x_0 e^{at}$ .

We use the pose exponential to take encoder measurement deltas and gyro angle deltas (which are in the tangent space and are thus a twist) and turn them into a change in pose. This gets added to the pose from the last update.

### 10.2.4 Derivation

We can obtain a more accurate approximation of the pose than Euler integration by including first-order dynamics for the heading  $\theta$ .

$$\mathbf{x} = \begin{bmatrix} x \\ y \\ \theta \end{bmatrix}$$

$v_x$ ,  $v_y$ , and  $\omega$  are the  $x$  and  $y$  velocities of the robot within its local coordinate frame, which will be treated as constants.

**R** There are two coordinate frames used here: robot and global. A superscript on the left side of a matrix denotes the coordinate frame in which that matrix is represented. The robot’s coordinate frame is denoted by  $R$  and the global coordinate frame is denoted by  $G$ .

In the robot frame (the tangent space)

$$\begin{aligned} {}^R dx &= {}^R v_x dt \\ {}^R dy &= {}^R v_y dt \end{aligned}$$

$${}^R d\theta = R_\omega dt$$

To transform this into the global frame SE(2), we apply a counterclockwise rotation matrix where  $\theta$  changes over time.

$${}^G \begin{bmatrix} dx \\ dy \\ d\theta \end{bmatrix} = \begin{bmatrix} \cos \theta(t) & -\sin \theta(t) & 0 \\ \sin \theta(t) & \cos \theta(t) & 0 \\ 0 & 0 & 1 \end{bmatrix} {}^R \begin{bmatrix} v_x \\ v_y \\ \omega \end{bmatrix} dt$$

$${}^G \begin{bmatrix} dx \\ dy \\ d\theta \end{bmatrix} = \begin{bmatrix} \cos \omega t & -\sin \omega t & 0 \\ \sin \omega t & \cos \omega t & 0 \\ 0 & 0 & 1 \end{bmatrix} {}^R \begin{bmatrix} v_x \\ v_y \\ \omega \end{bmatrix} dt$$

Now, integrate the matrix equation (matrices are integrated element-wise). This derivation heavily utilizes the integration method described in section 11.2.1.

$${}^G \begin{bmatrix} \Delta x \\ \Delta y \\ \Delta \theta \end{bmatrix} = \begin{bmatrix} \frac{\sin \omega t}{\omega} & \frac{\cos \omega t}{\omega} & 0 \\ -\frac{\cos \omega t}{\omega} & \frac{\sin \omega t}{\omega} & 0 \\ 0 & 0 & t \end{bmatrix} {}^R \begin{bmatrix} v_x \\ v_y \\ \omega \end{bmatrix} \Big|_0^t$$

$${}^G \begin{bmatrix} \Delta x \\ \Delta y \\ \Delta \theta \end{bmatrix} = \begin{bmatrix} \frac{\sin \omega t}{\omega} & \frac{\cos \omega t - 1}{\omega} & 0 \\ \frac{1 - \cos \omega t}{\omega} & \frac{\sin \omega t}{\omega} & 0 \\ 0 & 0 & t \end{bmatrix} {}^R \begin{bmatrix} v_x \\ v_y \\ \omega \end{bmatrix}$$

This equation assumes a starting orientation of  $\theta = 0$ . For nonzero starting orientations, we can apply a counterclockwise rotation by  $\theta$ .

$${}^G \begin{bmatrix} \Delta x \\ \Delta y \\ \Delta \theta \end{bmatrix} = \begin{bmatrix} \cos \theta & -\sin \theta & 0 \\ \sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} \frac{\sin \omega t}{\omega} & \frac{\cos \omega t - 1}{\omega} & 0 \\ \frac{1 - \cos \omega t}{\omega} & \frac{\sin \omega t}{\omega} & 0 \\ 0 & 0 & t \end{bmatrix} {}^R \begin{bmatrix} v_x \\ v_y \\ \omega \end{bmatrix} \quad (10.1)$$

If we factor out a  $t$ , we can use change in pose between updates instead of velocities.

$${}^G \begin{bmatrix} \Delta x \\ \Delta y \\ \Delta \theta \end{bmatrix} = \begin{bmatrix} \cos \theta & -\sin \theta & 0 \\ \sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} \frac{\sin \omega t}{\omega} & \frac{\cos \omega t - 1}{\omega} & 0 \\ \frac{1 - \cos \omega t}{\omega} & \frac{\sin \omega t}{\omega} & 0 \\ 0 & 0 & t \end{bmatrix} {}^R \begin{bmatrix} v_x \\ v_y \\ \omega \end{bmatrix}$$

$${}^G \begin{bmatrix} \Delta x \\ \Delta y \\ \Delta \theta \end{bmatrix} = \begin{bmatrix} \cos \theta & -\sin \theta & 0 \\ \sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} \frac{\sin \omega t}{\omega t} & \frac{\cos \omega t - 1}{\omega t} & 0 \\ \frac{1 - \cos \omega t}{\omega t} & \frac{\sin \omega t}{\omega t} & 0 \\ 0 & 0 & 1 \end{bmatrix} {}^R \begin{bmatrix} v_x \\ v_y \\ \omega \end{bmatrix} t$$

$${}^G \begin{bmatrix} \Delta x \\ \Delta y \\ \Delta \theta \end{bmatrix} = \begin{bmatrix} \cos \theta & -\sin \theta & 0 \\ \sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} \frac{\sin \omega t}{\omega t} & \frac{\cos \omega t - 1}{\omega t} & 0 \\ \frac{1 - \cos \omega t}{\omega t} & \frac{\sin \omega t}{\omega t} & 0 \\ 0 & 0 & 1 \end{bmatrix} {}^R \begin{bmatrix} v_x t \\ v_y t \\ \omega t \end{bmatrix}$$

$${}^G \begin{bmatrix} \Delta x \\ \Delta y \\ \Delta \theta \end{bmatrix} = \begin{bmatrix} \cos \theta & -\sin \theta & 0 \\ \sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} {}^R \begin{bmatrix} \frac{\sin \Delta \theta}{\Delta \theta} & \frac{\cos \Delta \theta - 1}{\Delta \theta} & 0 \\ \frac{1 - \cos \Delta \theta}{\Delta \theta} & \frac{\sin \Delta \theta}{\Delta \theta} & 0 \\ 0 & 0 & 1 \end{bmatrix} {}^R \begin{bmatrix} \Delta x \\ \Delta y \\ \Delta \theta \end{bmatrix} \quad (10.2)$$

The vector  ${}^R [\Delta x \ \Delta y \ \Delta \theta]^T$  is a twist because it's an element of the tangent space (the robot's local coordinate frame).

Equation (10.1) used the current velocity and projected the model forward to the next timestep (into the future). As such, the prediction must be done after any controller calculations are performed. With equation (10.2), the locally measured pose deltas can only be measured using past samples, so the model update must be performed before any controller calculations to advance the model to the current timestep.

When the robot is traveling on a straight trajectory ( $\omega = 0$ ), some expressions within the equation above are indeterminate. We can approximate these with Taylor series expansions.

$$\begin{aligned}\frac{\sin \omega t}{\omega} &= t - \frac{t^3 \omega^2}{6} + \dots \\ \frac{\sin \omega t}{\omega} &\sim t - \frac{t^3 \omega^2}{6} \\ \frac{\cos \omega t - 1}{\omega} &= -\frac{t^2 \omega}{2} + \frac{t^4 \omega^3}{4} - \dots \\ \frac{\cos \omega t - 1}{\omega} &\sim -\frac{t^2 \omega}{2} \\ \frac{1 - \cos \omega t}{\omega} &= \frac{t^2 \omega}{2} - \frac{t^4 \omega^3}{4} + \dots \\ \frac{1 - \cos \omega t}{\omega} &\sim \frac{t^2 \omega}{2}\end{aligned}$$

If we let  $\omega = 0$ , we should get the standard kinematic equations like  $x = vt$  with a rotation applied to them.

$$\begin{aligned}\frac{\sin \omega t}{\omega} &\sim t - \frac{t^3 \cdot 0^2}{6} = t \\ \frac{\cos \omega t - 1}{\omega} &\sim -\frac{t^2 \cdot 0}{2} = 0 \\ \frac{1 - \cos \omega t}{\omega} &\sim \frac{t^2 \cdot 0}{2} = 0\end{aligned}$$

Now substitute these into equation (10.3).

$$\begin{aligned}{}^G \begin{bmatrix} \Delta x \\ \Delta y \\ \Delta \theta \end{bmatrix} &= \begin{bmatrix} \cos \theta & -\sin \theta & 0 \\ \sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} t & 0 & 0 \\ 0 & t & 0 \\ 0 & 0 & t \end{bmatrix} {}^R \begin{bmatrix} v_x \\ v_y \\ \omega \end{bmatrix} \\ {}^G \begin{bmatrix} \Delta x \\ \Delta y \\ \Delta \theta \end{bmatrix} &= \begin{bmatrix} \cos \theta & -\sin \theta & 0 \\ \sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} v_x t \\ v_y t \\ \omega t \end{bmatrix}\end{aligned}$$

As expected, the equations simplify to the first-order case with a rotation matrix applied to the velocities in the robot's local coordinate frame.

Differential drive robots have  $v_y = 0$  since they only move in the direction of the current heading, which is along the x-axis. Therefore,

$${}^G \begin{bmatrix} \Delta x \\ \Delta y \\ \Delta \theta \end{bmatrix} = \begin{bmatrix} \cos \theta & -\sin \theta & 0 \\ \sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} v_x t \\ 0 \\ \omega t \end{bmatrix}$$



$${}^G \begin{bmatrix} \Delta x \\ \Delta y \\ \Delta \theta \end{bmatrix} = \begin{bmatrix} v_x t \cos \theta \\ v_y t \sin \theta \\ \omega t \end{bmatrix}$$

**Theorem 10.2.1 — Pose exponential.**

$${}^G \begin{bmatrix} \Delta x \\ \Delta y \\ \Delta \theta \end{bmatrix} = \begin{bmatrix} \cos \theta & -\sin \theta & 0 \\ \sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} \frac{\sin \omega t}{\omega} & \frac{\cos \omega t - 1}{\omega} & 0 \\ \frac{1 - \cos \omega t}{\omega} & \frac{\sin \omega t}{\omega} & 0 \\ 0 & 0 & t \end{bmatrix} {}^R \begin{bmatrix} v_x \\ v_y \\ \omega \end{bmatrix} \quad (10.3)$$

or

$${}^G \begin{bmatrix} \Delta x \\ \Delta y \\ \Delta \theta \end{bmatrix} = \begin{bmatrix} \cos \theta & -\sin \theta & 0 \\ \sin \theta & \cos \theta & 0 \\ 0 & 0 & 1 \end{bmatrix} {}^R \begin{bmatrix} \frac{\sin \Delta \theta}{\Delta \theta} & \frac{\cos \Delta \theta - 1}{\Delta \theta} & 0 \\ \frac{1 - \cos \Delta \theta}{\Delta \theta} & \frac{\sin \Delta \theta}{\Delta \theta} & 0 \\ 0 & 0 & 1 \end{bmatrix} {}^R \begin{bmatrix} \Delta x \\ \Delta y \\ \Delta \theta \end{bmatrix} \quad (10.4)$$

where  $G$  denotes global coordinate frame and  $R$  denotes robot's coordinate frame.

For sufficiently small  $\omega$ :

$$\frac{\sin \omega t}{\omega} = t - \frac{t^3 \omega^2}{6} \quad \frac{\cos \omega t - 1}{\omega} = -\frac{t^2 \omega}{2} \quad \frac{1 - \cos \omega t}{\omega} = \frac{t^2 \omega}{2} \quad (10.5)$$

$$\frac{\sin \omega t}{\omega t} = 1 - \frac{t^2 \omega^2}{6} \quad \frac{\cos \omega t - 1}{\omega t} = -\frac{t \omega}{2} \quad \frac{1 - \cos \omega t}{\omega t} = \frac{t \omega}{2} \quad (10.6)$$

$\Delta x$	change in pose's $x$	$v_x$	velocity along $x$ -axis
$\Delta y$	change in pose's $y$	$v_y$	velocity along $y$ -axis
$\Delta \theta$	change in pose's $\theta$	$\omega$	angular velocity
$t$	Time since last pose update	$\theta$	starting angle in global coordinate frame

This change in pose can be added directly to the previous pose estimate to update it.

Figure 10.1 shows the error in the global pose coordinates over time for the simpler odometry method compared to the method using twists (uses the Ramsete controller from subsection 8.7).

The highest error is  $4cm$  in  $x$  over a  $10m$  path starting with a  $2m$  displacement. The difference would be even more noticeable for paths with higher curvatures and longer durations. One mitigation is using a smaller update period. However, there are bigger sources of error like turning scrub on skid steer robots that should be dealt with before odometry numerical accuracy.

**10.2.5 Lie groups**

While we avoided the topic in our explanation, pose is what's known as a Lie group (a group that is also a differentiable manifold). There's a lot of mathematical and controls results developed around Lie groups, so we're mentioning the connection here in case you want to search the Internet for more information.




Figure 10.1: Odometry error compared to method using twists ( $dt = 0.05s$ )

### 10.3 Pose correction

The previous methods for pose estimation have assumed no direct pose measurements are available. At best, only heading is available. To augment any of them with corrections from full pose measurements, an Extended Kalman filter (section 9.8) or Unscented Kalman filter (section 9.9) can be used.



# IV

## System modeling

<b>11</b>	<b>Calculus</b> .....	<b>127</b>
11.1	Derivatives	
11.2	Integrals	
11.3	Tables	
<b>12</b>	<b>Dynamics</b> .....	<b>131</b>
12.1	Linear motion	
12.2	Angular motion	
12.3	Vectors	
12.4	Curvilinear motion	
<b>13</b>	<b>Newtonian mechanics examples</b> ....	<b>141</b>
13.1	DC brushed motor	
13.2	Elevator	
13.3	Flywheel	
13.4	Single-jointed arm	
13.5	Pendulum	
13.6	Differential drive	
<b>14</b>	<b>Lagrangian mechanics examples</b> ...	<b>157</b>
14.1	DC brushed motor	
14.2	Elevator	
14.3	Flywheel	
14.4	Single-jointed arm	
14.5	Pendulum	
14.6	Differential drive	
<b>15</b>	<b>System identification</b> .....	<b>159</b>
15.1	1-DOF mechanism model	
15.2	Drivetrain velocity model	

*This page intentionally left blank*

# 11. Calculus

This book uses derivatives and integrals occasionally to represent small changes in values over small changes in time and the infinitesimal sum of values over time respectively. The formulas and tables presented here are all you'll need to carry through with the math in later chapters.

If you are interested in more information after reading this chapter, 3Blue1Brown does a fantastic job of introducing them in his *Essence of calculus* video series [12]. We recommend watching videos 1 through 3 and 7 through 11 from that playlist for a solid foundation. The Taylor series (presented in video 11) will be used in chapter 6.

## 11.1 Derivatives

Derivatives are expressions for the slope of a curve at arbitrary points. Common notations for this operation on a function like  $f(x)$  include

Leibniz notation	Lagrange notation
$\frac{d}{dx} f(x)$	$f'(x)$
$\frac{d^2}{dx^2} f(x)$	$f''(x)$
$\frac{d^3}{dx^3} f(x)$	$f'''(x)$
$\frac{d^4}{dx^4} f(x)$	$f^{(4)}(x)$
$\frac{d^n}{dx^n} f(x)$	$f^{(n)}(x)$

Table 11.1: Notation for derivatives of  $f(x)$

Lagrange notation is usually voiced as “f prime of x”, “f double-prime of x”, etc.

### 11.1.1 Power rule

$$f(x) = x^n$$

$$f'(x) = nx^{n-1}$$

### 11.1.2 Product rule

This is for taking the derivative of the product of two expressions.

$$h(x) = f(x)g(x)$$

$$h'(x) = f'(x)g(x) + f(x)g'(x)$$

### 11.1.3 Chain rule

This is for taking the derivative of nested expressions.

$$h(x) = f(g(x))$$

$$h'(x) = f'(g(x)) \cdot g'(x)$$

For example

$$h(x) = (3x + 2)^5$$

$$h'(x) = 5(3x + 2)^4 \cdot (3)$$

$$h'(x) = 15(3x + 2)^4$$

## 11.2 Integrals

The integral is the inverse operation of the derivative and calculates the area under a curve. Here is an example of one based on table 11.2.

$$\int e^{at} dt$$

$$\frac{1}{a}e^{at} + C$$

The arbitrary constant  $C$  is needed because when you take a derivative, constants are discarded because vertical offsets don't affect the slope. When performing the inverse operation, we don't have enough information to determine the constant.

However, we can provide bounds for the integration.

$$\int_0^t e^{at} dt$$

$$\left( \frac{1}{a}e^{at} + C \right) \Big|_0^t$$

$$\left( \frac{1}{a}e^{at} + C \right) - \left( \frac{1}{a}e^{a \cdot 0} + C \right)$$

$$\left( \frac{1}{a}e^{at} + C \right) - \left( \frac{1}{a} + C \right)$$

$$\frac{1}{a}e^{at} + C - \frac{1}{a} - C$$

$$\frac{1}{a}e^{at} - \frac{1}{a}$$

When we do this, the constant cancels out.

### 11.2.1 Change of variables

Change of variables substitutes an expression with a single variable to make the calculation more straightforward. Here's an example of integration which utilizes it.

$$\int \cos \omega t \, dt$$

Let  $u = \omega t$ .

$$\begin{aligned} du &= \omega \, dt \\ dt &= \frac{1}{\omega} \, du \end{aligned}$$

Now substitute the expressions for  $u$  and  $dt$  in.

$$\begin{aligned} &\int \cos u \frac{1}{\omega} \, du \\ &\frac{1}{\omega} \int \cos u \, du \\ &\frac{1}{\omega} \sin u + C \\ &\frac{1}{\omega} \sin \omega t + C \end{aligned}$$

## 11.3 Tables

### 11.3.1 Common derivatives and integrals

$\int f(x) \, dx$	$f(x)$	$f'(x)$
$ax$	$a$	$0$
$\frac{1}{2}ax^2$	$ax$	$a$
$\frac{1}{a+1}x^{a+1}$	$x^a$	$ax^{a-1}$
$\frac{1}{a}e^{ax}$	$e^{ax}$	$ae^{ax}$
$-\cos(x)$	$\sin(x)$	$\cos(x)$
$\sin(x)$	$\cos(x)$	$-\sin(x)$
$\cos(x)$	$-\sin(x)$	$-\cos(x)$
$-\sin(x)$	$-\cos(x)$	$\sin(x)$

Table 11.2: Common derivatives and integrals

*This page intentionally left blank*

## 12. Dynamics

### 12.1 Linear motion

$$\sum F = ma$$

where  $\sum F$  is the sum of all forces applied to an object in Newtons,  $m$  is the mass of the object in  $kg$ , and  $a$  is the net acceleration of the object in  $\frac{m}{s^2}$ .

$$x(t) = x_0 + v_0t + \frac{1}{2}at^2$$

where  $x(t)$  is an object's position at time  $t$ ,  $x_0$  is the initial position,  $v_0$  is the initial velocity, and  $a$  is the acceleration.

### 12.2 Angular motion

$$\sum \tau = I\alpha$$

where  $\sum \tau$  is the sum of all torques applied to an object in Newton-meters,  $I$  is the moment of inertia of the object in  $kg\cdot m^2$  (also called the rotational mass), and  $\alpha$  is the net angular acceleration of the object in  $\frac{rad}{s^2}$ .

$$\theta(t) = \theta_0 + \omega_0t + \frac{1}{2}\alpha t^2$$

where  $\theta(t)$  is an object's angle at time  $t$ ,  $\theta_0$  is the initial angle,  $\omega_0$  is the initial angular velocity, and  $\alpha$  is the angular acceleration.

### 12.3 Vectors

Vectors are quantities with a magnitude and a direction. Vectors in three-dimensional space have a coordinate for each spatial direction  $x$ ,  $y$ , and  $z$ . Let's take the vector  $\vec{a} = \langle 1, 2, 3 \rangle$ .  $\vec{a}$  is a three-dimensional vector that describes a movement 1 unit in the  $x$  direction, 2 units in the  $y$  direction, and 3 units in the  $z$  direction.

We define  $\hat{i}$ ,  $\hat{j}$ , and  $\hat{k}$  as vectors that represent the fundamental movements one can make the three-dimensional space: 1 unit of movement in the  $x$  direction, 1 unit of movement  $y$  direction, and 1 unit of movement in the  $z$  direction respectively. These three vectors form a *basis* of three-dimensional space because copies of them can be added together to reach any point in three-dimensional space.

$$\hat{i} = \langle 1, 0, 0 \rangle$$

$$\hat{j} = \langle 0, 1, 0 \rangle$$

$$\hat{k} = \langle 0, 0, 1 \rangle$$

We can also write the vector  $\vec{a}$  in terms of these basis vectors.

$$\vec{a} = 1\hat{i} + 2\hat{j} + 3\hat{k}$$

#### 12.3.1 Basic vector operations

We will now show this is equivalent to the original notation through some vector mathematics. First, we'll substitute in the values for the basis vectors.

$$\vec{a} = 1\langle 1, 0, 0 \rangle + 2\langle 0, 1, 0 \rangle + 3\langle 0, 0, 1 \rangle$$

Scalars are multiplied component-wise with vectors.

$$\vec{a} = \langle 1, 0, 0 \rangle + \langle 0, 2, 0 \rangle + \langle 0, 0, 3 \rangle$$

Vectors are added by summing each of their components.

$$\vec{a} = \langle 1, 2, 3 \rangle$$

#### 12.3.2 Cross product

The cross product is denoted by  $\times$ . The cross product of the basis vectors are computed as follows.

$$\hat{i} \times \hat{j} = \hat{k}$$

$$\hat{j} \times \hat{k} = \hat{i}$$

$$\hat{k} \times \hat{i} = \hat{j}$$

They proceed in a cyclic fashion through  $i$ ,  $j$ , and  $k$ . If a vector is crossed with itself, it produces the zero vector (a scalar zero for each coordinate). The cross product of the basis vectors in the opposite order progress backwards and include a negative sign.

$$\hat{i} \times \hat{k} = -\hat{j}$$

$$\hat{k} \times \hat{j} = -\hat{i}$$

$$\hat{j} \times \hat{i} = -\hat{k}$$



Given vectors  $\vec{u} = a\hat{i} + b\hat{j} + c\hat{k}$  and  $\vec{v} = d\hat{i} + e\hat{j} + f\hat{k}$ ,  $\vec{u} \times \vec{v}$  is computed using the distributive property.

$$\begin{aligned}\vec{u} \times \vec{v} &= (a\hat{i} + b\hat{j} + c\hat{k}) \times (d\hat{i} + e\hat{j} + f\hat{k}) \\ \vec{u} \times \vec{v} &= ad(\hat{i} \times \hat{i}) + ae(\hat{i} \times \hat{j}) + af(\hat{i} \times \hat{k}) + \\ &\quad bd(\hat{j} \times \hat{i}) + be(\hat{j} \times \hat{j}) + bf(\hat{j} \times \hat{k}) + \\ &\quad cd(\hat{k} \times \hat{i}) + ce(\hat{k} \times \hat{j}) + cf(\hat{k} \times \hat{k}) \\ \vec{u} \times \vec{v} &= ae\hat{k} + af(-\hat{j}) + bd(-\hat{k}) + bf\hat{i} + cd\hat{j} + ce(-\hat{i}) \\ \vec{u} \times \vec{v} &= ae\hat{k} - af\hat{j} - bd\hat{k} + bf\hat{i} + cd\hat{j} - ce\hat{i} \\ \vec{u} \times \vec{v} &= (bf - ce)\hat{i} + (cd - af)\hat{j} + (ae - bd)\hat{k}\end{aligned}$$

## 12.4 Curvilinear motion

For these derivations, we'll assume positive  $x$  ( $\hat{i}$ ) is forward, positive  $y$  ( $\hat{j}$ ) is to the left, positive  $z$  ( $\hat{k}$ ) is up, and the robot is facing in the  $x$  direction. This axes convention is known as North-West-Up (NWU), and is shown in figure 12.1.




Figure 12.1: 2D projection of North-West-Up (NWU) axes convention. The positive  $z$  axis is pointed out of the page toward the reader.

The main equation we'll need is the following.

$$\vec{v}_B = \vec{v}_A + \omega_A \times \vec{r}_{B|A}$$

where  $\vec{v}_B$  is the velocity vector at point B,  $\vec{v}_A$  is the velocity vector at point A,  $\omega_A$  is the angular velocity vector at point A, and  $\vec{r}_{B|A}$  is the distance vector from point A to point B (also described as the “distance to B relative to A”).

### 12.4.1 Differential drive

A differential drive has two wheels, one on each side, separated by some distance  $2r_b$ . The forces they generate when moving forward are shown in figure 12.2.




Figure 12.2: Differential drive free body diagram

### Inverse kinematics

The mapping from  $v$  and  $\omega$  to the left and right wheel velocities  $v_l$  and  $v_r$  is derived as follows. Let  $\vec{v}_c$  be the velocity vector of the center of rotation,  $\vec{v}_l$  be the velocity vector of the left wheel,  $\vec{v}_r$  be the velocity vector of the right wheel,  $r_b$  is the distance from the center of rotation to each wheel, and  $\omega$  is the counterclockwise turning rate around the center of rotation.

Once we have the vector equation representing the wheel's velocity, we'll project it onto the wheel direction vector using the dot product.

First, we'll derive  $v_l$ .

$$\begin{aligned}\vec{v}_l &= v_c \hat{i} + \omega \hat{k} \times r_b \hat{j} \\ \vec{v}_l &= v_c \hat{i} - \omega r_b \hat{i} \\ \vec{v}_l &= (v_c - \omega r_b) \hat{i}\end{aligned}$$

Now, project this vector onto the left wheel, which is pointed in the  $\hat{i}$  direction.

$$v_l = (v_c - \omega r_b) \hat{i} \cdot \frac{\hat{i}}{\|\hat{i}\|}$$

The magnitude of  $\hat{i}$  is 1, so the denominator cancels.

$$\begin{aligned}v_l &= (v_c - \omega r_b) \hat{i} \cdot \hat{i} \\ v_l &= v_c - \omega r_b\end{aligned}\tag{12.1}$$

Next, we'll derive  $v_r$ .

$$\begin{aligned}\vec{v}_r &= v_c \hat{i} + \omega \hat{k} \times r_b \hat{j} \\ \vec{v}_r &= v_c \hat{i} + \omega r_b \hat{i} \\ \vec{v}_r &= (v_c + \omega r_b) \hat{i}\end{aligned}$$

Now, project this vector onto the right wheel, which is pointed in the  $\hat{i}$  direction.

$$v_r = (v_c + \omega r_b) \hat{i} \cdot \frac{\hat{i}}{\|\hat{i}\|}$$

The magnitude of  $\hat{i}$  is 1, so the denominator cancels.

$$v_r = (v_c + \omega r_b) \hat{i} \cdot \hat{i}$$

$$v_r = v_c + \omega r_b \quad (12.2)$$

So the two inverse kinematic equations are as follows.

$$v_l = v_c - \omega r_b \quad (12.3)$$

$$v_r = v_c + \omega r_b \quad (12.4)$$

### Forward kinematics

The mapping from the left and right wheel velocities  $v_l$  and  $v_r$  to  $v$  and  $\omega$  is derived as follows.

$$\begin{aligned} v_r &= v_c + \omega r_b \\ v_c &= v_r - \omega r_b \end{aligned} \quad (12.5)$$

Substitute equation (12.5) equation for  $v_l$ .

$$\begin{aligned} v_l &= v_c - \omega r_b \\ v_l &= (v_r - \omega r_b) - \omega r_b \\ v_l &= v_r - 2\omega r_b \\ 2\omega r_b &= v_r - v_l \\ \omega &= \frac{v_r - v_l}{2r_b} \end{aligned}$$

Substitute this back into equation (12.5).

$$\begin{aligned} v_c &= v_r - \omega r_b \\ v_c &= v_r - \left( \frac{v_r - v_l}{2r_b} \right) r_b \\ v_c &= v_r - \frac{v_r - v_l}{2} \\ v_c &= v_r - \frac{v_r}{2} + \frac{v_l}{2} \\ v_c &= \frac{v_r + v_l}{2} \end{aligned}$$

So the two forward kinematic equations are as follows.

$$v_c = \frac{v_r + v_l}{2} \quad (12.6)$$

$$\omega = \frac{v_r - v_l}{2r_b} \quad (12.7)$$

### 12.4.2 Mecanum drive

A mecanum drive has four wheels, one on each corner of a rectangular chassis. The wheels have rollers offset at 45 degrees (whether it's clockwise or not varies per wheel). The forces they generate when moving forward are shown in figure 12.3.

Note that the velocity of the wheel is the same as the velocity in the diagram for the purposes of feedback control. The rollers on the wheel redirect the velocity vector.




Figure 12.3: Mecanum drive free body diagram

### Inverse kinematics

First, we'll derive the front-left wheel kinematics.

$$\begin{aligned}\vec{v}_{fl} &= v_x \hat{i} + v_y \hat{j} + \omega \hat{k} \times (r_{fl_x} \hat{i} + r_{fl_y} \hat{j}) \\ \vec{v}_{fl} &= v_x \hat{i} + v_y \hat{j} + \omega r_{fl_x} \hat{j} - \omega r_{fl_y} \hat{i} \\ \vec{v}_{fl} &= (v_x - \omega r_{fl_y}) \hat{i} + (v_y + \omega r_{fl_x}) \hat{j}\end{aligned}$$

Project the front-left wheel onto its wheel vector.

$$\begin{aligned}v_{fl} &= ((v_x - \omega r_{fl_y}) \hat{i} + (v_y + \omega r_{fl_x}) \hat{j}) \cdot \frac{\hat{i} - \hat{j}}{\sqrt{2}} \\ v_{fl} &= ((v_x - \omega r_{fl_y}) - (v_y + \omega r_{fl_x})) \frac{1}{\sqrt{2}} \\ v_{fl} &= (v_x - \omega r_{fl_y} - v_y - \omega r_{fl_x}) \frac{1}{\sqrt{2}} \\ v_{fl} &= (v_x - v_y - \omega r_{fl_y} - \omega r_{fl_x}) \frac{1}{\sqrt{2}} \\ v_{fl} &= (v_x - v_y - \omega(r_{fl_x} + r_{fl_y})) \frac{1}{\sqrt{2}} \\ v_{fl} &= \frac{1}{\sqrt{2}} v_x - \frac{1}{\sqrt{2}} v_y - \frac{1}{\sqrt{2}} \omega(r_{fl_x} + r_{fl_y})\end{aligned}\tag{12.8}$$

Next, we'll derive the front-right wheel kinematics.

$$\begin{aligned}\vec{v}_{fr} &= v_x \hat{i} + v_y \hat{j} + \omega \hat{k} \times (r_{fr_x} \hat{i} + r_{fr_y} \hat{j}) \\ \vec{v}_{fr} &= v_x \hat{i} + v_y \hat{j} + \omega r_{fr_x} \hat{j} - \omega r_{fr_y} \hat{i} \\ \vec{v}_{fr} &= (v_x - \omega r_{fr_y}) \hat{i} + (v_y + \omega r_{fr_x}) \hat{j}\end{aligned}$$

Project the front-right wheel onto its wheel vector.

$$\begin{aligned}v_{fr} &= ((v_x - \omega r_{fr_y}) \hat{i} + (v_y + \omega r_{fr_x}) \hat{j}) \cdot \frac{\hat{i} + \hat{j}}{\sqrt{2}} \\ v_{fr} &= ((v_x - \omega r_{fr_y}) + (v_y + \omega r_{fr_x})) \frac{1}{\sqrt{2}} \\ v_{fr} &= (v_x - \omega r_{fr_y} + v_y + \omega r_{fr_x}) \frac{1}{\sqrt{2}}\end{aligned}$$

$$\begin{aligned}
v_{fr} &= (v_x + v_y - \omega r_{fr_y} + \omega r_{fr_x}) \frac{1}{\sqrt{2}} \\
v_{fr} &= (v_x + v_y + \omega(r_{fr_x} - r_{fr_y})) \frac{1}{\sqrt{2}} \\
v_{fr} &= \frac{1}{\sqrt{2}}v_x + \frac{1}{\sqrt{2}}v_y + \frac{1}{\sqrt{2}}\omega(r_{fr_x} - r_{fr_y})
\end{aligned} \tag{12.9}$$

Next, we'll derive the rear-left wheel kinematics.

$$\begin{aligned}
\vec{v}_{rl} &= v_x \hat{i} + v_y \hat{j} + \omega \hat{k} \times (r_{rl_x} \hat{i} + r_{rl_y} \hat{j}) \\
\vec{v}_{rl} &= v_x \hat{i} + v_y \hat{j} + \omega r_{rl_x} \hat{j} - \omega r_{rl_y} \hat{i} \\
\vec{v}_{rl} &= (v_x - \omega r_{rl_y}) \hat{i} + (v_y + \omega r_{rl_x}) \hat{j}
\end{aligned}$$

Project the rear-left wheel onto its wheel vector.

$$\begin{aligned}
v_{rl} &= ((v_x - \omega r_{rl_y}) \hat{i} + (v_y + \omega r_{rl_x}) \hat{j}) \cdot (\hat{i} + \hat{j}) \frac{1}{\sqrt{2}} \\
v_{rl} &= ((v_x - \omega r_{rl_y}) + (v_y + \omega r_{rl_x})) \frac{1}{\sqrt{2}} \\
v_{rl} &= (v_x - \omega r_{rl_y} + v_y + \omega r_{rl_x}) \frac{1}{\sqrt{2}} \\
v_{rl} &= (v_x + v_y - \omega r_{rl_y} + \omega r_{rl_x}) \frac{1}{\sqrt{2}} \\
v_{rl} &= (v_x + v_y + \omega(r_{rl_x} - r_{rl_y})) \frac{1}{\sqrt{2}} \\
v_{rl} &= \frac{1}{\sqrt{2}}v_x + \frac{1}{\sqrt{2}}v_y + \frac{1}{\sqrt{2}}\omega(r_{rl_x} - r_{rl_y})
\end{aligned} \tag{12.10}$$

Next, we'll derive the rear-right wheel kinematics.

$$\begin{aligned}
\vec{v}_{rr} &= v_x \hat{i} + v_y \hat{j} + \omega \hat{k} \times (r_{rr_x} \hat{i} + r_{rr_y} \hat{j}) \\
\vec{v}_{rr} &= v_x \hat{i} + v_y \hat{j} + \omega r_{rr_x} \hat{j} - \omega r_{rr_y} \hat{i} \\
\vec{v}_{rr} &= (v_x - \omega r_{rr_y}) \hat{i} + (v_y + \omega r_{rr_x}) \hat{j}
\end{aligned}$$

Project the rear-right wheel onto its wheel vector.

$$\begin{aligned}
v_{rr} &= ((v_x - \omega r_{rr_y}) \hat{i} + (v_y + \omega r_{rr_x}) \hat{j}) \cdot \frac{\hat{i} - \hat{j}}{\sqrt{2}} \\
v_{rr} &= ((v_x - \omega r_{rr_y}) - (v_y + \omega r_{rr_x})) \frac{1}{\sqrt{2}} \\
v_{rr} &= (v_x - \omega r_{rr_y} - v_y - \omega r_{rr_x}) \frac{1}{\sqrt{2}} \\
v_{rr} &= (v_x - v_y - \omega r_{rr_y} - \omega r_{rr_x}) \frac{1}{\sqrt{2}} \\
v_{rr} &= (v_x - v_y - \omega(r_{rr_x} + r_{rr_y})) \frac{1}{\sqrt{2}} \\
v_{rr} &= \frac{1}{\sqrt{2}}v_x - \frac{1}{\sqrt{2}}v_y - \frac{1}{\sqrt{2}}\omega(r_{rr_x} + r_{rr_y})
\end{aligned} \tag{12.11}$$

This gives the following inverse kinematic equations.

$$\begin{aligned}v_{fl} &= \frac{1}{\sqrt{2}}v_x - \frac{1}{\sqrt{2}}v_y - \frac{1}{\sqrt{2}}\omega(r_{flx} + r_{fly}) \\v_{fr} &= \frac{1}{\sqrt{2}}v_x + \frac{1}{\sqrt{2}}v_y + \frac{1}{\sqrt{2}}\omega(r_{frx} - r_{fry}) \\v_{rl} &= \frac{1}{\sqrt{2}}v_x + \frac{1}{\sqrt{2}}v_y + \frac{1}{\sqrt{2}}\omega(r_{rlx} - r_{rly}) \\v_{rr} &= \frac{1}{\sqrt{2}}v_x - \frac{1}{\sqrt{2}}v_y - \frac{1}{\sqrt{2}}\omega(r_{rrx} + r_{rry})\end{aligned}$$

Now we'll factor them out into matrices.

$$\begin{aligned}\begin{bmatrix} v_{fl} \\ v_{fr} \\ v_{rl} \\ v_{rr} \end{bmatrix} &= \begin{bmatrix} \frac{1}{\sqrt{2}} & -\frac{1}{\sqrt{2}} & -\frac{1}{\sqrt{2}}(r_{flx} + r_{fly}) \\ \frac{1}{\sqrt{2}} & \frac{1}{\sqrt{2}} & \frac{1}{\sqrt{2}}(r_{frx} - r_{fry}) \\ \frac{1}{\sqrt{2}} & \frac{1}{\sqrt{2}} & \frac{1}{\sqrt{2}}(r_{rlx} - r_{rly}) \\ \frac{1}{\sqrt{2}} & -\frac{1}{\sqrt{2}} & -\frac{1}{\sqrt{2}}(r_{rrx} + r_{rry}) \end{bmatrix} \begin{bmatrix} v_x \\ v_y \\ \omega \end{bmatrix} \\ \begin{bmatrix} v_{fl} \\ v_{fr} \\ v_{rl} \\ v_{rr} \end{bmatrix} &= \frac{1}{\sqrt{2}} \begin{bmatrix} 1 & -1 & -(r_{flx} + r_{fly}) \\ 1 & 1 & (r_{frx} - r_{fry}) \\ 1 & 1 & (r_{rlx} - r_{rly}) \\ 1 & -1 & -(r_{rrx} + r_{rry}) \end{bmatrix} \begin{bmatrix} v_x \\ v_y \\ \omega \end{bmatrix} \end{aligned} \quad (12.12)$$

### Forward kinematics

Let  $\mathbf{M}$  be the  $4 \times 3$  inverse kinematics matrix above including the  $\frac{1}{\sqrt{2}}$  factor. The forward kinematics are

$$\begin{bmatrix} v_x \\ v_y \\ \omega \end{bmatrix} = \mathbf{M}^\dagger \begin{bmatrix} v_{fl} \\ v_{fr} \\ v_{rl} \\ v_{rr} \end{bmatrix} \quad (12.13)$$

where  $\mathbf{M}^\dagger$  is the pseudoinverse of  $\mathbf{M}$ .

### 12.4.3 Swerve drive

A swerve drive has an arbitrary number of wheels which can rotate in place independent of the chassis. The forces they generate are shown in figure 12.4.




Figure 12.4: Swerve drive free body diagram

## Inverse kinematics

$$\vec{v}_{wheel1} = \vec{v}_{robot} + \vec{\omega}_{robot} \times \vec{r}_{robot2wheel1}$$

$$\vec{v}_{wheel2} = \vec{v}_{robot} + \vec{\omega}_{robot} \times \vec{r}_{robot2wheel2}$$

$$\vec{v}_{wheel3} = \vec{v}_{robot} + \vec{\omega}_{robot} \times \vec{r}_{robot2wheel3}$$

$$\vec{v}_{wheel4} = \vec{v}_{robot} + \vec{\omega}_{robot} \times \vec{r}_{robot2wheel4}$$

where  $\vec{v}$  is linear velocity vector,  $\vec{\omega}$  is angular velocity vector,  $\vec{r}$  is distance vector from the center of rotation to the wheel,  $\vec{v}_{robot} = v_x \hat{i} + v_y \hat{j}$ , and  $\vec{r}_{robot2wheel} = r_x \hat{i} + r_y \hat{j}$ .

$$\vec{v}_1 = v_x \hat{i} + v_y \hat{j} + \omega \hat{k} \times (r_{1x} \hat{i} + r_{1y} \hat{j})$$

$$\vec{v}_2 = v_x \hat{i} + v_y \hat{j} + \omega \hat{k} \times (r_{2x} \hat{i} + r_{2y} \hat{j})$$

$$\vec{v}_3 = v_x \hat{i} + v_y \hat{j} + \omega \hat{k} \times (r_{3x} \hat{i} + r_{3y} \hat{j})$$

$$\vec{v}_4 = v_x \hat{i} + v_y \hat{j} + \omega \hat{k} \times (r_{4x} \hat{i} + r_{4y} \hat{j})$$

$$\vec{v}_1 = v_x \hat{i} + v_y \hat{j} + (\omega r_{1x} \hat{j} - \omega r_{1y} \hat{i})$$

$$\vec{v}_2 = v_x \hat{i} + v_y \hat{j} + (\omega r_{2x} \hat{j} - \omega r_{2y} \hat{i})$$

$$\vec{v}_3 = v_x \hat{i} + v_y \hat{j} + (\omega r_{3x} \hat{j} - \omega r_{3y} \hat{i})$$

$$\vec{v}_4 = v_x \hat{i} + v_y \hat{j} + (\omega r_{4x} \hat{j} - \omega r_{4y} \hat{i})$$

$$\vec{v}_1 = v_x \hat{i} + v_y \hat{j} + \omega r_{1x} \hat{j} - \omega r_{1y} \hat{i}$$

$$\vec{v}_2 = v_x \hat{i} + v_y \hat{j} + \omega r_{2x} \hat{j} - \omega r_{2y} \hat{i}$$

$$\vec{v}_3 = v_x \hat{i} + v_y \hat{j} + \omega r_{3x} \hat{j} - \omega r_{3y} \hat{i}$$

$$\vec{v}_4 = v_x \hat{i} + v_y \hat{j} + \omega r_{4x} \hat{j} - \omega r_{4y} \hat{i}$$

$$\vec{v}_1 = v_x \hat{i} - \omega r_{1y} \hat{i} + v_y \hat{j} + \omega r_{1x} \hat{j}$$

$$\vec{v}_2 = v_x \hat{i} - \omega r_{2y} \hat{i} + v_y \hat{j} + \omega r_{2x} \hat{j}$$

$$\vec{v}_3 = v_x \hat{i} - \omega r_{3y} \hat{i} + v_y \hat{j} + \omega r_{3x} \hat{j}$$

$$\vec{v}_4 = v_x \hat{i} - \omega r_{4y} \hat{i} + v_y \hat{j} + \omega r_{4x} \hat{j}$$

$$\vec{v}_1 = (v_x - \omega r_{1y}) \hat{i} + (v_y + \omega r_{1x}) \hat{j}$$

$$\vec{v}_2 = (v_x - \omega r_{2y}) \hat{i} + (v_y + \omega r_{2x}) \hat{j}$$

$$\vec{v}_3 = (v_x - \omega r_{3y}) \hat{i} + (v_y + \omega r_{3x}) \hat{j}$$

$$\vec{v}_4 = (v_x - \omega r_{4y}) \hat{i} + (v_y + \omega r_{4x}) \hat{j}$$

Separate the i-hat components into independent equations.

$$v_{1x} = v_x - \omega r_{1y}$$

$$v_{2x} = v_x - \omega r_{2y}$$

$$v_{3x} = v_x - \omega r_{3y}$$

$$v_{4x} = v_x - \omega r_{4y}$$

Separate the  $\dot{j}$  components into independent equations.

$$v_{1y} = v_y + \omega r_{1x}$$

$$v_{2y} = v_y + \omega r_{2x}$$

$$v_{3y} = v_y + \omega r_{3x}$$

$$v_{4y} = v_y + \omega r_{4x}$$

Now we'll factor them out into matrices.

$$\begin{bmatrix} v_{1x} \\ v_{2x} \\ v_{3x} \\ v_{4x} \\ v_{1y} \\ v_{2y} \\ v_{3y} \\ v_{4y} \end{bmatrix} = \begin{bmatrix} 1 & 0 & -r_{1y} \\ 1 & 0 & -r_{2y} \\ 1 & 0 & -r_{3y} \\ 1 & 0 & -r_{4y} \\ 0 & 1 & r_{1x} \\ 0 & 1 & r_{2x} \\ 0 & 1 & r_{3x} \\ 0 & 1 & r_{4x} \end{bmatrix} \begin{bmatrix} v_x \\ v_y \\ \omega \end{bmatrix}$$

Rearrange the rows so the  $x$  and  $y$  components are in adjacent rows.

$$\begin{bmatrix} v_{1x} \\ v_{1y} \\ v_{2x} \\ v_{2y} \\ v_{3x} \\ v_{3y} \\ v_{4x} \\ v_{4y} \end{bmatrix} = \begin{bmatrix} 1 & 0 & -r_{1y} \\ 0 & 1 & r_{1x} \\ 1 & 0 & -r_{2y} \\ 0 & 1 & r_{2x} \\ 1 & 0 & -r_{3y} \\ 0 & 1 & r_{3x} \\ 1 & 0 & -r_{4y} \\ 0 & 1 & r_{4x} \end{bmatrix} \begin{bmatrix} v_x \\ v_y \\ \omega \end{bmatrix} \quad (12.14)$$

To convert from swerve module  $x$  and  $y$  velocity components to a velocity and heading, use the Pythagorean theorem and arctangent respectively, as shown below.

$$v = \sqrt{v_x^2 + v_y^2} \quad (12.15)$$

$$\theta = \tan^{-1} \left( \frac{v_y}{v_x} \right) \quad (12.16)$$

### Forward kinematics

Let  $\mathbf{M}$  be the  $8 \times 3$  inverse kinematics matrix above. The forward kinematics are

$$\begin{bmatrix} v_x \\ v_y \\ \omega \end{bmatrix} = \mathbf{M}^\dagger \begin{bmatrix} v_{1x} \\ v_{1y} \\ v_{2x} \\ v_{2y} \\ v_{3x} \\ v_{3y} \\ v_{4x} \\ v_{4y} \end{bmatrix} \quad (12.17)$$

where  $\mathbf{M}^\dagger$  is the pseudoinverse of  $\mathbf{M}$ .



## 13. Newtonian mechanics examples

A **model** is a set of differential equations describing how the **system** behaves over time. There are two common approaches for developing them.

1. Collecting data on the physical system's behavior and performing **system** identification with it.
2. Using physics to derive the **system's** model from first principles.

This chapter covers the second approach using Newtonian mechanics.

The **models** derived here should cover most types of motion seen on an FRC robot. Furthermore, they can be easily tweaked to describe many types of mechanisms just by pattern-matching. There's only so many ways to hook up a mass to a motor in FRC. The flywheel **model** can be used for spinning mechanisms, the elevator **model** can be used for spinning mechanisms transformed to linear motion, and the single-jointed arm **model** can be used for rotating servo mechanisms (it's just the flywheel **model** augmented with a position **state**).

These **models** assume all motor controllers driving DC brushed motors are set to brake mode instead of coast mode. Brake mode behaves the same as coast mode except where the applied voltage is zero. In brake mode, the motor leads are shorted together to prevent movement. In coast mode, the motor leads are an open circuit.

### 13.1 DC brushed motor

We will be deriving a first-order **model** for a DC brushed motor. A second-order **model** would include the inductance of the motor windings as well, but we're assuming the time constant of the inductor is small enough that its affect on the **model** behavior is negligible for FRC use cases (see subsection 19.3.1 for a demonstration of this for a real DC brushed motor).

The first-order **model** will only require numbers from the motor's datasheet. The second-order **model** would require measuring the motor inductance as well, which generally isn't in the datasheet. It can be difficult to measure accurately without the right equipment.

### 13.1.1 Equations of motion

The circuit for a DC brushed motor is shown in figure 13.1.




Figure 13.1: DC brushed motor circuit

$V$  is the voltage applied to the motor,  $I$  is the current through the motor in Amps,  $R$  is the resistance across the motor in Ohms,  $\omega$  is the angular velocity of the motor in radians per second, and  $K_v$  is the angular velocity constant in radians per second per Volt. This circuit reflects the following relation.

$$V = IR + \frac{\omega}{K_v} \quad (13.1)$$

The mechanical relation for a DC brushed motor is

$$\tau = K_t I \quad (13.2)$$

where  $\tau$  is the torque produced by the motor in Newton-meters and  $K_t$  is the torque constant in Newton-meters per Amp. Therefore

$$I = \frac{\tau}{K_t}$$

Substitute this into equation (13.1).

$$V = \frac{\tau}{K_t} R + \frac{\omega}{K_v} \quad (13.3)$$

### 13.1.2 Calculating constants

A typical motor's datasheet should include graphs of the motor's measured torque and current for different angular velocities for a given voltage applied to the motor. Figure 13.2 is an example. Data for the most common motors in FRC can be found at <https://motors.vex.com>.

**Torque constant  $K_t$**

$$\begin{aligned} \tau &= K_t I \\ K_t &= \frac{\tau}{I} \\ K_t &= \frac{\tau_{stall}}{I_{stall}} \end{aligned} \quad (13.4)$$

where  $\tau_{stall}$  is the stall torque and  $I_{stall}$  is the stall current of the motor from its datasheet.




Figure 13.2: Example motor datasheet for 775pro

**Resistance  $R$** 

Recall equation (13.1).

$$V = IR + \frac{\omega}{K_v}$$

When the motor is stalled,  $\omega = 0$ .

$$V = I_{stall}R$$

$$R = \frac{V}{I_{stall}} \quad (13.5)$$

where  $I_{stall}$  is the stall current of the motor and  $V$  is the voltage applied to the motor at stall.

**Angular velocity constant  $K_v$** 

Recall equation (13.1).

$$V = IR + \frac{\omega}{K_v}$$

$$V - IR = \frac{\omega}{K_v}$$

$$K_v = \frac{\omega}{V - IR}$$

When the motor is spinning under no load

$$K_v = \frac{\omega_{free}}{V - I_{free}R} \quad (13.6)$$

where  $\omega_{free}$  is the angular velocity of the motor under no load (also known as the free speed), and  $V$  is the voltage applied to the motor when it's spinning at  $\omega_{free}$ , and  $I_{free}$  is the current drawn by the motor under no load.

If several identical motors are being used in one gearbox for a mechanism, multiply the stall torque by the number of motors.

### 13.1.3 Current limiting

Current limiting of a DC brushed motor reduces the maximum input voltage to avoid exceeding a current threshold. Predictive current limiting uses a projected estimate of the current, so the voltage is reduced before the current threshold is exceeded. Reactive current limiting uses an actual current measurement, so the voltage is reduced after the current threshold is exceeded.

The following pseudocode demonstrates each type of current limiting.

```
# Normal feedback control
V = K @ (r - x)

# Calculations for predictive current limiting
omega = angular_velocity_measurement
I = V / R - omega / (Kv * R)

# Calculations for reactive current limiting
I = current_measurement
omega = Kv * V - I * R * Kv # or can be angular velocity measurement

# If predicted/actual current above max, limit current by reducing voltage
if I > I_max:
    V = I_max * R + omega / Kv
```

Snippet 13.1. Limits current of DC motor to  $I_{max}$

## 13.2 Elevator

### 13.2.1 Equations of motion

This elevator consists of a DC brushed motor attached to a pulley that drives a mass up or down.




Figure 13.3: Elevator system diagram

Gear ratios are written as output over input, so  $G$  is greater than one in figure 13.3.

We want to derive an equation for the carriage acceleration  $a$  (derivative of  $v$ ) given an input voltage  $V$ , which we can integrate to get carriage velocity and position.

First, we'll find a torque to substitute into the equation for a DC brushed motor. Based on figure 13.3

$$\tau_m G = \tau_p \quad (13.7)$$

where  $G$  is the gear ratio between the motor and the pulley and  $\tau_p$  is the torque produced by the pulley.

$$rF_m = \tau_p \quad (13.8)$$

where  $r$  is the radius of the pulley. Substitute equation (13.7) into  $\tau_m$  in the DC brushed motor equation (13.3).

$$V = \frac{\tau_p}{K_t} R + \frac{\omega_m}{K_v}$$

$$V = \frac{\tau_p}{GK_t} R + \frac{\omega_m}{K_v}$$

Substitute in equation (13.8) for  $\tau_p$ .

$$V = \frac{rF_m}{GK_t} R + \frac{\omega_m}{K_v} \quad (13.9)$$

The angular velocity of the motor armature  $\omega_m$  is

$$\omega_m = G\omega_p \quad (13.10)$$

where  $\omega_p$  is the angular velocity of the pulley. The velocity of the mass (the elevator carriage) is

$$v = r\omega_p$$

$$\omega_p = \frac{v}{r} \quad (13.11)$$

Substitute equation (13.11) into equation (13.10).

$$\omega_m = G\frac{v}{r} \quad (13.12)$$

Substitute equation (13.12) into equation (13.9) for  $\omega_m$ .

$$V = \frac{rF_m}{GK_t} R + \frac{Gv}{K_v}$$

$$V = \frac{RrF_m}{GK_t} + \frac{G}{rK_v}v$$

Solve for  $F_m$ .

$$\frac{RrF_m}{GK_t} = V - \frac{G}{rK_v}v$$

$$F_m = \left( V - \frac{G}{rK_v}v \right) \frac{GK_t}{Rr}$$

$$F_m = \frac{GK_t}{Rr}V - \frac{G^2K_t}{Rr^2K_v}v \quad (13.13)$$

$$\sum F = ma \quad (13.14)$$

where  $\sum F$  is the sum of forces applied to the elevator carriage,  $m$  is the mass of the elevator carriage in kilograms, and  $a$  is the acceleration of the elevator carriage.

$$ma = F_m$$

- R** Gravity is not part of the modeled dynamics because it complicates the state-space model and the controller will behave well enough without it.

$$\begin{aligned}
 ma &= \left( \frac{GK_t}{Rr} V - \frac{G^2 K_t}{Rr^2 K_v} v \right) \\
 a &= \frac{GK_t}{Rrm} V - \frac{G^2 K_t}{Rr^2 m K_v} v
 \end{aligned} \tag{13.15}$$

This model will be converted to state-space notation in section 8.1.

### 13.3 Flywheel

#### 13.3.1 Equations of motion

This flywheel consists of a DC brushed motor attached to a spinning mass of non-negligible moment of inertia.




Figure 13.4: Flywheel system diagram

Gear ratios are written as output over input, so  $G$  is greater than one in figure 13.4.

We want to derive an equation for the flywheel angular acceleration  $\dot{\omega}_f$  given an input voltage  $V$ , which we can integrate to get flywheel angular velocity.

We will start with the equation derived earlier for a DC brushed motor, equation (13.3).

$$V = \frac{\tau_m}{K_t} R + \frac{\omega_m}{K_v}$$

Solve for the angular acceleration. First, we'll rearrange the terms because from inspection,  $V$  is the model input,  $\omega_m$  is the state, and  $\tau_m$  contains the angular acceleration.

$$V = \frac{R}{K_t} \tau_m + \frac{1}{K_v} \omega_m$$

Solve for  $\tau_m$ .

$$\begin{aligned}
 V &= \frac{R}{K_t} \tau_m + \frac{1}{K_v} \omega_m \\
 \frac{R}{K_t} \tau_m &= V - \frac{1}{K_v} \omega_m
 \end{aligned}$$

$$\tau_m = \frac{K_t}{R}V - \frac{K_t}{K_v R}\omega_m$$

Since  $\tau_m G = \tau_f$  and  $\omega_m = G\omega_f$

$$\begin{aligned} \left(\frac{\tau_f}{G}\right) &= \frac{K_t}{R}V - \frac{K_t}{K_v R}(G\omega_f) \\ \frac{\tau_f}{G} &= \frac{K_t}{R}V - \frac{GK_t}{K_v R}\omega_f \\ \tau_f &= \frac{GK_t}{R}V - \frac{G^2K_t}{K_v R}\omega_f \end{aligned} \quad (13.16)$$

The torque applied to the flywheel is defined as

$$\tau_f = J\dot{\omega}_f \quad (13.17)$$

where  $J$  is the moment of inertia of the flywheel and  $\dot{\omega}_f$  is the angular acceleration. Substitute equation (13.17) into equation (13.16).

$$\begin{aligned} (J\dot{\omega}_f) &= \frac{GK_t}{R}V - \frac{G^2K_t}{K_v R}\omega_f \\ \dot{\omega}_f &= \frac{GK_t}{RJ}V - \frac{G^2K_t}{K_v RJ}\omega_f \\ \dot{\omega}_f &= -\frac{G^2K_t}{K_v RJ}\omega_f + \frac{GK_t}{RJ}V \end{aligned}$$

We'll relabel  $\omega_f$  as  $\omega$  for convenience.

$$\dot{\omega} = -\frac{G^2K_t}{K_v RJ}\omega + \frac{GK_t}{RJ}V \quad (13.18)$$

This model will be converted to state-space notation in section 8.2.

### 13.3.2 Calculating constants

#### Moment of inertia $J$

Given the simplicity of this mechanism, it may be easier to compute this value theoretically using material properties in CAD. A procedure for measuring it experimentally is presented below.

First, rearrange equation (13.18) into the form  $y = mx + b$  such that  $J$  is in the numerator of  $m$ .

$$\begin{aligned} \dot{\omega} &= -\frac{G^2K_t}{K_v RJ}\omega + \frac{GK_t}{RJ}V \\ J\dot{\omega} &= -\frac{G^2K_t}{K_v R}\omega + \frac{GK_t}{R}V \end{aligned}$$

Multiply by  $\frac{K_v R}{G^2K_t}$  on both sides.

$$\begin{aligned} \frac{JK_v R}{G^2K_t}\dot{\omega} &= -\omega + \frac{GK_t}{R} \cdot \frac{K_v R}{G^2K_t}V \\ \frac{JK_v R}{G^2K_t}\dot{\omega} &= -\omega + \frac{K_v}{G}V \end{aligned}$$

$$\omega = -\frac{JK_v R}{G^2 K_t} \dot{\omega} + \frac{K_v}{G} V \quad (13.19)$$

The test procedure is as follows.

1. Run the flywheel forward at a constant voltage. Record the angular velocity over time.
2. Compute the angular acceleration from the angular velocity data as the difference between each sample divided by the time between them.
3. Perform a linear regression of angular velocity versus angular acceleration. The slope of this line has the form  $-\frac{JK_v R}{G^2 K_t}$  as per equation (13.19).
4. Multiply the slope by  $-\frac{G^2 K_t}{K_v R}$  to obtain a least squares estimate of  $J$ .

## 13.4 Single-jointed arm

### 13.4.1 Equations of motion

This single-jointed arm consists of a DC brushed motor attached to a pulley that spins a straight bar in pitch.




Figure 13.5: Single-jointed arm system diagram

Gear ratios are written as output over input, so  $G$  is greater than one in figure 13.5.

We want to derive an equation for the arm angular acceleration  $\dot{\omega}_{arm}$  given an input voltage  $V$ , which we can integrate to get arm angular velocity and angle.

We will start with the equation derived earlier for a DC brushed motor, equation (13.3).

$$V = \frac{\tau_m}{K_t} R + \frac{\omega_m}{K_v}$$

Solve for the angular acceleration. First, we'll rearrange the terms because from inspection,  $V$  is the **model input**,  $\omega_m$  is the **state**, and  $\tau_m$  contains the angular acceleration.

$$V = \frac{R}{K_t} \tau_m + \frac{1}{K_v} \omega_m$$

Solve for  $\tau_m$ .

$$V = \frac{R}{K_t} \tau_m + \frac{1}{K_v} \omega_m$$



$$\begin{aligned}\frac{R}{K_t}\tau_m &= V - \frac{1}{K_v}\omega_m \\ \tau_m &= \frac{K_t}{R}V - \frac{K_t}{K_v R}\omega_m\end{aligned}$$

Since  $\tau_m G = \tau_{arm}$  and  $\omega_m = G\omega_{arm}$

$$\begin{aligned}\left(\frac{\tau_{arm}}{G}\right) &= \frac{K_t}{R}V - \frac{K_t}{K_v R}(G\omega_{arm}) \\ \frac{\tau_{arm}}{G} &= \frac{K_t}{R}V - \frac{GK_t}{K_v R}\omega_{arm} \\ \tau_{arm} &= \frac{GK_t}{R}V - \frac{G^2K_t}{K_v R}\omega_{arm}\end{aligned}\tag{13.20}$$

The torque applied to the arm is defined as

$$\tau_{arm} = J\dot{\omega}_{arm}\tag{13.21}$$

where  $J$  is the moment of inertia of the arm and  $\dot{\omega}_{arm}$  is the angular acceleration. Substitute equation (13.21) into equation (13.20).

$$\begin{aligned}(J\dot{\omega}_{arm}) &= \frac{GK_t}{R}V - \frac{G^2K_t}{K_v R}\omega_{arm} \\ \dot{\omega}_{arm} &= -\frac{G^2K_t}{K_v R J}\omega_{arm} + \frac{GK_t}{R J}V\end{aligned}$$

We'll relabel  $\omega_{arm}$  as  $\omega$  for convenience.

$$\dot{\omega} = -\frac{G^2K_t}{K_v R J}\omega + \frac{GK_t}{R J}V\tag{13.22}$$

This model will be converted to state-space notation in section 8.3.

### 13.4.2 Calculating constants

#### Moment of inertia $J$

Given the simplicity of this mechanism, it may be easier to compute this value theoretically using material properties in CAD.  $J$  can also be approximated as the moment of inertia of a thin rod rotating around one end. Therefore

$$J = \frac{1}{3}ml^2\tag{13.23}$$

where  $m$  is the mass of the arm and  $l$  is the length of the arm. Otherwise, a procedure for measuring it experimentally is presented below.

First, rearrange equation (13.22) into the form  $y = mx + b$  such that  $J$  is in the numerator of  $m$ .

$$\begin{aligned}\dot{\omega} &= -\frac{G^2K_t}{K_v R J}\omega + \frac{GK_t}{R J}V \\ J\dot{\omega} &= -\frac{G^2K_t}{K_v R}\omega + \frac{GK_t}{R}V\end{aligned}$$

Multiply by  $\frac{K_v R}{G^2 K_t}$  on both sides.

$$\begin{aligned}\frac{JK_v R}{G^2 K_t} \dot{\omega} &= -\omega + \frac{GK_t}{R} \cdot \frac{K_v R}{G^2 K_t} V \\ \frac{JK_v R}{G^2 K_t} \dot{\omega} &= -\omega + \frac{K_v}{G} V \\ \omega &= -\frac{JK_v R}{G^2 K_t} \dot{\omega} + \frac{K_v}{G} V\end{aligned}\quad (13.24)$$

The test procedure is as follows.

1. Orient the arm such that its axis of rotation is aligned with gravity (i.e., the arm is on its side). This avoids gravity affecting the measurements.
2. Run the arm forward at a constant voltage. Record the angular velocity over time.
3. Compute the angular acceleration from the angular velocity data as the difference between each sample divided by the time between them.
4. Perform a linear regression of angular velocity versus angular acceleration. The slope of this line has the form  $-\frac{JK_v R}{G^2 K_t}$  as per equation (13.24).
5. Multiply the slope by  $-\frac{G^2 K_t}{K_v R}$  to obtain a least squares estimate of  $J$ .

### 13.5 Pendulum

Kinematics and dynamics are a rather large topics, so for now, we'll just focus on the basics required for working with the [models](#) in this book. We'll derive the same [model](#), a pendulum, using three approaches: sum of forces, sum of torques, and conservation of energy.




Figure 13.6: Pendulum force diagrams

#### 13.5.1 Force derivation

Consider figure 13.6a, which shows the forces acting on a pendulum.

Note that the path of the pendulum sweeps out an arc of a circle. The angle  $\theta$  is measured in radians. The blue arrow is the gravitational force acting on the bob, and the violet arrows are that same force resolved into components parallel and perpendicular to the bob's instantaneous motion. The direction of the bob's instantaneous velocity always points along the red axis, which is considered the tangential axis because its direction is always tangent to the circle. Consider Newton's second law

$$F = ma$$

where  $F$  is the sum of forces on the object,  $m$  is mass, and  $a$  is the acceleration. Because we are only concerned with changes in speed, and because the bob is forced to stay in a circular path, we apply Newton's equation to the tangential axis only. The short violet arrow represents the component of the gravitational force in the tangential axis, and trigonometry can be used to determine its magnitude. Therefore

$$\begin{aligned} -mg \sin \theta &= ma \\ a &= -g \sin \theta \end{aligned}$$

where  $g$  is the acceleration due to gravity near the surface of the earth. The negative sign on the right hand side implies that  $\theta$  and  $a$  always point in opposite directions. This makes sense because when a pendulum swings further to the left, we would expect it to accelerate back toward the right.

This linear acceleration  $a$  along the red axis can be related to the change in angle  $\theta$  by the arc length formulas;  $s$  is arc length and  $l$  is the length of the pendulum.

$$\begin{aligned} s &= l\theta & (13.25) \\ v &= \frac{ds}{dt} = l \frac{d\theta}{dt} \\ a &= \frac{d^2s}{dt^2} = l \frac{d^2\theta}{dt^2} \end{aligned}$$

Therefore

$$\begin{aligned} l \frac{d^2\theta}{dt^2} &= -g \sin \theta \\ \frac{d^2\theta}{dt^2} &= -\frac{g}{l} \sin \theta \\ \ddot{\theta} &= -\frac{g}{l} \sin \theta \end{aligned}$$

### 13.5.2 Torque derivation

The equation can be obtained using two definitions for torque.

$$\boldsymbol{\tau} = \mathbf{r} \times \mathbf{F}$$

First start by defining the torque on the pendulum bob using the force due to gravity.

$$\boldsymbol{\tau} = \mathbf{l} \times \mathbf{F}_g$$

where  $\mathbf{l}$  is the length vector of the pendulum and  $\mathbf{F}_g$  is the force due to gravity.

For now just consider the magnitude of the torque on the pendulum.

$$|\tau| = -mgl \sin \theta$$

where  $m$  is the mass of the pendulum,  $g$  is the acceleration due to gravity,  $l$  is the length of the pendulum and  $\theta$  is the angle between the length vector and the force due to gravity.

Next rewrite the angular momentum.

$$\mathbf{L} = \mathbf{r} \times \mathbf{p} = m\mathbf{r} \times (\boldsymbol{\omega} \times \mathbf{r})$$

Again just consider the magnitude of the angular momentum.

$$\begin{aligned} |\mathbf{L}| &= mr^2\omega \\ |\mathbf{L}| &= ml^2\frac{d\theta}{dt} \\ \frac{d}{dt}|\mathbf{L}| &= ml^2\frac{d^2\theta}{dt^2} \end{aligned}$$

According to  $\tau = \frac{d\mathbf{L}}{dt}$ , we can just compare the magnitudes.

$$\begin{aligned} -mgl \sin \theta &= ml^2\frac{d^2\theta}{dt^2} \\ -\frac{g}{l} \sin \theta &= \frac{d^2\theta}{dt^2} \\ \ddot{\theta} &= -\frac{g}{l} \sin \theta \end{aligned}$$

which is the same result from force analysis.

### 13.5.3 Energy derivation

The equation can also be obtained via the conservation of mechanical energy principle: any object falling a vertical distance  $h$  would acquire kinetic energy equal to that which it lost to the fall. In other words, gravitational potential energy is converted into kinetic energy. Change in potential energy is given by

$$\Delta U = mgh$$

The change in kinetic energy (body started from rest) is given by

$$\Delta K = \frac{1}{2}mv^2$$

Since no energy is lost, the gain in one must be equal to the loss in the other

$$\frac{1}{2}mv^2 = mgh$$

The change in velocity for a given change in height can be expressed as

$$v = \sqrt{2gh}$$

Using equation (13.25), this equation can be rewritten in terms of  $\frac{d\theta}{dt}$ .

$$\begin{aligned} v &= l\frac{d\theta}{dt} = \sqrt{2gh} \\ \frac{d\theta}{dt} &= \frac{\sqrt{2gh}}{l} \end{aligned} \tag{13.26}$$

where  $h$  is the vertical distance the pendulum fell. Look at figure 13.6b, which presents the trigonometry of a pendulum. If the pendulum starts its swing from some initial angle  $\theta_0$ , then  $y_0$ , the vertical distance from the pivot point, is given by

$$y_0 = l \cos \theta_0$$

Similarly for  $y_1$ , we have

$$y_1 = l \cos \theta$$

Then  $h$  is the difference of the two

$$h = l(\cos \theta - \cos \theta_0)$$

Substituting this into equation (13.26) gives

$$\frac{d\theta}{dt} = \sqrt{\frac{2g}{l}(\cos \theta - \cos \theta_0)}$$

This equation is known as the first integral of motion. It gives the velocity in terms of the location and includes an integration constant related to the initial displacement ( $\theta_0$ ). We can differentiate by applying the chain rule with respect to time. Doing so gives the acceleration.

$$\begin{aligned} \frac{d}{dt} \frac{d\theta}{dt} &= \frac{d}{dt} \sqrt{\frac{2g}{l}(\cos \theta - \cos \theta_0)} \\ \frac{d^2\theta}{dt^2} &= \frac{1}{2} \frac{-\frac{2g}{l} \sin \theta}{\sqrt{\frac{2g}{l}(\cos \theta - \cos \theta_0)}} \frac{d\theta}{dt} \\ \frac{d^2\theta}{dt^2} &= \frac{1}{2} \frac{-\frac{2g}{l} \sin \theta}{\sqrt{\frac{2g}{l}(\cos \theta - \cos \theta_0)}} \sqrt{\frac{2g}{l}(\cos \theta - \cos \theta_0)} \\ \frac{d^2\theta}{dt^2} &= -\frac{g}{l} \sin \theta \\ \ddot{\theta} &= -\frac{g}{l} \sin \theta \end{aligned}$$

which is the same result from force analysis.

## 13.6 Differential drive

### 13.6.1 Equations of motion

This drivetrain consists of two DC brushed motors per side which are chained together on their respective sides and drive wheels which are assumed to be massless.




Figure 13.7: Differential drive system diagram

We want to derive equations for the accelerations of the left and right sides of the robot  $\dot{v}_l$  and  $\dot{v}_r$  given left and right input voltages  $V_l$  and  $V_r$ .

From equation (13.16) of the flywheel model derivations

$$\tau = \frac{GK_t}{R}V - \frac{G^2K_t}{K_vR}\omega \quad (13.27)$$

where  $\tau$  is the torque applied by one wheel of the differential drive,  $G$  is the gear ratio of the differential drive,  $K_t$  is the torque constant of the motor,  $R$  is the resistance of the motor, and  $K_v$  is the angular velocity constant. Since  $\tau = rF$  and  $\omega = \frac{v}{r}$  where  $v$  is the velocity of a given drive side along the ground and  $r$  is the drive wheel radius

$$\begin{aligned}(rF) &= \frac{GK_t}{R}V - \frac{G^2K_t}{K_vR} \left(\frac{v}{r}\right) \\ rF &= \frac{GK_t}{R}V - \frac{G^2K_t}{K_vRr}v \\ F &= \frac{GK_t}{Rr}V - \frac{G^2K_t}{K_vRr^2}v \\ F &= -\frac{G^2K_t}{K_vRr^2}v + \frac{GK_t}{Rr}V\end{aligned}$$

Therefore, for each side of the robot

$$\begin{aligned}F_l &= -\frac{G_l^2K_t}{K_vRr^2}v_l + \frac{G_lK_t}{Rr}V_l \\ F_r &= -\frac{G_r^2K_t}{K_vRr^2}v_r + \frac{G_rK_t}{Rr}V_r\end{aligned}$$

where the  $l$  and  $r$  subscripts denote the side of the robot to which each variable corresponds.

Let  $C_1 = -\frac{G_l^2K_t}{K_vRr^2}$ ,  $C_2 = \frac{G_lK_t}{Rr}$ ,  $C_3 = -\frac{G_r^2K_t}{K_vRr^2}$ , and  $C_4 = \frac{G_rK_t}{Rr}$ .

$$F_l = C_1v_l + C_2V_l \quad (13.28)$$

$$F_r = C_3v_r + C_4V_r \quad (13.29)$$

First, find the sum of forces.

$$\begin{aligned}\sum F &= ma \\ F_l + F_r &= m\dot{v} \\ F_l + F_r &= m\frac{\dot{v}_l + \dot{v}_r}{2} \\ \frac{2}{m}(F_l + F_r) &= \dot{v}_l + \dot{v}_r \\ \dot{v}_l &= \frac{2}{m}(F_l + F_r) - \dot{v}_r\end{aligned} \quad (13.30)$$

Next, find the sum of torques.

$$\begin{aligned}\sum \tau &= J\dot{\omega} \\ \tau_l + \tau_r &= J\left(\frac{\dot{v}_r - \dot{v}_l}{2r_b}\right)\end{aligned}$$

where  $r_b$  is the radius of the differential drive.

$$(-r_bF_l) + (r_bF_r) = J\frac{\dot{v}_r - \dot{v}_l}{2r_b}$$

$$\begin{aligned}
-r_b F_l + r_b F_r &= \frac{J}{2r_b} (\dot{v}_r - \dot{v}_l) \\
-F_l + F_r &= \frac{J}{2r_b^2} (\dot{v}_r - \dot{v}_l) \\
\frac{2r_b^2}{J} (-F_l + F_r) &= \dot{v}_r - \dot{v}_l \\
\dot{v}_r &= \dot{v}_l + \frac{2r_b^2}{J} (-F_l + F_r)
\end{aligned}$$

Substitute in equation (13.30) for  $\dot{v}_l$  to obtain an expression for  $\dot{v}_r$ .

$$\begin{aligned}
\dot{v}_r &= \left( \frac{2}{m} (F_l + F_r) - \dot{v}_r \right) + \frac{2r_b^2}{J} (-F_l + F_r) \\
2\dot{v}_r &= \frac{2}{m} (F_l + F_r) + \frac{2r_b^2}{J} (-F_l + F_r) \\
\dot{v}_r &= \frac{1}{m} (F_l + F_r) + \frac{r_b^2}{J} (-F_l + F_r) \tag{13.31}
\end{aligned}$$

$$\begin{aligned}
\dot{v}_r &= \frac{1}{m} F_l + \frac{1}{m} F_r - \frac{r_b^2}{J} F_l + \frac{r_b^2}{J} F_r \\
\dot{v}_r &= \left( \frac{1}{m} - \frac{r_b^2}{J} \right) F_l + \left( \frac{1}{m} + \frac{r_b^2}{J} \right) F_r \tag{13.32}
\end{aligned}$$

Substitute equation (13.31) back into equation (13.30) to obtain an expression for  $\dot{v}_l$ .

$$\begin{aligned}
\dot{v}_l &= \frac{2}{m} (F_l + F_r) - \left( \frac{1}{m} (F_l + F_r) + \frac{r_b^2}{J} (-F_l + F_r) \right) \\
\dot{v}_l &= \frac{1}{m} (F_l + F_r) - \frac{r_b^2}{J} (-F_l + F_r) \\
\dot{v}_l &= \frac{1}{m} (F_l + F_r) + \frac{r_b^2}{J} (F_l - F_r) \\
\dot{v}_l &= \frac{1}{m} F_l + \frac{1}{m} F_r + \frac{r_b^2}{J} F_l - \frac{r_b^2}{J} F_r \\
\dot{v}_l &= \left( \frac{1}{m} + \frac{r_b^2}{J} \right) F_l + \left( \frac{1}{m} - \frac{r_b^2}{J} \right) F_r \tag{13.33}
\end{aligned}$$

Now, plug the expressions for  $F_l$  and  $F_r$  into equation (13.32).

$$\begin{aligned}
\dot{v}_r &= \left( \frac{1}{m} - \frac{r_b^2}{J} \right) F_l + \left( \frac{1}{m} + \frac{r_b^2}{J} \right) F_r \\
\dot{v}_r &= \left( \frac{1}{m} - \frac{r_b^2}{J} \right) (C_1 v_l + C_2 V_l) + \left( \frac{1}{m} + \frac{r_b^2}{J} \right) (C_3 v_r + C_4 V_r) \tag{13.34}
\end{aligned}$$

Now, plug the expressions for  $F_l$  and  $F_r$  into equation (13.33).

$$\begin{aligned}
\dot{v}_l &= \left( \frac{1}{m} + \frac{r_b^2}{J} \right) F_l + \left( \frac{1}{m} - \frac{r_b^2}{J} \right) F_r \\
\dot{v}_l &= \left( \frac{1}{m} + \frac{r_b^2}{J} \right) (C_1 v_l + C_2 V_l) + \left( \frac{1}{m} - \frac{r_b^2}{J} \right) (C_3 v_r + C_4 V_r) \tag{13.35}
\end{aligned}$$

This model will be converted to state-space notation in section 8.6.

### 13.6.2 Calculating constants

#### Moment of inertia $J$

We'll use empirical measurements of linear and angular velocity to determine  $J$ . First, we'll derive the equation required to perform a linear regression using velocity test data.

$$\tau_1 = \mathbf{r} \times \mathbf{F}$$

$$\tau_1 = rma$$

where  $\tau_1$  is the torque applied by a drive motor during only linear acceleration,  $r$  is the wheel radius,  $m$  is the robot mass, and  $a$  is the linear acceleration.

$$\tau_2 = I\alpha$$

where  $\tau_2$  is the torque applied by a drive motor during only angular acceleration,  $I$  is the moment of inertia (same as  $J$ ), and  $\alpha$  is the angular acceleration. If a constant voltage is applied during both the linear and angular acceleration tests,  $\tau_1 = \tau_2$ . Therefore,

$$rma = I\alpha$$

Integrate with respect to time.

$$rmv + C_1 = I\omega + C_2$$

$$rmv = I\omega + C_3$$

$$v = \frac{I}{rm}\omega + C_3 \quad (13.36)$$

where  $v$  is linear velocity and  $\omega$  is angular velocity.  $C_1$ ,  $C_2$ , and  $C_3$  are arbitrary constants of integration that won't be needed. The test procedure is as follows.

1. Run the drivetrain forward at a constant voltage. Record the linear velocity over time using encoders.
2. Rotate the drivetrain around its center by applying the same voltage as the linear acceleration test with the motors driving in opposite directions. Record the angular velocity over time using a gyroscope.
3. Perform a linear regression of linear velocity versus angular velocity. The slope of this line has the form  $\frac{I}{rm}$  as per equation (13.36).
4. Multiply the slope by  $rm$  to obtain a least squares estimate of  $I$ .



## 14. Lagrangian mechanics examples

A **model** is a set of differential equations describing how the **system** behaves over time. There are two common approaches for developing them.

1. Collecting data on the physical system's behavior and performing **system** identification with it.
2. Using physics to derive the **system's** model from first principles.

This chapter covers the second approach using Lagrangian mechanics.

We suggest reading *An introduction to Lagrangian and Hamiltonian Mechanics* by Simon J.A. Malham for the basics [27]. Then, we'll apply Lagrangian mechanics to FRC mechanisms in particular.

The **models** derived here should cover most types of motion seen on an FRC robot. Furthermore, they can be easily tweaked to describe many types of mechanisms just by pattern-matching. There's only so many ways to hook up a mass to a motor in FRC. The flywheel **model** can be used for spinning mechanisms, the elevator **model** can be used for spinning mechanisms transformed to linear motion, and the single-jointed arm **model** can be used for rotating servo mechanisms (it's just the flywheel **model** augmented with a position **state**).

These **models** assume all motor controllers driving DC brushed motors are set to brake mode instead of coast mode. Brake mode behaves the same as coast mode except where the applied voltage is zero. In brake mode, the motor leads are shorted together to prevent movement. In coast mode, the motor leads are an open circuit.

- 14.1 DC brushed motor**
- 14.2 Elevator**
- 14.3 Flywheel**
- 14.4 Single-jointed arm**
- 14.5 Pendulum**
- 14.6 Differential drive**

## 15. System identification

For now, this chapter just covers how to obtain state-space models for common mechanisms from a feedforward model derived from performance data.

### 15.1 1-DOF mechanism model

$$\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u}$$

$$\mathbf{x} = \text{velocity} \quad \dot{\mathbf{x}} = \text{acceleration} \quad \mathbf{u} = \text{voltage}$$

We want to derive what  $\mathbf{A}$  and  $\mathbf{B}$  are from the following feedforward model

$$\mathbf{u} = K_v v + K_a a$$

where  $K_v$  and  $K_a$  are constants that should be measured from empirical quasistatic velocity tests and acceleration tests.

$K_v$  is a proportional constant that describes how much voltage is required to maintain a given constant velocity by offsetting the electromagnetic resistance of the motor and any friction that increases linearly with speed (viscous drag). The relationship between speed and voltage (at constant acceleration) is linear for permanent-magnet DC motors in the FRC operating regime.

$K_a$  is a proportional constant that describes how much voltage is required to induce a given acceleration in the motor shaft. As with  $K_v$ , the relationship between voltage and acceleration (at constant velocity) is linear.

Let  $\mathbf{u} = K_v v$  be the input that makes the system move at a constant velocity  $v$ . Therefore,  $\mathbf{x} = v$  and  $\dot{\mathbf{x}} = \mathbf{0}$ . Substitute these into the state-space model.

$$\mathbf{0} = \mathbf{A}v + \mathbf{B}(K_v v) \quad (15.1)$$

Let  $\mathbf{u} = K_v v + K_a a$  be the input that accelerates the system by  $a$  from an initial velocity of  $v$ . Therefore,  $\mathbf{x} = v$  and  $\dot{\mathbf{x}} = a$ . Substitute these into the state-space model.

$$a = \mathbf{A}v + \mathbf{B}(K_v v + K_a a) \quad (15.2)$$

Subtract equation (15.1) from equation (15.2).

$$\begin{aligned} a &= \mathbf{B}(K_a a) \\ 1 &= \mathbf{B}K_a \\ \mathbf{B} &= \frac{1}{K_a} \end{aligned}$$

Substitute  $\mathbf{B}$  back into (15.1) to obtain  $\mathbf{A}$ .

$$\begin{aligned} \mathbf{0} &= \mathbf{A}v + \left(\frac{1}{K_a}\right)(K_v v) \\ \mathbf{0} &= \mathbf{A}v + \frac{K_v}{K_a}v \\ -\frac{K_v}{K_a}v &= \mathbf{A}v \\ \mathbf{A} &= -\frac{K_v}{K_a} \end{aligned}$$

A model with position and velocity states would be

**Theorem 15.1.1 — 1-DOF mechanism position model.**

$$\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u}$$

$$\mathbf{x} = \begin{bmatrix} \text{position} \\ \text{velocity} \end{bmatrix} \quad \mathbf{u} = [\text{voltage}]$$

$$\dot{\mathbf{x}} = \begin{bmatrix} 0 & 1 \\ 0 & -\frac{K_v}{K_a} \end{bmatrix} \mathbf{x} + \begin{bmatrix} 0 \\ \frac{1}{K_a} \end{bmatrix} \mathbf{u} \quad (15.3)$$

## 15.2 Drivetrain velocity model

$$\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u}$$

$$\mathbf{x} = \begin{bmatrix} \text{left velocity} \\ \text{right velocity} \end{bmatrix} \quad \dot{\mathbf{x}} = \begin{bmatrix} \text{left acceleration} \\ \text{right acceleration} \end{bmatrix} \quad \mathbf{u} = \begin{bmatrix} \text{left voltage} \\ \text{right voltage} \end{bmatrix}$$

We want to derive what  $\mathbf{A}$  and  $\mathbf{B}$  are from linear and angular feedforward models. Since the left and right dynamics are symmetric, we'll guess the model has the form

$$\mathbf{A} = \begin{bmatrix} A_1 & A_2 \\ A_2 & A_1 \end{bmatrix} \quad \mathbf{B} = \begin{bmatrix} B_1 & B_2 \\ B_2 & B_1 \end{bmatrix}$$

Let  $\mathbf{u} = [K_{v,linear}v \quad K_{v,linear}v]^T$  be the input that makes both sides of the drivetrain move at a constant velocity  $v$ . Therefore,  $\mathbf{x} = [v \quad v]^T$  and  $\dot{\mathbf{x}} = [0 \quad 0]^T$ . Substitute these into the state-space model.

$$\begin{bmatrix} 0 \\ 0 \end{bmatrix} = \begin{bmatrix} A_1 & A_2 \\ A_2 & A_1 \end{bmatrix} \begin{bmatrix} v \\ v \end{bmatrix} + \begin{bmatrix} B_1 & B_2 \\ B_2 & B_1 \end{bmatrix} \begin{bmatrix} K_{v,linear}v \\ K_{v,linear}v \end{bmatrix}$$

Since the column vectors contain the same element, the elements in the second row can be rearranged.

$$\begin{bmatrix} 0 \\ 0 \end{bmatrix} = \begin{bmatrix} A_1 & A_2 \\ A_1 & A_2 \end{bmatrix} \begin{bmatrix} v \\ v \end{bmatrix} + \begin{bmatrix} B_1 & B_2 \\ B_1 & B_2 \end{bmatrix} \begin{bmatrix} K_{v,linear}v \\ K_{v,linear}v \end{bmatrix}$$

Since the rows are linearly dependent, we can use just one of them.

$$0 = [A_1 \quad A_2] v + [B_1 \quad B_2] K_{v,linear}v$$

$$0 = [v \quad v \quad K_{v,linear}v \quad K_{v,linear}v] \begin{bmatrix} A_1 \\ A_2 \\ B_1 \\ B_2 \end{bmatrix}$$

$$0 = [1 \quad 1 \quad K_{v,linear} \quad K_{v,linear}] \begin{bmatrix} A_1 \\ A_2 \\ B_1 \\ B_2 \end{bmatrix}$$

Let  $\mathbf{u} = [K_{v,linear}v + K_{a,linear}a \quad K_{v,linear}v + K_{a,linear}a]^T$  be the input that accelerates both sides of the drivetrain by  $a$  from an initial velocity of  $v$ . Therefore,  $\mathbf{x} = [v \quad v]^T$  and  $\dot{\mathbf{x}} = [a \quad a]^T$ . Substitute these into the state-space model.

$$\begin{bmatrix} a \\ a \end{bmatrix} = \begin{bmatrix} A_1 & A_2 \\ A_2 & A_1 \end{bmatrix} \begin{bmatrix} v \\ v \end{bmatrix} + \begin{bmatrix} B_1 & B_2 \\ B_2 & B_1 \end{bmatrix} \begin{bmatrix} K_{v,linear}v + K_{a,linear}a \\ K_{v,linear}v + K_{a,linear}a \end{bmatrix}$$

Since the column vectors contain the same element, the elements in the second row can be rearranged.

$$\begin{bmatrix} a \\ a \end{bmatrix} = \begin{bmatrix} A_1 & A_2 \\ A_1 & A_2 \end{bmatrix} \begin{bmatrix} v \\ v \end{bmatrix} + \begin{bmatrix} B_1 & B_2 \\ B_1 & B_2 \end{bmatrix} \begin{bmatrix} K_{v,linear}v + K_{a,linear}a \\ K_{v,linear}v + K_{a,linear}a \end{bmatrix}$$

Since the rows are linearly dependent, we can use just one of them.

$$a = [A_1 \quad A_2] v + [B_1 \quad B_2] [K_{v,linear}v + K_{a,linear}a]$$

$$a = \begin{bmatrix} v & v & K_{v,linear}v + K_{a,linear}a & K_{v,linear} + K_{a,linear}a \end{bmatrix} \begin{bmatrix} A_1 \\ A_2 \\ B_1 \\ B_2 \end{bmatrix}$$

Let  $\mathbf{u} = [-K_{v,angular}v \quad K_{v,angular}v]^T$  be the input that rotates the drivetrain in place where each wheel has a constant velocity  $v$ . Therefore,  $\mathbf{x} = [-v \quad v]^T$  and  $\dot{\mathbf{x}} = [0 \quad 0]^T$ .

$$\begin{aligned} \begin{bmatrix} 0 \\ 0 \end{bmatrix} &= \begin{bmatrix} A_1 & A_2 \\ A_2 & A_1 \end{bmatrix} \begin{bmatrix} -v \\ v \end{bmatrix} + \begin{bmatrix} B_1 & B_2 \\ B_2 & B_1 \end{bmatrix} \begin{bmatrix} -K_{v,angular}v \\ K_{v,angular}v \end{bmatrix} \\ \begin{bmatrix} 0 \\ 0 \end{bmatrix} &= \begin{bmatrix} -A_1 & A_2 \\ -A_2 & A_1 \end{bmatrix} \begin{bmatrix} v \\ v \end{bmatrix} + \begin{bmatrix} -B_1 & B_2 \\ -B_2 & B_1 \end{bmatrix} \begin{bmatrix} K_{v,angular}v \\ K_{v,angular}v \end{bmatrix} \\ \begin{bmatrix} 0 \\ 0 \end{bmatrix} &= \begin{bmatrix} -A_1 & A_2 \\ A_1 & -A_2 \end{bmatrix} \begin{bmatrix} v \\ v \end{bmatrix} + \begin{bmatrix} -B_1 & B_2 \\ B_1 & -B_2 \end{bmatrix} \begin{bmatrix} K_{v,angular}v \\ K_{v,angular}v \end{bmatrix} \end{aligned}$$

Since the column vectors contain the same element, the elements in the second row can be rearranged.

$$\begin{bmatrix} 0 \\ 0 \end{bmatrix} = \begin{bmatrix} -A_1 & A_2 \\ -A_1 & A_2 \end{bmatrix} \begin{bmatrix} v \\ v \end{bmatrix} + \begin{bmatrix} -B_1 & B_2 \\ -B_1 & B_2 \end{bmatrix} \begin{bmatrix} K_{v,angular}v \\ K_{v,angular}v \end{bmatrix}$$

Since the rows are linearly dependent, we can use just one of them.

$$\begin{aligned} 0 &= [-A_1 \quad A_2] v + [-B_1 \quad B_2] K_{v,angular}v \\ 0 &= -vA_1 + vA_2 - K_{v,angular}vB_1 + K_{v,angular}vB_2 \\ 0 &= [-v \quad v \quad -K_{v,angular}v \quad K_{v,angular}v] \begin{bmatrix} A_1 \\ A_2 \\ B_1 \\ B_2 \end{bmatrix} \\ 0 &= [-1 \quad 1 \quad -K_{v,angular} \quad K_{v,angular}] \begin{bmatrix} A_1 \\ A_2 \\ B_1 \\ B_2 \end{bmatrix} \end{aligned}$$

Let  $\mathbf{u} = [-K_{v,angular}v - K_{a,angular}a \quad K_{v,angular}v + K_{a,angular}a]^T$  be the input that rotates the drivetrain in place where each wheel has an initial speed of  $v$  and accelerates by  $a$ . Therefore,  $\mathbf{x} = [-v \quad v]^T$  and  $\dot{\mathbf{x}} = [-a \quad a]^T$ .

$$\begin{aligned} \begin{bmatrix} -a \\ a \end{bmatrix} &= \begin{bmatrix} A_1 & A_2 \\ A_2 & A_1 \end{bmatrix} \begin{bmatrix} -v \\ v \end{bmatrix} + \begin{bmatrix} B_1 & B_2 \\ B_2 & B_1 \end{bmatrix} \begin{bmatrix} -K_{v,angular}v - K_{a,angular}a \\ K_{v,angular}v + K_{a,angular}a \end{bmatrix} \\ \begin{bmatrix} -a \\ a \end{bmatrix} &= \begin{bmatrix} -A_1 & A_2 \\ -A_2 & A_1 \end{bmatrix} \begin{bmatrix} v \\ v \end{bmatrix} + \begin{bmatrix} -B_1 & B_2 \\ -B_2 & B_1 \end{bmatrix} \begin{bmatrix} K_{v,angular}v + K_{a,angular}a \\ K_{v,angular}v + K_{a,angular}a \end{bmatrix} \\ \begin{bmatrix} -a \\ a \end{bmatrix} &= \begin{bmatrix} -A_1 & A_2 \\ A_1 & -A_2 \end{bmatrix} \begin{bmatrix} v \\ v \end{bmatrix} + \begin{bmatrix} -B_1 & B_2 \\ B_1 & -B_2 \end{bmatrix} \begin{bmatrix} K_{v,angular}v + K_{a,angular}a \\ K_{v,angular}v + K_{a,angular}a \end{bmatrix} \end{aligned}$$

Since the column vectors contain the same element, the elements in the second row can be rearranged.

$$\begin{bmatrix} -a \\ -a \end{bmatrix} = \begin{bmatrix} -A_1 & A_2 \\ -A_1 & A_2 \end{bmatrix} \begin{bmatrix} v \\ v \end{bmatrix} + \begin{bmatrix} -B_1 & B_2 \\ -B_1 & B_2 \end{bmatrix} \begin{bmatrix} K_{v,angular}v + K_{a,angular}a \\ K_{v,angular}v + K_{a,angular}a \end{bmatrix}$$

Since the rows are linearly dependent, we can use just one of them.

$$\begin{aligned}
 -a &= [-A_1 \ A_2] v + [-B_1 \ B_2] [K_{v,angular}v + K_{a,angular}a] \\
 -a &= -vA_1 + vA_2 - (K_{v,angular}v + K_{a,angular}a)B_1 + K_{v,angular}v + K_{a,angular}a)B_2 \\
 -a &= [-v \ v \ -(K_{v,angular}v + K_{a,angular}a) \ K_{v,angular}v + K_{a,angular}a] \begin{bmatrix} A_1 \\ A_2 \\ B_1 \\ B_2 \end{bmatrix} \\
 a &= [v \ -v \ K_{v,angular}v + K_{a,angular}a \ -(K_{v,angular}v + K_{a,angular}a)] \begin{bmatrix} A_1 \\ A_2 \\ B_1 \\ B_2 \end{bmatrix}
 \end{aligned}$$

Now stack the rows.

$$\begin{bmatrix} 0 \\ a \\ 0 \\ a \end{bmatrix} = \begin{bmatrix} 1 & 1 & K_{v,linear} & K_{v,linear} \\ v & v & K_{v,linear}v + K_{a,linear}a & K_{v,linear}v + K_{a,linear}a \\ -1 & 1 & -K_{v,angular} & K_{v,angular} \\ v & -v & K_{v,angular}v + K_{a,angular}a & -(K_{v,angular}v + K_{a,angular}a) \end{bmatrix} \begin{bmatrix} A_1 \\ A_2 \\ B_1 \\ B_2 \end{bmatrix}$$

Solve for matrix elements with Wolfram Alpha. Let  $b = K_{v,linear}$ ,  $c = K_{a,linear}$ ,  $d = K_{v,angular}$ , and  $f = K_{a,angular}$ .

inverse of  $\{\{1, 1, b, b\}, \{v, v, b v + c a, b v + c a\}, \{-1, 1, -d, d\}, \{v, -v, d v + f a, -(d v + f a)\}\} * \{\{0\}, \{a\}, \{0\}, \{a\}\}$

$$\begin{bmatrix} A_1 \\ A_2 \\ B_1 \\ B_2 \end{bmatrix} = \frac{1}{2cf} \begin{bmatrix} -cd - bf \\ cd - bf \\ c + f \\ f - c \end{bmatrix}$$

$$\begin{bmatrix} A_1 \\ A_2 \\ B_1 \\ B_2 \end{bmatrix} = \frac{1}{2K_{a,linear}K_{a,angular}} \begin{bmatrix} -K_{a,linear}K_{v,angular} - K_{v,linear}K_{a,angular} \\ K_{a,linear}K_{v,angular} - K_{v,linear}K_{a,angular} \\ K_{a,linear} + K_{a,angular} \\ K_{a,angular} - K_{a,linear} \end{bmatrix}$$

To summarize,

**Theorem 15.2.1 — Drivetrain velocity model.**

$$\dot{\mathbf{x}} = \mathbf{Ax} + \mathbf{Bu}$$

$$\mathbf{x} = \begin{bmatrix} \text{left velocity} \\ \text{right velocity} \end{bmatrix} \quad \mathbf{u} = \begin{bmatrix} \text{left voltage} \\ \text{right voltage} \end{bmatrix}$$

$$\dot{\mathbf{x}} = \begin{bmatrix} A_1 & A_2 \\ A_2 & A_1 \end{bmatrix} \mathbf{x} + \begin{bmatrix} B_1 & B_2 \\ B_2 & B_1 \end{bmatrix} \mathbf{u}$$

$$\begin{bmatrix} A_1 \\ A_2 \\ B_1 \\ B_2 \end{bmatrix} = \frac{1}{2K_{a,linear}K_{a,angular}} \begin{bmatrix} -K_{a,linear}K_{v,angular} - K_{v,linear}K_{a,angular} \\ K_{a,linear}K_{v,angular} - K_{v,linear}K_{a,angular} \\ K_{a,linear} + K_{a,angular} \\ K_{a,angular} - K_{a,linear} \end{bmatrix} \quad (15.4)$$



If  $K_v$  and  $K_a$  are the same for both the linear and angular cases, it devolves to the one-dimensional case. This means the left and right sides are decoupled.

$$\begin{bmatrix} A_1 \\ A_2 \\ B_1 \\ B_2 \end{bmatrix} = \frac{1}{2K_a K_a} \begin{bmatrix} -K_a K_v - K_v K_a \\ K_a K_v - K_v K_a \\ K_a + K_a \\ K_a - K_a \end{bmatrix}$$

$$\begin{bmatrix} A_1 \\ A_2 \\ B_1 \\ B_2 \end{bmatrix} = \frac{1}{2K_a K_a} \begin{bmatrix} -2K_v K_a \\ 0 \\ 2K_a \\ 0 \end{bmatrix}$$

$$\begin{bmatrix} A_1 \\ A_2 \\ B_1 \\ B_2 \end{bmatrix} = \begin{bmatrix} -\frac{K_v}{K_a} \\ 0 \\ \frac{1}{K_a} \\ 0 \end{bmatrix}$$

*This page intentionally left blank*



# Motion planning

<b>16</b>	<b>Motion profiles</b> .....	<b>169</b>
16.1	1-DOF motion profiles	
16.2	2-DOF motion profiles	
<b>17</b>	<b>Configuration spaces</b> .....	<b>173</b>
17.1	Introduction	
17.2	Waypoint planning	
17.3	Waypoint traversal	
17.4	State machine validation with safe sets	
<b>18</b>	<b>Trajectory optimization</b> .....	<b>177</b>

*This page intentionally left blank*

## 16. Motion profiles

If smooth, predictable motion of a **system** over time is desired, it's best to only change a **system's** **reference** as fast as the **system** is able to physically move. Motion profiles, also known as trajectories, are used for this purpose. For multi-state **systems**, each **state** is given its own trajectory. Since these **states** are usually position and velocity, they share different derivatives of the same profile.

### 16.1 1-DOF motion profiles

Trapezoid profiles (figure 16.1) and S-curve profiles (figure 16.2) are the most commonly used motion profiles in FRC for point-to-point movements with one degree of freedom (1 DOF). These profiles accelerate the **system** to a maximum velocity from rest, then decelerate it later such that the final acceleration velocity, are zero at the moment the **system** arrives at the desired location.




Figure 16.1: Trapezoid profile




Figure 16.2: S-curve profile

These profiles are given their names based on the shape of their velocity trajectory. The trapezoid profile has a velocity trajectory shaped like a trapezoid and the S-curve profile has a velocity trajectory

shaped like an S-curve.

In the context of a point-to-point move, a full S-curve consists of seven distinct phases of motion. Phase I starts moving the **system** from rest at a linearly increasing acceleration until it reaches the maximum acceleration. In phase II, the profile accelerates at this maximum acceleration rate until it must start decreasing as it approaches the maximum velocity. This occurs in phase III when the acceleration linearly decreases until it reaches zero. In phase IV, the velocity is constant until deceleration begins, at which point the profiles decelerates in a manner symmetric to phases I, II and III.

A trapezoid profile, on the other hand, has three phases. It is a subset of an S-curve profile, having only the phases corresponding to phase II of the S-curve profile (constant acceleration), phase IV (constant velocity), and phase VI (constant deceleration). This reduced number of phases underscores the difference between these two profiles: the S-curve profile has extra motion phases which transition between periods of acceleration and periods of nonacceleration; the trapezoid profile has instantaneous transitions between these phases. This can be seen in the acceleration graphs of the corresponding velocity profiles for these two profile types.

### 16.1.1 Jerk

The motion characteristic that defines the change in acceleration, or transitional period, is known as “jerk”. Jerk is defined as the rate of change of acceleration with time. In a trapezoid profile, the jerk (change in acceleration) is infinite at the phase transitions, while in the S-curve profile the jerk is a constant value, spreading the change in acceleration over a period of time.

From figures 16.1 and 16.2, we can see S-curve profiles are smoother than trapezoid profiles. Why, however, do the S-curve profile result in less load oscillation? For a given load, the higher the jerk, the greater the amount of unwanted vibration energy will be generated, and the broader the frequency spectrum of the vibration’s energy will be.

This means that more rapid changes in acceleration induce more powerful vibrations, and more vibrational modes will be excited. Because vibrational energy is absorbed in the system mechanics, it may cause an increase in **settling time** or reduced accuracy if the vibration frequency matches resonances in the mechanical system.

### 16.1.2 Profile selection

Since trapezoid profiles spend their time at full acceleration or full deceleration, they are, from the standpoint of profile execution, faster than S-curve profiles. However, if this “all on”/“all off” approach causes an increase in settling time, the advantage is lost. Often, only a small amount of “S” (transition between acceleration and no acceleration) can substantially reduce induced vibration. Therefore to optimize throughput, the S-curve profile must be tuned for each a given load and given desired transfer speed.

What S-curve form is right for a given **system**? On an application by application basis, the specific choice of the form of the S-curve will depend on the mechanical nature of the **system** and the desired performance specifications. For example, in medical applications which involve liquid transfers that should not be jostled, it would be appropriate to choose a profile with no phase II and VI segment at all. Instead the acceleration transitions would be spread out as far as possible, thereby maximizing smoothness.

In other applications involving high speed pick and place, overall transfer speed is most important, so a good choice might be an S-curve with transition phases (phases I, III, V, and VII) that are five to fifteen percent of phase II and VI. In this case, the S-curve profile will add a small amount of time to

the overall transfer time. However, the reduced load oscillation at the end of the move considerably decreases the total effective transfer time. Trial and error using a motion measurement system is generally the best way to determine the right amount of “S” because modeling high frequency dynamics is difficult to do accurately.

Another consideration is whether that “S” segment will actually lead to smoother control of the [system](#). If the high frequency dynamics at play are negligible, one can use the simpler trapezoid profile.

**R** S-curve profiles are unnecessary for FRC mechanisms. Motors in FRC effectively have first-order velocity dynamics because the inductance effects are on the order of microseconds; FRC dynamics operate on the order of milliseconds. First-order motor models can achieve the instantaneous acceleration changes of trapezoid profiles because voltage is electromotive force, which is analogous to acceleration. That is, we can instantaneously achieve any desired acceleration with a finite voltage, and we can follow any trapezoid profile perfectly with only feedforward control.

### 16.1.3 Profile equations

The trapezoid profile uses the following equations.

$$x(t) = x_0 + v_0t + \frac{1}{2}at^2$$

$$v(t) = v_0 + at$$

where  $x(t)$  is the position at time  $t$ ,  $x_0$  is the initial position,  $v_0$  is the initial velocity, and  $a$  is the acceleration at time  $t$ . The S-curve profile equations also include jerk.

$$x(t) = x_0 + v_0t + \frac{1}{2}at^2 + \frac{1}{6}jt^3$$

$$v(t) = v_0 + at + \frac{1}{2}jt^2$$

$$a(t) = a_0 + jt$$

where  $j$  is the jerk at time  $t$ ,  $a(t)$  is the acceleration at time  $t$ , and  $a_0$  is the initial acceleration.

More derivations are required to determine when to start and stop the different profile phases. The derivations for a trapezoid profile are in appendix F.4. We’re omitting an S-curve profile derivation because the continuous acceleration over time that S-curves provide isn’t required for FRC mechanisms.

### 16.1.4 Other profile types

The ultimate goal of any profile is to match the profile’s motion characteristics to the desired application. Trapezoidal and S-curve profiles work well when the [system](#)’s torque response curve is fairly flat. In other words, when the output torque does not vary that much over the range of velocities the [system](#) will be experiencing. This is true for most servo motor systems, whether DC brushed or DC brushless.

Step motors, however, do not have flat torque/speed curves. Torque output is nonlinear, sometimes has a large drop at a location called the “mid-range instability”, and generally drops off at higher velocities.

Mid-range instability occurs at the step frequency when the motor’s natural resonance frequency matches the current step rate. To address mid-range instability, the most common technique is to use

a nonzero starting velocity. This means that the profile instantly “jumps” to a programmed velocity upon initial acceleration, and while decelerating. While crude, this technique sometimes provides better results than a smooth ramp for zero, particularly for systems that do not use a microstepping drive technique.

To address torque drop-off at higher velocities, a parabolic profile can be used. The corresponding acceleration curve has the smallest acceleration when the velocity is highest. This is a good match for stepper motors because there is less torque available at higher speeds. However, notice that starting and ending accelerations are very high, and there is no “S” phase where the acceleration smoothly transitions to zero. If load oscillation is a problem, parabolic profiles may not work as well as an S-curve despite the fact that a standard S-curve profile is not optimized for a stepper motor from the standpoint of the torque/speed curve.

### 16.1.5 Further reading

FRC teams 254 and 971 gave a talk at FIRST World Championships in 2015 about motion profiles [1].

## 16.2 2-DOF motion profiles

In FRC, point-to-point movements with two degrees of freedom (2 DOFs) are almost always within the context of drivetrains where the two degrees of freedom are the  $x$  and  $y$  axes.

A *path* is a set of  $(x, y)$  points for the drivetrain to follow. A *trajectory* is a path that includes both the states (e.g., position and velocity) and control inputs (e.g., voltage) of the drivetrain as functions of time.

Currently, the most common form of multidimensional trajectory planning in FRC is based on polynomial splines. The splines determine the path of the trajectory, and the path is parameterized by a trapezoidal motion profile to create a trajectory. *A Dive into WPILib Trajectories* by Declan Freeman-Gleason introduces 2-DOF trajectory planning in FRC using polynomial splines [17].

*Planning Motion Trajectories for Mobile Robots Using Splines* by Christoph Sprunk provides a more general treatment of spline-based trajectory generation [29].



## 17. Configuration spaces

### 17.1 Introduction

When a robot can interfere with itself, we need a motion profiling solution that ensures the robot doesn't destroy itself. Now that we've demonstrated various methods of motion profiling, how can we incorporate safe zones into the planning process or implement mechanism collision avoidance?

1-DOF systems are straightforward. We define the minimum and maximum position constraints for the arm, elevator, etc. and ensure we stay between them. To do so, we might use some combination of:

1. Rejecting, coercing, or clamping setpoints so that they are always within the valid range
2. Soft limits on the speed controller
3. Limit switches, and/or physical hard stops

Multi-DOF systems are more complex. In the 2-DOF case (e.g., an arm with a shoulder and a wrist, or an elevator and an arm), each DOF has some limits that are independent of the rest of the system (e.g., min and max angles), but there are also dependent constraints (e.g., if the shoulder is angled down, the wrist must be angled up to avoid hitting the ground). Examples of such constraints could include:

- Minimum/maximum angles
- Maximum extension rules
- Robot chassis
- Angles that require an infeasible amount of holding torque

One intuitive way to think about this is to envision an N-D space (2D for 2 DOFs, etc.) where the  $x$  and  $y$  axes are the positions of the degrees of freedom. A given point  $(x, y)$  can either be a valid configuration or an invalid configuration (meaning it violates one or more constraints). So, our 2D plot may have regions (half-planes, rectangles, etc.) representing constraints.




Figure 17.1: Elevator-arm configuration space with independent constraints

## 17.2 Waypoint planning

Our first example has 2 DOFs where all of the constraints are independent (minimum/maximum limits on each axis), as shown in figure 17.1.

Motion planning and control in this example is simple; just make sure all controller references are always inside the box of valid states.

Now let's make it more interesting. Say that if the arm is near the middle of travel (pointing straight down), the elevator must be above a certain height. Otherwise, the arm intersects the robot chassis. This configuration space would look like figure 17.2.

Let's consider motion planning in the second example. Say the current state of our system is  $x$  and our goal state is  $r$  as shown in figure 17.3.

Notice that the elevator height at the current state and the goal is identical. Do we just have to move the arm? Moving this way will sweep the system into the constraint we defined for preventing self-intersection with the chassis. Instead, we need to plan a sequence of references to execute that only pass through valid states. Figure 17.4 shows an example.

$a$  and  $b$  are intermediate waypoints we added to ensure that the whole system moves in a safe manner. Considering again our toy example, the elevator goes up, then the arm rotates underneath, then the elevator goes back down. There are many possible ways to generate this path (or other valid paths), including some sort of search (discretize the plot into a grid and find a valid path using breadth-first search or A\*) or hard-coded rules to handle different regions of the constraint space.




Figure 17.2: Elevator-arm configuration space requiring elevator to be above a certain height when arm is pointing down




Figure 17.3: Elevator-arm configuration space with initial state  $x$  and goal state  $r$




Figure 17.4: Elevator-arm configuration space with path between initial state  $x$  and final state  $r$

### 17.3 Waypoint traversal

Once we have a sequence of waypoints, there are a few options for traversing them:

1. Generate trajectories for each DOF and time-synchronize them. This ensures the mechanism follows the “diagonal lines” in the path above. The upside of this approach is it can yield the fastest (time-optimal) coordinated movements possible. The downside is that the motion planning is “open loop” – if one of the DOFs lags behind its trajectory, it’s possible that the system may still end up in an invalid state. In practice, we include some buffer around our references to ensure that tracking error doesn’t immediately lead to violated constraints. We are making our trajectories more robust to uncertainty.
2. Perform movements sequentially. That is, move from  $x$  to  $a$ , and only start moving toward  $b$  once the path from the current system state to  $b$  is a straight line that is collision-free. This gives robustness to control error, but may result in unnecessary stops or jerky movement compared to the optimized, open-loop trajectory.

This planning approach generalizes to an arbitrary number of DOFs and is essentially how industrial 7-DOF arms are operated.

### 17.4 State machine validation with safe sets

Configuration spaces can also be used for state machine validation. The states of all the mechanisms, including solenoid actuation states, would be axes in a configuration space. A state machine unit test would define a valid path through the configuration space, send the desired events to the state machine, then ensure the robot took the correct path in response to each event for all iterations.

## 18. Trajectory optimization

To contextualize some definitions related to trajectory optimization, let's use the example of a drivetrain in FRC. A *path* is a set of  $(x, y)$  points for the **system** to follow. A *trajectory* is a path that includes both the states (e.g., position and velocity) and control inputs (e.g., voltage) of the **system** as functions of time. *Trajectory optimization* refers to a set of methods for finding the best choice of trajectory (for some mathematical definition of “best”) by selecting states and inputs of the **system** as functions of time.

Matthew Kelly has an approachable introduction to trajectory optimization on his website [21].

*This page intentionally left blank*



# Classical control theory

<b>19</b>	<b>Transfer functions</b> .....	<b>181</b>
19.1	Laplace transform	
19.2	Parts of a transfer function	
19.3	Transfer functions in feedback	
19.4	Classical vs modern control	
<b>20</b>	<b>Laplace domain analysis</b> .....	<b>189</b>
20.1	Projections	
20.2	Fourier transform	
20.3	Laplace transform	
20.4	Laplace transform definition	
20.5	Case study: steady-state error	
20.6	Case study: flywheel PID control	
20.7	Gain margin and phase margin	

*This page intentionally left blank*



## 19. Transfer functions

This chapter is intended to provide a framework within which to understand results from the mathematical machinery of modern control as well as vocabulary to communicate that understanding. We will briefly discuss what transfer functions are, how the locations of poles and zeroes affect **system response** and stability, and how controllers affect pole locations.

### 19.1 Laplace transform

For an introduction to Laplace transforms and the geometric intuition behind transfer functions, we recommend watching Zach Star's video "What does the Laplace Transform really tell us? A visual explanation (plus applications)" (21 minutes) [30]. A more mathematical introduction is presented later in chapter 20.

### 19.2 Parts of a transfer function

A transfer function maps an input coordinate to an output coordinate in the Laplace domain. These can be obtained by applying the Laplace transform to a differential equation and rearranging the terms to obtain a ratio of the output variable to the input variable. Equation (19.1) is an example of a transfer function.

$$H(s) = \frac{\overbrace{(s - 9 + 9i)(s - 9 - 9i)}^{\text{zeroes}}}{\underbrace{s(s + 10)}_{\text{poles}}} \quad (19.1)$$

#### 19.2.1 Poles and zeroes

The roots of factors in the numerator of a transfer function are called *zeroes* because they make the transfer function approach zero. Likewise, the roots of factors in the denominator of a transfer function are called *poles* because they make the transfer function approach infinity; on a 3D graph, these look like the poles of a circus tent (see figure 19.1).




Figure 19.1: Equation (19.1) plotted in 3D

When the factors of the denominator are broken apart using partial fraction expansion into something like  $\frac{A}{s+a} + \frac{B}{s+b}$ , the constants  $A$  and  $B$  are called residues, which determine how much each pole contributes to the **system response**.

The factors representing poles are each the Laplace transform of a decaying exponential<sup>1</sup>. That means the time domain responses of **systems** comprise decaying exponentials (e.g.,  $y = e^{-t}$ ).

**R** Imaginary poles and zeroes always come in complex conjugate pairs (e.g.,  $-2 + 3i$ ,  $-2 - 3i$ ).

The locations of the closed-loop poles in the complex plane determine the stability of the **system**. Each pole represents a frequency mode of the **system**, and their location determines how much of each response is induced for a given input frequency. Figure 19.2 shows the **impulse responses** in the time domain for transfer functions with various pole locations. They all have an initial condition of 1.

Location	Stability
Left Half-plane (LHP)	Stable
Imaginary axis	Marginally stable
Right Half-plane (RHP)	Unstable

Table 19.1: Pole location and stability

When a **system** is stable, its output may oscillate but it converges to steady-state. When a **system** is marginally stable, its output oscillates at a constant amplitude forever. When a **system** is unstable, its output grows without bound.

<sup>1</sup>We are handwaving Laplace transform derivations because they are complicated and neither relevant nor useful.




Figure 19.2: Impulse response vs pole location

### 19.2.2 Nonminimum phase zeroes

While poles in the RHP are unstable, the same is not true for zeroes. They can be characterized by the **system** initially moving in the wrong direction before heading toward the **reference**. Since the poles always move toward the zeroes, zeroes impose a “speed limit” on the **system response** because it takes a finite amount of time to move the wrong direction, then change directions.

One example of this type of **system** is bicycle steering. Try riding a bicycle without holding the handle bars, then poke the right handle; the bicycle turns right. Furthermore, if one is holding the handlebars and wants to turn left, rotating the handlebars counterclockwise will make the bicycle fall toward the right. The rider has to lean into the turn and overpower the nonminimum phase dynamics to go the desired direction.

Another example is a Segway. To move forward by some distance, the Segway must first roll backward to rotate the Segway forward. Once the Segway starts falling in that direction, it begins rolling forward to avoid falling over until it reaches the target distance. At that point, the Segway increases its forward speed to pitch backward and slow itself down. To come to a stop, the Segway rolls backward again to level itself out.

### 19.2.3 Pole-zero cancellation

Pole-zero cancellation occurs when a pole and zero are located at the same place in the s-plane. This effectively eliminates the contribution of each to the **system** dynamics. By placing poles and zeroes at various locations (this is done by placing transfer functions in series), we can eliminate undesired **system** dynamics. While this may appear to be a useful design tool at first, there are major caveats. Most of these are due to **model** uncertainty resulting in poles which aren't in the locations the controls designer expected.

Notch filters are typically used to dampen a specific range of frequencies in the **system response**. If its band is made too narrow, it can still leave the undesirable dynamics, but now you can no longer measure them in the response. They are still happening, but they are what's called *unobservable*.

Never pole-zero cancel unstable or nonminimum phase dynamics. If the **model** doesn't quite reflect reality, an attempted pole cancellation by placing a nonminimum phase zero results in the pole still moving to the zero placed next to it. You have the same dynamics as before, but the pole is also stuck where it is no matter how much **feedback gain** is applied. For an attempted nonminimum phase zero cancellation, you have effectively placed an unstable pole that's unobservable. This means the **system**

will be going unstable and blowing up, but you won't be able to detect this and react to it.

Keep in mind when making design decisions that the **model** likely isn't perfect. The whole point of feedback control is to be robust to this kind of uncertainty.

### 19.3 Transfer functions in feedback

For **controllers** to **regulate** a **system** or **track** a reference, they must be placed in positive or negative feedback with the **plant** (whether to use positive or negative depends on the **plant** in question). Stable feedback loops attempt to make the **output** equal the **reference**.




Figure 19.3: Feedback controller block diagram

$X(s)$	input	$H$	measurement transfer function
$K$	controller gain	$Y(s)$	output
$G$	plant transfer function		

The transfer function of figure 19.3, a **control system** diagram with feedback, from input to output is

$$G_{cl}(s) = \frac{Y(s)}{X(s)} = \frac{KG}{1 + KGH} \quad (19.2)$$

The numerator is the **open-loop gain** and the denominator is one plus the gain around the feedback loop, which may include parts of the **open-loop gain** (see appendix F.1 for a derivation). As another example, the transfer function from the input to the **error** is

$$G_{cl}(s) = \frac{E(s)}{X(s)} = \frac{1}{1 + KGH} \quad (19.3)$$

The roots of the denominator of  $G_{cl}(s)$  are different from those of the open-loop transfer function  $KG(s)$ . These are called the closed-loop poles.

#### 19.3.1 Root locus

In closed-loop, the poles can be moved around by adjusting the controller gain, but the zeroes stay put. The root locus shows where the poles will go as the gain for a P controller is increased and tells us for what range of gains the controller will be stable. As the controller gain is increased, poles can move toward negative infinity (figure 19.4), move toward each other then split toward asymptotes (figure 19.5), or move toward zeroes (figure 19.6). The **system** in figure 19.6 becomes unstable as the gain is increased.

We won't be using root locus plots for any of our control systems analysis later, but it does help provide an intuition for what **controllers** actually do to a **system**.

If poles are much farther left in the LHP than the typical **system** dynamics exhibit, they can be considered negligible. Every **system** has some form of unmodeled high frequency, nonlinear dynamics, but they can be safely ignored depending on the operating regime.




Figure 19.4: Root locus showing pole moving toward negative infinity




Figure 19.5: Root locus showing poles moving toward asymptotes




Figure 19.6: Root locus of equation (19.1) showing poles moving toward zeroes.

To demonstrate this, consider the transfer function for a second-order DC brushed motor (a CIM motor) from voltage to velocity.

$$G(s) = \frac{K}{(Js + b)(Ls + R) + K^2}$$

where  $J = 3.2284 \times 10^{-6} \text{ kg-m}^2$ ,  $b = 3.5077 \times 10^{-6} \text{ N-m-s}$ ,  $K_e = K_t = 0.0181 \text{ V/rad/s}$ ,  $R = 0.0902 \Omega$ , and  $L = 230 \times 10^{-6} \text{ H}$ .

This system is second-order because it has two poles; one corresponds to velocity and the other corresponds to current. To make position the output instead, we'll multiply by  $\frac{1}{s}$  because position is the integral of velocity.<sup>2</sup>

$$G(s) = \frac{K}{s((Js + b)(Ls + R) + K^2)}$$

This plant has the root locus shown in figure 19.7. In proportional feedback, the plant is unstable for large values of  $K$ . However, if we remove the unstable pole by setting  $L$  in the transfer function to zero, we get the root locus in figure 19.8. For small values of  $K$ , both systems are stable and have nearly indistinguishable step responses due to the exceedingly small contribution from the fast pole

<sup>2</sup>This also has the effect of augmenting the system with a position state, making it a third-order system.

(see figures 19.9 and 19.10). The high frequency dynamics only cause instability for large values of  $K$  that induce fast **system responses**. In other words, the **system responses** of the second-order model and its first-order approximation are similar for low frequency operating regimes.




Figure 19.7: Root locus of second-order DC brushed motor plant augmented with position




Figure 19.8: Root locus of first-order DC brushed motor plant augmented with position




Figure 19.9: Step response of second-order DC brushed motor plant augmented with position




Figure 19.10: Step response of first-order DC brushed motor plant augmented with position

Why can't unstable poles close to the origin be ignored in the same way? The response of high frequency stable poles decays rapidly. Unstable poles, on the other hand, represent unstable dynamics which cause the **system output** to grow to infinity. Regardless of how slow these unstable dynamics are, they will eventually dominate the response.

## 19.4 Classical vs modern control

State-space notation provides a more convenient and compact way to model and analyze **systems** with multiple **inputs** and **outputs**. For a **system** with  $p$  **inputs** and  $q$  **outputs**, we would have to write  $q \times p$  transfer functions to represent it. Not only is the resulting algebra unwieldy, but it only works for linear **systems**. Including nonzero initial conditions complicates the algebra even more. State-space representation uses the time domain instead of the Laplace domain, so it can model nonlinear **systems**<sup>3</sup> and trivially supports nonzero initial conditions.

<sup>3</sup>This book focuses on analysis and control of linear **systems**. See chapter 7 for more on nonlinear control.

If modern control theory is so great and classical control theory isn't needed to use it, why learn classical control theory at all? We teach classical control theory because it provides a framework within which to understand results from the mathematical machinery of modern control as well as vocabulary with which to communicate that understanding. For example, faster poles (poles moved to the left in the  $s$ -plane) mean faster decay, and oscillation means there is at least one pair of complex conjugate poles. Not only can you describe what happened succinctly, but you know why it happened from a theoretical perspective.

*This page intentionally left blank*



## 20. Laplace domain analysis

This chapter uses Laplace transforms and transfer functions to analyze properties of control systems like *steady-state error*.

These case studies cover various aspects of PID control using the algebraic approach of transfer functions. For this, we'll be using equation (20.1), the transfer function for a PID controller.

$$K(s) = K_p + \frac{K_i}{s} + K_d s \quad (20.1)$$

First, we will define mathematically what Laplace transforms and transfer functions are, which is rooted in the concept of orthogonal projections.

### 20.1 Projections

Consider a two-dimensional Euclidean space  $\mathbb{R}^2$  shown in figure 20.1 (each  $\mathbb{R}$  is a dimension whose domain is the set of real numbers, so  $\mathbb{R}^2$  is the standard x-y plane).



Ordinarily, we notate points in this plane by their components in the set of basis vectors  $\{\hat{i}, \hat{j}\}$ , where  $\hat{i}$  (pronounced i-hat) is the unit vector in the positive  $x$  direction and  $\hat{j}$  is the unit vector in the positive  $y$  direction. Figure 20.2 shows an example vector  $\mathbf{v}$  in this basis.

How do we find the coordinates of  $\mathbf{v}$  in this basis mathematically? As long as the basis is *orthogonal* (i.e., the basis vectors are at right angles to each other), we simply take the *orthogonal projection* of  $\mathbf{v}$  onto  $\hat{i}$  and  $\hat{j}$ . Intuitively, this means finding “the amount of  $\mathbf{v}$  that points in the direction of  $\hat{i}$  or  $\hat{j}$ ”. Note that a set of orthogonal vectors have a dot product of zero with respect to each other.

More formally, we can calculate projections with the dot product - the projection of  $\mathbf{v}$  onto any other vector  $\mathbf{w}$  is as follows.

$$\text{proj}_{\mathbf{w}} \mathbf{v} = \frac{\mathbf{v} \cdot \mathbf{w}}{|\mathbf{w}|}$$

Since  $\hat{i}$  and  $\hat{j}$  are *unit vectors*, their magnitudes are 1 so the coordinates of  $\mathbf{v}$  are  $\mathbf{v} \cdot \hat{i}$  and  $\mathbf{v} \cdot \hat{j}$ .

Figure 20.1: Euclidean space  $\mathbb{R}^2$ Figure 20.2:  $\mathbf{v}$  with basis set  $\{\hat{i}, \hat{j}\}$ 

We can use this same process to find the coordinates of  $\mathbf{v}$  in *any* orthogonal basis. For example, imagine the basis  $\{\hat{i} + \hat{j}, \hat{i} - \hat{j}\}$  - the coordinates in this basis are given by  $\frac{\mathbf{v} \cdot (\hat{i} + \hat{j})}{\sqrt{2}}$  and  $\frac{\mathbf{v} \cdot (\hat{i} - \hat{j})}{\sqrt{2}}$ . Let's “unwrap” the formula for dot product and look a bit more closely.

$$\frac{\mathbf{v} \cdot (\hat{i} + \hat{j})}{\sqrt{2}} = \frac{1}{\sqrt{2}} \sum_{i=0}^n \mathbf{v}_i (\hat{i} + \hat{j})_i$$

where the subscript  $i$  denotes which component of each vector and  $n$  is the total number of components. To change coordinates, we expanded both  $\mathbf{v}$  and  $\hat{i} + \hat{j}$  in a basis, multiplied their components, and added them up. Here's a more concrete example. Let  $\mathbf{v} = 2\hat{i} + 1.5\hat{j}$  from figure 20.2. First, we'll project  $\mathbf{v}$  onto the  $\hat{i} + \hat{j}$  basis vector.

$$\begin{aligned} \frac{\mathbf{v} \cdot (\hat{i} + \hat{j})}{\sqrt{2}} &= \frac{1}{\sqrt{2}} (2\hat{i} \cdot \hat{i} + 1.5\hat{j} \cdot \hat{j}) \\ \frac{\mathbf{v} \cdot (\hat{i} + \hat{j})}{\sqrt{2}} &= \frac{1}{\sqrt{2}} (2 + 1.5) \\ \frac{\mathbf{v} \cdot (\hat{i} + \hat{j})}{\sqrt{2}} &= \frac{3.5}{\sqrt{2}} \end{aligned}$$

$$\frac{\mathbf{v} \cdot (\hat{i} + \hat{j})}{\sqrt{2}} = \frac{3.5\sqrt{2}}{2}$$

$$\frac{\mathbf{v} \cdot (\hat{i} + \hat{j})}{\sqrt{2}} = 1.75\sqrt{2}$$

Next, we'll project  $\mathbf{v}$  onto the  $\hat{i} - \hat{j}$  basis vector.

$$\frac{\mathbf{v} \cdot (\hat{i} - \hat{j})}{\sqrt{2}} = \frac{1}{\sqrt{2}}(2\hat{i} \cdot \hat{i} - 1.5\hat{j} \cdot \hat{j})$$

$$\frac{\mathbf{v} \cdot (\hat{i} - \hat{j})}{\sqrt{2}} = \frac{1}{\sqrt{2}}(2 - 1.5)$$

$$\frac{\mathbf{v} \cdot (\hat{i} - \hat{j})}{\sqrt{2}} = \frac{0.5}{\sqrt{2}}$$

$$\frac{\mathbf{v} \cdot (\hat{i} - \hat{j})}{\sqrt{2}} = \frac{0.5\sqrt{2}}{2}$$

$$\frac{\mathbf{v} \cdot (\hat{i} - \hat{j})}{\sqrt{2}} = 0.25\sqrt{2}$$

Figure 20.3 shows this result geometrically with respect to the basis  $\{\hat{i} + \hat{j}, \hat{i} - \hat{j}\}$ .




Figure 20.3:  $\mathbf{v}$  with basis  $\{\hat{i} + \hat{j}, \hat{i} - \hat{j}\}$

The previous example was only a change of coordinates in a finite-dimensional vector space. However, as we will see, the core idea does not change much when we move to more complicated structures. Observe the formula for the Fourier transform.

$$\hat{f}(\xi) = \int_{-\infty}^{\infty} f(x)e^{-2\pi i x \xi} dx \text{ where } \xi \in \mathbb{R}$$

This is fundamentally the same formula we had before.  $f(x)$  has taken the place of  $v_n$ ,  $e^{-2\pi i x \xi}$  has taken the place of  $(\hat{i} + \hat{j})_i$ , and the sum over  $i$  has turned into an integral over  $dx$ , but the underlying concept is the same. To change coordinates in a *function space*, we simply take the orthogonal projection onto our new basis *functions*. In the case of the Fourier transform, the function basis is the

family of functions of the form  $f(x) = e^{-2\pi i x \xi}$  for  $\xi \in \mathbb{R}$ . Since these functions are oscillatory at a frequency determined by  $\xi$ , we can think of this as a “frequency basis”.

**R** Watch the “Abstract vector spaces” video from 3Blue1Brown’s *Essence of linear algebra* series (17 minutes) [2] for a more geometric introduction to using functions as a basis.

Now, the Laplace transform is somewhat more complicated - as it turns out, the Fourier basis is orthogonal, so the analogy to the simpler vector space holds almost-precisely. The Laplace transform is *not* orthogonal, so we can’t interpret it *strictly* as a change of coordinates in the traditional sense. However, the intuition is the same: we are taking the orthogonal projection of our original function onto the functions of our new basis set.

$$F(s) = \int_0^{\infty} f(t)e^{-st} dt, \text{ where } s \in \mathbb{C}$$

Here, it becomes obvious that the Laplace transform is a *generalization* of the Fourier transform in that the basis family is strictly larger (we have allowed the “frequency” parameter to take *complex* values, as opposed to merely *real* values). As a result, the Laplace basis contains functions that grow and decay, while the Fourier basis does not.

## 20.2 Fourier transform

The Fourier transform decomposes a function of time into its component frequencies. Each of these frequencies is part of what’s called a *basis*. These basis waveforms can be multiplied by their respective contribution amount and summed to produce the original signal (this weighted sum is called a linear combination). In other words, the Fourier transform provides a way for us to determine, given some signal, what frequencies can we add together and in what amounts to produce the original signal.

Think of an Fmajor4 chord which has the notes  $F_4$  (349.23 Hz),  $A_4$  (440 Hz), and  $C_5$  (261.63 Hz). The waveform over time looks like figure 20.4.

Notice how this complex waveform can be represented just by three frequencies. They show up as Dirac delta functions<sup>1</sup> in the frequency domain with the area underneath them equal to their contribution (see figure 20.5).

---

<sup>1</sup>The Dirac delta function is zero everywhere except at the origin. The nonzero region has an infinitesimal width and has a height such that the area within that region is 1.




Figure 20.4: Frequency decomposition of Fmajor4 chord




Figure 20.5: Fourier transform of Fmajor4 chord

### 20.3 Laplace transform

The Laplace domain is a generalization of the frequency domain that has the frequency ( $j\omega$ ) on the imaginary y-axis and a real number on the x-axis, yielding a two-dimensional coordinate system. We represent coordinates in this space as a complex number  $s = \sigma + j\omega$ . The real part  $\sigma$  corresponds to the x-axis and the imaginary part  $j\omega$  corresponds to the y-axis (see figure 20.6).




Figure 20.6: Laplace domain

To extend our analogy of each coordinate being represented by some basis, we now have the y coordinate representing the oscillation frequency of the **system response** (the frequency domain) and also the x coordinate representing the speed at which that oscillation decays and the **system** converges to zero (i.e., a decaying exponential). Figure 19.2 shows this for various points.

If we move the component frequencies in the Fmajor4 chord example parallel to the real axis to  $\sigma = -25$ , the resulting time domain response attenuates according to the decaying exponential  $e^{-25t}$  (see figure 20.7).

Note that this explanation as a basis isn't exact because the Laplace basis isn't orthogonal (that is, the x and y coordinates affect each other and have cross-talk). In the frequency domain, we had a basis of sine waves that we represented as delta functions in the frequency domain. Each frequency contribution was independent of the others. In the Laplace domain, this is not the case; a pure exponential is  $\frac{1}{s-a}$  (a rational function where  $a$  is a real number) instead of a delta function. This function is nonzero at points that aren't actually frequencies present in the time domain. Figure 20.8 demonstrates this, which shows the Laplace transform of the Fmajor4 chord plotted in 3D.

Notice how the values of the function around each component frequency decrease according to  $\frac{1}{\sqrt{x^2+y^2}}$  in the  $x$  and  $y$  directions (in just the  $x$  direction, it would be  $\frac{1}{x}$ ).



Figure 20.7: Fmajor4 chord at  $\sigma = 0$  and  $\sigma = -25$ 

Figure 20.8: Laplace transform of Fmajor4 chord plotted in 3D

## 20.4 Laplace transform definition

The Laplace transform of a function  $f(t)$  is defined as

$$\mathcal{L}\{f(t)\} = F(s) = \int_0^{\infty} f(t)e^{-st} dt$$

We won't be computing any Laplace transforms by hand using this formula (everyone in the real world looks these up in a table anyway). Common Laplace transforms (assuming zero initial conditions) are shown in table 20.1. Of particular note are the Laplace transforms for the derivative, unit step<sup>2</sup>, and exponential decay. We can see that a derivative is equivalent to multiplying by  $s$ , and an integral is equivalent to multiplying by  $\frac{1}{s}$ .

	Time domain	Laplace domain
Linearity	$a f(t) + b g(t)$	$a F(s) + b G(s)$
Convolution	$(f * g)(t)$	$F(s) G(s)$
Derivative	$f'(t)$	$s F(s)$
$n^{\text{th}}$ derivative	$f^{(n)}(t)$	$s^n F(s)$
Unit step	$u(t)$	$\frac{1}{s}$
Ramp	$t u(t)$	$\frac{1}{s^2}$
Exponential decay	$e^{-\alpha t} u(t)$	$\frac{1}{s+\alpha}$

Table 20.1: Common Laplace transforms and Laplace transform properties with zero initial conditions

## 20.5 Case study: steady-state error

To demonstrate the problem of [steady-state error](#), we will use a DC brushed motor controlled by a velocity PID controller. A DC brushed motor has a transfer function from voltage ( $V$ ) to angular velocity ( $\dot{\theta}$ ) of

$$G(s) = \frac{\dot{\Theta}(s)}{V(s)} = \frac{K}{(Js + b)(Ls + R) + K^2} \quad (20.2)$$

First, we'll try controlling it with a P controller defined as

$$K(s) = K_p$$

When these are in unity feedback, the transfer function from the input voltage to the error is

$$\begin{aligned} \frac{E(s)}{V(s)} &= \frac{1}{1 + K(s)G(s)} \\ E(s) &= \frac{1}{1 + K(s)G(s)} V(s) \\ E(s) &= \frac{1}{1 + (K_p) \left( \frac{K}{(Js+b)(Ls+R)+K^2} \right)} V(s) \end{aligned}$$

<sup>2</sup>The unit step  $u(t)$  is defined as 0 for  $t < 0$  and 1 for  $t \geq 0$ .



$$E(s) = \frac{1}{1 + \frac{K_p K}{(Js+b)(Ls+R)+K^2}} V(s)$$

The steady-state of a transfer function can be found via

$$\lim_{s \rightarrow 0} sH(s) \quad (20.3)$$

since steady-state has an input frequency of zero.

$$\begin{aligned} e_{ss} &= \lim_{s \rightarrow 0} sE(s) \\ e_{ss} &= \lim_{s \rightarrow 0} s \frac{1}{1 + \frac{K_p K}{(Js+b)(Ls+R)+K^2}} V(s) \\ e_{ss} &= \lim_{s \rightarrow 0} s \frac{1}{1 + \frac{K_p K}{(Js+b)(Ls+R)+K^2}} \frac{1}{s} \\ e_{ss} &= \lim_{s \rightarrow 0} \frac{1}{1 + \frac{K_p K}{(Js+b)(Ls+R)+K^2}} \\ e_{ss} &= \frac{1}{1 + \frac{K_p K}{(J(0)+b)(L(0)+R)+K^2}} \\ e_{ss} &= \frac{1}{1 + \frac{K_p K}{bR+K^2}} \end{aligned} \quad (20.4)$$

Notice that the **steady-state error** is nonzero. To fix this, an integrator must be included in the controller.

$$K(s) = K_p + \frac{K_i}{s}$$

The same steady-state calculations are performed as before with the new controller.

$$\begin{aligned} \frac{E(s)}{V(s)} &= \frac{1}{1 + K(s)G(s)} \\ E(s) &= \frac{1}{1 + K(s)G(s)} V(s) \\ E(s) &= \frac{1}{1 + \left(K_p + \frac{K_i}{s}\right) \left(\frac{K}{(Js+b)(Ls+R)+K^2}\right)} \left(\frac{1}{s}\right) \\ e_{ss} &= \lim_{s \rightarrow 0} s \frac{1}{1 + \left(K_p + \frac{K_i}{s}\right) \left(\frac{K}{(Js+b)(Ls+R)+K^2}\right)} \left(\frac{1}{s}\right) \\ e_{ss} &= \lim_{s \rightarrow 0} \frac{1}{1 + \left(K_p + \frac{K_i}{s}\right) \left(\frac{K}{(Js+b)(Ls+R)+K^2}\right)} \\ e_{ss} &= \lim_{s \rightarrow 0} \frac{1}{1 + \left(K_p + \frac{K_i}{s}\right) \left(\frac{K}{(Js+b)(Ls+R)+K^2}\right)} \frac{s}{s} \\ e_{ss} &= \lim_{s \rightarrow 0} \frac{s}{s + (K_p s + K_i) \left(\frac{K}{(Js+b)(Ls+R)+K^2}\right)} \\ e_{ss} &= \frac{0}{0 + (K_p(0) + K_i) \left(\frac{K}{(J(0)+b)(L(0)+R)+K^2}\right)} \end{aligned}$$

$$e_{ss} = \frac{0}{K_i \frac{K}{bR+K^2}}$$

The denominator is nonzero, so  $e_{ss} = 0$ . Therefore, an integrator is required to eliminate **steady-state error** in all cases for this **model**.

It should be noted that  $e_{ss}$  in equation (20.4) approaches zero for  $K_p = \infty$ . This is known as a bang-bang controller. In practice, an infinite switching frequency cannot be achieved, but it may be close enough for some performance specifications.

## 20.6 Case study: flywheel PID control

PID controllers typically control voltage to a motor in FRC independent of the equations of motion of that motor. For position PID control, large values of  $K_p$  can lead to overshoot and  $K_d$  is commonly used to reduce overshoots. Let's consider a flywheel controlled with a standard PID controller. Why wouldn't  $K_d$  provide damping for velocity overshoots in this case?

PID control is designed to control second-order and first-order **systems** well. It can be used to control a lot of things, but struggles when given higher order **systems**. It has three degrees of freedom. Two are used to place the two poles of the **system**, and the third is used to remove steady-state error. With higher order **systems** like a one input, seven **state system**, there aren't enough degrees of freedom to place the **system's** poles in desired locations. This will result in poor control.

The math for PID doesn't assume voltage, a motor, etc. It defines an output based on derivatives and integrals of its input. We happen to use it for motors because it actually works pretty well for it because motors are second-order **systems**.

The following math will be in continuous time, but the same ideas apply to discrete time. This is all assuming a velocity controller.

Our simple motor model hooked up to a mass is

$$V = IR + \frac{\omega}{K_v} \quad (20.5)$$

$$\tau = IK_t \quad (20.6)$$

$$\tau = J \frac{d\omega}{dt} \quad (20.7)$$

For an explanation of where these equations come from, read section 13.1.

First, we'll solve for  $\frac{d\omega}{dt}$  in terms of  $V$ .

Substitute equation (20.6) into equation (20.5).

$$V = IR + \frac{\omega}{K_v}$$

$$V = \left( \frac{\tau}{K_t} \right) R + \frac{\omega}{K_v}$$

Substitute in equation (20.7).

$$V = \frac{\left( J \frac{d\omega}{dt} \right)}{K_t} R + \frac{\omega}{K_v}$$

Solve for  $\frac{d\omega}{dt}$ .

$$\begin{aligned} V &= \frac{J \frac{d\omega}{dt}}{K_t} R + \frac{\omega}{K_v} \\ V - \frac{\omega}{K_v} &= \frac{J \frac{d\omega}{dt}}{K_t} R \\ \frac{d\omega}{dt} &= \frac{K_t}{JR} \left( V - \frac{\omega}{K_v} \right) \\ \frac{d\omega}{dt} &= -\frac{K_t}{JRK_v} \omega + \frac{K_t}{JR} V \end{aligned}$$

Now take the Laplace transform. Because the Laplace transform is a linear operator, we can take the Laplace transform of each term individually. Based on table 20.1,  $\frac{d\omega}{dt}$  becomes  $s\omega$  and  $\omega(t)$  and  $V(t)$  become  $\omega(s)$  and  $V(s)$  respectively (the parenthetical notation has been dropped for clarity).

$$s\omega = -\frac{K_t}{JRK_v} \omega + \frac{K_t}{JR} V \quad (20.8)$$

Solve for the transfer function  $H(s) = \frac{\omega}{V}$ .

$$\begin{aligned} s\omega &= -\frac{K_t}{JRK_v} \omega + \frac{K_t}{JR} V \\ \left( s + \frac{K_t}{JRK_v} \right) \omega &= \frac{K_t}{JR} V \\ \frac{\omega}{V} &= \frac{\frac{K_t}{JR}}{s + \frac{K_t}{JRK_v}} \end{aligned}$$

That gives us a pole at  $-\frac{K_t}{JRK_v}$ , which is actually stable. Notice that there is only one pole.

First, we'll use a simple P loop.

$$V = K_p(\omega_{goal} - \omega)$$

Substitute this controller into equation (20.8).

$$s\omega = -\frac{K_t}{JRK_v} \omega + \frac{K_t}{JR} K_p(\omega_{goal} - \omega)$$

Solve for the transfer function  $H(s) = \frac{\omega}{\omega_{goal}}$ .

$$\begin{aligned} s\omega &= -\frac{K_t}{JRK_v} \omega + \frac{K_t K_p}{JR} (\omega_{goal} - \omega) \\ s\omega &= -\frac{K_t}{JRK_v} \omega + \frac{K_t K_p}{JR} \omega_{goal} - \frac{K_t K_p}{JR} \omega \\ \left( s + \frac{K_t}{JRK_v} + \frac{K_t K_p}{JR} \right) \omega &= \frac{K_t K_p}{JR} \omega_{goal} \\ \frac{\omega}{\omega_{goal}} &= \frac{\frac{K_t K_p}{JR}}{\left( s + \frac{K_t}{JRK_v} + \frac{K_t K_p}{JR} \right)} \end{aligned}$$

This has a pole at  $-\left(\frac{K_t}{JRK_v} + \frac{K_tK_p}{JR}\right)$ . Assuming that that quantity is negative (i.e., we are stable), that pole corresponds to a time constant of  $\frac{1}{\frac{K_t}{JRK_v} + \frac{K_tK_p}{JR}}$ .

As can be seen above, a flywheel has a single pole. It therefore only needs a single pole controller to place all of its poles anywhere.

**R** This analysis assumes that the motor is well coupled to the mass and that the time constant of the inductor is small enough that it doesn't factor into the motor equations. In Austin Schuh's experience with 971's robots, these are pretty good assumptions.

Next, we'll try a PD loop. (This will use a perfect derivative, but anyone following along closely already knows that we can't really take a derivative here, so the math will need to be updated at some point. We could switch to discrete time and pick a differentiation method, or pick some other way of modeling the derivative.)

$$V = K_p(\omega_{goal} - \omega) + K_d s(\omega_{goal} - \omega)$$

Substitute this controller into equation (20.8).

$$\begin{aligned} s\omega &= -\frac{K_t}{JRK_v}\omega + \frac{K_t}{JR}(K_p(\omega_{goal} - \omega) + K_d s(\omega_{goal} - \omega)) \\ s\omega &= -\frac{K_t}{JRK_v}\omega + \frac{K_tK_p}{JR}(\omega_{goal} - \omega) + \frac{K_tK_d s}{JR}(\omega_{goal} - \omega) \\ s\omega &= -\frac{K_t}{JRK_v}\omega + \frac{K_tK_p}{JR}\omega_{goal} - \frac{K_tK_p}{JR}\omega + \frac{K_tK_d s}{JR}\omega_{goal} - \frac{K_tK_d s}{JR}\omega \end{aligned}$$

Collect the common terms on separate sides and refactor.

$$\begin{aligned} s\omega + \frac{K_tK_d s}{JR}\omega + \frac{K_t}{JRK_v}\omega + \frac{K_tK_p}{JR}\omega &= \frac{K_tK_p}{JR}\omega_{goal} + \frac{K_tK_d s}{JR}\omega_{goal} \\ \left(s\left(1 + \frac{K_tK_d}{JR}\right) + \frac{K_t}{JRK_v} + \frac{K_tK_p}{JR}\right)\omega &= \frac{K_t}{JR}(K_p + K_d s)\omega_{goal} \\ \frac{\omega}{\omega_{goal}} &= \frac{\frac{K_t}{JR}(K_p + K_d s)}{\left(s\left(1 + \frac{K_tK_d}{JR}\right) + \frac{K_t}{JRK_v} + \frac{K_tK_p}{JR}\right)} \end{aligned}$$

So, we added a zero at  $-\frac{K_p}{K_d}$  and moved our pole to  $-\frac{\frac{K_t}{JRK_v} + \frac{K_tK_p}{JR}}{1 + \frac{K_tK_d}{JR}}$ . This isn't progress. We've added more complexity to our **system** and, practically speaking, gotten nothing good in return. Zeros should be avoided if at all possible because they amplify unwanted high frequency modes of the **system** and are noisier the faster the **system** is sampled. At least this is a stable zero, but it's still undesirable.

In summary, derivative doesn't help on an ideal flywheel.  $K_d$  may compensate for unmodeled dynamics such as accelerating projectiles slowing the flywheel down, but that effect may also increase

recovery time;  $K_d$  drives the acceleration to zero in the undesired case of negative acceleration as well as the actually desired case of positive acceleration.

We'll cover a superior compensation method much later in subsection 5.12.2 that avoids zeroes in the **controller**, doesn't act against the desired control action, and facilitates better **tracking**.

## 20.7 Gain margin and phase margin

One generally needs to learn about Bode plots and Nyquist plots to truly understand gain and phase margin and their origins, but those plots are large topics unto themselves. Since we won't be using either of them for controller design, we'll just cover what gain and phase margin are in a general sense and how they are used.

Gain margin and phase margin are two metrics for measuring a **system's** relative stability. Gain and phase margin are the amounts by which the closed-loop gain and phase can be varied respectively before the **system** becomes unstable. In a sense, they are safety margins for when unmodeled dynamics affect the **system response**.

For a more thorough explanation of gain and phase margin, watch Brian Douglas's video on them [16]. He has other videos too on classical control methods like Bode and Nyquist plots that we recommend.

*This page intentionally left blank*



# Appendices

<b>A</b>	<b>Simplifying block diagrams</b> .....	<b>205</b>
A.1	Cascaded blocks	
A.2	Combining blocks in parallel	
A.3	Removing a block from a feedforward loop	
A.4	Eliminating a feedback loop	
A.5	Removing a block from a feedback loop	
<b>B</b>	<b>Installing Python packages</b> .....	<b>209</b>
B.1	Windows instructions	
B.2	Linux instructions	
<b>C</b>	<b>Linear-quadratic regulator</b> .....	<b>211</b>
C.1	Derivation	
C.2	Output feedback	
C.3	Implicit model following	
C.4	Time delay compensation	
<b>D</b>	<b>QR-weighted linear plant inversion</b> ..	<b>221</b>
D.1	Necessary theorems	
D.2	Setup	
D.3	Minimization	
<b>E</b>	<b>Steady-state feedforward</b> .....	<b>225</b>
E.1	Continuous case	
E.2	Discrete case	
E.3	Deriving steady-state input	
<b>F</b>	<b>Derivations</b> .....	<b>229</b>
F.1	Transfer function in feedback	
F.2	Zero-order hold for state-space	
F.3	Kalman filter as Luenberger observer	
F.4	Trapezoidal motion profile	
	<b>Glossary</b> .....	<b>234</b>
	<b>Bibliography</b> .....	<b>235</b>
	Online	
	Miscellaneous	
	<b>Index</b> .....	<b>239</b>

*This page intentionally left blank*



## A. Simplifying block diagrams

### A.1 Cascaded blocks

$$Y = (P_1 P_2)X \quad (\text{A.1})$$



Figure A.1: Cascaded blocks




Figure A.2: Simplified cascaded blocks

### A.2 Combining blocks in parallel

$$Y = P_1 X \pm P_2 X \quad (\text{A.2})$$




Figure A.3: Parallel blocks




Figure A.4: Simplified parallel blocks

**A.3 Removing a block from a feedforward loop**

$$Y = P_1X \pm P_2X \tag{A.3}$$




Figure A.5: Feedforward loop




Figure A.6: Transformed feedforward loop

**A.4 Eliminating a feedback loop**

$$Y = P_1(X \mp P_2Y) \tag{A.4}$$




Figure A.7: Feedback loop




Figure A.8: Simplified feedback loop

**A.5 Removing a block from a feedback loop**

$$Y = P_1(X \mp P_2Y) \quad (\text{A.5})$$




Figure A.9: Feedback loop




Figure A.10: Transformed feedback loop

*This page intentionally left blank*

## B. Installing Python packages

### B.1 Windows instructions

To install Python, download the installer for Python 3.5 or higher from <https://www.python.org/downloads/> and run it.

To install Python packages, run `py -3 -m pip install pkg` via `cmd.exe` or Powershell where `pkg` should be the name of the package. Packages can be upgraded with `py -3 -m pip install --user --upgrade pkg`.

### B.2 Linux instructions

To install Python, install the appropriate packages from table B.1 using your system's package manager.

Debian/Ubuntu	Arch Linux
python3	python
python3-pip	python-pip

Table B.1: Required system packages

To install Python packages, run `pip3 install --user pkg` where `pkg` should be the name of the package. Using `--user` makes installation not require root privileges. Packages can be upgraded with `pip3 install --user --upgrade pkg`.

*This page intentionally left blank*

## C. Linear-quadratic regulator

This appendix will go into more detail on the linear-quadratic regulator's derivation and interesting applications.

### C.1 Derivation

Let a continuous time linear system be defined as

$$\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u} \quad (\text{C.1})$$

with the cost function

$$J = \int_0^{\infty} \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \begin{bmatrix} \mathbf{Q} & \mathbf{N} \\ \mathbf{N}^T & \mathbf{R} \end{bmatrix} \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix} dt$$

where  $J$  represents a trade-off between state excursion and control effort with the weighting factors  $\mathbf{Q}$ ,  $\mathbf{R}$ , and  $\mathbf{N}$ .  $\mathbf{Q}$  is the weight matrix for error,  $\mathbf{R}$  is the weight matrix for control effort, and  $\mathbf{N}$  is a cross weight matrix between error and control effort.  $\mathbf{N}$  is commonly utilized when penalizing the output in addition to the state and input.

$$\begin{aligned} J &= \int_0^{\infty} \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \begin{bmatrix} \mathbf{Q}\mathbf{x} + \mathbf{N}\mathbf{u} \\ \mathbf{N}^T\mathbf{x} + \mathbf{R}\mathbf{u} \end{bmatrix} dt \\ J &= \int_0^{\infty} \begin{bmatrix} \mathbf{x}^T & \mathbf{u}^T \end{bmatrix} \begin{bmatrix} \mathbf{Q}\mathbf{x} + \mathbf{N}\mathbf{u} \\ \mathbf{N}^T\mathbf{x} + \mathbf{R}\mathbf{u} \end{bmatrix} dt \\ J &= \int_0^{\infty} (\mathbf{x}^T (\mathbf{Q}\mathbf{x} + \mathbf{N}\mathbf{u}) + \mathbf{u}^T (\mathbf{N}^T\mathbf{x} + \mathbf{R}\mathbf{u})) dt \end{aligned}$$

$$\begin{aligned}
J &= \int_0^{\infty} (\mathbf{x}^T \mathbf{Q} \mathbf{x} + \mathbf{x}^T \mathbf{N} \mathbf{u} + \mathbf{u}^T \mathbf{N}^T \mathbf{x} + \mathbf{u}^T \mathbf{R} \mathbf{u}) dt \\
J &= \int_0^{\infty} (\mathbf{x}^T \mathbf{Q} \mathbf{x} + \mathbf{x}^T \mathbf{N} \mathbf{u} + (\mathbf{x}^T \mathbf{N} \mathbf{u})^T + \mathbf{u}^T \mathbf{R} \mathbf{u}) dt \\
J &= \int_0^{\infty} (\mathbf{x}^T \mathbf{Q} \mathbf{x} + 2\mathbf{x}^T \mathbf{N} \mathbf{u} + \mathbf{u}^T \mathbf{R} \mathbf{u}) dt \\
J &= \int_0^{\infty} (\mathbf{x}^T \mathbf{Q} \mathbf{x} + \mathbf{u}^T \mathbf{R} \mathbf{u} + 2\mathbf{x}^T \mathbf{N} \mathbf{u}) dt
\end{aligned}$$

The feedback **control law** which minimizes  $J$  subject to the constraint  $\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u}$  is

$$\mathbf{u} = -\mathbf{K}\mathbf{x}$$

where  $\mathbf{K}$  is given by

$$\mathbf{K} = \mathbf{R}^{-1} (\mathbf{B}^T \mathbf{S} + \mathbf{N}^T)$$

and  $\mathbf{S}$  is found by solving the continuous time algebraic Riccati equation defined as

$$\mathbf{A}^T \mathbf{S} + \mathbf{S} \mathbf{A} - (\mathbf{S} \mathbf{B} + \mathbf{N}) \mathbf{R}^{-1} (\mathbf{B}^T \mathbf{S} + \mathbf{N}^T) + \mathbf{Q} = 0$$

or alternatively

$$\mathcal{A}^T \mathbf{S} + \mathbf{S} \mathcal{A} - \mathbf{S} \mathbf{B} \mathbf{R}^{-1} \mathbf{B}^T \mathbf{S} + \mathcal{Q} = 0$$

with

$$\begin{aligned}
\mathcal{A} &= \mathbf{A} - \mathbf{B} \mathbf{R}^{-1} \mathbf{N}^T \\
\mathcal{Q} &= \mathbf{Q} - \mathbf{N} \mathbf{R}^{-1} \mathbf{N}^T
\end{aligned}$$

If there is no cross-correlation between **error** and **control effort**,  $\mathbf{N}$  is a zero matrix and the cost function simplifies to

$$J = \int_0^{\infty} (\mathbf{x}^T \mathbf{Q} \mathbf{x} + \mathbf{u}^T \mathbf{R} \mathbf{u}) dt$$

The feedback **control law** which minimizes this  $J$  subject to  $\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u}$  is

$$\mathbf{u} = -\mathbf{K}\mathbf{x}$$

where  $\mathbf{K}$  is given by

$$\mathbf{K} = \mathbf{R}^{-1} \mathbf{B}^T \mathbf{S}$$

and  $\mathbf{S}$  is found by solving the continuous time algebraic Riccati equation defined as

$$\mathbf{A}^T \mathbf{S} + \mathbf{S} \mathbf{A} - \mathbf{S} \mathbf{B} \mathbf{R}^{-1} \mathbf{B}^T \mathbf{S} + \mathbf{Q} = 0$$

The discrete time LQR **controller** is computed via a slightly different cost function, constraint, and resulting algebraic Riccati equation. Snippet C.1 computes the optimal infinite horizon, discrete time LQR **controller**.



```

import control as ct
import numpy as np
import scipy as sp

def lqr(*args, **kwargs):
    """Solves for the optimal linear-quadratic regulator (LQR).

    For a continuous system:

    .. math:: \dot{x} = A * x + B * u
    .. math:: J = \int_0^{\infty} (x^T Q x + u^T R u + 2 x^T N u) dt

    For a discrete system:

    .. math:: x(n + 1) = A x(n) + B u(n)
    .. math:: J = \sum_0^{\infty} (x^T Q x + u^T R u + 2 x^T N u) \Delta T

    Keyword arguments:
    sys -- StateSpace object representing a linear system.
    Q -- numpy.array(states x states), state cost matrix.
    R -- numpy.array(inputs x inputs), control effort cost matrix.
    N -- numpy.array(states x inputs), cross weight matrix.

    Returns:
    K -- numpy.array(states x inputs), controller gain matrix.
    """
    sys = args[0]
    Q = args[1]
    R = args[2]
    if len(args) == 4:
        N = args[3]
    else:
        N = np.zeros((sys.A.shape[0], sys.B.shape[1]))

    m = sys.A.shape[0]

    controllability_rank = np.linalg.matrix_rank(ct.ctrb(sys.A, sys.B))
    if controllability_rank != m:
        print(
            "Warning: Controllability of %d != %d, uncontrollable state"
            % (controllability_rank, m)
        )

    if sys.dt == None:
        P = sp.linalg.solve_continuous_are(a=sys.A, b=sys.B, q=Q, r=R, s=N)
        return np.linalg.solve(R, sys.B.T @ P + N.T)
    else:
        P = sp.linalg.solve_discrete_are(a=sys.A, b=sys.B, q=Q, r=R, s=N)
        return np.linalg.solve(R + sys.B.T @ P @ sys.B, sys.B.T @ P @ sys.A +
            N.T)

```

Snippet C.1. Infinite horizon, discrete time LQR computation in Python

Other formulations of LQR for finite horizon and discrete time can be seen on Wikipedia [15].

MIT OpenCourseWare has a rigorous proof of the results shown above [33].

## C.2 Output feedback

LQR is normally used for state feedback on

$$\begin{aligned}\dot{\mathbf{x}} &= \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u} \\ \mathbf{y} &= \mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u}\end{aligned}$$

with the cost functional

$$J = \int_0^{\infty} (\mathbf{x}^T \mathbf{Q}\mathbf{x} + \mathbf{u}^T \mathbf{R}\mathbf{u}) dt$$

However, we may not know how to select costs for some of the states, or we don't care what certain internal states are doing. Output feedback can accommodate this. Not only can we make our output contain a subset of states, but we can use any other cost metric we can think of as long as it's representable as a linear combination of the states and inputs<sup>1</sup>.

For output feedback, we want to minimize the following cost functional.

$$J = \int_0^{\infty} (\mathbf{y}^T \mathbf{Q}\mathbf{y} + \mathbf{u}^T \mathbf{R}\mathbf{u}) dt$$

Substitute in the expression for  $\mathbf{y}$ .

$$J = \int_0^{\infty} ((\mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u})^T \mathbf{Q}(\mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u}) + \mathbf{u}^T \mathbf{R}\mathbf{u}) dt$$

Apply the transpose to the left-hand side of the  $\mathbf{Q}$  term.

$$J = \int_0^{\infty} ((\mathbf{x}^T \mathbf{C}^T + \mathbf{u}^T \mathbf{D}^T) \mathbf{Q}(\mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u}) + \mathbf{u}^T \mathbf{R}\mathbf{u}) dt$$

Factor out  $\begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T$  from the left side and  $\begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}$  from the right side of each term.

$$J = \int_0^{\infty} \left( \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \begin{bmatrix} \mathbf{C}^T \\ \mathbf{D}^T \end{bmatrix} \mathbf{Q} [\mathbf{C} \ \mathbf{D}] \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix} + \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \begin{bmatrix} \mathbf{0} & \mathbf{0} \\ \mathbf{0} & \mathbf{R} \end{bmatrix} \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix} \right) dt$$

$$J = \int_0^{\infty} \left( \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \left( \begin{bmatrix} \mathbf{C}^T \\ \mathbf{D}^T \end{bmatrix} \mathbf{Q} [\mathbf{C} \ \mathbf{D}] + \begin{bmatrix} \mathbf{0} & \mathbf{0} \\ \mathbf{0} & \mathbf{R} \end{bmatrix} \right) \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix} \right) dt$$

Multiply in  $\mathbf{Q}$ .

$$J = \int_0^{\infty} \left( \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \left( \begin{bmatrix} \mathbf{C}^T \mathbf{Q} \\ \mathbf{D}^T \mathbf{Q} \end{bmatrix} [\mathbf{C} \ \mathbf{D}] + \begin{bmatrix} \mathbf{0} & \mathbf{0} \\ \mathbf{0} & \mathbf{R} \end{bmatrix} \right) \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix} \right) dt$$

Multiply matrices in the left term together.

$$J = \int_0^{\infty} \left( \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \left( \begin{bmatrix} \mathbf{C}^T \mathbf{Q} \mathbf{C} & \mathbf{C}^T \mathbf{Q} \mathbf{D} \\ \mathbf{D}^T \mathbf{Q} \mathbf{C} & \mathbf{D}^T \mathbf{Q} \mathbf{D} \end{bmatrix} + \begin{bmatrix} \mathbf{0} & \mathbf{0} \\ \mathbf{0} & \mathbf{R} \end{bmatrix} \right) \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix} \right) dt$$

<sup>1</sup>We'll see this later on in section C.3 when we define the cost metric as deviation from the behavior of another model.

Add the terms together.

$$J = \int_0^{\infty} \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \begin{bmatrix} \underbrace{\mathbf{C}^T \mathbf{Q} \mathbf{C}}_{\mathbf{Q}} & \underbrace{\mathbf{C}^T \mathbf{Q} \mathbf{D}}_{\mathbf{N}} \\ \underbrace{\mathbf{D}^T \mathbf{Q} \mathbf{C}}_{\mathbf{N}^T} & \underbrace{\mathbf{D}^T \mathbf{Q} \mathbf{D} + \mathbf{R}}_{\mathbf{R}} \end{bmatrix} \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix} dt \quad (\text{C.2})$$

Thus, output feedback can be defined as the following optimization problem.

**Theorem C.2.1 — Linear-quadratic regulator with output feedback.**

$$\min_{\mathbf{u}} \int_0^{\infty} \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \begin{bmatrix} \underbrace{\mathbf{C}^T \mathbf{Q} \mathbf{C}}_{\mathbf{Q}} & \underbrace{\mathbf{C}^T \mathbf{Q} \mathbf{D}}_{\mathbf{N}} \\ \underbrace{\mathbf{D}^T \mathbf{Q} \mathbf{C}}_{\mathbf{N}^T} & \underbrace{\mathbf{D}^T \mathbf{Q} \mathbf{D} + \mathbf{R}}_{\mathbf{R}} \end{bmatrix} \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix} dt$$

subject to  $\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u}$  (C.3)

The optimal control policy  $\mathbf{u}^*$  is  $\mathbf{K}(\mathbf{r} - \mathbf{y})$  where  $\mathbf{r}$  is the desired output and  $\mathbf{y}$  is the measured output defined as  $\mathbf{y} = \mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u}$ .  $\mathbf{K}$  can be computed via the typical LQR equations based on the algebraic Riccati equation.

If the output is only the whole state vector, then  $\mathbf{C} = \mathbf{I}$ ,  $\mathbf{D} = \mathbf{0}$ , and the cost functional simplifies to that of state feedback LQR.

$$J = \int_0^{\infty} \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \begin{bmatrix} \mathbf{Q} & \mathbf{0} \\ \mathbf{0} & \mathbf{R} \end{bmatrix} \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix} dt$$

### C.3 Implicit model following

If we want to design a feedback controller that erases the dynamics of our system and makes it behave like some other system, we can use *implicit model following*. This is used on the Blackhawk helicopter at NASA Ames research center when they want to make it fly like experimental aircraft (within the limits of the helicopter's actuators, of course).

Let the original system dynamics be

$$\begin{aligned} \dot{\mathbf{x}} &= \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u} \\ \mathbf{y} &= \mathbf{C}\mathbf{x} \end{aligned}$$

and the desired system dynamics be

$$\dot{\mathbf{z}} = \mathbf{A}_{ref}\mathbf{z}$$

$$\begin{aligned} \dot{\mathbf{y}} &= \mathbf{C}\dot{\mathbf{x}} \\ \dot{\mathbf{y}} &= \mathbf{C}(\mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u}) \\ \dot{\mathbf{y}} &= \mathbf{C}\mathbf{A}\mathbf{x} + \mathbf{C}\mathbf{B}\mathbf{u} \end{aligned}$$

We want to minimize the following cost functional.

$$J = \int_0^{\infty} ((\dot{\mathbf{y}} - \dot{\mathbf{z}})^T \mathbf{Q} (\dot{\mathbf{y}} - \dot{\mathbf{z}}) + \mathbf{u}^T \mathbf{R} \mathbf{u}) dt$$

We'll be measuring the desired system's state, so let  $\mathbf{y} = \mathbf{z}$ .

$$\begin{aligned}\dot{\mathbf{z}} &= \mathbf{A}_{ref}\mathbf{y} \\ \dot{\mathbf{z}} &= \mathbf{A}_{ref}\mathbf{C}\mathbf{x}\end{aligned}$$

Therefore,

$$\begin{aligned}\dot{\mathbf{y}} - \dot{\mathbf{z}} &= \mathbf{C}\mathbf{A}\mathbf{x} + \mathbf{C}\mathbf{B}\mathbf{u} - (\mathbf{A}_{ref}\mathbf{C}\mathbf{x}) \\ \dot{\mathbf{y}} - \dot{\mathbf{z}} &= (\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C})\mathbf{x} + \mathbf{C}\mathbf{B}\mathbf{u}\end{aligned}$$

Substitute this into the cost functional.

$$\begin{aligned}J &= \int_0^\infty ((\dot{\mathbf{y}} - \dot{\mathbf{z}})^T \mathbf{Q}(\dot{\mathbf{y}} - \dot{\mathbf{z}}) + \mathbf{u}^T \mathbf{R}\mathbf{u}) dt \\ J &= \int_0^\infty (((\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C})\mathbf{x} + \mathbf{C}\mathbf{B}\mathbf{u})^T \mathbf{Q}((\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C})\mathbf{x} + \mathbf{C}\mathbf{B}\mathbf{u}) + \mathbf{u}^T \mathbf{R}\mathbf{u}) dt\end{aligned}$$

Apply the transpose to the left-hand side of the  $\mathbf{Q}$  term.

$$J = \int_0^\infty ((\mathbf{x}^T (\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C})^T + \mathbf{u}^T (\mathbf{C}\mathbf{B})^T) \mathbf{Q}((\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C})\mathbf{x} + \mathbf{C}\mathbf{B}\mathbf{u}) + \mathbf{u}^T \mathbf{R}\mathbf{u}) dt$$

Factor out  $\begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T$  from the left side and  $\begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}$  from the right side of each term.

$$\begin{aligned}J &= \int_0^\infty \left( \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \begin{bmatrix} (\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C})^T \\ (\mathbf{C}\mathbf{B})^T \end{bmatrix} \mathbf{Q} [\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C} \quad \mathbf{C}\mathbf{B}] \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix} + \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \begin{bmatrix} \mathbf{0} & \mathbf{0} \\ \mathbf{0} & \mathbf{R} \end{bmatrix} \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix} \right) dt \\ J &= \int_0^\infty \left( \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \left( \begin{bmatrix} (\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C})^T \\ (\mathbf{C}\mathbf{B})^T \end{bmatrix} \mathbf{Q} [\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C} \quad \mathbf{C}\mathbf{B}] + \begin{bmatrix} \mathbf{0} & \mathbf{0} \\ \mathbf{0} & \mathbf{R} \end{bmatrix} \right) \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix} \right) dt\end{aligned}$$

Multiply in  $\mathbf{Q}$ .

$$J = \int_0^\infty \left( \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \left( \begin{bmatrix} (\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C})^T \mathbf{Q} \\ (\mathbf{C}\mathbf{B})^T \mathbf{Q} \end{bmatrix} [\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C} \quad \mathbf{C}\mathbf{B}] + \begin{bmatrix} \mathbf{0} & \mathbf{0} \\ \mathbf{0} & \mathbf{R} \end{bmatrix} \right) \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix} \right) dt$$

Multiply matrices in the left term together.

$$J = \int_0^\infty \left( \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \left( \begin{bmatrix} (\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C})^T \mathbf{Q}(\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C}) & (\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C})^T \mathbf{Q}(\mathbf{C}\mathbf{B}) \\ (\mathbf{C}\mathbf{B})^T \mathbf{Q}(\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C}) & (\mathbf{C}\mathbf{B})^T \mathbf{Q}(\mathbf{C}\mathbf{B}) \end{bmatrix} + \begin{bmatrix} \mathbf{0} & \mathbf{0} \\ \mathbf{0} & \mathbf{R} \end{bmatrix} \right) \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix} \right) dt$$

Add the terms together.

$$J = \int_0^\infty \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \begin{bmatrix} \underbrace{(\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C})^T \mathbf{Q}(\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C})}_{\mathbf{Q}} & \underbrace{(\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C})^T \mathbf{Q}(\mathbf{C}\mathbf{B})}_{\mathbf{N}} \\ \underbrace{(\mathbf{C}\mathbf{B})^T \mathbf{Q}(\mathbf{C}\mathbf{A} - \mathbf{A}_{ref}\mathbf{C})}_{\mathbf{N}^T} & \underbrace{(\mathbf{C}\mathbf{B})^T \mathbf{Q}(\mathbf{C}\mathbf{B}) + \mathbf{R}}_{\mathbf{R}} \end{bmatrix} \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix} dt \quad (\text{C.4})$$

Thus, implicit model following can be defined as the following optimization problem.

**Theorem C.3.1 — Implicit model following.**

$$\min_{\mathbf{u}} \int_0^{\infty} \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \begin{bmatrix} \underbrace{(\mathbf{CA} - \mathbf{A}_{ref}\mathbf{C})^T \mathbf{Q} (\mathbf{CA} - \mathbf{A}_{ref}\mathbf{C})}_{\mathbf{Q}} & \underbrace{(\mathbf{CA} - \mathbf{A}_{ref}\mathbf{C})^T \mathbf{Q} (\mathbf{CB})}_{\mathbf{N}} \\ \underbrace{(\mathbf{CB})^T \mathbf{Q} (\mathbf{CA} - \mathbf{A}_{ref}\mathbf{C})}_{\mathbf{N}^T} & \underbrace{(\mathbf{CB})^T \mathbf{Q} (\mathbf{CB}) + \mathbf{R}}_{\mathbf{R}} \end{bmatrix} \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix} dt$$

subject to  $\dot{\mathbf{x}} = \mathbf{Ax} + \mathbf{Bu}$  (C.5)

The optimal control policy  $\mathbf{u}^*$  is  $-\mathbf{Kx}$ .  $\mathbf{K}$  can be computed via the typical LQR equations based on the algebraic Riccati equation.

The control law  $\mathbf{u}_{imf} = -\mathbf{Kx}$  makes  $\dot{\mathbf{x}} = \mathbf{Ax} + \mathbf{Bu}_{imf}$  match the open-loop response of  $\dot{\mathbf{z}} = \mathbf{A}_{ref}\mathbf{z}$ .

If the original and desired system have the same states, then  $\mathbf{C} = \mathbf{I}$  and the cost functional simplifies to

$$J = \int_0^{\infty} \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix}^T \begin{bmatrix} \underbrace{(\mathbf{A} - \mathbf{A}_{ref})^T \mathbf{Q} (\mathbf{A} - \mathbf{A}_{ref})}_{\mathbf{Q}} & \underbrace{(\mathbf{A} - \mathbf{A}_{ref})^T \mathbf{Q} \mathbf{B}}_{\mathbf{N}} \\ \underbrace{\mathbf{B}^T \mathbf{Q} (\mathbf{A} - \mathbf{A}_{ref})}_{\mathbf{N}^T} & \underbrace{\mathbf{B}^T \mathbf{Q} \mathbf{B} + \mathbf{R}}_{\mathbf{R}} \end{bmatrix} \begin{bmatrix} \mathbf{x} \\ \mathbf{u} \end{bmatrix} dt \quad (C.6)$$

## C.4 Time delay compensation

Linear-Quadratic regulator controller gains tend to be aggressive. If sensor measurements are time-delayed too long, the LQR may be unstable (see figure C.1). However, if we know the amount of delay, we can compute the control based on where the system will be after the time delay.

We can compensate for the time delay if we know the control law we're applying in future timesteps ( $\mathbf{u} = -\mathbf{Kx}$ ) and the duration of the time delay. To get the true state at the current time for control purposes, we project our delayed state forward by the time delay using our model and the aforementioned control law. Figure C.2 shows improved control with the predicted state.<sup>2</sup>

For steady-state controller gains, this method of delay compensation seems to work better for second-order systems than first-order systems. Figures C.3 and C.5 show time delay for a drivetrain velocity system and flywheel system respectively. Figures C.4 and C.6 show that compensating the controller gain significantly reduces the feedback gain. For systems with fast dynamics and a long time delay, the delay-compensated controller has an almost open-loop response because only feedforward has a significant effect; this has poor disturbance rejection. Fixing the source of the time delay is always preferred for these systems.

Since we are computing the control based on future states and the state exponentially converges to zero over time, the control action we apply at the current timestep also converges to zero for longer time delays. During startup, the inputs we use to predict the future state are zero because there's initially no input history. This means the initial inputs are larger to give the system a kick in the right direction. As the input delay buffer fills up, the controller gain converges to a smaller steady-state value. If one uses the steady-state controller gain during startup, the transient response may be slow.

All figures shown here use the steady-state control law (the second case in equation (C.12)).

<sup>2</sup>Input delay and output delay have the same effect on the system, so the time delay can be simulated with either an input delay buffer or a measurement delay buffer.




Figure C.1: Elevator response at 5ms sample period with 50ms of output lag




Figure C.2: Elevator response at 5ms sample period with 50ms of output lag (delay-compensated)

We'll show how to derive this controller gain compensation for continuous and discrete systems.

#### C.4.1 Continuous case

We can avoid the time delay if we compute the control based on the plant  $L$  seconds in the future. Therefore, we need to derive an equation for the plant's state  $L$  seconds in the future given the current state.

The continuous linear system is defined as

$$\dot{\mathbf{x}} = \mathbf{A}\mathbf{x}(t) + \mathbf{B}\mathbf{u}(t)$$

Let the controller for this system be

$$\mathbf{u}(t) = -\mathbf{K}\mathbf{x}(t)$$

Substitute this into the continuous model.

$$\begin{aligned}\dot{\mathbf{x}} &= \mathbf{A}\mathbf{x}(t) + \mathbf{B}\mathbf{u}(t) \\ \dot{\mathbf{x}} &= \mathbf{A}\mathbf{x}(t) + \mathbf{B}(-\mathbf{K}\mathbf{x}(t)) \\ \dot{\mathbf{x}} &= \mathbf{A}\mathbf{x}(t) - \mathbf{B}\mathbf{K}\mathbf{x}(t) \\ \dot{\mathbf{x}} &= (\mathbf{A} - \mathbf{B}\mathbf{K})\mathbf{x}(t)\end{aligned}$$

Let  $L$  be the amount of time delay in seconds. Take the matrix exponential from the current time  $t$  to  $L$  in the future.

$$\mathbf{x}(t + L) = e^{(\mathbf{A} - \mathbf{B}\mathbf{K})L}\mathbf{x}(t) \quad (\text{C.7})$$

This works when  $t > L$ , but when  $0 \leq t < L$ , the inputs in the time interval  $[t, L)$  are zero because there's initially no input history. The state prediction for that time interval is thus

$$\mathbf{x}(L) = e^{\mathbf{A}(L-t)}\mathbf{x}(t)$$

The time interval  $[0, t)$  has nonzero inputs, so it uses the normal control law.

$$\mathbf{x}(t + L) = e^{(\mathbf{A} - \mathbf{B}\mathbf{K})t}\mathbf{x}(L)$$




Figure C.3: Drivetrain velocity response at 1ms sample period with 40ms of output lag




Figure C.4: Drivetrain velocity response at 1ms sample period with 40ms of output lag (delay-compensated)




Figure C.5: Flywheel response at 1ms sample period with 100ms of output lag




Figure C.6: Flywheel response at 1ms sample period with 100ms of output lag (delay-compensated)

$$\mathbf{x}(t+L) = e^{(\mathbf{A}-\mathbf{BK})t} e^{\mathbf{A}(L-t)} \mathbf{x}(t) \quad (\text{C.8})$$

Therefore, equations (C.7) and (C.8) give the latency-compensated control law for all  $t \geq 0$ .

$$\mathbf{u}(t) = -\mathbf{K}\mathbf{x}(t+L)$$

$$\mathbf{u}(t) = \begin{cases} -\mathbf{K}e^{(\mathbf{A}-\mathbf{BK})t} e^{\mathbf{A}(L-t)} \mathbf{x}(t) & \text{if } 0 \leq t < L \\ -\mathbf{K}e^{(\mathbf{A}-\mathbf{BK})L} \mathbf{x}(t) & \text{if } t \geq L \end{cases} \quad (\text{C.9})$$

#### C.4.2 Discrete case

We can avoid the time delay if we compute the control based on the plant  $L$  seconds in the future. Therefore, we need to derive an equation for the plant's state  $L$  seconds in the future given the current state.

The discrete linear system is defined as

$$\mathbf{x}_{k+1} = \mathbf{A}\mathbf{x}_k + \mathbf{B}\mathbf{u}_k$$

Let the controller for this system be

$$\mathbf{u}_k = -\mathbf{K}\mathbf{x}_k$$

Substitute this into the discrete model.

$$\begin{aligned}\mathbf{x}_{k+1} &= \mathbf{A}\mathbf{x}_k + \mathbf{B}\mathbf{u}_k \\ \mathbf{x}_{k+1} &= \mathbf{A}\mathbf{x}_k + \mathbf{B}(-\mathbf{K}\mathbf{x}_k) \\ \mathbf{x}_{k+1} &= \mathbf{A}\mathbf{x}_k - \mathbf{B}\mathbf{K}\mathbf{x}_k \\ \mathbf{x}_{k+1} &= (\mathbf{A} - \mathbf{B}\mathbf{K})\mathbf{x}_k\end{aligned}$$

Let  $T$  be the duration between timesteps in seconds and  $L$  be the amount of time delay in seconds.  $\frac{L}{T}$  gives the number of timesteps represented by  $L$ .

$$\mathbf{x}_{k+L} = (\mathbf{A} - \mathbf{B}\mathbf{K})^{\frac{L}{T}} \mathbf{x}_k \quad (\text{C.10})$$

This works when the current time  $kT$  is greater than or equal to  $L$ , but when  $0 \leq kT < L$ , the inputs in the time interval  $[kT, L)$  are zero because there's initially no input history. The state prediction for that time interval is thus

$$\begin{aligned}\mathbf{x}_L &= \mathbf{A}^{\frac{L-kT}{T}} \mathbf{x}_k \\ \mathbf{x}_L &= \mathbf{A}^{\frac{L}{T}-k} \mathbf{x}_k\end{aligned}$$

The time interval  $[0, kT)$  has nonzero inputs, so it uses the normal control law.

$$\begin{aligned}\mathbf{x}_{k+L} &= (\mathbf{A} - \mathbf{B}\mathbf{K})^k \mathbf{x}_L \\ \mathbf{x}_{k+L} &= (\mathbf{A} - \mathbf{B}\mathbf{K})^k \mathbf{A}^{\frac{L}{T}-k} \mathbf{x}_k\end{aligned} \quad (\text{C.11})$$

Therefore, equations (C.10) and (C.11) give the latency-compensated control law for all  $t \geq 0$ .

$$\begin{aligned}\mathbf{u}_k &= -\mathbf{K}\mathbf{x}_{k+L} \\ \mathbf{u}_k &= \begin{cases} -\mathbf{K}(\mathbf{A} - \mathbf{B}\mathbf{K})^k \mathbf{A}^{\frac{L}{T}-k} \mathbf{x}_k & \text{if } 0 \leq k < \frac{L}{T} \\ -\mathbf{K}(\mathbf{A} - \mathbf{B}\mathbf{K})^{\frac{L}{T}} \mathbf{x}_k & \text{if } k \geq \frac{L}{T} \end{cases}\end{aligned} \quad (\text{C.12})$$

If the delay  $L$  isn't a multiple of the sample period  $T$  in equation (C.12), we have to evaluate fractional matrix powers, which can be tricky.

Let there be a matrix  $\mathbf{M}$  raised to a fractional power  $n$ . If  $\mathbf{M}$  is diagonalizable, we can obtain an exact answer for  $\mathbf{M}^n$  by decomposing  $\mathbf{M}$  into  $\mathbf{P}\mathbf{D}\mathbf{P}^{-1}$  where  $\mathbf{D}$  is a diagonal matrix, computing  $\mathbf{D}^n$  as each diagonal element raised to  $n$ , then recomposing  $\mathbf{M}^n$  as  $\mathbf{P}\mathbf{D}^n\mathbf{P}^{-1}$ .

If a matrix raised to a fractional power in equation (C.12) isn't diagonalizable, we have to approximate by rounding  $\frac{L}{T}$  to the nearest integer. This approximation gets worse as  $L \bmod T$  approaches  $\frac{T}{2}$ .



## D. QR-weighted linear plant inversion

### D.1 Necessary theorems

The following theorem and corollary will be needed to derive the QR-weighted linear plant inversion equation.

$$\text{Theorem D.1.1} \quad \frac{\partial(\mathbf{Ax}+\mathbf{b})^T\mathbf{C}(\mathbf{Dx}+\mathbf{e})}{\partial\mathbf{x}} = \mathbf{A}^T\mathbf{C}(\mathbf{Dx}+\mathbf{e}) + \mathbf{D}^T\mathbf{C}^T(\mathbf{Ax}+\mathbf{b})$$

$$\text{Corollary D.1.2} \quad \frac{\partial(\mathbf{Ax}+\mathbf{b})^T\mathbf{C}(\mathbf{Ax}+\mathbf{b})}{\partial\mathbf{x}} = 2\mathbf{A}^T\mathbf{C}(\mathbf{Ax}+\mathbf{b}) \text{ where } \mathbf{C} \text{ is symmetric.}$$

Proof:

$$\begin{aligned} \frac{\partial(\mathbf{Ax}+\mathbf{b})^T\mathbf{C}(\mathbf{Ax}+\mathbf{b})}{\partial\mathbf{x}} &= \mathbf{A}^T\mathbf{C}(\mathbf{Ax}+\mathbf{b}) + \mathbf{A}^T\mathbf{C}^T(\mathbf{Ax}+\mathbf{b}) \\ \frac{\partial(\mathbf{Ax}+\mathbf{b})^T\mathbf{C}(\mathbf{Ax}+\mathbf{b})}{\partial\mathbf{x}} &= (\mathbf{A}^T\mathbf{C} + \mathbf{A}^T\mathbf{C}^T)(\mathbf{Ax}+\mathbf{b}) \end{aligned}$$

$\mathbf{C}$  is symmetric, so

$$\begin{aligned} \frac{\partial(\mathbf{Ax}+\mathbf{b})^T\mathbf{C}(\mathbf{Ax}+\mathbf{b})}{\partial\mathbf{x}} &= (\mathbf{A}^T\mathbf{C} + \mathbf{A}^T\mathbf{C})(\mathbf{Ax}+\mathbf{b}) \\ \frac{\partial(\mathbf{Ax}+\mathbf{b})^T\mathbf{C}(\mathbf{Ax}+\mathbf{b})}{\partial\mathbf{x}} &= 2\mathbf{A}^T\mathbf{C}(\mathbf{Ax}+\mathbf{b}) \end{aligned}$$

## D.2 Setup

Let's start with the equation for the [reference](#) dynamics

$$\mathbf{r}_{k+1} = \mathbf{A}\mathbf{r}_k + \mathbf{B}\mathbf{u}_k$$

where  $\mathbf{u}_k$  is the feedforward input. Note that this feedforward equation does not and should not take into account any feedback terms. We want to find the optimal  $\mathbf{u}_k$  such that we minimize the [tracking](#) error between  $\mathbf{r}_{k+1}$  and  $\mathbf{r}_k$ .

$$\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k = \mathbf{B}\mathbf{u}_k$$

To solve for  $\mathbf{u}_k$ , we need to take the inverse of the nonsquare matrix  $\mathbf{B}$ . This isn't possible, but we can find the pseudoinverse given some constraints on the [state tracking](#) error and [control effort](#). To find the optimal solution for these sorts of trade-offs, one can define a cost function and attempt to minimize it. To do this, we'll first solve the expression for  $\mathbf{0}$ .

$$\mathbf{0} = \mathbf{B}\mathbf{u}_k - (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k)$$

This expression will be the [state tracking](#) cost we use in our cost function.

Our cost function will use an  $H_2$  norm with  $\mathbf{Q}$  as the [state](#) cost matrix with dimensionality  $states \times states$  and  $\mathbf{R}$  as the [control input](#) cost matrix with dimensionality  $inputs \times inputs$ .

$$\mathbf{J} = (\mathbf{B}\mathbf{u}_k - (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k))^T \mathbf{Q} (\mathbf{B}\mathbf{u}_k - (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k)) + \mathbf{u}_k^T \mathbf{R} \mathbf{u}_k$$

## D.3 Minimization

Given theorem 5.11.1 and corollary D.1.2, find the minimum of  $\mathbf{J}$  by taking the partial derivative with respect to  $\mathbf{u}_k$  and setting the result to  $\mathbf{0}$ .

$$\begin{aligned} \frac{\partial \mathbf{J}}{\partial \mathbf{u}_k} &= 2\mathbf{B}^T \mathbf{Q} (\mathbf{B}\mathbf{u}_k - (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k)) + 2\mathbf{R}\mathbf{u}_k \\ \mathbf{0} &= 2\mathbf{B}^T \mathbf{Q} (\mathbf{B}\mathbf{u}_k - (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k)) + 2\mathbf{R}\mathbf{u}_k \\ \mathbf{0} &= \mathbf{B}^T \mathbf{Q} (\mathbf{B}\mathbf{u}_k - (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k)) + \mathbf{R}\mathbf{u}_k \\ \mathbf{0} &= \mathbf{B}^T \mathbf{Q} \mathbf{B} \mathbf{u}_k - \mathbf{B}^T \mathbf{Q} (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k) + \mathbf{R}\mathbf{u}_k \\ \mathbf{B}^T \mathbf{Q} \mathbf{B} \mathbf{u}_k + \mathbf{R}\mathbf{u}_k &= \mathbf{B}^T \mathbf{Q} (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k) \\ (\mathbf{B}^T \mathbf{Q} \mathbf{B} + \mathbf{R}) \mathbf{u}_k &= \mathbf{B}^T \mathbf{Q} (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k) \\ \mathbf{u}_k &= (\mathbf{B}^T \mathbf{Q} \mathbf{B} + \mathbf{R})^{-1} \mathbf{B}^T \mathbf{Q} (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k) \end{aligned}$$

**Theorem D.3.1 — QR-weighted linear plant inversion.** Given the discrete model  $\mathbf{x}_{k+1} = \mathbf{A}\mathbf{x}_k + \mathbf{B}\mathbf{u}_k$ , the plant inversion feedforward is

$$\mathbf{u}_k = \mathbf{K}_{ff} (\mathbf{r}_{k+1} - \mathbf{A}\mathbf{r}_k)$$

where  $\mathbf{K}_{ff} = (\mathbf{B}^T \mathbf{Q} \mathbf{B} + \mathbf{R})^{-1} \mathbf{B}^T \mathbf{Q}$ ,  $\mathbf{r}_{k+1}$  is the reference at the next timestep, and  $\mathbf{r}_k$  is the reference at the current timestep.

Figure D.1 shows [plant](#) inversion applied to a second-order CIM motor model.

[Plant](#) inversion isn't as effective with both  $\mathbf{Q}$  and  $\mathbf{R}$  cost because the  $\mathbf{R}$  matrix penalized [control effort](#). The [reference tracking](#) with no cost matrices is much better.




Figure D.1: Second-order CIM motor response with plant inversion

*This page intentionally left blank*

## E. Steady-state feedforward

Steady-state feedforwards apply the **control effort** required to keep a **system** at the **reference** if it is no longer moving (i.e., the **system** is at steady-state). The first steady-state feedforward converts desired **outputs** to desired **states**.

$$\mathbf{x}_c = \mathbf{N}_x \mathbf{y}_c$$

$\mathbf{N}_x$  converts desired **outputs**  $\mathbf{y}_c$  to desired **states**  $\mathbf{x}_c$  (also known as **r**). For steady-state, that is

$$\mathbf{x}_{ss} = \mathbf{N}_x \mathbf{y}_{ss} \quad (\text{E.1})$$

The second steady-state feedforward converts the desired **outputs**  $\mathbf{y}$  to the **control input** required at steady-state.

$$\mathbf{u}_c = \mathbf{N}_u \mathbf{y}_c$$

$\mathbf{N}_u$  converts the desired **outputs**  $\mathbf{y}$  to the **control input**  $\mathbf{u}$  required at steady-state. For steady-state, that is

$$\mathbf{u}_{ss} = \mathbf{N}_u \mathbf{y}_{ss} \quad (\text{E.2})$$

### E.1 Continuous case

To find the **control input** required at steady-state, set equation (5.1) to zero.

$$\dot{\mathbf{x}} = \mathbf{A}\mathbf{x} + \mathbf{B}\mathbf{u}$$

$$\mathbf{y} = \mathbf{C}\mathbf{x} + \mathbf{D}\mathbf{u}$$

$$\mathbf{0} = \mathbf{A}\mathbf{x}_{ss} + \mathbf{B}\mathbf{u}_{ss}$$

$$\mathbf{y}_{ss} = \mathbf{C}\mathbf{x}_{ss} + \mathbf{D}\mathbf{u}_{ss}$$

$$\mathbf{0} = \mathbf{A}\mathbf{N}_x \mathbf{y}_{ss} + \mathbf{B}\mathbf{N}_u \mathbf{y}_{ss}$$

$$\mathbf{y}_{ss} = \mathbf{C}\mathbf{N}_x\mathbf{y}_{ss} + \mathbf{D}\mathbf{N}_u\mathbf{y}_{ss}$$

$$\begin{bmatrix} \mathbf{0} \\ \mathbf{y}_{ss} \end{bmatrix} = \begin{bmatrix} \mathbf{A}\mathbf{N}_x + \mathbf{B}\mathbf{N}_u \\ \mathbf{C}\mathbf{N}_x + \mathbf{D}\mathbf{N}_u \end{bmatrix} \mathbf{y}_{ss}$$

$$\begin{bmatrix} \mathbf{0} \\ \mathbf{1} \end{bmatrix} = \begin{bmatrix} \mathbf{A}\mathbf{N}_x + \mathbf{B}\mathbf{N}_u \\ \mathbf{C}\mathbf{N}_x + \mathbf{D}\mathbf{N}_u \end{bmatrix}$$

$$\begin{bmatrix} \mathbf{0} \\ \mathbf{1} \end{bmatrix} = \begin{bmatrix} \mathbf{A} & \mathbf{B} \\ \mathbf{C} & \mathbf{D} \end{bmatrix} \begin{bmatrix} \mathbf{N}_x \\ \mathbf{N}_u \end{bmatrix}$$

$$\begin{bmatrix} \mathbf{N}_x \\ \mathbf{N}_u \end{bmatrix} = \begin{bmatrix} \mathbf{A} & \mathbf{B} \\ \mathbf{C} & \mathbf{D} \end{bmatrix}^\dagger \begin{bmatrix} \mathbf{0} \\ \mathbf{1} \end{bmatrix}$$

where  $\dagger$  is the Moore-Penrose pseudoinverse.

## E.2 Discrete case

Now, we'll do the same thing for the discrete system. To find the control input required at steady-state, set equation (5.3) to zero.

$$\mathbf{x}_{k+1} = \mathbf{A}\mathbf{x}_k + \mathbf{B}\mathbf{u}_k$$

$$\mathbf{y}_k = \mathbf{C}\mathbf{x}_k + \mathbf{D}\mathbf{u}_k$$

$$\mathbf{x}_{ss} = \mathbf{A}\mathbf{x}_{ss} + \mathbf{B}\mathbf{u}_{ss}$$

$$\mathbf{y}_{ss} = \mathbf{C}\mathbf{x}_{ss} + \mathbf{D}\mathbf{u}_{ss}$$

$$\mathbf{0} = (\mathbf{A} - \mathbf{I})\mathbf{x}_{ss} + \mathbf{B}\mathbf{u}_{ss}$$

$$\mathbf{y}_{ss} = \mathbf{C}\mathbf{x}_{ss} + \mathbf{D}\mathbf{u}_{ss}$$

$$\mathbf{0} = (\mathbf{A} - \mathbf{I})\mathbf{N}_x\mathbf{y}_{ss} + \mathbf{B}\mathbf{N}_u\mathbf{y}_{ss}$$

$$\mathbf{y}_{ss} = \mathbf{C}\mathbf{N}_x\mathbf{y}_{ss} + \mathbf{D}\mathbf{N}_u\mathbf{y}_{ss}$$

$$\begin{bmatrix} \mathbf{0} \\ \mathbf{y}_{ss} \end{bmatrix} = \begin{bmatrix} (\mathbf{A} - \mathbf{I})\mathbf{N}_x + \mathbf{B}\mathbf{N}_u \\ \mathbf{C}\mathbf{N}_x + \mathbf{D}\mathbf{N}_u \end{bmatrix} \mathbf{y}_{ss}$$

$$\begin{bmatrix} \mathbf{0} \\ \mathbf{1} \end{bmatrix} = \begin{bmatrix} (\mathbf{A} - \mathbf{I})\mathbf{N}_x + \mathbf{B}\mathbf{N}_u \\ \mathbf{C}\mathbf{N}_x + \mathbf{D}\mathbf{N}_u \end{bmatrix}$$

$$\begin{bmatrix} \mathbf{0} \\ \mathbf{1} \end{bmatrix} = \begin{bmatrix} \mathbf{A} - \mathbf{I} & \mathbf{B} \\ \mathbf{C} & \mathbf{D} \end{bmatrix} \begin{bmatrix} \mathbf{N}_x \\ \mathbf{N}_u \end{bmatrix}$$

$$\begin{bmatrix} \mathbf{N}_x \\ \mathbf{N}_u \end{bmatrix} = \begin{bmatrix} \mathbf{A} - \mathbf{I} & \mathbf{B} \\ \mathbf{C} & \mathbf{D} \end{bmatrix}^\dagger \begin{bmatrix} \mathbf{0} \\ \mathbf{1} \end{bmatrix}$$

where  $\dagger$  is the Moore-Penrose pseudoinverse.

### E.3 Deriving steady-state input

Now, we'll find an expression that uses  $\mathbf{N}_x$  and  $\mathbf{N}_u$  to convert the reference  $\mathbf{r}$  to a control input feedforward  $\mathbf{u}_{ff}$ . Let's start with equation (E.1).

$$\begin{aligned}\mathbf{x}_{ss} &= \mathbf{N}_x \mathbf{y}_{ss} \\ \mathbf{N}_x^\dagger \mathbf{x}_{ss} &= \mathbf{y}_{ss}\end{aligned}$$

Now substitute this into equation (E.2).

$$\begin{aligned}\mathbf{u}_{ss} &= \mathbf{N}_u \mathbf{y}_{ss} \\ \mathbf{u}_{ss} &= \mathbf{N}_u (\mathbf{N}_x^\dagger \mathbf{x}_{ss}) \\ \mathbf{u}_{ss} &= \mathbf{N}_u \mathbf{N}_x^\dagger \mathbf{x}_{ss}\end{aligned}$$

$\mathbf{u}_{ss}$  and  $\mathbf{x}_{ss}$  are also known as  $\mathbf{u}_{ff}$  and  $\mathbf{r}$  respectively.

$$\mathbf{u}_{ff} = \mathbf{N}_u \mathbf{N}_x^\dagger \mathbf{r}$$

So all together, we get theorem E.3.1.

#### Theorem E.3.1 — Steady-state feedforward.

Continuous:

$$\begin{bmatrix} \mathbf{N}_x \\ \mathbf{N}_u \end{bmatrix} = \begin{bmatrix} \mathbf{A} & \mathbf{B} \\ \mathbf{C} & \mathbf{D} \end{bmatrix}^\dagger \begin{bmatrix} \mathbf{0} \\ \mathbf{1} \end{bmatrix} \quad (\text{E.3})$$

Discrete:

$$\begin{bmatrix} \mathbf{N}_x \\ \mathbf{N}_u \end{bmatrix} = \begin{bmatrix} \mathbf{A} - \mathbf{I} & \mathbf{B} \\ \mathbf{C} & \mathbf{D} \end{bmatrix}^\dagger \begin{bmatrix} \mathbf{0} \\ \mathbf{1} \end{bmatrix} \quad (\text{E.4})$$

$$\mathbf{u}_{ff} = \mathbf{N}_u \mathbf{N}_x^\dagger \mathbf{r} \quad (\text{E.5})$$

In the augmented matrix,  $\mathbf{B}$  should contain one column corresponding to an actuator and  $\mathbf{C}$  should contain one row whose output will be driven by that actuator. More than one actuator or output can be included in the computation at once, but the result won't be the same as if they were computed independently and summed afterward.

After computing the feedforward for each actuator-output pair, the respective collections of  $\mathbf{N}_x$  and  $\mathbf{N}_u$  matrices can be summed to produce the combined feedforward.

If the augmented matrix in theorem E.3.1 is square (number of inputs = number of outputs), the normal matrix inverse can be used instead.

#### E.3.1 Case study: second-order CIM motor model

Each feedforward implementation has advantages. The steady-state feedforward allows using specific actuators to maintain the reference at steady-state. Plant inversion doesn't support this, but can be used for reference tracking as well with the same tuning parameters as LQR design. Figure E.1 shows both types of feedforwards applied to a second-order CIM motor model.




Figure E.1: Second-order CIM motor response with various feedforwards




Figure E.2: Second-order CIM motor response with plant inversions

Plant inversion isn't as effective in figure E.1 because the  $\mathbf{R}$  matrix penalized control effort. If the  $\mathbf{R}$  cost matrix is removed from the plant inversion calculation, the reference tracking is much better (see figure E.2).



## F. Derivations

### F.1 Transfer function in feedback

Given the feedback network in figure F.1, find an expression for  $Y(s)$ .




Figure F.1: Closed-loop block diagram

$$\begin{aligned}
 Y(s) &= Z(s)G(s) \\
 Z(s) &= X(s) - Y(s)H(s) \\
 X(s) &= Z(s) + Y(s)H(s) \\
 X(s) &= Z(s) + Z(s)G(s)H(s) \\
 \frac{Y(s)}{X(s)} &= \frac{Z(s)G(s)}{Z(s) + Z(s)G(s)H(s)} \\
 \frac{Y(s)}{X(s)} &= \frac{G(s)}{1 + G(s)H(s)} \tag{F.1}
 \end{aligned}$$

A more general form is

$$\frac{Y(s)}{X(s)} = \frac{G(s)}{1 \mp G(s)H(s)} \tag{F.2}$$

where positive feedback uses the top sign and negative feedback uses the bottom sign.

## F.2 Zero-order hold for state-space

Starting with the continuous [model](#)

$$\dot{\mathbf{x}}(t) = \mathbf{A}\mathbf{x}(t) + \mathbf{B}\mathbf{u}(t)$$

by premultiplying the [model](#) by  $e^{-\mathbf{A}t}$ , we get

$$\begin{aligned} e^{-\mathbf{A}t}\dot{\mathbf{x}}(t) &= e^{-\mathbf{A}t}\mathbf{A}\mathbf{x}(t) + e^{-\mathbf{A}t}\mathbf{B}\mathbf{u}(t) \\ e^{-\mathbf{A}t}\dot{\mathbf{x}}(t) - e^{-\mathbf{A}t}\mathbf{A}\mathbf{x}(t) &= e^{-\mathbf{A}t}\mathbf{B}\mathbf{u}(t) \end{aligned}$$

The derivative of the matrix exponential is

$$\frac{d}{dt}e^{\mathbf{A}t} = \mathbf{A}e^{\mathbf{A}t} = e^{\mathbf{A}t}\mathbf{A}$$

so we recognize the previous equation as

$$\frac{d}{dt}(e^{-\mathbf{A}t}\mathbf{x}(t)) = e^{-\mathbf{A}t}\mathbf{B}\mathbf{u}(t)$$

By integrating this equation, we get

$$\begin{aligned} e^{-\mathbf{A}t}\mathbf{x}(t) - e^0\mathbf{x}(0) &= \int_0^t e^{-\mathbf{A}\tau}\mathbf{B}\mathbf{u}(\tau) d\tau \\ \mathbf{x}(t) &= e^{\mathbf{A}t}\mathbf{x}(0) + \int_0^t e^{\mathbf{A}(t-\tau)}\mathbf{B}\mathbf{u}(\tau) d\tau \end{aligned}$$

which is an analytical solution to the continuous [model](#). Now we want to [discretize](#) it.

$$\begin{aligned} \mathbf{x}_k &\stackrel{def}{=} \mathbf{x}(kT) \\ \mathbf{x}_k &= e^{\mathbf{A}kT}\mathbf{x}(0) + \int_0^{kT} e^{\mathbf{A}(kT-\tau)}\mathbf{B}\mathbf{u}(\tau) d\tau \\ \mathbf{x}_{k+1} &= e^{\mathbf{A}(k+1)T}\mathbf{x}(0) + \int_0^{(k+1)T} e^{\mathbf{A}((k+1)T-\tau)}\mathbf{B}\mathbf{u}(\tau) d\tau \\ \mathbf{x}_{k+1} &= e^{\mathbf{A}(k+1)T}\mathbf{x}(0) + \int_0^{kT} e^{\mathbf{A}((k+1)T-\tau)}\mathbf{B}\mathbf{u}(\tau) d\tau + \int_{kT}^{(k+1)T} e^{\mathbf{A}((k+1)T-\tau)}\mathbf{B}\mathbf{u}(\tau) d\tau \\ \mathbf{x}_{k+1} &= e^{\mathbf{A}(k+1)T}\mathbf{x}(0) + \int_0^{kT} e^{\mathbf{A}((k+1)T-\tau)}\mathbf{B}\mathbf{u}(\tau) d\tau + \int_{kT}^{(k+1)T} e^{\mathbf{A}(kT+T-\tau)}\mathbf{B}\mathbf{u}(\tau) d\tau \\ \mathbf{x}_{k+1} &= e^{\mathbf{A}T} \left( \underbrace{e^{\mathbf{A}kT}\mathbf{x}(0) + \int_0^{kT} e^{\mathbf{A}(kT-\tau)}\mathbf{B}\mathbf{u}(\tau) d\tau}_{\mathbf{x}_k} \right) + \int_{kT}^{(k+1)T} e^{\mathbf{A}(kT+T-\tau)}\mathbf{B}\mathbf{u}(\tau) d\tau \end{aligned}$$

We assume that  $\mathbf{u}$  is constant during each timestep, so it can be pulled out of the integral.

$$\mathbf{x}_{k+1} = e^{\mathbf{A}T}\mathbf{x}_k + \left( \int_{kT}^{(k+1)T} e^{\mathbf{A}(kT+T-\tau)} d\tau \right) \mathbf{B}\mathbf{u}_k$$

The second term can be simplified by substituting it with the function  $v(\tau) = kT + T - \tau$ . Note that  $d\tau = -dv$ .

$$\begin{aligned}\mathbf{x}_{k+1} &= e^{\mathbf{A}T} \mathbf{x}_k - \left( \int_{v(kT)}^{v((k+1)T)} e^{\mathbf{A}v} dv \right) \mathbf{B} \mathbf{u}_k \\ \mathbf{x}_{k+1} &= e^{\mathbf{A}T} \mathbf{x}_k - \left( \int_T^0 e^{\mathbf{A}v} dv \right) \mathbf{B} \mathbf{u}_k \\ \mathbf{x}_{k+1} &= e^{\mathbf{A}T} \mathbf{x}_k + \left( \int_0^T e^{\mathbf{A}v} dv \right) \mathbf{B} \mathbf{u}_k \\ \mathbf{x}_{k+1} &= e^{\mathbf{A}T} \mathbf{x}_k + \mathbf{A}^{-1} e^{\mathbf{A}v} \Big|_0^T \mathbf{B} \mathbf{u}_k \\ \mathbf{x}_{k+1} &= e^{\mathbf{A}T} \mathbf{x}_k + \mathbf{A}^{-1} (e^{\mathbf{A}T} - e^{\mathbf{A}0}) \mathbf{B} \mathbf{u}_k \\ \mathbf{x}_{k+1} &= e^{\mathbf{A}T} \mathbf{x}_k + \mathbf{A}^{-1} (e^{\mathbf{A}T} - \mathbf{I}) \mathbf{B} \mathbf{u}_k\end{aligned}$$

which is an exact solution to the [discretization](#) problem.

### F.3 Kalman filter as Luenberger observer

A Luenberger [observer](#) is defined as

$$\hat{\mathbf{x}}_{k+1}^+ = \mathbf{A} \hat{\mathbf{x}}_k^- + \mathbf{B} \mathbf{u}_k + \mathbf{L} (\mathbf{y}_k - \hat{\mathbf{y}}_k) \quad (\text{F.3})$$

$$\hat{\mathbf{y}}_k = \mathbf{C} \hat{\mathbf{x}}_k^- \quad (\text{F.4})$$

where a superscript of minus denotes *a priori* and plus denotes *a posteriori* estimate. Combining equation (F.3) and equation (F.4) gives

$$\hat{\mathbf{x}}_{k+1}^+ = \mathbf{A} \hat{\mathbf{x}}_k^- + \mathbf{B} \mathbf{u}_k + \mathbf{L} (\mathbf{y}_k - \mathbf{C} \hat{\mathbf{x}}_k^-) \quad (\text{F.5})$$

The following is a Kalman filter that considers the current update step and the next predict step together rather than the current predict step and current update step.

Update step

$$\mathbf{K}_k = \mathbf{P}_k^- \mathbf{C}^T (\mathbf{C} \mathbf{P}_k^- \mathbf{C}^T + \mathbf{R})^{-1} \quad (\text{F.6})$$

$$\hat{\mathbf{x}}_k^+ = \hat{\mathbf{x}}_k^- + \mathbf{K}_k (\mathbf{y}_k - \mathbf{C} \hat{\mathbf{x}}_k^-) \quad (\text{F.7})$$

$$\mathbf{P}_k^+ = (\mathbf{I} - \mathbf{K}_k \mathbf{C}) \mathbf{P}_k^- \quad (\text{F.8})$$

Predict step

$$\hat{\mathbf{x}}_{k+1}^+ = \mathbf{A} \hat{\mathbf{x}}_k^+ + \mathbf{B} \mathbf{u}_k \quad (\text{F.9})$$

$$\mathbf{P}_{k+1}^- = \mathbf{A} \mathbf{P}_k^+ \mathbf{A}^T + \mathbf{\Gamma} \mathbf{Q} \mathbf{\Gamma}^T \quad (\text{F.10})$$

Substitute equation (F.7) into equation (F.9).

$$\hat{\mathbf{x}}_{k+1}^+ = \mathbf{A} (\hat{\mathbf{x}}_k^- + \mathbf{K}_k (\mathbf{y}_k - \mathbf{C} \hat{\mathbf{x}}_k^-)) + \mathbf{B} \mathbf{u}_k$$

$$\hat{\mathbf{x}}_{k+1}^+ = \mathbf{A} \hat{\mathbf{x}}_k^- + \mathbf{A} \mathbf{K}_k (\mathbf{y}_k - \mathbf{C} \hat{\mathbf{x}}_k^-) + \mathbf{B} \mathbf{u}_k$$

$$\hat{\mathbf{x}}_{k+1}^+ = \mathbf{A} \hat{\mathbf{x}}_k^- + \mathbf{B} \mathbf{u}_k + \mathbf{A} \mathbf{K}_k (\mathbf{y}_k - \mathbf{C} \hat{\mathbf{x}}_k^-)$$

Let  $\mathbf{L} = \mathbf{A} \mathbf{K}_k$ .

$$\hat{\mathbf{x}}_{k+1}^+ = \mathbf{A} \hat{\mathbf{x}}_k^- + \mathbf{B} \mathbf{u}_k + \mathbf{L} (\mathbf{y}_k - \mathbf{C} \hat{\mathbf{x}}_k^-) \quad (\text{F.11})$$

which matches equation (F.5). Therefore, the eigenvalues of the Kalman filter **observer** can be obtained by

$$\begin{aligned} & \text{eig}(\mathbf{A} - \mathbf{LC}) \\ & \text{eig}(\mathbf{A} - (\mathbf{AK}_k)(\mathbf{C})) \\ & \text{eig}(\mathbf{A}(\mathbf{I} - \mathbf{K}_k\mathbf{C})) \end{aligned} \quad (\text{F.12})$$

### F.3.1 Luenberger observer with separate prediction and update

To run a Luenberger **observer** with separate prediction and update steps, substitute the relationship between the Luenberger **observer** and Kalman filter matrices derived above into the Kalman filter equations.

Appendix F.3 shows that  $\mathbf{L} = \mathbf{AK}_k$ . Since  $\mathbf{L}$  and  $\mathbf{A}$  are constant, one must assume  $\mathbf{K}_k$  has reached steady-state. Then,  $\mathbf{K} = \mathbf{A}^{-1}\mathbf{L}$ . Substitute this into the Kalman filter update equation.

$$\begin{aligned} \hat{\mathbf{x}}_{k+1}^+ &= \hat{\mathbf{x}}_{k+1}^- + \mathbf{K}(\mathbf{y}_{k+1} - \mathbf{C}\hat{\mathbf{x}}_{k+1}^-) \\ \hat{\mathbf{x}}_{k+1}^+ &= \hat{\mathbf{x}}_{k+1}^- + \mathbf{A}^{-1}\mathbf{L}(\mathbf{y}_{k+1} - \mathbf{C}\hat{\mathbf{x}}_{k+1}^-) \end{aligned}$$

Substitute in equation (9.4).

$$\hat{\mathbf{x}}_{k+1}^+ = \hat{\mathbf{x}}_{k+1}^- + \mathbf{A}^{-1}\mathbf{L}(\mathbf{y}_{k+1} - \hat{\mathbf{y}}_{k+1})$$

The predict step is the same as the Kalman filter's. Therefore, a Luenberger **observer** run with prediction and update steps is written as follows.

Predict step

$$\hat{\mathbf{x}}_{k+1}^- = \mathbf{A}\hat{\mathbf{x}}_k^- + \mathbf{B}\mathbf{u}_k \quad (\text{F.13})$$

Update step

$$\hat{\mathbf{x}}_{k+1}^+ = \hat{\mathbf{x}}_{k+1}^- + \mathbf{A}^{-1}\mathbf{L}(\mathbf{y}_{k+1} - \hat{\mathbf{y}}_{k+1}) \quad (\text{F.14})$$

$$\hat{\mathbf{y}}_{k+1} = \mathbf{C}\hat{\mathbf{x}}_{k+1}^- \quad (\text{F.15})$$

## F.4 Trapezoidal motion profile

## Glossary

**agent** An independent actor being controlled through autonomy or human-in-the-loop (e.g., a robot, aircraft, etc.).

**control effort** A term describing how much force, pressure, etc. an actuator is exerting.

**control input** The input of a **plant** used for the purpose of controlling it.

**control law** Also known as control policy, is a mathematical formula used by the **controller** to determine the **input**  $u$  that is sent to the **plant**. This control law is designed to drive the **system** from its current **state** to some other desired **state**.

**control system** Monitors and controls the behavior of a **system**.

**controller** Applies an **input** to a **plant** to bring about a desired **system state** by driving the difference between a **reference** signal and the **output** to zero.

**discretization** The process by which a continuous (e.g., analog) **system** or **controller** design is converted to discrete (e.g., digital).

**disturbance** An external force acting on a **system** that isn't included in the **system's model**.

**disturbance rejection** The quality of a feedback control **system** to compensate for external forces to reach a desired **reference**.

**error** **Reference** minus an **output** or **state**.

**feedback controller** Used in positive or negative feedback with a **plant** to bring about a desired **system state** by driving the difference between a **reference** signal and the **output** to zero.

**feedback gain** The gain from the **output** to an earlier point in a **control system** diagram.

**feedforward controller** A **controller** that injects information about the **system's** dynamics (like a **model** does) or the desired movement. The feedforward handles parts of the control actions we already know must be applied to make a **system** track a **reference**, then the feedback controller compensates for what we do not or cannot know about the **system's** behavior at runtime.

**gain** A proportional value that shows the relationship between the magnitude of an input signal to the magnitude of an output signal at steady-state.

**gain margin** See section 20.7 on gain and phase margin.

**impulse response** The response of a **system** to the Dirac delta function.

**input** An input to the **plant** (hence the name) that can be used to change the **plant's state**.

**linearization** A method by which a nonlinear **system's** dynamics are approximated by a linear **system**.

**localization** The process of using measurements of the environment to determine an **agent's pose**.

**model** A set of mathematical equations that reflects some aspect of a physical **system's** behavior.

**noise immunity** The quality of a **system** to have its performance or stability unaffected by noise in the **outputs** (see also: **robustness**).

**observer** In control theory, a **system** that estimates the internal **state** of a given real **system** from measurements of the **input** and **output** of the real **system**.

**open-loop gain** The gain directly from the **input** to the **output**, ignoring loops.

**output** Measurements from sensors.

**output-based control** Controls the **system's state** via the **outputs**.

**overshoot** The amount by which a **system's state** surpasses the **reference** after rising toward it.

**phase margin** See section 20.7 on gain and phase margin.

**plant** The **system** or collection of actuators being controlled.

**pose** The orientation of an **agent** in the world, which is represented by all or part of the **agent's state**.

**process variable** The term used to describe the **output** of a **plant** in the context of PID control.

**realization** In control theory, this is an implementation of a given input-output behavior as a state-space **model**.

**reference** The desired state. This value is used as the reference point for a controller's error calculation.

**regulator** A **controller** that attempts to minimize the **error** from a constant **reference** in the presence of disturbances.

**rise time** The time a **system** takes to initially reach the **reference** after applying a **step input**.

**robustness** The quality of a feedback **control system** to remain stable in response to disturbances and uncertainty.

**setpoint** The term used to describe the **reference** of a PID controller.

**settling time** The time a **system** takes to settle at the **reference** after a **step input** is applied.

**state** A characteristic of a **system** (e.g., velocity) that can be used to determine the **system's** future behavior.

**state feedback** Uses **state** instead of **output** in feedback.

**steady-state error** Error after **system** reaches equilibrium.

**step input** A **system input** that is 0 for  $t < 0$  and a constant greater than 0 for  $t \geq 0$ . A step input that is 1 for  $t \geq 0$  is called a unit step input.

**step response** The response of a **system** to a **step input**.

**stochastic process** A process whose **model** is partially or completely defined by random variables.

**system** A term encompassing a **plant** and its interaction with a **controller** and **observer**, which is treated as a single entity. Mathematically speaking, a **system** maps **inputs** to **outputs** through a linear combination of **states**.

**system response** The behavior of a **system** over time for a given **input**.

**time-invariant** The **system's** fundamental response does not change over time.

**tracking** In control theory, the process of making the output of a **control system** follow the **reference**.

**unity feedback** A feedback network in a **control system** diagram with a feedback gain of 1.

## Bibliography

### Online

- [14] Wikimedia Commons. *Runge-Kutta methods: Explicit Runge-Kutta methods*. URL: [https://en.wikipedia.org/wiki/Runge%E2%80%93Kutta\\_methods#Explicit\\_Runge-E2.80.93Kutta\\_methods](https://en.wikipedia.org/wiki/Runge%E2%80%93Kutta_methods#Explicit_Runge-E2.80.93Kutta_methods) (visited on 06/18/2020) (cited on page 73).
- [15] Wikipedia Commons. *Linear-quadratic regulator*. URL: [https://en.wikipedia.org/wiki/Linear%E2%80%93quadratic\\_regulator](https://en.wikipedia.org/wiki/Linear%E2%80%93quadratic_regulator) (visited on 03/24/2018) (cited on page 213).
- [17] Declan Freeman-Gleason. *A Dive into WPILib Trajectories*. 2020. URL: <https://pietroglyph.github.io/trajectory-presentation/> (cited on page 172).
- [18] Sean Humbert. *Why do we have to linearize around an equilibrium point?* URL: [https://www.cds.caltech.edu/~emurray/courses/cds101/fa02/faq/02-10-09\\_linearization.html](https://www.cds.caltech.edu/~emurray/courses/cds101/fa02/faq/02-10-09_linearization.html) (visited on 07/12/2018) (cited on page 56).
- [19] Simon J. Julier and Jeffrey K. Uhlmann. *A New Extension of the Kalman Filter to Nonlinear Systems*. URL: [https://www.cs.unc.edu/~welch/kalman/media/pdf/Julier1997\\_SPIE\\_KF.pdf](https://www.cs.unc.edu/~welch/kalman/media/pdf/Julier1997_SPIE_KF.pdf) (visited on 09/29/2019) (cited on page 117).
- [20] Kapitanyuk, Proskurnikov, and Cao. *A guiding vector field algorithm for path following control of nonholonomic mobile robots*. URL: <https://arxiv.org/pdf/1610.04391.pdf> (visited on 08/09/2018) (cited on page 58).
- [21] Matthew Kelly. *An Introduction to Trajectory Optimization: How to Do Your Own Direct Collocation*. URL: [https://www.matthewpeterkelly.com/research/MatthewKelly\\_IntroTrajectoryOptimization\\_SIAM\\_Review\\_2017.pdf](https://www.matthewpeterkelly.com/research/MatthewKelly_IntroTrajectoryOptimization_SIAM_Review_2017.pdf) (visited on 08/27/2019) (cited on page 177).
- [22] Edgar Kraft. *A Quaternion-based Unscented Kalman Filter for Orientation Tracking*. URL: <https://kodlab.seas.upenn.edu/uploads/Arund/UKFpaper.pdf> (visited on 07/11/2018) (cited on page 117).
- [23] Roger Labbe. *Kalman and Bayesian Filters in Python*. URL: <https://github.com/rlabbe/Kalman-and-Bayesian-Filters-in-Python/> (visited on 04/29/2020) (cited on page 89).
- [24] Charles F. Van Loan. *Computing Integrals Involving the Matrix Exponential*. URL: <https://www.cs.cornell.edu/cv/ResearchPDF/computing.integrals.involving.Matrix.Exp.pdf> (visited on 06/21/2018) (cited on page 53).



- [25] Andrew W. Long et al. *The Banana Distribution is Gaussian: A Localization Study with Exponential Coordinates*. 2008. URL: [https://rpk.lcsr.jhu.edu/wp-content/uploads/2014/08/p34\\_Long12\\_The-Banana-Distribution.pdf](https://rpk.lcsr.jhu.edu/wp-content/uploads/2014/08/p34_Long12_The-Banana-Distribution.pdf) (cited on page 89).
- [26] Luca, Oriolo, and Vendittelli. *Control of Wheeled Mobile Robots: An Experimental Overview*. URL: <https://web.archive.org/web/20200709171003/https://www.dis.uniroma1.it/~labrob/pub/papers/Ramsete01.pdf> (visited on 08/09/2018) (cited on pages 78, 79).
- [27] Simon J.A. Malham. *An introduction to Lagrangian and Hamiltonian Mechanics*. URL: <http://www.macs.hw.ac.uk/~simonm/mechanics.pdf> (visited on 08/23/2016) (cited on page 157).
- [28] MIT OpenCourseWare. *Linear Quadratic Regulator*. URL: <https://ocw.mit.edu/courses/mechanical-engineering/2-154-maneuvering-and-control-of-surface-and-underwater-vehicles-13-49-fall-2004/lecture-notes/lec19.pdf> (visited on 06/26/2018) (cited on page 33).
- [29] Christoph Sprunk. *Planning Motion Trajectories for Mobile Robots Using Splines*. 2008. URL: <http://www2.informatik.uni-freiburg.de/~lau/students/Sprunk2008.pdf> (cited on page 172).
- [32] Russ Tedrake. *Underactuated Robotics*. 2019. URL: <http://underactuated.mit.edu> (cited on page 58).
- [33] Russ Tedrake. *Chapter 9. Linear Quadratic Regulators*. URL: <http://underactuated.mit.edu/lqr.html> (visited on 03/22/2020) (cited on page 213).
- [34] Eric A. Wan and Rudolph van der Merwe. *The Unscented Kalman Filter for Nonlinear Estimation*. URL: <https://www.seas.harvard.edu/courses/cs281/papers/unscented.pdf> (visited on 06/26/2018) (cited on page 117).

## Misc

- [1] FRC team 254. *Motion Planning and Control in FRC*. 2015. URL: <https://www.youtube.com/watch?v=8319J1BEHwM> (cited on page 172).
- [2] 3Blue1Brown. *Abstract vector spaces*. 2016. URL: <https://www.youtube.com/watch?v=TgKwz5Ikpc8> (cited on page 192).
- [3] 3Blue1Brown. *Eigenvectors and eigenvalues*. 2016. URL: <https://www.youtube.com/watch?v=PFDu9oVAE-g> (cited on page 24).
- [4] 3Blue1Brown. *Essence of linear algebra preview*. 2016. URL: <https://www.youtube.com/watch?v=kjBOesZCoqc> (cited on page 23).
- [5] 3Blue1Brown. *Inverse matrices, column space, and null space*. 2016. URL: <https://www.youtube.com/watch?v=uQhTuRIWMxw> (cited on page 24).
- [6] 3Blue1Brown. *Linear combinations, span, and basis vectors*. 2016. URL: <https://www.youtube.com/watch?v=k7RM-ot2NWY> (cited on page 23).
- [7] 3Blue1Brown. *Linear transformations and matrices*. 2016. URL: <https://www.youtube.com/watch?v=kYB8IZa5AuE> (cited on page 23).
- [8] 3Blue1Brown. *Matrix multiplication as composition*. 2016. URL: <https://www.youtube.com/watch?v=XkY2DOUCWMU> (cited on page 23).
- [9] 3Blue1Brown. *Nonsquare matrices as transformations between dimensions*. 2016. URL: [https://www.youtube.com/watch?v=v8VSDg\\_WQIA](https://www.youtube.com/watch?v=v8VSDg_WQIA) (cited on page 24).
- [10] 3Blue1Brown. *The determinant*. 2016. URL: <https://www.youtube.com/watch?v=Ip3X9LOh2dk> (cited on page 24).
- [11] 3Blue1Brown. *Vectors, what even are they?* 2016. URL: [https://www.youtube.com/watch?v=fNk\\_zzaMoSs](https://www.youtube.com/watch?v=fNk_zzaMoSs) (cited on page 23).
- [12] 3Blue1Brown. *Essence of calculus*. 2017. URL: <https://www.youtube.com/playlist?list=PLZHQObOWTQDMsr9K-rj53DwVRMYO3t5Yr> (cited on page 127).
- [13] 3Blue1Brown. *Taylor series*. 2017. URL: <https://www.youtube.com/watch?v=3d6DsJIBzJ4> (cited on page 51).



- 
- [16] Brian Douglas. *Gain and Phase Margins Explained!* 2015. URL: <https://www.youtube.com/watch?v=ThoA4amCAX4> (cited on page 201).
- [30] Zach Star. *What does the Laplace Transform really tell us? A visual explanation (plus applications)*. 2019. URL: <https://www.youtube.com/watch?v=n2y7n6jw5d0> (cited on page 181).
- [31] Russ Tedrake. *6.832 Underactuated Robotics*. 2019. URL: [https://www.youtube.com/channel/UChfUOAHz7ynELF-s\\_1LPpWg/videos](https://www.youtube.com/channel/UChfUOAHz7ynELF-s_1LPpWg/videos) (cited on page 58).

*This page intentionally left blank*

# Index

- block diagrams, 8
  - simplification, 205
- controller design
  - actuator saturation, 19
  - controllability, 28
  - linear time-varying control, 70
  - linear-quadratic regulator, 31
    - Bryson's rule, 33
    - definition, 33
    - implicit model following, 215
    - output feedback, 214
    - time delay compensation, 217
  - observability, 28
  - pole placement, 30
- digital signal processing
  - aliasing, 45
  - Nyquist frequency, 45
- discretization, 46
  - backward Euler method, 46
  - bilinear transform, 46
  - forward Euler method, 46
  - matrix exponential, 50
  - Taylor series, 51
  - zero-order hold, 52
- feedforward
  - linear plant inversion, 38
  - steady-state feedforward, 227
- FRC models
  - DC brushed motor equations, 142
  - differential drive equations, 69
  - elevator equations, 59
  - flywheel equations, 61
  - holonomic drivetrains, 68
  - single-jointed arm equations, 64
- gain, 8
- integral control
  - input error estimation, 40
  - plant augmentation, 40
- linear algebra
  - basis vectors, 23
  - linear combination, 23
  - vectors, 23
- matrices
  - determinant, 24
  - eigenvalues, 24
  - inverse, 24
  - linear systems, 24
  - linear transformation, 23
  - multiplication, 23
  - pseudoinverse, 24
  - rank, 24

- transpose, 24
- model augmentation
  - of controller, 34
  - of observer, 35
  - of output, 35
  - of plant, 34
- motion profiles
  - 1-DOF, 169
  - 2-DOF, 172
  - S-curve, 170
  - trajectory optimization, 177
  - trapezoid, 170
- nonlinear control
  - extended Kalman filter, 116
  - linear time-varying control, 70
  - linearization, 55, 67
  - Lyapunov stability, 56
  - Unscented Kalman filter, 116
- optimal control
  - linear plant inversion, 38
  - linear time-varying control, 70
  - linear-quadratic regulator, 31
    - Bryson's rule, 33
    - definition, 33
- physics
  - conservation of energy, 152
  - sum of forces, 150
  - sum of torques, 151
- PID control, 11, 25, 198
- probability, 92
  - Bayes's rule, 96
  - central limit theorem, 99
  - conditional expectation, 96
  - conditional probability density functions, 96
  - conditional variances, 96
  - covariance, 95
  - covariance matrix, 97
  - expected value, 93
  - marginal probability density functions, 96
  - probability density function, 92
  - probability density functions, 94
  - random variables, 92
  - variance, 93
- stability
  - eigenvalues, 30, 91
  - gain margin, 201
  - phase margin, 201
  - poles, 27
  - poles and zeroes, 182
  - root locus, 184
- state-space controllers
  - closed-loop, 30
  - open-loop, 27
- state-space observers
  - Extended Kalman filter, 116
  - Kalman filter
    - as Luenberger observer, 108
    - derivations, 99, 101
    - equations, 104
    - setup, 106
  - Kalman smoother, 110
    - derivations, 110
    - equations, 113
  - Luenberger observer, 90
  - multiple model adaptive estimation, 117
  - Unscented Kalman filter, 116
- steady-state error, 196
- stochastic
  - linear systems, 99
  - measurement noise, 99
  - process noise, 99
  - two-sensor problem, 101

