

# Offshore Oil and Gas Energy System Optimisation (OOGESO) DOCUMENTATION

Harald G Svendsen

12th August 2020

## Contents

<b>1</b>	<b>Introduction</b>	<b>3</b>
1.1	Objective . . . . .	3
<b>2</b>	<b>Model concepts</b>	<b>4</b>
2.1	Optimisation problem . . . . .	4
2.1.1	Time-steps and horizons . . . . .	5
2.2	Energy carrier networks . . . . .	5
2.2.1	Network components . . . . .	6
2.2.2	Energy carriers and network types . . . . .	7
2.3	Devices . . . . .	8
2.3.1	Upper and lower bounds . . . . .	8
2.3.2	Ramp rate limits . . . . .	8
2.3.3	Flexibility . . . . .	8
2.3.4	Electrical reserve power capacity . . . . .	9
2.3.5	Start-up time . . . . .	10
2.3.6	Optimisation variables . . . . .	10
<b>3</b>	<b>Energy carrier networks</b>	<b>10</b>
3.1	Electricity network . . . . .	10
3.2	Gas network (pipelines) . . . . .	11
3.2.1	Linearisation . . . . .	14

---

3.2.2	Volumetric flow vs energy flow . . . . .	15
3.3	Liquid flow network (oil and water) . . . . .	15
3.3.1	Darcy friction factor . . . . .	16
3.3.2	Linearisation of equation (UPDATE) . . . . .	17
3.4	Wellstream (not yet implemented) . . . . .	18
3.5	Heat network . . . . .	18
<b>4</b>	<b>Devices</b>	<b>18</b>
4.1	Production well [well_production] . . . . .	19
4.2	Separator [separator] . . . . .	19
4.3	Compressor [compressor_el] . . . . .	20
4.4	Compressor [compressor_gas] . . . . .	23
4.5	Water pump [pump_water] . . . . .	23
4.6	Oil pump [pump_oil] . . . . .	24
4.7	Gas heater [gasheater] . . . . .	25
4.8	Heat pump and electric boiler [heatpump] . . . . .	25
4.9	Gas turbine [gasturbine] . . . . .	25
4.10	Source water [source_water] . . . . .	26
4.11	Source el [source_el] . . . . .	27
4.12	Electrical battery [storage_el] . . . . .	27
4.13	Water sink [sink_water] . . . . .	28
4.14	Gas sink [sink_gas] . . . . .	28
4.15	Oil sink [sink_oil] . . . . .	29
4.16	Electrical load [sink_el] . . . . .	29
4.17	Heat sink [sink_heat] . . . . .	29
4.18	Device types not yet implemented . . . . .	29
<b>5</b>	<b>Input data</b>	<b>30</b>
<b>6</b>	<b>Examples</b>	<b>32</b>

# 1 Introduction

This document describes a simulation model for studying operational strategies for low-emission offshore oil and gas field energy systems (illustrated in Figure 1), and the performance with different system designs.

The simulation model is being developed within the Norwegian *Low Emission Research Centre*<sup>1</sup>, with financial support from the Research Council of Norway and Centre partners. The Centre aims to develop new technologies and concepts for offshore energy systems, energy efficiency and integration with renewable power production technologies for application on the Norwegian Continental Shelf.

The program code is open-source with a permissible MIT licence, and is freely available.<sup>2</sup>

## 1.1 Objective

There are two main objectives of the hybrid energy system modelling

- Compute CO2 emissions in different scenarios with different design choices and operational strategies, and compare results to provide design decision support
- Provide operational decision support to give economical operation with minimal CO2 emissions

Examples of operational decisions are

- Start/stop signals to gas turbines
- Energy storage charging and discharging signals
- Curtailment of wind power
- Power setpoint signals for flexible loads
- Load shedding

Design choices that may be relevant to consider and compare include:

- Power supply and energy storage options (numbers, types, capacities)
- Pipe dimensions and other properties
- Device parameters (e.g. ramp rate and capacity of gas turbine)
- Amount of load flexibility

Operational strategy is encoded in the problem formulation indirectly through

---

<sup>1</sup><https://www.sintef.no/en/projects/lowemission-research-centre/>

<sup>2</sup>[https://bitbucket.org/harald\\_g\\_svensen/oogeso](https://bitbucket.org/harald_g_svensen/oogeso)




Figure 1: Offshore oil and gas field hybrid energy system

- Strategy for storage utilisation
- Risk tolerance level
- Forecasting
- Parameter choices (e.g. allowable max/min bounds).

## 2 Model concepts

This chapter provides a high-level description of the underlying concepts applied in the model. More details are given in chapters 3 and 4.

### 2.1 Optimisation problem

The purpose of this software tool is to provide operational decision support for an offshore energy system with a specified configuration. Specifically, the task is to provide set-points for controllable variables in the system to minimise CO<sub>2</sub> emissions as well as costs for fuel and costs associated with lost oil/gas export. The main controllable variables are power output of generators, power demand of flexible loads, charging and discharging of energy storages. This is therefore an optimisation problem with an objective function given by weighing between CO<sub>2</sub> emissions and costs, and constraints that represent inter-dependencies and bounds. For example, the relationship between pressure drop and energy flow in a gas pipe is represented by an equation that is a constraint in the optimisation problem. Another example

is the relationship between gas consumption and electric power and heat output of a gas turbine generator.

The problem includes *integer* variables representing start/stop status of devices. For solvability, the problem is *linearised*, i.e. objective function and constraints are linear expression with respect to the variables. The optimisation problem therefore classifies as a mixed-integer linear programming (MILP) problem.

### 2.1.1 Time-steps and horizons

For operational control and CO<sub>2</sub> emission estimation, the variability with time of energy demand and energy availability is important, as are start-up costs and ramp rate limitations of turbines, and possibly other device types. Time variability is included via time-series and time-step by time-step solutions of the problem.

For the planning of start-up and shut-down of devices, notably gas turbines operated in combination with wind power supply, it is necessary to consider a time-horizon stretching into the future rather than just the present time snapshot. If wind power is rapidly dropping and an extra gas turbine is required at full power in 2 hours, the gas turbine may have to be started already now because of ramp rate limits. And instead of shutting down the gas turbine for one hour, and then starting it up again, it may be more economical to keep it running (to avoid start-up costs). Optimal charging and discharging of battery, and utilisation of demand flexibility likewise depends on what is expected to happen next.

As an operational planning tool, therefore, the model contains a rolling horizon optimization, where the system is optimised for a certain planning horizon that is continuously shifted forward, see Figure 2. For example. The optimisation may be done for every 15 minutes for the next 12 hours, repeated at every hour.

## 2.2 Energy carrier networks

The offshore energy system is modelled as a hybrid system with multiple energy carriers, see Figure 3. There are energy transfer links or *networks* for each energy carrier, and *devices* that consume, produce, or convert energy from one form to another.




Figure 2: Rolling horizon optimization

Networks are modelled for the different energy carriers. Network topology is specified by sets of nodes and edges. An edge is a connection between two nodes.

### 2.2.1 Network components

**Nodes** Connection points for devices and edges. A node has input/output terminals (see below) for different energy carriers.

**Terminals** Terminals exist within a node. There are different terminals for the different energy carriers. If there are *series* connected devices, the terminal is split in an *in* terminal and an *out* terminal. Edges and devices are linked to specific terminals within a node.

**Edges** Connection between nodes, with physical properties depending on network type. Energy flows through the edges.

**Devices** Things that "do" something in the network. Consumption and generation of one or more of the energy carriers. Devices are modelled as either

- consumer/producer – these are devices that extract and/or inject power into of one or more energy carriers. Examples: gas turbine, electric auxiliary load, water injection pump, ...
- series devices – these are devices with power flowing through with




Figure 3: Example schematic of an offshore multi-carrier hybrid energy system

an input terminal and an output terminal with different properties (e.g. gas pressure). Examples: oil pumps, gas compressors  
More information about device modelling is given in Section 4.

### 2.2.2 Energy carriers and network types

The energy carriers and their most relevant network properties/characteristics are:

**Electricity** Electric power through electric conductors

- impedance, energy loss, max flow, 2-directional
- power flow determined by endpoint voltage angles

**Heat** Thermal energy transport

- modelled as lossless energy transfer (assuming short distances)

**Wellstream** Raw crude oil through pipelines

- pressure, viscosity, 1-directional
- composition (oil/gas/water) of wellstream is highly case-dependent

**Gas** Gas through pipelines

- pressure, diameter, friction, gas properties, 1-directional

- flow determined by endpoint pressure and pipeline friction

**Oil/water** Liquid oil and water through pipelines

- pressure, diameter, friction, fluid properties, 1-directional
- flow determined by endpoint pressure and pipeline friction

The raw wellstream flowing from the well is considered a mix of oil, gas and water, with composition ratio specified as input.

## 2.3 Devices

Detailed description of the various device types are given in Section 4, but some common, generic concepts are described in the following.

### 2.3.1 Upper and lower bounds

Typically the energy or volume flow rate ( $P$  or  $Q$ ) in or out of devices are limited by maximum and minimum values (provided as user input). Sometimes these bounds are time-dependent. For example, for wind power the maximum electrical output is limited by available wind power.

$$P_{\min} \leq P_{\text{device}} \leq p(t)P_{\max} \quad (1)$$

The function  $p(t)$  is a time profile that may be specified to represent e.g. wind power availability. If no time profile is specified in the input,  $p(t) = 1$  is used.

### 2.3.2 Ramp rate limits

Devices may have ramp rate limits defined, and exactly what is limited varies slightly between different device models. Typically this is electric power input or output, or heat output:

$$\text{maxRampDown} \leq P_t - P_{t-1} \leq \text{maxRampUp} \quad (2)$$

### 2.3.3 Flexibility

An important aspect of the integrated modelling of the system is the analysis of the impact and benefit of flexibility such as the option of adjusting water injection in response to available wind power.



Flexibility is included in the model by introducing an energy buffer that allows power demand to deviate from the nominal or average value. Mathematically, this is very similar to the modelling of energy storage.

#### 2.3.4 Electrical reserve power capacity

In case of a fault on a power supply unit, reserve capacity is needed to cover the lost supply – either by ramping up other supply units or by reducing power consumption by loads. For a generator  $i$ , the reserve capacity contribution is the capacity not used  $RC_i(t)$ , i.e. the difference between available capacity (that may be time-dependent, e.g. for wind power) and current power output:

$$RC_i(t) = P_i^{\max} p_i(t) - P_i. \quad (3)$$

*For a battery, the available power is in reality limited not just by the maximum power, but also by the energy stored in the battery. This is not included at present. Possibly, this could be included in a linear way by computing an effective capacity profile from the battery energy scheduling from the previous timestep optimisation.*

For a load, the reserve capacity contribution is the part of the load which can be shed (if any):

$$RL_i(t) = f_i^{shed} P_i, \quad (4)$$

where  $f_i^{shed}$  is a factor (input parameter) that specifies which fraction of the load that can be shed. If the load cannot be shed, this factor is zero. If all can be shed, it is 1.

The overall reserve capacity is then

$$R = \sum_i [RC_i(t) + RL_i(t)]. \quad (5)$$

However, if there is a fault on device  $i$ , the critical issue is not the overall reserve capacity, but the overall reserve capacity *minus the contribution from the device itself*, which is:

$$R_i = \sum_{j \neq i} [RC_j(t) + RL_j(t)]. \quad (6)$$

To ensure there is enough reserve capacity in case of fault on any power supply device, the following constraint must be satisfied for all electrical devices:

$$R_i \geq P_i \quad (7)$$

### 2.3.5 Start-up time

Devices may be specified with a start-up delay, meaning that once turned on, some time is required before power can be ramped up. This is relevant at least for gas turbines. Simple cycle gas turbines may have a start-up delay of 10 minutes, while combined cycle gas turbines about 30 minutes.

### 2.3.6 Optimisation variables

Associated with devices are the following variables:

- device flow (`varDeviceFlow`) – power/volume flow per carrier, in and out of the device

For devices with start-up time delay or costs, the following variables are used:

- on/off status (`varDeviceIsOn`) – boolean variables representing operational status
- starting (`varDeviceStarting`) – boolean variable indicating if device is changing from stopped to started
- stopping (`varDeviceStopping`) – boolean variable indicating if device is changing from started to stopped

And for devices with energy storage:

- device energy storage level (`varDeviceEnergy`) – state of charge for associated energy storage

Section 4 gives an overview of the various implemented device types.

## 3 Energy carrier networks

This chapter describes in more detail the modelling of energy flow in the different types of networks.

### 3.1 Electricity network

Alternating current (AC) power flow in an electricity network is governed by non-linear power flow equations which express the relationships between line impedances (physical properties), complex net power injections, and voltage angle and magnitude at each node. Power flow is derived from voltage angle differences

The electricity network for offshore energy systems (platform or cluster of platforms) is a type of distribution grid with voltage levels from 230 V to

20 kV, potentially higher for interconnections. The network normally has a radial structure. There are three main modelling alternatives

- Energy transport model
  - power flow only limited by line capacity limits
  - voltages ignored; only active power considered
- Linearised power flow model (DC power flow)
  - power flow determined by linearised power flow equations
  - line flow limited by line capacity
  - assumes voltage magnitudes at nominal values, ignores reactive power flow
- Non-linear power flow model (AC power flow) (not implemented)
  - computes active and reactive power flow, voltage magnitude and angle

Constraints:

- Power flow balance at each node (power flow equations)
- Limits on transmitted power in edges
- Voltage limits at nodes

### 3.2 Gas network (pipelines)

Energy flow in the gas pipeline network is modelled using linearised Weymouth equations, as outlined in the following. Symbols are defined in Table 1.

The flow equation relates gas flow and pressure. Mass conservation means that the mass flow (measured in kg/s) is constant throughout a pipe with fixed diameter, whereas the volumetric flow (measured in m<sup>3</sup>/s) depends on the pressure, flow increases when pressure decreases (gas particles require more space). Mass and volumetric flow are related via the pressure:

$$W = \rho_{in}Q_{in} = \rho_{out}Q_{out} = \rho_s Q. \quad (8)$$

The subscript  $s$  denotes standard conditions (temperature  $T_s = 273.15$  K and pressure  $p_s = 100$  kPa). The density  $\rho_s$  is a fixed value but  $\rho_{in}$  and  $\rho_{out}$  depend on the pressure and temperature. The below gas flow equations are expressed using standard condition flow rate  $Q$ . As mass flow, this is the same at any point on the pipe.

For a gas, the density depends on the pressure. Assuming ideal gas, this relationship is

$$p_i = \rho_i \frac{R}{M} T_i, \quad (9)$$

where  $R = 8.314 \frac{J}{\text{mol K}}$  is the universal gas constant,  $M$  is the molar mass (kg), and  $T$  is the temperature (K). For natural gas, the molar mass is  $M = 0.019$  kg/mol. Thus,  $\rho_s = \frac{Mp_s}{RT_s} = 0.84 \frac{kg}{m^3}$ .

There are several different approximations describing the gas flow in a gas pipeline network<sup>3</sup>. The general flow equations, expressing the gas volumetric flow rate (under standard conditions)  $Q_d$  from high to low pressure (  $p_{in} \geq p_{out}$  ) is

$$Q_d = 1.1494 \times 10^{-3} \frac{T_b}{P_b} \sqrt{\frac{(p_{in}^2 - p_{out}^2)}{GT_f LZ f}} D^{5/2} = (\dots) \sqrt{(p_{in}^2 - p_{out}^2)}, \quad (10)$$

The Darcy friction factor  $f$  is sometimes replaced by  $F = 2/\sqrt{f}$  (transmission factor).

Including elevation difference, the equation becomes

$$Q_d = 1.1494 \times 10^{-3} \frac{T_b}{P_b} \sqrt{\frac{(p_{in}^2 - e^s p_{out}^2)}{GT_f L_e Z f}} D^{\frac{5}{2}} \quad (11)$$

The factor  $e^s$  and the equivalent length  $L_e$  together account for elevation differences. These are defined as:

$$s = 0.0684G \frac{h_2 - h_1}{T_f Z}, \quad (12)$$

$$L_e = L \frac{e^s - 1}{s}, \quad (13)$$

where  $h$  is elevation (in m) and  $L$  is the segment length (km).

Using for the friction factor  $F = 6.521D^{1/6}$ , or equivalently,  $f = \frac{4}{F^2} = 0.09406D^{-1/3}$ , we get the (non-linear) Weymouth equation:

$$Q_d = 3.7435 \cdot 10^{-3} \frac{T_b}{P_b} \sqrt{\frac{(p_{in}^2 - e^s p_{out}^2)}{GT_f L_e Z}} D^{\frac{8}{3}}. \quad (14)$$

In our model, we base the description on the Weymouth equation, which is appropriate for high pressure, high flow rates and large diameter gas pipelines.

---

<sup>3</sup> E Sashi Menon, Gas Pipeline Hydraulics, Taylor & Francis (2005), <https://doi.org/10.1201/9781420038224>

Table 1: Symbols used in gas network modelling

symbol	unit	description	value
$Q_d$	m <sup>3</sup> /day	gas flow rate, standard conditions	(computed)
$Q$	m <sup>3</sup> /s	gas flow rate, SI units, standard conditions	(computed)
$W$	kg/s	mass flow rate	
$P$	MW	energy flow	(computed)
$CV$	MJ/m <sup>3</sup>	energy value (calorific value) at standard conditions	40 MJ/m <sup>3</sup> for natural gas
$T_b$	K	base temperature, ambient temperature?	273+15 K
$p_b$	kPa	base pressure, local atmospheric pressure	101 kPa (1 bar)
$p_{in}$	kPa	pipe pressure inlet	
$p_{out}$	kPa	pipe pressure outlet	
$L$	km	pipe length	
$\rho_s$	kg/m <sup>3</sup>	gas density, standard conditions	0.84 kg/m <sup>3</sup> for natural gas
$T_f$	K	gas temperature	
$G$	1	gas gravity (air = 1)	0.6 ?
$Z$	1	compressibility factor	0.9 ?
$f$	1	Darcy friction factor	(computed)
$D$	mm	pipe inside diameter	150–1200 ??
$h_{in}$	m	height inlet	
$h_{out}$	m	height outlet	
$s$	1	elevation factor	(computed)
$L_e$	km	equivalent length	(computed)

The flow rate  $Q$  in standard SI units (m<sup>3</sup>/s) is:

$$Q = \frac{1 \text{ day}}{24 \cdot 3600 \text{ s}} Q_d = k \sqrt{(p_{in}^2 - e^s p_{out}^2)}, \quad (15)$$

where the constant  $k$  is a property of the pipeline and the gas, given as

$$k = 4.3328 \cdot 10^{-8} \frac{\text{m}^3}{\text{s MPa}} \cdot \frac{T_b}{P_b} [GT_f L_e Z]^{-\frac{1}{2}} D^{\frac{8}{3}}, \quad (16)$$

where quantities are expressed in units [T]=K, [P]=MPa, [L]=km, [D]=mm.

### 3.2.1 Linearisation

Assuming that the pressure remains close to the given nominal values  $p_{in,0}$  and  $p_{out,0}$  at the pipe endpoints, we can linearise the Weymouth equation by expanding around these values<sup>4</sup>:

$$p_{in} = p_{in,0} + \Delta p_{in}, \quad p_{out} = p_{out,0} + \Delta p_{out} \quad (17)$$

This gives the following linear approximation:

$$Q \simeq \frac{k}{\sqrt{(p_{in,0}^2 - e^s p_{out,0}^2)}} [p_{in,0} \Delta p_{in} - e^s p_{out,0} \Delta p_{out}] \quad (18)$$

(if  $p_{out}$  is smaller,  $Q$  is larger). Note: This approximation is only valid if  $p_{in} \approx p_{in,0}$  and  $p_{out} \approx p_{out,0}$ . To determine appropriate nominal pressure values, the non-linear Weymouth equation may be used to compute the pressure drop in a pipe for the expected flow rate.

Constraints:

- Energy balance at each terminal
- Limits on pressure deviation from nominal value
- Edge flow vs terminal pressure (Weymouth equation)

---

<sup>4</sup> A Tomasgard et al., Optimization models for the natural gas value chain, in: Geometric Modelling, Numerical Simulation and Optimization. Springer Verlag, New York (2007), [https://doi.org/10.1007/978-3-540-68783-2\\_16](https://doi.org/10.1007/978-3-540-68783-2_16)

Table 2: Symbols used in liquid pipeline modelling

symbol	unit	description	value
$Q$	m <sup>3</sup> /s	liquid flow rate, SI units	(computed)
$P$	MW	energy flow	(computed)
$CV$	MJ/m <sup>3</sup>	energy value (calorific value)	36000 MJ/m <sup>3</sup> for raw oil
$f$	1	Darcy friction factor	0.008 – 0.10
$z$	m	elevation at inlet and outlet	
$p$	Pa	pressure at inlet and outlet	
$\rho$	kg/m <sup>3</sup>	fluid mass density (water: 1000 kg/m <sup>3</sup> oil: 900 kg/m <sup>3</sup> )	
$L$	m	pipe length	
$D$	m	pipe internal diameter	0.2
$e$	m	absolute pipe roughness	
$\langle V \rangle$	m/s	average liquid velocity	oil: 2.5, gas: 15
$g$	m/s <sup>2</sup>	gravitational acceleration	9.98
$\nu$	m <sup>2</sup> /s	fluid kinematic viscosity	brent: 2.86e-6 at 50°C
$\mu = \nu\rho$	kg/(m s)	fluid viscosity (depends on temperature)	oil: ca 0.0026, water: 0.0010
Re	1	Reynolds number	oil: 1.75e5

### 3.2.2 Volumetric flow vs energy flow

The energy flow ( $P$ ) is given by the standard condition volume flow ( $Q$ ) and the gas energy value (calorific value),  $CV$  :

$$P = Q \cdot CV \quad (19)$$

The units are MW for energy flow, m<sup>3</sup>/s for volume flow and MJ/m<sup>3</sup> for the energy value.

## 3.3 Liquid flow network (oil and water)

The mass or energy flow from the well, oil and water is modelled as the flow of incompressible fluids as follows. Symbols used are defined in Table 2.

The pressure loss (head loss) in an incompressible fluid (liquid) pipeline due to friction is described by the empirical Darcy-Weisbach equation<sup>5</sup> (with

<sup>5</sup> E Shashi Menon, Liquid Pipeline Hydraulics, CRC Press (2004), <https://doi.org/10.1201/9780203021385>

the effect of elevation difference (  $z$  ) included),

$$\Delta p = p_{out} - p_{in} = -\rho g (z_{out} - z_{in}) - f \frac{\rho L}{D} \frac{\langle V \rangle^2}{2}, \quad (20)$$

where symbols are explained in Table 2. Since the velocity  $\langle V \rangle$  is related to the volumetric flow rate (  $Q$  ),

$$Q = A \langle V \rangle = \frac{\pi D^2}{4} \langle V \rangle \implies \langle V \rangle^2 = \frac{16}{\pi^2 D^4} Q^2, \quad (21)$$

we can write

$$p_{out} - p_{in} = -\rho g (z_{out} - z_{in}) - \frac{8f\rho L Q^2}{\pi^2 D^5}. \quad (22)$$

Or the equation can be inverted to give the flow rate in terms of pressure:

$$Q = \sqrt{\frac{\pi^2 D^5}{8f\rho L}} \sqrt{p_{in} - p_{out} - \rho g (z_{out} - z_{in})} \quad (23)$$

*Example:* Friction factor  $f = 0.01$ , density  $\rho = 900$  kg/m<sup>3</sup>, diameter  $D = 0.2$  m, flow rate  $Q = 0.1$  m<sup>3</sup>/s, and no height difference, gives pressure drop  $\Delta p/L = 0.22$  MPa/km.

### 3.3.1 Darcy friction factor

The Darcy friction factor  $f$  depends on pipe properties. First, the Reynolds number is defined as

$$Re = \frac{\rho \langle V \rangle D}{\mu} = \frac{\langle V \rangle D}{\nu}. \quad (24)$$

There are three flow regimes, depending on the Reynolds number:

- laminar,  $Re < 2000$
- critical,  $2000 < Re < 4000$
- turbulent,  $Re > 4000$

For laminar flow ( $Re < 2000$ ), the friction factor depends only on the Reynolds number, and not e.g. on the internal smoothness of the pipe. This is referred to as the Moody friction factor:

$$f = f_{\text{Moody}} = \frac{64}{Re}.$$



However, for oil pipes, flow velocity is typically so high that the flow is turbulent. In this case ( $Re > 4000$ ), the friction factor is given by the phenomenological *Colebrook-White* equation:

$$\frac{1}{\sqrt{f}} = -2 \log_{10} \left( \frac{e}{3.7D} + \frac{2.51}{Re\sqrt{f}} \right).$$

In smooth pipes, the roughness term may be neglected, giving the *Kármán-Prandtl* resistance equation:

$$\frac{1}{\sqrt{f}} = -2 \log_{10} \left( \frac{2.51}{Re\sqrt{f}} \right) = 2 \log_{10} (Re\sqrt{f}) - 0.8.$$

Another set of coefficients for this equation sometimes used is:

$$\frac{1}{\sqrt{f}} = 1.930 \log (Re\sqrt{f}) - 0.537 = 0.838 W(0.629 Re),$$

where  $W$  is the Lambert  $W$  function. The friction factor changes by about one order of magnitude for a five orders of magnitude change in Reynolds number:  $Re=4000$  gives  $f=0.039$ , whereas  $Re=10^8$  gives  $f=0.006$ .

Knowing the volumetric flow rate ( $Q$ ), the fluid density ( $\rho$ ) and viscosity ( $\mu$ ), and pipe internal diameter ( $D$ ), the Reynolds number is given as

$$Re = \frac{\rho}{\mu} \langle V \rangle D = \frac{2}{\pi} \frac{\rho Q}{\mu D}.$$

Note that  $\rho Q$  equals the mass flow rate (kg/s)

*In our model, it is assumed that the friction factor is provided as user input for each oil pipe. Differences in friction factor due to changes in the flow rate and temperature (affecting viscosity) are ignored.*

*Example:* Assume  $Q = 1.85 \text{ Sm}^3/\text{s}$ ,  $\rho = 900 \text{ kg/m}^3$ , giving  $\rho Q = 1666 \text{ kg/s}$ ,  $\mu = 3$ ,  $D = 0.1 \text{ m}$  gives  $Re = 5300$ , which in turn gives  $f = 0.036$ .  $\rho Q = 1666 \text{ kg/s}$ ,  $\mu = 0.003$ ,  $D = 0.1 \text{ m}$  gives  $Re = 3.5e6$ , which in turn gives  $f = 0.0097$ .

### 3.3.2 Linearisation of equation (UPDATE)

Since the pressure drop depends on the square of the flow rate, the above Darcy-Weisbach is non-linear and must be linearised to give linear constraint

equations. Let the operating point be defined by pressure levels and flow rate  $p_{in,0}$ ,  $p_{out,0}$ ,  $Q_0$  :

$$Q_0 = \sqrt{\frac{\pi^2 D^5}{8f\rho L}} \sqrt{p_{in,0} - p_{out,0} - \rho g (z_{out} - z_{in})} \quad (25)$$

Then the linearisation around this point becomes:

$$Q \simeq Q_0 + \sqrt{\frac{\pi^2 D^5}{8f\rho L}} \frac{1}{2\sqrt{p_{in,0} - p_{out,0} - \rho g (z_{out} - z_{in})}} [p_{in} - p_{out} - (p_{in,0} - p_{out,0})] \quad (26)$$

### 3.4 Wellstream (not yet implemented)

The wellstream consists of multi-phase flow with characteristics dependent on the This is used for the transport of the (multi-phase) mixed liquid from the well to the separator. The height difference between the well head and a separator placed on a platform contributes to the pressure drop.

*Presently, wellstream flow is modelled using gas or liquied equations with parameters chocen to give as close match as possible in terms of pressure drop.*

### 3.5 Heat network

It is assumed that heat production is close to the heat demand so a simple lossless energy transport model is used for heat transport (energy out equals energy in).

## 4 Devices

In general, devices are modelled with multiple energy carriers in and multiple energy carriers out. A set of constraint equations are linking these together, representing the physical characteristics of different device types. An overview of various device types are shown in Figure 4




Figure 4: Illustration of some device types and their input/output energy streams

#### 4.1 Production well [well\_production]

A production well is a petroleum source, with a natural well head pressure that allows a mixed liquid to flow up at a certain rate. Flow from multiple wells is combined in a manifold and fed into a separator.

- In: –
- Out: wellstream
- Parameters:
  - $p_{natural}$ , wellhead natural pressure [MPa]
  - $Q_{max}$ ,  $Q_{min}$  [optional], wellstream max/min flow rate [Sm<sup>3</sup>/s]
  - profile identifier (string ID) [optional], a time-varying profile that modifies  $Q_{max}$

Output terminal pressure equals natural pressure:

$$p_{out} = p_{natural} \quad (27)$$

Gas lift is not yet considered.

#### 4.2 Separator [separator]

A separator splits the mixed liquid stream from the well into oil, gas and water in a separation process.

- In: wellstream, heat, el
- Out: oil, gas, water
- Parameters:
  - $\eta_{el}$  electric demand as fraction of wellstream inflow [MJ/Sm<sup>3</sup>]
  - $\eta_{heat}$  heat demand as fraction of wellstream inflow [MJ/Sm<sup>3</sup>]
  - output nominal pressure (gas, oil, water)
  - $c$ , wellstream composition factors

Flow out of separator is determined by wellstream flow in in and composition factors:

$$Q_{out}^{gas} = c_{gas} Q_{in}^{wellstream} \quad (28)$$

$$Q_{out}^{oil} = c_{oil} Q_{in}^{wellstream} \quad (29)$$

$$Q_{out}^{water} = c_{water} Q_{in}^{wellstream} \quad (30)$$

Separator heat and power demands are assumed proportional to the well stream flow, with proportionality factors provided as input:

$$P_{in}^{el} = \eta_{el} Q_{in}^{wellstream} \quad (31)$$

$$P_{in}^{heat} = \eta_{heat} Q_{in}^{wellstream} \quad (32)$$

Output pressure is equal to nominal pressure specified for terminals:

$$p_{out}^{gas} = p_{out,0}^{gas} \quad (33)$$

$$p_{out}^{oil} = p_{out,0}^{oil} \quad (34)$$

$$p_{out}^{water} = p_{out,0}^{water} \quad (35)$$

*Presently no dependence on input pressure is considered*

### 4.3 Compressor [compressor\_el]

A compressor is used to increase gas pressure. It may be driven by gas (see below) or electricity.

- In: gas, el
- Out: gas
- Parameters:
  - $\eta_{is}$ , isentropic efficiency (example: 0.7)
  - $T_1$ , inlet temperature [K]
  - $Q_0$ , gas flow operating point used for linearisation

Symbols used in the following description of compressors are defined in Table 3 Compressor power consumption can be computed from the work done compressing the gas, assuming the ideal gas law

$$pV^k = ZmRT, \quad (36)$$

where  $k = \frac{c_p}{c_v}$  is the specific heat ratio,  $Z$  is compressibility factor,  $R$  is the characteristic gas constant  $m$  is the amount of gas (mass),  $V$  is the volume,  $p$  is the pressure and  $T$  is the temperature. This expression together with the expression for work done in an adiabatic process,  $dW = pdV$ , can be used to derive the compressor power consumption as:

$$P_{compr} = \frac{\dot{m}}{\eta_{is}} \frac{1}{k-1} ZRT_1 \left[ \left( \frac{p_2}{p_1} \right)^{\frac{k-1}{k}} - 1 \right] = cQ \left[ \left( \frac{p_2}{p_1} \right)^\alpha - 1 \right], \quad (37)$$

where  $\dot{m}$  is the mass flow rate,  $\eta_{is}$  is the isentropic efficiency, and subscripts 1 and 2 refer to inlet and outlet respectively, and we have defined

$$c = \frac{\rho_s}{\eta_{is}} \frac{1}{k-1} ZRT_1, \quad \alpha = \frac{k-1}{k}. \quad (38)$$

The mass flow is related to standard condition volumetric flow and energy flow via,  $\dot{m} = \rho_s Q = \rho_s \frac{P}{CV}$ , where  $\rho_s$  is the standard condition mass density and  $CV$  is the energy content. For natural gas,  $k = 1.27$  and  $R = 438 \frac{J}{kg \cdot K}$ ,  $\rho_s = 0.84 \frac{kg}{m^3}$ . Assuming values  $\eta_{is} = 0.7$ ,  $T = 300K$ ,  $Z = 1$ , and compression ratio  $\frac{p_2}{p_1} = 5$  we get:

$$P_{compr} = 0.584 \frac{MJ}{Sm^3} \left[ \left( \frac{p_2}{p_1} \right)^{0.21} - 1 \right] Q = 0.23 \frac{MJ}{Sm^3} Q = 0.0059 P. \quad (39)$$

I.e. the compressor power consumption is 0.06% of the power content of the gas being compressed.

The power consumption depends non-linearly on flow rate and pressure (and temperature), so for the linear model, this needs to be simplified. Linearisation around operating points

$$p_1 = p_1^0 + \Delta p_1, \quad p_2 = p_2^0 + \Delta p_2, \quad \dot{m} = \rho_s Q = \rho_s (Q^0 + \Delta Q), \quad (40)$$

Table 3: Symbols used for compressor description

symbol	unit	description	value
$R$	J/kg K	characteristic gas constant	438 (natural gas)
$k = \frac{c_P}{c_V}$	1	specific heat ratio of gas	1.27 (natural gas)
$\eta_{is}$	1	isentropic efficiency	0.7
$Z$	1	compressibility factor (Z=1 for ideal gas)	1
$\rho_s$	kg/Sm <sup>3</sup>	gas density (standard conditions)	0.84 (natural gas)

gives

$$\begin{aligned}
P_{compr} &= cQ \left[ \left( \frac{p_2}{p_1} \right)^\alpha - 1 \right] \\
&= P_{compr}^0 + \frac{\partial P}{\partial Q} \Delta Q + \frac{\partial P}{\partial p_1} \Delta p_1 + \frac{\partial P}{\partial p_2} \Delta p_2 + O(\Delta^2) \\
&= cQ^0 \left[ \left( \frac{p_2^0}{p_1^0} \right)^\alpha - 1 \right] + c \left( \left( \frac{p_2^0}{p_1^0} \right)^\alpha - 1 \right) \Delta Q \\
&\quad + c\alpha Q^0 \left( \frac{p_2^0}{p_1^0} \right)^\alpha \left( -\frac{\Delta p_1}{p_1^0} + \frac{\Delta p_2}{p_2^0} \right) + O(\Delta^2) \\
&= c \left\{ \alpha \left( \frac{p_2^0}{p_1^0} \right)^\alpha Q^0 \left( \frac{p_2}{p_2^0} - \frac{p_1}{p_1^0} \right) + \left( \left( \frac{p_2^0}{p_1^0} \right)^\alpha - 1 \right) Q \right\} + O(\Delta^2).
\end{aligned} \tag{41}$$

If pressure variations can be ignored, the linearised expression is identical to the full one:

$$P_{compr} = c \left( \left( \frac{p_2^0}{p_1^0} \right)^\alpha - 1 \right) Q \tag{42}$$

Compressor power demand is a function of inlet/outlet pressure and flow, as described above:

$$P_{in}^{el} = P_{compr} \tag{43}$$

Gas flow out is equal to gas flow in:

$$Q_{out}^{gas} = Q_{in}^{gas} \tag{44}$$

Outlet pressure is fixed at nominal value:

$$p_2 = p_2^0 \tag{45}$$

#### 4.4 Compressor [compressor\_gas]

A gas-driven compressor is like an electrically driven compressor, but with power demand supplied from the gas flowing through.

- In: gas
- Out: gas
- Parameters:
  - $\eta_{is}$ , efficiency, including efficiency of converting gas energy content to work (so this value is less for gas compressor than for an electric compressor) (example: 0.7)
  - $T_1$ , inlet temperature [K]
  - $Q_0$ , gas flow operating point used for linearisation

Power demand  $P_{compr}$  is computed in the same way as for electric compressor.

The gas output equals the input minus the self-consumption:

$$Q_{out}^{gas} = Q_{in}^{gas} - \frac{P_{compr}}{CV} \quad (46)$$

#### 4.5 Water pump [pump\_water]

A water pump may be used either to pump water up from a water reservoir, or into an injection well. Water injection wells are used to increase/maintain the reservoir pressure, which in turn is needed to extract petroleum.

- In: water, el
- Out: water
- Parameters:
  - $\eta$ , pump efficiency (example: 0.8)

Electric power is needed by a pump to increase water pressure and can be computed considering the work needed to move the liquid up a pressure gradient. The power is work per time, so assuming constant flow-rate (incompressible fluid):

$$\begin{aligned} P &= \frac{d}{dt}W = \frac{d}{dt} \int F ds = \frac{d}{dt} \int p A ds = \frac{d}{dt} \int p dV \\ &= \int \frac{d}{dt} p Q dt = Q \int_{p_1}^{p_2} dp = Q (p_2 - p_1) \end{aligned} \quad (47)$$

Accounting for the efficiency of the pump we therefore have

$$\eta P_{in}^{el} = P = Q (p_2 - p_1) . \quad (48)$$

Expanding around operating points

$$p_1 = p_1^0 + \Delta p_1, \quad p_2 = p_2^0 + \Delta p_2, \quad Q = Q^0 + \Delta Q, \quad (49)$$

this becomes

$$\begin{aligned} P &= Q^0 (p_2^0 - p_1^0) + (Q - Q^0) (p_2^0 - p_1^0) \\ &\quad + Q^0 (p_2 - p_2^0) - Q^0 (p_1 - p_1^0) + O(\Delta^2) \\ &= Q (p_2^0 - p_1^0) + Q^0 (p_2 - p_2^0) - Q^0 (p_1 - p_1^0) + O(\Delta^2) \end{aligned} \quad (50)$$

Considering that the outlet pressure is determined by the reservoir pressure and fixed ( $p_2 = p_2^0$ ), we get the linear relationship,

$$\eta P_{in}^{el} = P = [Q (p_2^0 - p_1^0) + Q^0 (p_1^0 - p_1)] . \quad (51)$$

Assuming that the pressure deviations are small, we can ignore the second term. Therefore, the electric power demand is proportional to water flow:

$$\eta P_{in}^{el} = Q_{in}^{water} (p_2^0 - p_1^0) \quad (52)$$

## 4.6 Oil pump [pump\_oil]

An oil pump is as pump that increases oil pressure for transport through pipelines.

- In: oil, el
- Out: oil
- Parameters:
  - $\eta$ , efficiency

*As for water pumps, we pressure ignore inlet and outlet pressure variations (deviations from nominal values)*

Flow out equals flow in

$$Q_{out}^{oil} = Q_{in}^{oil} \quad (53)$$

Pump power demand is proportional to energy flow and (nominal) pressure difference

$$\eta P_{in}^{el} = \eta Q_{in}^{oil} (p_2^0 - p_1^0), \quad (54)$$

where  $p_1^0$  and  $p_2^0$  are nominal pressure levels at inlet and outlet respectively.



## 4.7 Gas heater [gasheater]

A gas heater produces heat from burning gas.

- In: gas
- Out: heat
- Parameters:
  - $\eta_{heat}$ , efficiency

Heat output equals heating efficiency times gas consumption:

$$P_{out}^{heat} = \eta_{heat} P_{in}^{gas} \quad (55)$$

## 4.8 Heat pump and electric boiler [heatpump]

A heat pump or boiler converts electrical energy to heat using an external heat source. The electric heating efficiency for air-to-air heat pumps is typically around  $\eta_{heat} = 3$ . The temperature dependence is not modelled.

- In: el
- Out: heat
- Parameters:
  - $\eta_{heat}$ , efficiency

Heat output equals electric power times efficiency:

$$P_{out}^{heat} = \eta_{heat} P_{in}^{el} \quad (56)$$

## 4.9 Gas turbine [gasturbine]

A gas turbine generator converts natural gas to electric power and heat.

- In: gas
- Out: el
- Parameters:
  - $\eta_{heat}$ , output heat as fraction of power output
  - $A$ ,  $B$ , fuel consumption parameters

Fuel consumption  $Q_{in}^{gas}$  is assumed to be a linear function of the electrical power output  $P_{out}^{el}$ :

$$\frac{Q_{in}^{gas} CV}{P_{max}} = A \frac{P_{out}^{el}}{P_{max}} + B \quad (57)$$

To determine typical  $A$  and  $B$  parameter values, we use emission factors found in the literature.<sup>6</sup> At maximum power ( $P_{out}^{el} = P_{max}$ ), the fuel consumption should be about  $A + B = 1/0.347$  (efficiency about 34.7%). At minimum load (ca 20% loading), the efficiency should be about 20%, i.e.  $\frac{0.2A+B}{0.2} = 0.2$ . Together these two conditions give  $A=2.35$ ,  $B=0.53$ . Schematics of fuel characteristics of gas turbines are shown in Figure 5.

The specific fuel efficiency is the gas fuel usage (in MW) times the CO<sub>2</sub> content (kg/MWh) divided by the electric output (in MW). The CO<sub>2</sub> content of natural gas combusted on the Norwegian continental shelf is<sup>7</sup> 2.34 kgCO<sub>2</sub>/Sm<sup>3</sup> (using density and energy content factors, this equals 2.03 kgCO<sub>2</sub>/kg<sub>gas</sub> or 211 kgCO<sub>2</sub>/MWh<sub>gas</sub>).

Power output is non-zero only if gas turbine is running:

$$P_{out}^{el} \leq y P_{max}, \quad (58)$$

where  $y$  is a binary variable that is 0 if turbine is not running and 1 if the turbine is running.

Heat output is given as gas fuel consumption (energy content) times a heat fraction parameter:

$$P_{out}^{heat} = \eta_{heat} Q_{in}^{gas} CV \quad (59)$$

#### 4.10 Source water [source\_water]

Water source. This external source may be associated with a time-series that specifies available power and determines the maximum output value.

- In: –
- Out: water
- Parameters:
  - $p_{natural}$ , natural pressure (MPa)

The output pressure equals the natural pressure,

$$p_{out}^{water} = p_{natural} \quad (60)$$

<sup>6</sup> MA Gonzalez-Salazara, T Kirstena, L Prchlik, Review of the operational flexibility and emissions of gas- and coal-fired power plants in a future with growing renewables Ren Sust Energy Rev. (2018), <https://doi.org/10.1016/j.rser.2017.05.278>

<sup>7</sup>T Sandmo, SSB Documents 2016/22, <https://www.ssb.no/natur-og-miljo/artikler-og-publikasjoner/the-norwegian-emission-inventory-2016> (Table B1)




Figure 5: Gas turbine fuel characteristics (schematic, for A=2.35, B=0.53)

#### 4.11 Source el [source\_el]

Electric power source. This may be a wind turbine, diesel generator, solar power generator or similar – something that generates electricity from an external source. This external source may be associated with a time-series that specifies available power and determines the maximum output value.

- In: –
- Out: el
- Parameters: –

#### 4.12 Electrical battery [storage\_el]

Electrical storage can absorb electrical power (charging) or supply electrical power (discharging), with some losses indicated by the cycle efficiency parameter.

- In: el
- Out: el
- Parameters:
  - $2\eta$ , cycle efficiency
  - $E_{max}$ , energy storage capacity

Energy balance of the storage:

$$\left[ \eta P_{in}^{el} - \frac{1}{\eta} P_{out}^{el} \right] \Delta t = E_t - E_{t-1}, \quad (61)$$

where  $\Delta t$  is the time-step length.

Energy storage is limited by lower and upper bounds:

$$0 \leq E_t \leq E_{\max} \quad (62)$$

Charging and discharging limits:

$$P_{in}^{el} \leq P_{\max}, \quad P_{out}^{el} \leq P_{\max}. \quad (63)$$

### 4.13 Water sink [sink\_water]

A water sink, either for water disposal or water injection. The pressure is specified by the parameters of the water pipe (edge) connecting to the water sink.

- In: water
- Out: –
- Parameters:
  - $Q_{avg}$  (optional), water flow required average (Sm<sup>3</sup>/s)
  - $V_{\max}$  (optional), water flow buffer size (allowing flexibility) (Sm<sup>3</sup>/s h)

*Flexible* water injection is modelled by introducing a buffer of limited size  $V_{\max}$  that decouples the long-term required average water flow  $Q_{avg}$  from the actual water flow at a given time. Change in volume buffer level  $V_t$  equals water in minus required average flow  $Q_{avg}$

$$[Q_{in}^{water} - Q_{avg}] \Delta t = V_t - V_{t-1}, \quad (64)$$

where  $\Delta t$  is the time-step length. The buffer level is limited by lower and upper bounds

$$-\frac{V_{\max}}{2} \leq V_t \leq \frac{V_{\max}}{2} \quad (65)$$

### 4.14 Gas sink [sink\_gas]

Generic gas load (or export point)

- In: gas
- Out: –
- Parameters: –

#### 4.15 Oil sink [sink\_oil]

Generic oil load (or export point)

- In:oil
- Out: –
- Parameters: –

**Constraint:** Device power equals oil in

$$P_{device} = P_{oil}^{gas}$$

#### 4.16 Electrical load [sink\_el]

Generic electrical load.

- In:el
- Out: –
- Parameters: –

#### 4.17 Heat sink [sink\_heat]

Generic heat load.

- In:heat
- Out: el
- Parameters: –

#### 4.18 Device types not yet implemented

Device types that may be implemented later:

- Heat storage
- Electrolysis (el to H2)
- fuel cell (H2 to el)
- H2 turbine (H2 to el/heat)
- H2 storage
- gas-to-fuel (H2+CO2)
- heat demand determined by thermodynamic equations (heat storage, heat loss function of temperature difference, max/min temperature)

## 5 Input data

Input data is provided as an XLSX file with multiple worksheets:

- node** list of nodes with their properties
- edge** list of edges (connections between nodes) with their properties
- device** list of devices with their properties
- carriers** list of energy carriers with properties
- parameters** list of global parameter values
- profiles** time-varying profiles (actual values)
- profiles\_forecast** time-varying profiles (forecasts)

The worksheets have column headers which specifies what type of information is provided in each column. The columns with headers `param_id` and `param_value` are special. In these two columns, multiple parameter key-value pairs may be provided. Which parameters are relevant differs for each case.

Table 4: Node input data

header	type	description
id	string	Unique identifier
name	string	Name of node
param_id	string	parameter identifier
param_value		parameter value

Table 5: Edge input data

header	type	description
id	string	Unique identifier
type	string	Energy carrier
node_from	string	id of edge starting node
node_to	string	id of edge end node
include	bool	ignore (0) or include (1) this edge
length_km	float	edge length in km
param_id	string	parameter identifier
param_value		parameter value

Table 6: Device input data

header	type	description
id	string	Unique identifier
name	string	Name of device
node	string	id of node where connected
include	bool	ignore (0) or include (1) this device
model	string	device model identifier
param_id	string	parameter identifier
param_value		parameter value

Table 7: Carriers input data

header	type	description
id	string	Unique identifier
param_id	string	parameter identifier
param_value		parameter value

Table 8: Parameters input data

header	type	description
param_id	string	parameter identifier
param_value		parameter value

Table 9: Profiles input data

header	type	description
profiles	float	one column per profile (header is profile identifier)

## 6 Examples

Examples showing how to use the simulation tool are provided together with the program code at [https://bitbucket.org/harald\\_g\\_svensen/ooges0](https://bitbucket.org/harald_g_svensen/ooges0).