

# Getting Started with the Low-Cost Cyclone IV EP4CE6E22C8N FPGA Board

**Keywords:** Altera Cyclone IV FPGA, Quartus Prime Lite, EP4CE6E22C8N, VHDL Example

## ► Cyclone IV FPGA

In March 2024, Intel (formerly Altera) announced the extension of the lifecycle for its legacy FPGA product lines, including the **Cyclone IV series**, through the year **2040**. This extended support ensures continued availability of Cyclone IV FPGA devices, making them a practical and cost-effective choice for educational purposes and FPGA design learning. In addition, a variety of low-cost [Cyclone IV FPGA](#) boards manufactured in China are readily available on the market.



**Figure:** Intel/Altera FPGA Longevity Extended to 2040 (Source: Intel)

This blog provides a short tutorial on experimenting with a low-cost **Cyclone IV (E-Series) FPGA board**. VHDL source code is provided and intended for use with Intel/Altera Quartus Prime Lite (v24.x).




Figure: Intel/Altera Cyclone IV EP4CE6E22C8N FPGA Board

New Project Wizard

### Family, Device & Board Settings

Device Board

Select the family and device you want to target for compilation.  
You can install additional device support with the Install Devices command on the Tools menu.

To determine the version of the Quartus Prime software in which your target device is supported, refer to the [Device Support List](#) webpage.

Device family

Family: Cyclone IV E

Device: All

Target device

☐ Auto device selected by the Fitter

☒ Specific device selected in 'Available devices' list

☐ Other: n/a

Show in 'Available devices' list

Package: Any

Pin count: Any

Core speed grade: Any

Name filter:

☒ Show advanced devices

Available devices:

Name	Core Voltage	LEs	Total I/Os	GPIOs	Memory Bits	Embedded multiplier 9-bit
EP4CE6E22A7	1.2V	6272	92	92	276480	30
EP4CE6E22C6	1.2V	6272	92	92	276480	30
EP4CE6E22C7	1.2V	6272	92	92	276480	30
EP4CE6E22C8	1.2V	6272	92	92	276480	30
EP4CE6E22C8L	1.0V	6272	92	92	276480	30


Help < Back Next > Finish Cancel

Figure: Device Selection in Quartus Prime Lite

## ► FPGA Board Information

The FPGA development board used in this project integrates a mid-range Altera Cyclone IV device, basic peripheral interfaces, on-board storage, and power regulation circuits. The following list summarizes the key hardware specifications and pin assignments.

- **FPGA:** EP4CE6E22C8N
  - Logic Elements (LEs): 6,272
  - PLLs: 2
  - Embedded Memory: 276,480 bits
  - I/Os: 91
  - Package: 144-LQFP
- **USB-to-Serial Interface:** CH340
  - FPGA TX pin: PIN\_10
  - FPGA RX pin: PIN\_23
- **Clock Sources**
  - 50 MHz: PIN\_24, PIN\_25
  - 27 MHz: PIN\_90, PIN\_91
- **Push Buttons** (Active-Low with Pull-Ups)
  - FPGA Reset: PIN\_88
  - 4x User Buttons [3:0]: PIN\_73, PIN\_80, PIN\_89, PIN\_114
- **LEDs (Active-Low)**
  - 5x LEDs [4:0]: PIN\_1, PIN\_2, PIN\_3, PIN\_7, PIN\_11
- **On-Board Storage**
  - Altera EPCS4N (Serial Configuration Device)
  - Winbond 25Q64JVS1Q (64 Mbit / 8 MB Serial NOR Flash)
- **Power Supply**
  - +5V via USB Type-C connector
  - 4x AMS1117 LDO voltage regulators: +3.3 V, +2.5 V, +1.8 V, and +1.2 V outputs
- **Bitstream Programming**
  - via a JTAG socket for USB Blaster



## ► FPGA Demo Code

11/16/2025, 12:04 AM



```

-----
LIBRARY ieee;
USE ieee.std_logic_1164.ALL;
USE ieee.numeric_std.ALL;
-----

ENTITY top IS
    PORT (
        CLK      : IN  STD_LOGIC; -- 50MHz clock
        nRST     : IN  STD_LOGIC; -- active-low, asynchronous reset
        LEDS     : OUT STD_LOGIC_VECTOR(4 DOWNTO 0); -- active-low
        BUTTONS  : IN  STD_LOGIC_VECTOR(3 DOWNTO 0); -- active-low
        SERIAL_TX : OUT STD_LOGIC;
        SERIAL_RX : IN  STD_LOGIC
    );
END top;

ARCHITECTURE SYNTH OF top IS
    CONSTANT BIT_WIDTH      : INTEGER := 5;
    CONSTANT ALL_ONES      : UNSIGNED := TO_UNSIGNED(2**BIT_WIDTH-1,BIT_WIDTH);
    CONSTANT COUNT_PERIOD  : INTEGER := 10_000_000;
    SUBTYPE count_t IS INTEGER RANGE 0 TO (COUNT_PERIOD - 1);
    SIGNAL count      : count_t := 0;
    SIGNAL reg        : STD_LOGIC_VECTOR(BIT_WIDTH-1 DOWNTO 0);
    SIGNAL shift_en   : STD_LOGIC;

    -- Define constants
    CONSTANT CLK_FREQ      : INTEGER := 50e6; -- 50 MHz clock
    CONSTANT BAUD_RATE     : INTEGER := 115200; -- 115200 baud rate
    CONSTANT BAUD_PERIOD   : INTEGER := CLK_FREQ / BAUD_RATE - 1;

    -- ASCII message to be transmitted
    TYPE ascii_array_t IS ARRAY (0 TO 13) OF STD_LOGIC_VECTOR(7 DOWNTO 0);
    CONSTANT MESSAGE : ascii_array_t := (
        x"48", -- H
        x"65", -- e
        x"6C", -- l
        x"6C", -- l
        x"6F", -- o
        x"20", -- (space)
        x"57", -- W
        x"6F", -- o
        x"72", -- r
        x"6C", -- l
        x"64", -- d
        x"21", -- !
        x"0D", -- \r
        x"0A" -- \n
    );

    -- FSM states
    TYPE state_t IS (ST_IDLE, ST_LOAD_DATA, ST_SEND_DATA, ST_STOP, ST_WAIT);
    SIGNAL state : state_t := ST_IDLE;
    SIGNAL next_state : state_t := ST_IDLE;
    SIGNAL wait_counter : INTEGER := 0;
    SIGNAL bit_counter : INTEGER RANGE 0 TO 9 := 0;
    SIGNAL char_counter : INTEGER RANGE 0 TO MESSAGE'length := 0;
    SIGNAL shift_reg : STD_LOGIC_VECTOR(9 DOWNTO 0) := (OTHERS => '1');
    SIGNAL btn_capture : STD_LOGIC_VECTOR(1 DOWNTO 0) := (OTHERS => '1');
    SIGNAL txd : STD_LOGIC := '1';

BEGIN

    SERIAL_TX <= txd;

    LEDS <= NOT reg WHEN BUTTONS = "1111" ELSE "10101";

```

```

PROCESS (nRST, CLK) BEGIN
    IF nRST = '0' THEN
        count <= 0;
        shift_en <= '0';
    ELSIF rising_edge(CLK) THEN
        -- check whether the counter reaches the max. value.
        IF count = (COUNT_PERIOD - 1) THEN
            count <= 0; -- reset the counter.
            shift_en <= '1'; -- enable register shift.
        ELSE
            count <= count + 1; -- increment counter by 1.
            shift_en <= '0'; -- disable register shift.
        END IF;
    END IF;
END PROCESS;

PROCESS (nRST, CLK) BEGIN
    IF nRST = '0' THEN
        reg <= (OTHERS => '0'); -- clear the shift register.
    ELSIF rising_edge(CLK) THEN
        IF shift_en = '1' THEN -- register shifting is enabled.
            IF reg = STD_LOGIC_VECTOR(ALL_ONES) THEN
                -- clear the shift register.
                reg <= (OTHERS => '0');
            ELSE
                -- shift left, insert '1' as LSB.
                reg <= reg(reg'left - 1 DOWNT0 0) & '1';
            END IF;
        END IF;
    END IF;
END PROCESS;

PROCESS (CLK, nRST)
BEGIN
    IF nRST = '0' THEN
        state <= ST_IDLE;
        bit_counter <= 0;
        wait_counter <= 0;
        char_counter <= 0;
        btn_capture <= "11";
        shift_reg <= (OTHERS => '1');
        txd <= '1'; -- TXD idle (high)

    ELSIF rising_edge(CLK) THEN

        btn_capture <= btn_capture(0) & BUTTONS(0);

        CASE state IS
            WHEN ST_IDLE =>
                TXD <= '1';
                IF btn_capture = "01" THEN -- button click
                    state <= ST_LOAD_DATA;
                    char_counter <= 0;
                END IF;

            WHEN ST_LOAD_DATA =>
                shift_reg <= '1' & MESSAGE(char_counter) & '0';
                state <= ST_SEND_DATA;
                bit_counter <= 0;

            WHEN ST_SEND_DATA =>
                txd <= shift_reg(0); -- LSB bit
                shift_reg <= '1' & shift_reg(9 DOWNT0 1); -- Shift data
                state <= ST_WAIT;
                wait_counter <= BAUD_PERIOD;
        END CASE;
    END IF;
END PROCESS;

```

```
        IF bit_counter = 9 THEN
            next_state <= ST_STOP;
            bit_counter <= 0;
        ELSE
            next_state <= ST_SEND_DATA;
            bit_counter <= bit_counter + 1;
        END IF;

    WHEN ST_STOP =>
        txd <= '1';
        IF char_counter = MESSAGE'length - 1 THEN
            state <= ST_IDLE;
        ELSE
            char_counter <= char_counter + 1;
            state <= ST_LOAD_DATA;
        END IF;

    WHEN ST_WAIT =>
        IF wait_counter = 0 THEN
            state <= next_state;
        ELSE
            wait_counter <= wait_counter - 1;
        END IF;

    WHEN OTHERS =>
        state <= ST_IDLE;
    END CASE;
END IF;
END PROCESS;

END SYNTH;
```

A Tcl script file is also provided to set up the FPGA pin assignments automatically.

```
#set_global_assignment -name FAMILY "Cyclone IV E"
#set_global_assignment -name DEVICE EP4CE6E22C8
#set_global_assignment -name TOP_LEVEL_ENTITY top

set_location_assignment PIN_24 -to CLK
set_location_assignment PIN_88 -to nRST

set_location_assignment PIN_1 -to Leds[0]
set_location_assignment PIN_2 -to Leds[1]
set_location_assignment PIN_3 -to Leds[2]
set_location_assignment PIN_7 -to Leds[3]
set_location_assignment PIN_11 -to Leds[4]

set_location_assignment PIN_73 -to BUTTONS[3]
set_location_assignment PIN_80 -to BUTTONS[2]
set_location_assignment PIN_89 -to BUTTONS[1]
set_location_assignment PIN_114 -to BUTTONS[0]


set_location_assignment PIN_10 -to SERIAL_TX
set_location_assignment PIN_23 -to SERIAL_RX

set_instance_assignment -name IO_STANDARD "3.3-V LVCMOS" -to Leds[4]
set_instance_assignment -name IO_STANDARD "3.3-V LVCMOS" -to Leds[3]
set_instance_assignment -name IO_STANDARD "3.3-V LVCMOS" -to Leds[2]
set_instance_assignment -name IO_STANDARD "3.3-V LVCMOS" -to Leds[1]
set_instance_assignment -name IO_STANDARD "3.3-V LVCMOS" -to Leds[0]


set_instance_assignment -name IO_STANDARD "3.3-V LVCMOS" -to BUTTONS[3]
set_instance_assignment -name IO_STANDARD "3.3-V LVCMOS" -to BUTTONS[2]
set_instance_assignment -name IO_STANDARD "3.3-V LVCMOS" -to BUTTONS[1]
set_instance_assignment -name IO_STANDARD "3.3-V LVCMOS" -to BUTTONS[0]

set_instance_assignment -name IO_STANDARD "3.3-V LVCMOS" -to nRST
set_instance_assignment -name IO_STANDARD "3.3-V LVCMOS" -to CLK
set_instance_assignment -name IO_STANDARD "3.3-V LVCMOS" -to SERIAL_TX
set_instance_assignment -name IO_STANDARD "3.3-V LVCMOS" -to SERIAL_RX
```

To upload the bitstream file (.sof) to the FPGA board, you'll need a USB Blaster (or a compatible clone). Make sure the USB Blaster driver is properly installed on your Windows 10 or 11 system. The USB driver is included with the Quartus Prime software package.







**Figure:** Device Programming using USB Blaster

---

## ► Conclusion

Low-cost FPGA boards, such as the one based on the **EP4CE6E22C8N**, offer a practical entry point into the world of digital design. They provide just enough logic resources and peripherals to let beginners explore essential concepts – from basic combinational circuits to complete embedded systems.

However, it's important to understand the trade-offs. Entry-level FPGA boards may have limited memory, fewer I/O pins, or reduced clock speeds compared to their higher-end counterparts. Beginners should also consider factors such as toolchain compatibility, availability of learning resources, and community support when selecting a board. Choosing a platform with good documentation and an active user base often makes the learning process much smoother.

As skills develop, moving to higher-capacity or more advanced FPGA devices opens the door to a wider range of projects – including high-speed signal processing, or custom system-on-chip designs. The foundations built on low-cost boards translate naturally to these larger systems, helping learners grow into confident and capable FPGA developers.

---

*This work is licensed under a **Creative Commons Attribution-ShareAlike 4.0 International License**.*

Created: 2025-10-26 | Last Updated: 2025-10-26

---

Copyright © 2021-2025 IoT Engineering Education, Bangkok/Thailand

Documentation built with [MkDocs](#).