

Presonus Atom SQ Bitwig Extension Manual

Requirements

- This extension is based on the API version 17, available in Bitwig 4.4
- It has only been tested on a Windows 11 sytem. Feedback from anyone using it on a Mac or Linux would be most welcome.

Installation (Windows)

- Add the AtomSQ.bwextension file into the Extensions folder under My Documents:
- C:\Users\USER\Documents\Bitwig Studio\Extensions
- In Bitwig, under the Settings/Controllers, add a new controller, and select the Atom SQ (by James) controller under the PreSonus folder.
- Assign the **ATM SQ** and **MID IN/OUT 2 (ATM SQ)** inputs and outputs to controller.
- Thats it. The **Inst** button on the controller should now be lit, and if you have a project already loaded, the Track and Device names should appear on the controller display.

Quick Start

- The B-H buttons, pitch bend, mod, and notes work as expected.
- There are two "modes" currently configured. These are triggered by the **Song** (for Tracks) and **Inst** (for Devices) buttons.
- The **User button** accesses the controller-native keyboard controls.
- Extra "pages" of menu are indicated by the Fwd/Bck buttons under the encoder on the right of the screen being lit.
- Undo/Redo are bound to Shift-Back and Shift-Forward.
- Based on the mode (including in the preset/device pop-up browser) the encoders do different things. Not always all 8.

The Slow start, I guess?

The Keys

As stated above: the The B-H buttons, pitch bend, mod, and notes work as expected. Octaves can be changed by the B-H buttons, the keyboard scale, root note et al can be manipulated in the Keyboard menu as in Midi Mode.

Currently, the A button does nothing. Working on it.

Transport

The usual stuff, but with some shift functions too:

Key	Function	Shift
Stop	Stops playback, sets play to beginning	-

Key	Function	Shift
Play	Starts/pauses playback	Enables loop mode
Record	Starts recording	Saves project
Metronome	Toggles metronome	-

Navigation

The main click encoder (#9) and arrow buttons (Back/Fwd) to the right of the display, as well as the 4 direction buttons below it (Left/Right/Up/Down).

Control	Function	Shift
Encoder 9	Moves Playhead in Arranger. Not the smoothest, working on it	-
Back	Page back in a mode. lights up if this is possible.	Undo
Forward	Page forward in a mode. lights up if this is possible.	Redo
Up /Down	Moves between tracks. lights up if this is possible.	-
Left/Right	Moves between devices. lights up if this is possible.	-

Modes

The concept here was to leverage the four buttons on the left of the display to make 4 Modes for use. I went back and forth a good while trying different things and settled on the following Modes:

Button	Mode	Description
Song	Tracks	Controls related to the Tracks, like Mute, Solo, creating new tracks etc
Inst	Devices	Controls related to Devices, like Enable, Move, view Remote Controls, select Prefix etc.
Editor	-	Nothing to see here. Yet. I had to stop somewhere, or this would never have come out.
User	Keyboard	Native Keyboard controls from the Atom SQ itself.
-	*Browser	Selecting presets or new devices. Opens either by a button in another mode, or when the browser is opened in the app

Each Mode, or more specifically each page of each mode, controls the display, the buttons around it, and the encoders (1-8). The keyboard mode is really self explanatory, and the editor mode is TBD, so we will only look at the other two, Tracks and Devices, in detail.

for all modes, the encoders are as numbered, top left to bottom right, on the controller. The buttons are also top left to bottom right, thusly:

1 2 3 [display] 4 5 6

Tracks Mode

When the Song button is lit, this mode is active. It provides access to controls for the Tracks. There are two pages of controls, indicated by the Fwd/Back buttons being lit. I know, this is not how it was done in f.e. Studio One, but I could not yet be bothered to find the right code for the little "pagination" icons. Working on it.

In this mode, the center of the display shows the Track: in yellow and the Device: in white. The button text is also in yellow.

Page 1

Control	Function	Shift
Encoders 1-6	Controls the send amount for sends 1-6, if present	-
Encoder 7	Controls track panning	-
Encoder 8	Controls track volume	-
Button 1	Toggles track mute	-
Button 2	Toggles track solo	-
Button 3	Toggles track being armed	-
Button 4	-	-
Button 5	Moves track up	-
Button 6	Moves track down	-

Page 2

Control	Function	Shift
Encoders 1-6	Controls the send amount for sends 1-6, if present	-
Encoder 7	Controls track panning	-
Encoder 8	Controls track volume	-
Button 1	Toggles track being active	-
Button 2	Copies track (below)	-
Button 3	Deletes track	-
Button 4	Creates new Audio Track (below)	-
Button 5	Creates new Inst Track (below)	-
Button 6	Creates new FX Track (below existing)	-

Devices Mode

When the Inst button is lit, this mode is active. It provides access to controls for the Devices. There are two pages of controls, indicated by the Fwd/Back buttons being lit.

In this mode, the center of the display shows the Track: in yellow and the Device: in white. The button text is also in white.

Page 1

Control	Function	Shift
Encoders 1-8	Device remote controls 1-8	-
Button 1	Toggles device enabled	-
Button 2	Toggles display of device window	-
Button 3	Toggles display of expanded/collapsed device	-
Button 4	Toggles display of remote controls	-
Button 5	Moves the device to the left	-
Button 6	Moves the device to the right	-

Page 2

Control	Function	Shift
Encoders 1-8	Device remote controls 1-8	-
Button 1	-	-
Button 2	Copies device (to the right)	-
Button 3	Deletes device	-
Button 4	Opens the browser to insert a new device to the left	-
Button 5	Opens the preset browser	-
Button 6	Opens the browser to insert a new device to the right	-

Browser

Browser mode is activated either by the new device or preset buttons in page 2 of the device mode, or when the browser is activated in Bitwig itself.

In this mode, the center of the display shows the Device: in white and the Preset/New Device in magenta. The button text is also in magenta.

Page 1

Control	Function	Shift
---------	----------	-------

Control	Function	Shift
Encoders 1-4	-	-
Encoder 5	Navigates the category column, if present	-
Encoder 6	Navigates the tag column, if present	-
Encoder 7	Navigates the creator column, if present	-
Encoder 8	Navigates the preset/device column	-
Buttons 1-3	-	-
Button 4	Toggles preset preview	-
Button 5	Cancels selection and closes the browser	-
Button 6	OKs the selection and closes the browser	-

Technical Info

This extension is written in Java to leverage the Hardware abstraction in the API, which I will not describe here because Moss does an excellent job in his Youtube channel, and you should check that out if you want to know more: https://www.youtube.com/watch?v=kTf_SSlyBEg

Additionally, I have imported the Framework folder from the Bitwig repository (<https://github.com/bitwig/bitwig-extensions/tree/api-17/src/main/java/com/bitwig/extensions/framework>) because, while learning to git gud at both Java and controller scripting, I discovered the Layers defined here and used in a ton of the officially provided scripts. The framework stuff is not at all documented (that I could find, at least) so the TL:DR is that Layers allow multiple layers of control bindings that can be combined, or used to replace, bindings from other layers. This makes what I refer to as "Modes" much easier to conceptualize and program. Example: the Inst (Devices) layer binds the 8 main encoders to the remote control settings for a device in Bitwig, as well as binding the display buttons. Inst 2 (Devices 2nd page) leaves the encoders alone, and only re-binds the display buttons to the new functions displayed for that page. Go back to the first page, and these are deactivated again. Noice.

Not Included

The stuff I am aware of that I could, and probably will, improve or add

1. Automatic recognition of the controller
2. Track Color on the device, esp for the keys
3. Arranger/Clip focus switching. I would like to get the clip stuff on the Editor menu, but tbh I have a Launchpad, which I think is much better for this. Considering a companion controller setup with a super simple Launchpad script as an alternative.
4. Preset save
5. Grouping for Tracks
6. Device Type selection in the browser (bottom left) and smart folders . Should be easy though.

Stuff that, to me, seems unnecessary to add, but if you see a good argument for it, let me know. 😊

1. anything to control complicated devices like layers, multi-fx etc. will evaluate the usefulness/complexity of managing these things via controller.
2. Device modulators. No idea how to toggle the viewing at the moment. Selection should then be easy with the browser. the connections for modulators to the synth is a whole other ballgame though, probably not something one would want to do with a controller.

These are not exhaustive lists. I have a ton of functions listed out that could theoretically be bound to a controller. If you dig my extension, but feel it really needs X or Y function added, just let me know and I can take a look for a future version.