

delta_dfu_lib

This is a user guider to tell you how to test the delta dfu , it is really ease for you to merge it to your SDK.

A delta firmware upgrade consists of the following steps:

- install essential tools
- pull the new boot code to replace your old code
- prepare test application
- generate patch file and transfer it to the secondary slot
- Restart MCU to perform the update
- Checking the result of the delta update

(1). install essential tools

you should install detools on your PC: enter **"pip install detools"** command in the python environment.

you should install cryptography,intelhex,click,cbor: enter **"pip install -r requirements.txt"** command in the python environment.

(2). pull the new boot code to replace your old code

you should pull the new boot code from below url and replace the boot folder in your SDK directory (v2.x.x/bootloader/ mcubboot/boot),
remember to change the folder name to boot or copy the folder contents to boot folder.

https://github.com/Noy0908/delta_dfu_lib.git

delta_dfu_lib_9160 branch is the library for nRF9160;

delta_dfu_lib_52840 branch is the library for nRF52840

(3). prepare test application

- you can test it on our demos. We provide two demoed, one is for nRF9169, the other is for nRF52840, below is the url and branches.

https://github.com/Noy0908/delta_dfu.git

9160-delta-ota is the demo for nRF9160

52840-delta-ota is the demo for nRF52840

remember thatwhen you test different demos, you must switch the delta_dfu_lib to the corresponding branch. For example, 9160-delta-ota corresponds to delta_dfu_lib_9160.

- Of course you can test it on any application samples, but need to create two folders in your project root directory to save images and patch file.
one is "binaries/signed_images" which used to save source image and target image; the other is "binaries/patches" which used to save patch image.

it > asset_tracker_new > binaries					Search binaries	
<input type="checkbox"/>	Name	Date modified	Type	Size		
	patches	12/8/2022 3:41 PM	File folder			
	signed_images	12/8/2022 3:21 PM	File folder			

- copy the scripts folder("boot/zephyr/scripts") from delta_mcuboot folder to the root directory of your application ,
and double-click the "scripts/patch.exe" file when generating the patch image.
- allocate your flash partition. you can create a "pm_static.yml" file in your project root directory to redefine the flash partition.

remember that you must define the primary slot and secondary slot, and these two slots support differnet size.

- enable delta dfu. you can create a "child_image/mcuboot.conf" file to set these macros:

```
CONFIG_BOOT_MAX_IMG_SECTORS=160
CONFIG_BOOT_UPGRADE_APP_DELTA=y
```

- enable mcuboot in your project config files(prj.conf).

```
CONFIG_BOOTLOADER_MCUBOOT=y
CONFIG_IMG_MANAGER=y
CONFIG_MCUBOOT_IMG_MANAGER=y
```

(4). generate patch file and transfer it to the secondary slot

- Edit "scripts/signature.py" file. replace the imgtool.py path and root-ec-p256.pem path in the file with your own path, and modify the primary slot size to your own define.

```
1 python C:/NCS_50K/v2.1.0/bootloader/mcuboot/scripts/imgtool.py sign --key C:/NCS_50K/v2.1.0/bootloader/mcuboot/root-ec-p256.pem --header-size 0x200 --align 4 --version 0.0.0+ --pad-header --slot-size 0x60000
2
3
```

- Generate the patch file. The patch file is generated by comparing the difference between the source image and the target image. The source image is a binary file which converted from the "app_signed.hex" file that compiled from the source project, we can directly use the J-Flash tool to convert "app_signed.hex" to a binary file by saving it to a binary file named "source_xxx.bin"; or convert it with command line : **arm-none-eabi-objcopy --input-target=ihex --output-target=binary --gap-fill=0xff app_signed.hex source_xxx.bin**. Modify the source project and compile again, then get the target file: app_update.bin, rename it to target_xxx.bin, such as target_2.0.0.bin. Copy the source_ xxx.bin and target_xxx. bin to binaries/signed_images folder, then execute scripts/patch.exe, and the differential file will be automatically generated in the directory binaries/patches. Please use the differential file signed_patch.bin as patch file.
- Transmit the patch image to secondary slot. Now we supports multiple OTA methods, such as **4G/WiFi/Bluetooth/NFC**, etc. It can also be delivered through wired methods, such as **UART, USB or SPI bus**.

(5). Restart MCU to perform the update

After the patch image is saved to flash, you should call the function `(boot_request_upgrade(BOOT_UPGRADE_PERMANENT))` and then restart MCU. After the MCU restarts, it will check whether the differential image in the flash area is valid, verify the signature and hash data. Differential upgrading will only be performed when all these information are matched. While applying patch.bin, the old image (source. bin) and patch image combines to generate a new image and save it in the flash primary slot area, then MCU jump to the application entry, the whole process supports power down protection.

```
I: Swap type: perm
slot=1
swap_type = 3
```

```
I: Starting swap using move algorithm.
source hash is matched, now start delta upgrade!!!
```

```
##patch_size = 105638      opFlag = 10
```

```
Init: from_current=0x29000 to_current=0x28000 patch_current=0x90228
STATUS_ADDRESS=0xf6000 BACKUP_STATUS_ADDRESS=0xf3000 backup_addr=0x0
write_size=0
```

-----patch_offset=512	patch_size=105638	progress = 0%
-----patch_offset=1024	patch_size=105638	progress = 0%
-----patch_offset=1536	patch_size=105638	progress = 1%
-----patch_offset=2048	patch_size=105638	progress = 1%
-----patch_offset=2560	patch_size=105638	progress = 2%
-----patch_offset=3072	patch_size=105638	progress = 2%
-----patch_offset=3584	patch_size=105638	progress = 3%
-----patch_offset=4096	patch_size=105638	progress = 3%
-----patch_offset=4608	patch_size=105638	progress = 4%

(6). Checking the result of the update

you can check the output log to see if the upgrade is successful and the MCU run the target image.

```
-----patch_offset=102912      patch_size=105638      progress = 97%
-----patch_offset=103424      patch_size=105638      progress = 97%
-----patch_offset=103936      patch_size=105638      progress = 98%
-----patch_offset=104448      patch_size=105638      progress = 98%
-----patch_offset=104960      patch_size=105638      progress = 99%
-----patch_offset=105472      patch_size=105638      progress = 99%
-----patch_offset=105638      patch_size=105638      progress = 100%
==== Apply last Flash buffer
Apply patch file reslt = 295038
Before : bs->idx=1      bs->op=3      bs->state=1      bs->swap_type=3

I: Primary image: magic=unset, swap_type=0x1, copy_done=0x3, image_ok=0x3
I: Secondary image: magic=unset, swap_type=0x1, copy_done=0x3, image_ok=0x3
I: Boot source: none
After:bs->idx=1      bs->op=1      bs->state=1      bs->swap_type=1

I: Swap type: none
swap_type = 1

swap_type = 1

slot=0
I: Bootloader chainload address offset: 0x28000
I: Jumping to the first image slot
*** Booting Zephyr OS build v3.2.99-ncs1 ***
```