



RSDK Supplementary Library Module

**Realtek Semiconductor Corp.
Release 1.5.5p3
May 16, 2011**

Realtek Proprietary and Confidential

RSDK Supplementary Library Module1.5.5p3

This document is proprietary and confidential to Realtek Semiconductor Corp.
Copyright © 2006 Realtek Semiconductor Corp.
ALL RIGHTS RESERVED

MIPS, MIPS16, MIPS ABI, MIPSII, MIPSIV, MIPSV, MIPS32, R3000, R4000, and other MIPS common law marks are trademarks and/or registered trademarks of MIPS Technologies.

SmoothCore, Radiax, and NetVortex are trademarks of Lexra, Inc.

Contents

1	CP3 Library	1
1.1	Introduction	1
1.2	Interface	1
2	GDB Remote I/O Library	13
2.1	Introduction	13
2.2	Interface	13
3	Profiler Library	31
3.1	Introduction	31
3.2	Interface	31
4	RLX Code Coverage Library	47
4.1	Introduction	47
4.2	Interface	47
A	Example - CP3 Library	51
A.1	Example program	51
A.2	Example C run-time	51
A.3	Example makefile	53
A.4	Example linker script	54
B	Example - GDB Library	59
B.1	Example program	59
B.2	Example C run-time	59
B.3	Example makefile	61
B.4	Example linker script	62
C	Example - Profiler Library	67
C.1	Example program	67
C.2	Example C run-time	68
C.3	Example makefile	70
C.4	Example linker script	71
C.5	Example interrupt handler	75

D

Example - RLX Code Coverage Library

77

D.1

Example program

77

D.2

Example C run-time

77

D.3

Example makefile

79

D.4

Example linker script

80

List of Tables

2.1	Errno values	14
2.2	rlx_gdb_open flags	15
2.3	rlx_gdb_open modes	15
2.4	rlx_gdb_lseek flag	19
2.5	fields of struct stat	22
2.6	rlx_gdb_printf format	26
2.7	rlx_gdb_printf format	27

List of Figures

Chapter 1 CP3 Library

1.1 Introduction

Co-Processor3 (CP3) implements a modest set of 48-bit wide counters for monitoring certain performance parameters. There are four counters, each of which can be programmed to count one of the set of parameters. The counters are general read/write registers in CP3.

The CP3 library is a set of subroutines that makes use of the CP3 to achieve high accuracy CPU performance statistics.

In order to eliminate the impact on the cache and memory system casted by the CP3 library itself, the CP3 library should be put into the uncacheable region of the memory. This can be done by dedicating a ELF section which roots in proper memory region for CP3 library in the linker script.

The three sections reserved for the CP3 library are **.rlxprof_text**, **.rlxprof_data**, and **.rlxprof_bss**. These sections should be put into the uncacheable region of the memory. Examples are shown in [Appendix A](#).

1.2 Interface

The APIs for the CP3 performance counter library are summarized as follows:

- **rlx_cp3_init** – init CP3 counters
- **rlx_cp3_start** – start CP3 counting
- **rlx_cp3_start_dual** – start CP3 counting in dual counter mode
- **rlx_cp3_get_counter_hi** – get high part of CP3 counter
- **rlx_cp3_get_counter_lo** – get low part of CP3 counter
- **rlx_cp3_get_counter** – get CP3 counter
- **rlx_cp3_get_counters** – save CP3 counters
- **rlx_cp3_print_counter** – print CP3 counter
- **rlx_cp3_print_counters** – print CP3 counters
- **rlx_cp3_print_counters_dual** – print CP3 counters compatible for dual-counter mode
- **rlx_cp3_stop** – stop CP3 counting

The synopses of these APIs are described in the following pages.

- **RLX_CP3_INIT**

NAME

rlx_cp3_init – init CP3 counters

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_cp3_init(void)
```

DESCRIPTION

rlx_cp3_init initializes the CP3 performance counting mechanism. First, it enables CP3 performance counting by updating STATUS register (CP0 general register \$12). Then, it resets the CP3 counters to zero.

RETURN VALUE

This function does not return any value.

- **RLX_CP3_START**

NAME

rlx_cp3_start – start CP3 counting

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_cp3_start(unsigned int mode)
```

DESCRIPTION

rlx_cp3_start marks the start of the CP3 counting. The **mode** is an unsigned int that defines the counting mode. The counting mode is a combination of 1-byte constant that denotes what each counter in the CP3 registers is for. For Taroko processor, this sets the count events in single-counter mode.

RETURN VALUE

This function does not return any value.

- **RLX_CP3_START_DUAL**

NAME

rlx_cp3_start_dual – start CP3 counting in dual-counter mode

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_cp3_start_dual(unsigned int ctrl0, unsigned int ctrl1,
                   unsigned int ctrl2)
```

DESCRIPTION

rlx_cp3_start marks the start of the CP3 counting in dual-counter mode. This is only applicable for Taroko processor. The **ctrl0** is an unsigned int that defines the counting mode for low part. The **ctrl1** is an unsigned int that defines the counting mode for high part. The **ctrl2** is an unsigned int that defines the counting mode for dual-counter mode. The counting mode of ctrl0 or ctrl1 is a combination of 1-byte constant that denotes what each counter in the CP3 registers is for. Dual-counter mode is enabled/disabled by ctrl2.

RETURN VALUE

This function does not return any value.

- **RLX_CP3_STOP**

NAME

rlx_cp3_stop – stop CP3 counting

SYNOPSIS

```
#include "rlx_library.h"
```

```
void  
rlx_cp3_stop(void)
```

DESCRIPTION

rlx_cp3_stop marks the stop of the CP3 counting.

- **RLX_CP3_GET_COUNTER_HI**

NAME

rlx_cp3_get_counter_hi - get high part of CP3 counter

SYNOPSIS

```
#include "rlx_library.h"

unsigned int
rlx_cp3_get_counter_hi(int id)
```

DESCRIPTION

rlx_cp3_get_counter_hi retrieves the number stored in the high part of the specified CP3 counter. **id** is the counter index, such as 0, 1, 2, 3.

RETURN VALUE

This function returns the high part of the specific CP3 counter value.

- **RLX_CP3_GET_COUNTER_LO**

NAME

rlx_cp3_get_counter_lo - get low part of CP3 counter

SYNOPSIS

```
#include "rlx_library.h"

unsigned int
rlx_cp3_get_counter_lo(int id)
```

DESCRIPTION

rlx_cp3_get_counter_lo retrieves the number stored in the low part of the specified CP3 counter. **id** is the counter index, such as 0, 1, 2, 3.

RETURN VALUE

This function returns the low part of the specific CP3 counter value.

- **RLX_CP3_GET_COUNTER**

NAME

rlx_cp3_get_counter - get CP3 counter value

SYNOPSIS

```
#include "rlx_library.h"

CP3_COUNTER
rlx_cp3_get_counter(int id)
```

DESCRIPTION

rlx_cp3_get_counter retrieves the number stored in the specified CP3 counter. **id** is the counter index, such as 0, 1, 2, 3.

RETURN VALUE

This function returns the value of the specific CP3 counter.

- **RLX_CP3_GET_COUNTERS**

NAME

rlx_cp3_get_counters - save CP3 counters to an external array

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_cp3_get_counters(CP3_COUNTER *counters)
```

DESCRIPTION

rlx_cp3_get_counters retrieves the numbers stored in the CP3 counters and saves them into **counters**. **counters** is a pointer to a CP3_COUNTER array of four elements.

RETURN VALUE

This function does not return any value.

- **RLX_CP3_PRINT_COUNTER**

NAME

rlx_cp3_print_counter – print readable CP3 counter

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_cp3_print_counter(unsigned int mode, CP3_COUNTER value, int id)
```

DESCRIPTION

rlx_cp3_print_counter interprets the saved CP3 number and displays it in a human-readable form. It takes three parameters. **mode** is the counting mode that is used for this specific counter when starting the CP3 counter(s). It is extracted from the control register. **value** is the counter value. **id** is the counter index, such as 0, 1, 2, 3, etc. This value is only shown in output. It's not used to extract the counting mode from the control register. The example output is shown as follows:

```
counter0 = 000097571862 CPU cycles.
```

RETURN VALUE

This function does not return any value.

- **RLX_CP3_PRINT_COUNTERS**

NAME

rlx_cp3_print_counters – print readable CP3 counters

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_cp3_print_counters(unsigned int mode, CP3_COUNTER *counters)
```

DESCRIPTION

rlx_cp3_print_counters interprets the saved CP3 numbers and displays them in a human-readable form. It takes two parameters. **mode** is the counting mode that is used when starting the CP3 counters. **counters** is a pointer to the array of saved numbers. The example output is shown as follows:

```
counter control = 0x1a121110
counter0 = 000097571862 CPU cycles.
counter1 = 000102877702 Instructions.
counter2 = 000000003016 Icache Misses.
counter3 = 000000000269 Dcache Misses.
```

RETURN VALUE

This function does not return any value.

- **RLX_CP3_PRINT_COUNTERS_DUAL**

NAME

rlx_cp3_print_counters_dual – print readable CP3 counters compatible for dual-counter mode

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_cp3_print_counters_dual(unsigned int ctrl0, unsigned int ctrl1,
                           unsigned int ctrl2, CP3_COUNTER *counters)
```

DESCRIPTION

rlx_cp3_print_counters_dual interprets the saved CP3 numbers and displays them in a human-readable form. It takes four parameters. **ctrl0** is the counting mode that is used when starting the CP3 control register 0 **ctrl1** is the counting mode that is used when starting the CP3 control register 1 **ctrl2** is the counting mode that is used when starting the CP3 control register 2 **counters** is a pointer to the array of saved numbers. The example output is shown as follows:

```
counter ctrl0 = 0x06050408
counter ctrl1 = 0x09250307
counter ctrl2 = 0x00000005
counter0 = 000000000723 cycles
counter1 = 000000000379 completed instructions
counter2 = 000000000085 store instructions
counter3 = 000000000074 load instructions
counter4 = 000000000009 OCP bus writes
counter5 = 000000000159 load or store instructions
```

RETURN VALUE

This function does not return any value.

Chapter 2 GDB Remote I/O Library

2.1 Introduction

The GDB Remote Serial Protocol (RSP) is a simple, ASCII message-based protocol suitable for use on serial lines, local area networks, or just about any other communications medium that can support at least half-duplex data exchange.

The GDB remote I/O library uses a predefined address region, starting from **0x80000090**, 1KB size, for passing parameters. Please make sure the application does not use the memory within 1K range starting at **0x80000090**. The memory region can be changed by the interface API of `rlx_gdb_set_para_addr(unsigned int)`. **NOTE:** if you are using the built-in simulator for RSDK, do not change the memory region.

The GDB remote I/O library is a set of subroutines that bases on the RSP protocol to emulate I/O interactions during remote debugging. It allows the target to use the host's file system and console I/O to perform various system calls. This simulates file system operations even on targets that lack file systems.

If there's any error finishing the I/O call, the library tries to set the global variable `errno`. Error numbers are listed in table 2.1.

In order to link with the library, add "-lrlx" to your link flags.

2.2 Interface

The APIs for the GDB Remote I/O library are summarized as follows:

- **rlx_gdb_open** – remote file open
- **rlx_gdb_close** – remote file close
- **rlx_gdb_read** – remote file read
- **rlx_gdb_write** – remote file write
- **rlx_gdb_lseek** – remote file lseek
- **rlx_gdb_rename** – remote file rename
- **rlx_gdb_unlink** – remote file unlink
- **rlx_gdb_stat/fstat** – remote file stat/fstat
- **rlx_gdb_gettimeofday** – remote gettimeofday
- **rlx_gdb_isatty** – remote isatty
- **rlx_gdb_system** – remote system
- **rlx_gdb_printf** – remote printf
- **rlx_gdb_fprintf** – remote fprintf
- **rlx_gdb_set_param_addr** – set GDB IO parameter base address
- **rlx_gdb_get_param_addr** – get GDB IO parameter base address

The synopses of these APIs are described in the following pages.

Table 2.1: Errno values

Errno	Value	Description
EPERM	1	Not super-user
ENOENT	2	No such file or directory
EINTR	4	Interrupted system call
EBADF	9	Bad file number
EACCES	13	Permission denied
EFAULT	14	Bad address
EBUSY	16	Mount device busy
EEXIST	17	File exists
ENODEV	19	No such device
ENOTDIR	20	Not a directory
EISDIR	21	Is a directory
EINVAL	22	Invalid argument
ENFILE	23	Too many open files in system
EMFILE	24	Too many open files
EFBIG	27	File too large
ENOSPC	28	No space left on device
ESPIPE	29	Illegal seek
EROFS	30	Read only file system
ENAMETOOLONG	91	File or path name too long
EUNKONWN	9999	Unknown error

• RLX_GDB_OPEN

NAME

rlx_gdb_open – remote file open via GDB remote protocol

SYNOPSIS

```
#include "rlx_library.h"

int
rlx_gdb_open(const char *pathname, int flags, mode_t mode)
```

DESCRIPTION

rlx_gdb_open implements the **open** system call via the GDB remote protocol.

flags is the bitwise OR of the following values:

RETURN VALUE

rlx_gdb_open returns the new file descriptor or -1 if error.

ERRORS

EEXIST *pathname* already exists and O_CREAT and O_EXCL were used.

Table 2.2: rlx_gdb_open flags

Flag	Mask	Description
O_RDONLY	0x0	open for reading only
O_WRONLY	0x1	open for writing only
O_RDWR	0x2	open for reading and writing
O_APPEND	0x8	open in append mode
O_CREAT	0x200	create if it does not exist
O_TRUNC	0x400	truncate to zero if in writing mode (O_RDWR O_WRONLY)
O_EXCL	0x800	return error if the file already exists in O_CREAT mode

Table 2.3: rlx_gdb_open modes

Mode	Mask	Description
S_IXOTH	0x1	others have execute/search permission
S_IWOTH	0x2	others have write permission
S_IROTH	0x4	others have read permission
s_IXGRP	0x8	group has execute/search permission
S_IWGRP	0x10	group has write permission
S_IRGRP	0x20	group has read permission
S_IXUSR	0x40	user has execute/search permission
S_IWUSR	0x80	user has write permission
S_IRUSR	0x100	user has read permission
_S_IFDIR	0x4000	directory
_S_IFREG	0x8000	regular

EISDIR *pathname* refers to a directory.

EACCES The requested access is not allowed.

ENAMETOOLONG *pathname* was too long.

ENOENT A directory component in *pathname* does not exist.

ENODEV *pathname* refers to a device, pipe, named pipe or socket.

EROFS *pathname* refers to a file on a read-only filesystem and write access was requested.

EFAULT *pathname* is an invalid pointer value.

ENOSPC No space on device to create the file.

EMFILE The process already has the maximum number of file open.

ENFILE The limit on the total number of file open on the system has been reached.

EINTR The call was interrupted by the user.

- **RLX_GDB_CLOSE**

NAME

rlx_gdb_close – remote file close via GDB remote protocol

SYNOPSIS

```
#include "rlx_library.h"

int
rlx_gdb_close(int fd)
```

DESCRIPTION

rlx_gdb_close implements the file close system call via the GDB remote protocol.

RETURN VALUE

rlx_gdb_close returns zero on success, non-zero otherwise.

ERRORS

EBADF *fd* isn't a valid open file descriptor.

EINTR The call was interrupted by the user.

- **RLX_GDB_READ**

NAME

rlx_gdb_read – remote file read via GDB remote protocol

SYNOPSIS

```
#include "rlx_library.h"

int
rlx_gdb_read(int fd, void *buf, unsigned int count)
```

DESCRIPTION

rlx_gdb_read implements the file read system call via the GDB remote protocol.

RETURN VALUE

On success, the number of bytes read is returned. Zero indicates end of file. If count is zero, read returns zero as well.

ERRORS

EBADF *fd* is not a valid file descriptor or is not open for reading.

EFAULT *bufptr* is an invalid pointer value.

EINTR The call was interrupted by the user.

- **RLX_GDB_WRITE**

NAME

rlx_gdb_write - remote file write via GDB remote protocol

SYNOPSIS

```
#include "rlx_library.h"

int
rlx_gdb_write(int fd, const void *buf, int count)
```

DESCRIPTION

rlx_gdb_write implements the file write system call via the GDB remote protocol.

RETURN VALUE

On success, the number of bytes written is returned. Zero indicates nothing was written.

ERRORS

EBADF *fd* is not a valid file descriptor or is not open for writing.

EFAULT *bufptr* is an invalid pointer value.

EFBIG An attempt was made to write a file that exceeds the host specific maximum file size allowed.

ENOSPC No space on device to write the data.

EINTR The call was interrupted by the user.

- **RLX_GDB_LSEEK**

NAME

rlx_gdb_lseek – remote file lseek via GDB remote protocol

SYNOPSIS

```
#include "rlx_library.h"

int
rlx_gdb_lseek(int fd, int offset, int flag)
```

DESCRIPTION

rlx_gdb_lseek implements the file lseek system call via the GDB remote protocol.

Table 2.4: rlx_gdb_lseek flag

Flag	Mask	Description
SEEK_SET	0x0	the offset is set to offset bytes
SEEK_CUR	0x1	the offset is set to its current position plus offset bytes
SEEK_END	0x2	the offset is set to the size of the file plus offset bytes

RETURN VALUE

On success, the resulting unsigned offset in bytes from the beginning of the file is returned.

ERRORS

EBADF *fd* is not a valid open file descriptor.

ESPIPE *fd* is associated with the GDB console.

EINVAL *flag* is not a proper value.

EINTR The call was interrupted by the user.

- **RLX_GDB_RENAME**

NAME

rlx_gdb_rename – remote file rename via GDB remote protocol

SYNOPSIS

```
#include "rlx_library.h"

int
rlx_gdb_rename(const char *oldpath, const char *newpath)
```

DESCRIPTION

rlx_gdb_rename implements the file rename system call via the GDB remote protocol.

RETURN VALUE

On success, zero is returned. On error, -1 is returned.

ERRORS

EISDIR *newpath* is an existing directory, but *oldpath* is not a directory.

EEXIST *newpath* is a non-empty directory.

EBUSY *oldpath* or *newpath* is a directory that is in use by some process.

EINVAL An attempt was made to make a directory a subdirectory of itself.

ENOTDIR A component used as a directory in *oldpath* or new path is not a directory. Or *oldpath* is a directory and *newpath* exists but is not a directory.

EFAULT *oldpathptr* or *newpathptr* are invalid pointer values.

EACCES No access to the file or the path of the file.

ENAMETOOLONG *oldpath* or *newpath* was too long.

ENOENT A directory component in *oldpath* or *newpath* does not exist.

EROFS The file is on a read-only filesystem.

ENOSPC The device containing the file has no room for the new directory entry.

EINTR The call was interrupted by the user.

- **RLX_GDB_UNLINK**

NAME

rlx_gdb_unlink – remote file unlink via GDB remote protocol

SYNOPSIS

```
#include "rlx_library.h"

int
rlx_gdb_unlink(const char *pathname)
```

DESCRIPTION

rlx_gdb_unlink implements the file unlink system call via the GDB remote protocol.

RETURN VALUE

On success, zero is returned. On error, -1 is returned.

ERRORS

EACCES No access to the file or the path of the file.

EPERM The system does not allow unlinking of directories.

EBUSY The file *pathname* cannot be unlinked because it's being used by another process.

EFAULT *pathnameptr* is an invalid pointer value.

ENAMETOOLONG *pathname* was too long.

ENOENT A directory component in *pathname* does not exist.

ENOTDIR A component of the path is not a directory.

EROFS The file is on a read-only filesystem.

EINTR The call was interrupted by the user.

- **RLX_GDB_STAT/FSTAT**

NAME

rlx_gdb_stat/fstat – remote file stat/fstat via GDB remote protocol

SYNOPSIS

```
#include "rlx_library.h"

int
rlx_gdb_stat(const char *pathname, struct stat *buf)
int
rlx_gdb_fstat(int fd, struct stat *buf);
```

DESCRIPTION

rlx_gdb_stat/fstat implements the file stat/fstat system call via the GDB remote protocol. Note that due to size differences between the host, target, and protocol representations of **struct stat** members, these members could eventually get truncated on the target.

The values of several fields of **struct stat** have a restricted meaning and/or range of values:

Table 2.5: fields of struct stat

Fields	Description
st_dev	A value of 0 represents a file, 1 the console.
st_ino	No valid meaning for the target. Transmitted unchanged.
st_mode	Valid mode bits are described in table 2.3.
st_uid	No valid meaning for the target. Transmitted unchanged.
st_gid	
st_rdev	
st_atime	These values have a host file system dependent accuracy.
st_mtime	
st_ctime	

RETURN VALUE

On success, zero is returned. On error, -1 is returned.

ERRORS

EBADF *fd* is not a valid open file.

ENOENT A directory component in *pathname* does not exist or the path is an empty string.

ENOTDIR A component of the path is not a directory.

EFAULT *pathnameptr* is an invalid pointer value.

EACCES No access to the file or the path of the file.

ENAMETOOLONG *pathname* was too long.

EINTR The call was interrupted by the user.

- **RLX_GDB_GETTIMEOFDAY**

NAME

rlx_gdb_gettimeofday – remote gettimeofday via GDB remote protocol

SYNOPSIS

```
#include "rlx_library.h"

int
rlx_gdb_gettimeofday(struct timeval *tv, void *tz)
```

DESCRIPTION

rlx_gdb_gettimeofday implements the gettimeofday system call via the GDB remote protocol.

RETURN VALUE

On success, zero is returned. On error, -1 is returned.

ERRORS

EINVAL *tz* is a non-NULL pointer.

EFAULT *tvptr* and/or *tzptr* is an invalid pointer value.

- **RLX_GDB_ISATTY**

NAME

rlx_gdb_isatty – remote isatty via GDB remote protocol

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_gdb_isatty(int desc)
```

DESCRIPTION

rlx_gdb_isatty implements the isatty call via the GDB remote protocol.

RETURN VALUE

returns 1 if desc is an open descriptor connected to a terminal and 0 else.

ERRORS

EINTR The call was interrupted by the user.

- **RLX_GDB_SYSTEM**

NAME

rlx_gdb_system – remote system via GDB remote protocol

SYNOPSIS

```
#include "rlx_library.h"

int
rlx_gdb_system(const char *command)
```

DESCRIPTION

rlx_gdb_system implements the remote system call via the GDB remote protocol. GDB takes over the full task of calling the necessary host calls to perform the system call. The return value of system on the host is simplified before it's returned to the target. Any termination signal information from the child process is discarded, and the return value consists entirely of the exit status of the called command. Due to security concerns, the system call is by default refused by gdb. The user has to allow this call explicitly with the **set remote system-call-allowed 1** command.

set remote system-call-allowed Control whether to allow the system calls in the File I/O protocol for the remote target. The default is zero (disabled).

show remote system-call-allowed Show whether the system calls are allowed in the File I/O protocol.

RETURN VALUE

If *len* is zero, the return value indicates whether a shell is available. A zero return value indicates a shell is not available. For non-zero *len*, the value returned is -1 on error and the return status of the command otherwise. Only the exit status of the command is returned, which is extracted from the host's system return value by calling `WEXITSTATUS(retval)`. In case `'/bin/sh'` could not be executed, 127 is returned.

ERRORS

EINTR The call was interrupted by the user.

- **RLX_GDB_PRINTF**

NAME

rlx_gdb_printf – remote printf via GDB remote protocol

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_gdb_printf(char *format, ...)
```

DESCRIPTION

rlx_gdb_printf implements the printf call via the GDB remote protocol.

Table 2.6: rlx_gdb_printf format

Format	Description
s	print string
c	print character
x	print hex value
d	print decimal value

RETURN VALUE

This function does not return any value. If there's any error, it tries to find the global variable errno, and sets it according to errno from host.

- **RLX_GDB_FPRINTF**

NAME

rlx_gdb_fprintf – remote fprintf via GDB remote protocol

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_gdb_printf(int fd, char *format, ...)
```

DESCRIPTION

rlx_gdb_fprintf implements the fprintf call via the GDB remote protocol.

Table 2.7: rlx_gdb_printf format

Format	Description
s	print string
c	print character
x	print hex value
d	print decimal value

RETURN VALUE

This function does not return any value. If there's any error, it tries to find the global variable errno, and sets it according to errno from host.

- **RLX_GDB_SET_PARAM_ADDR**

NAME

rlx_gdb_set_param_addr – set GDB IO parameter base address

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_gdb_set_param_addr(unsigned int addr)
```

DESCRIPTION

rlx_gdb_set_param_addr sets the base address where the GDB IO parameters will be stored. In remote I/O, function call parameters will be saved at a predefined address so that the remote/host side can access them. This function sets the parameter address. The default address is 0x80000090.

RETURN VALUE

This function does not return any value.

- **RLX_GDB_GET_PARAM_ADDR**

NAME

rlx_gdb_get_param_addr – get GDB IO parameter base address

SYNOPSIS

```
#include "rlx_library.h"

unsigned int
rlx_gdb_get_param_addr(void)
```

DESCRIPTION

rlx_gdb_get_param_addr gets the base address where the GDB IO parameters will be stored. In remote I/O, function call parameters will be saved at a predefined address so that the remote/host side can access them. This function sets the parameter address. The default address is 0x80000090.

RETURN VALUE

This function returns the base address for GDB IO parameters.

Chapter 3 Profiler Library

3.1 Introduction

RLX profiler library is a set of subroutines that collects performance statistics for user-mode applications at functional level.

To use the RLX profiler library, the compiler flags and linker options must be modified to generate specific object codes and to link proper libraries for function-level profiling. The OS must also provide functions to disable and enable interrupts for the profiler to call upon entering and leaving function prologues and function epilogue.

The default CP3 counting mode is 0x1b1a1110. Dual counter mode for Taroko is disabled by default.

- **Compiler** The compiler must insert codes to call profiler subroutines upon entering and leaving function prologue as well as function epilogue. In RSDK, this is done by adding **-pg** to the compiler flag.
- **Linker** The linker should put the profiler library in the uncacheable memory region to avoid impact on the memory and cache system casted by the profiler library. This can be done by dedicating ELF sections which root in proper memory location for the profiler library in the linker script.

The three sections reserved for the profiler library are **.rlxprof_text**, **.rlxprof_data**, and **.rlxprof_bss**. These sections should be put into the uncacheable region of the memory.

Two additional variables, **__rlxprof_bss_ent** and **__rlxprof_bss_end**, must be set to mark the begin and end address of the **.rlxprof_bss** section. These two variables are required for the library to correctly access the **.rlxprof_bss** section.

Example linker script is shown as follows:

```
/* Script for -z combreloc: combine and sort reloc sections */
OUTPUT_FORMAT("elf32-bigmips", "elf32-bigmips", "elf32-littlemips")
OUTPUT_ARCH(mips)
ENTRY(start)

SECTIONS
{
    /* profiler section */
    .rlxprof_text 0xa0200000 : { *(.rlxprof_text) rlx_*(.text) }
    .rlxprof_data ALIGN(0x8) : { *(.rlxprof_data) }

    __rlxprof_bss_ent = ABSOLUTE(.);
    .rlxprof_bss ALIGN(0x8) (NOLOAD) : { *(.rlxprof_bss) }
    __rlxprof_bss_end = ABSOLUTE(.);

    ...
}
```

3.2 Interface

The profiler library interface can be divided into three categories, API, Callback, and Hook. The APIs are subroutines that can be directly invoked by the user application. The Callback functions are library checkpoints that are called

upon when specific events occur. The Hook functions are machine-dependent part that needs to be implemented by the developers.

The APIs are summarized as follows:

- **rlx_prof_init** – init profiler
- **rlx_prof_start** – start profiler
- **rlx_prof_stop** – stop profiler
- **rlx_prof_save_result** – save profiling result
- **rlx_prof_set_cp3_ctrl** – set CP3 counting mode
- **rlx_prof_set_cp3_ctrl1** – set CP3 counting mode for high part (only for Taroko)
- **rlx_prof_set_cp3_ctrl2** – enable/disable CP3 counting dual counter mode (only for Taroko)
- **rlx_prof_register_save_cb** – register callback function to save profiling result

The CALLBACK functions are summarized as follows:

- **_mcount** – function prologue callback
- **_ecount** – function epilogue callback
- **rlx_prof_mcount** – called by _mcount
- **rlx_prof_ecount** – called by _ecount

The HOOK functions are summarized as follows:

- **rlx_prof_disable_int** – disable interrupt
- **rlx_prof_enable_int** – enable interrupt

- **RLX_PROF_INIT**

NAME

rlx_prof_init – init function profiling

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_prof_init(void)
```

DESCRIPTION

rlx_prof_init initializes the function-level profiling mechanism. First, it zeros out the **.rlxprof_bss** section. Second, it starts the CP3 performance counting by calling the **rlx_cp3_init** and **rlx_cp3_start**.

RETURN VALUE

This function does not return any value.

- **RLX_PROF_START**

NAME

rlx_prof_start - start function profiling

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_prof_start(void)
```

DESCRIPTION

rlx_prof_start marks the start of function profiling mechanism.

The proper place to call this function is in the crt0 or crtbegin section before entering the main function.

RETURN VALUE

This function does not return any value.

- **RLX_PROF_STOP**

NAME

rlx_prof_stop - stop function profiling

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_prof_stop(void)
```

DESCRIPTION

rlx_prof_stop marks the end of function profiling mechanism.

The proper place to call this function is in the crtn or crtend section after returning from the main function.

RETURN VALUE

This function does not return any value.

- **RLX_PROF_SAVE_RESULT**

NAME

rlx_prof_save_result - save profiling result

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_prof_save_result(void)
```

DESCRIPTION

rlx_prof_save_result saves the profiling result. If a callback function is registered through the API **rlx_prof_register_save_cb**, the library calls the callback function to save the result. It's the user's responsibility to save the profiling data to a file on host to be parsed. If no callback function is registered, it writes the profiling output to a local file , **rsdk_mon.out**, on the host via the remote GDB I/O library. The output file is a binary file that can be parsed by the **rsdk-elf-gdb** or **rsdk-elf-insight** program.

RETURN VALUE

This function does not return any value.

- **RLX_PROF_SET_CP3_CTRL**

NAME

rlx_prof_set_cp3_ctrl – set CP3 counting mode

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_prof_set_cp3_ctrl(unsigned int mode)
```

DESCRIPTION

rlx_prof_set_cp3_ctrl sets the CP3 counting mode. The counting mode is a combination of 1-byte constant that denotes what each counter in the CP3 registers is for. Please refer to [chapter 1](#) for more information.

The default CP3 counting mode is 0x1b1a1110, which counts the following items: total number of CPU cycles, total number instruction fetches, total number of instruction fetch cache misses, and total number of busy cycles caused by instruction fetch cache.

RETURN VALUE

This function does not return any value.

- **RLX_PROF_SET_CP3_CTRL1**

NAME

rlx_prof_set_cp3_ctrl1 – set CP3 counting mode for high part in dual-counter mode

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_prof_set_cp3_ctrl1(unsigned int mode)
```

DESCRIPTION

rlx_prof_set_cp3_ctrl sets the CP3 counting mode for high part in dual-counter mode. This is only applicable for Taroko processor. The counting mode is a combination of 1-byte constant that denotes what each counter in the CP3 registers is for. Please refer to chapter [1](#) for more information.

The default CP3 counting mode for high part is 0.

RETURN VALUE

This function does not return any value.

- **RLX_PROF_SET_CP3_CTRL2**

NAME

rlx_prof_set_cp3_ctrl2 – enable/disable CP3 dual-counter mode

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_prof_set_cp3_ctrl2(unsigned int mode)
```

DESCRIPTION

rlx_prof_set_cp3_ctrl2 sets the CP3 counting mode. Set the appropriate bit can enable dual-counter mode for the monitor counter. This is only applicable for Taroko processor. Please refer to [chapter 1](#) for more information.

Dual-counter mode is disabled by default.

RETURN VALUE

This function does not return any value.

- **RLX_PROF_REGISTER_SAVE_CB**

NAME

rlx_prof_registers_save_cb - register callback function to save profiling result

SYNOPSIS

```
#include "rlx_library.h"

typedef void (rlx_prof_save_ftype)(const void *buf, size_t len);

void
rlx_prof_register_save_cb(rlx_prof_save_ftype *p_cb)
```

DESCRIPTION

rlx_prof_register_save_cb registers a callback function to be called by **rlx_prof_save_result** to save profiling result. The argument **buf** of the callback points to a memory region of the profiling result. The argument **len** of the callback tells the length in bytes of the memory region. The library can call the callback multiple times to save all the profiling data. It's the responsibility of the user to save the data in sequence. When there is no more profiling data, the library calls the callback with **buf** = 0 and **len** = 0.

RETURN VALUE

This function does not return any value.

- **_MCOUNT**

NAME

_mcount – function prologue callback function

SYNOPSIS

```
#include "rlx_library.h"

void
_mcount(void)
```

DESCRIPTION

_mcount is the callback function which the compiler will insert upon entering function prologue. This function, in turn, calls **rlx_prof_mcount** to collect calling graph and performance count of the function under investigation.

This function is implemented in the profiler library.

RETURN VALUE

This function does not return any value.

- **_ECOUNT**

NAME

_ecount – function epilogue callback function

SYNOPSIS

```
#include "rlx_library.h"

void
_ecount(void)
```

DESCRIPTION

_ecount is the callback function which the compiler will insert upon entering function epilogue. This function, in turn, calls **rlx_prof_ecount** to collect calling graph and performance count of the function under investigation. This function is implemented in the profiler library.

RETURN VALUE

This function does not return any value.

- **RLX_PROF_MCOUNT**

NAME

rlx_prof_mcount – 2nd level prologue callback function

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_prof_mcount(void)
```

DESCRIPTION

rlx_prof_mcount is the 2nd level callback function which the **_mcount** will call in function prologue. This function collects calling graph and performance count of the function under investigation.

This function is implemented in the profiler library.

RETURN VALUE

This function does not return any value.

- **RLX_PROF_ECOUNT**

NAME

rlx_prof_ecount – 2nd level epilogue callback function

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_prof_ecount(void)
```

DESCRIPTION

rlx_prof_ecount is the 2nd level callback function which the **_ecount** will call in function epilogue. This function collects calling graph and performance count of the function under investigation.

This function is implemented in the profiler library.

RETURN VALUE

This function does not return any value.

- **RLX_PROF_ENABLE_INT**

NAME

rlx_prof_enable_int – enable interrupts

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_prof_enable_int(void) __attribute__((section(".rlxprof_text")))
```

DESCRIPTION

rlx_prof_enable_int enables the interrupts. This function will be called by the profiler library after it has finished its task in function prologue or epilogue. This function should be implemented by the developer to meet the operating system and platform the application is running on.

By default, this function should be put in a special section **.rlxprof_text**. An example implementation is shown in [appendix C](#).

RETURN VALUE

This function does not return any value.

- **RLX_PROF_DISABLE_INT**

NAME

rlx_prof_disable_int - disables interrupts

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_prof_disable_int(void) __attribute__((section(".rlxprof_text")))
```

DESCRIPTION

rlx_prof_disable_int disables the interrupts. This function will be called by the profiler library right before starting its task in function prologue or epilogue. This function should be implemented by the developer to meet the operation system and platform the application is running on.

By default, this function should be put in a special section **.rlxprof_text**. An example implementation is shown in [appendix C](#).

RETURN VALUE

This function does not return any value.

Chapter 4 RLX Code Coverage Library

4.1 Introduction

The RLX Code Coverage Library (RLXCOV) is a set of subroutines that help developers collect code coverage statistics in remote debugging environment. This library is similar to the GNU code coverage library (GCOV) except that the `rlxcov` library supports remote file I/O via GDB remote serial protocol.

To use the RLXCOV library, the compiler flags and linker options must be modified to generate and link proper codes and libraries to enable code coverage analysis.

- **Compiler:**

In order to enable code coverage analysis, the compiler option **-frlxcov** must be added to the compiler flag when generating codes.

- **Linker:**

The coverage analysis codes will be placed in a special **.rlxcov** section to avoid interference of the analysis statistics. Therefore, the linker script must be modified to explicitly allocate the **.rlxcov** section.

Two variables, **__rlxcov_ent** and **__rlxcov_end** must be set to mark the begin and end address of the **.rlxcov** section. These two variables are required for the library to read and parse symbols in the **.rlxcov** section.

Example linker script is shown as follows:

```
SECTIONS
{
    ....

    __rlxcov_ent = ABSOLUTE(.);
    .rlxcov BLOCK(0x8) : { *(.rlxcov) }
    __rlxcov_end = ABSOLUTE(.);

    ....
}
```

Examples are shown in [Appendix D](#).

4.2 Interface

The APIs for the RLX code coverage analysis library are summarized as follows:

- **rlx_cov_init** – init code coverage library
- **rlx_cov_exit** – stop code coverage library

The synopses of these APIs are described in the following pages.

- **RLX_COV_INIT**

NAME

rlx_cov_init – init code coverage library

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_cov_init(void)
```

DESCRIPTION

rlx_cov_init initializes the RLXCOV code analysis mechanism. This function must be called exactly once for the application under investigation. Upon initialization, the RLXCOV reads the symbols in the .rlxcov section and initializes bookkeeping fields for each function in the application.

The proper place to call this function is in the crt0 or crtbegin before entering the main function.

RETURN VALUE

This function does not return any value.

- **RLX_COV_EXIT**

NAME

rlx_cov_exit – stop code coverage library

SYNOPSIS

```
#include "rlx_library.h"

void
rlx_cov_exit(void)
```

DESCRIPTION

rlx_cov_exit marks the end of the code coverage analysis. This function must be called exactly once for the application under investigation.

The proper place to call this function is in the `crtn` or `crtend` after returning from the main function.

RETURN VALUE

This function does not return any value.

Appendix A Example - CP3 Library

A.1 Example program

```
#include "rlx_library.h"

int main(int argc, char **argv)
{
    CP3_COUNTER counters[4];

    /* init CP3 counters */
    rlx_cp3_init();
    rlx_cp3_start(CP3_PERFMODE1);

    /* your code here */
    printf("do something here\n");

    /* stop CP3 counters */
    rlx_cp3_stop();
    rlx_cp3_get_counters(counters);
    rlx_cp3_print_counters(CP3_PERFMODE1, counters);

    return 0;
}
```

A.2 Example C run-time

```
/*
 * Realtek Semiconductor Corp.
 *
 * c.S:
 */
#include <regdef.h>
#include "rlx_library.h"

#define PERFMODE1 0x1a121110
#define UART_DATA_ADDRESS 0xbc00000c

.set nomips16

.globl _stack_base
_stack_base:
.rept 512*1024
.byte 0
.endr

.balign 16
.globl _stack
```

```

_stack:
.rept 8
.long 0
.endr

.data
.globl my_argv
my_argv:
.rept 16
.byte 0
.endr

.data
.globl my_arg_str
my_arg_str:
.rept 256
.byte 0
.endr

.comm cp3_counter,32

.text

.globl start
.globl _exit

.ent start
start:
/*
 * Initialize COP3 counters
 */
la t0, rlx_cp3_init
jalr t0
nop
la t0, rlx_cp3_start
li a0, CP3_PERFMODE1
jalr t0
nop

/*
** Initialize data.
*/
la v0, _edata
/*
** Align pointer.
*/
add v0, 3
srl v0, 2
sll v0, 2
la v1, end
loop0: sw zero, 0x0(v0)
sw zero, 0x4(v0)
sw zero, 0x8(v0)
sw zero, 0xc(v0)
addu v0, 16
blt v0, v1, loop0

/*
** Initialize the global data pointer.

```

```

*/
la gp, _gp
    la sp, _stack

/*
** Every good C program has a main.
*/
#if defined(__mips16)
jalx main
#else
jal main
#endif
nop
move a0, v0
.end start

.ent _exit
_exit:
    move s0, a0
    la t0, rlx_cp3_get_counters
    la a0, cp3_counter
    jalr t0
    nop
    la t0, rlx_cp3_print_counters
    li a0, CP3_PERFMODE1
    la a1, cp3_counter
    jalr t0
    nop
    move a0, s0
    syscall 1
.end _exit

/*
** PutC
** Instruction used to perform character output
** from programs running during simulation.
*/
.globl __PutCharacter
.ent __PutCharacter
__PutCharacter:
    li a0, UART_DATA_ADDRESS
    sw a1, 0(a0)
j ra # Return
.end __PutCharacter

.comm __errno,4

```

A.3 Example makefile

```

#
# Realtek Semiconductor Corp.
#
# RSDK CP3 Library
#
# Tony Wu (tonywu@realtek.com.tw)
# Jul. 07, 2006
#

```

```

#####
ARCH = 4180
PROGRAM = testcp3
RSDKDIR = /rsdk/rsdk-1.2.7/linux/newlib

CC = $(RSDKDIR)/bin/rsdk-elf-gcc
LD = $(RSDKDIR)/bin/rsdk-elf-ld

CFLAGS = -march=$(ARCH) -c -G0 -fno-pic -DRLX_UNCACHEABLE
IFLAGS = -I$(RSDKDIR)/include
LFLAGS = -Ttext 80000000 -e start -N -n
LIBS = -L$(RSDKDIR)/lib/$(ARCH) -lrlx -lm -lc -lgcc -L. -lrlxsim_gdb

#####
all: $(PROGRAM)

.S.o:
$(CC) -D__ASM__ -x assembler-with-cpp $(CFLAGS) $(IFLAGS) $<

.c.o:
$(CC) $(CFLAGS) $(IFLAGS) $<

testcp3: c.o cp3.o
$(LD) -T target-rlxsim.ld -o testcp3 $(LFLAGS) c.o cp3.o $(LIBS)

clean:
rm -f *.o $(PROGRAM)

```

A.4 Example linker script

```

/* Script for -z combreloc: combine and sort reloc sections */
OUTPUT_FORMAT("elf32-bigmips", "elf32-bigmips", "elf32-littlemips")
OUTPUT_ARCH(mips)
ENTRY(start)

SECTIONS
{
    /* profiler section */
    .rlxprof_text 0xa0200000 : { *(.rlxprof_text) rlx_*.text) }
    .rlxprof_data ALIGN(0x8) : { *(.rlxprof_data) }

    __rlxprof_bss_begin = ABSOLUTE(.);
    .rlxprof_bss ALIGN(0x8) (NOLOAD) : { *(.rlxprof_bss) }
    __rlxprof_bss_end = ABSOLUTE(.);

    /* Read-only sections, merged into text segment: */
    PROVIDE (__executable_start = 0x0400000); . = 0x0400000;
    .interp : { *(.interp) }
    .reginfo : { *(.reginfo) }
    .dynamic : { *(.dynamic) }
    .hash : { *(.hash) }
    .dynsym : { *(.dynsym) }
    .dynstr : { *(.dynstr) }
    .gnu.version : { *(.gnu.version) }
    .gnu.version_d : { *(.gnu.version_d) }
    .gnu.version_r : { *(.gnu.version_r) }
    .rel.dyn :
    {
        *(.rel.init)
        *(.rel.text .rel.text.* .rel.gnu.linkonce.t.*)
    }

```

```

*(.rel.fini)
*(.rel.rodata .rel.rodata.* .rel.gnu.linkonce.r.*)
*(.rel.data.rel.ro*)
*(.rel.data .rel.data.* .rel.gnu.linkonce.d.*)
*(.rel.tdata .rel.tdata.* .rel.gnu.linkonce.td.*)
*(.rel.tbss .rel.tbss.* .rel.gnu.linkonce.tb.*)
*(.rel.ctors)
*(.rel.dtors)
*(.rel.got)
*(.rel.sdata .rel.sdata.* .rel.gnu.linkonce.s.*)
*(.rel.sbss .rel.sbss.* .rel.gnu.linkonce.sb.*)
*(.rel.sdata2 .rel.sdata2.* .rel.gnu.linkonce.s2.*)
*(.rel.sbss2 .rel.sbss2.* .rel.gnu.linkonce.sb2.*)
*(.rel.bss .rel.bss.* .rel.gnu.linkonce.b.*)
}
.rela.dyn      :
{
    *(.rela.init)
    *(.rela.text .rela.text.* .rela.gnu.linkonce.t.*)
    *(.rela.fini)
    *(.rela.rodata .rela.rodata.* .rela.gnu.linkonce.r.*)
    *(.rela.data .rela.data.* .rela.gnu.linkonce.d.*)
    *(.rela.tdata .rela.tdata.* .rela.gnu.linkonce.td.*)
    *(.rela.tbss .rela.tbss.* .rela.gnu.linkonce.tb.*)
    *(.rela.ctors)
    *(.rela.dtors)
    *(.rela.got)
    *(.rela.sdata .rela.sdata.* .rela.gnu.linkonce.s.*)
    *(.rela.sbss .rela.sbss.* .rela.gnu.linkonce.sb.*)
    *(.rela.sdata2 .rela.sdata2.* .rela.gnu.linkonce.s2.*)
    *(.rela.sbss2 .rela.sbss2.* .rela.gnu.linkonce.sb2.*)
    *(.rela.bss .rela.bss.* .rela.gnu.linkonce.b.*)
}
.rel.plt      : { *(.rel.plt) }
.rela.plt     : { *(.rela.plt) }
.init         :
{
    KEEP (*(init))
} =0
.plt          : { *(.plt) }
.text 0x80000000 :
{
    _ftext = . ;
    *(.text .stub .text.* .gnu.linkonce.t.*)
    KEEP (*(text.*personality*))
    /* .gnu.warning sections are handled specially by elf32.em.  */
    *(.gnu.warning)
    *(.mips16.fn.*) *(.mips16.call.*)
} =0
.fini         :
{
    KEEP (*(fini))
} =0
PROVIDE (__etext = .);
PROVIDE (_etext = .);
PROVIDE (etext = .);
.rodata       : { *(.rodata .rodata.* .gnu.linkonce.r.*) }
.rodata1      : { *(.rodata1) }
.sdata2       : { *(.sdata2 .sdata2.* .gnu.linkonce.s2.*) }
.sbss2        : { *(.sbss2 .sbss2.* .gnu.linkonce.sb2.*) }
.eh_frame_hdr : { *(.eh_frame_hdr) }
.eh_frame     : ONLY_IF_RO { KEEP (*(eh_frame)) }
.gcc_except_table : ONLY_IF_RO { KEEP (*(gcc_except_table)) *(gcc_except_table.*) }
/* Adjust the address for the data segment.  We want to adjust up to
   the same address within the page on the next page up.  */

```

```

. = ALIGN (0x40000) - ((0x40000 - .) & (0x40000 - 1)); . =
                                DATA_SEGMENT_ALIGN (0x40000, 0x1000);

/* Exception handling */
.eh_frame      : ONLY_IF_RW { KEEP (*.eh_frame) }
.gcc_except_table : ONLY_IF_RW { KEEP (*.gcc_except_table) (*.gcc_except_table.*) }
/* Thread Local Storage sections */
.tdata      : { (*.tdata .tdata.* .gnu.linkonce.td.*) }
.tbss       : { (*.tbss .tbss.* .gnu.linkonce.tb.*) (*.tcommon) }
/* Ensure the __preinit_array_start label is properly aligned.  We
   could instead move the label definition inside the section, but
   the linker would then create the section even if it turns out to
   be empty, which isn't pretty.  */
. = ALIGN(32 / 8);
PROVIDE (__preinit_array_start = .);
.preinit_array : { KEEP (*.preinit_array) }
PROVIDE (__preinit_array_end = .);
PROVIDE (__init_array_start = .);
.init_array   : { KEEP (*.init_array) }
PROVIDE (__init_array_end = .);
PROVIDE (__fini_array_start = .);
.fini_array   : { KEEP (*.fini_array) }
PROVIDE (__fini_array_end = .);
.ctors
{
    /* gcc uses crtbegin.o to find the start of
       the constructors, so we make sure it is
       first.  Because this is a wildcard, it
       doesn't matter if the user does not
       actually link against crtbegin.o; the
       linker won't look for a file to match a
       wildcard.  The wildcard also means that it
       doesn't matter which directory crtbegin.o
       is in.  */
    KEEP (*crtbegin*.o(.ctors))
    /* We don't want to include the .ctor section from
       from the crtend.o file until after the sorted ctors.
       The .ctor section from the crtend file contains the
       end of ctors marker and it must be last */
    KEEP (*EXCLUDE_FILE (*crtend*.o ) .ctors))
    KEEP (* (SORT(.ctors.*)))
    KEEP (*.ctors)
}
.dtors
{
    KEEP (*crtbegin*.o(.dtors))
    KEEP (* (EXCLUDE_FILE (*crtend*.o ) .dtors))
    KEEP (* (SORT(.dtors.*)))
    KEEP (*.dtors)
}
.jcr      : { KEEP (*.jcr) }
.data.rel.ro : { (*.data.rel.ro.local) (*.data.rel.ro*) }
. = DATA_SEGMENT_RELRO_END (0, .);
.data
{
    _fdata = . ;
    (*.data .data.* .gnu.linkonce.d.*)
    KEEP (*.gnu.linkonce.d.*personality*)
    SORT(CONSTRUCTORS)
}
.data1      : { (*.data1) }
. = .;
_gp = ALIGN(16) + 0x7ff0;
.got        : { (*.got.plt) (*.got) }
/* We want the small data sections together, so single-instruction offsets
   can access them all, and initialized data all before uninitialized, so

```



```

    we can shorten the on-disk segment size.  */
.sdata          :
{
    *(.sdata .sdata.* .gnu.linkonce.s.*)
}
.lit8            : { *(.lit8) }
.lit4            : { *(.lit4) }
_edata = .;
PROVIDE (edata = .);
__bss_start = .;
_fbss = .;
.sbss           :
{
    PROVIDE (__sbss_start = .);
    PROVIDE (___sbss_start = .);
    *(.dynsbss)
    *(.sbss .sbss.* .gnu.linkonce.sb.*)
    *(.scommon)
    PROVIDE (__sbss_end = .);
    PROVIDE (___sbss_end = .);
}
.bss            :
{
    *(.dynbss)
    *(.bss .bss.* .gnu.linkonce.b.*)
    *(COMMON)
    /* Align here to ensure that the .bss section occupies space up to
       _end.  Align after .bss to ensure correct alignment even if the
       .bss section disappears because there are no input sections.  */
    . = ALIGN(32 / 8);
}
. = ALIGN(32 / 8);
_end = .;
PROVIDE (end = .);
. = DATA_SEGMENT_END (.);
/* Stabs debugging sections.  */
.stab          0 : { *(.stab) }
.stabstr       0 : { *(.stabstr) }
.stab.excl     0 : { *(.stab.excl) }
.stab.exclstr  0 : { *(.stab.exclstr) }
.stab.index    0 : { *(.stab.index) }
.stab.indexstr 0 : { *(.stab.indexstr) }
.comment       0 : { *(.comment) }
/* DWARF debug sections.
   Symbols in the DWARF debugging sections are relative to the beginning
   of the section so we begin them at 0.  */
/* DWARF 1 */
.debug         0 : { *(.debug) }
.line          0 : { *(.line) }
/* GNU DWARF 1 extensions */
.debug_srcinfo 0 : { *(.debug_srcinfo) }
.debug_sfnames 0 : { *(.debug_sfnames) }
/* DWARF 1.1 and DWARF 2 */
.debug_aranges 0 : { *(.debug_aranges) }
.debug_pubnames 0 : { *(.debug_pubnames) }
/* DWARF 2 */
.debug_info    0 : { *(.debug_info .gnu.linkonce.wi.*) }
.debug_abbrev  0 : { *(.debug_abbrev) }
.debug_line    0 : { *(.debug_line) }
.debug_frame   0 : { *(.debug_frame) }
.debug_str     0 : { *(.debug_str) }
.debug_loc     0 : { *(.debug_loc) }
.debug_macinfo 0 : { *(.debug_macinfo) }
/* SGI/MIPS DWARF 2 extensions */
.debug_weaknames 0 : { *(.debug_weaknames) }

```

```
.debug_funcnames 0 : { *(.debug_funcnames) }  
.debug_typenames 0 : { *(.debug_typenames) }  
.debug_varnames 0 : { *(.debug_varnames) }  
.gptab.sdata : { *(.gptab.data) *(.gptab.sdata) }  
.gptab.sbss : { *(.gptab.bss) *(.gptab.sbss) }  
/DISCARD/ : { *(.note.GNU-stack) }  
}
```

Appendix B Example - GDB Library

B.1 Example program

```
/*
 * Copyright (c) 2006, Realtek Semiconductor Corp.
 *
 * gdbio.c:
 *   GDB remote I/O example program
 *
 * Tony Wu (tonyw@realtek.com.tw)
 * Jul. 26, 2006
 */

#include <stdio.h>
#include "rlx_library.h"

int
main(int argc, char **argv)
{
    int fd;
    char buff[] = "This is a test string";

    fd = rlx_gdb_open("test.txt", O_CREAT | O_RDWR | O_TRUNC,
                     S_IRUSR|S_IWUSR|S_IRGRP|S_IWGRP|S_IROTH|S_IWOTH);
    if (fd < 0)
    {
        rlx_gdb_printf("ERROR: unable to open the test.txt\n");
        return -1;
    }

    rlx_gdb_write(fd, buff, sizeof(buff));
    rlx_gdb_close(fd);
    return 0;
}
```

B.2 Example C run-time

```
/*
 * Realtek Semiconductor Corp.
 *
 * c.S:
 */
#include <regdef.h>
#include "rlx_library.h"

#define PERFMODE1 0x1a121110
#define UART_DATA_ADDRESS 0xbc00000c

.set nomips16
```

```

.globl _stack_base
_stack_base:
.rept 512*1024
.byte 0
.endr

.balign 16
.globl _stack
_stack:
.rept 8
.long 0
.endr

.data
.globl my_argv
my_argv:
.rept 16
.byte 0
.endr

.data
.globl my_arg_str
my_arg_str:
.rept 256
.byte 0
.endr

.comm cp3_counter,32

.text

.globl start
.globl _exit

```

```

.ent start
start:
/*
** Initialize data.
*/
la v0, _edata
/*
** Align pointer.
*/
add v0, 3
srl v0, 2
sll v0, 2
la v1, end
loop0: sw zero, 0x0(v0)
sw zero, 0x4(v0)
sw zero, 0x8(v0)
sw zero, 0xc(v0)
addu v0, 16
blt v0, v1, loop0

/*
** Initialize the global data pointer.
*/
la gp, _gp
la sp, _stack

/*
** Every good C program has a main.
*/
#if defined(__mips16)

```

```

jalx main
#else
jal main
#endif
nop
move a0, v0
.end start

.ent _exit
_exit:
    syscall 1
.end _exit

/*
** PutC
** Instruction used to perform character output
** from programs running during simulation.
*/
.globl __PutCharacter
.ent __PutCharacter
__PutCharacter:
    li a0, UART_DATA_ADDRESS
    sw a1, 0(a0)
    j ra # Return
.end __PutCharacter

.comm __errno,4

```

B.3 Example makefile

```

#
# Realtek Semiconductor Corp.
#
# RSDK GDB Remote IO Library
#
# Tony Wu (tonywu@realtek.com.tw)
# Jul. 07, 2006
#

#//////////////////////////////////////////
ARCH = 4180
PROGRAM = testgdbio
RSDKDIR = /rsdk/rsdk-1.2.7/linux/newlib

CC = $(RSDKDIR)/bin/rsdk-elf-gcc
LD = $(RSDKDIR)/bin/rsdk-elf-ld

CFLAGS = -march=$(ARCH) -c -G0 -fno-pic
IFLAGS = -I$(RSDKDIR)/include
LFLAGS = -Ttext 80000000 -e start -N -n
LIBS = -L$(RSDKDIR)/lib/$(ARCH) -lrlx -lm -lc -lgcc -L. -lrlxsim_gdb

#//////////////////////////////////////////
all: $(PROGRAM)

.S.o:
$(CC) -D__ASM__ -x assembler-with-cpp $(CFLAGS) $(IFLAGS) $<

.C.o:
$(CC) $(CFLAGS) $(IFLAGS) $<

testgdbio: c.o gdbio.o
$(LD) -T target-rlxsim.ld -o testgdbio $(LFLAGS) c.o gdbio.o $(LIBS)

```

```
clean:
rm -f *.o $(PROGRAM)
```

B.4 Example linker script

```
/* Script for -z combreloc: combine and sort reloc sections */
OUTPUT_FORMAT("elf32-bigmips", "elf32-bigmips", "elf32-littlemips")
OUTPUT_ARCH(mips)
ENTRY(start)

SECTIONS
{
    /* Read-only sections, merged into text segment: */
    PROVIDE (__executable_start = 0x0400000); . = 0x0400000;
    .interp      : { *(.interp) }
    .reginfo     : { *(.reginfo) }
    .dynamic     : { *(.dynamic) }
    .hash        : { *(.hash) }
    .dynsym      : { *(.dynsym) }
    .dynstr      : { *(.dynstr) }
    .gnu.version : { *(.gnu.version) }
    .gnu.version_d : { *(.gnu.version_d) }
    .gnu.version_r : { *(.gnu.version_r) }
    .rel.dyn     :
    {
        *(.rel.init)
        *(.rel.text .rel.text.* .rel.gnu.linkonce.t.*)
        *(.rel.fini)
        *(.rel.rodata .rel.rodata.* .rel.gnu.linkonce.r.*)
        *(.rel.data.rel.ro*)
        *(.rel.data .rel.data.* .rel.gnu.linkonce.d.*)
        *(.rel.tdata .rel.tdata.* .rel.gnu.linkonce.td.*)
        *(.rel.tbss .rel.tbss.* .rel.gnu.linkonce.tb.*)
        *(.rel.ctors)
        *(.rel.dtors)
        *(.rel.got)
        *(.rel.sdata .rel.sdata.* .rel.gnu.linkonce.s.*)
        *(.rel.sbss .rel.sbss.* .rel.gnu.linkonce.sb.*)
        *(.rel.sdata2 .rel.sdata2.* .rel.gnu.linkonce.s2.*)
        *(.rel.sbss2 .rel.sbss2.* .rel.gnu.linkonce.sb2.*)
        *(.rel.bss .rel.bss.* .rel.gnu.linkonce.b.*)
    }
    .rela.dyn    :
    {
        *(.rela.init)
        *(.rela.text .rela.text.* .rela.gnu.linkonce.t.*)
        *(.rela.fini)
        *(.rela.rodata .rela.rodata.* .rela.gnu.linkonce.r.*)
        *(.rela.data .rela.data.* .rela.gnu.linkonce.d.*)
        *(.rela.tdata .rela.tdata.* .rela.gnu.linkonce.td.*)
        *(.rela.tbss .rela.tbss.* .rela.gnu.linkonce.tb.*)
        *(.rela.ctors)
        *(.rela.dtors)
        *(.rela.got)
        *(.rela.sdata .rela.sdata.* .rela.gnu.linkonce.s.*)
        *(.rela.sbss .rela.sbss.* .rela.gnu.linkonce.sb.*)
        *(.rela.sdata2 .rela.sdata2.* .rela.gnu.linkonce.s2.*)
        *(.rela.sbss2 .rela.sbss2.* .rela.gnu.linkonce.sb2.*)
        *(.rela.bss .rela.bss.* .rela.gnu.linkonce.b.*)
    }
    .rel.plt    : { *(.rel.plt) }
```

```

.rela.plt      : { *(.rela.plt) }
.init         :
{
    KEEP (*(init))
} =0
.plt          : { *(.plt) }
.text 0x80000000 :
{
    _ftext = . ;
    *(.text .stub .text.* .gnu.linkonce.t.*)
    KEEP (*(text.*personality*))
    /* .gnu.warning sections are handled specially by elf32.em.  */
    *(.gnu.warning)
    *(.mips16.fn.*) *(.mips16.call.*)
} =0
.fini         :
{
    KEEP (*(fini))
} =0
PROVIDE (__etext = .);
PROVIDE (_etext = .);
PROVIDE (etext = .);
.rodata       : { *(.rodata .rodata.* .gnu.linkonce.r.*) }
.rodata1      : { *(.rodata1) }
.sdata2       : { *(.sdata2 .sdata2.* .gnu.linkonce.s2.*) }
.sbss2        : { *(.sbss2 .sbss2.* .gnu.linkonce.sb2.*) }
.eh_frame_hdr : { *(.eh_frame_hdr) }
.eh_frame     : ONLY_IF_RO { KEEP (*(eh_frame)) }
.gcc_except_table : ONLY_IF_RO { KEEP (*(gcc_except_table)) *(gcc_except_table.*) }
/* Adjust the address for the data segment.  We want to adjust up to
   the same address within the page on the next page up.  */
. = ALIGN (0x40000) - ((0x40000 - .) & (0x40000 - 1)); . =
    DATA_SEGMENT_ALIGN (0x40000, 0x1000);

/* Exception handling */
.eh_frame     : ONLY_IF_RW { KEEP (*(eh_frame)) }
.gcc_except_table : ONLY_IF_RW { KEEP (*(gcc_except_table)) *(gcc_except_table.*) }
/* Thread Local Storage sections */
.tdata       : { *(.tdata .tdata.* .gnu.linkonce.td.*) }
.tbss        : { *(.tbss .tbss.* .gnu.linkonce.tb.*) *(tcommon) }
/* Ensure the __preinit_array_start label is properly aligned.  We
   could instead move the label definition inside the section, but
   the linker would then create the section even if it turns out to
   be empty, which isn't pretty.  */
. = ALIGN(32 / 8);
PROVIDE (__preinit_array_start = .);
.preinit_array : { KEEP (*(preinit_array)) }
PROVIDE (__preinit_array_end = .);
PROVIDE (__init_array_start = .);
.init_array   : { KEEP (*(init_array)) }
PROVIDE (__init_array_end = .);
PROVIDE (__fini_array_start = .);
.fini_array   : { KEEP (*(fini_array)) }
PROVIDE (__fini_array_end = .);
.ctors        :
{
    /* gcc uses crtbegin.o to find the start of
       the constructors, so we make sure it is
       first.  Because this is a wildcard, it
       doesn't matter if the user does not
       actually link against crtbegin.o; the
       linker won't look for a file to match a
       wildcard.  The wildcard also means that it
       doesn't matter which directory crtbegin.o
       is in.  */
    KEEP (*crtbegin*.o(.ctors))

```

```

/* We don't want to include the .ctor section from
   from the crtend.o file until after the sorted ctors.
   The .ctor section from the crtend file contains the
   end of ctors marker and it must be last */
KEEP (*(EXCLUDE_FILE (*crtend*.o ) .ctors))
KEEP (*(SORT(.ctors.*)))
KEEP (*(.ctors))
}
.dtors      :
{
    KEEP (*crtbegin*.o(.dtors))
    KEEP (*(EXCLUDE_FILE (*crtend*.o ) .dtors))
    KEEP (*(SORT(.dtors.*)))
    KEEP (*(.dtors))
}
.jcr        : { KEEP (*(.jcr)) }
.data.rel.ro : { *(.data.rel.ro.local) *(.data.rel.ro*) }
. = DATA_SEGMENT_RELRO_END (0, .);
.data       :
{
    _fdata = . ;
    *(.data .data.* .gnu.linkonce.d.*)
    KEEP (*(.gnu.linkonce.d.*personality*))
    SORT(CONSTRUCTORS)
}
.data1      : { *(.data1) }
. = .;
_gp = ALIGN(16) + 0x7ff0;
.got        : { *(.got.plt) *(.got) }
/* We want the small data sections together, so single-instruction offsets
   can access them all, and initialized data all before uninitialized, so
   we can shorten the on-disk segment size. */
.sdata      :
{
    *(.sdata .sdata.* .gnu.linkonce.s.*)
}
.lit8       : { *(.lit8) }
.lit4       : { *(.lit4) }
_edata = .;
PROVIDE (edata = .);
__bss_start = .;
_fbss = .;
.sbss       :
{
    PROVIDE (__sbss_start = .);
    PROVIDE (___sbss_start = .);
    *(.dynsbss)
    *(.sbss .sbss.* .gnu.linkonce.sb.*)
    *(.scommon)
    PROVIDE (__sbss_end = .);
    PROVIDE (___sbss_end = .);
}
.bss        :
{
    *(.dynbss)
    *(.bss .bss.* .gnu.linkonce.b.*)
    *(COMMON)
    /* Align here to ensure that the .bss section occupies space up to
       _end. Align after .bss to ensure correct alignment even if the
       .bss section disappears because there are no input sections. */
    . = ALIGN(32 / 8);
}
. = ALIGN(32 / 8);
_end = .;
PROVIDE (end = .);

```



```

. = DATA_SEGMENT_END (.);
/* Stabs debugging sections. */
.stab          0 : { *(.stab) }
.stabstr       0 : { *(.stabstr) }
.stab.excl     0 : { *(.stab.excl) }
.stab.exclstr  0 : { *(.stab.exclstr) }
.stab.index    0 : { *(.stab.index) }
.stab.indexstr 0 : { *(.stab.indexstr) }
.comment       0 : { *(.comment) }
/* DWARF debug sections.
   Symbols in the DWARF debugging sections are relative to the beginning
   of the section so we begin them at 0. */
/* DWARF 1 */
.debug         0 : { *(.debug) }
.line         0 : { *(.line) }
/* GNU DWARF 1 extensions */
.debug_srcinfo 0 : { *(.debug_srcinfo) }
.debug_sfnames 0 : { *(.debug_sfnames) }
/* DWARF 1.1 and DWARF 2 */
.debug_aranges 0 : { *(.debug_aranges) }
.debug_pubnames 0 : { *(.debug_pubnames) }
/* DWARF 2 */
.debug_info    0 : { *(.debug_info.gnu.linkonce.wi.*) }
.debug_abbrev  0 : { *(.debug_abbrev) }
.debug_line    0 : { *(.debug_line) }
.debug_frame   0 : { *(.debug_frame) }
.debug_str     0 : { *(.debug_str) }
.debug_loc     0 : { *(.debug_loc) }
.debug_macinfo 0 : { *(.debug_macinfo) }
/* SGI/MIPS DWARF 2 extensions */
.debug_weaknames 0 : { *(.debug_weaknames) }
.debug_funcnames 0 : { *(.debug_funcnames) }
.debug_typenames 0 : { *(.debug_typenames) }
.debug_varnames  0 : { *(.debug_varnames) }
.gptab.sdata : { *(.gptab.data) *(.gptab.sdata) }
.gptab.sbss : { *(.gptab.bss) *(.gptab.sbss) }
/DISCARD/ : { *(.note.GNU-stack) }
}

```


Appendix C Example - Profiler Library

C.1 Example program

```
#include <stdarg.h>

extern void abort (void);
extern void exit (int);

void bar (int n, int c)
{
    static int lastn = -1, lastc = -1;

    if (lastn != n)
    {
        if (lastc != lastn)
        abort ();
        lastc = 0;
        lastn = n;
    }

    if (c != (char) (lastc ^ (n << 3)))
        abort ();
    lastc++;
}

#define D(N) typedef struct { char x[N+1]; } A##N;
D(0) D(1) D(2) D(3) D(4) D(5) D(6) D(7)
D(8) D(9) D(10) D(11) D(12) D(13) D(14) D(15)
D(16) D(31) D(32) D(35) D(72)
#undef D

void foo (int size, ...)
{
    #define D(N) A##N a##N;
    D(0) D(1) D(2) D(3) D(4) D(5) D(6) D(7)
    D(8) D(9) D(10) D(11) D(12) D(13) D(14) D(15)
    D(16) D(31) D(32) D(35) D(72)
    #undef D
    va_list ap;
    int i;

    if (size != 21)
        abort ();
    va_start (ap, size);
    #define D(N) \
    a##N = va_arg (ap, typeof (a##N)); \
    for (i = 0; i < N; i++) \
        bar (N, a##N.x[i]);
    D(0) D(1) D(2) D(3) D(4) D(5) D(6) D(7)
    D(8) D(9) D(10) D(11) D(12) D(13) D(14) D(15)
    D(16) D(31) D(32) D(35) D(72)
    #undef D
    va_end (ap);
}
```

```

}

int main (void)
{
#define D(N) A##N a##N;
D(0) D(1) D(2) D(3) D(4) D(5) D(6) D(7)
D(8) D(9) D(10) D(11) D(12) D(13) D(14) D(15)
D(16) D(31) D(32) D(35) D(72)
#undef D
    int i;

#define D(N) \
    for (i = 0; i < N; i++) \
        a##N.x[i] = i ^ (N << 3);
D(0) D(1) D(2) D(3) D(4) D(5) D(6) D(7)
D(8) D(9) D(10) D(11) D(12) D(13) D(14) D(15)
D(16) D(31) D(32) D(35) D(72)
#undef D

    foo (21
#define D(N) , a##N
D(0) D(1) D(2) D(3) D(4) D(5) D(6) D(7)
D(8) D(9) D(10) D(11) D(12) D(13) D(14) D(15)
D(16) D(31) D(32) D(35) D(72)
#undef D
        );
    exit (0);
}

```

C.2 Example C run-time

```

/*
 * Realtek Semiconductor Corp.
 *
 * c.S:
 */
#include <regdef.h>
#include "rlx_library.h"

#define UART_DATA_ADDRESS    0xbc00000c

.set nomips16

.globl _stack_base
_stack_base:
.rept 512*1024
.byte 0
.endr

.balign 16
.globl _stack
_stack:
.rept 8
.long 0
.endr

.data
.globl my_argv
my_argv:
.rept 16
.byte 0
.endr

```

```

.data
.globl my_arg_str
my_arg_str:
.rept 256
.byte 0
.endr

.comm cp3_counter,32

.text

.globl start
.globl _exit

.ent start
start:
    /*
     * init profiler
     */
    la t0, rlx_prof_init
    jalr ra, t0
    nop

    /*
     * set counting mode
     */
    la t0, rlx_prof_set_cp3_ctrl
    li a0, CP3_PERFMODE1
    jalr ra, t0
    nop

    /*
     * start profiler
     */
    la t0, rlx_prof_start
    jalr ra, t0
    nop

    /*
    ** Initialize data.
    */
    la v0, _edata

    /*
    ** Align pointer.
    */
    add v0, 3
    srl v0, 2
    sll v0, 2
    la v1, end
loop0: sw zero, 0x0(v0)
    sw zero, 0x4(v0)
    sw zero, 0x8(v0)
    sw zero, 0xc(v0)
    addu v0, 16
    blt v0, v1, loop0

    /*
    ** Initialize the global data pointer.
    */
    la gp, _gp
    la sp, _stack

    /*

```

```

** Every good C program has a main.
*/
#if defined(__mips16)
jalx main
#else
jal main
#endif
nop
move a0, v0
.end start

.ent _exit
_exit:
/*
 * save current return value
 */
move s0, a0

/*
 * stop profiler
 */
la t0, rlx_prof_stop
jalr ra,t0
nop

/*
 * save profiler output
 */
la t0, rlx_prof_save_result
jalr ra,t0
nop
move a0, s0
syscall 1
.end _exit

/*
** PutC
** Instruction used to perform character output
** from programs running during simulation.
*/
.globl __PutCharacter
.ent __PutCharacter
__PutCharacter:
    li a0, UART_DATA_ADDRESS
    sw a1, 0(a0)
    j ra # Return
.end __PutCharacter

.comm __errno,4

```

C.3 Example makefile

```

#
# Realtek Semiconductor Corp.
#
# RSDK Profiler Library
#
# Tony Wu (tonywu@realtek.com.tw)
# Jul. 07, 2006
#

#####
ARCH = 4180

```

```

PROGRAM = testprof
RSDKDIR = /rsdk/rsdk-1.2.7/linux/newlib

CC = $(RSDKDIR)/bin/rsdk-elf-gcc
LD = $(RSDKDIR)/bin/rsdk-elf-ld

CFLAGS = -march=$(ARCH) -c -G0 -fno-pic -pg -DRLX_UNCACHABLE
IFLAGS = -I$(RSDKDIR)/include
LFLAGS = -Ttext 80000000 -e start -N -n
LIBS = -L$(RSDKDIR)/lib/$(ARCH) -lrlx -lm -lc -lgcc -L. -lrlxsim_gdb

#####
all: $(PROGRAM)

.S.o:
$(CC) -D__ASM__ -x assembler-with-cpp $(CFLAGS) $(IFLAGS) $<

.C.o:
$(CC) $(CFLAGS) $(IFLAGS) $<

testprof: c.o prof.o rlx_prof_int.o
$(LD) -T target-rlxsim.ld -o testprof $(LFLAGS) c.o prof.o rlx_prof_int.o $(LIBS)

clean:
rm -f *.o $(PROGRAM)

```

C.4 Example linker script

```

/* Script for -z combreloc: combine and sort reloc sections */
OUTPUT_FORMAT("elf32-bigmips", "elf32-bigmips", "elf32-littlemips")
OUTPUT_ARCH(mips)
ENTRY(start)

SECTIONS
{
    /* profiler section */
    .rlxprof_text 0xa0200000 : { *(.rlxprof_text) rlx_*.text) }
    .rlxprof_data ALIGN(0x8) : { *(.rlxprof_data) }
    __rlxprof_bss_end = ABSOLUTE(.);
    .rlxprof_bss ALIGN(0x8) (NOLOAD) : { *(.rlxprof_bss) }
    __rlxprof_bss_end = ABSOLUTE(.);

    /* Read-only sections, merged into text segment: */
    PROVIDE (__executable_start = 0x0400000); . = 0x0400000;
    .interp : { *(.interp) }
    .reginfo : { *(.reginfo) }
    .dynamic : { *(.dynamic) }
    .hash : { *(.hash) }
    .dynsym : { *(.dynsym) }
    .dynstr : { *(.dynstr) }
    .gnu.version : { *(.gnu.version) }
    .gnu.version_d : { *(.gnu.version_d) }
    .gnu.version_r : { *(.gnu.version_r) }
    .rel.dyn :
    {
        *(.rel.init)
        *(.rel.text .rel.text.* .rel.gnu.linkonce.t.*)
        *(.rel.fini)
        *(.rel.rodata .rel.rodata.* .rel.gnu.linkonce.r.*)
        *(.rel.data.rel.ro*)
        *(.rel.data .rel.data.* .rel.gnu.linkonce.d.*)
        *(.rel.tdata .rel.tdata.* .rel.gnu.linkonce.td.*)
    }
}

```

```

        *(.rel.tbss .rel.tbss.* .rel.gnu.linkonce.tb.*)
        *(.rel.ctors)
        *(.rel.dtors)
        *(.rel.got)
        *(.rel.sdata .rel.sdata.* .rel.gnu.linkonce.s.*)
        *(.rel.sbss .rel.sbss.* .rel.gnu.linkonce.sb.*)
        *(.rel.sdata2 .rel.sdata2.* .rel.gnu.linkonce.s2.*)
        *(.rel.sbss2 .rel.sbss2.* .rel.gnu.linkonce.sb2.*)
        *(.rel.bss .rel.bss.* .rel.gnu.linkonce.b.*)
    }
.rela.dyn      :
{
    *(.rela.init)
    *(.rela.text .rela.text.* .rela.gnu.linkonce.t.*)
    *(.rela.fini)
    *(.rela.rodata .rela.rodata.* .rela.gnu.linkonce.r.*)
    *(.rela.data .rela.data.* .rela.gnu.linkonce.d.*)
    *(.rela.tdata .rela.tdata.* .rela.gnu.linkonce.td.*)
    *(.rela.tbss .rela.tbss.* .rela.gnu.linkonce.tb.*)
    *(.rela.ctors)
    *(.rela.dtors)
    *(.rela.got)
    *(.rela.sdata .rela.sdata.* .rela.gnu.linkonce.s.*)
    *(.rela.sbss .rela.sbss.* .rela.gnu.linkonce.sb.*)
    *(.rela.sdata2 .rela.sdata2.* .rela.gnu.linkonce.s2.*)
    *(.rela.sbss2 .rela.sbss2.* .rela.gnu.linkonce.sb2.*)
    *(.rela.bss .rela.bss.* .rela.gnu.linkonce.b.*)
}
.rel.plt      : { *(.rel.plt) }
.rela.plt     : { *(.rela.plt) }
.init         :
{
    KEEP (*(init))
} =0
.plt          : { *(.plt) }
.text 0x80000000 :
{
    _ftext = . ;
    *(.text .stub .text.* .gnu.linkonce.t.*)
    KEEP (*(text.*personality*))
    /* .gnu.warning sections are handled specially by elf32.em.  */
    *(.gnu.warning)
    *(.mips16.fn.*) *(.mips16.call.*)
} =0
.fini         :
{
    KEEP (*(fini))
} =0
PROVIDE (__etext = .);
PROVIDE (_etext = .);
PROVIDE (etext = .);
.rodata       : { *(.rodata .rodata.* .gnu.linkonce.r.*) }
.rodata1      : { *(.rodata1) }
.sdata2       : { *(.sdata2 .sdata2.* .gnu.linkonce.s2.*) }
.sbss2        : { *(.sbss2 .sbss2.* .gnu.linkonce.sb2.*) }
.eh_frame_hdr : { *(.eh_frame_hdr) }
.eh_frame     : ONLY_IF_RO { KEEP (*(eh_frame)) }
.gcc_except_table : ONLY_IF_RO { KEEP (*(gcc_except_table)) *(gcc_except_table.*) }
/* Adjust the address for the data segment.  We want to adjust up to
   the same address within the page on the next page up.  */
. = ALIGN (0x40000) - ((0x40000 - .) & (0x40000 - 1)); . =
                                DATA_SEGMENT_ALIGN (0x40000, 0x1000);
/* Exception handling */
.eh_frame     : ONLY_IF_RW { KEEP (*(eh_frame)) }
.gcc_except_table : ONLY_IF_RW { KEEP (*(gcc_except_table)) *(gcc_except_table.*) }

```



```

/* Thread Local Storage sections */
.tdata : { *(.tdata .tdata.* .gnu.linkonce.td.*) }
.tbss : { *(.tbss .tbss.* .gnu.linkonce.tb.*) *(.tcommon) }
/* Ensure the __preinit_array_start label is properly aligned. We
   could instead move the label definition inside the section, but
   the linker would then create the section even if it turns out to
   be empty, which isn't pretty. */
. = ALIGN(32 / 8);
PROVIDE (__preinit_array_start = .);
.preinit_array : { KEEP (*(preinit_array)) }
PROVIDE (__preinit_array_end = .);
PROVIDE (__init_array_start = .);
.init_array : { KEEP (*(init_array)) }
PROVIDE (__init_array_end = .);
PROVIDE (__fini_array_start = .);
.fini_array : { KEEP (*(fini_array)) }
PROVIDE (__fini_array_end = .);
.ctors :
{
    /* gcc uses crtbegin.o to find the start of
       the constructors, so we make sure it is
       first. Because this is a wildcard, it
       doesn't matter if the user does not
       actually link against crtbegin.o; the
       linker won't look for a file to match a
       wildcard. The wildcard also means that it
       doesn't matter which directory crtbegin.o
       is in. */
    KEEP (*crtbegin*.o(.ctors))
    /* We don't want to include the .ctor section from
       from the crtend.o file until after the sorted ctors.
       The .ctor section from the crtend file contains the
       end of ctors marker and it must be last */
    KEEP (*(EXCLUDE_FILE (*crtend*.o) .ctors))
    KEEP (*(SORT(.ctors.*)))
    KEEP (*(.ctors))
}
.dtors :
{
    KEEP (*crtbegin*.o(.dtors))
    KEEP (*(EXCLUDE_FILE (*crtend*.o) .dtors))
    KEEP (*(SORT(.dtors.*)))
    KEEP (*(.dtors))
}
.jcr : { KEEP (*(jcr)) }
.data.rel.ro : { *(.data.rel.ro.local) *(.data.rel.ro*) }
. = DATA_SEGMENT_RELRO_END (0, .);
.data :
{
    _fdata = . ;
    *(.data .data.* .gnu.linkonce.d.*)
    KEEP (*(gnu.linkonce.d.*personality*))
    SORT(CONSTRUCTORS)
}
.data1 : { *(.data1) }
. = .;
_gp = ALIGN(16) + 0x7ff0;
.got : { *(.got.plt) *(.got) }
/* We want the small data sections together, so single-instruction offsets
   can access them all, and initialized data all before uninitialized, so
   we can shorten the on-disk segment size. */
.sdata :
{
    *(.sdata .sdata.* .gnu.linkonce.s.*)
}

```

```

.lit8      : { *(.lit8) }
.lit4      : { *(.lit4) }
_edata = .;
PROVIDE (edata = .);
__bss_start = .;
_fbss = .;
.sbss      :
{
    PROVIDE (__sbss_start = .);
    PROVIDE (___sbss_start = .);
    *(.dynsbss)
    *(.sbss .sbss.* .gnu.linkonce.sb.*)
    *(.scommon)
    PROVIDE (__sbss_end = .);
    PROVIDE (___sbss_end = .);
}
.bss       :
{
    *(.dynbss)
    *(.bss .bss.* .gnu.linkonce.b.*)
    *(COMMON)
    /* Align here to ensure that the .bss section occupies space up to
       _end.  Align after .bss to ensure correct alignment even if the
       .bss section disappears because there are no input sections.  */
    . = ALIGN(32 / 8);
}
    . = ALIGN(32 / 8);
_end = .;
PROVIDE (end = .);
. = DATA_SEGMENT_END (.);
/* Stabs debugging sections.  */
.stab      0 : { *(.stab) }
.stabstr    0 : { *(.stabstr) }
.stab.excl  0 : { *(.stab.excl) }
.stab.exclstr 0 : { *(.stab.exclstr) }
.stab.index 0 : { *(.stab.index) }
.stab.indexstr 0 : { *(.stab.indexstr) }
.comment    0 : { *(.comment) }
/* DWARF debug sections.
   Symbols in the DWARF debugging sections are relative to the beginning
   of the section so we begin them at 0.  */
/* DWARF 1 */
.debug      0 : { *(.debug) }
.line       0 : { *(.line) }
/* GNU DWARF 1 extensions */
.debug_srcinfo 0 : { *(.debug_srcinfo) }
.debug_sfnames 0 : { *(.debug_sfnames) }
/* DWARF 1.1 and DWARF 2 */
.debug_aranges 0 : { *(.debug_aranges) }
.debug_pubnames 0 : { *(.debug_pubnames) }
/* DWARF 2 */
.debug_info   0 : { *(.debug_info .gnu.linkonce.wi.*) }
.debug_abbrev 0 : { *(.debug_abbrev) }
.debug_line   0 : { *(.debug_line) }
.debug_frame  0 : { *(.debug_frame) }
.debug_str     0 : { *(.debug_str) }
.debug_loc     0 : { *(.debug_loc) }
.debug_macinfo 0 : { *(.debug_macinfo) }
/* SGI/MIPS DWARF 2 extensions */
.debug_weaknames 0 : { *(.debug_weaknames) }
.debug_funcnames 0 : { *(.debug_funcnames) }
.debug_typenames 0 : { *(.debug_typenames) }
.debug_varnames 0 : { *(.debug_varnames) }
.gptab.sdata : { *(.gptab.data) *(.gptab.sdata) }
.gptab.sbss : { *(.gptab.bss) *(.gptab.sbss) }

```

```

/DISCARD/ : { *(.note.GNU-stack) }
}

```

C.5 Example interrupt handler

C example

```

/*
 * Copyright (c) 2006, Realtek Semiconductor Corp.
 *
 * rlx_prof_int.c:
 *   Enable/Disable interrupts
 *
 * Zhe Jiang (zhe_jiang@realtek.com.cn)
 * Tony Wu (tonywu@realtek.com.tw)
 *
 * Jul. 19, 2006
 */

#include <rlx_library.h>

#undef printf
int printf(const char *, ...) __attribute__((long_call));

void
rlx_prof_disable_int(void) __attribute__((section(".rlxprof_text")))
{
    /* disable interrupt here */
    printf("to be implemented\n");
}

void
rlx_prof_enable_int(void) __attribute__((section(".rlxprof_text")))
{
    /* enable interrupt here */
    printf("to be implemented\n");
}

```

ASM example

```

/*
 * Copyright (c) 2006, Realtek Semiconductor Corp.
 *
 * rlx_profiler_int.S:
 *   Enable/Disable interrupts
 *
 * Zhe Jiang (zhe_jiang@realtek.com.cn)
 * Tony Wu (tonywu@realtek.com.tw)
 *
 * Jul. 19, 2006
 */

#include <regdef.h>

.globl rlx_prof_disable_int
.section .rlxprof_text
.ent rlx_prof_disable_int
rlx_prof_disable_int:
    .set noreorder
    /* save the status register and disable interrupt */

```

```

        mfc0    t4,$12
        nop
        or     t5,t4,$0
        lui    t6,0xffff
        ori    t6,0xfffc
        and    t4,t4,t6
        mtc0   t4,$12
        nop
        nop
        lui    t7,%hi(old_status_register)
        sw     t5,%lo(old_status_register)(t7)
#if defined(_ROS_)
        /* add this code to stop timer */
        lui    t4,0xbd01
        lw     t4,0x84(t4)
        lui    t5,%hi(profiler_timer_value)
        sw     t4,%lo(profiler_timer_value)(t5)
        lui    t6,0xbd01
        ori    t4,0x202
        sw     t4,0x84(t6)
        jr     $31
        sw     t4,0x84(t6)
#endif
.set reorder
.end _ros_enter_call_back

.globl rlx_prof_enable_int
.section .rlxprof_text
.ent    rlx_prof_enable_int
rlx_prof_enable_int:
        .set    noreorder
        /* restore the status register */
        lui    t5,%hi(old_status_register)
        lw     t5,%lo(old_status_register)(t5)
        lui    t6,%hi(profiler_timer_value)
        lw     t6,%lo(profiler_timer_value)(t6)
        mtc0   t5,$12
        nop
        nop
#if defined(_ROS_)
        /* restore the timer status */
        lui    t7,0xbd01
        jr     $31
        sw     t6,0x84(t7)
#endif
.set    reorder
.end    rlx_prof_eanble_int

```

Appendix D Example - RLX Code Coverage Library

D.1 Example program

```
/*
 * Copyright (c) 2006, Realtek Semiconductor Corp.
 *
 * cov.c:
 *   RLXCOV example program
 *
 * Tony Wu (tonywu@realtek.com.tw)
 * Jul. 26, 2006
 */

#include <stdio.h>
#include "rlx_library.h"

int func1(void)
{
    printf("This is function 1");
    return 0;
}

int func2(void)
{
    printf("This is function 2");
    return 0;
}

int
main(int argc, char **argv)
{
    int n;

    printf("We should do something here\n");

    n = rand();
    if (n%2 == 0) {
        func1();
    } else {
        func2();
    }

    printf("Nah.\n");
    return 0;
}
```

D.2 Example C run-time

```
/*
```

```

* Realtek Semiconductor Corp.
*
* c.S:
*/
#include <regdef.h>
#include "rlx_library.h"

#define PERFMODE1 0x1a121110
#define UART_DATA_ADDRESS    0xbc00000c

.set nomips16

.globl _stack_base
_stack_base:
.rept 512*1024
.byte 0
.endr

.balign 16
.globl _stack
_stack:
.rept 8
.long 0
.endr

.data
.globl my_argv
my_argv:
.rept 16
.byte 0
.endr

.data
.globl my_arg_str
my_arg_str:
.rept 256
.byte 0
.endr

.comm cp3_counter,32

.text

.globl start
.globl _exit

.ent start
start:
/*
 * Initialize COV library
 */
    la t0, rlx_cov_init
    jalr t0
    nop

/*
** Initialize data.
*/
    la v0, _edata
/*
** Align pointer.
*/
    add v0, 3
    srl v0, 2

```

```

sll v0, 2
la v1, end
loop0: sw zero, 0x0(v0)
sw zero, 0x4(v0)
sw zero, 0x8(v0)
sw zero, 0xc(v0)
addu v0, 16
blt v0, v1, loop0

/*
** Initialize the global data pointer.
*/
la gp, _gp
    la sp, _stack

/*
** Every good C program has a main.
*/
#ifdef __mips16
jalx main
#else
jal main
#endif
nop
move a0, v0
.end start

.ent _exit
_exit:
    move s0, a0
    la t0, rlx_cov_exit
    jalr t0
    nop
    move a0, s0
    syscall 1
.end _exit

/*
** PutC
** Instruction used to perform character output
** from programs running during simulation.
*/
.globl __PutCharacter
.ent __PutCharacter
__PutCharacter:
    li a0, UART_DATA_ADDRESS
    sw a1, 0(a0)
    j ra # Return
.end __PutCharacter

.comm __errno,4

```

D.3 Example makefile

```

#
# Realtek Semiconductor Corp.
#
# RSDK RLXCOV Library
#
# Tony Wu (tonywu@realtek.com.tw)
# Jul. 07, 2006
#

```

```

#####
ARCH = 4180
PROGRAM = testcov
RSDKDIR = /rsdk/rsdk-1.2.7/linux/newlib

CC = $(RSDKDIR)/bin/rsdk-elf-gcc
LD = $(RSDKDIR)/bin/rsdk-elf-ld

CFLAGS = -march=$(ARCH) -c -G0 -fno-pic -frelxcov
IFLAGS = -I$(RSDKDIR)/include
LFLAGS = -Ttext 80000000 -e start -N -n
LIBS = -L$(RSDKDIR)/lib/$(ARCH) -lrlx -lm -lc -lgcc -L. -lrlxsim_gdb

#####
all: $(PROGRAM)

.S.o:
$(CC) -D__ASM__ -x assembler-with-cpp $(CFLAGS) $(IFLAGS) $<

.C.o:
$(CC) $(CFLAGS) $(IFLAGS) $<

testcov: c.o cov.o
$(LD) -T target-rlxsim.ld -o testcov $(LFLAGS) c.o cov.o $(LIBS)

clean:
rm -f *.o $(PROGRAM)

```

D.4 Example linker script

```

/* Script for -z combreloc: combine and sort reloc sections */
OUTPUT_FORMAT("elf32-bigmips", "elf32-bigmips", "elf32-littlemips")
OUTPUT_ARCH(mips)
ENTRY(start)

SECTIONS
{
    /* RLX code coverage section */
    __rlxcov_ent = ABSOLUTE(.);
    .rlxcov BLOCK(0x8) : { *(.rlxcov) rlx_*(.text) }
    __rlxcov_end = ABSOLUTE(.);

    /* Read-only sections, merged into text segment: */
    PROVIDE (__executable_start = 0x0400000); . = 0x0400000;
    .interp          : { *(.interp) }
    .reginfo         : { *(.reginfo) }
    .dynamic         : { *(.dynamic) }
    .hash            : { *(.hash) }
    .dynsym          : { *(.dynsym) }
    .dynstr          : { *(.dynstr) }
    .gnu.version     : { *(.gnu.version) }
    .gnu.version_d   : { *(.gnu.version_d) }
    .gnu.version_r   : { *(.gnu.version_r) }
    .rel.dyn         :
    {
        *(.rel.init)
        *(.rel.text .rel.text.* .rel.gnu.linkonce.t.*)
        *(.rel.fini)
        *(.rel.rodata .rel.rodata.* .rel.gnu.linkonce.r.*)
        *(.rel.data.rel.ro*)
        *(.rel.data .rel.data.* .rel.gnu.linkonce.d.*)
        *(.rel.tdata .rel.tdata.* .rel.gnu.linkonce.td.*)
    }
}

```



```

        *(.rel.tbss .rel.tbss.* .rel.gnu.linkonce.tb.*)
        *(.rel.ctors)
        *(.rel.dtors)
        *(.rel.got)
        *(.rel.sdata .rel.sdata.* .rel.gnu.linkonce.s.*)
        *(.rel.sbss .rel.sbss.* .rel.gnu.linkonce.sb.*)
        *(.rel.sdata2 .rel.sdata2.* .rel.gnu.linkonce.s2.*)
        *(.rel.sbss2 .rel.sbss2.* .rel.gnu.linkonce.sb2.*)
        *(.rel.bss .rel.bss.* .rel.gnu.linkonce.b.*)
    }
.rela.dyn      :
{
    *(.rela.init)
    *(.rela.text .rela.text.* .rela.gnu.linkonce.t.*)
    *(.rela.fini)
    *(.rela.rodata .rela.rodata.* .rela.gnu.linkonce.r.*)
    *(.rela.data .rela.data.* .rela.gnu.linkonce.d.*)
    *(.rela.tdata .rela.tdata.* .rela.gnu.linkonce.td.*)
    *(.rela.tbss .rela.tbss.* .rela.gnu.linkonce.tb.*)
    *(.rela.ctors)
    *(.rela.dtors)
    *(.rela.got)
    *(.rela.sdata .rela.sdata.* .rela.gnu.linkonce.s.*)
    *(.rela.sbss .rela.sbss.* .rela.gnu.linkonce.sb.*)
    *(.rela.sdata2 .rela.sdata2.* .rela.gnu.linkonce.s2.*)
    *(.rela.sbss2 .rela.sbss2.* .rela.gnu.linkonce.sb2.*)
    *(.rela.bss .rela.bss.* .rela.gnu.linkonce.b.*)
}
.rel.plt      : { *(.rel.plt) }
.rela.plt     : { *(.rela.plt) }
.init         :
{
    KEEP (*(init))
} =0
.plt          : { *(.plt) }
.text 0x80000000 :
{
    _ftext = . ;
    *(.text .stub .text.* .gnu.linkonce.t.*)
    KEEP (*(text.*personality*))
    /* .gnu.warning sections are handled specially by elf32.em.  */
    *(.gnu.warning)
    *(.mips16.fn.*) *(.mips16.call.*)
} =0
.fini         :
{
    KEEP (*(fini))
} =0
PROVIDE (__etext = .);
PROVIDE (_etext = .);
PROVIDE (etext = .);
.rodata       : { *(.rodata .rodata.* .gnu.linkonce.r.*) }
.rodata1      : { *(.rodata1) }
.sdata2       : { *(.sdata2 .sdata2.* .gnu.linkonce.s2.*) }
.sbss2        : { *(.sbss2 .sbss2.* .gnu.linkonce.sb2.*) }
.eh_frame_hdr : { *(.eh_frame_hdr) }
.eh_frame     : ONLY_IF_RO { KEEP (*(eh_frame)) }
.gcc_except_table : ONLY_IF_RO { KEEP (*(gcc_except_table)) *(gcc_except_table.*) }
/* Adjust the address for the data segment.  We want to adjust up to
   the same address within the page on the next page up.  */
. = ALIGN (0x40000) - ((0x40000 - .) & (0x40000 - 1)); . =
        DATA_SEGMENT_ALIGN (0x40000, 0x1000);
/* Exception handling */
.eh_frame     : ONLY_IF_RW { KEEP (*(eh_frame)) }
.gcc_except_table : ONLY_IF_RW { KEEP (*(gcc_except_table)) *(gcc_except_table.*) }

```

```

/* Thread Local Storage sections */
.tdata : { *(.tdata .tdata.* .gnu.linkonce.td.*) }
.tbss : { *(.tbss .tbss.* .gnu.linkonce.tb.*) *(.tcommon) }
/* Ensure the __preinit_array_start label is properly aligned. We
   could instead move the label definition inside the section, but
   the linker would then create the section even if it turns out to
   be empty, which isn't pretty. */
. = ALIGN(32 / 8);
PROVIDE (__preinit_array_start = .);
.preinit_array : { KEEP (*( .preinit_array)) }
PROVIDE (__preinit_array_end = .);
PROVIDE (__init_array_start = .);
.init_array : { KEEP (*( .init_array)) }
PROVIDE (__init_array_end = .);
PROVIDE (__fini_array_start = .);
.fini_array : { KEEP (*( .fini_array)) }
PROVIDE (__fini_array_end = .);
.ctors :
{
    /* gcc uses crtbegin.o to find the start of
       the constructors, so we make sure it is
       first. Because this is a wildcard, it
       doesn't matter if the user does not
       actually link against crtbegin.o; the
       linker won't look for a file to match a
       wildcard. The wildcard also means that it
       doesn't matter which directory crtbegin.o
       is in. */
    KEEP (*crtbegin*.o(.ctors))
    /* We don't want to include the .ctor section from
       from the crtend.o file until after the sorted ctors.
       The .ctor section from the crtend file contains the
       end of ctors marker and it must be last */
    KEEP (*(EXCLUDE_FILE (*crtend*.o) .ctors))
    KEEP (*(SORT(.ctors.*)))
    KEEP (*(.ctors))
}
.dtors :
{
    KEEP (*crtbegin*.o(.dtors))
    KEEP (*(EXCLUDE_FILE (*crtend*.o) .dtors))
    KEEP (*(SORT(.dtors.*)))
    KEEP (*(.dtors))
}
.jcr : { KEEP (*( .jcr)) }
.data.rel.ro : { *(.data.rel.ro.local) *(.data.rel.ro*) }
. = DATA_SEGMENT_RELRO_END (0, .);
.data :
{
    _fdata = . ;
    *(.data .data.* .gnu.linkonce.d.*)
    KEEP (*( .gnu.linkonce.d.*personality*))
    SORT(CONSTRUCTORS)
}
.data1 : { *(.data1) }
. = .;
_gp = ALIGN(16) + 0x7ff0;
.got : { *(.got.plt) *(.got) }
/* We want the small data sections together, so single-instruction offsets
   can access them all, and initialized data all before uninitialized, so
   we can shorten the on-disk segment size. */
.sdata :
{
    *(.sdata .sdata.* .gnu.linkonce.s.*)
}

```

```

.lit8      : { *(.lit8) }
.lit4      : { *(.lit4) }
_edata = .;
PROVIDE (edata = .);
__bss_start = .;
_fbss = .;
.sbss      :
{
    PROVIDE (__sbss_start = .);
    PROVIDE (___sbss_start = .);
    *(.dynsbss)
    *(.sbss .sbss.* .gnu.linkonce.sb.*)
    *(.scommon)
    PROVIDE (__sbss_end = .);
    PROVIDE (___sbss_end = .);
}
.bss       :
{
    *(.dynbss)
    *(.bss .bss.* .gnu.linkonce.b.*)
    *(COMMON)
    /* Align here to ensure that the .bss section occupies space up to
       _end.  Align after .bss to ensure correct alignment even if the
       .bss section disappears because there are no input sections.  */
    . = ALIGN(32 / 8);
}
    . = ALIGN(32 / 8);
_end = .;
PROVIDE (end = .);
. = DATA_SEGMENT_END (.);
/* Stabs debugging sections.  */
.stab      0 : { *(.stab) }
.stabstr    0 : { *(.stabstr) }
.stab.excl  0 : { *(.stab.excl) }
.stab.exclstr 0 : { *(.stab.exclstr) }
.stab.index 0 : { *(.stab.index) }
.stab.indexstr 0 : { *(.stab.indexstr) }
.comment    0 : { *(.comment) }
/* DWARF debug sections.
   Symbols in the DWARF debugging sections are relative to the beginning
   of the section so we begin them at 0.  */
/* DWARF 1 */
.debug      0 : { *(.debug) }
.line       0 : { *(.line) }
/* GNU DWARF 1 extensions */
.debug_srcinfo 0 : { *(.debug_srcinfo) }
.debug_sfnames 0 : { *(.debug_sfnames) }
/* DWARF 1.1 and DWARF 2 */
.debug_aranges 0 : { *(.debug_aranges) }
.debug_pubnames 0 : { *(.debug_pubnames) }
/* DWARF 2 */
.debug_info   0 : { *(.debug_info .gnu.linkonce.wi.*) }
.debug_abbrev 0 : { *(.debug_abbrev) }
.debug_line   0 : { *(.debug_line) }
.debug_frame  0 : { *(.debug_frame) }
.debug_str     0 : { *(.debug_str) }
.debug_loc     0 : { *(.debug_loc) }
.debug_macinfo 0 : { *(.debug_macinfo) }
/* SGI/MIPS DWARF 2 extensions */
.debug_weaknames 0 : { *(.debug_weaknames) }
.debug_funcnames 0 : { *(.debug_funcnames) }
.debug_typenames 0 : { *(.debug_typenames) }
.debug_varnames 0 : { *(.debug_varnames) }
.gptab.sdata : { *(.gptab.data) *(.gptab.sdata) }
.gptab.sbss : { *(.gptab.bss) *(.gptab.sbss) }

```

```
/DISCARD/ : { *(.note.GNU-stack) }  
}
```