

# Volt32 CPU

Andrew Clark

May 16, 2023

## Table of Contents

<b>Table of Contents</b>	<b>1</b>
<b>Registers, Main Widths, etc.</b>	<b>2</b>
<b>Exceptions</b>	<b>5</b>
<b>Instructions</b>	<b>7</b>
4.1 Group 0 Instructions . . . . .	7
4.2 Group 1 Instructions . . . . .	9
4.3 Group 2 Instructions . . . . .	10
4.4 Group 3 Instructions . . . . .	11
4.5 Group 4 Instructions . . . . .	12
4.6 Group 5 Instructions . . . . .	13
4.7 Group 6 Instructions . . . . .	14
4.8 Group 7 Instructions . . . . .	16
4.9 Group 8 Instructions . . . . .	17
4.10 Group 9 Instructions . . . . .	19
4.11 Group 10 Instructions . . . . .	22
4.12 Group 11 Instructions . . . . .	24
4.13 Group 12 Instructions . . . . .	27

## Registers, Main Widths, etc.

- The machine is an implementation of Line Associative Registers (LARs). Both instruction LARs (ILARs) and data LARs (DLARs) are included in the design. There are a grand total of 128 ILARs and 128 DLARs, but they are split between the LARs owned by the supervisor mode and the LARs owned by the user mode. There are 64 supervisor mode ILARs, 64 supervisor mode DLARs, 64 user mode ILARs, and 64 user mode DLARs.
- Addresses are 32-bit.
- 8 types of integer operations are supported, specifically `u8`, `s8`, `u16`, `s16`, `u32`, `s32`, `u64`, and `s64`.
- The machine boots in supervisor mode. On that note, the processor jumps to address `0x0` whenever it enters supervisor mode.
- ILARs
  - In user mode, ILARs 0 to 63 are referred to as `i0`, `i1`, `i2`, ..., `i61`, `i62`, `ipc`.
  - In supervisor mode, ILARs 64 to 127 are referred to as `i0`, `i1`, `i2`, ..., `i61`, `i62`, `ipc`. Note that supervisor mode ILARs are encoded into instructions without the most significant bit, i.e. supervisor mode `i0` is encoded as `0b000000`.
  - The two ILARs called "`i0`" have all their fields set to zero, and when written to, the contents of the ILAR does not change.
  - The two ILARs called "`ipc`" are the program counters for the two operating modes of the processor.
  - An ILAR's data field is 128 bytes long. It is composed of 32-bit instructions aligned to 32 bits.
  - An ILAR's scalar offset field is  $(7 - 2 = 5)$ -bit due to instructions being 32-bit and the data field being 128 bytes long.
  - The `base_address` field of an ILAR is  $(32 - 6 = 26)$ -bit.
  - An ILAR's tag field is 7-bit because there are 128 total ILARs.
- DLARs
  - In user mode, DLARs 0 to 63 are referred to as `d0`, `d1`, `d2`, ..., `d57`, `d58`, `dt0` (aka `d59`, assembler temporary 0), `dt1` (aka `d60`, assembler temporary 1), `dcp` (aka `d61`, intended to be used as the constant pools pointer), `dfp` (aka `d62`, intended to be used as the frame pointer), `dsp` (aka `d63`, intended to be used as the stack pointer).
  - In supervisor mode, DLARs 64 to 127 are referred to as `d0`, `d1`, `d2`, ..., `d57`, `d58`, `dt0` (aka `d59`, assembler temporary 0), `dt1` (aka `d60`, assembler temporary 1), `dcp` (aka `d61`, intended to be used as the constant pools

pointer), `dfp` (aka `d62`, intended to be used as the frame pointer), `dsp` (aka `d63`, intended to be used as the stack pointer). Note that supervisor mode DLARs are encoded into instructions without the most significant bit, i.e. supervisor mode `d0` is encoded as `0b000000`.

- The two DLARs called "d0" have all their fields set to zero, and when written to, the contents of the particular `d0` DLAR do not change.
- A DLAR's data field is 128 bytes long. It is composed of the scalar data elements of the 128 byte vectors, where the type of the scalar data elements is determined by the type tag field of the DLAR.
- A DLAR's scalar offset field is 7-bit due to the data field being 128 bytes long. However, the address of the scalar data is forcibly aligned to the width of the DLAR's type when used as source operands in instructions that read from the full `address` field of the instruction.
- The base address field of a DLAR is  $(32 - 6 = 26)$ -bit.
- Note that the full address of a scalar located in a DLAR, `dA`, is determined by the following formula: `cat(dA.base_address, dA.scalar_offset)`. For types other than `u8` and `s8`, the
- DLARs can take on the following types (3-bit enum):
  - \* 8-bit, unsigned (`u8`)
  - \* 8-bit, signed (`s8`)
  - \* 16-bit, unsigned (`u16`)
  - \* 16-bit, signed (`s16`)
  - \* 32-bit, unsigned (`u32`)
  - \* 32-bit, signed (`s32`)
  - \* 64-bit, unsigned (`u64`)
  - \* 64-bit, signed (`s64`)
- A DLAR's tag field is 7-bit because there are 128 total DLARs.
- Similarly, a DLAR's reference count field is 7-bit because there are 128 total DLARs.
- A DLAR's dirty field is 1-bit.

- The `ie` register

- "ie" is short for "interrupt enable".
- This register is 1-bit.
- This register is a flag indicating whether or not an interrupt can be serviced. It can be read from/written to using `cpy` instructions.
- The `reti` instruction sets `ie` to `0b1` and returns to user mode from supervisor mode.

- The `xct` register

- ”exception type”
  - This register is 32-bit.
  - This register is set to the numerical value of an exception’s type upon the machine entering supervisor mode. It can be read from/written to using `cpy` instructions.
- The `swiarg0` register
  - This register is 128 bytes long.
  - This register indicates argument 0 to `swi`. In supervisor mode, it can be read from/written to with `cpy` instructions.
- The `swiarg1` register
  - This register is 128 bytes long.
  - This register indicates argument 1 to `swi`. In supervisor mode, it can be read from/written to with `cpy` instructions.
- The `swiarg2` register
  - This register is 128 bytes long.
  - This register indicates argument 2 to `swi`. In supervisor mode, it can be read from/written to with `cpy` instructions.
- The `swiarg3` register
  - This register is 128 bytes long.
  - This register indicates argument 3 to `swi`. In supervisor mode, it can be read from/written to with `cpy` instructions.

## Exceptions

Some instructions may cause an exception to occur, putting the processor in supervisor mode.

The following exceptions may occur during normal execution of a program. `xct` is set to a numerical value representing these upon the processor encountering an exception.

- When `xct == 0x0`: Nothing.
- When `xct == 0x1`: Taking a non-software interrupt (which would also set `ie` to `0b0`).
- When `xct == 0x2`: `swi`.
- When `xct == 0x3`: `reti` when in user mode.
- When `xct == 0x4`: `retx` when in user mode.
- When `xct == 0x5`: Undefined instruction.
- When `xct == 0x6`: Division by zero.
- When `xct == 0x7`: Reserved for future expansion.
  - Note: This value of `xct` might be used for floating point exceptions in a future revision of this document.
- When `xct == 0x8`: `cpy.s` that reads from `ie` in user mode.
- When `xct == 0x9`: `cpy.s` that writes to `ie` in user mode.
- When `xct == 0xa`: `cpy.s` that reads from `xct` in user mode.
- When `xct == 0xb`: `cpy.s` that writes to `xct` in user mode.
- When `xct == 0xc`: `cpy.v` that reads from `swiarg0` when in user mode.
- When `xct == 0xd`: `cpy.v` that writes to `swiarg0` when in user mode.
- When `xct == 0xe`: `cpy.v` that reads from `swiarg1` when in user mode.
- When `xct == 0xf`: `cpy.v` that writes to `swiarg1` when in user mode.
- When `xct == 0x10`: `cpy.v` that reads from `swiarg2` when in user mode.
- When `xct == 0x11`: `cpy.v` that writes to `swiarg2` when in user mode.
- When `xct == 0x12`: `cpy.v` that reads from `swiarg3` when in user mode.
- When `xct == 0x13`: `cpy.v` that writes to `swiarg3` when in user mode.
- When `xct == 0x14`: Instructions that read from supervisor mode ILARs or DLARs when in user mode.

- When `xct == 0x15`: Instructions that write to supervisor mode ILARs or DLARs when in user mode.
- When `xct == 0x16`: When user mode `ipc`'s next destination is not in any ILARs.

## Instructions

### 4.1 Group 0 Instructions

- Encoding 0: 0000 aaaa aabb bbbb cccc cc00 000v oooo
- Encoding 1: 0000 aaaa aabb bbbb cccc ccdd dddd oooo
  - a: DLAR a
  - b: DLAR b or ILAR b
  - c: DLAR c
  - d: DLAR d
  - v:
    - \* when 0b0: scalar operation. The assembly syntax indicating a scalar operation simply adds ".s" to the instruction's name.
    - \* when 0b1: vector operation. The assembly syntax indicating a vector operation simply adds ".v" to the instruction's name.
  - o: Opcode
- Most instructions in this group use Encoding 0. The instructions `div.s` and `div.v` use Encoding 1. These two instructions have opcodes of 0b1110 and 0b1111, respectively, such that bit 0 of the instruction specifies the same information as the v bit does for Encoding 0.
- Instruction List:
  1. `add dA, dB, dC`
  2. `sub dA, dB, dC`
  3. `slt dA, dB, dC`
  4. `mul dA, dB, dC`
  5. `and dA, dB, dC`
  6. `or dA, dB, dC`
  7. `xor dA, dB, dC`
  8. `shl dA, dB, dC`
    - Logical shift left.
    - This instruction casts a temporary copy of dC to the unsigned type that is the same size as dA's type and uses that instead of dC.
  9. `shr dA, dB, dC`
    - Logical shift right if dA is unsigned, or arithmetic shift right if dA is signed.
    - This instruction casts a temporary copy of dC to the unsigned type that is the same size as dA's type and uses that instead of dC.



10. `rol dA, dB, dC`
  - Rotate left.
  - This instruction casts a temporary copy of `dC` to the unsigned type that is the same size as `dA`'s type and uses that instead of `dC`.
11. `ror dA, dB, dC`
  - Rotate right.
  - This instruction casts a temporary copy of `dC` to the unsigned type that is the same size as `dA`'s type and uses that instead of `dC`.
12. `add dA, dB.addr, dC`
  - For `add.s dA, dB.addr, dC`, this instruction uses the value of `cast(dA.type, align(dB.type, dB.addr))` as the second argument of the `add`.
  - For `add.v dA, dB.addr, dC`, this instruction duplicates the value of `cast(dA.type, align(dB.type, dB.addr))` (a scalar) into a temporary (DLAR data's length number of bytes long) vector of element type `dA.type` for the purposes of this calculation.
13. `add dA, iB.addr, dC`
  - For `add.s dA, iB.addr, dC`, this instruction uses the value of `cast(dA.type, align(u32, dB.addr))` as the second argument of the `add`.
  - For `add.v dA, iB.addr, dC`, this instruction duplicates the value of `cast(dA.type, align(u32, iB.addr))` (a scalar) into a temporary (DLAR data's length number of bytes long) vector of element type `dA.type` for the purposes of this calculation.
14. `shl dA, dB.addr, dC`
  - For `shl.s dA, dB.addr, dC`, this instruction uses the value of `cast(dA.type, align(dB.type, dB.addr))` as the second argument of the `shl`.
  - For `shl.v dA, dB.addr, dC`, this instruction duplicates the value of `cast(dA.type, align(dB.type, dB.addr))` (a scalar) into a temporary (DLAR data's length number of bytes long) vector of element type `dA.type` for the purposes of this calculation.
  - This instruction casts a temporary copy of `dC` to the unsigned type that is the same size as `dA`'s type and uses that instead of `dC`.
15. `div.s dA, dB, dC, dD`
  - This instruction writes the quotient into `dA`, and the remainder into `dD`.
16. `div.v dA, dB, dC, dD`
  - This instruction writes the quotient into `dA`, and the remainder into `dD`.

## 4.2 Group 1 Instructions

- Encoding: 0001 aaaa aabb bbbb cccc cc00 0000 0ooo
  - a: DLAR a
  - b: DLAR b
  - c: DLAR c
  - o: Opcode
- Instruction List:
  1. `add.r dA, dB`
    - This instruction casts a temporary copy of dB to the dA's type and performs a sum of all the scalar data elements of the temporary copy of dB, then stores the result in dA's scalar data.
  2. `mul.r dA, dB`
    - This instruction casts a temporary copy of dB to the dA's type and performs a product of all the scalar data elements of the temporary copy of dB, then stores the result in dA's scalar data.
  3. `max.r dA, dB`
    - This instruction casts a temporary copy of dB to the dA's type and finds the scalar data element of the temporary copy of dB that is the maximum, then stores the result in dA's scalar data.
  4. `min.r dA, dB`
    - This instruction casts a temporary copy of dB to the dA's type and finds the scalar data element of the temporary copy of dB that is the minimum, then stores the result in dA's scalar data.
  5. `and.r dA, dB`
    - This instruction casts a temporary copy of dB to the dA's type and performs a bitwise AND reduction of all the scalar data elements of the temporary copy of dB, then stores the result in dA's scalar data.
  6. `or.r dA, dB`
    - This instruction casts a temporary copy of dB to the dA's type and performs a bitwise OR reduction of all the scalar data elements of the temporary copy of dB, then stores the result in dA's scalar data.
  7. `xor.r dA, dB`
    - This instruction casts a temporary copy of dB to the dA's type and performs a bitwise XOR reduction of all the scalar data elements of the temporary copy of dB, then stores the result in dA's scalar data.
  8. *Reserved for future expansion.*

### 4.3 Group 2 Instructions

- Encoding: 0010 aaaa aabb bbbb iiii iiii iiii oooo
  - a: DLAR a
  - b: DLAR b
  - i: `simm12` (sign-extended 12-bit immediate)
  - o: Opcode
- For these instructions, the value of `cast(u32, dB.scalar_data) + cast(s32, simm12)` is used as the address to load from.
- Also, the type `dA` is set to is indicated in the instruction name, with, for example, `ldu8i` setting `dA`'s type to `u8`.
- Instruction List:
  1. `ldu8i dA, dB, simm12`
  2. `lds8i dA, dB, simm12`
  3. `ldu16i dA, dB, simm12`
  4. `lds16i dA, dB, simm12`
  5. `ldu32i dA, dB, simm12`
  6. `lds32i dA, dB, simm12`
  7. `ldu64i dA, dB, simm12`
  8. `lds64i dA, dB, simm12`
  9. *Reserved for future expansion.*
  10. *Reserved for future expansion.*
  11. *Reserved for future expansion.*
  12. *Reserved for future expansion.*
  13. *Reserved for future expansion.*
  14. *Reserved for future expansion.*
  15. *Reserved for future expansion.*
  16. *Reserved for future expansion.*

## 4.4 Group 3 Instructions

- Encoding: 0011 aaaa aabb bbbb iiii iiii iiii oooo
  - a: DLAR a
  - b: DLAR b
  - i: `simm12` (sign-extended 12-bit immediate)
  - o: Opcode
- For these instructions, the value of `cast(u32, align(dB.type, dB.addr)) + cast(s32, simm12)` is used as the address to load from.
- Also, the type `dA` is set to is indicated in the instruction name, with, for example, `ldu8` setting `dA`'s type to `u8`.
- Instruction List:
  1. `ldu8i dA, dB.addr, simm12`
  2. `lds8i dA, dB.addr, simm12`
  3. `ldu16i dA, dB.addr, simm12`
  4. `lds16i dA, dB.addr, simm12`
  5. `ldu32i dA, dB.addr, simm12`
  6. `lds32i dA, dB.addr, simm12`
  7. `ldu64i dA, dB.addr, simm12`
  8. `lds64i dA, dB.addr, simm12`
  9. *Reserved for future expansion.*
  10. *Reserved for future expansion.*
  11. *Reserved for future expansion.*
  12. *Reserved for future expansion.*
  13. *Reserved for future expansion.*
  14. *Reserved for future expansion.*
  15. *Reserved for future expansion.*
  16. *Reserved for future expansion.*

## 4.5 Group 4 Instructions

- Encoding: 0100 aaaa aabb bbbb cccc cc00 0000 oooo
  - a: DLAR a
  - b: DLAR b
  - c: DLAR c
  - o: Opcode
- For these instructions, the value of `cast(u32, dB.scalar_data) + cast(u32, dC.scalar_data)` is used as the address to load from.
- Also, the type `dA` is set to is indicated in the instruction name, with, for example, `ldu8` setting `dA`'s type to `u8`.
- Instruction List:
  1. `ldu8 dA, dB, dC`
  2. `lds8 dA, dB, dC`
  3. `ldu16 dA, dB, dC`
  4. `lds16 dA, dB, dC`
  5. `ldu32 dA, dB, dC`
  6. `lds32 dA, dB, dC`
  7. `ldu64 dA, dB, dC`
  8. `lds64 dA, dB, dC`
  9. *Reserved for future expansion.*
  10. *Reserved for future expansion.*
  11. *Reserved for future expansion.*
  12. *Reserved for future expansion.*
  13. *Reserved for future expansion.*
  14. *Reserved for future expansion.*
  15. *Reserved for future expansion.*
  16. *Reserved for future expansion.*

## 4.6 Group 5 Instructions

- Encoding: 0101 aaaa aabb bbbb iiii iiii iiii oooo
  - a: DLAR a
  - b: DLAR b
  - i: simm12 (sign-extended 12-bit immediate)
  - o: Opcode
- For these instructions, the value of `cast(u32, dB.scalar_data) + cast(s32, simm12)` is used as the address being stored to.
- Also, the type dA is set to is indicated in the instruction name, with, for example, `stu8` setting dA's type to u8.
- Instruction List:
  1. `stu8i dA, dB, simm12`
  2. `sts8i dA, dB, simm12`
  3. `stu16i dA, dB, simm12`
  4. `sts16i dA, dB, simm12`
  5. `stu32i dA, dB, simm12`
  6. `sts32i dA, dB, simm12`
  7. `stu64i dA, dB, simm12`
  8. `sts64i dA, dB, simm12`
  9. *Reserved for future expansion.*
  10. *Reserved for future expansion.*
  11. *Reserved for future expansion.*
  12. *Reserved for future expansion.*
  13. *Reserved for future expansion.*
  14. *Reserved for future expansion.*
  15. *Reserved for future expansion.*
  16. *Reserved for future expansion.*

## 4.7 Group 6 Instructions

- Encoding: 0110 aaaa aabb bbbb 0000 0000 0000 oooo
  - a: DLAR a
  - b: DLAR b
  - o: Opcode
- For these instructions, the dB register's scalar data field is used.
- Instruction List:
  1. dpu8 dA, dB
    - This instruction casts (a temporary copy of) the scalar data of dB to the u8 type. The casted scalar data is then stored into every u8 vector element of dA. The type of dA is then changed to u8.
  2. dps8 dA, dB
    - This instruction casts (a temporary copy of) the scalar data of dB to the s8 type. The casted scalar data is then stored into every s8 vector element of dA. The type of dA is then changed to s8.
  3. dpu16 dA, dB
    - This instruction casts (a temporary copy of) the scalar data of dB to the u16 type. The casted scalar data is then stored into every u16 vector element of dA. The type of dA is then changed to u16.
  4. dps16 dA, dB
    - This instruction casts (a temporary copy of) the scalar data of dB to the s16 type. The casted scalar data is then stored into every s16 vector element of dA. The type of dA is then changed to s16.
  5. dpu32 dA, dB
    - This instruction casts (a temporary copy of) the scalar data of dB to the u32 type. The casted scalar data is then stored into every u32 vector element of dA. The type of dA is then changed to u32.
  6. dps32 dA, dB
    - This instruction casts (a temporary copy of) the scalar data of dB to the s32 type. The casted scalar data is then stored into every s32 vector element of dA. The type of dA is then changed to s32.
  7. dpu64 dA, dB
    - This instruction casts (a temporary copy of) the scalar data of dB to the u64 type. The casted scalar data is then stored into every u64 vector element of dA. The type of dA is then changed to u64.
  8. dps64 dA, dB

- This instruction casts (a temporary copy of) the scalar data of `dB` to the `s64` type. The casted scalar data is then stored into every `s64` vector element of `dA`. The type of `dA` is then changed to `s64`.

9. *Reserved for future expansion.*
10. *Reserved for future expansion.*
11. *Reserved for future expansion.*
12. *Reserved for future expansion.*
13. *Reserved for future expansion.*
14. *Reserved for future expansion.*
15. *Reserved for future expansion.*
16. *Reserved for future expansion.*



## 4.8 Group 7 Instructions

- Encoding 0: 0111 aaaa aabb bbbb cccc cc00 000j jjjo
- Encoding 1: 0111 aaaa aabb bbbb iiii iiii iiij jjjo
  - a: ILAR a
  - b: ILAR b
  - c: DLAR c
  - i: `isimm11` (11-bit immediate, left shifted by 2, then sign-extended)
  - j: `jimm4`, the number of consecutive ILARs past `iA` to fetch into.
  - o: Opcode
- For instructions using Encoding 0, the address to `fetch` from is computed with the following formula: `cast(u32, align(u32, dC.scalar_data))`.
- For instructions using Encoding 1, the address to `fetchi` from is computed with the following formula: `cast(u32, iB.addr) + cast(u32, (isimm11 << 2))`.
- Additionally, this and any other instructions with "fetch" in their names are the only way to fetch instructions from memory (or other ILARs) in this CPU's design. The instruction pipeline only automatically fetches instructions from `ipc`, with straight line code that overflows outside of `ipc` causing `ipc` to set its data field to that of the other ILARs that have the data from the destination. If no ILARs have the data from the destination, an exception is thrown.
- Instruction List:
  1. `fetch iA, iB, dC, jimm4`
    - This instruction uses Encoding 0.
  2. `fetchi iA, iB, isimm11, jimm4`
    - This instruction uses Encoding 1.

## 4.9 Group 8 Instructions

- Encoding: 1000 aaaa aabb bbbb 0iii iijj jjjv oooo
  - a: DLAR a
  - b: ILAR b
  - i: iimm5 (5-bit immediate, left shifted by 2, then zero-extended)
  - j: jimm5 (5-bit immediate, left shifted by 2, then zero-extended)
  - v:
    - \* when 0b0: scalar operation (uses the scalar data of dA). The assembly syntax indicating a scalar operation simply adds ".s" to the instruction's name.
    - \* when 0b1: vector operation (uses the vector data of dA). The assembly syntax indicating a vector operation simply adds ".v" to the instruction's name.
  - o: Opcode
- These instructions use the scalar or vector data field of dA.
- Instruction List:
  1. sel dA, iB, iimm5, jimm5
    - This instruction jumps to iB[iimm5 << 2] if the particular data field of dA is non-zero, otherwise to the address iB[jimm5 << 2].
  2. jz dA, iB, iimm5
    - This instruction jumps to iB[iimm5 << 2] if the particular data field of dA is zero.
  3. jnz dA, iB, iimm5
    - This instruction jumps to iB[iimm5 << 2] if the particular data field of dA is non-zero.
  4. reti dA
    - This instruction returns from an interrupt if dA is non-zero, setting ie to 0b1.
    - This instruction causes an exception if the processor is in user mode.
  5. retx dA
    - This instruction returns from supervisor mode to user mode if dA is non-zero.
    - This instruction causes an exception if the processor is in user mode.
  6. *Reserved for future expansion.*
  7. *Reserved for future expansion.*
  8. *Reserved for future expansion.*

9. *Reserved for future expansion.*
10. *Reserved for future expansion.*
11. *Reserved for future expansion.*
12. *Reserved for future expansion.*
13. *Reserved for future expansion.*
14. *Reserved for future expansion.*
15. *Reserved for future expansion.*
16. *Reserved for future expansion.*

## 4.10 Group 9 Instructions

- Encoding: 1001 aaaa aabb bbbb cccc ccii iiiii Sooo
  - a: ILAR a or DLAR a
  - b: ILAR b or DLAR b
  - c: DLAR c
  - i: imm6 (zero-extended 6-bit immediate), amount of consecutive LARs to use
  - S:
    - \* when 0b0: Destination LARs (the ones starting with iA or dA) or source LARs (the ones starting with iB/dB and, if the instruction uses it, dC) are supervisor mode LARs. An example of the syntax for `getaddrs` in this case is `getaddrs.U`. The “.U” suffix indicates this instruction will have the S bit set to 0b0.
    - \* when 0b1: Destination LARs (the ones starting with iA or dA) or source LARs (the ones starting with iB/dB and, if the instruction uses it, dC) are supervisor mode LARs. An example of the syntax for `getaddrs` in this case is `getaddrs.S`. The “.S” suffix indicates this instruction will have the S bit set to 0b1.
    - \* Note: whether S applies to destination LARs or source LARs is indicated in the description of the instruction.
  - o: Opcode
- Instruction List:
  1. `getaddrs dA, dB, imm6`
    - This instruction uses the S bit to indicate which mode the source DLARs belong to.
    - This instruction grabs the addresses of source DLARs starting with dB and then also the following  $\text{imm6} - 1$  source DLARs. The grabbed addresses are then written into consecutive scalar data elements of destination DLARs (starting with dA and continuing into the following destination DLARs as necessary).
    - When supervisor mode LARs are used for the source(s), this instruction causes an exception if used in user mode.
  2. `getaddrs dA, iB, imm6`
    - This instruction uses the S bit to indicate which mode the source ILARs belong to.
    - This instruction grabs the addresses of source ILARs starting with dB and then also the following  $\text{imm6} - 1$  source DLARs. The grabbed addresses are then written into consecutive scalar data elements of destination DLARs (starting with dA and continuing into the following destination DLARs as necessary).

- When supervisor mode LARs are used for the source(s), this instruction causes an exception if used in user mode.
3. `gettypes dA, dB, imm6`
- This instruction uses the `S` bit to indicate which mode the source DLARs belong to.
  - This instruction grabs the types of source DLARs starting with `dB` and then also the following `imm6 - 1` source DLARs. The grabbed types are then written into consecutive scalar data elements of destination DLARs (starting with `dA` and continuing into the following destination DLARs as necessary).
  - When supervisor mode LARs are used for the source(s), this instruction causes an exception if used in user mode.
4. `ldm dA, dB, dC, imm6`
- This instruction's name is short for "load multiple".
  - This instruction uses the `S` bit to indicate to which mode the destination DLARs belong.
  - This instruction uses addresses stored in the `imm6` scalar data elements of consecutive DLARs (starting with `dB`) and types stored in the `imm6` scalar data elements of consecutive DLARs (starting with `dC`). Multiple loads from memory are performed into the `imm6` destination DLARs (starting with `dA`).
  - When supervisor mode LARs are used for the destination(s), this instruction causes an exception if used in user mode.
5. `fetchm iA, dB, imm6`
- This instruction's name is short for "fetch multiple".
  - This instruction uses the `S` bit to indicate to which mode the destination DLARs belong.
  - This instruction uses addresses stored in the `imm6` scalar data elements of consecutive DLARs (starting with `dB`). Multiple fetches from memory are performed into the `imm6` destination ILARs (starting with `iA`).
  - When supervisor mode LARs are used for the destination(s), this instruction causes an exception if used in user mode.
6. `reload dA, imm6`
- This instruction uses the `S` bit to indicate to which mode the operand DLARs belong.
  - This instruction forcibly re-loads the `imm6` consecutive DLARs, starting with `dA`, from memory. The `dirty` flags of each of these DLARs' shared data elements are cleared.
  - When supervisor mode LARs are used for the operands, this instruction causes an exception if used in user mode.
7. `reload iA, imm6`

- This instruction uses the *S* bit to indicate to which mode the operand DLARs belong.
- This instruction forcibly re-loads the *imm6* consecutive ILARs, starting with *iA*, from memory.
- When supervisor mode LARs are used for the operands, this instruction causes an exception if used in user mode.
- Note: This instruction is potentially useful for self-modifying code.

#### 8. `flush dA, imm6`

- This instruction uses the *S* bit to indicate to which mode the operand DLARs belong.
- This instruction forcibly flushes the *imm6* consecutive DLARs, starting with *dA*, to memory. The *dirty* flags of each of these DLARs' shared data elements are cleared.
- When supervisor mode LARs are used for the operands, this instruction causes an exception if used in user mode.

## 4.11 Group 10 Instructions

- Encoding: 1010 aaaa aabb bbbb cccc ccdd dddd oooo

- a: DLAR a
- b: DLAR b
- c: DLAR c
- d: DLAR d
- o: Opcode

- Instruction List:

1. `cpy.s dA, ie`
  - This instruction copies `ie` to `dA.scalar_data`.
2. `cpy.s ie, dA`
  - This instruction copies `dA.scalar_data` to `ie`.
3. `cpy.s dA, xct`
  - This instruction copies `xct` to `dA.scalar_data`.
4. `cpy.s xct, dA`
  - This instruction copies `dA.scalar_data` to `xct`.
5. `cpy.v dA, swiarg0`
  - This instruction copies `swiarg0` to `dA.vector_data`.
6. `cpy.v swiarg0, dA`
  - This instruction copies `dA.vector_data` to `swiarg0`.
7. `cpy.v dA, swiarg1`
  - This instruction copies `swiarg1` to `dA.vector_data`.
8. `cpy.v swiarg1, dA`
  - This instruction copies `dA.vector_data` to `swiarg1`.
9. `cpy.v dA, swiarg2`
  - This instruction copies `swiarg2` to `dA.vector_data`.
10. `cpy.v swiarg2, dA`
  - This instruction copies `dA.vector_data` to `swiarg2`.
11. `cpy.v dA, swiarg3`
  - This instruction copies `swiarg3` to `dA.vector_data`.
12. `cpy.v swiarg3, dA`
  - This instruction copies `dA.vector_data` to `swiarg3`.
13. `swi dA, dB, dC, dD`
  - This instruction copies `dA.vector_data` to `swiarg0`.

- This instruction copies `dB.vector_data` to `swiarg1`.
  - This instruction copies `dC.vector_data` to `swiarg2`.
  - This instruction copies `dD.vector_data` to `swiarg3`.
  - Lastly, this instruction performs a software interrupt, switching the processor to supervisor mode.
  - Note that this instruction always causes an exception to occur.
14. *Reserved for future expansion.*
  15. *Reserved for future expansion.*
  16. *Reserved for future expansion.*



## 4.12 Group 11 Instructions

- Encoding: 1011 aaaa aabb bbbb cccc cc00 00vo oooo
  - a: DLAR a
  - b: DLAR b
  - c: DLAR c
  - v:
    - \* when 0b0: scalar operation. The assembly syntax indicating a scalar operation simply adds ".s" to the instruction's name.
    - \* when 0b1: vector operation. The assembly syntax indicating a vector operation simply adds ".v" to the instruction's name.
  - o: Opcode
- These instructions perform a read from/write to the IO address calculated by the following formula: `cast(u32, dB.scalar_data) + cast(u32, dC.scalar_data)`.
- When a scalar operation is being performed, only the scalar data of dA is read into from/written out to IO space.
- When a vector operation is being performed, the entire vector data of dA is read into from/written out to IO space.
- Instruction List:
  1. `inu8 dA, dB, dC`
    - This instruction sets the type of dA to u8 before performing anything else of the operation.
    - This instruction reads from IO space and writes to dA.
  2. `ins8 dA, dB, dC`
    - This instruction sets the type of dA to s8 before performing anything else of the operation.
    - This instruction reads from IO space and writes to dA.
  3. `inu16 dA, dB, dC`
    - This instruction sets the type of dA to u16 before performing anything else of the operation.
    - This instruction reads from IO space and writes to dA.
  4. `ins16 dA, dB, dC`
    - This instruction sets the type of dA to s16 before performing anything else of the operation.
    - This instruction reads from IO space and writes to dA.
  5. `inu32 dA, dB, dC`

- This instruction sets the type of dA to u32 before performing anything else of the operation.
  - This instruction reads from IO space and writes to dA.
6. `ins32 dA, dB, dC`
- This instruction sets the type of dA to s32 before performing anything else of the operation.
  - This instruction reads from IO space and writes to dA.
7. `inu64 dA, dB, dC`
- This instruction sets the type of dA to u64 before performing anything else of the operation.
  - This instruction reads from IO space and writes to dA.
8. `ins64 dA, dB, dC`
- This instruction sets the type of dA to s64 before performing anything else of the operation.
  - This instruction reads from IO space and writes to dA.
9. *Reserved for future expansion.*
10. *Reserved for future expansion.*
11. *Reserved for future expansion.*
12. *Reserved for future expansion.*
13. *Reserved for future expansion.*
14. *Reserved for future expansion.*
15. *Reserved for future expansion.*
16. *Reserved for future expansion.*
17. `outu8 dA, dB, dC`
- This instruction sets the type of dA to u8 before performing anything else of the operation.
  - This instruction writes to IO space and reads from dA.
18. `outs8 dA, dB, dC`
- This instruction sets the type of dA to s8 before performing anything else of the operation.
  - This instruction writes to IO space and reads from dA.
19. `outu16 dA, dB, dC`
- This instruction sets the type of dA to u16 before performing anything else of the operation.
  - This instruction writes to IO space and reads from dA.
20. `outs16 dA, dB, dC`
- This instruction sets the type of dA to s16 before performing anything else of the operation.

- This instruction writes to IO space and reads from dA.
- 21. `outu32 dA, dB, dC`
  - This instruction sets the type of dA to u32 before performing anything else of the operation.
  - This instruction writes to IO space and reads from dA.
- 22. `outs32 dA, dB, dC`
  - This instruction sets the type of dA to s32 before performing anything else of the operation.
  - This instruction writes to IO space and reads from dA.
- 23. `outu64 dA, dB, dC`
  - This instruction sets the type of dA to u64 before performing anything else of the operation.
  - This instruction writes to IO space and reads from dA.
- 24. `outs64 dA, dB, dC`
  - This instruction sets the type of dA to s64 before performing anything else of the operation.
  - This instruction writes to IO space and reads from dA.
- 25. *Reserved for future expansion.*
- 26. *Reserved for future expansion.*
- 27. *Reserved for future expansion.*
- 28. *Reserved for future expansion.*
- 29. *Reserved for future expansion.*
- 30. *Reserved for future expansion.*
- 31. *Reserved for future expansion.*
- 32. *Reserved for future expansion.*

### 4.13 Group 12 Instructions

- Encoding: 1100 aaaa aaii iiii iiii iiii iiii iioo
  - a: DLAR a
  - i: simm20: (sign-extended 20-bit immediate)
  - o: Opcode
- Instruction List:
  - `cpyi.s dA, simm20`
    - \* This instruction copies the value of `cast(dA.type, cast(s64, simm20))` to `dA.scalar_data`.
  - `addi.s dA, ipc.addr, simm20`
    - \* This instruction copies the value of `cast(dA.type, ipc.addr) + cast(dA.type, cast(s64, simm20))` to `dA.scalar_data`.
  - *Reserved for future expansion.*
  - *Reserved for future expansion.*