

# SPORK

## Solar Pile Optimization & Report Kit

### User Manual

Version 1.0 | February 2026

# Table of Contents

<b>Table of Contents.....</b>	<b>2</b>
<b>1. Introduction .....</b>	<b>5</b>
Intended Audience .....	5
Recommended Workflow .....	5
<b>2. Project Setup.....</b>	<b>6</b>
Project Information .....	6
TOPL Import.....	6
Save and Load Projects .....	6
<b>3. Soil Profile .....</b>	<b>7</b>
Water Table .....	7
Layer Inputs .....	7
How "Auto" (0) Estimation Works .....	8
SPT Corrections.....	8
Soil Type -- What It Controls.....	9
p-y Curve Model .....	9
Frost Depth Check .....	11
<b>4. Pile Properties.....</b>	<b>11</b>
Section Selection .....	11
Installation and Geometry .....	12
Corrosion Allowance.....	12
Computed Design Properties.....	13
<b>5. Loading .....</b>	<b>13</b>
Design Method .....	13
Per-Pile Loads .....	13
Load Combination Tables .....	14
Optional Calculators .....	15
<b>6. Pile Optimization.....</b>	<b>15</b>
Optimization Settings .....	15
What Is Checked .....	15
Outputs.....	16
<b>7. Axial Capacity.....</b>	<b>16</b>
Analysis Settings .....	16
Calculation Methods.....	16
LRFD Resistance Factors .....	17

Outputs .....	17
<b>8. Lateral Analysis .....</b>	<b>17</b>
Load Inputs .....	17
FDM Lateral Analysis .....	17
Broms Simplified Check .....	18
Service Load Deflection Check .....	18
Minimum Embedment for Lateral Stability .....	18
<b>9. Group Analysis .....</b>	<b>19</b>
Group Configuration .....	19
Axial Group Efficiency .....	19
Lateral Group Effects -- p-Multipliers .....	19
<b>10. FEM Analysis .....</b>	<b>20</b>
Analysis Configuration .....	20
Applied Loads .....	20
Options .....	20
Pushover Settings (if pushover analysis) .....	20
Advanced (OpenSeesPy Only) .....	20
Outputs .....	21
Spring Models .....	21
<b>11. Structural Check .....</b>	<b>21</b>
Unbraced Length and Buckling Parameters .....	21
Applied Loads .....	22
AISC H1-1 Interaction Check .....	22
Outputs .....	22
<b>12. Liquefaction Screening .....</b>	<b>23</b>
Seismic Parameters .....	23
Methodology .....	23
Outputs .....	23
<b>13. Installation QC .....</b>	<b>24</b>
Driven Piles -- Dynamic Formulas .....	24
Helical Piles -- Torque Correlation .....	24
<b>14. Export Report .....</b>	<b>25</b>
Analysis Status .....	25
Report Settings .....	25
Design Limits .....	25
Report Contents .....	25

<b>15. Limitations and Assumptions .....</b>	<b>26</b>
General .....	26
Soil Modeling .....	26
Structural .....	26
Lateral Analysis .....	26
Axial Analysis .....	26
Group Analysis .....	26
Liquefaction .....	27
Installation QC .....	27
<b>16. References.....</b>	<b>27</b>
Design Standards .....	27
Textbooks .....	27
Axial Capacity.....	27
Lateral Load Analysis -- p-y Curves .....	27
Lateral Load -- Broms Method .....	28
Pile Groups.....	28
Liquefaction .....	28
SPT Correlations.....	28
Frost Depth .....	29
Installation QC .....	29
Helical Piles .....	29

## 1. Introduction

SPORK (Solar Pile Optimization & Report Kit) is a web-based engineering tool for designing and analyzing driven, drilled, and helical steel pile foundations for utility-scale solar projects. It performs axial capacity, lateral load (p-y curve), pile group, finite element, structural capacity, liquefaction screening, and installation QC analyses, then exports a professional PDF report.

### Intended Audience

Practicing civil, structural, and geotechnical engineers performing pile foundation design for solar tracker and fixed-tilt racking systems.

### Recommended Workflow

Work through pages sequentially. Each page builds on data entered in prior pages:

1. **Project Setup** -- Enter project info, optionally import a TOPL document
2. **Soil Profile** -- Define soil layers, SPT data, water table, frost depth
3. **Pile Properties** -- Select steel section, embedment, installation method
4. **Loading** -- Enter per-pile loads, review load combinations
5. **Pile Optimization** (*optional*) -- Sweep sections and embedments to find the lightest passing design
6. **Axial Capacity** -- Compute compression and tension capacity
7. **Lateral Analysis** -- Run p-y curve analysis, Broms check, deflection checks
8. **Group Analysis** (*if applicable*) -- Evaluate pile group efficiency
9. **FEM Analysis** (*optional*) -- BNWF finite element model for combined loading
10. **Structural Check** -- AISC 360 combined axial + bending interaction
11. **Liquefaction Screening** (*if seismic zone*) -- SPT-based liquefaction assessment
12. **Installation QC** -- Dynamic formula or torque correlation acceptance criteria
13. **Export Report** -- Generate and download a PDF summary

## 2. Project Setup

Page 01: Project Setup

### Project Information

Field	Description
<b>Project Name</b>	Descriptive name for the project. Used in the PDF report header and JSON filename.
<b>Site Location</b>	City, state, or geographic description. For record-keeping and report identification.
<b>Project Notes</b>	Free-text field for design basis notes, assumptions, or references. Included in the PDF report.

### TOPL Import

SPORK can auto-populate loading data from manufacturer Top-of-Pile-Load (TOPL) documents. TOPL documents specify the unfactored loads that the tracker or racking system delivers to each pile.

Field	Description
<b>Manufacturer</b>	Select the tracker manufacturer: ATI, Nevados, or Nextpower. This determines the parser used.
<b>Upload TOPL Document</b>	Upload the manufacturer's TOPL file. ATI and Nevados use PDF format; Nextpower uses XLSX.
<b>Select Column / Post Type</b>	After parsing, select which pile position (interior post, motor post, end post, etc.) to import loads for. Different positions have different load magnitudes.

After parsing, SPORK displays the extracted loads in an editable table. You can adjust any value before clicking **Apply TOPL Loads to Project**, which populates the Loading page (Page 04).

### Save and Load Projects

Feature	Description
<b>Download Project File</b>	Exports all current session data (soil layers, pile properties, loads, analysis settings) to a JSON file.
<b>Upload Project File</b>	Restores a previously saved project from a JSON file. All session state is overwritten with the file contents.

Project files are backward-compatible: older files missing newer fields (such as p-y model selections) will load correctly with default values.

## 3. Soil Profile

Page 02: Soil Profile

This page defines the subsurface conditions used in all downstream analyses. At minimum, each layer requires a soil type and SPT N-value.

### Water Table

Field	Description
<b>Water table present?</b>	Checkbox. If checked, a depth input appears.
<b>Water table depth (ft)</b>	Depth below ground surface to the groundwater level. Affects effective stress calculations, buoyant unit weights, and liquefaction screening.

When the water table is above a layer's midpoint, that layer is flagged as submerged and its effective unit weight is reduced by the unit weight of water (62.4 pcf).

### Layer Inputs

Each layer is defined by the following fields:

#### Row 1: Depth and Classification

Field	Units	Description
<b>Top Depth</b>	ft	Depth from ground surface to the top of this layer.
<b>Bottom Depth</b>	ft	Depth from ground surface to the bottom of this layer. Must be greater than top depth.
<b>Soil Type</b>	--	Classification of the layer: Sand, Clay, Silt, Gravel, or Organic. See the Soil Type section below for how this affects calculations.

#### Row 2: p-y Curve Model and Description

Field	Description
<b>p-y Curve Model</b>	Selects the lateral soil response model for this layer. Default is "Auto." See the p-y Curve Model section below for all 18 options.
<b>Description</b>	Optional free-text label (e.g., "Brown silty sand, medium dense"). Appears in the layer table and on the soil profile visualization.

#### Row 3: Soil Parameters

Field	Units	Default	Description
<b>SPT N-value</b>	blows/ft	15	Raw Standard Penetration Test blow count from the field boring log. This is the primary input for all auto-estimated parameters.
<b>gamma</b>	pcf	0 (auto)	Total unit weight. Enter 0 to

			auto-estimate from SPT N-value and soil type.
<b>phi</b>	degrees	0 (auto)	Drained friction angle. Enter 0 to auto-estimate from N-value. Only meaningful for granular soils (Sand, Gravel, Silt). Clay layers use phi = 0 (undrained).
<b>c_u</b>	psf	0 (auto)	Undrained shear strength. Enter 0 to auto-estimate from N-value. Only meaningful for cohesive soils (Clay, Silt, Organic). Sand/Gravel layers return c_u = 0.

## How "Auto" (0) Estimation Works

When a parameter is left at zero, SPORK estimates it from the SPT N-value using widely accepted correlations:

### Unit weight (gamma):

Estimated from N<sub>60</sub> using Terzaghi & Peck (1967) ranges, differentiated by soil type and whether the layer is submerged.

### Friction angle (phi):

- Sand/Gravel: Hatanaka & Uchida (1996):  $\phi = \sqrt{20 * N_{60}} + 20$ , capped at 45 degrees
- Silt:  $\phi = 24 + 0.25 * N_{60}$ , capped at 34 degrees
- Clay: Returns 0 (undrained, phi = 0 assumption)

### Undrained shear strength (c\_u):

- Clay/Silt/Organic:  $c_u = 125 * N_{60}$  (psf), after Terzaghi & Peck
- Sand/Gravel: Returns 0 (no undrained strength)

## SPT Corrections

SPORK automatically applies the following corrections to the raw N-value:

Correction	Symbol	Default	Description
Energy ratio	C_E	60%	Hammer energy correction. $N_{60} = N_{spt} * (ER / 60)$
Borehole diameter	C_B	1.0	Correction for borehole size
Rod length	C_R	1.0	Correction for short rod lengths
Sampler correction	C_S	1.0	Correction for liner presence

The displayed values in the layer table:

- $N_{60} = N_{spt} * C_E * C_B * C_R * C_S$
- $(N1)_{60} = N_{60} * C_N$ , where C<sub>N</sub> is the overburden correction factor per Liao & Whitman (1986)



## Soil Type -- What It Controls

The Soil Type classification (Sand, Clay, Silt, Gravel, Organic) is used throughout SPORK in the following ways:

Downstream Use	How Soil Type Affects It
Auto p-y model	Clay/Silt/Organic -> Matlock Soft Clay; Sand/Gravel -> API Sand
Unit weight estimation	Different lookup tables for granular vs. cohesive
Friction angle	Returns 0 for Clay (undrained); estimates from N for Sand/Silt/Gravel
Undrained shear strength	Returns 0 for Sand/Gravel; estimates from N for Clay/Silt/Organic
Axial capacity method	Alpha method (total stress) for cohesive; Beta method (effective stress) for granular
Broms lateral check	Cohesive vs. cohesionless formulation
Subgrade reaction modulus	Different k <sub>h</sub> lookup tables for sand vs. clay
Liquefaction screening	Only evaluates granular layers (Sand, Gravel) below the water table
Profile visualization	Color-coded by soil type

Soil Type is independent of the p-y Curve Model. You must always select a Soil Type for each layer, even if you override the p-y model.

## p-y Curve Model

The p-y Curve Model controls the lateral soil resistance model used during lateral load analysis (Pages 07 and 09). The default "Auto" mode selects the model based on Soil Type. Alternatively, you can select a specific model from the 18 LPILE v2022 formulations.

### Auto Mode (Default)

When set to "Auto":

- Clay, Silt, Organic layers -> **Matlock Soft Clay** (Matlock, 1970)
- Sand, Gravel layers -> **API Sand** (O'Neill & Murchison, 1983)

This is appropriate for most routine solar pile designs.

### Available Models

Model	Typical Soil	Key Reference
Soft Clay (Matlock)	Soft to medium clay	Matlock (1970)
API Soft Clay w/ User J	Soft clay with explicit J factor	API RP 2A
Stiff Clay w/ Free Water (Reese)	Stiff clay above water table or with free water	Reese, Cox & Koop (1975)
Stiff Clay w/o Free Water (Reese)	Stiff clay below water table, no free water	Welch & Reese (1972)
Modified Stiff Clay w/o Free Water	Modified stiff clay with initial modulus	Brown (2002)
Sand (Reese)	Clean sand	Reese, Cox & Koop (1974)
API Sand (O'Neill)	Sand (API/industry standard)	O'Neill & Murchison (1983)
Small Strain Sand	Sand with small-strain stiffness	Hanssen (2015), Hardin & Drnevich (1972)
Liquefied Sand (Rollins)	Fully liquefied sand	Rollins et al. (2005)

Liquefied Sand Hybrid	Partially liquefied sand	Franke & Rollins (2013)
Weak Rock (Reese)	Weak/weathered rock	Reese (1997)
Strong Rock (Vuggy)	Strong rock / vuggy limestone	LPile (Ensoft)
Massive Rock	Competent rock mass	Liang et al. (2009), Hoek-Brown
Piedmont Residual Soil	Residual soils (SE United States)	Simpson & Brown (2006)
Loess	Wind-deposited silt (loess)	Johnson et al. (2006)
Silt (Cemented c-phi)	Cemented silt with both c and phi	LPile Section 3.7
Elastic Subgrade	Linear spring (no ultimate cap)	Winkler model
User-Input p-y	User-defined curve data	--

## When to Change from Auto

Select a specific model when:

- Your geotechnical report recommends a particular p-y formulation
- The soil is stiff clay (the Matlock soft clay model may significantly underpredict stiffness)
- You are designing in rock or cemented soils
- You have small-strain shear modulus data ( $G_{max}$ ) and want a more accurate sand model
- You are evaluating post-liquefaction pile performance
- You want to match results with LPile or similar commercial software

## Model-Specific Parameters

When you select a non-Auto model, additional parameter fields may appear. These fields are model-specific:

Parameter	Units	Models That Use It	Description
epsilon_50	--	All clay models	Strain at 50% of ultimate soil resistance. 0 = auto from $c_u$ . Typical range: 0.004 (stiff) to 0.02 (soft).
J	--	API Soft Clay w/ User J	Matlock empirical constant. 0.25 for shallow, 0.5 for deep (Matlock, 1970).
k (lb/in <sup>3</sup> )	lb/in <sup>3</sup>	Stiff Clay w/ Free Water, Sand (Reese), API Sand, Silt (Cemented)	Initial modulus of subgrade reaction. 0 = auto from soil type.
q_u (psf)	psf	Weak Rock, Strong Rock	Unconfined compressive strength of rock.
E <sub>ir</sub> (psi)	psi	Weak Rock	Initial modulus of the rock mass.
RQD (%)	%	Weak Rock	Rock Quality Designation, used for strength reduction.
k <sub>rm</sub>	--	Weak Rock	Strain wedge factor for the weak rock model.
sigma <sub>ci</sub> (psi)	psi	Massive Rock	Intact rock uniaxial compressive strength (Hoek-Brown criterion).
m <sub>i</sub>	--	Massive Rock	Hoek-Brown material constant (depends on rock type; typical 5-35).
GSI	--	Massive Rock	Geological Strength Index (0-100). Describes rock mass

			quality.
E <sub>rock</sub> (psi)	psi	Massive Rock	Rock mass deformation modulus.
G <sub>max</sub> (psi)	psi	Small Strain Sand	Maximum (small-strain) shear modulus. From resonant column, crosshole, or correlation.
Poisson's ratio	--	Small Strain Sand, Massive Rock	Soil or rock Poisson's ratio.
Void ratio	--	Small Strain Sand	Soil void ratio.
C <sub>u</sub> (uniformity)	--	Small Strain Sand	Coefficient of uniformity (D <sub>60</sub> / D <sub>10</sub> ). Not to be confused with undrained shear strength c <sub>u</sub> .

## Frost Depth Check

Located at the bottom of the Soil Profile page. Verifies that pile embedment extends below the frost line per IBC 1809.5: "The bottom of footings shall extend below the frost line unless otherwise protected."

SPORK requires embedment to exceed the frost depth plus 12 inches.

Field	Description
<b>Frost depth method</b>	Choose from: Regional lookup, Stefan equation, or Manual entry.
<b>US Region</b> *(Regional lookup)*	Approximate frost depths by US region (Southern states, Mid-Atlantic, Midwest, Northern states, Alaska).
<b>Freezing Index</b> *(Stefan equation)*	Cumulative degree-days of freezing. Used in the modified Berggren (Stefan) equation: $d = C * \sqrt{F_I}$ , where C depends on soil type.
<b>Frost depth (in)</b> *(Manual)*	Direct entry of the local frost depth in inches.

### Outputs:

- Frost depth (in and ft)
- Minimum required embedment (ft) = frost depth + 12 in
- Pass/Fail against the current pile embedment from Page 03
- Estimated adfreeze uplift force (if pile perimeter is available)

## 4. Pile Properties

Page 03: Pile Properties

### Section Selection

Field	Description
<b>Steel Section</b>	Dropdown of all available W-shapes and C-shapes in the database. Common solar pile sections include W6x7, W6x9, W6x12, W6x15, W8x10, W8x13, W8x18, etc.

# Bowman

After selecting a section, SPORK displays all section properties: depth, flange width, area, weight (plf), moment of inertia ( $I_x$ ,  $I_y$ ), section modulus ( $S_x$ ,  $S_y$ ), plastic modulus ( $Z_x$ ,  $Z_y$ ), perimeter, and tip area.

## Installation and Geometry

Field	Units	Default	Description
Embedment Depth	ft	10.0	Length of pile below ground surface. This is the primary design variable.
Installation Method	--	driven	How the pile is installed: driven, drilled, or helical. Affects axial capacity reduction factors and Installation QC page behavior.
Pile Head Condition	--	free	Boundary condition at the ground surface for lateral analysis: "free" (rotation allowed, typical for solar) or "fixed" (rotation restrained).
Bending Axis	--	strong	Which axis resists lateral load: "strong" (bending about x-axis, load on flanges) or "weak" (bending about y-axis, load on web). Solar trackers typically load the strong axis.

### Pile head condition guidance:

- **Free head:** Use for most solar pile applications. The pile is embedded in the ground with the tracker torque tube connection above grade providing minimal rotational restraint.
- **Fixed head:** Use when a rigid pile cap or concrete grade beam provides full moment fixity at the ground surface.

## Corrosion Allowance

Optional analysis that reduces section properties to account for steel loss over the design life.

Field	Description
Enable corrosion analysis	Checkbox. When enabled, downstream analyses use the corroded section properties.
Design Life (years)	Project service life. Typical: 25-35 years for solar.
Environment	Exposure condition: Atmospheric (rural), Atmospheric (industrial), Buried (undisturbed), Buried (disturbed), Immersed (fresh water), or Immersed (salt water). Each has a different corrosion rate in mils/year.
Coating	Protective coating: None, Hot-dip galvanized, Epoxy, or Zinc-rich primer. Coatings apply a reduction factor to the base corrosion rate.

SPORK computes the total thickness loss per side over the design life, then reduces flange and web thicknesses to produce a corroded section. A comparison table shows the nominal vs. corroded section properties and percent reductions.

## Computed Design Properties

Displayed at the bottom of the page using the active section (nominal or corroded):

Property	Description
<b>EI</b>	Flexural rigidity (lb-in <sup>2</sup> ) for the selected bending axis.
<b>M<sub>y</sub></b>	Yield moment (kip-in). The moment at which the extreme fiber reaches F <sub>y</sub> .
<b>M<sub>p</sub></b>	Plastic moment (kip-in). The moment when the full cross section has yielded.
<b>F<sub>y</sub></b>	Steel yield strength (default: 50 ksi for A572 Gr 50).

## 5. Loading

Page 04: Loading

### Design Method

Option	Description
<b>LRFD</b>	Load and Resistance Factor Design per ASCE 7-22 Section 2.3. Uses factored loads and resistance factors. This is the recommended method.
<b>ASD</b>	Allowable Stress Design per ASCE 7-22 Section 2.4. Uses unfactored loads with safety factors on resistance.
<b>Both</b>	Generates both LRFD and ASD combination tables for comparison.

### Per-Pile Loads

All loads are entered as unfactored (service-level) values per pile. SPORK generates the factored load combinations automatically.

#### Gravity Loads

Field	Units	Default	Description
<b>Dead load</b>	lbs	400	Self-weight of the tracker/racking, modules, and connections tributary to this pile. Acts as compression (downward).
<b>Live load</b>	lbs	0	Maintenance or access live load per pile. Typically zero for ground-mount solar.
<b>Snow load</b>	lbs	0	Snow load per pile. Enter the total snow force on the tributary area.

#### Wind Loads

Field	Units	Default	Description
<b>Wind downward</b>	lbs	0	Wind-induced downward

			force per pile. Occurs when wind pushes down on the tracker modules (e.g., tilt angle creates downforce).
Wind uplift	lbs	1500	Wind-induced upward force per pile. Typically the largest load on a solar pile. This force acts to pull the pile out of the ground.
Wind lateral	lbs	1500	Horizontal wind force per pile. This is the lateral load that the pile must resist through soil-structure interaction.
Wind moment at ground	ft-lbs	0	Direct moment applied at the ground surface from wind. Enter 0 if the moment is entirely from the lateral load acting at the lever arm height (SPORK computes $H * lever\_arm$ automatically in the analysis).

## Seismic and Geometry

Field	Units	Default	Description
Seismic lateral	lbs	0	Horizontal seismic force per pile.
Seismic vertical	lbs	0	Vertical seismic force per pile (can be up or down).
Seismic moment	ft-lbs	0	Seismic moment at ground per pile.
Lateral load height above ground	ft	4.0	The height above the ground surface where the lateral load (wind or seismic) is applied. Also called the "lever arm" or "eccentricity." The moment at ground = $H * lever\_arm$ . Typical values for solar trackers: 3-6 ft.

## Load Combination Tables

SPORK generates all applicable ASCE 7-22 load combinations. The table displays each combination with:

- **V\_comp**: Factored vertical compression (lbs)
- **V\_tens**: Factored vertical tension/uplift (lbs)
- **H\_lat**: Factored lateral load (lbs)
- **M\_ground**: Factored moment at the ground surface (ft-lbs)

**Key combinations for solar piles (LRFD):**

Combination	Typical Governing Condition
LC1: 1.4D	Maximum gravity (rarely governs)
LC4a: 1.2D + 1.0W(down) + L + 0.5S	Maximum compression with wind

LC4b: $1.2D + 1.0W(\text{up}) + L + 0.5S$	Uplift case
LC6: $0.9D + 1.0W$	<b>Usually governs for solar</b> -- minimum gravity with full wind uplift and lateral

LC6 ( $0.9D + 1.0W$ ) almost always governs solar pile design because dead loads are very light and wind uplift/lateral forces are large relative to gravity.

## Optional Calculators

Three expandable calculators are provided for convenience:

**Wind Pressure Calculator (ASCE 7):** Computes velocity pressure  $q_z = 0.00256 K_z K_{zt} K_d K_e * V^2$  (psf). Inputs: basic wind speed  $V$ , exposure coefficient  $K_z$ , topographic factor  $K_{zt}$ , directionality factor  $K_d$ , and elevation factor  $K_e$ .

**Seismic  $C_s$  Calculator:** Computes base shear coefficient  $C_s = S_{DS} / R$  per ASCE 7 simplified method. Inputs: spectral acceleration  $S_{DS}$  and response modification factor  $R$ .

**Snow Load Calculator:** Computes flat-roof snow load  $p_f = 0.7 C_e C_t I_s p_g$  per ASCE 7 Chapter 7. Inputs: ground snow load  $p_g$ , exposure factor  $C_e$ , thermal factor  $C_t$ , and importance factor  $I_s$ .

## 6. Pile Optimization

*Page 05: Pile Design Optimization*

This page sweeps across multiple steel sections and embedment depths to find the lightest pile design that passes all capacity checks.

**Prerequisites:** Soil layers (Page 02) and loads (Page 04) must be defined.

### Optimization Settings

Field	Description
Section Family	Which group of sections to include in the sweep (e.g., "W6", "W8", "W6+W8").
Min Embedment (ft)	Starting embedment depth for the sweep.
Max Embedment (ft)	Ending embedment depth for the sweep.
Embedment Step (ft)	Increment between embedment depths.
Deflection Limit (in)	Maximum allowable ground-line deflection for the lateral analysis check.

### What Is Checked

For each section-embedment combination, SPORK runs:

- Axial compression check** -- Ultimate compression capacity vs. factored demand ( $DCR \leq 1.0$ )
- Axial tension check** -- Ultimate tension capacity vs. factored uplift ( $DCR \leq 1.0$ )
- Lateral structural check** -- Maximum bending moment vs. yield moment ( $DCR \leq 1.0$ )
- Lateral deflection check** -- Ground-line deflection vs. the specified limit

A combination passes only if all four checks pass.

## Outputs

- **Pass/Fail Heatmap:** A matrix of sections vs. embedment depths. Green = pass, red = fail. The optimal design (lightest passing combination) is annotated.
- **Detailed Results Table:** Every combination with its DCR values and deflection.
- **Apply Optimal Design:** Button to set the optimal section and embedment as the active design for downstream pages.

## 7. Axial Capacity

Page 06: Axial Capacity Analysis

### Analysis Settings

Field	Default	Description
Capacity Method	auto	The method used to compute skin friction. "auto" selects Alpha for cohesive layers and Beta for granular layers. You can force a single method: alpha, beta, or meyerhof.
FS Compression	2.5	Factor of safety for allowable compression capacity (ASD).
FS Tension	3.0	Factor of safety for allowable tension capacity (ASD). Tension FS is higher because tension failure is more sudden and skin friction in uplift may be lower.

### Calculation Methods

**Alpha Method (Total Stress)** -- Used for cohesive soils (Clay, Silt, Organic):

$$Q_s = \sum(\alpha * c_u * \text{perimeter} * \text{delta}_L)$$

Where alpha is the adhesion factor from API RP 2A. Alpha decreases as  $c_u$  increases (alpha = 1.0 for soft clay, ~0.5 for stiff clay, ~0.3 for hard clay).

Reference: API RP 2A; Tomlinson (1957).

**Beta Method (Effective Stress)** -- Used for granular soils (Sand, Gravel):

$$Q_s = \sum(\beta * \sigma_v' * \text{perimeter} * \text{delta}_L)$$

Where  $\beta = K_s \tan(\delta)$ .  $K_s$  is the lateral earth pressure coefficient (depends on OCR and installation method) and  $\delta$  is the soil-pile interface friction angle (typically 0.7  $\phi$  for smooth steel).

Reference: Burland (1973); Meyerhof (1976).

**Meyerhof SPT Method** -- Empirical method directly from SPT N-values:

$$Q_s = \sum(2 * N_{60} * \text{perimeter} * \text{delta}_L) \quad (\text{for sand, in psf})$$

$$Q_b = 400 * N_{60} * A_{\text{tip}} \quad (\text{for sand, in psf})$$

Reference: Meyerhof (1976).

**End Bearing:**

$$Q_b = q_b * A_{\text{tip}}$$

Where  $q_b$  depends on the soil type and method: for sand,  $q_b = N_q \sigma_v'$  (Meyerhof bearing capacity factor); for clay,  $q_b = 9 c_u$ .



## Tension Capacity:

$$Q_{ult\_tension} = 0.75 * Q_s \text{ (skin friction only, reduced)}$$

A 0.75 reduction factor is applied to skin friction for tension because the stress state reversal can reduce interface friction. End bearing does not contribute to tension capacity.

## LRFD Resistance Factors

Condition	phi	Reference
Driven piles, clay (alpha)	0.35	AASHTO LRFD
Driven piles, sand (beta/Nordlund)	0.45	AASHTO LRFD
Driven piles, end bearing	0.40-0.50	AASHTO LRFD
With PDA/CAPWAP verification	0.65	AASHTO LRFD
With static load test	0.75-0.80	AASHTO LRFD
Helical piles	0.40-0.60	ICC-ES

## Outputs

- **Q<sub>s</sub>**: Total skin friction (lbs)
- **Q<sub>b</sub>**: End bearing (lbs)
- **Q<sub>ult</sub> (Compression)**:  $Q_s + Q_b$
- **Q<sub>allow</sub> (Compression)**:  $Q_{ult} / FS_{compression}$
- **Q<sub>ult</sub> (Tension)**:  $0.75 * Q_s$
- **Q<sub>allow</sub> (Tension)**:  $Q_{ult\_tension} / FS_{tension}$
- **phi\*R<sub>n</sub> (LRFD)**: Factored resistance for both compression and tension
- **Layer-by-layer breakdown**: Table showing each layer's contribution to skin friction
- **Cumulative skin friction vs. depth plot**

## 8. Lateral Analysis

Page 07: Lateral Load Analysis

### Load Inputs

Field	Units	Description
Lateral load H	lbs	Horizontal load applied at the ground surface. Defaults to wind lateral from Page 04.
Moment at ground	ft-lbs	Applied moment at ground. Defaults to $H * lever\_arm$ .
Cyclic loading	checkbox	If checked, p-y curves are degraded for cyclic loading. Matlock soft clay uses $0.72 * p_{ult}$ (static) for cyclic. Reese sand uses different coefficients.

### FDM Lateral Analysis

The primary analysis uses a finite difference method (FDM) to solve the beam-on-elastic-foundation equation:

$$EI * d^4y/dz^4 + p(y, z) = 0$$

# Bowman

The pile is discretized into elements. At each depth, p-y curves define the nonlinear relationship between lateral displacement (y) and soil resistance (p). The solver iterates using secant stiffness until convergence (typically 20-50 iterations).

## Outputs:

Result	Units	Description
Ground Deflection	in	Lateral displacement at the ground surface. The primary serviceability criterion.
Max Moment	ft-lbs	Maximum bending moment along the pile length. Occurs below ground.
Depth of M_max	ft	Depth at which the maximum moment occurs.
Depth of Zero Deflection	ft	Depth at which the pile deflection crosses zero. Below this depth, the pile is effectively "anchored."
Structural DCR	--	$M_{max} / M_y$ . Must be $\leq 1.0$ to avoid yielding.

## Plots:

- Deflection, moment, shear, and soil reaction vs. depth (4-panel plot)
- p-y curves at selected depths (showing the nonlinear soil response)

## Broms Simplified Check

A closed-form method for estimating ultimate lateral capacity. Uses the top layer only.

- **Cohesive soils:** Broms (1964a) -- assumes uniform  $c_u$ , evaluates short-pile (soil failure) and long-pile (structural failure) modes.
- **Cohesionless soils:** Broms (1964b) -- assumes linear increase of passive pressure with depth ( $K_p \gamma z$ ).

Outputs:  $H_{ult}$  (ultimate lateral capacity),  $H_{allow}$  ( $= H_{ult} / 2.5$ ), and governing failure mode (short pile vs. long pile).

## Service Load Deflection Check

Verifies that the pile head deflection under unfactored (service-level) loads stays within an acceptable limit.

Field	Default	Description
Wind ASD factor	0.6	Reduction factor on wind lateral load for service conditions. Per ASCE 7 ASD, wind is factored by 0.6.
Service lateral load	$0.6 * \text{wind\_lateral}$	The actual lateral load used for the service check.
Deflection limit	0.50 in	Maximum allowable ground-line deflection. Typical limits: 0.25-1.0 in for solar depending on tracker manufacturer requirements.

## Minimum Embedment for Lateral Stability

Uses Broms method with bisection to find the shortest embedment at which the pile's ultimate lateral capacity meets the required demand.

Field	Default	Description
-------	---------	-------------

Factor of safety for lateral	2.0	Safety factor applied to the required lateral load.
H required	H_applied * FS	The lateral capacity that must be achieved.

## 9. Group Analysis

Page 08: Pile Group Analysis

Evaluates how closely spaced piles interact and reduce each other's capacity.

**Prerequisites:** Soil layers (Page 02). Axial capacity analysis (Page 06) is recommended for accurate group capacity.

### Group Configuration

Field	Units	Default	Description
Number of rows	--	1	Rows of piles in the direction of lateral loading.
Piles per row	--	1	Number of piles in each row, perpendicular to lateral loading.
Center-to-center spacing	in	36	Distance between pile centers. Must be >= 6 in.

The s/d ratio (spacing divided by pile width) is computed and displayed. AASHTO recommends s/d >= 3. At s/d >= 8, group effects are negligible.

### Axial Group Efficiency

**Converse-Labarre Formula:**

$$\eta = 1 - \theta * [(n1 - 1) * n2 + (n2 - 1) * n1] / (90 * n1 * n2)$$

where  $\theta = \arctan(d/s)$  in degrees.

Reference: Converse (1962); widely used in AASHTO and FHWA practice.

**Block Failure:** For cohesive soils, the group is also checked as a single large "block" foundation. The block capacity is the lesser of perimeter shear + base bearing. The governing group capacity is the minimum of the individual (efficiency-reduced) capacity and the block failure capacity.

### Lateral Group Effects -- p-Multipliers

When piles are closely spaced, "shadowing" reduces the lateral resistance of trailing piles. SPORK assigns p-multipliers ( $f_m$ ) by row position per Brown et al. (2001):

Row Position	s/d = 3	s/d = 5	s/d >= 8
Lead row	0.80	0.90	1.00
Second row	0.40	0.60	1.00
Third+ row	0.30	0.50	1.00

The average lateral group efficiency = mean of all  $f_m$  values.

## 10. FEM Analysis

Page 09: FEM Analysis (BNWF)

Advanced finite element model for combined axial and lateral loading using a Beam on Nonlinear Winkler Foundation (BNWF) approach.

### Analysis Configuration

Field	Description
Analysis type	Static (single load step), Pushover Lateral (incremental lateral), or Pushover Axial (incremental axial).
Solver	Auto (uses OpenSeesPy if installed, otherwise Python), Python (always available), or OpenSeesPy (requires installation).

### Applied Loads

Field	Units	Description
Axial load V	lbs	Axial compression (positive) applied at the pile head.
Lateral load H	lbs	Horizontal load at the pile head.
Moment at ground M	ft-lbs	Applied moment at the ground surface.

### Options

Field	Default	Description
Include P-delta effects	Yes	Second-order effects from axial load acting through lateral displacement. Important for long, slender piles under combined loading.
Cyclic loading	From Page 07	Degrades p-y curves for cyclic loading conditions.
Pile type	From Page 03	Affects t-z curve selection (driven vs. drilled).
Head condition	From Page 03	Free or fixed head boundary.

### Pushover Settings (if pushover analysis)

Field	Description
Number of load steps	How many increments to apply between 0 and the maximum load.
Max load multiplier	Maximum load as a multiple of the input load. For example, 3.0 means the pushover goes up to 3x the input load.

### Advanced (OpenSeesPy Only)

Field	Description
Fiber section	Use fiber discretization for nonlinear moment-curvature behavior instead of elastic EI. Captures gradual yielding.

Eigenvalue analysis	Compute natural frequencies and mode shapes of the pile-soil system.
Number of modes	Number of eigenvalues to extract (1-10).

## Outputs

- **Lateral and axial deflections at ground**
- **Maximum moment and its depth**
- **P\_critical (buckling load)** if P-delta is enabled
- **Pile head stiffness matrix** (3x3: axial, lateral, rotational)
- **Depth profiles** (6 plots): lateral deflection, axial deflection, moment, shear, axial force, lateral soil reaction
- **Pushover curve** (load vs. displacement at ground) if pushover analysis
- **Natural frequencies** if eigenvalue analysis
- **t-z curves** (skin friction transfer curves at selected depths)
- **q-z curve** (tip resistance transfer curve)
- **p-y curves** (lateral soil resistance at selected depths)

## Spring Models

The BNWF model uses three types of nonlinear springs:

- **p-y springs (lateral):** Same models as Page 07. Represent lateral soil resistance.
- **t-z springs (axial skin friction):** Represent load transfer along the pile shaft. Use API (1993) formulations: for clay,  $t_{max} = \alpha c_u$ ; for sand,  $t_{max} = \beta \sigma'_v$ .
- **q-z spring (tip bearing):** Represents end bearing. Uses API (1993) tip resistance curve: hyperbolic shape reaching  $q_{ult}$  at approximately 10% of pile diameter displacement.

## 11. Structural Check

*Page 11: AISC 360 Structural Capacity Check*

Evaluates the combined axial compression and bending interaction per AISC 360-22 Chapter H.

### Unbraced Length and Buckling Parameters

Field	Units	Default	Description
Above-grade height	ft	4.0	Height from ground surface to the point of lateral load application. This is the unsupported length above ground.
Effective length factor K	--	2.1	Column buckling effective length factor. K = 2.1 is typical for a cantilever with partial base fixity (common for piles). K = 2.0 is an ideal cantilever.

**Depth of Fixity (D<sub>f</sub>):** Automatically computed from the top soil layer's subgrade reaction modulus. This represents the equivalent fixed point below ground for structural buckling analysis.

- For sand:  $D_f = 1.8 * (EI / n_h)^{0.2}$ , where  $n_h$  = coefficient of subgrade reaction
- For clay:  $D_f = 1.4 * (EI / k_h)^{0.25}$

Reference: Davisson & Robinson (1965).

**Unbraced Length:**  $L_b$  = above-grade height + depth of fixity.

## Applied Loads

Two input modes:

- **From analysis results:** Auto-populates  $M_{ux}$  from the lateral analysis (Page 07) and  $P_u$  from load combinations. Edit as needed.
- **Manual entry:** Enter  $P_u$ ,  $M_{ux}$ , and  $M_{uy}$  directly.

Field	Units	Description
$P_u$	lbs	Factored axial compression.
$M_{ux}$	kip-in	Factored strong-axis bending moment.
$M_{uy}$	kip-in	Factored weak-axis bending moment. Typically 0 for single-axis lateral loading.

## AISC H1-1 Interaction Check

SPORK evaluates the combined axial-flexural interaction using AISC 360-22 Equations H1-1a and H1-1b:

**When  $P_u / (\phi_c * P_n) \geq 0.2$  (Eq. H1-1a):**

$$P_u / (\phi_c * P_n) + (8/9) * [M_{ux} / (\phi_b * M_{nx}) + M_{uy} / (\phi_b * M_{ny})] \leq 1.0$$

**When  $P_u / (\phi_c * P_n) < 0.2$  (Eq. H1-1b):**

$$P_u / (2 * \phi_c * P_n) + M_{ux} / (\phi_b * M_{nx}) + M_{uy} / (\phi_b * M_{ny}) \leq 1.0$$

Where:

- $\phi_c = 0.90$  (compression)
- $\phi_b = 0.90$  (flexure)
- $P_n = F_{cr} * A_g$  (nominal compression capacity, based on flexural buckling with  $KL/r$ )
- $M_{nx} = F_y * Z_x$  (nominal strong-axis moment capacity)
- $M_{ny} = F_y * Z_y$  (nominal weak-axis moment capacity)

Reference: AISC 360-22, Chapter H.

## Outputs

- **Unity Ratio:** The governing interaction value. Must be  $\leq 1.0$  to pass.
- **Equation Used:** H1-1a or H1-1b (depends on axial ratio).
- **$P_u / \phi_c * P_n$ :** Axial demand-to-capacity ratio.
- **$KL/r$ :** Governing slenderness ratio.
- **Interaction Diagram:** Plot of the H1-1a/H1-1b envelope with the demand point marked.
- **Detailed breakdown** of compression and flexural capacities.

## 12. Liquefaction Screening

Page 12: Liquefaction Screening

SPT-based simplified procedure per Boulanger & Idriss (2014) for evaluating whether sandy layers are susceptible to liquefaction during a design earthquake.

### Seismic Parameters

Field	Units	Default	Description
PGA, a_max	g	0.2	Peak ground acceleration at the site. Typically taken as SDS / 2.5 for the design earthquake, or from a site-specific seismic hazard analysis.
Earthquake magnitude M_w	--	7.5	Moment magnitude of the design earthquake. Affects the magnitude scaling factor (MSF).
Default fines content	%	15	Percent passing the No. 200 sieve. Used to adjust the clean-sand CRR curve for fines. Higher fines content generally increases liquefaction resistance.
Maximum screening depth	ft	65	Depth below which liquefaction is not evaluated (typically 65-80 ft for the simplified procedure).

### Methodology

For each granular soil layer below the water table:

18. **Compute CSR** (Cyclic Stress Ratio):

$$CSR = 0.65 * (\sigma_v / \sigma_v') * (a_{max} / g) * r_d / MSF$$

where  $r_d$  is the stress reduction factor (depth-dependent) and MSF is the magnitude scaling factor.

19. **Correct N-value:** Compute (N1)\_60cs (overburden-corrected, energy-corrected, fines-adjusted blow count).

20. **Compute CRR** (Cyclic Resistance Ratio) from the Boulanger & Idriss (2014) CRR curve:

$$CRR = \exp[(N1)_{60cs}/14.1 + ((N1)_{60cs}/126)^2 - ((N1)_{60cs}/23.6)^3 + ((N1)_{60cs}/25.4)^4 - 2.8]$$

21. **Factor of Safety:**

$$FS_{liq} = CRR / CSR$$

FS < 1.0: Liquefiable. FS 1.0-1.3: Marginal. FS > 1.3: Non-liquefiable.

Reference: Boulanger & Idriss (2014), "CPT and SPT Based Liquefaction Triggering Procedures."

### Outputs

- **Summary banner:** Overall assessment (liquefiable layers found, marginal, or all safe)
- **Layer results table:** Depth, soil type, N\_SPT, (N1)\_60, (N1)\_60cs, CSR, CRR, FS, and status for each evaluated layer
- **FS vs. depth plot:** Factor of safety profile with threshold lines at FS = 1.0 and 1.3

Cohesive layers and layers above the water table are reported as "N/A" (not susceptible).

## 13. Installation QC

Page 13: Installation QC

Provides acceptance criteria to verify that piles are achieving the required capacity during installation.

### Driven Piles -- Dynamic Formulas

When the installation method is "driven" (set on Page 03), three dynamic pile driving formulas are evaluated:

Field	Units	Description
Ram weight	lbs	Weight of the hammer ram.
Drop height	ft	Height the ram falls before striking the pile.
Set per blow	in	Pile penetration per hammer blow, measured over the last 10 blows of driving.

#### Methods:

Formula	FS	Description
ENR (Engineering News Record)	6.0	$R_u = (W_r * h * 12) / (s + c)$ . Historically conservative. Not recommended for final design but widely used as a field check.
Gates (1957)	3.0	$R_u = a * \sqrt{E_h} * (b - \log(s))$ . Empirical formula with better statistical correlation than ENR.
FHWA Modified Gates	3.0	$R_u = 1.75 * \sqrt{E_h} * \log(10 * N_b) - 100$ . <b>Generally considered the most reliable</b> of the three formulas. Recommended by FHWA for preliminary capacity assessment.

Reference: FHWA HI-97-013; Hannigan et al. (2016).

### Helical Piles -- Torque Correlation

When the installation method is "helical," the page shows the torque-capacity correlation method.

Field	Units	Description
Shaft size	--	Helical pile shaft size (determines $K_t$ ). Options include standard round shaft and square shaft sizes.
Installation torque	ft-lbs	Measured installation torque at the final depth.
Factor of safety	--	Applied to the torque-predicted ultimate capacity. Typical: 2.0.

#### Method:

$$Q_{ult} = K_t * T$$

Where  $K_t$  is the empirical torque correlation factor (1/ft) that depends on shaft size, and T is the installation torque (ft-lbs).

Reference: Hoyt & Clemence (1989); ICC-ES AC358.



## 14. Export Report

Page 14: Export PDF Report

Generates a professional PDF summarizing all analyses performed in the session.

### Analysis Status

Before generating the report, SPORK displays which analyses have been completed and which were skipped. At minimum, a soil profile and pile section must be defined.

### Report Settings

Field	Description
<b>Project Number</b>	Project identification number for the report header.
<b>Engineer of Record</b>	Name of the responsible engineer.
<b>Report Date</b>	Date printed on the report cover.
<b>Above-grade pile length</b>	Pile reveal height for the configuration diagram.

### Design Limits

Field	Default	Description
<b>Top Deflection Limit</b>	4.0 in	Maximum allowable deflection at the pile top (above grade).
<b>Grade Deflection Limit</b>	1.0 in	Maximum allowable deflection at the ground surface.
<b>Bottom Deflection Limit</b>	0.1 in	Maximum allowable deflection at the pile tip.

### Report Contents

The PDF includes all completed analyses, organized into sections:

1. Project information and design basis
2. Soil profile summary and parameters
3. Pile section properties (nominal and corroded if applicable)
4. TOPL import summary (if used)
5. Load combinations table
6. Optimization results (if run)
7. Axial capacity analysis
8. Lateral analysis results and p-y curves
9. Service deflection check
10. Minimum embedment check
11. BNWF FEM results (if run)
12. Pile group analysis (if run)
13. AISC structural check
14. Frost depth check
15. Liquefaction screening (if run)
16. Installation QC criteria

## 15. Limitations and Assumptions

### General

- SPORK is a design aid and does not replace engineering judgment. All results should be reviewed by a licensed professional engineer before use in construction.
- SPORK does not produce stamped or sealed design documents.
- All analyses use US customary units (lbs, ft, in, psf, psi, ksi).

### Soil Modeling

- Soil layers are assumed horizontal and of uniform properties within each layer.
- SPT-based correlations for gamma, phi, and  $c_u$  are approximate. Site-specific laboratory or field data should be used where available.
- The p-y curve approach models soil as independent springs at each depth (Winkler assumption). It does not capture soil continuity or arching effects between depths.
- Auto-estimated parameters use widely accepted but generalized correlations. Actual soil behavior can vary significantly from these estimates.

### Structural

- Steel sections are assumed to be A572 Grade 50 ( $F_y = 50$  ksi) unless modified.
- Corrosion analysis assumes uniform thickness loss on both sides of flanges and the web.
- The AISC H1-1 check assumes compact sections (no local buckling check).

### Lateral Analysis

- The FDM solver assumes small deflections. For very large deflections, the secant stiffness approach may not capture geometric nonlinearity adequately; use the BNWF FEM analysis (Page 09) with P-delta effects for those cases.
- Cyclic degradation is applied using simplified reduction factors (Matlock 0.72 for soft clay). More rigorous cyclic degradation models are not included.
- The Broms method uses only the top layer for capacity estimation. It is a simplified check and may not be accurate for layered profiles.

### Axial Analysis

- No negative skin friction (downdrag) is computed.
- No setup or relaxation effects are modeled (capacity changes after installation).
- End bearing is based on the layer at the pile tip. Punching through a thin bearing layer into weaker soil is not checked automatically.

### Group Analysis

- The Converse-Labarre formula is an empirical approximation. It may not be appropriate for all group geometries.
- Block failure is only checked for groups with cohesive soil layers.
- p-multipliers are interpolated from published values (Brown et al., 2001) for limited spacing ratios.

## Liquefaction

- The simplified procedure (Boulanger & Idriss, 2014) is a screening tool. It uses magnitude-weighted cyclic stress ratios and empirical CRR curves. Site-specific analysis (effective stress, ground response) may be warranted for high-risk sites.
- Only SPT-based triggering is implemented. CPT-based methods are not included.

## Installation QC

- Dynamic formulas (ENR, Gates, FHWA Modified Gates) are empirical and provide approximate capacity estimates. They should be supplemented with PDA/CAPWAP or static load tests for critical applications.
- Helical torque correlation ( $K_t$  method) assumes the empirical relationship holds for the site soils. Verify with load testing.

## 16. References

### Design Standards

- AISC. (2022). *Specification for Structural Steel Buildings* (ANSI/AISC 360-22). American Institute of Steel Construction, Chicago, IL.
- ASCE. (2022). *Minimum Design Loads and Associated Criteria for Buildings and Other Structures* (ASCE/SEI 7-22). American Society of Civil Engineers, Reston, VA.
- ICC. (2021). *International Building Code* (IBC 2021). International Code Council, Washington, DC.
- AASHTO. (2020). *LRFD Bridge Design Specifications* (9th Ed.). American Association of State Highway and Transportation Officials, Washington, DC.
- API. (2014). *Recommended Practice for Planning, Designing and Constructing Fixed Offshore Platforms -- Working Stress Design* (API RP 2A-WSD, 22nd Ed.). American Petroleum Institute, Washington, DC.

### Textbooks

- Das, B.M. (2011). *Principles of Foundation Engineering* (7th Ed.). Cengage Learning, Stamford, CT.
- Tomlinson, M.J. (2004). *Pile Design and Construction Practice* (4th Ed.). E & FN Spon, London.
- Rajapakse, R. (2016). *Pile Design and Construction Rules of Thumb* (2nd Ed.). Butterworth-Heinemann.

### Axial Capacity

- Tomlinson, M.J. (1957). "The adhesion of piles driven in clay soils." *Proceedings, 4th International Conference on Soil Mechanics and Foundation Engineering*, Vol. 2, pp. 66-71.
- Burland, J.B. (1973). "Shaft friction of piles in clay -- A simple fundamental approach." *Ground Engineering*, 6(3), 30-42.
- Meyerhof, G.G. (1976). "Bearing capacity and settlement of pile foundations." *Journal of the Geotechnical Engineering Division, ASCE*, 102(GT3), 197-228.

### Lateral Load Analysis -- p-y Curves

- Matlock, H. (1970). "Correlations for design of laterally loaded piles in soft clay." *Proceedings, 2nd Offshore Technology Conference*, Houston, TX, OTC 1204, pp. 577-594.
- Reese, L.C., Cox, W.R., and Koop, F.D. (1974). "Analysis of laterally loaded piles in sand." *Proceedings, 6th Offshore Technology Conference*, Houston, TX, OTC 2080, pp. 473-483.
- Reese, L.C., Cox, W.R., and Koop, F.D. (1975). "Field testing and analysis of laterally loaded piles in stiff clay." *Proceedings, 7th Offshore Technology Conference*, Houston, TX, OTC 2312, pp. 671-690.

- Welch, R.C. and Reese, L.C. (1972). "Laterally loaded behavior of drilled shafts." *Research Report 3-5-65-89*, Center for Highway Research, University of Texas at Austin.
- O'Neill, M.W. and Murchison, J.M. (1983). "An evaluation of p-y relationships in sands." *Report to the American Petroleum Institute*, PRAC 82-41-1, University of Houston.
- Rollins, K.M., Gerber, T.M., Lane, J.D., and Ashford, S.A. (2005). "Lateral resistance of a full-scale pile group in liquefied sand." *Journal of Geotechnical and Geoenvironmental Engineering*, ASCE, 131(1), 115-125.
- Franke, B.W. and Rollins, K.M. (2013). "Lateral pile resistance in liquefied soil using the hybrid p-y approach." *Proceedings, GeoCongress 2013*, ASCE, pp. 1-10.
- Reese, L.C. (1997). "Analysis of laterally loaded piles in weak rock." *Journal of Geotechnical and Geoenvironmental Engineering*, ASCE, 123(11), 1010-1017.
- Liang, R., Yang, K., and Nusairat, J. (2009). "p-y criterion for rock mass." *Journal of Geotechnical and Geoenvironmental Engineering*, ASCE, 135(1), 26-36.
- Simpson, M. and Brown, D.A. (2006). *Development of p-y curves for Piedmont residual soils*. Highway Research Center, Auburn University.
- Johnson, J.T., Brown, D.A., and Reese, L.C. (2006). *Behavior of laterally loaded drilled shafts in loess*. Highway Research Center, Auburn University.
- Brown, D.A. (2002). "Effect of construction on laterally loaded piles in cohesive soils." *Proceedings, International Deep Foundations Congress*, ASCE, GSP 116, pp. 774-788.
- Hardin, B.O. and Drnevich, V.P. (1972). "Shear modulus and damping in soils: measurement and parameter effects." *Journal of Soil Mechanics and Foundations Division*, ASCE, 98(SM6), 603-624.
- Ensoft, Inc. (2022). *LPile v2022 Technical Manual*. Ensoft, Inc., Austin, TX.

## Lateral Load -- Broms Method

- Broms, B.B. (1964a). "Lateral resistance of piles in cohesive soils." *Journal of Soil Mechanics and Foundations Division*, ASCE, 90(SM2), 27-63.
- Broms, B.B. (1964b). "Lateral resistance of piles in cohesionless soils." *Journal of Soil Mechanics and Foundations Division*, ASCE, 90(SM3), 123-156.
- Davisson, M.T. and Robinson, K.E. (1965). "Bending and buckling of partially embedded piles." *Proceedings, 6th International Conference on Soil Mechanics and Foundation Engineering*, Vol. 2, pp. 243-246.

## Pile Groups

- Converse, F.J. (1962). "Foundations subjected to dynamic forces." *Foundation Engineering* (ed. G.A. Leonards), McGraw-Hill, New York.
- Brown, D.A., Morrison, C., and Reese, L.C. (2001). "Lateral load behavior of pile group in sand." *Journal of Geotechnical and Geoenvironmental Engineering*, ASCE, 114(11), 1261-1276.

## Liquefaction

- Boulanger, R.W. and Idriss, I.M. (2014). "CPT and SPT based liquefaction triggering procedures." *Report No. UCD/CGM-14/01*, Center for Geotechnical Modeling, University of California, Davis.
- Liao, S.S.C. and Whitman, R.V. (1986). "Overburden correction factors for SPT in sand." *Journal of Geotechnical Engineering*, ASCE, 112(3), 373-377.

## SPT Correlations

- Hatanaka, M. and Uchida, A. (1996). "Empirical correlation between penetration resistance and internal friction angle of sandy soils." *Soils and Foundations*, 36(4), 1-9.
- Terzaghi, K. and Peck, R.B. (1967). *Soil Mechanics in Engineering Practice* (2nd Ed.). John Wiley & Sons, New York.

## Frost Depth

- Modified Berggren (Stefan) equation as implemented in U.S. Army Corps of Engineers frost depth procedures.

## Installation QC

- Hannigan, P.J., Rausche, F., Likins, G.E., Robinson, B.R., and Becker, M.L. (2016). *Design and Construction of Driven Pile Foundations* (FHWA-NHI-16-009). Federal Highway Administration, Washington, DC.
- Gates, M. (1957). "Empirical formula for predicting pile bearing capacity." *Civil Engineering*, ASCE, 27(3), 65-66.
- Hoyt, R.M. and Clemence, S.P. (1989). "Uplift capacity of helical anchors in soil." *Proceedings, 12th International Conference on Soil Mechanics and Foundation Engineering*, Vol. 2, pp. 1019-1022.

## Helical Piles

- ICC-ES. (2017). *Acceptance Criteria for Helical Foundation Systems and Devices* (AC358). ICC Evaluation Service, Brea, CA.