

Open Source Rover Rocker-Bogie Assembly Instructions



Contents

1	3D printing	2
2	Machining/Fabrication	2
	2.1 Shaft Coupler cuts	2
3	Mechanical/Structural Assembly	3

1 3D printing

The first thing to do is get the 3D printed encoder mounts. The STL files for this are located in the Corner Steering Assembly folder, under 3D Printed Parts. If you do not have a 3D printer there are many online 3D printing services available, one such is:

• https://www.makexyz.com

To order these parts from Makexyz upload the STL file, select FDM under process, and PLA for Material, and then your desired color. You will need 4 total of these pieces.

2 Machining/Fabrication


2.1 Shaft Coupler cuts

Parts/Tools Necessary

Item	Ref	Qty	Image	Item	Ref	Qty	Image
0.25 Inch - 4mm Shaft Coupler	S23	4		Metal Hacksaw or Bandsaw	N/A	N/A	
Vice Clamp or C clamps	N/A	N/A					

Shaft couplers are used to attach the motor shaft to another shaft, in this particular instance it attaches the corner steering motor to a 0.25 in shaft. This system must hold at least the

max torque that the corner system can see so that the shafts don't slip and free spin, however there is too much material in these couplers to allow them to deform and fully grab around the two shafts. There is another cut made horizontally in the couplers, which de-couples the clamping done by each screw, allowing you to grab on each shaft independently and reduce slippage.






Figure 1: Cutting the Shaft couplers

Using a Clamp or Vice similar to the clamping hub align the cutting blade with the channel in the shaft couplers **S23**. Use the drawings in 1 to determine how deep to go with the cut.


3 Mechanical/Structural Assembly

The Corner Steering assembly is what contains the steering motor and allows the rover to perform Ackerman steering. An important aspect of this assembly is the use of the bearing blocks. They are used to react moments against the shaft, allowing you to decouple the motor shaft from these forces that could damage the motor/gearbox. The lever arm for the corner system is much farther away then at the drive motors, where we get away with attaching the load path directly into the motor shaft.

		,						
Item	Ref	Qty	Image	Item	Ref	Qty	Image	
3 Inch Channel	S2	4		Gearmotor w/o Encoder	E6	4	The state of the s	
Motor Mount F	S9	4	1474	Absolute Encoder	E7	4		
0.25 Pillow Bearing Block	S10	8		#6-32 x ¼ Spacer	T1	16		
0.25 Inch D-Shaft	S15	4		#6-32 x ¾ Threaded Standoff	Т3	16		
0.25 Inch - 4mm Shaft Coupler	S23A	4		6-32 x ¼ Button Head Screw	B1	24		
16 Tooth Set Screw Gear	S27	4		6-32 x ¾ Button head Screw	B5	16		
3D Printed Encoder Mount	S31	4		7/64 Allen Key	N/A	1		

Parts/Tools Necessary

 Motor Mount: Begin by mounting the motor E6 to the 3 inch channel S2 using the motor mount F S9 and screws B1 as shown.






Figure 2: Corner Steering Step 1

2. Shaft Coupler/Standoffs Attachment: Using the shaft coupler (S23) attach the motor shaft to the 0.25 inch D-shaft (S15). Also take the 0.75inch long standoffs (T5)

and attach to the bottom of the channel centered around the motor using screws (B1)





Figure 3: Corner Steering Step 2

3. Encoder Mount: Press the 0.25inch Spacers T1 into the 3D printed encoder mount S31. If they do not fit you can drill or file out the holes slightly until they do press fit in. The size/tolerance of the holes will change based on different 3D printers/materials. Then using screws B5 and 0.25 inch pillow bearing blocks S10 attach the encoder mount/bearings to the threaded standoffs T3.







Figure 4: Corner Steering Step 3

4. Encoder: Attach the encoder E7 to the encoder mount S31, and then attach the 12T gear S27 to the encoder shaft. We will worry about it's exact placement later on. This concludes building one Corner Steering assembly. Unlike all the previous assemblies however this assembly isn't identical for all of them. You will need to build two versions where the encoder mount is mirrored about the motor shaft, see picture below for example. Repeat these steps to build the 4 corner steering assemblies.






Figure 5: Corner Steering Step 4