

## 3.5.1 AC-L1 pin-out for basic TRACTION application

K1 connector pin-out for AC-L1 : basic TRACTION application		
Pin	Name	Function
1	KEY SWITCH IN	Positive supply of the control section of the AC-L1
2	DIGITAL IN 1	Seat switch
3	DIGITAL IN 2	Reverse direction
4	DIGITAL IN 3	Forward direction
5	DIGITAL IN 4	Throttle inhibit
6	DIGITAL IN 5	Pedal Brake
7	DIGITAL IN 6	Parking Brake
8	DIGITAL OUT 1	-
9	COIL RETURN	Positive common
10	RS-232 RX	Serial port
11	RS-232 TX	Serial port
12	DIGITAL IN 7	-
13	DIGITAL IN 8	-
14	LIN IN/OUT	LIN display connection
15	CAN-H	CAN H (No internal termination resistor)
16	DRIVER OUT 1	EM brake
17	DRIVER OUT 2	Main contactor command
18	I/O GROUND	Negative logic supply
19	DIGITAL OUT 2	-
20	DRIVER OUT 3 (*)	-
21	+12V OUT	12V supply
22	CAN GROUND	CAN- bus negative supply
23	CAN-L	CAN L (No internal termination resistor)

(\*) If an inductive load is connected to the driver output 3 (K1-20), there is the necessity to add an external freewheeling diode anti-parallel connected as described in the wiring diagrams.

Driver output 3 (K1-20) must be connected to the +B or to another supply source with the negative reference connected to the -B.

Driver out 1 (K1-16) and driver out 2 (K1-17) must be connected to the COIL RETURN.