

# **CLOCK GENERATOR VVC** – Quick Reference

For general information see UVVM Essential Mechanisms located in uvvm vvc framework/doc.

#### start\_clock (VVCT, vvc\_instance\_idx, msg, [scope])

Example: start\_clock(CLOCK\_GENERATOR\_VVCT, 1, "Start clock generator");

# VVC

#### stop\_clock (VVCT, vvc\_instance\_idx, msg, [scope])

**Example**: stop\_clock(CLOCK\_GENERATOR\_VVCT, 1, "Stop clock generator");

clock\_generator\_vvc.vhd

#### set\_clock\_period (VVCT, vvc\_instance\_idx, clock\_period, msg, [scope])

Example: set clock period(CLOCK GENERATOR VVCT, 1, 10 ns, "Change clock period to 10 ns");

#### set\_clock\_high\_time(VVCT, vvc\_instance\_idx, clock\_high\_time, msg, [scope])

Example: set\_clock\_high\_time(CLOCK\_GENERATOR\_VVCT, 1, 5 ns , "Change duty cycle to 50%");

## CLOCK GENERATOR VVC Configuration record 'vvc config' -- accessible via

| Sharea_clock_generator_vvc_comig      |                   |   |  |
|---------------------------------------|-------------------|---|--|
| Record element                        | Type              | C_CLOCK_GENERATOR_VVC_CONFIG_DEFAULT      |  |
| inter_bfm_delay                       | t_inter_bfm_delay | C_CLOCK_GENERATOR_INTER_BFM_DELAY_DEFAULT |  |
| cmd_queue_count_max                   | natural           | C_CMD_QUEUE_COUNT_MAX                     |  |
| cmd_queue_count_threshold             | natural           | C_CMD_QUEUE_COUNT_THRESHOLD               |  |
| cmd_queue_count_threshold_severity    | t_alert_level     | C_CMD_QUEUE_COUNT_THRESHOLD_SEVERITY      |  |
| result_queue_count_max                | natural           | C_RESULT_QUEUE_COUNT_MAX                  |  |
| result_queue_count_threshold          | natural           | C_RESULT_QUEUE_COUNT_THRESHOLD            |  |
| result_queue_count_threshold_severity | t_alert_level     | C_RESULT_QUEUE_COUNT_THERSHOLD_SEVERITY   |  |
| bfm_config                            | t_bfm_config      | C_CLOCK_GENERATOR_CONFIG_DEFAULT          |  |
| msg_id_panel                          | t_msg_id_panel    | C_VVC_MSG_ID_PANEL_DEFAULT                |  |

# Clock Generator VVC Status record signal 'vvc\_status' -- accessible via shared clock generator vvc status

| Record element   | Туре    |
|------------------|---------|
| current_cmd_idx  | natural |
| previous_cmd_idx | natural |
| pending cmd cnt  | natural |

shared clock generator vvc config

## Common VVC procedures applicable for this VVC

- See UVVM Methods QuickRef for details.

await\_completion()

enable\_log\_msg()

disable\_log\_msg()

fetch\_result()

flush\_command\_queue()

terminate\_current\_command()

terminate\_all\_commands()

insert\_delay()

get\_last\_received\_cmd\_idx()



Copyright © 2017 by Bitvis AS. All rights reserved.



## VVC target parameters

| Name             | Туре                | Example(s)           | Description  |
|------------------|---------------------|----------------------|--|
| VVCT             | t_vvc_target_record | CLOCK_GENERATOR_VVCT | VVC target type compiled into each VVC in order to differentiate between VVCs. |
| vvc_instance_idx | integer             | 1                    | Instance number of the VVC   |

## VVC functional parameters

| Name            | Туре   | Example(s)            | Description   |
|-----------------|--------|-----------------------|---|
| clock_period    | time   | 10 ns                 | Clock period  |
| clock_high_time | time   | 5 ns                  | Time of the clock cycle that is '1'. Value have to be less than clock_period. |
| msg             | string | "Read from DUT"       | A custom message to be appended in the log/alert                              |
| scope           | string | "CLOCK GENERATOR VVC" | A string describing the scope from which the log/alert originates.            |

## VVC entity signals

| Name | Туре      | Direction | Description      |
|------|-----------|-----------|------------------|
| clk  | std_logic | Output    | VVC Clock signal |

## VVC entity generic constants

| Name                                     | Туре          | Default                          | Description  |
|--|---------------|----------------------------------|--|
| GC_INSTANCE_IDX                          | natural       | 1                                | Instance number to assign the VVC                                    |
| GC_CLOCK_GENERATOR_CONFIG                | t_bfm_config  | C_CLOCK_GENERATOR_CONFIG_DEFAULT | Configuration for the Clock Generator.                               |
| GC_CMD_QUEUE_COUNT_MAX                   | natural       | 1000                             | Absolute maximum number of commands in the VVC command               |
|  |               |                                  | queue  |
| GC_CMD_QUEUE_COUNT_THRESHOLD             | natural       | 950                              | An alert will be generated when reaching this threshold to indicate  |
|  |               |                                  | that the command queue is almost full. The queue will still accept   |
|  |               |                                  | new commands until it reaches C_CMD_QUEUE_COUNT_MAX.                 |
| GC_CMD_QUEUE_COUNT_THRESHOLD_SEVERITY    | t_alert_level | WARNING                          | Alert severity which will be used when command queue reaches         |
|  |               |                                  | GC_CMD_QUEUE_COUNT_THRESHOLD.  |
| GC_RESULT_QUEUE_COUNT_MAX                | natural       | 1000                             | Maximum number of unfetched results before result_queue is full.     |
| GC_RESULT_QUEUE_COUNT_THRESHOLD          | natural       | 950                              | An alert with severity 'result_queue_count_threshold_severity' will  |
|  |               |                                  | be issued if result queue exceeds this count. Used for early         |
|  |               |                                  | warning if result queue is almost full. Will be ignored if set to 0. |
| GC_RESULT_QUEUE_COUNT_THRESHOLD_SEVERITY | t_alert_level | WARNING                          | Severity of alert to be initiated if exceeding                       |
|  |               |                                  | result_queue_count_threshold   |



# VVC details

All VVC procedures are defined in vvc\_methods\_pkg (dedicated this VVC), and uvvm\_vvc\_framework.td\_vvc\_framework\_common\_methods\_pkg (common VVC procedures) It is also possible to send a multicast to all instances of a VVC with ALL\_INSTANCES as parameter for vvc\_instance\_idx.

Note: Every procedure here can be called without the optional parameters enclosed in [].

## 1 VVC procedure details and examples

| Described in          |  |
|-----------------------|--|
| Procedure             | Description  |
| start_clock()         | start_clock(VVCT, vvc_instance_idx, msg, [scope])  |
|                       | This procedure adds a start_clock command to the Clock Generator VVCs executor queue, which will run as soon as all preceding commands have completed. When the start_clock command is scheduled to run, the executor activates the clock generator process in the VVC.  |
|                       | <pre>Example:     start_clock(CLOCK_GENERATOR_VVCT, 1, "Start clock generator", C_SCOPE);</pre>  |
| stop_clock()          | stop_clock (VVCT, vvc_instance_idx, msg, [scope])  |
|                       | This procedure adds a stop_clock command to the Clock Generator VVCs executor queue, which will run as soon as all preceding commands have completed. When the stop_clock command is scheduled to run, the executor deactivates the clock generator process in the VVC after finishing current clock cycle.    |
|                       | <pre>Example:     stop_clock(CLOCK_GENERATOR_VVCT, 1 "Stop clock generator", C_SCOPE);</pre>   |
| set_clock_period()    | set_clock_period (VVCT, vvc_instance_idx, clock_period, msg, [scope])  |
|                       | This procedure adds a set_clock_period command to the CLOCK GENERATOR VVCs executor queue, which will run as soon as all preceding commands have completed. When the set_clock_period command is scheduled to run, the executor will change the clock period instantly.  |
|                       | <pre>Examples:     set_clock_period(CLOCK_GENERATOR_VVCT, 1, 10 ns, "Change clock period to 10 ns", C_SCOPE);</pre>  |
| set_clock_high_time() | set_clock_high_time (VVCT, vvc_instance_idx, clock_high_time, msg, [scope])  |
|                       | This procedure adds a set_clock_high_time command to the CLOCK_GENERATOR VVCs executor queue, which will run as soon as all preceding commands have completed. When the write command is scheduled to run, the executor changes the clock high time and the change will take effect from the next rising edge. |
|                       | <pre>Examples:     set_clock_high_time(CLOCK_GENERATOR_VVCT, 1, 6 ns, "Changing the duty cycle to 60%", C_SCOPE);</pre>  |



## 2 VVC Configuration

| Record element                        | Туре              | C_CLOCK_GENERATOR_CONFIG_DEFAULT          | Description   |
|---------------------------------------|-------------------|---|---|
| inter_bfm_delay                       | t_inter_bfm_delay | C_CLOCK_GENERATOR_INTER_BFM_DELAY_DEFAULT | Delay between any requested BFM accesses towards the DUT.                         |
|                                       |                   |   | <ul> <li>TIME_START2START: Time from a BFM start to the next BFM start</li> </ul> |
|                                       |                   |   | (A TB_WARNING will be issued if access takes                                      |
|                                       |                   |   | longer than TIME_START2START).  |
|                                       |                   |   | <ul> <li>TIME_FINISH2START: Time from a BFM end to the next BFM start.</li> </ul> |
|                                       |                   |   | Any insert_delay() command will add to the above minimum delays,                  |
|                                       |                   |   | giving for instance the ability to skew the BFM starting time.                    |
| cmd_queue_count_max                   | natural           | C_CMD_QUEUE_COUNT_MAX                     | Maximum pending number in command queue before queue is full.                     |
|                                       |                   |   | Adding additional commands will result in an ERROR.                               |
| cmd_queue_count_threshold             | natural           | C_CMD_QUEUE_COUNT_THRESHOLD               | An alert with severity "cmd_queue_count_threshold_severity" will be               |
|                                       |                   |   | issued if command queue exceeds this count. Used for early warning if             |
|                                       |                   |   | command queue is almost full. Will be ignored if set to 0.                        |
| cmd_queue_count_threshold_severity    | t_alert_level     | C_CMD_QUEUE_COUNT_THRESHOLD_SEVERITY      | Severity of alert to be initiated if exceeding cmd_queue_count_threshold          |
| result_queue_count_max                | natural           | C_RESULT_QUEUE_COUNT_MAX                  | Maximum number of unfetched results before result_queue is full.                  |
| result_queue_count_threshold          | natural           | C_RESULT_QUEUE_COUNT_THRESHOLD            | An alert with severity 'result_queue_count_threshold_severity' will be issued if  |
|                                       |                   |   | result queue exceeds this count. Used for early warning if result queue is almost |
|                                       |                   |   | full. Will be ignored if set to 0.  |
| result_queue_count_threshold_severity | t_alert_level     | C_RESULT_QUEUE_COUNT_THRESHOLD_SEVERITY   | Severity of alert to be initiated if exceeding result_queue_count_threshold       |
| bfm_config                            | t_bfm_config      | C_CLOCK_GENERATOR_CONFIG_DEFAULT          | Configuration for Clock Generator.  |
| msg_id_panel                          | t_msg_id_panel    | C_VVC_MSG_ID_PANEL_DEFAULT                | VVC dedicated message ID panel  |

The configuration record can be accessed from the Central Testbench Sequencer through the shared variable array, e.g.:

shared\_clock\_generator\_vvc\_config(1).inter\_bfm\_delay.delay\_in\_time := 50 ns;

#### 3 VVC Status

The current status of the VVC can be retrieved during simulation. This is achieved by reading from the shared variable shared\_clock\_generator\_vvc\_status record from the test sequencer. The record contents can be seen below:

| 1110 100014 0011101110 0411 20 001 | The record contains can be east below. |   |  |
|------------------------------------|--|---|--|
| Record element                     | Туре                                   | Description                                     |  |
| current_cmd_idx                    | natural                                | Command index currently running                 |  |
| previous_cmd_idx                   | natural                                | Previous command index to run                   |  |
| pending cmd cnt                    | natural                                | Pending number of commands in the command queue |  |



#### 4 Additional Documentation

Additional documentation about UVVM and its features can be found under "/uvvm vvc framework/doc/".

## 5 Compilation

The Clock Generator VVC must be compiled with VHDL 2008.

It is dependent on the following libraries

- UVVM Utility Library (UVVM-Util), version 2.5.0 and up
- UVVM VVC Framework, version 2.3.0 and up

Before compiling the Clock Generator VVC, assure that uvvm vvc framework and uvvm util have been compiled.

See UVVM Essential Mechanisms located in uvvm vvc framework/doc for information about compile scripts.

#### Compile order for the Clock Generator VVC:

| Compile to library         | File   | Comment   |
|----------------------------|--|---|
| bitvis_vip_clock_generator | vvc_cmd_pkg.vhd  | Clock Generator VVC command types and operations                                |
| bitvis_vip_clock_generator | /uvvm_vvc_framework/src_target_dependent/td_target_support_pkg.vhd               | UVVM VVC target support package, compiled into the Clock Generator VVC library. |
| bitvis_vip_clock_generator | /uvvm_vvc_framework/src_target_dependent/td_vvc_framework_common_methods_pkg.vhd | Common UVVM framework methods compiled into the Clock Generator VVC library     |
| bitvis_vip_clock_generator | vvc_methods_pkg.vhd  | Clock Generator VVC methods   |
| bitvis_vip_clock_generator | /uvvm_vvc_framework/src_target_dependent/td_queue_pkg.vhd                        | UVVM queue package for the VVC  |
| bitvis_vip_clock_generator | /uvvm_vvc_framework/src_target_dependent/td_vvc_entity_support_pkg.vhd           | UVVM VVC entity support compiled into the Clock Generator VVC library           |
| bitvis_vip_clock_generator | clock_generator_vvc.vhd  | Clock Generator VVC   |

## 6 Simulator compatibility and setup

This VVC has been compiled and tested with Modelsim version 10.5b and Riviera-PRO version 2016.02.81. For required simulator setup see *UVVM-Util* Quick reference.



Disclaimer: This IP and any part thereof are provided "as is", without warranty of any kind, express or implied, including but not limited to the warranties of merchantability, fitness for a particular purpose and noninfringement. In no event shall the authors or copyright holders be liable for any claim, damages or other liability, whether in an action of contract, tort or otherwise, arising from, out of or in connection with this IP.