MODBUS Specification for Irradiance Sensors Si-RS485 Series

From Firmware Version 1.51



1. Supported Bus Protocol

Baud Rate: 1200, 2400, 9600, 19200, 38400

Parity: No, even, odd

Stop Bit: 1, 2 (only at no parity)
Factory Default: 9600 Baud, 8N1, address: 1

For setting the bus protocol parameter the sensor offers the function code 0x46 of the MODBUS protocol. Alternatively you can use the software tool Si-MODBUS-Configurator (free download on our website) for setting the bus parameter and testing the communication.

2. MODBUS Specification

References:

- MODBUS over Serial Line Specification and Implementation Guide V1.02

- MODBUS Application Protocol Specification V1.1b

Transmission mode: MODBUS RTU

The Sensors will start MODBUS operation 4 seconds after power up.

Supported function codes:

- 0x04: Read Input Register

Register	Value	Gain	Offset	Phys. Range	Data Range	Data Type
0000	Irradiance in W/m²	0.1	0	01500 W/m ² 1)	015000 1)	UINT16
0003	Wind Speed in m/s	0.1	0	080 m/s	0800	UINT16
0007 2)	Cell Temperature in °C	0.1	0	-40+90°C	-400900	INT16
0008 2)	External Temperature in °C	0.1	0	-40+90°C	-400900	INT16

¹⁾ Up to Firmware Version 1.52 range is 0...1400 W/m²

<u>Please note:</u> The Register 0003 and 0008 are optional for some sensor types. If your sensor does not support this register, it will return the value 0 for this register.

Date: March 2017

²⁾ Only available from Firmware Version 1.53

MODBUS Specification for Irradiance Sensors Si-RS485 Series From Firmware Version 1.51



To keep compatibility to old firmware versions, additional are available:

Register	Value	Gain	Offset	Phys. Range	Data Range	Data Type
0001	Cell Temperature in °C	0.1	-25	-25+75°C	01000	UINT16
0002	External Temperature in °C	0.1	-25	-25+75°C	01000	UINT16
0004	reserved	./.	./.	./.	0	UINT16
0005 3)	Cell Temperature in °C	0.1	-100	-40+90°C	6001900	UINT16
0006 3)	External Temperature in °C	0.1	-100	-40+90°C 4)	6001900 4)	UINT16

³⁾ Only available from Firmware Version 1.52

<u>Please note:</u> The Register 0002 and 0006 are optional for some sensor types. If your sensor does not support this register, it will return the value 0 for this register.

For using the full temperature measurement range of -40...90°C use register 0005 and 0006 resp. 0007 and 0008.

- 0x08: Diagnostics

- Sub function 0x00: Return Query Data
- Sub function 0x01: Restart Communications Option
- Sub function 0x04: Force Listen Only Mode
- Sub function 0x0A: Clear Counters
- Sub function 0x0B: Return Bus Message Count
- Sub function 0x0C: Return Bus Communication Error Count
- Sub function 0x0D: Return Slave Exception Error Count
- Sub function 0x0E: Return Slave Message Count
- Sub function 0x0F: Return Slave No Response Count
- Sub function 0x10: Return Slave NAK Count
- Sub function 0x11: Return Slave Busy Count
- Sub function 0x12: Return Bus Character Overrun Count

0x46: Communication Parameter

Please note: These settings will take effect after restart of the sensor by power on reset or restart communication command (function 0x08, Sub function 01).

- Sub function 04: Write Module Address

Request:

00	Address	1 Byte	1 to 247
01	Function Code	1 Byte	0x46
02	Sub Function Code	1 Byte	0x04
03	New Address	1 Byte	1 to 247

^{40...+85°}C for Firmware Version V1.52 / -40...+90°C for Firmware Version V1.53

MODBUS Specification for Irradiance Sensors Si-RS485 Series From Firmware Version 151



Response:

00	Address	1 Byte	1 to 247
01	Function Code	1 Byte	0x46
02	Sub Function Code	1 Byte	0x04
03	New Address	1 Byte	1 to 247

- Sub function 05: Read Communication Parameter

Request:

00	Address	1 Byte	1 to 247
01	Function Code	1 Byte	0x46
02	Sub Function Code	1 Byte	0x05

Response:

00	Address	1 Byte	1 to 247
01	Function Code	1 Byte	0x46
02	Sub Function Code	1 Byte	0x05
03	Baud rate	1 Byte	0 to 4, see table below
04	Parity / Stop Bit	1 Byte	0 to 3, see table below

- Sub function 06: Write Communication Parameter

Request:

00	Address	1 Byte	1 to 247
01	Function Code	1 Byte	0x46
02	Sub Function Code	1 Byte	0x05
03	Baud Rate	1 Byte	0 to 4, see table below
04	Parity / Stop Bit	1 Byte	0 to 3, see table below

Response:

00	Address	1 Byte	1 to 247
01	Function Code	1 Byte	0x46
02	Sub Function Code	1 Byte	0x05
03	Baud Rate	1 Byte	0 to 3, see table below
04	Parity / Stop Bit	1 Byte	0 to 3, see table below

Date: March 2017





- Communication Parameter Setting Sub Function 05 and 06:

Baud Rate	Value
1200	0
2400	1
9600	2
19200	3
38400	4

Parity / Stop Bit	Value
8N1 (10 Bit)	0
8N2 (11 Bit)	1
8E1 (11 Bit)	2
8O1 (11 Bit)	3

- Sub function 07: Hardware and Firmware Version

Request:

00	Address	1 Byte	1 to 247
01	Function Code	1 Byte	0x46
02	Sub Function Code	1 Byte	0x07

Response:

00	Address	1 Byte	1 to 247
01	Function Code	1 Byte	0x46
02	Sub Function Code	1 Byte	0x07
03	Hardware Version	2 Byte	0 to 65535
04	Firmware Version	2 Byte	0 to 65535

Date: March 2017

Exception Codes:

- 01: Illegal Function

- 02: Illegal Data Access

- 03: Illegal Data Value

- 04: Slave Device Failure