

Intel® Platform Innovation Framework for EFI Miscellaneous Subclass Specification

Draft for Review

Version 0.9 April 1, 2004



THIS SPECIFICATION IS PROVIDED "AS IS" WITH NO WARRANTIES WHATSOEVER, INCLUDING ANY WARRANTY OF MERCHANTABILITY, NONINFRINGEMENT, FITNESS FOR ANY PARTICULAR PURPOSE, OR ANY WARRANTY OTHERWISE ARISING OUT OF ANY PROPOSAL, SPECIFICATION OR SAMPLE. Except for a limited copyright license to copy this specification for internal use only, no license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted herein.

Intel disclaims all liability, including liability for infringement of any proprietary rights, relating to implementation of information in this specification. Intel does not warrant or represent that such implementation(s) will not infringe such rights.

Designers must not rely on the absence or characteristics of any features or instructions marked "reserved" or "undefined." Intel reserves these for future definition and shall have no responsibility whatsoever for conflicts or incompatibilities arising from future changes to them.

This document is an intermediate draft for comment only and is subject to change without notice. Readers should not design products based on this document.

Intel, the Intel logo, and Itanium are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

* Other names and brands may be claimed as the property of others.

Copyright © 2001–2004, Intel Corporation.

Intel order number xxxxxx-001



Draft for Review

Revision History

Revision	Revision History	Date
0.9	First public release.	4/1/04

Draft for Review





Contents

1 Introduction	13
Overview	13
Conventions Used in This Document	13
Data Structure Descriptions	
Pseudo-Code Conventions	
Typographic Conventions	14
2 Design Discussion	17
Overview	
Additional References	
Scope	
Consumer versus Producer	
Compliancy Requirements Header Information	
Miscellaneous Subclass Definition	
Data Record Header	
Data Class Header	
Raw Data	
Data Record Number	
3 Code Definitions	21
Introduction	
Header Information	
Miscellaneous Subclass Definition	
EFI_MISC_SUBCLASS	
Subclass Version	
EFI_MISC_SUBCLASS_VERSION	
Data Record Number	
Legacy Miscellaneous Record Numbers	
Legacy Miscellaneous Record NumbersLast PCI Bus Number	
EFI_MISC_LAST_PCI_BUS_DATA	
BIOS Information (Type 0)	
EFI_MISC_BIOS_VENDOR_DATA	
System Information (Type 1)	29
EFI_MISC_SYSTEM_MANUFACTURER_DATA	29
Baseboard Information (Type 2) EFI_MISC_BASE_BOARD_MANUFACTURER_DATA	31
System/Chassis Enclosure (Type 3)	
EFI_MISC_CHASSIS_MANUFACTURER_DATA	
Port Connector Information (Type 8)EFI_MISC_PORT_INTERNAL_CONNECTOR_DESIGNATOR_DATA	39
System Slots (Type 9)	
EFI MISC SYSTEM SLOT DESIGNATION DATA	43



Onboard Devices Information (Type 10)	47
EFI_MISC_ONBOARD_DEVICE_DATA	
OEM Strings (Type 11)	49
EFI_MISC_OEM_STRING_DATA	49
System Configuration Options (Type 12)	
EFI_MISC_SYSTEM_OPTION_STRING_DATA	50
BIOS Language Information (Type 13)	
Number of Installable Languages	
EFI_MISC_NUMBER_OF_INSTALLABLE_LANGUAGES_DATA	
System Language String	
EFI_MISC_SYSTEM_LANGUAGE_STRING_DATA	
Group Associations (Type 14)	
Group Name	
EFI_MISC_GROUP_NAME_DATA	
Group Item Set Element	57
EFI_MISC_GROUP_ITEM_SET_DATA	57
Built-in Pointing Device (Type 21)	59
EFI_MISC_POINTING_DEVICE_TYPE_DATA	59
Portable Battery (Type 22)	
EFI_MISC_BATTERY_LOCATION_DATA	61
System Reset (Type 23)	
EFI_MISC_RESET_CAPABILITIES_DATA	
Hardware Security (Type 24)	
EFI_MISC_HARDWARE_SECURITY_SETTINGS_DATA	
System Power Controls (Type 25)	
System Power Controls (Type 25)	
Scheduled Power-On	
EFI_MISC_SCHEDULED_POWER_ON_MONTH_DATA	
Voltage Probe (Type 26)	71
EFI_MISC_VOLTAGE_PROBE_DESCRIPTION_DATA	71
Cooling Device (Type 27)	75
EFI_MISC_COOLING_DEVICE_TEMP_LINK_DATA	75
Temperature Probe (Type 28)	
EFI_MISC_TEMPERATURE_PROBE_DESCRIPTION_DATA	78
Electrical Current Probe (Type 29)	
EFI_MISC_ELECTRICAL_CURRENT_PROBE_DESCRIPTION_DATA	82
Out-of-Band Remote Access (Type 30)	
EFI_MISC_REMOTE_ACCESS_MANUFACTURER_DESCRIPTION_	00
	0.0
DATA	80
Boot Integrity Services (BIS) Entry Point (Type 31)	
EFI_MISC_BIS_ENTRY_POINT_DATA	
System Boot Information (Type 32)	89
EFI_MISC_BOOT_INFORMATION_STATUS_DATA	
Management Device (Type 34)	91
EFI_MISC_MANAGEMENT_DEVICE_DESCRIPTION_DATA	91
Management Device Component (Type 35)	
EFI_MISC_MANAGEMENT_DEVICE_COMPONENT_DESCRIPTION	
_DATA	93



	IPMI Device Information (Type 38)	
	EFI_MISC_IPMI_INTERFACE_TYPE_DATA	95
	System Power Supply (Type 39)	97
	EFI_MISC_POWER_SUPPLY_UNIT_GROUP_DATA	97
	SMBIOS Structure Encapsulation (Types 0x80 to 0xFF)	101
	EFI_MISC_SMBIOS_STRUCT_ENCAPSULATION_DATA	101
4	Examples	103
-	Legacy Miscellaneous Record Numbers	
	Last PCI Bus Number	
	BIOS Information (Type 0) Record Numbers	
	BIOS Vendor	
	BIOS Version	
	BIOS Release Date	
	BIOS Starting Address	
	BIOS Physical Device Size	
	BIOS Characteristics	
	BIOS Characteristics Extension Bytes	
	System Information (Type 1) Record Numbers	
	System Manufacturer	
	System Product Name	
	System Version	
	System Serial Number	
	System UUID	
	System Wake-up Type	
	Baseboard Information (Type 2) Record Numbers	105
	Baseboard Manufacturer	
	Baseboard Product Name	105
	Baseboard Version	105
	Baseboard Serial Number	105
	Baseboard Asset Tag	105
	Baseboard Chassis Location	105
	Baseboard Feature Flags	
	Baseboard Type	
	Baseboard Chassis Link	
	Baseboard Number of Links	
	Baseboard LinkN	
	System/Chassis Enclosure (Type 3) Record Numbers	
	Chassis Manufacturer	
	Chassis Version	
	Chassis Serial Number	
	Chassis Asset Tag Number	
	Chassis Type	
	Chassis Boot-up State	
	Chassis Power Supply State	
	Chassis Thermal State	
	Chassis Security State	
	Chassis OEM Defined	107



Chassis Height	108
Chassis Number of Power Cords	
Chassis Element Count	108
Chassis Element Record Length	108
Chassis Elements	
Port Connector Information (Type 8) Record Numbers	109
Port Internal Connector Reference Designator	
Port External Connector Reference Designator	
Port Internal Connector Type	
Port External Connector Type	
Port Type	
System Slots (Type 9) Record Numbers	
Slot Designation	
Slot Type	
Slot Data Bus Width	
Slot Current Usage	
Slot Length	
Slot ID	
Slot Characteristics	
Onboard Devices Information (Type 10) Record Numbers	
Onboard Device Description	
Onboard Device Type	
OEM Strings (Type 11) Record Numbers	
Number of OEM Strings	
OEM Strings	
System Configuration Options (Type 12) Record Numbers	
Number of System Configuration Option Strings	
System Configuration Option Strings	
BIOS Language Information (Type 13) Record Numbers	
Number of Installable Languages	
Language Flags	
Current Language Number	
Language String	
Group Associations (Type 14) Record Numbers	
Group Name	112
Number of Items in Group	112
Group Item Set	
Built-in Pointing Device (Type 21) Record Numbers	
Pointing Device Type	
Pointing Device Interface	
Number of Pointing Device Buttons	
Portable Battery (Type 22) Record Numbers	
Portable Battery Location	
Portable Battery Manufacturer	
Portable Battery Manufacture Date	
Portable Battery Serial Number	
Portable Battery Device Name	
Portable Battery SBDS Version Number	

Draft for Review Contents

Portable Battery SBDS Device Chemistry	
Portable Battery Device Chemistry	115
Portable Battery Design Capacity	115
Portable Battery Design Voltage	115
Portable Battery Maximum Error in Battery Data	115
Portable Battery SBDS Serial Number	
Portable Battery SBDS Manufacture Date	115
Portable Battery OEM Specific	
System Reset (Type 23) Record Numbers	
Reset Capabilities	
Reset Count	116
Reset Limit	
Reset Timer Interval	
Reset Timeout	
Hardware Security (Type 24) Record Numbers	
Hardware Security Settings	
System Power Controls (Type 25) Record Numbers	
System Power Controls (Type 25) Record Numbers	
Scheduled Power-on Month	
Scheduled Power-on Day-of-Month	
Scheduled Power-on Hour	
Scheduled Power-on Minute	
Scheduled Power-on Second	
Voltage Probe (Type 26) Record Numbers	
Voltage Probe Description	
Voltage Probe Location and Status	
Voltage Probe Maximum Value	
Voltage Probe Minimum Value	
Voltage Probe Resolution	
Voltage Probe Tolerance	
Voltage Probe Accuracy	
Voltage Probe Nominal Value	
Management Device Lower Noncritical Threshold (Type 26)	
Management Device Upper Noncritical Threshold (Type 26)	
Management Device Lower Critical Threshold (Type 26)	
Management Device Upper Critical Threshold (Type 26)	
Management Device Lower Nonrecoverable Threshold (Type 26)	
Management Device Upper Nonrecoverable Threshold (Type 26)	
Voltage Probe OEM Defined	
Cooling Device (Type 27) Record Numbers	
Cooling Device Type and Status	
Cooling Device Temperature Link	
Cooling Device Unit Group	
Cooling Device Nominal Speed	
Cooling Device OEM Defined	
Temperature Probe (Type 28) Record Numbers	
Temperature Probe Description	
Temperature Probe Location and Status	
	·



Temperature Probe Maximum Value	121
Temperature Probe Minimum Value	
Temperature Probe Resolution	
Temperature Probe Tolerance	
Temperature Probe Accuracy	122
Temperature Probe Nominal Value	
Management Device Lower Noncritical Threshold (Type 28)	122
Management Device Upper Noncritical Threshold (Type 28)	
Management Device Lower Critical Threshold (Type 28)	122
Management Device Upper Critical Threshold (Type 28)	123
Management Device Lower Nonrecoverable Threshold (Type 28)	123
Management Device Upper Nonrecoverable Threshold (Type 28)	123
Temperature Probe OEM Defined	123
Electrical Current Probe (Type 29) Record Numbers	123
Electrical Current Probe Description	123
Electrical Current Probe Location and Status	123
Electrical Current Probe Maximum Value	124
Electrical Current Probe Minimum Value	124
Electrical Current Probe Resolution	124
Electrical Current Probe Tolerance	
Electrical Current Probe Accuracy	124
Electrical Current Probe Nominal Value (Type 29)	124
Management Device Lower Noncritical Threshold (Type 29)	124
Management Device Upper Noncritical Threshold (Type 29)	125
Management Device Upper Critical Threshold (Type 29)	125
Management Device Lower Critical Threshold (Type 29)	
Management Device Lower Nonrecoverable Threshold (Type 29)	
Management Device Upper Nonrecoverable Threshold (Type 29)	
Electrical Current Probe OEM Defined	
Out-of-Band Remote Access (Type 30) Record Numbers	
Remote Access Manufacturer Name Description	
Remote Access Connections	126
Boot Integrity Services (BIS) Entry Point (Type 31) Record Numbers	126
BIS Entry Point Address	126
System Boot Information (Type 32) Record Numbers	126
Boot Information Status	_
Boot Information Data	
Management Device (Type 34) Record Numbers	
Management Device Description	
Management Device Type	
Management Device Address	
Management Device Address Type	
Management Device Component (Type 35) Record Numbers	
Management Device Component Description	
Management Device Link	
Management Device Component Link	
IPMI Device Information (Type 38) Record Numbers	
IPMI Interface Type	128



Draft for Review Contents

IPMI Specification Revision	128
IPMI I2C Slave Address	
IPMI NV Storage Device Address	
IPMI Base Address	
System Power Supply (Type 39) Record Numbers	
Power Supply Group	
Power Supply Location	
Power Supply Device Name	
Power Supply Manufacturer Name	
Power Supply Serial Number	
Power Supply Asset Tag	
Power Supply Model Part Number	
Power Supply Revision Level	
Power Supply Maximum Power Capacity	
Power Supply Characteristics	
Power Supply Input Voltage Probe Link	
Power Supply Cooling Device Link	
Power Supply Input Current Probe Link	
SMBIOS Structure Encapsulation (Types 0x80 to 0xFF) Record Numbers	
SMBIOS Header	
Raw Data	

Draft for Review



ר Introduction

Overview

This specification defines the core code that is required for an implementation of the miscellaneous data hub subclass of the Intel® Platform Innovation Framework for EFI (hereafter referred to as the "Framework"). This specification does the following:

- Describes the <u>basic components</u> of the miscellaneous data hub subclass and miscellaneous subclass data records
- Provides <u>code definitions</u> for type and record definitions for the miscellaneous subclass that are architecturally required by the *Intel® Platform Innovation Framework for EFI Architecture* Specification
- Provides examples of the data records for the miscellaneous subclass

This specification complies with the System Management BIOS (SMBIOS) Reference Specification, version 2.3.4.

Conventions Used in This Document

This document uses the typographic and illustrative conventions described below.

Data Structure Descriptions

Intel® processors based on 32-bit Intel® architecture (IA-32) are "little endian" machines. This distinction means that the low-order byte of a multibyte data item in memory is at the lowest address, while the high-order byte is at the highest address. Processors of the Intel® Itanium® processor family may be configured for both "little endian" and "big endian" operation. All implementations designed to conform to this specification will use "little endian" operation.

In some memory layout descriptions, certain fields are marked *reserved*. Software must initialize such fields to zero and ignore them when read. On an update operation, software must preserve any reserved field.

The data structures described in this document generally have the following format:

STRUCTURE NAME: The formal name of the data structure.

Summary: A brief description of the data structure.

Prototype: A "C-style" type declaration for the data structure.

Parameters: A brief description of each field in the data structure prototype.

Description: A description of the functionality provided by the data structure,

including any limitations and caveats of which the caller should

be aware.

Related Definitions: The type declarations and constants that are used only by

this data structure.



Pseudo-Code Conventions

Pseudo code is presented to describe algorithms in a more concise form. None of the algorithms in this document are intended to be compiled directly. The code is presented at a level corresponding to the surrounding text.

In describing variables, a *list* is an unordered collection of homogeneous objects. A *queue* is an ordered list of homogeneous objects. Unless otherwise noted, the ordering is assumed to be First In First Out (FIFO).

Pseudo code is presented in a C-like format, using C conventions where appropriate. The coding style, particularly the indentation style, is used for readability and does not necessarily comply with an implementation of the *Extensible Firmware Interface Specification*.

Typographic Conventions

This document uses the typographic and illustrative conventions described below:

Plain text The normal text typeface is used for the vast majority of the descriptive

text in a specification.

Plain text (blue) In the online help version of this specification, any plain text that is

underlined and in blue indicates an active link to the cross-reference. Click on the word to follow the hyperlink. Note that these links are *not*

active in the PDF of the specification.

Bold In text, a Bold typeface identifies a processor register name. In other

instances, a **Bold** typeface can be used as a running head within a

paragraph.

Italic In text, an Italic typeface can be used as emphasis to introduce a new

term or to indicate a manual or specification name.

BOLD Monospace Computer code, example code segments, and all prototype code

segments use a **BOLD Monospace** typeface with a dark red color. These code listings normally appear in one or more separate paragraphs, though words or segments can also be embedded in a normal text

paragraph.

Bold Monospace In the online help version of this specification, words in a

Bold Monospace typeface that is underlined and in blue indicate an active hyperlink to the code definition for that function or type definition. Click on the word to follow the hyperlink. Note that these links are *not* active in the PDF of the specification. Also, these inactive links in the PDF may instead have a **Bold Monospace** appearance that is

underlined but in dark red. Again, these links are not active in the PDF of

the specification.

Italic Monospace In code or in text, words in Italic Monospace indicate placeholder

names for variable information that must be supplied (i.e., arguments).

Plain Monospace In code, words in a Plain Monospace typeface that is a dark red

color but is not bold or italicized indicate pseudo code or example code. These code segments typically occur in one or more separate paragraphs.



Draft for Review Introduction

text text text

In the PDF of this specification, text that is highlighted in yellow indicates that a change was made to that text since the previous revision of the PDF. The highlighting indicates only that a change was made since the previous version; it does not specify what changed. If text was deleted and thus cannot be highlighted, a note in red and highlighted in yellow (that looks like (*Note: text text text.*)) appears where the deletion occurred.

See the master Framework glossary in the Framework Interoperability and Component Specifications help system for definitions of terms and abbreviations that are used in this document or that might be useful in understanding the descriptions presented in this document.

See the master Framework references in the Interoperability and Component Specifications help system for a complete list of the additional documents and specifications that are required or suggested for interpreting the information presented in this document.

The Framework Interoperability and Component Specifications help system is available at the following URL:

http://www.intel.com/technology/framework/spec.htm

Draft for Review





Design Discussion

Overview

This specification describes a group of data records that have similar characteristics. The data records are records that will be input to the data hub to be consumed by one or more drivers.

This specification complies with the <u>Intel® Platform Innovation Framework for EFI Data Hub</u> <u>Specification</u> and it is assumed that the consumer of this specification is well versed in the concept of the data hub. This specification describes in more detail how to implement a driver that will log all the miscellaneous data records and how to create drivers that will consume this data.

This specification also specifies the format of each data record. Each data record must be capable of being used by current and potential consumers of the data—in other words, the format should also be consumable by all potential agents. The unit of measurement, if applicable, should be the most common unit of measurement for the specific data record, and the range of values for a data record should be usable for the foreseeable future.

Additional References

In addition to the other Framework, industry, and Intel® specifications listed in <u>References</u> in the Interoperability and Component Specifications help system, the following sources are also referenced in this specification or may be useful to you:

- Boot Integrity Services: http://www.intel.com/labs/manage/wfm/tools/bis/index.htm
- Distributed Management Task Force, Inc.: http://www.dmtf.org/*
- Smart Battery Data Specification: http://www.sbs-forum.org/specs/*

Scope

This specification is the contract for miscellaneous data between the appropriate data drivers and the associated data consumers. Miscellaneous data includes information from the following:

- BIOS
- Physical system and baseboard
- Port
- Onboard device
- Security
- Power
- Cooling
- Management
- Power supply



This specification does not include cache, memory, or processor data, which can be found in their own specifications.

The data driver does not have to declare all the record types listed in this specification but should declare only those data types that are applicable. If the data is not applicable (for example, if no battery power exists in the system), the data consumer should make the necessary adjustment and not declare the associated data records.

A specific record defines the semantic context of the data. All records related to miscellaneous data are documented in this specification. The record type is numbered sequentially and a new record type can be appended to the end of the list. The record type in this specification defines the semantic context of the data. The data records in this specification comply to the EFI_SUBCLASS_TYPE1_HEADER . Version field of 1. Type EFI_SUBCLASS_TYPE1_HEADER is defined in the Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide.

Data records can be added or deleted as long as backward compatibility is maintained. If a data record needs to be updated, a new entry to this specification can be added. At some point when the objectives of this subclass are not accomplished or become inconsistent, an entirely new subclass with a new Globally Unique Identifier (GUID) will be introduced.



The data records and structures sometimes are System Management BIOS (SMBIOS)—centric as the initial document is based on the SMBIOS requirements.

Consumer versus Producer

It is possible that a producer of miscellaneous data is also a consumer and vice versa. An example is a producer of a management device component that consumes a thermal device or cooling device.

Compliancy Requirements

None of the record numbers described in this document are required by the *Extensible Firmware Interface Specification*. Some record number entries may be required by other industry-wide specifications such as the *System Management BIOS (SMBIOS) Reference Specification*.

Some **ENUM** definitions are controlled by the Distributed Management Task Force, Inc. (DMTF) organization. Refer to their Web site at www.dmtf.org/standards/dmi* and select the link to *Master MIF*.

Header Information

Miscellaneous Subclass Definition

The miscellaneous subclass belongs to the data class and is identified as the miscellaneous subclass by the GUID. See Miscellaneous Subclass Definition in Code Definitions for the definition.

Data Record Header

Each data record that is logged or read starts with a standard header of type **EFI_DATA_RECORD_HEADER**. The format of the header is defined in the *Intel® Platform Innovation Framework for EFI Data Hub Specification*.

Data Class Header

Each data record that is a member of the data class starts with a standard header of type **EFI_SUBCLASS_TYPE1_HEADER**. The format of the header is defined in the *Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide*. This header follows the data record header **EFI_DATA_RECORD_HEADER**, which is defined in the *Intel® Platform Innovation Framework for EFI Data Hub Specification*.

The Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide provides generic descriptions of the fields in **EFI_SUBCLASS_TYPE1_HEADER**. The following explanation further clarifies the descriptions for the miscellaneous subclass:

- The *Instance* is the instance number of the miscellaneous class in the system. A new producer of a subsystem should use the next incremental *Instance* number. The exact definition of what constitutes a new *Instance* number is a system architecture decision. An example is to partition the system into subsystems and assign an *Instance* to each subsystem. Examples of a subsystem could be a node in a hyper-cube system or a peripheral bay in a server.
- The *SubInstance* is a "device" in the miscellaneous subsystem, as multiple identical "devices" can exist in a miscellaneous subsystem. An example would be multiple onboard devices in a device bay. The *SubInstance* would be used to identify each SCSI controller. The *SubInstance* number should increment for each new identical "device" in the subsystem.

Raw Data

The raw data follows the **EFI_SUBCLASS_TYPE1_HEADER** header and its definition is specific to the *RecordNumber*. The syntax of the raw data is defined in <u>Data Record Number</u> in <u>Code Definitions</u>. Type **EFI_SUBCLASS_TYPE1_HEADER** is defined in the <u>Intel® Platform</u>
Innovation Framework for EFI Data Hub Subclass Design Guide.



Data Record Number

The <u>EFI_SUBCLASS_TYPE1_HEADER</u> is followed by a data record. The data record format is specific to a *RecordNumber*. The sections in <u>Data Record Number</u> in <u>Code Definitions</u> define the data *RecordNumbers* for the miscellaneous subclass. The *RecordNumbers* are subdivided into different subsections on a per-SMBIOS type for ease of reference. See the <u>Examples</u> section for examples of these record numbers.

The **EFI_INTER_LINK_DATA** structure is used to link together multiple data hub items of the same subclass. An example is the use of the cooling device (see <u>Cooling Device (Type 27)</u>) to link a temperature probe (see <u>Temperature Probe (Type 28)</u>) with a fan. The *CoolingDeviceTemperatureLink* points to the temperature probe record.

All generic macros are defined in the <u>Intel® Platform Innovation Framework for EFI Data Hub</u>
<u>Subclass Design Guide</u>. <u>STRING_REF</u> is defined in the <u>Intel® Platform Innovation Framework for</u>
<u>EFI Human Interface Infrastructure Specification</u>.



Code Definitions

Introduction

This section contains the basic definitions of the data record header fields that are specific to the miscellaneous subclass, as well as definitions of miscellaneous data records. The following data types and data records are defined in this section:

- EFI_MISC_SUBCLASS
- EFI_MISC_SUBCLASS_VERSION
- <u>EFI_MISC_LAST_PCI_BUS_DATA</u>
- EFI_MISC_BIOS_VENDOR_DATA
- EFI_MISC_SYSTEM_MANUFACTURER_DATA
- EFI_MISC_BASE_BOARD_MANUFACTURER_DATA
- EFI_MISC_CHASSIS_MANUFACTURER_DATA
- EFI_MISC_PORT_INTERNAL_CONNECTOR_DESIGNATOR_DATA
- EFI_MISC_SYSTEM_SLOT_DESIGNATION_DATA
- EFI_MISC_ONBOARD_DEVICE_DATA
- EFI_MISC_OEM_STRING_DATA
- EFI_MISC_SYSTEM_OPTION_STRING_DATA
- EFI_MISC_NUMBER_OF_INSTALLABLE_LANGUAGES_DATA
- EFI_MISC_SYSTEM_LANGUAGE_STRING_DATA
- EFI_MISC_GROUP_NAME_DATA
- EFI_MISC_GROUP_ITEM_SET_DATA
- EFI_MISC_POINTING_DEVICE_TYPE_DATA
- EFI_MISC_BATTERY_LOCATION_DATA
- EFI_MISC_RESET_CAPABILITIES_DATA
- EFI_MISC_HARDWARE_SECURITY_SETTINGS_DATA
- EFI_MISC_SCHEDULED_POWER_ON_MONTH_DATA
- EFI_MISC_VOLTAGE_PROBE_DESCRIPTION_DATA
- EFI MISC COOLING DEVICE TEMP LINK DATA
- EFI_MISC_TEMPERATURE_PROBE_DESCRIPTION_DATA
- EFI MISC ELECTRICAL CURRENT PROBE DESCRIPTION DATA
- EFI_MISC_REMOTE_ACCESS_MANUFACTURER_DESCRIPTION_DATA
- EFI_MISC_BIS_ENTRY_POINT_DATA
- EFI_MISC_BOOT_INFORMATION_STATUS_DATA
- EFI MISC MANAGEMENT DEVICE DESCRIPTION DATA
- EFI_MISC_MANAGEMENT_DEVICE_COMPONENT_DESCRIPTION_DATA



- <u>EFI_MISC_IPMI_INTERFACE_TYPE_DATA</u>
- EFI_MISC_POWER_SUPPLY_UNIT_GROUP_DATA
- EFI_MISC_SMBIOS_STRUCT_ENCAPSULATION_DATA

See the **Examples** section for examples using these data records.



Header Information

Miscellaneous Subclass Definition

EFI_MISC_SUBCLASS

Summary

The miscellaneous subclass belongs to the data class and is identified as the miscellaneous subclass by the GUID.

GUID

```
#define EFI_MISC_SUBCLASS_GUID \
{ 0x772484B2, 0x7482, 0x4b91, 0x9F, 0x9A, 0xAD, 0x43, 0xF8, 0x1C,
0x58, 0x81}
```

Class

Description

Summary

The miscellaneous subclass belongs to the data class and is identified as the miscellaneous subclass by the GUID.

For this subclass, the values defined above are used as follows:

- **EFI_DATA_RECORD_HEADER.** DataRecordGuid = **EFI_MISC_SUBCLASS_GUID**, which is the GUID that is specific to the miscellaneous subclass.
- **EFI_DATA_RECORD_HEADER.** DataRecordClass = **EFI_DATA_CLASS_DATA**. The "class" may be equal to the GUID "class" or a superset of the GUID "class."

Type **EFI_DATA_CLASS_DATA** is defined in **EFI_DATA_RECORD_HEADER**, which is defined in the *Intel® Platform Innovation Framework for EFI Data Hub Specification*.



Subclass Version

EFI_MISC_SUBCLASS_VERSION

Summary

Indicates the version of the miscellaneous subclass.

Prototype

#define EFI_MISC_SUBCLASS_VERSION 0x0100

Description

This value indicates the version of the miscellaneous subclass. It is used in EFI_SUBCLASS_TYPE1_HEADER is defined in the Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide.



Data Record Number

Legacy Miscellaneous Record Numbers

Legacy Miscellaneous Record Numbers

This section describes information that is not part of the SMBIOS specification but of either other legacy specifications or information that is pertinent to an operating system.

Last PCI Bus Number

```
EFI_MISC_LAST_PCI_BUS_DATA
```

Summary

This data record refers to the last PCI bus that was found.

Prototype

Parameters

LastPciBus

A zero-based value that indicates the last PCI bus enumeration during power-on.

Description

This data record refers to the last PCI bus that was found.

```
For this data record, EFI_SUBCLASS_TYPE1_HEADER. RecordType = EFI_MISC_LAST_PCI_BUS_RECORD_NUMBER. Type EFI_SUBCLASS_TYPE1_HEADER is defined in the Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide.
```

Related Definitions



BIOS Information (Type 0)

EFI_MISC_BIOS_VENDOR_DATA

Summary

This data record refers to the BIOS.

Prototype

```
typedef struct {
 STRING REF
                                 BiosVendor;
 STRING REF
                                 BiosVersion;
 STRING REF
                                 BiosReleaseDate:
 EFI PHYSICAL ADDRESS
                                 BiosStartingAddress:
 EFI_EXP_BASE2_DATA
                                 BiosPhysicalDeviceSize;
 EFI_MISC_BIOS_CHARACTERISTICS
                                 BiosCharacteristics1;
 EFI MISC BIOS CHARACTERISTICS EXTENSION
                                 BiosCharacteristics2:
} EFI_MISC_BIOS_VENDOR_DATA;
```

Parameters

BiosVendor

The BIOS vendor. Type **STRING_REF** is defined in the *Intel® Platform Innovation*Framework for EFI Human Interface Infrastructure Specification.

BiosVersion

The BIOS version number.

BiosReleaseDate

The BIOS release date.

BiosStartingAddress

The starting address of BIOS code space. Type **EFI_PHYSICAL_ADDRESS** is defined in **AllocatePages()** in the *EFI 1.10 Specification*.

BiosPhysicalDeviceSize

The maximum size in bytes of the physical device containing the BIOS. Type **EFI_EXP_BASE2_DATA** is defined in the *Intel® Platform Innovation Framework* for EFI Data Hub Subclass Design Guide.

BiosCharacteristics1

The BIOS characteristics supported by the system. Type **EFI_MISC_BIOS_CHARACTERISTICS** is defined in "Related Definitions" below.



BiosCharacteristics2

The BIOS characteristics supported by the system. Type **EFI_MISC_BIOS_CHARACTERISTICS_EXTENSION** is defined in "Related Definitions" below.

Description

This data record refers to the BIOS. This data record is a structure.

The type definition structure for **EFI_MISC_BIOS_VENDOR_DATA** is in SMBIOS 2.3.4, Type 0, in the following tables:

- Table 3.3.1.1
- Table 3.3.1.2.1
- Table 3.3.1.2.2

For this data record, <u>EFI_SUBCLASS_TYPE1_HEADER</u>. RecordType = <u>EFI_MISC_BIOS_VENDOR_RECORD_NUMBER</u>. Type <u>EFI_SUBCLASS_TYPE1_HEADER</u> is defined in the <u>Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide</u>.

Related Definitions

```
//*******************
// Record number
//***************
#define EFI_MISC_BIOS_VENDOR_RECORD_NUMBER
                                           0 \times 000000002
//*****************
// EFI_MISC_BIOS_CHARACTERISTICS
//****************
typedef struct {
 UINT64 Reserved1
                                      :2;
 UINT64 Unknown
                                      :1;
 UINT64 BiosCharacteristicsNotSupported
                                      :1;
 UINT64 IsaIsSupported
                                      :1;
 UINT64 McaIsSupported
                                      :1;
 UINT64 EisaIsSupported
                                      :1;
 UINT64 PciIsSupported
                                      :1;
 UINT64 PcmciaIsSupported
                                      :1;
 UINT64 PlugAndPlayIsSupported
                                      :1;
 UINT64 ApmIsSupported
                                      :1;
 UINT64 BiosIsUpgradable
                                      :1;
 UINT64 BiosShadowingAllowed
                                      :1;
 UINT64 VlVesaIsSupported
                                      :1;
 UINT64 EscdSupportIsAvailable
                                      :1;
 UINT64 BootFromCdIsSupported
                                      :1;
 UINT64 SelectableBootIsSupported
                                      :1;
 UINT64 RomBiosIsSocketed
                                      :1;
 UINT64 BootFromPcmciaIsSupported
                                      :1;
 UINT64 EDDSpecificationIsSupported
                                      :1;
```



```
UINT64 JapaneseNecFloppyIsSupported
                                           :1;
 UINT64 JapaneseToshibaFloppyIsSupported
                                          :1;
 UINT64 Floppy525_360IsSupported
                                           :1;
 UINT64 Floppy525 12IsSupported
                                           :1;
 UINT64 Floppy35_720IsSupported
                                           :1;
 UINT64 Floppy35_288IsSupported
                                           :1;
 UINT64 PrintScreenIsSupported
                                           :1;
 UINT64 Keyboard8042IsSupported
                                           :1;
 UINT64 SerialIsSupported
                                           :1;
 UINT64 PrinterIsSupported
                                           :1;
 UINT64 CgaMonoIsSupported
                                           :1;
 UINT64 NecPc98
                                           :1;
 UINT64 AcpiIsSupported
                                           :1;
 UINT64 UsbLegacyIsSupported
                                           :1;
 UINT64 AgpIsSupported
                                           :1;
 UINT64 I20BootIsSupported
                                          :1;
 UINT64 Ls120BootIsSupported
                                           :1;
 UINT64 AtapiZipDrivBootIsSupported
                                           :1;
 UINT64 Boot1394IsSupported
                                           :1;
 UINT64 SmartBatteryIsSupported
                                           :1;
 UINT64 BiosBootSpecIsSupported
                                          :1;
 UINT64 FunctionKeyNetworkBootIsSupported
                                          :1;
 UINT64 Reserved
                                           :22;
} EFI MISC BIOS CHARACTERISTICS;
//****************************
// EFI_MISC_BIOS_CHARACTERISTICS_EXTENSION
//****************
typedef struct {
 UINT64 BiosReserved
                                           :16;
 UINT64 SystemReserved
                                           :16;
 UINT64 Reserved
                                           :32;
} EFI_MISC_BIOS_CHARACTERISTICS_EXTENSION;
  BiosReserved
```

Reserved for future BIOS use. Must be initialized to zero.

SystemReserved

Reserved for future system use. Must be initialized to zero.

Reserved

Reserved for future use. Must be initialized to zero.



System Information (Type 1)

EFI MISC SYSTEM MANUFACTURER DATA

Summary

This data record refers to the system manufacturer.

Prototype

Parameters

```
SystemManufacturer
```

The system manufacturer. Type **STRING_REF** is defined in the *Intel® Platform Innovation Framework for EFI Human Interface Infrastructure Specification*.

```
SystemProductName
```

The system product name.

```
SystemVersion
```

The system version number.

```
SystemSerialNumber
```

The system serial number.

```
SystemUuid
```

The system Universal Unique ID (UUID) number. Type **EFI_GUID** is defined in **InstallProtocolInterface()** in the *EFI 1.10 Specification*.

```
SystemWakeupType
```

```
The event that caused the system to wake up. Type EFI_MISC_SYSTEM_WAKEUP_TYPE is defined in "Related Definitions" below.
```

Description

This data record refers to the system manufacturer. This data record is a structure.

```
The type definition structure for EFI_MISC_SYSTEM_MANUFACTURER_DATA is in SMBIOS 2.3.4, Type 1, Table 3.3.2.1.
```



For this data record, EFI_SUBCLASS_TYPE1_HEADER • RecordType = EFI_MISC_SYSTEM_MANUFACTURER_RECORD_NUMBER. Type EFI_SUBCLASS_TYPE1_HEADER is defined in the Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide.

Related Definitions

```
//******************
// Record number
//*****************
#define EFI_MISC_SYSTEM_MANUFACTURER_RECORD_NUMBER 0x00000003
//********************
// EFI_MISC_SYSTEM_WAKEUP_TYPE
//****************
typedef enum {
 EfiSystemWakeupTypeReserved
                            = 0,
 EfiSystemWakeupTypeOther
 EfiSystemWakeupTypeUnknown
                             = 2,
 EfiSystemWakeupTypeApmTimer
                             = 3,
 EfiSystemWakeupTypeModemRing
                             = 4,
 EfiSystemWakeupTypeLanRemote
                            = 5,
 EfiSystemWakeupTypePowerSwitch
                            = 6,
 EfiSystemWakeupTypePciPme
                             = 7,
 EfiSystemWakeupTypeAcPowerRestored = 8
} EFI_MISC_SYSTEM_WAKEUP_TYPE;
```



Baseboard Information (Type 2)

EFI MISC BASE BOARD MANUFACTURER DATA

Summary

This data record refers to the baseboard manufacturer.

Prototype

```
typedef struct {
  STRING REF
                                  BaseBoardManufacturer;
 STRING REF
                                  BaseBoardProductName;
 STRING REF
                                  BaseBoardVersion:
 STRING REF
                                  BaseBoardSerialNumber:
 STRING_REF
                                  BaseBoardAssetTag;
 STRING_REF
                                  BaseBoardChassisLocation;
                                 BaseBoardFeatureFlags;
 EFI BASE BOARD FEATURE FLAGS
 EFI_BASE_BOARD_TYPE
                                  BaseBoardType;
 EFI_INTER_LINK_DATA
                                  BaseBoardChassisLink;
                                 BaseBoardNumberLinks;
 UINT32
 EFI_INTER_LINK_DATA
                                 LinkN;
} EFI MISC BASE BOARD MANUFACTURER DATA;
```

Parameters

BaseBoardManufacturer

The baseboard manufacturer. Type **STRING_REF** is defined in the *Intel® Platform Innovation Framework for EFI Human Interface Infrastructure Specification*.

BaseBoardProductName

The baseboard product name.

BaseBoardVersion

The baseboard version number.

BaseBoardSerialNumber

The baseboard serial number.

BaseBoardAssetTag

The baseboard asset tag.

BaseBoardChassisLocation

The location of the baseboard within the chassis.

BaseBoardFeatureFlags

Flags that identify features contained on this baseboard. Type **EFI_BASE_BOARD_FEATURE_FLAGS** is defined in "Related Definitions" below.



BaseBoardType

Identifies the type of baseboard. Type **EFI_BASE_BOARD_TYPE** is defined in "Related Definitions" below.

BaseBoardChassisLink

A link to a chassis enclosure structure. Type **EFI_INTER_LINK_DATA** is defined in the *Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide*.

BaseBoardNumberLinks

The number of links to other structures.

LinkN

A link to another structure. N is between 1 and BaseBoardNumberLinks.

Description

This data record refers to the baseboard manufacturer. This data record is a structure.

The type definition structure for **EFI_MISC_BASE_BOARD_MANUFACTURER_DATA** is in SMBIOS 2.3.4, Type 2.

For this data record, EFI_MISC_BASE_BOARD_MANUFACTURER_RECORD_NUMBER. Type EFI_SUBCLASS_TYPE1_HEADER is defined in the Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide.

Related Definitions

```
//********************
// Record number
//***************
#define EFI_MISC_BASE_BOARD_MANUFACTURER_RECORD_NUMBER 0x00000004
//******************
// EFI BASE BOARD FEATURE FLAGS
//***************
typedef struct {
 UINT32 Motherboard
                        :1;
 UINT32 RequiresDaughterCard
                        :1;
 UINT32 Removable
                        :1;
 UINT32 Replaceable
                        :1;
 UINT32 HotSwappable
                        :1;
 UINT32 Reserved
                        :27;
} EFI_BASE_BOARD_FEATURE_FLAGS;
```

Code Definitions



```
//********************
// EFI_BASE_BOARD_TYPE
//***************
typedef enum {
 EfiBaseBoardTypeUnknown
                                   = 1,
 EfiBaseBoardTypeOther
                                   = 2,
 EfiBaseBoardTypeServerBlade
                                   = 3,
 EfiBaseBoardTypeConnectivitySwitch
                                = 4,
 EfiBaseBoardTypeSystemManagementModule = 5,
 EfiBaseBoardTypeProcessorModule
                                = 6,
 EfiBaseBoardTypeIOModule
                                   = 7,
 EfiBaseBoardTypeMemoryModule
                                   = 8,
 EfiBaseBoardTypeDaughterBoard
                                  = 9,
 EfiBaseBoardTypeMotherBoard
                                   = A,
 EfiBaseBoardTypeProcessorMemoryModule = B,
                                 = C,
 EfiBaseBoardTypeProcessorIOModule
 EfiBaseBoardTypeInterconnectBoard
                                   = D
} EFI_BASE_BOARD_TYPE;
```



System/Chassis Enclosure (Type 3)

EFI MISC CHASSIS MANUFACTURER DATA

Summary

This data record refers to the chassis manufacturer.

Prototype

```
typedef struct {
  STRING REF
                                        ChassisManufacturer;
 STRING REF
                                        ChassisVersion;
 STRING_REF
                                        ChassisSerialNumber:
 STRING REF
                                        ChassisAssetTaq;
 EFI_MISC_CHASSIS_STATUS
                                        ChassisType;
 EFI_MISC_CHASSIS_STATE
                                        ChassisBootupState;
 EFI MISC CHASSIS STATE
                                        ChassisPowerSupplyState;
 EFI_MISC_CHASSIS_STATE
                                        ChassisThermalState:
 EFI_MISC_CHASSIS_SECURITY_STATE
                                        ChassisSecurityState;
 UINT32
                                        ChassisOemDefined;
 UINT32
                                        ChassisHeight;
 UINT32
                                        ChassisNumberPowerCords;
                                        ChassisElementCount;
 UINT32
 UINT32
                                        ChassisElementRecordLength;
 EFI MISC ELEMENTS
                                        ChassisElements:
} EFI_MISC_CHASSIS_MANUFACTURER_DATA;
```

Parameters

ChassisManufacturer

The chassis manufacturer. Type **STRING_REF** is defined in the *Intel® Platform Innovation Framework for EFI Human Interface Infrastructure Specification*.

ChassisVersion

The chassis version number.

ChassisSerialNumber

The chassis serial number.

ChassisAssetTag

The chassis asset tag.

ChassisType

The type of chassis. Type **EFI_MISC_CHASSIS_STATUS** is defined in "Related Definitions" below.

ChassisBootupState

The state of the enclosure when the system was last booted. Type **EFI_MISC_CHASSIS_STATE** is defined in "Related Definitions" below.



Draft for Review Code Definitions

ChassisPowerSupplyState

The state of the enclosure's power supply when the system was last booted.

ChassisThermalState

The state of the enclosure's thermal state when the system was last booted.

ChassisSecurityState

The chassis security state when the system was last booted. Type **EFI_MISC_CHASSIS_SECURITY_STATE** is defined in "Related Definitions" below.

ChassisOemDefined

Original equipment manufacturer (OEM)– or BIOS-defined data.

ChassisHeight

Height in "U"s (1U=1.75"). A value of 0x00 indicates that the height is unspecified.

ChassisNumberPowerCords

The number of power cords associated with the chassis. A value of 0x00 indicates that the number of cords is unspecified.

ChassisElementCount

The number of element records that follow. A value of 0x00 indicates that no elements follow.

ChassisElementRecordLength

The length of each **EFI_MISC_ELEMENTS** structure. Type **EFI_MISC_ELEMENTS** is defined in "Related Definitions" below.

ChassisElements

Provides additional information about each element contained in the chassis. If present, then these <code>ChassisElementCounts</code> consist of <code>ChassisElements</code> of length <code>EFI_MISC_ELEMENTS</code>.

Description

This data record refers to the chassis manufacturer. This data record is a structure.

The type definition structure for **EFI_MISC_CHASSIS_MANUFACTURER_DATA** is in SMBIOS 2.3.4, Type 3, in the following tables:

- Table 3.3.4.1
- Table 3.3.4.2
- Table 3.3.4.3
- Table 3.3.4.4

For this data record, efi_subclass_type1_header. RecordType = efi_misc_chassis_manufacturer_record_number. Type efi_subclass_type1_header is defined in the lntel@Platform Innovation Framework for EFI Data Hub Subclass Design Guide.



Related Definitions

```
//*********************
// Record number
//******************************
#define EFI_MISC_CHASSIS_MANUFACTURER_RECORD_NUMBER
                                                   0 \times 000000005
//*****************
// EFI_MISC_CHASSIS_STATUS
//****************
typedef struct {
 UINT32 EFI_MISC_CHASSIS_TYPE
                                   :16;
 UINT32 ChassisLockPresent
                                   :1;
 UINT32 Reserved
                                   :15;
} EFI_MISC_CHASSIS_STATUS;
//********************************
// EFI_MISC_CHASSIS_TYPE
//*******************
typedef enum {
 EfiMiscChassisTypeOther = 0x1,
 EfiMiscChassisTypeUnknown = 0x2,
 EfiMiscChassisTypeDeskTop = 0x3,
 EfiMiscChassisTypeLowProfileDesktop = 0x4,
 EfiMiscChassisTypePizzaBox = 0x5,
 EfiMiscChassisTypeMiniTower = 0x6,
 EfiMiscChassisTypeTower = 0x7,
 EfiMiscChassisTypePortable = 0x8,
 EfiMiscChassisTypeLapTop = 0x9,
 EfiMiscChassisTypeNotebook = 0xA,
 EfiMiscChassisTypeHandHeld = 0xB,
 EfiMiscChassisTypeDockingStation = 0xC,
 EfiMiscChassisTypeAllInOne = 0xD,
 EfiMiscChassisTypeSubNotebook = 0xE,
 EfiMiscChassisTypeSpaceSaving = 0xF,
 EfiMiscChassisTypeLunchBox = 0x10,
 EfiMiscChassisTypeMainServerChassis = 0x11,
 EfiMiscChassisTypeExpansionChassis = 0x12,
 EfiMiscChassisTypeSubChassis = 0x13,
 EfiMiscChassisTypeBusExpansionChassis = 0x14,
 EfiMiscChassisTypePeripheralChassis = 0x15,
 EfiMiscChassisTypeRaidChassis = 0x16,
 EfiMiscChassisTypeRackMountChassis = 0x17,
 EfiMiscChassisTypeSealedCasePc = 0x18,
 EfiMiscChassisMultiSystemChassis = 0x19
} EFI_MISC_CHASSIS_TYPE;
```

```
//*******************
// EFI MISC CHASSIS STATE
//*******************
typedef enum {
 EfiChassisStateOther = 1,
 EfiChassisStateUnknown = 2,
 EfiChassisStateSafe = 3,
 EfiChassisStateWarning = 4,
 EfiChassisStateCritical = 5,
 EfiChassisStateNonRecoverable = 6
} EFI_MISC_CHASSIS_STATE;
//********************
// EFI_MISC_CHASSIS_SECURITY_STATE
//********************
typedef enum {
 EfiChassisSecurityStatusOther = 1,
 EfiChassisSecurityStatusUnknown = 2,
 EfiChassisSecurityStatusNone = 3,
 EfiChassisSecurityStatusExternalInterfaceLockedOut = 4,
 EfiChassisSecurityStatusExternalInterfaceLockedEnabled = 5
} EFI_MISC_CHASSIS_SECURITY_STATE;
//****************************
// EFI MISC ELEMENTS
//*******************
typedef struct {
 EFI MISC ELEMENT TYPE
                        ChassisElementType;
 EFI INTER LINK DATA
                        ChassisElementStructure:
 EFI BASE BOARD TYPE
                        ChassisBaseBoard;
 UINT32
                        ChassisElementMinimum;
 UINT32
                        ChassisElementMaximum;
} EFI MISC ELEMENTS;
  ChassisElementType
       Specifies how to decode the other fields. If ChassisElementType = 0, then the
       ChassisBaseBoard field is valid and ChassisElementStructure is
       invalid. If ChassisElementType = 1, then vice versa. See below for the
       definition of EFI MISC ELEMENT TYPE.
```

ChassisElementStructure

Specifies a link to a structure associated with this record. Only valid if

RecordType = 1. Type <u>EFI_INTER_LINK_DATA</u> is defined in the <u>Intel®</u>

Platform Innovation Framework for EFI Data Hub Subclass Design Guide.



ChassisBaseBoard

```
Specifies an <u>EFI_BASE_BOARD_TYPE</u>. Only valid if RecordType = 0. Type <u>EFI_BASE_BOARD_TYPE</u> is defined in "Related Definitions" in <u>EFI_MISC_BASE_BOARD_MANUFACTURER_DATA</u>.
```

ChassisElementMinimum

The minimum number of an element type that can be installed in the chassis for the chassis to properly operate. The valid range is 0x00 to 0xFE.

ChassisElementMaximum

The maximum number of an element type that can be installed in the chassis for the chassis to properly operate. The valid range is 0x01 to 0xFF.

RecordType

0 = **EFI_BASE_BOARD_TYPE**. Type **EFI_BASE_BOARD_TYPE** is defined in "Related Definitions" in **EFI_MISC_BASE_BOARD_MANUFACTURER_DATA**.

1 = Link to other structure. For example, *RecordType* could link to a <u>system power</u> supply (type 39) structure.

Type

The SMBIOS record type other than type 2 (baseboard information).

Reserved

Reserved for future use. Must be initialized to zero.



Port Connector Information (Type 8)

EFI_MISC_PORT_INTERNAL_CONNECTOR_DESIGNATOR_DATA

Summary

This data record refers to the connector designator that is internal to the chassis.

Prototype

Parameters

PortInternalConnectorDesignator

The connector designator that is internal to the chassis. Type **STRING_REF** is defined in the *Intel*® *Platform Innovation Framework for EFI Human Interface Infrastructure Specification*.

PortExternalConnectorDesignator

The connector designator that is external to the chassis.

PortInternalConnectorType

The internal port connector type. Type **EFI_MISC_PORT_CONNECTOR_TYPE** is defined in "Related Definitions" below.

PortExternalConnectorType

The external port connector type.

PortType

The function of the port. Type **EFI_MISC_PORT_TYPE** is defined in "Related Definitions" below.

PortPath

The path to the physical device. Type **EFI_DEVICE_PATH** is defined in **LocateDevicePath()** in the *EFI 1.10 Specification*.



Description

This data record refers to the connector designator that is internal to the chassis. This data record is a structure.

The type definition structure for **EFI_MISC_PORT_INTERNAL_CONNECTOR_DESIGNATOR_DATA** is in SMBIOS 2.3.4, Type 8, in the following tables:

- Table 3.3.9.2
- Table 3.3.9.3

For this data record, **EFI_SUBCLASS_TYPE1_HEADER** • RecordType = **EFI_MISC_PORT_INTERNAL_CONNECTOR_DESIGNATOR_RECORD_NUMBER**. Type **EFI_SUBCLASS_TYPE1_HEADER** is defined in the *Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide*.

```
//*******************************
// Record number
//****************
#define EFI MISC PORT INTERNAL CONNECTOR DESIGNATOR RECORD NUMBER
                                                0x0000006
//*******************
// EFI_MISC_PORT_CONNECTOR_TYPE
//****************************
typedef enum {
 EfiPortConnectorTypeNone = 0x0,
 EfiPortConnectorTypeCentronics = 0x1,
 EfiPortConnectorTypeMiniCentronics = 0x2,
 EfiPortConnectorTypeProprietary = 0x3,
 EfiPortConnectorTypeDB25Male = 0x4,
 EfiPortConnectorTypeDB25Female = 0x5,
 EfiPortConnectorTypeDB15Male = 0x6,
 EfiPortConnectorTypeDB15Female = 0x7,
 EfiPortConnectorTypeDB9Male = 0x8,
 EfiPortConnectorTypeDB9Female = 0x9,
 EfiPortConnectorTypeRJ11 = 0xA,
 EfiPortConnectorTypeRJ45 = 0xB,
 EfiPortConnectorType50PinMiniScsi = 0xC,
 EfiPortConnectorTypeMiniDin = 0xD,
 EfiPortConnectorTypeMicriDin = 0xE,
 EfiPortConnectorTypePS2 = 0xF,
 EfiPortConnectorTypeInfrared = 0x10,
```



```
EfiPortConnectorTypeHpHil = 0x11,
 EfiPortConnectorTypeUsb = 0x12,
 EfiPortConnectorTypeSsaScsi = 0x13,
 EfiPortConnectorTypeCircularDin8Male = 0x14,
 EfiPortConnectorTypeCircularDin8Female = 0x15,
 EfiPortConnectorTypeOnboardIde = 0x16,
 EfiPortConnectorTypeOnboardFloppy = 0x17,
 EfiPortConnectorType9PinDualInline = 0x18,
 EfiPortConnectorType25PinDualInline = 0x19,
 EfiPortConnectorType50PinDualInline = 0x1A,
 EfiPortConnectorType68PinDualInline = 0x1B,
 EfiPortConnectorTypeOnboardSoundInput = 0x1C,
 EfiPortConnectorTypeMiniCentronicsType14 = 0x1D,
 EfiPortConnectorTypeMiniCentronicsType26 = 0x1E,
 EfiPortConnectorTypeHeadPhoneMiniJack = 0x1F,
 EfiPortConnectorTypeBNC = 0x20,
 EfiPortConnectorType1394 = 0x21,
 EfiPortConnectorTypePC98 = 0xA0,
 EfiPortConnectorTypePC98Hireso = 0xA1,
 EfiPortConnectorTypePCH98 = 0xA2,
 EfiPortConnectorTypePC98Note = 0xA3,
 EfiPortConnectorTypePC98Full = 0xA4,
 EfiPortConnectorTypeOther = 0xFF
} EFI MISC PORT CONNECTOR TYPE;
//********************
// EFI_MISC_PORT_TYPE
//*****************
typedef enum {
 EfiPortTypeNone = 0,
 EfiPortTypeParallelXtAtCompatible = 1,
 EfiPortTypeParallelPortPs2 = 2,
 EfiPortTypeParallelPortEcp = 3,
 EfiPortTypeParallelPortEpp = 4,
 EfiPortTypeParallelPortEcpEpp = 5,
 EfiPortTypeSerialXtAtCompatible = 6,
 EfiPortTypeSerial16450Compatible = 7,
 EfiPortTypeSerial16550Compatible = 8,
 EfiPortTypeSerial16550ACompatible = 9,
 EfiPortTypeScsi = A,
 EfiPortTypeMidi = B,
 EfiPortTypeJoyStick = C,
 EfiPortTypeKeyboard = D,
```



```
EfiPortTypeMouse = E,
 EfiPortTypeSsaScsi = F,
 EfiPortTypeUsb = 10,
 EfiPortTypeFireWire = 11,
 EfiPortTypePcmciaTypeI = 12,
 EfiPortTypePcmciaTypeII = 13,
 EfiPortTypePcmciaTypeIII = 14,
 EfiPortTypeCardBus = 15,
 EfiPortTypeAccessBusPort = 16,
 EfiPortTypeScsiII = 17,
 EfiPortTypeScsiWide = 18,
 EfiPortTypePC98 = 19,
 EfiPortTypePC98Hireso = 1A,
 EfiPortTypePCH98 = 1B,
 EfiPortTypeVideoPort = 1C,
 EfiPortTypeAudioPort = 1D,
 EfiPortTypeModemPort = 1E,
 EfiPortTypeNetworkPort = 1F,
 EfiPortType8251Compatible = A0,
 EfiPortType8251FifoCompatible = A1,
 EfiPortTypeOther = FF
} EFI_MISC_PORT_TYPE;
```



System Slots (Type 9)

EFI MISC SYSTEM SLOT DESIGNATION DATA

Summary

This data record refers to a system slot.

Prototype

```
typedef struct {
 STRING REF
                                 SlotDesignation;
 EFI MISC SLOT TYPE
                                 SlotType;
 EFI_MISC_SLOT_DATA_BUS_WIDTH
                                 SlotDataBusWidth:
 EFI MISC SLOT USAGE
                                 SlotUsage;
 EFI_MISC_SLOT_LENGTH
                                 SlotLength;
 UINT16
                                 SlotId;
 EFI MISC SLOT CHARACTERISTICS SlotCharacteristics:
 EFI DEVICE PATH PROTOCOL
                                 SlotDevicePath;
} EFI_MISC_SYSTEM_SLOT_DESIGNATION_DATA;
```

Parameters

SlotDesignation

The destination string of the slot. Type **STRING_REF** is defined in the *Intel*® *Platform Innovation Framework for EFI Human Interface Infrastructure Specification*.

SlotType

The type of slot. Type **EFI_MISC_SLOT_TYPE** is defined in "Related Definitions" below.

SlotDataBusWidth

The bit width of the slot. Type **EFI_MISC_SLOT_DATA_BUS_WIDTH** is defined in "Related Definitions" below.

SlotUsage

Indicates how the slot is currently used. Type **EFI_MISC_SLOT_USAGE** is defined in "Related Definitions" below.

SlotLength

The physical length of the slot. Type **EFI_MISC_SLOT_LENGTH** is defined in "Related Definitions" below.

SlotId

The logical slot identification. The ID varies depending upon the type of slot. Micro Channel Architecture (MCA) is 0x01 through 0x0F. EISA is 0x01 through 0x0F. PCI/AGP/PCI-X is 0x00x through 0x00y, where xx and yy are determined by the PCI IRQ routing table. PCMCIA is 0xyxx, where yy is the socket number and xx is the adapter number.



SlotCharacteristics

The characteristics of the slot. Type **EFI_MISC_SLOT_CHARACTERISTICS** is defined in "Related Definitions" below.

SlotDevicePath

The path to the physical device. Type **EFI_DEVICE_PATH** is defined in **LocateDevicePath()** in the *EFI 1.10 Specification*.

Description

This data record refers to a system slot. This data record is a structure.

The type definition structure for **EFI_MISC_SYSTEM_SLOT_DESIGNATION_DATA** is in SMBIOS 2.3.4, Type 9, in the following tables:

- Table 3.3.10.1
- Table 3.3.10.2
- Table 3.3.10.3
- Table 3.3.10.4
- Table 3.3.10.5
- Table 3.3.10.6
- Table 3.3.10.7

For this data record, EFI_SUBCLASS_TYPE1_HEADER • RecordType = EFI_MISC_SYSTEM_SLOT_DESIGNATION_RECORD_NUMBER. Type EFI_SUBCLASS_TYPE1_HEADER is defined in the Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide.



```
EfiSlotTypeVlVesa = 0x8,
 EfiSlotTypeProprietary = 0x9,
 EfiSlotTypeProcessorCardSlot = 0xA,
 EfiSlotTypeProprietaryMemoryCardSlot = 0xB,
 EfiSlotTypeIORiserCardSlot = 0xC,
 EfiSlotTypeNuBus = 0xD,
 EfiSlotTypePci66MhzCapable = 0xE,
 EfiSlotTypeAgp = 0xF,
 EfiSlotTypeApg2X = 0x10,
 EfiSlotTypeAgp4X = 0x11,
 EfiSlotTypePciX = 0x12,
 EfiSlotTypeAgp8x = 0x13,
 EfiSlotTypePC98C20 = 0xA0,
 EfiSlotTypePC98C24 = 0xA1,
 EfiSlotTypePC98E = 0xA2,
 EfiSlotTypePC98LocalBus = 0xA3,
 EfiSlotTypePC98Card = 0xA4
} EFI_MISC_SLOT_TYPE;
//****************
// EFI_MISC_SLOT_DATA_BUS_WIDTH
//******************
typedef enum {
 EfiSlotDataBusWidthOther = 1,
 EfiSlotDataBusWidthUnknown = 2,
 EfiSlotDataBusWidth8Bit = 3,
 EfiSlotDataBusWidth16Bit = 4,
 EfiSlotDataBusWidth32Bit = 5,
 EfiSlotDataBusWidth64Bit = 6,
 EfiSlotDataBusWidth128Bit = 7
} EFI_MISC_SLOT_DATA_BUS_WIDTH;
//*******************
// EFI_MISC_SLOT_USAGE
//*****************
typedef enum {
 EfiSlotUsageOther = 1,
 EfiSlotUsageUnknown = 2,
 EfiSlotUsageAvailable = 3,
 EfiSlotUsageInUse = 4
} EFI_MISC_SLOT_USAGE;
```



```
//******************
// EFI_MISC_SLOT_LENGTH
//****************
typedef enum {
 EfiSlotLengthOther = 1,
 EfiSlotLengthUnknown = 2,
 EfiSlotLengthShort = 3,
 EfiSlotLengthLong = 4
} EFI MISC SLOT LENGTH;
//******************
// EFI_MISC_SLOT_CHARACTERISTICS
//*******************************
typedef struct {
 UINT32 CharacteristicsUnknown :1;
 UINT32 Provides50Volts
                            :1;
 UINT32 Provides33Volts
                           :1;
 UINT32 SharedSlot
                           :1;
 UINT32 PcCard16Supported
                           :1;
 UINT32 CardBusSupported
                           :1;
 UINT32 ZoomVideoSupported
                           :1;
 UINT32 ModemRingResumeSupported :1;
 UINT32 PmeSignalSupported
                        :1;
 UINT32 HotPlugDevicesSupported :1;
 UINT32 SmbusSignalSupported
                           :1;
 UINT32 Reserved
                            :21;
} EFI_MISC_SLOT_CHARACTERISTICS;
```



Onboard Devices Information (Type 10)

EFI_MISC_ONBOARD_DEVICE_DATA

Summary

This data record refers to an onboard device that is present in the system.

Prototype

Parameters

OnBoardDeviceDescription

The description of the onboard device. Type **STRING_REF** is defined in the *Intel*® *Platform Innovation Framework for EFI Human Interface Infrastructure*Specification.

OnBoardDeviceType

The type of device and its status. Type **EFI_MISC_ONBOARD_DEVICE_STATUS** is defined in "Related Definitions" below.

OnBoardDevicePath

The path to the physical device. Type **EFI_DEVICE_PATH** is defined in **LocateDevicePath()** in the *EFI 1.10 Specification*.

Description

This data record refers to an onboard device that is present in the system. This data record is a **UINT16**.

The type definition structure for **EFI_MISC_ONBOARD_DEVICE_DATA** is in SMBIOS 2.3.4, Type 10, Table 3.3.11.1.

For this data record, <u>EFI_SUBCLASS_TYPE1_HEADER</u>. RecordType = <u>EFI_MISC_ONBOARD_DEVICE_RECORD_NUMBER</u>. Type <u>EFI_SUBCLASS_TYPE1_HEADER</u> is defined in the <u>Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide</u>.



```
//****************************
// EFI_MISC_ONBOARD_DEVICE_STATUS
//****************
typedef struct {
 UINT32 DeviceType
                      :16;
 UINT32 DeviceEnabled
                       :1;
 UINT32 Reserved
                       :15;
} EFI_MISC_ONBOARD_DEVICE_STATUS;
       Values for DeviceType are defined in EFI_MISC_ONBOARD_DEVICE_TYPE
       below.
//***************************
// EFI_MISC_ONBOARD_DEVICE_TYPE
//*******************************
typedef enum {
 EfiOnBoardDeviceTypeOther = 1,
 EfiOnBoardDeviceTypeUnknown = 2,
 EfiOnBoardDeviceTypeVideo = 3,
 EfiOnBoardDeviceTypeScsiController = 4,
 EfiOnBoardDeviceTypeEthernet = 5,
 EfiOnBoardDeviceTypeTokenRing = 6,
 EfiOnBoardDeviceTypeSound = 7
} EFI_MISC_ONBOARD_DEVICE_TYPE;
```



OEM Strings (Type 11)

EFI_MISC_OEM_STRING_DATA

Summary

This data record refers to an OEM string.

Prototype

Parameters

OemStringRef

The reference to a string. Type **STRING_REF** is defined in the *Intel® Platform Innovation Framework for EFI Human Interface Infrastructure Specification*.

NumberOfInstallableLanguages

As defined in **EFI_MISC_OEM_STRING_DATA**. If the record does not exist, then one language is assumed.

Description

This data record refers to an OEM string. This data record is a string.

```
The type definition structure for EFI_MISC_OEM_STRING_DATA is in SMBIOS 2.3.4, Type 11.
```

```
For this data record, EFI_SUBCLASS_TYPE1_HEADER. RecordType = EFI_MISC_OEM_STRING_RECORD_NUMBER. Type EFI_SUBCLASS_TYPE1_HEADER is defined in the Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide.
```



System Configuration Options (Type 12)

EFI_MISC_SYSTEM_OPTION_STRING_DATA

Summary

This data record refers to a system configuration option string.

Prototype

Parameters

```
SystemOptionStringRef
```

The reference to a string. Type **STRING_REF** is defined in the *Intel® Platform Innovation Framework for EFI Human Interface Infrastructure Specification*.

NumberOfInstallableLanguages

As defined in **EFI_MISC_OEM_STRING_DATA**. If the record does not exist, then one language is assumed.

Description

This data record refers to a system configuration option string. This data record is a string.

The type definition structure for **EFI_MISC_SYSTEM_OPTION_STRING_DATA** is in SMBIOS 2.3.4, Type 12.

For this data record, EFI_SUBCLASS_type1_header. RecordType = EFI_MISC_SYSTEM_OPTION_STRING_RECORD_NUMBER. Type EFI_SUBCLASS_type1_header is defined in the Lntel@Platform Innovation Framework for EFI Data Hub Subclass Design Guide.



BIOS Language Information (Type 13)

Number of Installable Languages

EFI_MISC_NUMBER_OF_INSTALLABLE_LANGUAGES_DATA

Summary

This data record refers to an OEM string.

Prototype

Parameters

NumberOfInstallableLanguages

The number of languages supported. This parameter is one based.

```
LanguageFlags
```

The language flags. Type **EFI_MISC_LANGUAGE_FLAGS** is defined in "Related Definitions" below.

CurrentLanguageNumber

The current language number.

Description

This data record refers to an OEM string. This data record is a **UINT16**.

```
The type definition structure for
```

```
EFI_MISC_NUMBER_OF_INSTALLABLE_LANGUAGES_DATA is in SMBIOS 2.3.4, Type 13.
```

```
For this data record, <a href="mailto:efi_subclass_type1_header">efi_subclass_type1_header</a>. <a href="mailto:RecordType">RecordType</a> = <a href="mailto:efi_misc_number">efi_misc_number</a>. <a href="mailto:type1">Type</a> = <a href="mailto:efi_subclass_type1_header">efi_subclass_type1_header</a> is defined in the <a href="mailto:lntel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide">efi_subclass Design Guide</a>.
```



Related Definitions

AbbreviatedLanguageFormat

If *AbbreviatedLanguageFormat* is 0b, then the string is the two-character ISO 639 language name directly followed by the two-character ISO 3166 territory name.

If AbbreviatedLanguageFormat is 1b, then the string is in the form of "ISO 639 Language Name | ISO 3166 Territory Name | Encoding Method."

Reserved

Reserved for future use. Must be initialized to zero.



System Language String

EFI_MISC_SYSTEM_LANGUAGE_STRING_DATA

Summary

This data record refers to a language string.

Prototype

Parameters

LanguageId

A number between 1 and NumberOfInstallableLanguages. See EFI_MISC_OEM_STRING_DATA.

If *AbbreviatedLanguageFormat* is 0b, then the string is the two-character ISO 639 language name directly followed by the two-character ISO 3166 territory name.

If AbbreviatedLanguageFormat is 1b, then the string is in the form of "ISO 639 Language Name | ISO 3166 Territory Name | Encoding Method."

See the definition of **EFI_MISC_LANGUAGE_FLAGS** in "Related Definitions" in **EFI_MISC_NUMBER_OF_INSTALLABLE_LANGUAGES_DATA** to detect if this field is in *AbbreviatedLanguageFormat*.

SystemLanguageString

Determines the format of string. Type **STRING_REF** is defined in the *Intel® Platform Innovation Framework for EFI Human Interface Infrastructure Specification*.

Description

This data record refers to a language string. One data record per language is supported. This data record is a string.

The type definition structure for **EFI_MISC_SYSTEM_LANGUAGE_STRING_DATA** is in SMBIOS 2.3.4, Type 13.

For this data record, EFI_MISC_SYSTEM_LANGUAGE_STRING_RECORD_NUMBER. Type EFI_SUBCLASS_TYPE1_HEADER is defined in the Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide.





Group Associations (Type 14)

Group Name

EFI MISC GROUP NAME DATA

Summary

This data record refers to a structure name that groups a set of subclass structures.

Prototype

Parameters

GroupName

A string name that groups a set of subclass structures. Type **STRING_REF** is defined in the *Intel® Platform Innovation Framework for EFI Human Interface Infrastructure Specification*.

NumberGroupItems

The number of group item sets. See **EFI_MISC_GROUP_ITEM_SET_DATA**.

GroupId

The ID of the group.

Description

This data record refers to a structure name that groups a set of subclass structures. The purpose of this record and the **EFI_MISC_GROUP_ITEM_SET_DATA** record is to allow an association of apparently diverse devices. An example could be an integrated circuit chip that contains both a voltage and a current probe. The integrated circuit could be given a group name with the voltage and temperature probes as separate **EFI_MISC_GROUP_ITEM_SET_DATA** records. This data record is a string.

The type definition structure for **EFI_MISC_GROUP_NAME_DATA** is in SMBIOS 2.3.4, Type 14, Offset 0x4.

For this data record, <u>EFI_SUBCLASS_TYPE1_HEADER</u>. RecordType = <u>EFI_MISC_GROUP_NAME_RECORD_NUMBER</u>. Type <u>EFI_SUBCLASS_TYPE1_HEADER</u> is defined in the <u>Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide</u>.

Draft for Review





Group Item Set Element

EFI_MISC_GROUP_ITEM_SET_DATA

Summary

This data record refers to a group item set element.

Prototype

Parameters

SubClass

The data hub subclass that is associated with the *GroupLink*. Type **EFI_GUID** is defined in **InstallProtocolInterface()** in the *EFI 1.10 Specification*.

GroupLink

The *Producer*, *Instance*, and *SubInstance* of a data hub structure. Type **EFI_INTER_LINK_DATA** is defined in the *Intel® Platform Innovation Framework* for *EFI Data Hub Subclass Design Guide*.

GroupId

The ID of the group.

GroupElementId

A number between 1 and NumberGroupItems for the specified GroupId. See EFI_MISC_GROUP_NAME_DATA.

Description

This data record refers to a group item set element. Each set is identified by a group ID and each element is identified by an element ID. This data record is a structure.

The type definition structure for **EFI_MISC_GROUP_ITEM_SET_DATA** is in SMBIOS 2.3.4, Type 14, Offset 0x5 and 0x6.

For this data record, <u>EFI_SUBCLASS_TYPE1_HEADER</u>. RecordType = <u>EFI_MISC_GROUP_ITEM_SET_RECORD_NUMBER</u>. Type <u>EFI_SUBCLASS_TYPE1_HEADER</u> is defined in the <u>Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide</u>.





Built-in Pointing Device (Type 21)

EFI_MISC_POINTING_DEVICE_TYPE_DATA

Summary

This data record refers to a pointing device.

Prototype

Parameters

PointingDeviceType

The type of device and its status. Type **EFI_MISC_POINTING_DEVICE_TYPE** is defined in "Related Definitions" below.

PointingDeviceInterface

The type of device interface. Type **EFI_MISC_POINTING_DEVICE_INTERFACE** is defined in "Related Definitions" below.

NumberPointingDeviceButtons

The number of buttons on the pointing device.

PointingDevicePath

The path to the physical device. Type **EFI_DEVICE_PATH** is defined in **LocateDevicePath()** in the *EFI 1.10 Specification*.

Description

This data record refers to a pointing device. This data record is an enumeration.

The type definition structure for **EFI_MISC_POINTING_DEVICE_TYPE_DATA** is in SMBIOS 2.3.4, Type 21, in the following tables:

- Table 3.3.22.1
- Table 3.3.22.2

For this data record, EFI_MISC_POINTING_DEVICE_TYPE_RECORD_NUMBER. Type EFI_SUBCLASS_TYPE1_HEADER is defined in the Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide.



```
//**********************
// Record number
//*****************************
#define EFI MISC POINTING DEVICE TYPE RECORD NUMBER
                                                0 \times 00000000F
//****************
// EFI_MISC_POINTING_DEVICE_TYPE
//*******************************
typedef enum {
 EfiPointingDeviceTypeOther = 1,
 EfiPointingDeviceTypeUnknown = 2,
 EfiPointingDeviceTypeMouse = 3,
 EfiPointingDeviceTypeTrackBall = 4,
 EfiPointingDeviceTypeTrackPoint = 5,
 EfiPointingDeviceTypeGlidePoint = 6,
 EfiPointingDeviceTouchPad = 7,
 EfiPointingDeviceTouchScreen = 8,
 EfiPointingDeviceOpticalSensor = 9
} EFI MISC POINTING DEVICE TYPE;
//******************
// EFI MISC POINTING DEVICE INTERFACE
//*******************************
typedef enum {
 EfiPointingDeviceInterfaceOther = 1,
 EfiPointingDeviceInterfaceUnknown = 2,
 EfiPointingDeviceInterfaceSerial = 3,
 EfiPointingDeviceInterfacePs2 = 4,
 EfiPointingDeviceInterfaceInfrared = 5,
 EfiPointingDeviceInterfaceHpHil = 6,
 EfiPointingDeviceInterfaceBusMouse = 7,
 EfiPointingDeviceInterfaceADB = 8,
 EfiPointingDeviceInterfaceBusMouseDB9 = 0xA0,
 EfiPointingDeviceInterfaceBusMouseMicroDin = 0xA1,
 EfiPointingDeviceInterfaceUsb = 0xA2
} EFI MISC POINTING DEVICE INTERFACE;
```



Portable Battery (Type 22)

EFI_MISC_BATTERY_LOCATION_DATA

Summary

This data record refers to a portable battery.

Prototype

```
typedef struct {
 STRING REF
                                     BatteryLocation;
 STRING REF
                                     BatteryManufacturer;
 STRING_REF
                                     BatteryManufactureDate;
 STRING REF
                                     BatterySerialNumber;
 STRING_REF
                                     BatteryDeviceName;
 STRING_REF
                                     BatterySbdsVersionNumber;
                                     BatterySbdsDeviceChemistry;
 STRING REF
 EFI_MISC_BATTERY_DEVICE_CHEMISTRY BatteryDeviceChemistry;
 EFI_EXP_BASE10_DATA
                                     BatteryDesignCapacity;
 EFI_EXP_BASE10_DATA
                                     BatteryDesignVoltage;
 UINT16
                                     BatteryMaximumError;
 UINT16
                                     BatterySbdsSerialNumber;
 EFI_MISC_BATTERY_SBDS_MANUFACTURE_DATE
                                     BatterySbdsManufacturingDate;
                                     BatteryOemSpecific;
} EFI_MISC_BATTERY_LOCATION_DATA;
```

Parameters

```
BatteryLocation
```

The portable battery location. Type **STRING_REF** is defined in the *Intel® Platform Innovation Framework for EFI Human Interface Infrastructure Specification*.

```
BatteryManufacturer
```

The portable battery manufacturer.

```
BatteryManufactureDate
```

The manufacture date of the portable battery.

```
BatterySerialNumber
```

The battery serial number.

BatteryDeviceName

The battery device name.

BatterySbdsVersionNumber

The Smart Battery Data Specification (SBDS) version supported by this battery.



BatterySbdsDeviceChemistry

The battery chemistry identifier. For this field to be valid, BatteryDeviceChemistry must be set to 0x02 or unknown.

BatteryDeviceChemistry

The battery device chemistry. Type **EFI_MISC_BATTERY_DEVICE_CHEMISTRY** is defined in "Related Definitions" below.

BatteryDesignCapacity

The battery design capacity in watt-hours. If the value is unknown, the field contains 0x00. Type **EFI_EXP_BASE10_DATA** is defined in the *Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide*.

BatteryDesignVoltage

The design voltage in volts. If the value is unknown, the field is 0x00.

BatteryMaximumError

The maximum error in watt-hour data that is reported by the battery. Error is a percentage from 0 to 100. If the value is unknown, the field contains 0xFFFF.

BatterySbdsSerialNumber

The SBDS version supported by this battery.

${\it BatterySbdsManufacturingDate}$

The battery's SBDS manufacture date. For this field to be valid, the <code>BatteryManufacturerDate</code> STRING_REF must be NULL. Type <code>EFI_MISC_BATTERY_SBDS_MANUFACTURE_DATE</code> is defined in "Related Definitions" below.

BatteryOemSpecific

OEM- or BIOS-vendor-specific information.

Description

This data record refers to a portable battery. This data record is a structure.

The type definition structure for **EFI_MISC_BATTERY_LOCATION_DATA** is in SMBIOS 2.3.4, Type 22, Table 3.3.23.1.

For this data record, EFI_MISC_BATTERY_LOCATION_RECORD_NUMBER. Type EFI_SUBCLASS_type1_header is defined in the EFI Data Hub Subclass Design Guide.



Related Definitions

```
//*******************
// Record number
//****************
#define EFI_MISC_BATTERY_LOCATION_RECORD_NUMBER 0x00000010
//*******************************
// EFI_MISC_BATTERY_DEVICE_CHEMISTRY
//*******************************
typedef enum {
 EfiBatteryDeviceChemistryTypeOther = 1,
 EfiBatteryDeviceChemistryTypeUnknown = 2,
 EfiBatteryDeviceChemistryTypeLeadAcid = 3,
 EfiBatteryDeviceChemistryTypeNickelCadmium = 4,
 EfiBatteryDeviceChemistryTypeNickelMetalHydride = 5,
 EfiBatteryDeviceChemistryTypeLithiumIon = 6,
 EfiBatteryDeviceChemistryTypeZincAir = 7,
 EfiBatteryDeviceChemistryTypeLithiumPolymer = 8
} EFI MISC BATTERY DEVICE CHEMISTRY;
//****************************
// EFI_MISC_BATTERY_SBDS_MANUFACTURE_DATE
//*******************************
typedef struct {
 UINT32 Date
                       :5;
 UINT32 Month
                        :4;
 UINT32 Year
                        :7;
 UINT32 Reserved
                        :16;
} EFI_MISC_BATTERY_SBDS_MANUFACTURE_DATE;
  Date
       A value in the range 1 to 31.
  Month
       A value in the range 1 to 12.
  Year
       A value in the range 0 to 127 biased by 1980.
  Reserved
```

Reserved for future use. Must be initialized to zero.



System Reset (Type 23)

EFI_MISC_RESET_CAPABILITIES_DATA

Summary

This data record refers to the system reset.

Prototype

Parameters

ResetCapabilities

The system reset capabilities. Type **EFI_MISC_RESET_CAPABILITIES** is defined in "Related Definitions" below.

ResetCount

The number of automatic system resets since the last intentional reset. A value of 0xFFFF indicates that the reset count is unknown.

ResetLimit

The maximum number of automatic resets that can be attempted. A value of 0xFFFF indicates that the limit is unknown.

ResetTimerInterval

The watchdog timer interval in minutes. If this timer is not reset within this value, then the system-reset timer is started. A value of 0xFFFF indicates that the interval is unknown.

ResetTimeout

The number of minutes before a reboot occurs. It occurs after a system power cycle, system reset, or an automatic reset. A value of 0xFFFF indicates that the interval is unknown.

Description

This data record refers to the system reset. This data record is a structure.

The type definition structure for **EFI_MISC_RESET_CAPABILITIES_DATA** is in SMBIOS 2.3.4, Type 23.



Draft for Review Code Definitions

For this data record, EFI_SUBCLASS_type1_header. RecordType = EFI_MISC_RESET_CAPABILITIES_RECORD_NUMBER. Type EFI_SUBCLASS_type1_header is defined in the Lntel@Platform Innovation Framework for EFI Data Hub Subclass Design Guide.

Related Definitions

```
***************
// Record number
//*****************
#define EFI MISC RESET CAPABILITIES RECORD NUMBER
                                        0 \times 00000011
//****************************
// EFI MISC RESET CAPABILITIES
//****************
typedef struct {
 EFI MISC RESET CAPABILITIES TYPE ResetCapabilities;
 UINT16
                           ResetCount;
 UINT16
                           ResetLimit;
 UINT16
                           ResetTimerInterval;
 UINT16
                           ResetTimeout;
} EFI MISC RESET CAPABILITIES;
```

ResetCapabilities

Describes the types of resets that are supported. Type **EFI_MISC_RESET_CAPABILITIES_TYPE** is defined below.

ResetCount

The count of resets since the last intentional reset. A value of 0xFFFF indicates unknown.

ResetLimit

The number of consecutive times to attempt a system reset. A value of 0xFFFF indicates unknown.

ResetTimerInterval

The number of minutes to use for the watchdog timer. A value of 0xFFFF indicates unknown.

ResetTimeout

Indicates the number of minutes before a reboot is initiated. A value of 0xFFFF indicates unknown.



Status

1 =Reset enabled by the user.

BootOption

Indicates the action to be taken following a watchdog reset:

- 00b: Reserved
- 01b: Operating system
- 10b: System utilities
- 11b: Do not reboot

BootOptionOnLimit

Indicates the action to be taken when the reset limit is reached:

- 00b: Reserved
- 01b: Operating system
- 10b: System utilities
- 11b: Do not reboot

WatchdogTimerPresent

1 =The watchdog timer is present.

Reserved

Reserved for future use. Must be initialized to zero



Hardware Security (Type 24)

EFI MISC HARDWARE SECURITY SETTINGS DATA

Summary

This data record refers to the password and reset status of the system.

Prototype

Parameters

```
HardwareSecuritySettings
```

The status of current security settings. Type **EFI_MISC_HARDWARE_SECURITY_SETTINGS** is defined in "Related Definitions" below.

Description

This data record refers to the password and reset status of the system. This data record is a bit map.

The type definition structure for **EFI_MISC_HARDWARE_SECURITY_SETTINGS_DATA** is in SMBIOS 2.3.4, Type 24, Offset 0x4.

```
For this data record, <a href="mailto:EFI_SUBCLASS_TYPE1_HEADER">EFI_MISC_HARDWARE_SECURITY_RECORD_NUMBER</a>. Type

EFI_SUBCLASS_TYPE1_HEADER is defined in the <a href="mailto:Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide">Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide</a>.
```



FrontPanelResetStatus

The current status of the front panel reset:

- 00b: Disabled
- 01b: Enabled
- 10b: Not implemented
- 11b: Unknown

AdministratorPasswordStatus

The current status of the administrator password:

- 00b: Disabled
- 01b: Enabled
- 10b: Not implemented
- 11b: Unknown

KeyboardPasswordStatus

The current status of the keyboard password:

- 00b: Disabled
- 01b: Enabled
- 10b: Not implemented
- 11b: Unknown

PowerOnPasswordStatus

The current status of the power-on password:

- 00b: Disabled
- 01b: Enabled
- 10b: Not implemented
- 11b: Unknown

Reserved

Reserved for future use. Must be initialized to zero.



System Power Controls (Type 25)

System Power Controls (Type 25)

All fields are in Binary Coded Decimal (BCD). Any value out of range is ignored. The DMTF System Power Controls group contains a *Next Scheduled Power-on Time* that is specified as a number of seconds. Management software uses the date and time information that is specified in these structures to calculate the number of seconds from the current time to the specified power-on time. Out-of-range values are ignored.

Scheduled Power-On

EFI_MISC_SCHEDULED_POWER_ON_MONTH_DATA

Summary

This data record refers to the scheduled power-on.

Prototype

Parameters

ScheduledPoweronMonth

The month of the scheduled power-on. A valid number is 1 through 12.

ScheduledPoweronDayOfMonth

The day of the month of the scheduled power-on. Valid values are 1 through 31.

ScheduledPoweronHour

The hour of the scheduled power-on. Valid values are 0 through 23.

ScheduledPoweronMinute

The minute of the scheduled power-on. Valid values are 0 through 59.

ScheduledPoweronSecond

The second of the scheduled power-on. Valid values are 00 through 59.

Description

This data record refers to the scheduled power-on. This data record is a structure.

The type definition structure for **EFI_MISC_SCHEDULED_POWER_ON_MONTH_DATA** is in SMBIOS 2.3.4, Type 25, Table 3.3.26.1.



For this data record, EFI_MISC_SCHEDULED_POWER_ON_MONTH_RECORD_NUMBER. Type EFI_SUBCLASS_TYPE1_HEADER is defined in the Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide.

intel

Voltage Probe (Type 26)

EFI_MISC_VOLTAGE_PROBE_DESCRIPTION_DATA

Summary

This data record refers to a voltage probe.

Prototype

```
typedef struct {
 STRING REF
                                  VoltageProbeDescription;
 EFI_MISC_VOLTAGE_PROBE_LOCATION VoltageProbeLocation;
 EFI_EXP_BASE10_DATA
                                  VoltageProbeMaximumValue:
 EFI EXP BASE10 DATA
                                  VoltageProbeMinimumValue;
 EFI_EXP_BASE10_DATA
                                  VoltageProbeResolution;
 EFI_EXP_BASE10_DATA
                                  VoltageProbeTolerance;
 EFI EXP BASE10 DATA
                                  VoltageProbeAccuracy;
 EFI_EXP_BASE10_DATA
                                  VoltageProbeNominalValue:
 EFI EXP BASE10 DATA
                                  MDLowerNoncriticalThreshold;
 EFI_EXP_BASE10_DATA
                                  MDUpperNoncriticalThreshold;
 EFI_EXP_BASE10_DATA
                                  MDLowerCriticalThreshold:
 EFI EXP BASE10 DATA
                                  MDUpperCriticalThreshold;
                                  MDLowerNonrecoverableThreshold;
 EFI_EXP_BASE10_DATA
 EFI EXP BASE10 DATA
                                  MDUpperNonrecoverableThreshold;
                                  VoltageProbeOemDefined;
} EFI_MISC_VOLTAGE_PROBE_DESCRIPTION_DATA;
```

Parameters

VoltageProbeDescription

A name describing the voltage probe. Type **STRING_REF** is defined in the *Intel*® *Platform Innovation Framework for EFI Human Interface Infrastructure*Specification.

VoltageProbeLocation

The location of the probe and its status. Type **EFI_MISC_VOLTAGE_PROBE_LOCATION** is defined in "Related Definitions" below.

VoltageProbeMaximumValue

The maximum voltage level in volts that is readable by the probe. A value of 0xFFFF FFFF indicates that the value is unknown. Type **EFI_EXP_BASE10_DATA** is defined in the *Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide*.

VoltageProbeMinimumValue

The minimum voltage level in volts that is readable by the probe. A value of 0xFFFF FFFF indicates that the value is unknown.



VoltageProbeResolution

The resolution voltage level in volts that is readable by the probe. A value of 0xFFFF FFFF indicates that the value is unknown.

VoltageProbeTolerance

The tolerance of a value read by the probe in plus/minus volts. A value of 0xFFFF FFFF indicates that the value is unknown

VoltageProbeAccuracy

The accuracy of a value read by the probe in plus/minus one percent. A value of 0xFFFF FFFF indicates that the value is unknown.

VoltageProbeNominalValue

The nominal value in volts for the probe's reading. A value of 0xFFFF FFFF indicates that the value is unknown.

MDLowerNoncriticalThreshold

The lower noncritical threshold for this component

MDUpperNoncriticalThreshold

The upper noncritical threshold for this component.

MDLowerCriticalThreshold

The lower critical threshold for this component.

MDUpperCriticalThreshold

The upper critical threshold for this component.

MDLowerNonrecoverableThreshold

The lower nonrecoverable threshold for this component.

MDUpperNonrecoverableThreshold

The upper nonrecoverable threshold for this component.

VoltageProbeOemDefined

OEM- or BIOS-vendor-specific data.

Description

This data record refers to a voltage probe. This data record is a structure.

The type definition structure for **EFI_MISC_VOLTAGE_PROBE_DESCRIPTION_DATA** is in SMBIOS 2.3.4, Type 26, Table 3.3.27.1, Type 36.

For this data record, eff_subclass_type1_header. Record eff_misc_voltage_probe_description_record_number. Type eff_subclass_type1_header is defined in the eff_Data Hub Subclass Design Guide.



Related Definitions

VoltageProbeSite

The location of the probe within the chassis:

- 00000b: Reserved
- 00001b: Other
- 00010b: Unknown
- 00011b: Processor
- 00100b: Disk
- 00101b: Peripheral bay
- 00110b: System management module
- 00111b: Motherboard
- 01000b: Memory module
- 01001b: Processor module
- 01010b: Power unit
- 01011b: Add-in card
- 01100b-11111b: Reserved

VoltageProbeStatus

The last reading from the probe:

- 000b: Reserved
- 001b: Other
- 010b: Unknown
- 011b: OK
- 100b: Noncritical



• 101b: Critical

• 110b: Nonrecoverable

• 111b: Reserved

Reserved

Reserved for future use. Must be initialized to zero.



Cooling Device (Type 27)

EFI MISC COOLING DEVICE TEMP LINK DATA

Summary

This data record refers to a temperature probe.

Prototype

Parameters

CoolingDeviceType

```
The type of cooling device and its status. Type EFI_MISC_COOLING_DEVICE_TYPE is defined in "Related Definitions" below.
```

CoolingDeviceTemperatureLink

The ID of a temperature probe. See <u>Temperature Probe (Type 28)</u>. Type <u>EFI_INTER_LINK_DATA</u> is defined in the <u>Intel® Platform Innovation Framework</u> for EFI Data Hub Subclass Design Guide.

CoolingDeviceUnitGroup

The group of which this cooling device is a member. A value of 0x0000 indicates that the device is not a member of a group. A nonzero value indicates that multiple devices are in the same group and implies a redundant configuration.

CoolingDeviceNominalSpeed

The nominal value of the cooling device's rotational speed. A value of 0xFFFF FFFF indicates that the value is unknown. Type **EFI_EXP_BASE10_DATA** is defined in the *Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide*.

CoolingDeviceOemDefined

OEM- or BIOS-specific data.

Description

This data record refers to a temperature probe. See <u>Temperature Probe (Type 28)</u>. This data record is a structure.

The type definition structure for **EFI_MISC_COOLING_DEVICE_TEMP_LINK_DATA** is in SMBIOS 2.3.4, Type 27, Table 3.3.28.1.



For this data record, EFI_SUBCLASS_TYPE1_HEADER . RecordType = EFI_MISC_COOLING_DEVICE_TEMP_LINK_RECORD_NUMBER. Type EFI_SUBCLASS_TYPE1_HEADER is defined in the Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide.

Related Definitions

```
//********************
// Record number
//****************
#define EFI_MISC_COOLING_DEVICE_TEMP_LINK_RECORD_NUMBER
                                    0x00000015
//*******************
// EFI_MISC_COOLING_DEVICE_TYPE
//******************
typedef struct {
 UINT32 CoolingDevice
                           :5;
 UINT32 CoolingDeviceStatus
                           :3;
 UINT32 Reserved
                           :24;
} EFI_MISC_COOLING_DEVICE_TYPE;
```

CoolingDevice

The type of cooling device:

- 00000b: Reserved
- 00001b: Other
- 00010b: Unknown
- 00011b: Fan
- 00100b: Centrifugal blower
- 00101b: Chip fan
- 00110b: Cabinet fan
- 00111b: Power supply fan
- 01000b: Heat pipe
- 01001b: Integrated refrigeration
- 01010b-10011b: Reserved
- 10100b: Active cooling
- 10101b: Passive cooling
- 10110b–11111b: Reserved

CoolingDeviceStatus

The last state of the device:

• 000b: Reserved

• 001b: Other

• 010b: Unknown

• 011b: OK

• 100b: Noncritical

• 101b: Critical

• 110b: Nonrecoverable

• 111b: Reserved

Reserved

Reserved for future use. Must be initialized to zero.



Temperature Probe (Type 28)

EFI_MISC_TEMPERATURE_PROBE_DESCRIPTION_DATA

Summary

This data record refers to a temperature probe.

Prototype

```
typedef struct {
  STRING REF
                           TemperatureProbeDescription;
 EFI_MISC_TEMPERATURE_PROBE_LOCATION
                           TemperatureProbeLocation:
 EFI EXP BASE10 DATA
                           TemperatureProbeMaximumValue:
 EFI_EXP_BASE10_DATA
                           TemperatureProbeMinimumValue;
 EFI_EXP_BASE10_DATA
                           TemperatureProbeResolution;
 EFI EXP BASE10 DATA
                           TemperatureProbeTolerance;
 EFI_EXP_BASE10_DATA
                           TemperatureProbeAccuracy:
 EFI EXP BASE10 DATA
                           TemperatureProbeNominalValue;
 EFI_EXP_BASE10_DATA
                           MDLowerNoncriticalThreshold;
 EFI EXP BASE10 DATA
                           MDUpperNoncriticalThreshold:
 EFI EXP BASE10 DATA
                           MDLowerCriticalThreshold;
 EFI_EXP_BASE10_DATA
                           MDUpperCriticalThreshold;
                           MDLowerNonrecoverableThreshold:
 EFI EXP BASE10 DATA
 EFI EXP BASE10 DATA
                           MDUpperNonrecoverableThreshold;
 UINT32
                           TemperatureProbeOemDefined;
} EFI_MISC_TEMPERATURE_PROBE_DESCRIPTION_DATA;
```

Parameters

TemperatureProbeDescription

A name describing the temperature probe. Type **STRING_REF** is defined in the *Intel® Platform Innovation Framework for EFI Human Interface Infrastructure Specification*.

TemperatureProbeLocation

The location of the probe and its status. Type **EFI_MISC_TEMPERATURE_PROBE_LOCATION** is defined in "Related Definitions" below.

TemperatureProbeMaximumValue

The maximum temperature level in degrees Celsius that is readable by the probe. A value of 0xFFFF FFFF indicates that the value is unknown. Type **EFI_EXP_BASE10_DATA** is defined in the *Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide*.

TemperatureProbeMinimumValue

The minimum temperature level in degrees Celsius that is readable by the probe. A value of 0xFFFF FFFF indicates that the value is unknown.



Draft for Review Code Definitions

TemperatureProbeResolution

The resolution temperature level in degrees Celsius that is readable by the probe. A value of 0xFFFF FFFF indicates that the value is unknown.

TemperatureProbeTolerance

The tolerance of a value read by the probe in plus/minus degrees Celsius. A value of 0xFFFF indicates that the value is unknown.

TemperatureProbeAccuracy

The accuracy of a value read by the probe in plus/minus one percent. A value of 0xFFFF FFFF indicates that the value is unknown.

TemperatureProbeNominalValue

The nominal value in degrees Celsius for the probe's reading. A value of 0xFFFF FFFF indicates that the value is unknown.

MDLowerNoncriticalThreshold

The lower noncritical threshold for this component

MDUpperNoncriticalThreshold

The upper noncritical threshold for this component.

MDLowerCriticalThreshold

The lower critical threshold for this component.

MDUpperCriticalThreshold

The upper critical threshold for this component.

MDLowerNonrecoverableThreshold

The lower nonrecoverable threshold for this component.

MDUpperNonrecoverableThreshold

The upper nonrecoverable threshold for this component.

TemperatureProbeOemDefined

OEM- or BIOS-vendor-specific data.

Description

This data record refers to a temperature probe. This data record is a structure.

The type definition structure for **EFI_MISC_TEMPERATURE_PROBE_DESCRIPTION_DATA** is in SMBIOS 2.3.4, in the following types:

- Type 28, Table 3.3.29.1
- Type 36

For this data record, EFI_SUBCLASS_TYPE1_HEADER . RecordType = EFI_MISC_TEMPERATURE_PROBE_DESCRIPTION_RECORD_NUMBER. Type EFI_SUBCLASS_TYPE1_HEADER is defined in the Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide.



Related Definitions

```
//*******************
// Record number
//***************
#define EFI_MISC_TEMPERATURE_PROBE_DESCRIPTION_RECORD_NUMBER
                                       0x0000016
//*******************************
// EFI_MISC_TEMPERATURE_PROBE_LOCATION
//****************
typedef struct {
 UINT32 TemperatureProbeSite
                            :5;
 UINT32 TemperatureProbeStatus
                            :3;
 UINT32 Reserved
                            :24;
} EFI_MISC_TEMPERATURE_PROBE_LOCATION;
```

TemperatureProbeSite

The location of the probe within the chassis:

- 00000b: Reserved
- 00001b: Other
- 00010b: Unknown
- 00011b: Processor
- 00100b: Disk
- 00101b: Peripheral bay
- 00110b: System management module
- 00111b: Motherboard
- 01000b: Memory module
- 01001b: Processor module
- 01010b: Power unit
- 01011b: Add-in card
- 01100b: Front panel board
- 01101b: Back panel board
- 01110b: Power system board
- 01111b: Drive back plane
- 10000b–11111b: Reserved



Draft for Review

Code Definitions

Temperaure Probe Status

The last temperature status read from the probe:

• 000b: Reserved

• 001b: Other

• 010b: Unknown

• 011b: OK

• 100b: Noncritical

• 101b: Critical

• 110b: Nonrecoverable

• 111b: Reserved

Reserved

Reserved for future use. Must be initialized to zero.



Electrical Current Probe (Type 29)

EFI MISC ELECTRICAL CURRENT PROBE DESCRIPTION DATA

Summary

This data record refers to an electrical current probe.

Prototype

```
typedef struct {
  STRING REF
                           ElectricalCurrentProbeDescription;
 EFI_MISC_ELECTRICAL_CURRENT_PROBE_LOCATION
                           ElectricalCurrentProbeLocation:
 EFI EXP BASE10 DATA
                           ElectricalCurrentProbeMaximumValue:
 EFI_EXP_BASE10_DATA
                           ElectricalCurrentProbeMinimumValue;
 EFI_EXP_BASE10_DATA
                           ElectricalCurrentProbeResolution;
 EFI EXP BASE10 DATA
                           ElectricalCurrentProbeTolerance;
 EFI_EXP_BASE10_DATA
                           ElectricalCurrentProbeAccuracy;
 EFI EXP BASE10 DATA
                           ElectricalCurrentProbeNominalValue;
 EFI_EXP_BASE10_DATA
                           MDLowerNoncriticalThreshold;
 EFI EXP BASE10 DATA
                           MDUpperNoncriticalThreshold;
 EFI EXP BASE10 DATA
                           MDLowerCriticalThreshold;
 EFI_EXP_BASE10_DATA
                          MDUpperCriticalThreshold;
 EFI_EXP_BASE10_DATA
                          MDLowerNonrecoverableThreshold;
 EFI EXP BASE10 DATA
                           MDUpperNonrecoverableThreshold:
 UINT32
                           ElectricalCurrentProbeOemDefined;
} EFI_MISC_ELECTRICAL_CURRENT_PROBE_DESCRIPTION_DATA;
```

Parameters

ElectricalCurrentProbeDescription

A name describing the electrical current probe. Type **STRING_REF** is defined in the *Intel® Platform Innovation Framework for EFI Human Interface Infrastructure*Specification.

ElectricalCurrentProbeLocation

The location of the probe and its status. Type **EFI_MISC_ELECTRICAL_CURRENT_PROBE_LOCATION** is defined in "Related Definitions" below.

ElectricalCurrentProbeMaximumValue

The maximum electrical current level in amperes that is readable by the probe. A value of 0xFFFF FFFF indicates that the value is unknown. Type **EFI_EXP_BASE10_DATA** is defined in the *Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide*.

ElectricalCurrentProbeMinimumValue

The minimum electrical current level in amperes that is readable by the probe. A value of 0xFFFF FFFF indicates that the value is unknown.



Draft for Review Code Definitions

ElectricalCurrentProbeResolution

The resolution electrical current level in amperes that is readable by the probe. A value of 0xFFFF FFFF indicates that the value is unknown.

ElectricalCurrentProbeTolerance

The tolerance in plus/minus amperes of a value read by the probe. A value of 0xFFFF FFFF indicates that the value is unknown.

ElectricalCurrentProbeAccuracy

The accuracy in plus/minus one percent of a value read by the probe. A value of 0xFFFF FFFF indicates that the value is unknown.

ElectricalCurrentProbeNominalValue

The nominal value in amperes for the probe's reading. A value of 0xFFFF FFFF indicates that the value is unknown.

MDLowerNoncriticalThreshold

The lower noncritical threshold for this component

MDUpperNoncriticalThreshold

The upper noncritical threshold for this component.

MDLowerCriticalThreshold

The lower critical threshold for this component.

MDUpperCriticalThreshold

The upper critical threshold for this component.

MDLowerNonrecoverableThreshold

The lower nonrecoverable threshold for this component.

MDUpperNonrecoverableThreshold

The upper nonrecoverable threshold for this component.

ElectricalCurrentProbeOemDefined

OEM- or BIOS-vendor-specific data.

Description

This data record refers to an electrical current probe. This data record is a structure.

The type definition structure for

EFI_MISC_ELECTRICAL_CURRENT_PROBE_DESCRIPTION_DATA is in SMBIOS 2.3.4, in the following types:

- Type 29, Table 3.3.30.1
- Type 36

For this data record, **EFI_SUBCLASS_TYPE1_HEADER** . RecordType = **EFI_MISC_ELECTRICAL_CURRENT_PROBE_DESCRIPTION_RECORD_NUMBER**. Type **EFI_SUBCLASS_TYPE1_HEADER** is defined in the Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide.



Related Definitions

ElectricalCurrentProbeSite

The location of the probe within the chassis:

- 00000b: Reserved
- 00001b: Other
- 00010b: Unknown
- 00011b: Processor
- 00100b: Disk
- 00101b: Peripheral bay
- 00110b: System management module
- 00111b: Motherboard
- 01000b: Memory module
- 01001b: Processor module
- 01010b: Power unit
- 01011b: Add-in card
- 01100b-11111b: Reserved

ElectricalCurrentProbeStatus

The last current status read by the probe:

- 000b: Reserved
- 001b: Other
- 010b: Unknown
- 011b: OK



Draft for Review

Code Definitions

• 100b: Noncritical

• 101b: Critical

• 110b: Nonrecoverable

• 111b: Reserved

Reserved

Reserved for future use. Must be initialized to zero.



Out-of-Band Remote Access (Type 30)

EFI MISC REMOTE ACCESS MANUFACTURER DESCRIPTION DATA

Summary

This data record refers to a manufacturer of the out-of-band access facility.

Prototype

Parameters

RemoteAccessManufacturerNameDescription

A name describing the manufacturer of the out-of-band access facility. Type **STRING_REF** is defined in the *Intel® Platform Innovation Framework for EFI Human Interface Infrastructure Specification*.

RemoteAccessConnections

The current remote access connections. Type **EFI_MISC_REMOTE_ACCESS_CONNECTIONS** is defined in "Related Definitions" below.

Description

This data record refers to a manufacturer of the out-of-band access facility. This data record is a structure.

The type definition structure for

EFI_MISC_REMOTE_ACCESS_MANUFACTURER_DESCRIPTION_DATA is in SMBIOS 2.3.4, Type 30.

For this data record, **EFI_SUBCLASS_TYPE1_HEADER**. RecordType = **EFI_MISC_REMOTE_ACCESS_MANUFACTURER_DESCRIPTION_RECORD_NUMBER**. Type **EFI_SUBCLASS_TYPE1_HEADER** is defined in the Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide.

Related Definitions

Draft for Review Code Definitions

InboundConnectionEnabled

1 = The facility is allowed to initiate outbound connections to receive incoming connections for the purpose of remote operations or problem management.

OutboundConnectionEnabled

1 = The facility is allowed to initiate outbound connections to contact an alert management facility when critical connections occur.

Reserved

Reserved for future use. Must be initialized to zero.



Boot Integrity Services (BIS) Entry Point (Type 31)

EFI_MISC_BIS_ENTRY_POINT_DATA

Summary

This data record refers to the Boot Integrity Services (BIS) entry point address.

Prototype

Parameters

```
BisEntryPoint
```

The physical address of the BIS entry point. Type **EFI_PHYSICAL_ADDRESS** is defined in **AllocatePages()** in the *EFI 1.10 Specification*.

Description

This data record refers to the BIS entry point address. This data record is a structure.

The type definition structure for **EFI_MISC_BIS_ENTRY_POINT_DATA** is in SMBIOS 2.3.4, Type 31.

```
For this data record, <a href="mailto:efi_subclass_type1_header">EFI_MISC_BIS_ENTRY_POINT_RECORD_NUMBER</a>. Type

EFI_SUBCLASS_TYPE1_HEADER is defined in the <a href="mailto:lntel@Platform Innovation Framework for EFI Data Hub Subclass Design Guide">Lntel@Platform Innovation Framework for EFI Data Hub Subclass Design Guide</a>.
```

Related Definitions



System Boot Information (Type 32)

EFI MISC BOOT INFORMATION STATUS DATA

Summary

This data record refers to the system boot information status.

Prototype

Parameters

BootInformationStatus

The system boot information status. Type **EFI_MISC_BOOT_INFORMATION_STATUS_TYPE** is defined in "Related Definitions" below.

BootInformationData

OEM- or product-specific implementations.

Description

This data record refers to the system boot information status. This data record is a structure.

The type definition structure for **EFI_MISC_BOOT_INFORMATION_STATUS_DATA** is in SMBIOS 2.3.4, Type 32.

```
For this data record, <a href="mailto:EFI_SUBCLASS_TYPE1_HEADER">EFI_MISC_BOOT_INFORMATION_STATUS_RECORD_NUMBER</a>. Type <a href="mailto:EFI_SUBCLASS_TYPE1_HEADER">EFI_SUBCLASS_TYPE1_HEADER</a> is defined in the <a href="mailto:Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide">Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide</a>.
```

Related Definitions



```
//*******************
// EFI_MISC_BOOT_INFORMATION_STATUS_TYPE
//*****************
typedef enum {
 EfiBootInformationStatusNoError = 0,
 EfiBootInformationStatusNoBootableMedia = 1,
 EfiBootInformationStatusNormalOSFailedLoading = 2,
 EfiBootInformationStatusFirmwareDetectedFailure = 3,
 EfiBootInformationStatusOSDetectedFailure = 4,
 EfiBootInformationStatusUserRequestedBoot = 5,
 EfiBootInformationStatusSystemSecurityViolation = 6,
 EfiBootInformationStatusPreviousRequestedImage = 7,
 EfiBootInformationStatusWatchdogTimerExpired = 8,
 EfiBootInformationStatusStartReserved = 9,
 EfiBootInformationStatusStartOemSpecific = 128,
 EfiBootInformationStatusStartProductSpecific = 192
} EFI MISC BOOT INFORMATION STATUS TYPE;
```

® NOTE

The last three entries specify the start of a range for reserved, OEM-specific, or product-specific entries respectively.





Management Device (Type 34)

EFI_MISC_MANAGEMENT_DEVICE_DESCRIPTION_DATA

Summary

This data record refers to a management device.

Prototype

Parameters

ManagementDeviceDescription

A name describing the management device. Type **STRING_REF** is defined in the *Intel® Platform Innovation Framework for EFI Human Interface Infrastructure Specification*.

ManagementDeviceType

The type of management device. Type **EFI_MISC_MANAGEMENT_DEVICE_TYPE** is defined in "Related Definitions" below.

ManagementDeviceAddress

The management device address.

ManagementDeviceAddressType

The type of address presented in *ManagementDeviceAddress*. Type **EFI_MISC_MANAGEMENT_DEVICE_ADDRESS_TYPE** is defined in "Related Definitions" below.

Description

This data record refers to a management device. This data record is a structure.

The type definition structure for **EFI_MISC_MANAGEMENT_DEVICE_DESCRIPTION_DATA** is in SMBIOS 2.3.4, Type 34, in the following tables:

- Table 3.3.35.1
- Table 3.3.35.2

For this data record, eff_subclass_type1_header. RecordType = eff_management_device_description_record_number. Type eff_subclass_type1_header is defined in the eff_subclass Design Guide.



Related Definitions

```
//*******************
// Record number
//****************
#define EFI_MISC_MANAGEMENT_DEVICE_DESCRIPTION_RECORD_NUMBER
                                              0x000001B
//*******************
// EFI_MISC_MANAGEMENT_DEVICE_TYPE
//*******************************
typedef enum {
 EfiManagementDeviceTypeOther = 1,
 EfiManagementDeviceTypeUnknown = 2,
 EfiManagementDeviceTypeLm75 = 3,
 EfiManagementDeviceTypeLm78 = 4,
 EfiManagementDeviceTypeLm79 = 5,
 EfiManagementDeviceTypeLm80 = 6,
 EfiManagementDeviceTypeLm81 = 7,
 EfiManagementDeviceTypeAdm9240 = 8,
 EfiManagementDeviceTypeDs1780 = 9,
 EfiManagementDeviceTypeMaxim1617 = A,
 EfiManagementDeviceTypeGl518Sm = B,
 EfiManagementDeviceTypeW83781D = C,
 EfiManagementDeviceTypeHt82H791 = D
} EFI_MISC_MANAGEMENT_DEVICE_TYPE;
//***********************
// EFI_MISC_MANAGEMENT_DEVICE_ADDRESS_TYPE
//********************
typedef enum {
 EfiManagementDeviceAddressTypeOther = 1,
 EfiManagementDeviceAddressTypeUnknown = 2,
 EfiManagementDeviceAddressTypeIOPort = 3,
 EfiManagementDeviceAddressTypeMemory = 4,
 EfiManagementDeviceAddressTypeSmbus = 5
} EFI_MISC_MANAGEMENT_DEVICE_ADDRESS_TYPE;
```



Management Device Component (Type 35)

EFI_MISC_MANAGEMENT_DEVICE_COMPONENT_DESCRIPTION_DATA

Summary

This data record refers to a management device component.

Prototype

Parameters

 ${\it Management Device Component Description}$

A name describing the management device. Type **STRING_REF** is defined in the *Intel® Platform Innovation Framework for EFI Human Interface Infrastructure Specification*.

ManagementDeviceLink

The ID of a management device. See <u>Management Device (Type 34)</u> for management device structures. Type **EFI_INTER_LINK_DATA** is defined in the <u>Intel® Platform</u> Innovation Framework for EFI Data Hub Subclass Design Guide.

ManagementDeviceComponentLink

The ID of a component device like a voltage probe. See <u>Voltage Probe (Type 26)</u> through <u>Electrical Current Probe (Type 29)</u> for device component structures.

Description

This data record refers to a management device component. This data record is a structure.

The type definition structure for

```
EFI_MISC_MANAGEMENT_DEVICE_COMPONENT_DESCRIPTION_DATA is in SMBIOS 2.3.4, Type 35.
```

For this data record, **EFI_SUBCLASS_TYPE1_HEADER**. RecordType = **EFI_MISC_MANAGEMENT_DEVICE_COMPONENT_DESCRIPTION_RECORD_NUMBER**. Type **EFI_SUBCLASS_TYPE1_HEADER** is defined in the Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide.

Draft for Review



Related Definitions



IPMI Device Information (Type 38)

EFI_MISC_IPMI_INTERFACE_TYPE_DATA

Summary

This data record refers to the Intelligent Platform Management Interface (IPMI) type.

Prototype

Parameters

IpmiInterfaceType

The IPMI Baseboard Management Controller (BMC) interface type. Type **EFI_MISC_IPMI_INTERFACE_TYPE** is defined in "Related Definitions" below.

IpmiSpecificationRevision

The revision of the *Intelligent Platform Management Interface Specification*. Type **EFI_MISC_IPMI_SPECIFICATION_REVISION** is defined in "Related Definitions" below.

IpmiI2CSlaveAddress

The I2C slave address of this BMC.

IpmiNvDeviceAddress

The bus ID of the nonvolatile storage device. A value of 0xFFFF indicates that there is no storage device.

IpmiBaseAddress

The I/O or memory-mapped base address of the BMC. If the least significant bit is a 1, then the address is I/O; otherwise, the address is memory mapped.

IpmiDevicePath

The path to the physical device.

Description

This data record refers to the IPMI type. This data record is a structure.

```
The type definition structure for EFI_MISC_IPMI_INTERFACE_TYPE_DATA is in SMBIOS 2.3.4, Type 38, Table 3.3.39.1.
```



For this data record, EFI_SUBCLASS_TYPE1_HEADER . RecordType = EFI_MISC_IPMI_INTERFACE_TYPE_RECORD_NUMBER. Type EFI_SUBCLASS_TYPE1_HEADER is defined in the Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide.

Related Definitions

```
*************
// Record number
//*****************
#define EFI_MISC_IPMI_INTERFACE_TYPE_RECORD_NUMBER 0x0000001D
//********************
// EFI_MISC_IPMI_INTERFACE_TYPE
//****************
typedef enum {
 EfiIpmiOther = 0,
 EfiIpmiKcs = 1,
 EfilpmiSmic = 2,
 EfiIpmiBt = 3,
} EFI_MISC_IPMI_INTERFACE_TYPE;
//******************
// EFI MISC IPMI SPECIFICATION REVISION
//****************
typedef struct {
 UINT16 IpmiSpecLeastSignificantDigit :4;
 UINT16 IpmiSpecMostSignificantDigit
 UINT16 Reserved
                            :8;
} EFI_MISC_IPMI_SPECIFICATION_REVISION;
```

IpmiSpecLeastSignificantDigit

The least significant digit of the IPMI specification that this record referenced.

IpmiSpecMostSignificantDigit

The most significant digit of the IPMI specification that this record referenced.

Reserved

Reserved for future use. Should be initialized to zero.



System Power Supply (Type 39)

EFI MISC POWER SUPPLY UNIT GROUP DATA

Summary

This data record refers to a system power supply.

Prototype

```
typedef struct {
 UINT16
                           PowerUnitGroup;
 STRING REF
                           PowerSupplyLocation;
 STRING REF
                           PowerSupplyDeviceName;
 STRING REF
                           PowerSupplyManufacturerName;
 STRING_REF
                           PowerSupplySerialNumber;
 STRING_REF
                           PowerSupplyAssetTag;
                           PowerSupplyModelPartNumber;
 STRING REF
                           PowerSupplyRevisionLevel;
 STRING REF
 UINT16
                           PowerSupplyMaxPowerCapacity;
 EFI_MISC_POWER_SUPPLY_CHARACTERISTICS
                           PowerSupplyCharacteristics:
 EFI INTER LINK DATA
                           PowerSupplyInputVoltageProbeLink;
 EFI_INTER_LINK_DATA
                           PowerSupplyCoolingDeviceLink;
 EFI INTER LINK DATA
                           PowerSupplyInputCurrentProbeLink;
} EFI MISC POWER SUPPLY UNIT GROUP DATA;
```

Parameters

PowerUnitGroup

The group of which this power supply is a member. A value of 0x0000 indicates that the device is not a member of a group. A nonzero value indicates that multiple devices are in the same group and implies a redundant configuration.

PowerSupplyLocation

A name indicating the power supply's location. Type **STRING_REF** is defined in the *Intel® Platform Innovation Framework for EFI Human Interface Infrastructure*Specification.

PowerSupplyDeviceName

The power supply's device name.

PowerSupplyManufacturerName

The power supply manufacturer's name.

PowerSupplySerialNumber

The power supply's serial number.

PowerSupplyAssetTag

The power supply's asset tag.



PowerSupplyModelPartNumber

The power supply's model part number.

PowerSupplyRevisionLevel

The revision of the power supply.

PowerSupplyMaxPowerCapacity

The maximum sustained power output in watts. The DMTF specification is in milliwatts. A value of 0x8000 indicates that the value is unknown.

PowerSupplyCharacteristics

The characteristics and status of the power supply. Type **EFI_MISC_POWER_SUPPLY_CHARACTERISTICS** is defined in "Related Definitions" below.

PowerSupplyInputVoltageProbeLink

The ID of the input voltage probe. See <u>Voltage Probe (Type 26)</u> for input voltage probe structures. Type <u>EFI_INTER_LINK_DATA</u> is defined in the <u>Intel® Platform</u> <u>Innovation Framework for EFI Data Hub Subclass Design Guide</u>.

PowerSupplyCoolingDeviceLink

The ID of a cooling device. See <u>Cooling Device (Type 27)</u> for cooling device structures.

PowerSupplyInputCurrentProbeLink

The ID of the input current probe. See <u>Electrical Current Probe (Type 29)</u> for input current probe structures.

Description

This data record refers to a system power supply. This data record is structure.

The type definition structure for **EFI_MISC_POWER_SUPPLY_UNIT_GROUP_DATA** is in SMBIOS 2.3.4, Type 39, Table 3.3.40.1.

```
For this data record, <a href="mailto:efi_subclass_type1_header.RecordType">efi_misc_power_supply_unit_group_record_number</a>. Type <a href="mailto:efi_subclass_type1_header">efi_subclass_type1_header</a> is defined in the <a href="mailto:lntel@Platform Innovation Framework for EFI Data Hub Subclass Design Guide">efi_subclass Design Guide</a>.
```

Related Definitions



```
//****************************
// EFI MISC POWER SUPPLY CHARACTERISTICS
//********************
typedef struct {
 UINT32 PowerSupplyHotReplacable
                                 :1;
 UINT32 PowerSupplyPresent
                                  :1;
 UINT32 PowerSupplyIsUnplugged
                                  :1;
 UINT32 InputVoltageRangeSwitch
                                  :4;
 UINT32 PowerSupplyStatus
                                  :3;
 UINT32 PowerSupplyType
                                  :4;
 UINT32 Reserved
                                  :18;
} EFI MISC POWER SUPPLY CHARACTERISTICS;
```

PowerSupplyHotReplacable

Indicates that the power supply can be replaced while AC is connected to the chassis.

PowerSupplyPresent

Indicates that the power supply is present in the system.

PowerSupplyIsUnplugged

Indicates that the power supply is currently removed from the system.

InputVoltageRangeSwitch

- 0000b: Reserved
- 0001b: Other
- 0010b: Unknown
- 0011b: Manual
- 0100b: Auto switch
- 0101b: Wide range
- 0110b: Not applicable
- 0111b-1111b: Reserved

PowerSupplyStatus

Indicates the status of the power supply:

- 000b: Reserved
- 001b: Other
- 010b: Unknown
- 011b: OK
- 100b: Noncritical
- 101b: Critical
- 110b: Reserved
- 111b: Reserved



PowerSupplyType

The type of power supply being described:

- 0000b: Reserved
- 0001b: Other
- 0010b: Unknown
- 0011b: Linear
- 0100b: Switching
- 0101b: Battery
- 0110b: UPS
- 0111b: Converter
- 1000b: Regulator
- 1001b–1111b: Reserved

Reserved

Reserved for future use. Must be initialized to zero.

intel

SMBIOS Structure Encapsulation (Types 0x80 to 0xFF)

EFI_MISC_SMBIOS_STRUCT_ENCAPSULATION_DATA

Summary

This data record carries one complete SMBIOS structure.

Prototype

Parameters

Header

The SMBIOS structure header. The *Type* and *Length* fields must correspond to the desired SMBIOS structure. *Handle* is ignored. Type **EFI_SMBIOS_STRUCTURE_HDR** is defined in "Related Definitions" below.

RawData

The raw data to be included in this SMBIOS structure.

Description

This data record carries one complete SMBIOS structure. Unlike other records, this record must contain the entire SMBIOS structure including the structure type, length, and handle. The structure's *Type* and *Length* must contain the values corresponding to the corresponding SMBIOS structure. The *Handle* field will be ignored by the consumers. As in SMBIOS structures, *Length* represents the length of the formatted part of the structure. If the SMBIOS structure requires any strings, raw strings (not string tokens) must be included in this record after the formatted data, just like the actual SMBIOS structures. The length of this data record depends upon the *Length* field and the length of the unformatted data. A consumer of this record can determine the length by using the *RecordSize* field in the data hub record header (EFI_DATA_RECORD_HEADER, which is defined in the *Intel® Platform Innovation Framework* for EFI Data Hub Specification) or by parsing the unformatted data such as SMBIOS table parsers.

This record is intended to be used for OEM-type SMBIOS structures. According to the SMBIOS Specification, structure types 0x80 to 0xFF are available for OEM usage. Any driver that creates an SMBIOS table based on the data hub records will copy the contents of

EFI_MISC_SMBIOS_STRUCT_ENCAPSULATION_DATA to the SMBIOS table and update the handle number. This driver is allowed to reject a record of this type if the *Type* is less than 0x80. Therefore, producers should not use this type of record for generating standard SMBIOS structures in the range of 0 to 0x7F.



For this data record, EFI_SUBCLASS_TYPE1_HEADER . RecordType = EFI_MISC_SMBIOS_STRUCT_ENCAP_RECORD_NUMBER. Type EFI_SUBCLASS_TYPE1_HEADER is defined in the Intel® Platform Innovation Framework for EFI Data Hub Subclass Design Guide.

Related Definitions

```
//****************
// Record number
//***************
#define EFI_MISC_SMBIOS_STRUCT_ENCAP_RECORD_NUMBER 0x0000001F
//*****************
// EFI_SMBIOS_STRUCTURE_HDR
//****************
//
// The SMBIOS structure header
//
#pragma pack(1)
typedef struct {
 UINT8
       Type;
 UINT8
         Length;
 UINT16
         Handle;
} EFI_SMBIOS_STRUCTURE_HDR;
#pragma pack()
```



Examples

Legacy Miscellaneous Record Numbers

Last PCI Bus Number

```
Data Example: The last PCI bus enumerated is 7.

LastPciBus = 0x07;
```

BIOS Information (Type 0) Record Numbers

BIOS Vendor

```
Data Example: The BIOS vendor is AMI.

BiosVendor = String reference to "AMI", 0;
```

BIOS Version

```
Data Example: The BIOS version is production release 10.

BiosVersion = String reference to "P10",0;
```

BIOS Release Date

```
Data Example: The BIOS release date is January 31, 2001.

BiosReleaseDate = String reference to "01/31/2001",0;
```

BIOS Starting Address

```
Data Example: The BIOS start of code space is FFFE0000 physical.

BiosStartingAddress = 0xFFFE0000;
```

BIOS Physical Device Size

```
Data Example: Physical size is 256 KB.

BiosPhysicalDeviceSize.Value = 0x04;

BiosPhysicalDeviceSize.Exponent = 0x04;
```



BIOS Characteristics

Data Example: BIOS supports PCI; is upgradeable; can be shadowed; and supports the following: boot from CD, selectable boot, print screen, 8042, serial, and parallel.

BIOS Characteristics Extension Bytes

System Information (Type 1) Record Numbers

System Manufacturer

```
Data Example: The system manufacturer is Fly-by-Night.

SystemManufacturer = String reference to "Fly-by-Night",0;
```

System Product Name

```
Data Example: The system product name is Crash-n-Burn.

SystemProductName = String reference to "Crash-n-Burn", 0;
```

System Version

```
Data Example: The system version is 1001.

SystemVersion =String reference to "1001",0;
```

System Serial Number

```
Data Example: The system's serial number is 1.

SystemSerialNumber = String reference to "01",0;
```

System UUID

```
Data Example: The system UUID is DEAD0000-1111-2222-3333-444455556666.

SystemUuid = 0xDEAD0000111122223333444455556666;
```

System Wake-up Type

Data Example: The system woke up from PCI PME#.

SystemWakeupType = EfiSystemWakeupTypePciPme;

Baseboard Information (Type 2) Record Numbers

Baseboard Manufacturer

```
Data Example: The system's product name is Crispy PC.
```

```
BaseBoardManufacturer = String reference to "Crispy PC",0;
```

Baseboard Product Name

```
Data Example: The baseboard's product name is Krakatoa.
```

```
BaseBoardProductName = String reference to "Krakatoa",0;
```

Baseboard Version

```
Data Example: The baseboard version is 9999.
```

```
BaseBoardVersion = Sting reference to "9999",0;
```

Baseboard Serial Number

```
Data Example: The baseboard's serial number is DEAD987.
```

```
BaseBoardSerialNumber = String reference to "DEAD987",0;
```

Baseboard Asset Tag

```
Data Example: The baseboard's asset tag is 1234.
```

```
BaseBoardAssetTag = String reference to "1234",0;
```

Baseboard Chassis Location

Data Example: The chassis location is the motherboard.

```
BaseBoardChassisLocation = String reference to "Motherboard",0;
```



Baseboard Feature Flags

Data Example: The baseboard is a motherboard and is replacable.

```
BaseBoardFeatureFlags = 0x09;
```

Baseboard Type

Data Example: The baseboard is a motherboard.

```
BaseBoardType = EfiBaseBoardTypeMotherBoard;
```

Baseboard Chassis Link

Data Example: The *Instance* number of the <u>chassis enclosure (type 3)</u> that contains this baseboard is 1.

```
BaseBoardChassisLink = 0x01;
```

Baseboard Number of Links

Data Example: This structure does not have any links to other structures.

```
BaseBoardNumberLinks = 0x00;
```

Baseboard LinkN

```
Data Example: There are no other links.
```

```
LinkN = 0x00;
```

System/Chassis Enclosure (Type 3) Record Numbers

Chassis Manufacturer

```
Data Example: The chassis manufacturer is Slice-n-Dice.
```

```
ChassisManufacturer = String reference to "Slice-n-Dice",0;
```

Chassis Version

```
Data Example: The chassis version is No Fingers.
```

```
ChassisVersion = String reference to "No Fingers",0;
```



Chassis Serial Number

```
Data Example: The chassis's serial number is 123.

ChassisSerialNumber = String reference to "123",0;
```

Chassis Asset Tag Number

```
Data Example: The chassis's asset tag number is 444.

ChassisAssetTag = String reference to "444",0;
```

Chassis Type

```
Data Example: The chassis type is pizza box.

ChassisType = EfiMiscChassisTypePizzaBox;
```

Chassis Boot-up State

```
Data Example: The chassis boot-up state is safe.

ChassisBootupState = EfiChassisStateSafe;
```

Chassis Power Supply State

```
Data Example: The chassis's power supply state is safe.

ChassisPowerSupplyState = EfiChassisStateSafe;
```

Chassis Thermal State

```
Data Example: The chassis's thermal state is safe.

ChassisThermalState = EfiChassisStateSafe;
```

Chassis Security State

```
Data Example: The chassis's security state is unknown.

ChassisSecurityState = EfiChassisSecurityStatusUnknown;
```

Chassis OEM Defined

```
Data Example: The chassis's OEM defined field is null.

ChassisOemDefined = 0x00;
```



Chassis Height

```
Data Example: The chassis is 2 "U"s high.

ChassisHeight = 0x02;
```

Chassis Number of Power Cords

Data Example: One power cord is associated with chassis.

ChassisNumberPowerCords = 0x01;

Chassis Element Count

```
Data Example: No element records follow.

ChassisElementCount = 0x00;
```

Chassis Element Record Length

```
Data Example: The length of the chassis element record is the size of EFI_MISC_ELEMENTS.

ChassisElementRecordLength = sizeof (EFI_MISC_ELEMENTS);
```

Chassis Elements

Data Example: In the first example, the *ChassisBaseBoard* field is valid and the *ChassisElementStructure* field is invalid. The baseboard is a motherboard, and the number of motherboards must be 1.

```
ChassisElements.ChassisElementType.RecordType = 0;
ChassisElements.ChassisBaseBoard = EfiBaseBoardTypeMotherBoard;
ChassisElements.ChassisElementMinimum = 1;
ChassisElements.ChassisElementMaximum = 1;
```

Data Example: The *ChassisBaseBoard* field is invalid and the *ChassisElementStructure* field is valid. The *ChassisElementType*. *Type* field refers to a <u>type 28 record number</u>, which is 0x1C and a temperature probe. This instance is the third instance of a type 28 record. There must be a minimum of one type 28 record and a maximum of five.

```
ChassisElements.ChassisElementType.RecordType = 1;
ChassisElements.ChassisElementType.Type = 28;
ChassisElements.ChassisElementStructure = 3;
ChassisElements.ChassisElementMinimum = 1;
ChassisElements.ChassisElementMaximum = 5;
```



Port Connector Information (Type 8) Record Numbers

Port Internal Connector Reference Designator

```
Data Example: The internal connection is at J4C1.
```

```
PortInternalConnectorDesignator = String reference to "J4C1",0;
```

Port External Connector Reference Designator

```
Data Example: The external port connector's reference designator is "Parallel Port."
```

```
PortExternalConnectorReferenceDesignator = String reference to
"Parallel Port",0;
```

Port Internal Connector Type

```
Data Example: The internal port is a 25-pin dual inline connector.
```

```
PortInternalConnectorType = EfiPortConnectorType25PinDualInline;
```

Port External Connector Type

```
Data Example: The internal port is a 25-pin DB male connector.
```

```
PortExternalConnectorType = EfiPortConnectorTypeDB25Male;
```

Port Type

```
Data Example: The port type is ECP/EPP parallel port.
```

```
PortType = EfiPortTypeParallelPortEcpEpp;
```

System Slots (Type 9) Record Numbers

Slot Designation

```
Data Example: The slot designation is "PCI 3."

SlotDesignation = String reference to "PCI 3",0;
```

Slot Type

```
Data Example: The slot type is PCI.

SlotType = EfiSlotTypePci;
```



Slot Data Bus Width

```
Data Example: The slot width is 32 bits.

SlotDataBusWidth = EfiSlotDataBusWidth32Bit;
```

Slot Current Usage

```
Data Example: The slot is in use.

SlotUsage = EfiSlotUsageInUse;
```

Slot Length

```
Data Example: The slot length is short.

SlotLength = EfiSlotLengthShort;
```

Slot ID

```
Data Example: The ID of the PCI slot is 31 decimal.

SlotId = 0x1F;
```

Slot Characteristics

```
Data Example: The slot provides both 5.0 and 3.3 volts and PME#.

SlotCharacteristics = 0000 0000 0000 0000 0001 0000 0110b;
```

Onboard Devices Information (Type 10) Record Numbers

Onboard Device Description

```
Data Example: Video is onboard and VGA.

OnBoardDeviceDescription = String reference to "VGA Video",0;
```

Onboard Device Type

```
Data Example: Video is onboard and enabled.

OnBoardDeviceType = EfiOnBoardDeviceTypeVideo | 0x800;
```

intel

OEM Strings (Type 11) Record Numbers

Number of OEM Strings

```
Data Example: There are five OEM strings.

NumberOfInstallableLanguages = 0x05;
```

OEM Strings

Data Example: "This string is OEM string #1." Note that the <u>Number of OEM Strings</u> example implies that there are five OEM strings records, each with a unique *OemStringId* between 1 and 5 inclusively.

```
OemStringId = 0x01;
OemStringRef = String reference to "This string is OEM string
#1",0;
```

System Configuration Options (Type 12) Record Numbers

Number of System Configuration Option Strings

```
Data Example: There are three option strings.

NumberOfInstallableLanguages = 0x03;
```

System Configuration Option Strings

Data Example: "This string is option string #2." Note that the <u>Number of System Configuration</u> <u>Option Strings</u> example implies that there are three System Configuration Option Strings records, each with a unique <u>SystemOptionStringId</u> between 1 and 3 inclusively.

```
SystemOptionStringId = 0x02;
SystemOptionStringRef = String reference to "This string is option string #2",0;
```

BIOS Language Information (Type 13) Record Numbers

Number of Installable Languages

Data Example: Five languages are supported. The order is French, French Canadian, English, German, and Spanish.

```
NumberOfInstallableLanguages = 0x05;
```



Language Flags

```
Data Example: The BIOS uses an abbreviated language format.

LanguageFlags = 0000 0000 0000 0000 0000 0000 0001b;
```

Current Language Number

Data Example: The current language is number 2 (1 based), which is French Canadian. This value must be smaller than **EFI_MISC_NUMBER_OF_INSTALLABLE_LANGUAGES_DATA**.

```
CurrentLanguageNumber = 2;
```

Language String

Data Example: "This string is Language string #2." Note that the <u>Number of Installable Languages</u> example implies that there are 5 language strings records, each with a unique <u>LanguageId</u> between 1 and 5 inclusively. The <u>Current Language Number</u> example indicates that the current language has a <u>LanguageId</u> of 2, which is French Canadian in this example. Both formats are shown.

```
LanguageId = 0x02;
SystemLanguageString =
String reference to "fr|CA|iso8859-1",0; /* Long format */
SystemLanguageString =
String reference to "frCA",0; /* Abbreviated format */
```

Group Associations (Type 14) Record Numbers

Group Name

```
Data Example: The group name is "Chassis Cooling System."

Instance = 0x14;

GroupName = String reference to "Chassis Cooling System",0;
```

Number of Items in Group

```
Data Example: There are two items in the group.

Instance = 0x14;

NumberGroupItems = 0x02;
```



Group Item Set

Data Example: Both processor number 1 (GroupElementId 0x01) and onboard SCSI (GroupElementId 0x02) are cooled by same fan (GoupElementId 0x03) and grouped together by group device (GroupID 0x14). There are three group item sets, one per device.

The processor is the one identified by an *Instance* 0x37.

Onboard SCSI is the one identified by an *Instance* 0x28E.

The fan is the one identified by an *Instance* 0x27, *SubInstance* 0x03.

```
DeviceOne.GroupId = 0x14;
DeviceOne.GroupElementID = 0x01;
DeviceOne.GroupLink.SubClassNumber = EFI_PROCESSOR_SUBCLASS;
DeviceOne.GroupLink.ProducerName = GUID processor;
DeviceOne.GroupLink.GroupId = 0x37;
DeviceOne.GroupLink.GroupElementId = 0x01;
DeviceTwo.GroupId = 0x14;
DeviceTwo.GroupElementID = 0x02;
DeviceTwo.GroupLink.SubClassNumber = EFI_MISC_SUBCLASS;
DeviceTwo.GroupLink.ProducerName = GUID Block IO;
DeviceTwo.GroupLink.GroupId = 0x28E;
DeviceTwo.GroupLink.GroupElementId = 0x00;
DeviceThree.GroupId = 0x14;
DeviceThree.GroupElementID = 0x03;
DeviceThree.GroupLink.SubClassNumber = EFI_MISC_SUBCLASS;
DeviceThree.GroupLink.ProducerName= GUID fan;
DeviceThree.GroupLink.GoupId = 0x27;
DeviceThree.GroupLink.GroupElementId = 0x03;
```

Built-in Pointing Device (Type 21) Record Numbers

Pointing Device Type

```
Data Example: The pointing device is a mouse.

PointingDeviceType = EfiPointingDeviceTypeMouse;
```

Pointing Device Interface

```
Data Example: The device is on a PS/2* port.

PointingDeviceInterface = EfiPointingDeviceInterfacePs2;
```



Number of Pointing Device Buttons

```
Data Example: The mouse has two buttons.

NumberPointingDeviceButtons = 0x02;
```

Portable Battery (Type 22) Record Numbers

Portable Battery Location

```
Data Example: The battery is in the case.

BatteryLocation = String reference to "In the case",0;
```

Portable Battery Manufacturer

```
Data Example: The battery is made by Shocking Corp.

BatteryManufacturer = String reference to "Shocking Corp",0;
```

Portable Battery Manufacture Date

```
Data Example: Use the SBDS field instead.

BatteryManufactureDate = 0;
```

Portable Battery Serial Number

```
Data Example: Use the SBDS field instead.

BatterySerialNumber = 0;
```

Portable Battery Device Name

```
Data Example: The battery name is "The Bomb."

BatteryDeviceName = String reference to "The Bomb", 0;
```

Portable Battery SBDS Version Number

```
Data Example: The battery supports SBDS version 1.0.

BatterySbdsVersionNumber = String reference to "1.0",0;
```



Portable Battery SBDS Device Chemistry

Data Example: The SBDS information is invalid because the *BatteryDeviceChemistry* field is known. See the <u>Portable Battery Device Chemistry</u> example.

```
BatterySbdsDeviceChemistry = 0;
```

Portable Battery Device Chemistry

```
Data Example: The battery is Lithium ion.

BatteryDeviceChemistry = EfiBatteryDeviceChemistryTypeLithiumIon;
```

Portable Battery Design Capacity

```
Data Example: The battery is good for 1 watt-hour.

BatteryDesignCapacity.Value = 0x01;

BatteryDesignCapacity.Exponent = 0x00;
```

Portable Battery Design Voltage

```
Data Example: The battery is 3.0 volts.

BatteryDesignVoltage.Value = 0x03;

BatteryDesignVoltage.Exponent = 0x00;
```

Portable Battery Maximum Error in Battery Data

Data Example: The battery data has a maximum error of 10 percent. This value is denoted by 10 decimal or 0x0A.

```
BatteryMaximumError = 0x0A;
```

Portable Battery SBDS Serial Number

```
Data Example: The SBDS serial number is 0x1234.

BatterySbdsSerialNumber = 0x1234;
```

Portable Battery SBDS Manufacture Date

Data Example: The battery was made on March 10, 2001. The day is 10 decimal or 01010b. The month is 3 decimal or 0011b. The year is 2001 minus 1980 or 21 decimal or 0010101b.



Portable Battery OEM Specific

Data Example: There is no OEM-specific data.

BatteryOemSpecific = 0x0;

System Reset (Type 23) Record Numbers

Reset Capabilities

Data Example: Reset was enabled by user, the operating system handles resets on error conditions, and the watchdog timer is enabled.

```
ResetCapabilities = 0000 0000 0000 0000 0000 0000 0010 1011b;
```

Reset Count

Data Example: No automatic system resets occurred.

```
ResetCount = 0x0;
```

Reset Limit

Data Example: The operating system can try a maximum of three resets before a fatal error.

```
ResetLimit = 0x03;
```

Reset Timer Interval

Data Example: The watchdog timer is set for 5 minutes.

```
ResetTimerInterval = 0x05;
```

Reset Timeout

Data Example: Do not reboot for 3 minutes after any reset.

```
ResetTimeout = 0x03;
```



Hardware Security (Type 24) Record Numbers

Hardware Security Settings

Data Example: All passwords are enabled. Front panel reset is disabled.

```
HardwareSecuritySettings =
```

0000 0000 0000 0000 0000 0000 0101 0100b;

System Power Controls (Type 25) Record Numbers

System Power Controls (Type 25) Record Numbers

All structures and all examples are in Binary Coded Decimal (BCD). Out-of-range values are ignored.

Scheduled Power-on Month

```
Data Example: Ignore the month of a scheduled power-on.
```

```
ScheduledPoweronMonth = 0xFF;
```

Scheduled Power-on Day-of-Month

```
Data Example: Power on the fifteenth of each month.
```

```
ScheduledPoweronDayOfMonth = 0x15;
```

Scheduled Power-on Hour

```
Data Example: Power on at 3:45 AM.

ScheduledPoweronHour = 0x03;
```

Scheduled Power-on Minute

```
Data Example: Power on at 3:45 AM.
```

```
ScheduledPoweronMinute = 0x45;
```

Scheduled Power-on Second

```
Data Example: Power on at 3:45:00 AM.
```

ScheduledPoweronSecond = 0x00;



Voltage Probe (Type 26) Record Numbers

Voltage Probe Description

```
Data Example: The voltage probe is on the processor.

VoltageProbeDescription = String reference to "Processor voltage probe",0;
```

Voltage Probe Location and Status

```
Data Example: The processor probe and voltage are okay.

VoltageProbeLocation = 0000 0000 0000 0000 0000 0110

0011b;
```

Voltage Probe Maximum Value

```
Data Example: The probe can read up to 15.0 volts.

VoltageProbeMaximumValue.Value = 0x0f;

VoltageProbeMaximumValue.Exponent = 0x00;
```

Voltage Probe Minimum Value

```
Data Example: The probe can read up to -10.0 volts.

VoltageProbeMinimumValue.Value = 0x8001;

VoltageProbeMinimumValue.Exponent = 0x01;
```

Voltage Probe Resolution

```
Data Example: The probe resolves voltage down to 1 millivolt.

VoltageProbeResolution.Value = 0x01;

VoltageProbeResolution.Exponent = 0x8003;
```

Voltage Probe Tolerance

```
Data Example: The probe is accurate to 20 millivolts.

VoltageProbeTolerance.Value = 0x02;

VoltageProbeTolerance.Exponent = 0x8002;
```



Voltage Probe Accuracy

```
Data Example: Based upon the position of the probe, it is accurate to 1 percent.
```

```
VoltageProbeAccuracy.Value = 0x01;
VoltageProbeAccuracy.Exponent = 0x00;
```

Voltage Probe Nominal Value

```
Data Example: The nominal value is 5.0 volts.

VoltageProbeNominalValue.Value = 0x05;

VoltageProbeNominalValue.Exponent = 0x00;
```

Management Device Lower Noncritical Threshold (Type 26)

Data Example: The voltage probe's lower noncritical threshold is 0 volts.

```
MDLowerNoncriticalThreshold.Value = 0x00;
MDLowerNoncriticalThreshold.Exponent = 0x00;
```

Management Device Upper Noncritical Threshold (Type 26)

```
Data Example: The voltage probe's upper noncritical threshold is 5 volts.

MDUpperNoncriticalThreshold.Value = 0x05;
```

```
MDUpperNoncriticalThreshold.Exponent = 0x00;
```

Management Device Lower Critical Threshold (Type 26)

```
Data Example: The voltage probe's lower critical threshold is -5.0 volts.

MDLowerCriticalThreshold.Value = 0x8005:
```

```
MDLowerCriticalThreshold.Exponent = 0x00;
```

Management Device Upper Critical Threshold (Type 26)

```
Data Example: The voltage probe's upper critical threshold is 10 volts.
```

```
MDUpperCriticalThreshold.Value = 0x01;
MDUpperCriticalThreshold.Exponent = 0x01;
```

Management Device Lower Nonrecoverable Threshold (Type 26)

Data Example: The voltage probe's lower nonrecoverable threshold is -10 volts.

```
MDLowerNonrecoverableThreshold.Value = 0x8001;
MDLowerNonrecoverableThreshold.Exponent = 0x0001;
```



Management Device Upper Nonrecoverable Threshold (Type 26)

Data Example: The voltage probe's upper nonrecoverable threshold is 15 volts.

```
MDUpperNonrecoverableThreshold.Value = 0x0f;
MDUpperNonrecoverableThreshold.Exponent = 0x00;
```

Voltage Probe OEM Defined

```
Data Example: No OEM bit fields are defined.

VoltageProbeOemDefined = 0x0;
```

Cooling Device (Type 27) Record Numbers

Cooling Device Type and Status

```
Data Example: The cooling device is a fan and the temperature is okay.

CoolingDeviceType = 0000 0000 0000 0000 0000 0110 0011b;
```

Cooling Device Temperature Link

Data Example: This cooling device, which has an Instance of 0x13, is associated with a temperature probe structure set that has an Instance of 0x88.

```
ThisDevice.Instance = 0x13;
ThisDevice.CoolingDeviceTemperatureLink.ProducerName = GUID Temp
probe;
ThisDevice.CoolingDeviceTemperatureLink.Instance = 0x88;
ThisDevice.CoolingDeviceTemperatureLink.SubInstance = 0x01;
```

Cooling Device Unit Group

```
Data Example: The fan is the sole cooling device for the given area.

CoolingDeviceUnitGroup = 0x0;
```

Cooling Device Nominal Speed

```
Data Example: The fan's normal rotational speed is unknown.

CoolingDeviceNominalSpeed.Value = 0xFFFF;

CoolingDeviceNominalSpeed.Exponent = 0xFFFF;
```

intط

Cooling Device OEM Defined

```
Data Example: There are no OEM-defined fields.

CoolingDeviceOemDefined = 0x0;
```

Temperature Probe (Type 28) Record Numbers

Temperature Probe Description

```
Data Example: The temperature probe is in the processor.
```

```
TemperatureProbeDescription = String reference to "Processor
Temperature Probe",0;
```

Temperature Probe Location and Status

Data Example: The probe is on the processor and temperature is noncritical.

Temperature Probe Maximum Value

```
Data Example: The maximum probe value is 100 degrees Celsius.
```

```
TemperatureProbeMaximumValue.Value = 0x01;
TemperatureProbeMaximumValue.Exponent = 0x02;
```

Temperature Probe Minimum Value

```
Data Example: The minimum probe value is 0 degrees Celsius.
```

```
TemperatureProbeMinimumValue.Value = 0x00;
TemperatureProbeMinimumValue.Exponent = 0x00;
```

Temperature Probe Resolution

```
Data Example: The probe resolves to 1 degree Celsius.
```

```
TemperatureProbeResolution.Value = 0x01;
TemperatureProbeResolution.Exponent = 0x00;
```



Temperature Probe Tolerance

```
Data Example: The probe tolerance is 1 degree Celsius.

TemperatureProbeTolerance.Value = 0x01;

TemperatureProbeTolerance.Exponent = 0x00;
```

Temperature Probe Accuracy

```
Data Example: The probe only gives 5 percent accuracy.

TemeratureProbeAccuracy.Value = 0x05;

TemeratureProbeAccuracy.Exponent = 0x00;
```

Temperature Probe Nominal Value

Data Example: The nominal value is 70 degrees Celsius.

```
TemperatureProbeNominalValue.Value = 0x07;
TemperatureProbeNominalValue.Exponent = 0x01;
```

Management Device Lower Noncritical Threshold (Type 28)

Data Example: The device is a fan with a lower noncritical threshold of 15 degrees Celsius or 0x0F.

```
MDLowerNoncriticalThreshold.Value = 0x0F;
MDLowerNoncriticalThreshold.Exponent = 0x00;
```

Management Device Upper Noncritical Threshold (Type 28)

Data Example: The device is a fan with an upper noncritical threshold of 75 degrees Celsius or 0x4B.

```
MDUpperNoncriticalThreshold.Value = 0x4B;
MDUpperNoncriticalThreshold.Exponent = 0x00;
```

Management Device Lower Critical Threshold (Type 28)

Data Example: The device is a fan with a lower critical threshold of 10 degrees Celsius.

```
MDLowerCriticalThreshold.Value = 0x01;
MDLowerCriticalThreshold.Exponent = 0x01;
```

Draft for Review Examples

intel

Management Device Upper Critical Threshold (Type 28)

Data Example: The device is a fan with an upper noncritical threshold of 80 degrees Celsius.

```
MDUpperCriticalThreshold.Value = 0x08;
MDUpperCriticalThreshold.Exponent = 0x01;
```

Management Device Lower Nonrecoverable Threshold (Type 28)

Data Example: The device is a fan with a lower nonrecoverable threshold of 5 degrees Celsius.

```
MDLowerNonrecoverableThreshold.Value = 0x05;
MDLowerNonrecoverableThreshold.Exponent = 0x00;
```

Management Device Upper Nonrecoverable Threshold (Type 28)

Data Example: The device is a fan with an upper nonrecoverable threshold of 85 degrees Celsius or 0x55.

```
MDUpperNonrecoverableThreshold.Value = 0x55;
MDUpperNonrecoverableThreshold.Exponent = 0x00;
```

Temperature Probe OEM Defined

```
Data Example: There are no OEM-defined values.

TemperatureProbeOemDefined = 0x0;
```

Electrical Current Probe (Type 29) Record Numbers

Electrical Current Probe Description

```
Data Example: The current probe is on the IDE disk.
    ElectricalCurrentProbeDescription = String reference to "IDE Disk Current Probe",0;
```

Electrical Current Probe Location and Status

```
Data Example: The probe is for the IDE disk and its status is okay.
```



Electrical Current Probe Maximum Value

```
Data Example: The maximum current is 3 amperes.

ElectricalCurrentProbeMaximumValue.Value = 0x03;

ElectricalCurrentProbeMaximumValue.Exponent = 0x01;
```

Electrical Current Probe Minimum Value

```
Data Example: The minimum current is 0 amperes.

ElectricalCurrentProbeMinimumValue.Value = 0x00;

ElectricalCurrentProbeMinimumValue.Exponent = 0x00;
```

Electrical Current Probe Resolution

```
Data Example: The probe's resolution is 50 milliamperes.

ElectricalCurrentProbeResolution.Value = 0x05;

ElectricalCurrentProbeResolution.Exponent = 0x8002;
```

Electrical Current Probe Tolerance

```
Data Example: The probe's tolerance is 10 milliamperes.

ElectricalCurrentProbeTolerance.Value = 0x01;

ElectricalCurrentProbeTolerance.Exponent = 0x8002;
```

Electrical Current Probe Accuracy

```
Data Example: The probe's accuracy is 10 percent.

ElectricalCurrentProbeAccuracy.Value = 0x01;

ElectricalCurrentProbeAccuracy.Exponent = 0x01;
```

Electrical Current Probe Nominal Value (Type 29)

```
Data Example: The nominal value is 100 milliamperes.

ElectricalCurrentProbeNominalValue.Value = 0x01;

ElectricalCurrentProbeNominalValue.Exponent = 0x80014;
```

Management Device Lower Noncritical Threshold (Type 29)

```
Data Example: The probe's lower noncritical threshold is 0.5 amperes.

MDLowerNoncriticalThreshold.Value = 0x05;

MDLowerNoncriticalThreshold.Exponent = 0x8001;
```



Management Device Upper Noncritical Threshold (Type 29)

Data Example: The probe's upper noncritical threshold is 2.5 amperes.

```
MDUpperNoncriticalThreshold.Value = 0x19;
MDUpperNoncriticalThreshold.Exponent = 0x8001;
```

Management Device Upper Critical Threshold (Type 29)

```
Data Example: The probe's upper critical threshold is 2.75 amperes. 275 decimal is 0x113.
```

```
MDUpperCriticalThreshold.Value = 0x0113;
MDUpperCriticalThreshold.Exponent = 0x8002;
```

Management Device Lower Critical Threshold (Type 29)

Data Example: The probe's lower critical threshold is 0.25 amperes.

```
MDLowerCriticalThreshold.Value = 0x19;
MDLowerCriticalThreshold.Exponent = 0x8002;
```

Management Device Lower Nonrecoverable Threshold (Type 29)

```
Data Example: The probe's lower nonrecoverable threshold is 0.1 amperes.
```

```
MDLowerNonrecoverableThreshold.Value = 0x01;
MDLowerNonrecoverableThreshold.Exponent = 0x8001;
```

Management Device Upper Nonrecoverable Threshold (Type 29)

```
Data Example: The probe's nonrecoverable threshold is 2.90 amperes. 29 decimal is 0x1d.
```

```
MDUpperNonrecoverableThreshold.Value = 0x1d;
MDUpperNonrecoverableThreshold.Exponent = 0x8001;
```

Electrical Current Probe OEM Defined

```
Data Example: No OEM fields are defined.
```

```
ElectricalCurrentProbeOemDefined = 0x0;
```



Out-of-Band Remote Access (Type 30) Record Numbers

Remote Access Manufacturer Name Description

```
Data Example: The manufacturer is Big Brother.
```

```
RemoteAccessManufacturerNameDescription = String reference to
"Big Brother",0;
```

Remote Access Connections

```
Data Example: Only outbound connections are enabled.
```

```
RemoteAccessConnecions =
```

0000 0000 0000 0000 0000 0000 0000 0010b;

Boot Integrity Services (BIS) Entry Point (Type 31) Record Numbers

BIS Entry Point Address

```
Data Example: The BIS entry point is 0xFFFE1234.

BisEntryPoint = 0xFFFE1234;
```

System Boot Information (Type 32) Record Numbers

Boot Information Status

```
Data Example: There is no bootable media.
```

```
BootInformationStatus = EfiBootInformationStatusNoBootableMedia;
```

Boot Information Data

Data Example: The OEM defined byte 0 with a value of 0x55.

```
BootInformationData[0] = 0x55;
BootInformationData[1] = 0x0;
BootInformationData[2] = 0x0;
BootInformationData[3] = 0x0;
BootInformationData[4] = 0x0;
BootInformationData[5] = 0x0;
BootInformationData[6] = 0x0;
BootInformationData[7] = 0x0;
BootInformationData[8] = 0x0;
```



Management Device (Type 34) Record Numbers

Management Device Description

```
Data Example: The device's description is "Keeping tab on you."

ManagementDeviceDescription = String reference to "Keeping tab on you",0;
```

Management Device Type

```
Data Example: The management type is National Semiconductor* LM 75.

ManagementDeviceType = EfiManagementDeviceTypeLm75;
```

Management Device Address

```
Data Example: The device address is 3.

ManagementDeviceAddress = 0x03;
```

Management Device Address Type

```
Data Example: The device is a System Management Bus (SMBus) device.

ManagementDeviceAddressType =

EfiManagementDeviceAddressTypeSmbus;
```

Management Device Component (Type 35) Record Numbers

Management Device Component Description

```
Data Example: The management device component is "Freezer Fan."

ManagementDeviceComponentDescription = String reference to

"Freezer Fan",0;
```

Management Device Link

```
Data Example: The device Instance is 0x12E.
  ThisDevice.ManagementDeviceLink.ProducerName = GUID Fan
  management;
  ThisDevice.ManagementDeviceLink.Instance = 0x12E;
  ThisDevice.ManagementDeviceLink.SubInstance = 0x00;
```



Management Device Component Link

Data Example: The fan device component *Instance* is 0x12F and *SubInstance* is 0x02 (second fan).

```
ThisDevice.ManagementDeviceComponentLink.ProducerName = GUID fan;
ThisDevice.ManagementDeviceComponentLink.Instance = 0x12F;
ThisDevice.ManagementDeviceComponentLink.SubInstance = 0x02;
```

IPMI Device Information (Type 38) Record Numbers

IPMI Interface Type

```
Data Example: The interface type is keyboard controller style.
```

```
IpmiInterfaceType = EfiIpmiKcs;
```

IPMI Specification Revision

```
Data Example: The IPMI specification is revision 1.2.

IpmiSpecificationRevision = 0000 0000 0001 0010b;
```

IPMI I2C Slave Address

```
Data Example: The I2C slave address is 2.

IpmiI2CSlaveAddress = 0x2;
```

IPMI NV Storage Device Address

```
Data Example: There is no storage device.

IpmiNvDeviceAddress = 0xFFFF;
```

IPMI Base Address

```
Data Example: The base address is 0x68.

IpmiBaseAddress = 0x68;
```



System Power Supply (Type 39) Record Numbers

Power Supply Group

Data Example: The power supply is not a part of a group and is not redundant.

```
PowerSupplyGroup = 0x0;
```

Power Supply Location

```
Data Example: The power supply is in the chassis.
```

```
PowerSupplyLocation = String reference to "In the chassis",0;
```

Power Supply Device Name

```
Data Example: The power supply's device name is "Shocker."
```

```
PowerSupplyDeviceName = String reference to "Shocker",0;
```

Power Supply Manufacturer Name

```
Data Example: The manufacturer is "Zap."
```

```
PowerSupplyManufacturer = String reference to "Zap",0;
```

Power Supply Serial Number

```
Data Example: The power supply's serial number is 00001.
```

```
PowerSupplySerialNumber = String reference to "00001",0;
```

Power Supply Asset Tag

```
Data Example: The power supply's asset tag does not exist.
```

```
PowerSupplyAssetTag = 0;
```

Power Supply Model Part Number

```
Data Example: The power supply's model part number is 666.
```

```
PowerSupplyModelPartNumber = String reference to "666",0;
```



Power Supply Revision Level

```
Data Example: The power supply's revision number is 13.7.

PowerSupplyRevisionLevel = String reference to "13.7",0;
```

Power Supply Maximum Power Capacity

```
Data Example: The maximum power supply wattage is 3 watts.

PowerSupplyMaxPowerCapacity.Value = 0x03;

PowerSupplyMaxPowerCapacity.Exponent = 0x00;
```

Power Supply Characteristics

Data Example: The power supply is present, the input voltage range is manual switching, the power supply is okay, and the power supply type is switching.

Power Supply Input Voltage Probe Link

Data Example: The power supply's input voltage probe *Instance* is 0x3E7.

```
ThisDevice.PowerSupplyInputVoltageProbeLink.ProducerName = GUID
Voltage probe;
ThisDevice.PowerSupplyInputVoltageProbeLink.Instance = 0x3E7;
ThisDevice.PowerSupplyInputVoltageProbeLink.SubInstance = 0x00;
```

Power Supply Cooling Device Link

Data Example: The power supply's cooling device *Instance* is 0x489 and the *SubInstance* is 0x02 (second fan).

```
ThisDevice.PowerSupplyCoolingDeviceLink.ProducerName = GUID fan;
ThisDevice.PowerSupplyCoolingDeviceLink.Instance = 0x489;
ThisDevice.PowerSupplyCoolingDeviceLink.SubInstance = 0x02;
```

Power Supply Input Current Probe Link

Data Example: The power supply's input current probe *Instance* is 0x1033.

```
ThisDevice.PowerSupplyInputCurrentProbeLink.ProducerName = GUID
current probe;
ThisDevice.PowerSupplyInputCurrentProbeLink.Instance = 0x1033;
ThisDevice.PowerSupplyInputCurrentProbeLink.SubInstance = 0x00;
```

SMBIOS Structure Encapsulation (Types 0x80 to 0xFF) Record Numbers

SMBIOS Header

Data Example: Need to describe SMBIOS OEM-specific structure type 0x80 that conveys information about an OEM server management card. The structure prototype is defined below:

The formatted data is followed on one double **NULL**-terminated string that represents the name of the card.

Therefore, the data producer sets *Hdr*. Type is to **0x80**.

Hdr.Length is initialized to sizeof (EFI_SMBIOS_TYPE80_FORMATTED_DATA) by the producer.

Hdr. Handle is left uninitialized.

Raw Data

Data Example: The card version is 3. Therefore, the producer initializes *CardVersion* to 3. *CardNameStrRef* is 0x1 in accordance with the *SMBIOS Specification*.

The card is named "The Greatest." The formatted data is followed by the actual string "The Greatest," followed by two **NULL** bytes. The raw data can be represented by the following sequence of bytes:

```
0x3, 0x1, 'T', 'h', 'e', 'G', 'r', 'e', 'a', 't', 'e', 's', 't', 0x0, 0x0
```

The producer can choose to publish the string in a language that corresponds to the system language as described by the global variable *Lang*.

In any case, the raw data is opaque to a driver that consumes this record to construct an SMBIOS table.