Enabling Zephyr on Your Hardware Platform

Diego Sueiro, Sepura / Embarcados www.embarcados.com.br

OpenIoT Summit Europe 2018

Agenda



Hardware support implementation in Zephyr

Adding a new HAL

Adding a new SoC

Adding new drivers

Adding a new board

Debugging tips

Hardware support checklist

Contributing to mainline

Preamble



- Source code examples based on master branch <u>1ec4b68</u>;
- Some sources were stripped to fit on the screen;
- All examples based on the support for Zephyr running on the ARM Cortex M4 core embedded in the i.MX7 processor;
- This presentation will not cover how to add a new CPU core architecture support. But a
 good documentation on how to achieve this can be find here;
- Not all hardware aspects will be covered;

Agenda



Hardware support implementation in Zephyr

Adding a new HAL

Adding a new SoC

Adding new drivers

Adding a new board

Debugging tips


Hardware support checklist

Contributing to mainline



Hardware support implementation in Zephyr

Hardware Configuration Hierarchy (bottom to top):



OpenIoTSummit Europe

Hardware support implementation in Zephyr

Hardware Configuration Hierarchy:

Architecture: arc, arm, nios2, posix, riscv32, x86 and xtensa

CPU Core (a.k.a architecture):

- Implements: early boot sequence, interrupt and exception handling, thread context switching, thread creation and termination, CPU idling/power management, fault management, linker scripts and toolchains;
- Examples: ARCV2, CORTEX_M0, CORTEX_M0PLUS, CORTEX_M4, CORTEX_M7, CORTEX_M23,
 CORTEX_M33, NIOS2_GEN2, ATOM, MINUTEIA and APOLLO_LAKE.

SoC Family:

- Represents a single SoC type that can have more than one variations in terms of peripherals and features;
- Examples: KINETIS, IMX, SAM, SAM0, NRF, EXX32, LPC, TISIMPLELINK, STM32 and QUARK.

SoC Series:

- Represents the specific peripherals and features for the SoC family variations;
- Examples: KINETIS_K6X, KINETIS_KWX, KINETIS_KL2X, IMX_RT, IMX7_M4, IMX6_M4, NRF51X, NRF52X, EFM32WG, EFR32FG1P.

OpenIoTSummit Europe

Hardware support implementation in Zephyr

Hardware Configuration Hierarchy (cont):

SoC:

- The actual SoC that is "soldered" in the hardware platform and its configuration;
- Examples: MKL25Z32VFM4, MCIMX7D5EVM10SC, SAMD20E14, EFM32WG990F256, LPC54114J256BD64.

Drivers:

- Include device model responsible for configuring and initialize drivers. Each driver follows a device model API and a specific driver type API;
- Examples: interrupt controller, timer, serial communications (UART, I2C etc) and random number generator.

Board:

- Includes a SoC and it's associated peripherals and features including external components and devices;
- Examples: NRF51_BLENANO, NUCLEO_F103RB, COLIBRI_IMX7D_M4, 96B_CARBON, MIMXRT1050_EVK, HEXIWEAR_K64, QUARK_SE_C1000_BLE, CC2650_SENSORTAG, ADAFRUIT_TRINKET_M0 (more than 100 available).



Hardware support implementation in Zephyr

 Top level hardware configurations are defined via Kconfigs and the final processing results located in the files:

```
build/<board>/zephyr/.config
build/<board>/zephyr/include/generated/autoconf.h
```

 Low level hardware specific configurations are defined via device tree and the final processing results located in the files:

```
build/<board>/zephyr/include/generated/generated_dts_board.conf
build/<board>/zephyr/include/generated/generated_dts_board.h
```





Hardware support implementation in Zephyr

Adding a new HAL	Architecture		
Adding a new SoC	CPU Core		
Adding new drivers	SoC Family	▶	
Adding a new board	SoC Series	▶	
Debugging tips	SoC	▶	External HAL (optional)
Hardware support checklist	Drivers	▶	
Contributing to mainline	Board	▶	

OpenloTSummit Europe

Adding a new HAL

- Added to support SoC, board and drivers implementations;
- Low level libraries mostly implemented by the SoC vendor to interface and configure the hardware;
- Different types of HAL, pros and cons covered at Maureen Helm's presentation: Using SoC Vendor HALs in the Zephyr Project - <u>Video</u>, <u>slides</u>;
- Needs to be approved by the <u>Zephyr Technical Steering Committee</u> for non-Apache 2.0;
- Located at: ext/hal/<vendor>/<lib_name>/;


OpenIoTSummit Europe

Adding a new HAL

- Just bug fixing modifications are allowed in these source/headers files;
- No standard coding style and directory structure;
- Almost all ARM devices follow the CMSIS standard headers for registers manipulation;
- Enabled with a config option, example: CONFIG_HAS_IMX_HAL;
- Has a set of Kconfig and CMakeLists.txt files to determine what to include and compile;



Example: i.XM7 ARM Cortex M4 core from NXP FreeRTOS BSP locate at ext/hal/nxp/imx/ with the following structure:





Example: i.XM7 ARM Cortex M4 (cont)

```
ext/hal/nxp/imx/README:
iMX7D and MX6SX Port
#######################
Origin:
   <...>
Status:
   <...>
Purpose:
   <...>
Description:
   <...>
<...>
```

Follows the structure defined Contributing non-Apache 2.0 licensed components.



Example: i.XM7 ARM Cortex M4 (cont)

```
ext/hal/nxp/imx/Kconfig:
      config HAS IMX HAL
              bool
              select HAS CMSIS
              depends on SOC FAMILY IMX
      if HAS IMX HAL
      config HAS IMX RDC
              bool
              help
                Set if the RDC module is present in the
                SoC.
      config HAS IMX CCM
              bool
              help
                Set if the CCM module is present in the
                SoC.
```

```
ext/hal/nxp/imx/Kconfig (cont):
      config HAS IMX GPIO
               bool
              help
                Set if the GPIO module is present in the
                 SoC.
      config HAS IMX I2C
               bool
              help
                Set if the I2C module is present in the
                 SoC.
      endif # HAS IMX HAL
```

OpenIoTSummir Europe

Example: i.XM7 ARM Cortex M4 (cont)

```
ext/hal/nxp/imx/CMakeLists.txt:
    # Translate the SoC name and part number into the imx device and cpu
# name respectively.
    string(TOUPPER ${CONFIG_SOC} IMX_DEVICE)

zephyr_include_directories(devices/${IMX_DEVICE})

# Build imx drivers and utilities that can be used for multiple SoC's.
    add_subdirectory(drivers)
    add_subdirectory(devices/${IMX_DEVICE})
```

Example: Toradex Colibri iMX7 Dual HAL related generated configs

build/colibri_imx7d_m4/zephyr/.config: CONFIG_HAS_IMX_HAL=y CONFIG_HAS_IMX_GPIO=y CONFIG_HAS_IMX_I2C=y







Hardware support implementation in Zephyr

Adding a new HAL	Architecture		
Adding a new SoC	CPU Core		
Adding new drivers	SoC Family		
Adding a new board	SoC Series		
Debugging tips	SoC	······	External HAL (optional)
Hardware support checklist	Drivers	······	(Optional)
Contributing to mainline	Board		

OpenloTSummit Europe

Adding a new SoC

- Defines the SOC_FAMILY, SOC_SERIES, SOC and SOC_PART_NUMBER configs;
- Located at: soc/<architecture>/<soc_family>/<soc_series>/;
- SoC initialization like clocks, memories, cache, chip erratas, watchdog etc in a soc.c file;
- Called in the system initialization process with the level PRE_KERNEL_1 and priority 0;
- Provides a soc.h header which will be often included by the board and drivers sources;
- Can extend functionalities not provided by the vendor HAL;
- Contains a set of Kconfig files, linker definitions, and device tree fixups.



- These default configs will dictate what Kconfigs will be sourced and which CONFIG_ entries will be selected and generated for the SoC presented on the hardware platform;
- Has a dtsi defining peripherals and features properties presented in the SoC and is located at dts/<architecture>/<vendor>/<vendor>_<soc_name>.dtsi;
- May have a dts.fixup file that contain mappings from existing Kconfig options to the actual underlying DTS derived configuration #defines.



dtsi defining peripherals and features properties presented in the SoC Example: i.XM7 ARM Cortex M4 locate dtsi at dts/arm/nxp/

```
dts/arm/nxp/nxp imx7d m4.dtsi:
      #include <arm/armv7-m.dtsi>
      #include <dt-bindings/gpio/gpio.h>
      #include <dt-bindings/i2c/i2c.h>
      #include <dt-bindings/rdc/imx rdc.h>
      / {
              cpus {
                      #address-cells = <1>;
                      #size-cells = <0>;
                       cpu@0 {
                               device type = "cpu";
                               compatible = "arm,cortex-m4";
                               reg = <0>;
                       };
              };
```

```
dts/arm/nxp/nxp imx7d m4.dtsi (cont):
       soc {
              <...>
             tcml code: code@1fff8000 {
                      compatible = "nxp,imx-code-bus";
                      reg = <0x1fff8000 0x8000>;
                      label = "TCML CODE";
             };
             tcmu sys: memory@20000000 {
                      device type = "memory";
                      compatible = "nxp,imx-sys-bus";
                      reg = \langle 0x20000000 0x8000 \rangle;
                      label = "TCMU SYSTEM";
              };
              <...>
```



dtsi defining peripherals and features properties presented in the SoC Example: i.XM7 ARM Cortex M4 locate dtsi at dts/arm/nxp/

```
dts/arm/nxp/nxp imx7d m4.dtsi (cont):
      <...>
      gpio7: gpio@30260000 {
             compatible = "nxp,imx-gpio";
             reg = <0x30260000 0x10000>;
             interrupts = <76 0>, <77 0>;
             label = "GPIO 7";
             rdc = <(RDC DOMAIN PERM(A7 DOMAIN ID, RDC DOMAIN PERM RW) |\
                     RDC DOMAIN PERM(M4 DOMAIN ID, RDC DOMAIN PERM RW))>;
             gpio-controller;
             #gpio-cells = <2>;
             status = "disabled";
      };
      <...>
      &nvic {
              arm,num-irq-priority-bits = <4>;
      };
```




dts.fixup files contain mappings from existing Kconfig options to the actual underlying DTS derived configuration #defines.

Example: i.XM7 ARM Cortex M4

soc/arm/nxp imx/mcimx7 m4/dts.fixup:

<...>

```
<...>
#define CONFIG NUM IRQ PRIO BITS
                                               ARM V7M NVIC E000E100 ARM NUM IRQ PRIORITY BITS
<...>
#define CONFIG GPIO IMX PORT 7 NAME
                                               NXP IMX GPIO 30260000 LABEL
#define CONFIG GPIO IMX PORT 7 BASE ADDRESS
                                               NXP IMX GPIO 30260000 BASE ADDRESS
#define CONFIG GPIO IMX PORT 7 IRQ 0
                                               NXP IMX GPIO 30260000 IRQ 0
#define CONFIG GPIO IMX PORT 7 IRQ 0 PRI
                                               NXP IMX GPIO 30260000 IRQ 0 PRIORITY
#define CONFIG GPIO IMX PORT 7 IRQ 1
                                               NXP IMX GPIO 30260000 IRQ 1
#define CONFIG GPIO IMX PORT 7 IRQ 1 PRI
                                               NXP IMX GPIO 30260000 IRQ 1 PRIORITY
<...>
#define CONFIG UART IMX UART 2 NAME
                                               NXP IMX UART 30890000 LABEL
#define CONFIG UART IMX UART 2 BASE ADDRESS
                                               NXP IMX UART 30890000 BASE ADDRESS
#define CONFIG UART IMX UART 2 BAUD RATE
                                               NXP IMX UART 30890000 CURRENT SPEED
#define CONFIG UART IMX UART 2 IRQ NUM
                                               NXP IMX UART 30890000 IRQ 0
#define CONFIG UART IMX UART 2 IRQ PRI
                                               NXP IMX UART 30890000 IRQ 0 PRIORITY
#define CONFIG UART IMX UART 2 MODEM MODE
                                               NXP IMX UART 30890000 MODEM MODE
```





Example: i.XM7 ARM Cortex M4 SoC specific source code at soc/arm/nxp_imx/mcimx7_m4/ with the following structure:

```
soc/arm/nxp_imx/
           CMakeLists.txt
         Kconfig

    Kconfig.defconfig

         Kconfig.soc
         - mcimx7 m4
                CMakeLists.txt
               dts.fixup
               — Kconfig.defconfig.mcimx7 m4
               — Kconfig.defconfig.series
               — Kconfig.series
                — Kconfig.soc
                - linker.ld
                - soc.c
                soc clk freq.c
                soc clk freq.h
                - soc.h
```



Kconfig processing order when cmake -DBOARD=<BOARD_NAME> ../.. command is issued:

```
[00] $(BOARD DIR)/<BOARD NAME> defconfig
[01] Kconfig -> [02]
[02] Kconfig.zephyr -> [03] | [04] | [05] | [08] | [11] | [17]
[03] $(BOARD DIR)/Kconfig.defconfig
[04] boards/shields/*/Kconfig.defconfig
[05] $(SOC DIR)/$(ARCH)/*/Kconfig.defconfig -> [06]
[06] $(SOC DIR)/$(ARCH)/<SOC FAMILY>/*/Kconfig.defconfig.series -> [07]
[07] $(SOC DIR)/$(ARCH)/<SOC FAMILY>/<SOC SERIES>/Kconfig.defconfig.<SOC SERIES>
[08] boards/Kconfig -> [09] | [10]
[09] $(BOARD DIR)/Kconfig.board
[10] $(BOARD DIR)/Kconfig
[11] $(SOC DIR)/Kconfig -> [12] | [14] | [15]
[12] $(SOC DIR)/$(ARCH)/*/Kconfig.soc -> [13]
[13] $(SOC DIR)/$(ARCH)/<SOC FAMILY>/*/Kconfig.series
[14] $(SOC DIR)/$(ARCH)/Kconfig
[15] $(SOC DIR)/$(ARCH)/*/Kconfig -> [16]
[16] $(SOC_DIR)/$(ARCH)/<SOC_FAMILY>/*/Kconfig.soc
[17] arch/Kconfig
```



Kconfig processing order (cont)

Example: Toradex Colibri iMX7 Dual (cmake -DBOARD=colibri_imx7d_m4 ../..)

```
[00] boards/arm/colibri imx7d m4/colibri imx7d m4 defconfig
[01] Kconfig -> [02]
[02] Kconfig.zephyr -> [03] | [04] | [05] | [08] | [11]
[03] boards/arm/colibri imx7d m4/Kconfig.defconfig
[04] boards/shields/*/Kconfig.defconfig
[05] soc/arm/nxp imx/Kconfig.defconfig -> [06]
[06] soc/arm/nxp imx/mcimx7 m4/Kconfig.defconfig.series -> [07]
[07] soc/arm/nxp imx/mcimx7 m4/Kconfig.defconfig.mcimx7 m4
[08] boards/Kconfig -> [09] | [10]
[09] boards/arm/colibri imx7d m4/Kconfig.board
[10] boards/arm/colibri imx7d m4/Kconfig
[11] soc/Kconfig -> [12] | [14] | [15]
[12] soc/arm/nxp imx/Kconfig.soc -> [13]
[13] soc/arm/nxp imx/mcimx7 m4/Kconfig.series
[14] soc/arm/Kconfig
[15] soc/arm/nxp imx/Kconfig -> [16]
[16] soc/arm/nxp imx/mcimx7 m4/Kconfig.soc
```

OpenIoTSummit Europe

SoC specific Kconfig files

Example: i.XM7 ARM Cortex M4

```
[00] boards/arm/colibri imx7d m4/colibri imx7d m4 defconfig
[01] Kconfig -> [02]
[02] Kconfig.zephyr -> [03] | [04] | [05] | [08] | [11]
[03] boards/arm/colibri imx7d m4/Kconfig.defconfig
[04] boards/shields/*/Kconfig.defconfig
[05] soc/arm/nxp imx/Kconfig.defconfig -> [06]
[06] soc/arm/nxp imx/mcimx7 m4/Kconfig.defconfig.series -> [07]
[07] soc/arm/nxp imx/mcimx7 m4/Kconfig.defconfig.mcimx7 m4
[08] boards/Kconfig -> [09] | [10]
[09] boards/arm/colibri imx7d m4/Kconfig.board
[10] boards/arm/colibri imx7d m4/Kconfig
[11] soc/Kconfig -> [12] | [14] | [15]
[12] soc/arm/nxp imx/Kconfig.soc -> [13]
[13] soc/arm/nxp_imx/mcimx7_m4/Kconfig.series
[14] soc/arm/Kconfig
[15] soc/arm/nxp_imx/Kconfig -> [16]
[16] soc/arm/nxp imx/mcimx7 m4/Kconfig.soc
```





Example: Toradex Colibri iMX7 Dual SoC related generated configs

```
samples/subsys/shell/shell module/build/colibri imx7d m4/zephyr/.config:
      CONFIG SOC="mcimx7d"
      CONFIG SOC SERIES="mcimx7 m4"
      CONFIG NUM IRQS=127
      CONFIG_SYS_CLOCK_HW_CYCLES_PER_SEC=200000000
      CONFIG SOC PART NUMBER="MCIMX7D5EVM10SC"
      CONFIG_CLOCK_CONTROL IMX CCM=y
      CONFIG GPIO IMX=y
      CONFIG UART IMX=y
      CONFIG SYS CLOCK TICKS PER SEC=1000
      CONFIG SOC SERIES IMX7 M4=y
      CONFIG SOC FAMILY="nxp imx"
      CONFIG SOC FAMILY IMX=y
      CONFIG SOC MCIMX7 M4=y
      CONFIG SOC PART NUMBER MCIMX7D5EVM10SC=y
      CONFIG SOC PART NUMBER IMX7 M4="MCIMX7D5EVM10SC"
```





Hardware support implementation in Zephyr

Adding a new HAL	Architecture	
Adding a new SoC	CPU Core	
Adding new drivers	SoC Family	
Adding a new board	SoC Series	
Debugging tips	SoC	 External HAL (optional)
Hardware support checklist	Drivers	
Contributing to mainline	Board	

Adding a new Driver



- Provides interface to the hardware;
- Located at drivers/<driver_type>/;
- Must implement the API exposed in include/<driver_type>.h;
- One driver multiple instances;
- Selection and configuration done via Kconfigs and device tree;
- May use the vendor HAL (shim drivers);
- Initialization performed during the kernel boot.

OpenloTSummit Europe

Adding a new Driver

- Yaml file to describe the device tree nodes and properties;
- Device tree file to define driver properties and configurations;
- Good ramp up <u>documentation</u> available;
- Unfortunately we don't have time to cover this topic in this presentation :-(





Agenda

Hardware support implementation in Zephyr

Adding a new HAL	Architecture	
Adding a new SoC	CPU Core	
Adding new drivers	SoC Family	
Adding a new board	SoC Series	
Debugging tips	SoC	 External HAL (optional)
Hardware support checklist	Drivers	
Contributing to mainline	Board	

OpenloTSummit Europe

Adding a new Board

- Represents the application hardware platform;
- Located at boards/<architecture>/<board_name>/;
- Extends the SoC and enable/disable its peripherals and functions and instantiate external devices via device tree (<board_name>.dts) and Kconfigs;
- Applies the pin muxing configuration;
- Contains a board.h to be used by the drivers;
- Contains a <board_name>_defconfig file to define which SoC and basic features and interfaces included;

OpenloTSummit Europe

Adding a new Board

- May set flash partitions layout in the <board_name>.dts file;
- May include a dts.fixup file which contain mappings from existing Kconfig options to the actual underlying DTS derived configuration #defines;
- May include other source files to configure specific hardware and board features;
- May provide a board.cmake to instruct how to flash/debug;
- Includes a <board_name>.yaml file to list the board properties: e.g. flash and ram sizes and toolchain used, etc;
- Must have documentation listing the supported features, interfaces etc.



OpenIoTSummit Europe

Source code located at boards/<architecture>/<board_name>/
Example: Toradex Colibri iMX7 Dual



Adding a new Board

Includes a <board_name>.yaml file to list the board properties: e.g. flash and ram sizes and toolchain used, etc

Example: Toradex Colibri iMX7 Dual



Adding a new Board

Device tree boards/<architecture>/<board_name>.dts extending the SoC and setting external devices.

Example: Toradex Colibri iMX7 Dual

```
boards/arm/colibri imx7d m4/colibri imx7d m4.dts:
      /dts-v1/;
      #include <nxp/nxp imx7d m4.dtsi>
      / {
              model = "TORADEX Colibri IMX7D board";
              compatible = "nxp,mcimx7d m4";
              aliases {
                      gpio-1 = \&gpio1;
                      gpio-2 = &gpio2;
                      uart-2 = &uart2;
                      led0 = &green led;
                             = &user switch 1;
                      sw0
                      i2c-4 = &i2c4;
                      pwm-1 = &pwm1;
              };
```

```
boards/arm/colibri imx7d m4/colibri imx7d m4.dts (cont):
      chosen {
      #if defined(CONFIG XIP)
             zephyr,flash = &tcml code;
      #endif
              zephyr,sram = &tcmu sys;
             zephyr,console = &uart2;
      };
      leds {
             compatible = "gpio-leds";
              green led: led@0 {
              gpios = <&gpio1 2 GPIO INT ACTIVE LOW>;
              label = "User LED1";
             };
      };
```



Device tree boards/<architecture>/<board_name>.dts extending the SoC and setting external devices.

```
boards/arm/colibri imx7d m4/colibri imx7d m4.dts (cont):
              gpio keys {
                       compatible = "gpio-keys";
                       user switch 1: sw@0 {
                               gpios = <&gpio2 26
                                  GPIO INT ACTIVE LOW>;
                               label = "User SW1";
                      };
              };
      };
      &uart2 {
              status = "ok";
              current-speed = <115200>;
              modem-mode = <64>;
      };
```

```
boards/arm/colibri imx7d m4/colibri imx7d m4.dts (cont):
      &gpio1 {
              status = "ok";
      };
      &gpio2 {
              status = "ok";
      };
      &i2c4 {
              status = "ok";
      };
      &pwm1 {
              status = "ok";
      };
```



boards/<architecture>/<board_name>/Kconfig.board file that basically defines the board config, list SOC_SERIES dependency and selects the SOC_PART_NUMBER

```
boards/arm/colibri_imx7d_m4/Kconfig.board:
    config BOARD_COLIBRI_IMX7D_M4
        bool "Toradex Colibri iMX7 Dual"
        depends on SOC_SERIES_IMX7_M4
        select SOC_PART_NUMBER_MCIMX7D5EVM10SC
```



boards/<architecture>/<board_name>/Kconfig.defconfig file with invisible symbols that selects hardware interfaces and features and sets its default values.



boards/<architecture>/<board_name>/<board_name>_defconfig file with visible symbols that selects the architecture, SoC aspects, board config, top level interfaces and features.

Agenda



Hardware support implementation in Zephyr

Adding a new HAL

Adding a new SoC

Adding new drivers

Adding a new board

Debugging tips

Hardware support checklist

OpenIoTSummit Europe

Debugging tips

- Look at other source code reference (e.g. FreeRTOS) to understand what needs to be done to initialize the SoC;
- Try to print to UART (accessing the registers directly) in the SoC initialization to guarantee that the core is up and running;
- Implement the UART driver first, printk is life;
- Turn on the <u>System Logging</u> or <u>Logger</u>;
- Turn on asserts (CONFIG_ASSERT) to try to catch errors;
- Use a on-chip debugger (J-Link, ULINK etc).

Agenda



Hardware support implementation in Zephyr

Adding a new HAL

Adding a new SoC

Adding new drivers

Adding a new board

Debugging tips

Hardware support checklist

OpenloTSummit Europe

Hardware support checklist

- For a new HAL:
 - Add a Kconfig and CMakeLists.txt files for build configuration and source codes includes and selection;
 - Import all the source code but only compile and include what is needed;
- For a new SoC, files to add:
 - o dts/<architecture>/<vendor>/<vendor>_<soc_name>.dtsi
 - o soc/<architecture>/<soc_family>/<soc_series>/

```
CMakeLists.txt
C
```

Hardware support checklist

- For a new Board, files to add:
 - boards/<architecture>/<board_name>/

```
board.h
CMakeLists.txt
CMakeLists.txt
Compare config
```



Agenda



Hardware support implementation in Zephyr

Adding a new HAL

Adding a new SoC

Adding new drivers

Adding a new board

Debugging tips

Hardware support checklist

OpenIoTSummit Europe

- Follow the <u>coding style</u> (except for vendor HAL or source inside /ext directory);
- Follow the <u>commit guidelines</u>;
- Follow the <u>documentation guidelines</u>;
- Run the <u>sanitycheck</u> before pushing;
- There is a good example of <u>contribution workflow</u> when submitting patches for review;

OpenIoTSummit Europe

- When adding a new hardware platform split the PR in different patches:
 - ext/hal: for adding a new hal
 - o drivers: for adding a new driver
 - soc: for adding a new SoC
 - boards: for adding a new board
- Be patient.

References



- Zephyr docs:
 - Architecture Porting Guide
 - Board Porting Guide
 - <u>Device Tree in Zephyr</u>
 - Application Development Primer
- Using SoC Vendor HALs in the Zephyr Project Maureen Helm, NXP Semiconductors -Embedded Linux Conference Europe 2017 - <u>Video</u>, <u>slides</u>.

THANK YOU!!!!

Questions?

Diego Sueiro, Embarcados

www.embarcados.com.br diego.sueiro@gmail.com linkedin.com/in/diegosueiro/

OpenIoT Summit Europe 2018