P4.3 TEST PLAN

READING TEMPERATURE SENSOR (GUI)

VERSION I

NOV. 17, 2017

RICHARD CONSTANTINE

#7686561

TABLE OF CONTENTS

1	- TPP VERSION HISTORY	3
2	- INTRODUCTION	3
	- READING TEMPERATURE SENSOR (GUI)	
	3.1 Test Plan and Cases	
	3.2 Test Procedure	
4	- TEST PLAN TEMPLATE APPROVAL	5
5	- REFERENCES	6

1 - TPP VERSION HISTORY

Version #	Implemented By	Revision Date	Approved By	Approval Date	Reason	Mark
1	Richard Constantine	11/17/2017				

2 - INTRODUCTION

2.1 PURPOSE OF THE TEST PLAN TEMPLATE DOCUMENT

The purpose of this test plan document is to test the client software (with the GUI) to confirm that it can successfully establish a TCP connection with the server software on the MX7 board, as well as provide functionality to read the connected temperature sensor (via the I2C bus).

3 - READING TEMPERATURE SENSOR (GUI)

3.1 TEST PLAN AND CASES

Item to Test	Test Description	Test Date	Responsibility
SENSOR (GUI)	The tester will connect and command the MX7 server via the graphic interface. The tester will confirm that the MX7 board can successfully read and communicate the temperature, and the client can successfully display it.		Richard Constantine

3.2 TEST PROCEDURE

Instru	action	P/F
1.	Ensure the PC being used has an up-to-date version of Windows (Windows 7 or later) along with the Netbeans IDE, ensuring to download the Java JDK (these can be found via google).	
2.	Also, ensure that a version of MPLAB X (v4.01 or later) is installed – this can be accomplished by downloading the software via the Microchip website – then connect the MX7 board (using the debug port) to the host PC with the USB micro cable. Also connect the device to the host PC using an ethernet connection.	
3.	Ensure that the MX7 board has the temperature sensor connected to the right-most pins of the I2C2 jumper,	
4.	Go to the Google OneDrive URL sent via email. This should take you a folder called Richard Constantine - 7686561 - ECE 3740 - Assignment 8. Download and extract all files within P4.3.zip, and place its contents in a directory called C:\Users\ <yourusername>\ECE3740\Constantine_Richard_P4\P4.3.</yourusername>	
5.	Start the Netbeans IDE by doubling clicking the desktop icon, or locating the install folder and running the .exe.	

6.	Next, within Nebeans, open the client project by selecting File -> Open Project. Browse to			
	C:\Users\ <yourusername>\ECE3740\Constantine_Richard_P4\P4.3\v1\ClientwithGUI and open the project called client.java.</yourusername>			
7.	Within MPLAB X, open the server project by selecting File -> Open Project and browsing to C:\Users\ <yourusername>\ECE3740\Constantine_Richard_P4\P4.3\v1\MX7Server\TCPIPStack\TCPIP\Demo App\ and opening the project XC32-PIC32_ETH_SK_ETH795.</yourusername>			
8.	Ensure that the IP address is correctly configured in the clienttest.java file of the Client.			
9.	Run the client program by highlighting the client project in the Projects tab (within Netbeans) and selecting Run -> Run Project (client).			
10.	Run the server program by highlighting the XC32-PIC32_ETH_SK_ETH795 project in the Projects tab (within MPLAB X) and selecting Run -> Run Project.			
11.	Once the server has finished compiling and programming (a message will indicate when the program has been uploaded). When the 'Connect' button is pressed, a message should appear in the 'Console Messages' confirming this button press.			
12.	Try pressing the 'Get Temperature' button. This should display the temperature to 4 decimal places in the 'Console Messages' of the GUI.			
13.	The 'Get Time' button also reads the temperature in this design.			
14.	When one of the 'Read' buttons are pressed, it should alter the 'Console Messages' with the appropriate pushbutton status – confirm this by pressing the read button while the PBs are up and down to confirm that they are being read correctly.			
15.	When one of the LED buttons are pressed, a message should appear in the 'Console Messages' confirming this button press, as well as the button should stay highlighted indicating that the LED is currently toggled on. The same should occur when the LED is toggled off. This can be confirmed by looking at the MX7 board and confirming the LEDs are responding.			
16.	When the 'Disconnect' button is pressed, a message should appear in the 'Console Messages' confirming this button press.			
17.	Try to again connect to the server using the 'Connect' button – ensure that the client can successfully reconnect and communicate with the server.			
18.	Check that the client can still receive temperature readings from the MX7 server by clicking the 'Get Time' button.			
19.	Finally, exit the GUI by clicking the 'Quit' button or the 'x' in the top right corner. This should also disconnect the client if quitting while connected.			

4 - TEST PLAN TEMPLATE APPROVAL

Required Signatures:

The undersigned acknowledge they have reviewed the P4.3 Test Plan Template document and agree with the approach it presents. Any changes to this Requirements Definition will be coordinated with and approved by the undersigned or their designated representatives.

 TA - Kaiser Nahiyan 		
Signature:	Date:	
Print Name:		
Title:		
Role:		

REFERENCES

