
iDronam Suparna

Processing Specifications v1.0 Dec 1, 2024





Searching for Keywords

Search for keywords such as "battery" and "install" to find a topic. Press Ctrl+F on Windows or Command+F on Mac to begin a search.

? Printing this Document

This document supports high resolution printing.

Revision Notes				
v1.0	01-Dec-2024	Initial Version		

Using this Manual

Read Before the First Flight

Read the following documents before using the **Suparna**:

- 1. Disclaimer and Safety Guidelines
- 2. Quick Start Guide
- 3. User Manual

It is recommended to watch all tutorial videos on the official Menthosa website and read the disclaimer and safety guidelines before using for the first time. Prepare for your first flight by reviewing the quick start guide and refer to this user manual for more information

The operating temperature of this product is 0° to 40° C. It does not meet the standard operating temperature for military grade application (-55° to 125° C), which is required to endure greater environmental variability. Operate the product appropriately and only for applications that meet the operating temperature range requirements of that grade.

iDronam Suparna : User Manual

Content

Processing Specifications	6
On-board Computer Specifications	6
Contact Us	8
Contact	8

iDronam Suparna: User Manual

Processing Specifications

This section provides specifications about **Suparna** on board computer.

Processing Specifications

On-board Computer Specifications

SOC Name	Broadcom BCM2711
CPU Name	ARM Cortex-A72 (ARM v8)
Core Count	4 (Quad-Core)
Architecture	64 bit
Processing Speed	1.5 GHz
RAM	4 GB LPDDR4 @ 3200 MHz
Storage	32GB

iDronam Suparna : User Manual

Contact Us

Feel Free to Contact Us

Contact Us

Contact

Visit www.menthosa.com

For Software Updates and Downloads Visit https://idronam.com/

Sales Support : Mail us at sales@idronam.com

I This content is subject to change.

If you have any questions about this document, please contact Menthosa Solutions by sending a message to <u>director@menthosa.com</u> OR <u>sales@idronam.com</u>

iDronam Suparna : User Manual	Ĺ
END OF DOCUMENT	
END OF BOGGMENT	