TM-J2000 TM-J2100 TM-L90 TM-P20 TM-P60 TM-P60II TM-P80 TM-T20 TM-T20II TM-T70
TM-T70II TM-T82II TM-T88IV TM-T88V TM-T90 TM-U220 TM-U230

Select Printer(s)

GS (k <Function 165>

[Models]	TM-J2000 TM-J2100 ~~TM-L90~~ ~~TM-P20~~ ~~TM-P60~~ ~~TM-P60II~~ ~~TM-P80~~ ~~TM-T20~~ ~~TM-T20II~~ ~~TM-T70~~ ~~TM-T70II~~ ~~TM-T82II~~ ~~TM-T88IV~~ ~~TM-T88V~~ TM-T90 TM-U220 TM-U230
[Name]	QR Code: Select the model

[Format]

ASCII	GS	(	k	*pL*	*pH*	*cn*	*fn*	*n1* *n2*
Hex	1D	28	6B	04	00	31	41	*n1* *n2*
Decimal	29	40	107	4	0	49	65	*n1* *n2*

[Range] (pL + pH × 256) = 4

cn = 49

fn = 65

$n2$ = 0

$n1$: different depending on the printers

TM-L90:

[TM-L90 4** models]

$n1$ = 49, 50, 51

[TM-L90 Peeler, TM-L90 other than 4** models]

$n1$ = 49, 50

TM-P20, TM-P60, TM-P60II, TM-P80, TM-T20, TM-T20II, TM-T70, TM-T70II, TM-T82II, TM-T88IV, TM-T88V, TM-T90II:

$n1$ = 49, 50

[Default] $n1$ = 50, $n2$ = 0

[Description] Selects the model for QR Code.

$n1$	Function
49	Selects model 1
50	Selects model 2
51	Selects Micro QR Code

[Notes]
- Settings of this function affect the processing of Function 181 and 182.
- Settings of this function are effective until **ESC @** is executed, the printer is reset, or the power is turned off.

TM-P60:

Only the Peeler model supports this command.