Magic VLSI Cheatsheet

Harald Pretl Institute for Integrated Circuits, Johannes Kepler University Linz

© 2021-2022

This cheat sheet compiles useful commands (to be entered in the Tcl console) and bind keys (in the layout window) as well as a summary of the mouse operations for the different tool modes. This compilation relates to Magic 8.3 (see https://github.com/RTimothyEdwards/magic).

A comprehensive Magic documentation and description of all macros can be found at http://opencircuitdesign.com/magic/userguide.html.

The command macro layout in the Magic Tcl console lists all defined macros.

Useful commands:	
$ exttt{addpath} [\mathit{path}]$	add search $path$ of cells
$array \ xsize \ ysize$	array the selection <i>xsize</i> -times in X, <i>ysize</i> -times in Y,
	spacing by box
$\verb"contact" type"$	create contact inside box of intersecting layers
corner $dir1$ $dir2$	draws a corner inside box, first in dir1, then in dir2
	(cf. fill)
drc find	locate DRC error
drc why	explain DRC errors in box
$\mathtt{dump}\ cell$	copy given <i>cell</i> into current layout cell
erase $layers$	erase comma-separated list of <i>layers</i> in box
erase *	all layers but not labels
erase \$	erase everything (like CTRL-D)
erase labels	erase selected label(s) in box
fill dir	extend layers from one side of box to the other in the
	given direction (cf. corner)
findlabel $label$	center the box on the $label$
flatten cell	flatten the current edit cell incl. hierarchy into a new cell
flush	revert edit cell to last state on disk
get $cell$	instantiate cell into current edit cell
help [pattern]	shows help for various commands
identify cell-id	name the selected cell as $cell$ - id
iroute	interactive point-to-point router, from cursor to box
label $string$ [position]	create a point, line or box label
[layer]]	
load $cell$	open the <i>cell</i> in the layout window
$\begin{array}{ll} \texttt{macro} & [window_type] \\ [key & [value]] \end{array}$	new macro definition
measure [hor ver auto]	create a ruler in the box
paint <i>layers</i>	paint the comma-separated list of <i>layers</i> in box
plow dir	move layout structures incl. connectivity in <i>direction</i> , see manual
port make	create a port from selected label
port index number	assign a port index (must match the number from schematic)
quit [-nocheck]	exit magic (using -nocheck discards unsaved changes)
see [no] layers	show or hide comma-separated list of <i>layers</i>
see [no] *	show or hide all layers
select save file	Save selection as new file.mag
select short $label1$	Find the path that electrically connects (shorts) the
label2	nodes labeled <i>label1</i> and <i>label2</i> .
$straighten \ dir$	try to repair jogs by pulling in direction
tool	changes the currently used tool to (box, wiring, netlist, pick)
redraw	redraws the window
unmeasure	remove all rulers in box
what	print information about the current selection
xload cell	open the <i>cell</i> in the layout window unexpanded
xview	full view, with unexpanded cells

Bind keys:	
a	select everything in box
A	select additional objects in box
CTRL-A	deselect objects in box
b	print information about the box
В	center window on the box
С	сору
d	delete selection
CTRL-D	delete all layers and labels in box selected by cursor
е	makes the selected cell the new edit cell
F	flip the selection upside-down
g	toggle grid
G	toggle grid 2
i	select instance under cursor
I	select additional instance under cursor
CTRL-I	deselect instance under cursor
m	move selection to cursor position
0	openwindow (with current selection)
r	rotate 90
R	rotate -90
S	select objects under cursor
S	select additional objects under cursor
CTRL-S	deselect objects under cursor
u	undo the last operation
U	redo the last undo
v	view, full view of layout
W	writeall changed cells to disk
х	expand cells (make visible) in box
X	unexpand cells (hide) inside the box
CTRL-X	toggle the visibility of cells in box
У	drc why
Z	zoom out
Z	zoom in
CTRL-Z	zoom in on box
>	edit the selected cell in layout window (cf. <)
<	return from editing a cell (cf. >)
,	clear selection
:	directly jump to command window (like VI)
SPACE	${\rm change\ the\ tool}$
SHIFT + SPACE	change to the box tool
KEYPAD-2	move selection south, equivalent to 'move s 1'
SHIFT + KEYPAD-2	stretch selection south, equivalent to 'stretch s 1'
KEYPAD-4	move selection west, equivalent to 'move w 1'
SHIFT + KEYPAD-4	stretch selection west, equivalent to 'stretch w 1'
KEYPAD-6	move selection east, equivalent to 'move e 1'
SHIFT + KEYPAD-6	stretch selection east, equivalent to 'stretch e 1'
KEYPAD-8	move selection north, equivalent to 'move n 1'
SHIFT + KEYPAD-8	stretch selection north, equivalent to 'stretch n 1'

Bind keys (IIC add-on):	
f	full layout view
CTRL-F	flip the selection sideways
k	measure (ruler)
K	remove rulers
p	draw a wiring path
q	open poperty dialog of p-cell
?	show what is contained in box
=	find DRC error(s) and zoom to it (thanks M. Guthaus)
0	show locali
!	show metal-1
@	show metal-2
#	show metal-3
\$	show metal-4
%	show metal-5
9	show all layers

Mouse operations:	
Box tool: LEFT RIGHT MIDDLE SHIFT + MIDDLE	set lower-left corner of box set upper-right corner of box paint layer pointed with cursor in box erase layer pointed with cursor in box
Layer selection tool: LEFT RIGHT	show selected layer, cf. see hide selected layer, cf. see no
Wiring tool: LEFT MIDDLE RIGHT SHIFT + LEFT SHIFT + RIGHT SHIFT + MIDDLE	pick wire material and size from cursor place wire at cursor cancel wire change to higher layer (e.g. m1 to m2) change to lower layer (e.g. m2 to m1) place a contact at cursor and continue on higher layer
Pick tool: LEFT MIDDLE RIGHT SHIFT + MIDDLE	remove current selection and follow cursor place a copy and continue cancel make a copy of selection and follow cursor