GENERAL INFORMATION:			
SIMPLWINDOWS NAME:	Qsys Core		
CATEGORY:	Qsys		
VERSION:	2.2.2		
SUMMARY:	Multiple core modules can be used in the same program slot.  This module has a built in reconnect feature.		
GENERAL NOTES:	N/A		
CRESTRON HARDWARE REQUIRED:	3 Series Processor or 4 Series Processor		
SETUP OF CRESTRON HARDWARE:	TCP managed inside the module.		
VENDOR FIRMWARE:	N/A		
VENDOR SETUP:	N/A		

CONTROL:		
Initialize	D	Pulse to Initialize connection to the Q-SYS Core. Pulse this after DeploymentHost, TestingHost, DeploymentMode, and UseExternalConnection have been set to their desired states.
DeploymentHost	S	IP Address or Hostname of the Q-SYS Core to connect to for Deployment. This value will be used when DeploymentMode is 0.
[TestingHost]	S	IP Address or Hostname of the Q-SYS Core to connect to for Testing. This value will be used when DeploymentMode is 1.
DeploymentMode	Α	Specifies whether to use DeploymentHost or Testing Host.  0: DeploymentHost  1: TestingHost
[Debug]	A	Specifies the Debug level for the program 0: Off 1: Normal Debug 2: Verbose Debug Debug prints to Console Output.
[UseExternalConnection]	D	Raise to handle TCP connection outside of this module.
[ExternalConnectionRx]	S	Rx from the external TCP socket.

FEEDBACK:		
[IsInitialized]	D	Signal used to show if the Q-SYS Core has been initialized.
[IsConnected]	D	Signal used to show if the Q-SYS Core is communicating.
[IsLoggedIn]	D	Signal used to show if this module is logged in with the Q-SYS Core.
[IsRedundant]	D	Signal used to show if the Q-SYS Core is redundant.
[IsEmulator]	D	Signal used to show if the Q-SYS Core is connected to an emulated file.
[DesignName]	S	Signal used to show the current running design on the Q-SYS Core.
[ExternalConnectionTx]	S	Tx to the external TCP socket.

PARAMETERS:		
CoreID	S	Used to Address Core Module to Control Modules
Username	S	Username for the Core (if required)
Password	S	Password for the Core (if required)
Port	Dec	Default: 1710  Can be changed if doing port forwarding to get to a Q-SYS Core

TESTING:	
SAMPLE PROGRAM:	3-Series: 3 Series Test.smw 4-Series: 4 Series Test.smw
REVISION HISTORY:	