# 2015 Test beam Run Control

Generated by Doxygen 1.8.9.1

Wed Jun 3 2015 17:39:49

# **Contents**

1	Mod	lule Inde	ex		1
	1.1	Module	es		1
2	Hier	archica	I Index		3
	2.1	Class I	Hierarchy		3
3	Data	Structi	ure Index		5
	3.1	Data S	tructures		5
4	Mod	ule Doc	umentatio	on	7
	4.1	FPGA	board cont	trol	7
		4.1.1	Detailed	Description	7
	4.2	Socket	communic	cation objects	8
		4.2.1	Detailed	Description	8
		4.2.2	Enumera	tion Type Documentation	8
			4.2.2.1	SocketType	8
	4.3	HPTD	C chip cont	trol	9
		4.3.1	Detailed	Description	10
		4.3.2	Enumera	tion Type Documentation	10
			4.3.2.1	CoreClockSource	10
			4.3.2.2	DeadTime	10
			4.3.2.3	DLLClockSource	10
			4.3.2.4	DLLSpeedMode	10
			4.3.2.5	EdgeResolution	11
			4.3.2.6	EnabledError	11
			4.3.2.7	EnablePattern	11
			4.3.2.8	EventType	11
			4.3.2.9	IOClockSource	12
			4.3.2.10	ReadoutSingleCycleSpeed	12
			4.3.2.11	ReadoutSpeed	12
			4.3.2.12	RegisterName	12
			12212	Sorial Clook Source	10

iv CONTENTS

			4.3.2.14	SerialStrobeType	13
			4.3.2.15	WidthResolution	13
5	Data	Structi	ire Docum	mentation	15
•	5.1			erence	15
	0.1	5.1.1		Description	17
		5.1.2		etor & Destructor Documentation	17
		0.1.2	5.1.2.1	Client	17
			5.1.2.2	Client	17
			5.1.2.3	~Client	17
		5.1.3		Function Documentation	17
		5.1.5	5.1.3.1	Announce	17
			5.1.3.1	Connect	18
				Disconnect	
			5.1.3.3		18
			5.1.3.4	GetType	19
			5.1.3.5	ParseMessage	19
			5.1.3.6	Receive	19
			5.1.3.7	Send	20
		- 4	5.1.3.8	SendAndReceive	20
		5.1.4		cumentation	20
			5.1.4.1	fClientId	20
		_	5.1.4.2	flsConnected	20
	5.2			Reference	20
		5.2.1		Description	21
		5.2.2		tor & Destructor Documentation	21
			5.2.2.1	Exception	21
			5.2.2.2	Exception	21
			5.2.2.3	~Exception	21
		5.2.3	Member	Function Documentation	22
			5.2.3.1	Description	22
			5.2.3.2	Dump	22
			5.2.3.3	ErrorNumber	22
			5.2.3.4	From	22
			5.2.3.5	Type	22
			5.2.3.6	TypeString	22
		5.2.4	Field Doo	cumentation	22
			5.2.4.1	fDescription	22
			5.2.4.2	fErrorNumber	22
			5.2.4.3	fFrom	22
			5.2.4.4	fType	23

CONTENTS

5.3	file_he	ader_t Str	ruct Reference	23
	5.3.1	Detailed	Description	23
	5.3.2	Field Do	cumentation	23
		5.3.2.1	magic	23
		5.3.2.2	num_hptdc	23
		5.3.2.3	run_id	23
		5.3.2.4	spill_id	23
5.4	FileRe	ader Class	s Reference	23
	5.4.1	Construc	ctor & Destructor Documentation	24
		5.4.1.1	FileReader	25
		5.4.1.2	~FileReader	25
	5.4.2	Member	Function Documentation	25
		5.4.2.1	GetNextEvent	25
		5.4.2.2	GetNumTDCs	25
	5.4.3	Field Do	cumentation	25
		5.4.3.1	fFile	25
		5.4.3.2	fHeader	25
		5.4.3.3	fSetupCollection	25
5.5	FPGAI	Handler Cl	lass Reference	25
	5.5.1	Detailed	Description	27
	5.5.2	Construc	ctor & Destructor Documentation	27
		5.5.2.1	FPGAHandler	27
		5.5.2.2	~FPGAHandler	28
	5.5.3	Member	Function Documentation	28
		5.5.3.1	CloseFile	28
		5.5.3.2	ErrorState	28
		5.5.3.3	GetFilename	28
		5.5.3.4	GetTDC	28
		5.5.3.5	GetType	28
		5.5.3.6	OpenFile	28
		5.5.3.7	ReadBuffer	29
		5.5.3.8	SetTDCSetup	29
		5.5.3.9	Stop	29
	5.5.4	Field Do	cumentation	29
		5.5.4.1	fFilename	29
		5.5.4.2	flsFileOpen	29
		5.5.4.3	flsTDCInReadout	29
		5.5.4.4	fOutput	29
		5.5.4.5	fTDC	29
5.6	HTTPN	Message C	Class Reference	29

vi CONTENTS

		Description	
5.6.2	Construct	tor & Destructor Documentation	31
	5.6.2.1	HTTPMessage	31
	5.6.2.2	HTTPMessage	31
5.6.3	Member I	Function Documentation	31
	5.6.3.1	Decode	31
	5.6.3.2	Dump	31
	5.6.3.3	Encode	31
	5.6.3.4	GetKey	32
5.6.4	Field Doc	umentation	32
	5.6.4.1	fOriginalString	32
	5.6.4.2	fWS	32
Messag	ge Class R	deference	32
5.7.1	Detailed I	Description	33
5.7.2	Construct	tor & Destructor Documentation	33
	5.7.2.1	Message	33
	5.7.2.2	Message	33
	5.7.2.3	Message	33
	5.7.2.4	~Message	33
5.7.3	Member F	Function Documentation	33
	5.7.3.1	Dump	33
	5.7.3.2	GetKey	33
	5.7.3.3	GetString	33
	5.7.3.4	IsFromWeb	33
5.7.4	Field Doc	umentation	33
	5.7.4.1	fString	33
Messer	nger Class	Reference	34
5.8.1	Detailed I	Description	35
5.8.2	Construct	tor & Destructor Documentation	35
	5.8.2.1	Messenger	35
	5.8.2.2	Messenger	35
	5.8.2.3	$\sim$ Messenger	36
5.8.3	Member F	Function Documentation	36
	5.8.3.1	AddClient	36
	5.8.3.2	Broadcast	37
	5.8.3.3	Connect	37
	5.8.3.4	Disconnect	37
	5.8.3.5	DisconnectClient	38
	5.8.3.6	GetType	38
	5.8.3.7	ProcessMessage	38
	5.6.3 5.6.4 Messag 5.7.1 5.7.2 5.7.3	5.6.2.1 5.6.2.2 5.6.3.1 5.6.3.2 5.6.3.3 5.6.3.4 5.6.3.4 5.6.4.1 5.6.4.2  Message Class R 5.7.1 Detailed R 5.7.2 Construct 5.7.2.1 5.7.2.2 5.7.2.3 5.7.2.4 5.7.3 Member R 5.7.3.1 5.7.3.2 5.7.3.3 5.7.3.4 5.7.4 Field Door 5.7.4.1  Messenger Class 5.8.1 Detailed R 5.8.2 Construct 5.8.2.1 5.8.2.2 5.8.2.3 5.8.3.1 5.8.3.2 5.8.3.1 5.8.3.2 5.8.3.3 5.8.3.4 5.8.3.5 5.8.3.6	5.6.2.1       HTTPMessage         5.6.2.2       HTTPMessage         5.6.3.1       Decode         5.6.3.2       Dump         5.6.3.3       Encode         5.6.3.4       GetKey         5.6.4.1       OriginalString         5.6.4.2       IWS         Message Class Reference       Ference         5.7.1       Detailed Description         5.7.2.1       Message         5.7.2.1       Message         5.7.2.1       Message         5.7.2.3       Message         5.7.2.4       ~Message         5.7.3.1       Dump         5.7.3.2       GetKey         5.7.3.3       GetString         5.7.3.4       IsFromWeb         5.7.4.1       IString         Messerger Class Reference         5.8.1       Detailed Description         5.8.2       Messenger         5.8.2.1       Messenger         5.8.2.2       Messenger         5.8.3.3       AddClient         5.8.3.3       Connect         5.8.3.3       Disconnect         5.8.3.5       DisconnectClient         5.8.3.5       DisconnectClient

CONTENTS vii

		5.8.3.8	Receive	39
		5.8.3.9	Send	39
		5.8.3.10	StartAcquisition	40
		5.8.3.11	StopAcquisition	40
		5.8.3.12	SwitchClientType	41
	5.8.4	Field Doo	cumentation	41
		5.8.4.1	fNumAttempts	41
		5.8.4.2	fWS	41
5.9	Socket	Class Ref	ference	41
	5.9.1	Detailed	Description	43
	5.9.2	Member	Typedef Documentation	43
		5.9.2.1	SocketCollection	43
	5.9.3	Construc	tor & Destructor Documentation	43
		5.9.3.1	Socket	43
		5.9.3.2	Socket	43
		5.9.3.3	~Socket	43
	5.9.4	Member	Function Documentation	43
		5.9.4.1	AcceptConnections	43
		5.9.4.2	Bind	44
		5.9.4.3	Configure	44
		5.9.4.4	Create	44
		5.9.4.5	DumpConnected	44
		5.9.4.6	FetchMessage	44
		5.9.4.7	GetPort	45
		5.9.4.8	GetSocketId	45
		5.9.4.9	GetSocketType	45
		5.9.4.10	IsWebSocket	45
		5.9.4.11	Listen	45
		5.9.4.12	PrepareConnection	45
		5.9.4.13	SelectConnections	46
		5.9.4.14	SendMessage	46
		5.9.4.15	SetPort	46
		5.9.4.16	SetSocketId	46
		5.9.4.17	Start	46
		5.9.4.18	Stop	46
	5.9.5	Field Doo	cumentation	47
		5.9.5.1	fAddress	47
		5.9.5.2	fBuffer	47
		5.9.5.3	fMaster	47
		5.9.5.4	fPort	47

viii CONTENTS

		5.9.5.5 fReadFds	17
		5.9.5.6 fSocketId	17
		5.9.5.7 fSocketsConnected	17
5.10	Socket	Message Class Reference	17
	5.10.1	Detailed Description	19
	5.10.2	Constructor & Destructor Documentation	19
		5.10.2.1 SocketMessage	19
		5.10.2.2 SocketMessage	19
		5.10.2.3 SocketMessage	50
		5.10.2.4 SocketMessage	50
		5.10.2.5 SocketMessage	50
		5.10.2.6 SocketMessage	50
		5.10.2.7 SocketMessage	51
		5.10.2.8 SocketMessage	51
		5.10.2.9 SocketMessage	51
			51
		5.10.2.11 SocketMessage	52
		<u> </u>	52
	5.10.3		52
		·	52
			52
			52
		•	52
			52
			52
		•	53
		•	53
			53
			53
			54
		· · · · · · · · · · · · · · · · · · ·	54
	5.10.4		54
			54
5.11			54
		•	55
	5.11.2		55
			55
			56
	5.11.3		6
		5.11.3.1 CheckFirmwareVersion	56

CONTENTS

	5.11.3.2	FetchEvents	56
	5.11.3.3	GetSetupRegister	56
	5.11.3.4	ReadConfiguration	56
	5.11.3.5	ReadRegister	56
	5.11.3.6	ReadStatus	57
	5.11.3.7	SendConfiguration	57
	5.11.3.8	SetSetupRegister	57
	5.11.3.9	SoftReset	57
	5.11.3.10	WriteRegister	57
5.11.4	Field Doo	cumentation	58
	5.11.4.1	fBS	58
	5.11.4.2	fControl	58
	5.11.4.3	fld	58
	5.11.4.4	fSetup	58
	5.11.4.5	fStatus	58
	5.11.4.6	fUSB	58
5.12 TDCB	oundarySc	an Class Reference	58
5.12.1	Detailed	Description	59
5.12.2	Construc	tor & Destructor Documentation	60
	5.12.2.1	TDCBoundaryScan	60
	5.12.2.2	TDCBoundaryScan	60
5.12.3	Member	Function Documentation	60
	5.12.3.1	SetConstantValues	60
5.12.4	Field Doo	cumentation	60
	5.12.4.1	kAuxClock	60
	5.12.4.2	kBunchReset	60
	5.12.4.3	kClk	60
	5.12.4.4	kDataReady	60
	5.12.4.5	kEncodedControl	60
	5.12.4.6	kError	60
	5.12.4.7	kEventReset	61
	5.12.4.8	kGetData	61
	5.12.4.9	kHit	61
	5.12.4.10	kParallelDataOut	61
	5.12.4.11	kParallelEnable	61
	5.12.4.12	2 kReset	61
	5.12.4.13	B kSerialBypassIn	61
	5.12.4.14	4 kSerialIn	61
	5.12.4.15	5 kSerialOut	61
	5.12.4.16	S kStrobeOut	61

CONTENTS

	5.12.4.17 kTest	61
	5.12.4.18 kTokenBypassIn	61
	5.12.4.19 kTokenIn	61
	5.12.4.20 kTokenOut	61
	5.12.4.21 kTrigger	61
5.13 TDCC	ontrol Class Reference	61
5.13.1	Detailed Description	63
5.13.2	Constructor & Destructor Documentation	63
	5.13.2.1 TDCControl	63
	5.13.2.2 TDCControl	63
5.13.3	Member Function Documentation	63
	5.13.3.1 DisableAllChannels	63
	5.13.3.2 DisableChannel	64
	5.13.3.3 Dump	64
	5.13.3.4 EnableAllChannels	64
	5.13.3.5 EnableChannel	64
	5.13.3.6 GetDLLReset	65
	5.13.3.7 GetEnablePattern	65
	5.13.3.8 GetGlobalReset	65
	5.13.3.9 GetPLLReset	66
	5.13.3.10 SetConstantValues	66
	5.13.3.11 SetControlParity	66
	5.13.3.12 SetDLLReset	66
	5.13.3.13 SetEnablePattern	67
	5.13.3.14 SetGlobalReset	67
	5.13.3.15 SetPLLReset	67
5.13.4	Field Documentation	67
	5.13.4.1 kControlParity	67
	5.13.4.2 kDLLReset	67
	5.13.4.3 kEnableChannel	67
	5.13.4.4 kEnablePattern	67
	5.13.4.5 kGlobalReset	67
	5.13.4.6 kPLLReset	68
5.14 TDCE	vent Class Reference	68
5.14.1	Detailed Description	69
5.14.2	Constructor & Destructor Documentation	69
	5.14.2.1 TDCEvent	69
	5.14.2.2 TDCEvent	69
	5.14.2.3 ~TDCEvent	69
5.14.3	Member Function Documentation	69

CONTENTS xi

		5.14.3.1	GetBunchld	69
		5.14.3.2	GetErrorFlags	69
		5.14.3.3	GetEventId	70
		5.14.3.4	GetLeadingTime	70
		5.14.3.5	GetTDCld	70
		5.14.3.6	GetTrailingTime	70
		5.14.3.7	GetType	71
		5.14.3.8	GetWidth	71
		5.14.3.9	GetWordCount	71
		5.14.3.10	SetWord	71
!	5.14.4	Field Doo	eumentation	71
		5.14.4.1	fWord	71
5.15	TDCRe	gister Cla	ss Reference	71
!	5.15.1	Detailed I	Description	73
!	5.15.2	Member <sup>-</sup>	Typedef Documentation	73
		5.15.2.1	bit	73
		5.15.2.2	$word\_t \ \ldots \ldots \ldots \ldots \ldots \ldots \ldots$	73
!	5.15.3	Construct	tor & Destructor Documentation	73
		5.15.3.1	TDCRegister	73
		5.15.3.2	TDCRegister	73
		5.15.3.3	~TDCRegister	74
!	5.15.4	Member I	Function Documentation	74
		5.15.4.1	Clear	74
		5.15.4.2	DumpRegister	74
		5.15.4.3	GetBits	74
		5.15.4.4	GetNumWords	74
		5.15.4.5	GetWord	74
		5.15.4.6	operator=	74
		5.15.4.7	SetBits	74
		5.15.4.8	SetConstantValues	74
		5.15.4.9	SetWord	74
!	5.15.5	Field Doo	eumentation	75
		5.15.5.1	fNumWords	75
		5.15.5.2	fWord	75
		5.15.5.3	fWordSize	75
5.16	TDCSe	tup Class	Reference	75
!	5.16.1	Detailed I	Description	82
!	5.16.2	Construct	tor & Destructor Documentation	82
		5.16.2.1	TDCSetup	83
		5.16.2.2	TDCSetup	84

xii CONTENTS

5.16.3	Member F	Function Documentation	. 84
	5.16.3.1	Dump	. 85
	5.16.3.2	GetChannelOffset	. 85
	5.16.3.3	GetCoarseCountOffset	. 85
	5.16.3.4	GetDeadTime	. 86
	5.16.3.5	GetDLLAdjustment	. 86
	5.16.3.6	GetEdgeResolution	. 87
	5.16.3.7	GetEdgesPairing	. 87
	5.16.3.8	GetEnableError	. 87
	5.16.3.9	GetEnableErrorBypass	. 88
	5.16.3.10	GetEnableErrorMark	. 88
	5.16.3.11	GetEnableJTAGReadout	. 88
	5.16.3.12	GetEnableReadoutOccupancy	. 89
	5.16.3.13	GetEnableReadoutSeparator	. 89
	5.16.3.14	GetEnableSerial	. 89
	5.16.3.15	GetLeadingMode	. 89
	5.16.3.16	GetMatchWindow	. 90
	5.16.3.17	GetMaxEventSize	. 90
	5.16.3.18	GetRCAdjustment	. 90
	5.16.3.19	GetReadoutFIFOSize	. 91
	5.16.3.20	GetRejectCountOffset	. 91
	5.16.3.21	GetRejectFIFOFull	. 91
	5.16.3.22	? GetSearchWindow	. 92
	5.16.3.23	GetSetupParity	. 92
	5.16.3.24	GetTestInvert	. 93
	5.16.3.25	GetTestMode	. 93
	5.16.3.26	GetTrailingMode	. 93
	5.16.3.27	GetTriggerCountOffset	. 93
	5.16.3.28	GetTriggerLatency	. 94
	5.16.3.29	GetTriggerMatchingMode	. 94
	5.16.3.30	GetVernierOffset	. 94
	5.16.3.31	GetWidthResolution	. 95
	5.16.3.32	SetAllChannelsOffset	. 95
	5.16.3.33	SetAllTapsDLLAdjustment	. 95
	5.16.3.34	SetBypassInputs	. 96
	5.16.3.35	SetChannelOffset	. 96
	5.16.3.36	SetCoarseCountOffset	. 96
	5.16.3.37	SetConstantValues	. 96
	5.16.3.38	SetCoreClockDelay	. 97
	5.16.3.39	SetCoreClockSource	. 98

CONTENTS xiii

5.16.3.40 SetDeadTime
5.16.3.41 SetDLLAdjustment
5.16.3.42 SetDLLClockDelay
5.16.3.43 SetDLLClockSource
5.16.3.44 SetDLLControl
5.16.3.45 SetDLLMode
5.16.3.46 SetEdgeResolution
5.16.3.47 SetEdgesPairing
5.16.3.48 SetEnableAutomaticReject
5.16.3.49 SetEnableBytewise
5.16.3.50 SetEnableDirectBunchReset
5.16.3.51 SetEnableDirectEventReset
5.16.3.52 SetEnableDirectTrigger
5.16.3.53 SetEnableError
5.16.3.54 SetEnableErrorBypass
5.16.3.55 SetEnableErrorMark
5.16.3.56 SetEnableGlobalHeader
5.16.3.57 SetEnableGlobalTrailer
5.16.3.58 SetEnableJTAGReadout
5.16.3.59 SetEnableLocalHeader
5.16.3.60 SetEnableLocalTrailer
5.16.3.61 SetEnableMasterResetCode
5.16.3.62 SetEnableMasterResetOnEventReset
5.16.3.63 SetEnableOverflowDetect
5.16.3.64 SetEnableReadoutOccupancy
5.16.3.65 SetEnableReadoutSeparator
5.16.3.66 SetEnableRelative
5.16.3.67 SetEnableResetChannelBufferWhenSeparator
5.16.3.68 SetEnableSeparatorOnBunchReset
5.16.3.69 SetEnableSeparatorOnEventReset
5.16.3.70 SetEnableSerial
5.16.3.71 SetEnableSetCountersOnBunchReset
5.16.3.72 SetEnableTTLClock
5.16.3.73 SetEnableTTLControl
5.16.3.74 SetEnableTTLHit
5.16.3.75 SetEnableTTLReset
5.16.3.76 SetEnableTTLSerial
5.16.3.77 SetEventCountOffset
5.16.3.78 SetIOClockDelay
5.16.3.79 SetIOClockSource

xiv CONTENTS

	5.16.3.80	SetKeepToken			 	 	 	 	 	 	•	112
	5.16.3.81	SetLeadingMod	e		 	 	 	 	 	 		112
	5.16.3.82	SetLowPowerMo	ode		 	 	 	 	 	 		112
	5.16.3.83	SetMaster			 	 	 	 	 	 		113
	5.16.3.84	SetMatchWindo	w		 	 	 	 	 	 		113
	5.16.3.85	SetMaxEventSiz	e		 	 	 	 	 	 		113
	5.16.3.86	SetModeRC .			 	 	 	 	 	 		114
	5.16.3.87	SetModeRCCor	npression	١	 	 	 	 	 	 		114
	5.16.3.88	SetPLLControl			 	 	 	 	 	 		114
	5.16.3.89	SetRCAdjustme	nt		 	 	 	 	 	 		115
	5.16.3.90	SetReadoutFIF(	OSize .		 	 	 	 	 	 		115
	5.16.3.91	SetReadoutSing	leCycleS	Speed	 	 	 	 	 	 		115
	5.16.3.92	SetReadoutSpe	edSelect		 	 	 	 	 	 		116
	5.16.3.93	SetRejectCount	Offset .		 	 	 	 	 	 		116
	5.16.3.94	SetRejectFIFOF	ull		 	 	 	 	 	 		117
	5.16.3.95	SetRollOver .			 	 	 	 	 	 		117
	5.16.3.96	SetSearchWindo	ow		 	 	 	 	 	 		117
	5.16.3.97	SetSerialClockD	elay		 	 	 	 	 	 		117
	5.16.3.98	SetSerialClockS	ource .		 	 	 	 	 	 		118
	5.16.3.99	SetSerialDelay			 	 	 	 	 	 		118
	5.16.3.100	SetSetupParity			 	 	 	 	 	 		118
	5.16.3.10	SetStrobeSelect			 	 	 	 	 	 		119
	5.16.3.102	SetTestInvert .			 	 	 	 	 	 		119
	5.16.3.103	SetTestMode .			 	 	 	 	 	 		119
	5.16.3.104	SetTokenDelay			 	 	 	 	 	 		120
	5.16.3.105	SetTrailingMode			 	 	 	 	 	 		120
	5.16.3.106	SetTriggerCount	Offset .		 	 	 	 	 	 		120
	5.16.3.107	SetTriggerMatch	ingMode		 	 	 	 	 	 		121
	5.16.3.108	SetVernierOffse	t		 	 	 	 	 	 		121
	5.16.3.109	SetWidthResolu	tion		 	 	 	 	 	 		121
5.16.4	Field Doc	umentation			 	 	 	 	 	 		122
	5.16.4.1	kCoarseCountO	ffset		 	 	 	 	 	 		122
	5.16.4.2	kCoreClockDela	y		 	 	 	 	 	 		122
	5.16.4.3	kCoreClockSou	ce		 	 	 	 	 	 		122
	5.16.4.4	kDeadTime			 	 	 	 	 	 		122
	5.16.4.5	kDLLClockDelay	<i>'</i>		 	 	 	 	 	 		122
	5.16.4.6	kDLLClockSour	е		 	 	 	 	 	 		122
	5.16.4.7	kDLLControl .			 	 	 	 	 	 		122
	5.16.4.8	kDLLMode			 	 	 	 	 	 		122
	5.16.4.9	kDLLTapAdjust0			 	 	 	 	 	 		122

CONTENTS xv

5.16.4.10 kEnableAutomaticReject
5.16.4.11 kEnableBytewise
5.16.4.12 kEnableDirectBunchReset
5.16.4.13 kEnableDirectEventReset
5.16.4.14 kEnableDirectTrigger
5.16.4.15 kEnableError
5.16.4.16 kEnableErrorBypass
5.16.4.17 kEnableErrorMark
5.16.4.18 kEnableGlobalHeader
5.16.4.19 kEnableGlobalTrailer
5.16.4.20 kEnableJTAGReadout
5.16.4.21 kEnableLocalHeader
5.16.4.22 kEnableLocalTrailer
5.16.4.23 kEnableMasterResetCode
5.16.4.24 kEnableMasterResetOnEventReset
5.16.4.25 kEnableMatching
5.16.4.26 kEnableOverflowDetect
5.16.4.27 kEnablePair
5.16.4.28 kEnableReadoutOccupancy
5.16.4.29 kEnableReadoutSeparator
5.16.4.30 kEnableRelative
5.16.4.31 kEnableResetChannelBufferWhenSeparator
5.16.4.32 kEnableSeparatorOnBunchReset
5.16.4.33 kEnableSeparatorOnEventReset
5.16.4.34 kEnableSerial
5.16.4.35 kEnableSetCountersOnBunchReset
5.16.4.36 kEnableTTLClock
5.16.4.37 kEnableTTLControl
5.16.4.38 kEnableTTLHit
5.16.4.39 kEnableTTLReset
5.16.4.40 kEnableTTLSerial
5.16.4.41 kEventCountOffset
5.16.4.42 kIOClockDelay
5.16.4.43 kIOClockSource
5.16.4.44 kKeepToken
5.16.4.45 kLeading
5.16.4.46 kLeadingResolution
5.16.4.47 kLowPowerMode
5.16.4.48 kMaster
5.16.4.49 kMatchWindow

xvi CONTENTS

		5.16.4.50 kMaxEventSize	24
		5.16.4.51 kModeRC	24
		5.16.4.52 kModeRCCompression	24
		5.16.4.53 kOffset0	24
		5.16.4.54 kPLLControl	24
		5.16.4.55 kRCAdjust0	24
		5.16.4.56 kReadoutFIFOSize	24
		5.16.4.57 kReadoutSingleCycleSpeed	24
		5.16.4.58 kReadoutSpeedSelect	24
		5.16.4.59 kRejectCountOffset	24
		5.16.4.60 kRejectFIFOFull	24
		5.16.4.61 kRollOver	24
		5.16.4.62 kSearchWindow	24
		5.16.4.63 kSelectBypassInputs	24
		5.16.4.64 kSerialClockDelay	24
		5.16.4.65 kSerialClockSource	24
		5.16.4.66 kSerialDelay	24
		5.16.4.67 kSetupParity	24
		5.16.4.68 kStrobeSelect	24
		5.16.4.69 kTDCld	24
		5.16.4.70 kTestInvert	
		5.16.4.71 kTestMode	
		5.16.4.72 kTestSelect	24
		5.16.4.73 kTokenDelay	24
		5.16.4.74 kTrailing	24
		5.16.4.75 kTriggerCountOffset	24
		5.16.4.76 kVernierOffset	24
		5.16.4.77 kWidthSelect	25
5.17 T	DCSta	atus Class Reference	25
5	5.17.1	Detailed Description	26
5	5.17.2	Constructor & Destructor Documentation	26
		5.17.2.1 TDCStatus	26
		5.17.2.2 TDCStatus	26
5	5.17.3	Member Function Documentation	26
		5.17.3.1 SetConstantValues	27
5	5.17.4	Field Documentation	27
		5.17.4.1 kDLLLock	27
		5.17.4.2 kError	27
		5.17.4.3 kHaveToken	27
		5.17.4.4 kL1Occupancy	27

CONTENTS xvii

	5.17.4.5	kReadoutFIFOEmpty	12	27
	5.17.4.6	kReadoutFIFOFull	12	27
	5.17.4.7	kReadoutFIFOOccupancy	12	27
	5.17.4.8	kTriggerFIFOEmpty	12	27
	5.17.4.9	kTriggerFIFOFull	12	27
	5.17.4.10	kTriggerFIFOOccupancy	12	27
5.18 USBH	andler Clas	ss Reference	12	27
5.18.1	Detailed	Description	12	28
5.18.2	Construc	tor & Destructor Documentation	12	28
	5.18.2.1	USBHandler	12	28
	5.18.2.2	USBHandler	12	28
	5.18.2.3	~USBHandler	12	28
5.18.3	Member	Function Documentation	12	28
	5.18.3.1	DumpDevice	12	28
	5.18.3.2	Fetch	12	28
	5.18.3.3	Init	12	29
	5.18.3.4	Reset	12	29
	5.18.3.5	Write	12	29
5.18.4	Field Doo	cumentation	12	29
	5.18.4.1	fDevice	12	29
		fHandle		
		flsStopping		
		fProductId		
	5.18.4.5	fVendorld	12	29
Index			13	31

# Chapter 1

# **Module Index**

_	_	_		_	
4	4		١л	ᆔ	 PS
		- 1	VIC	11	 76

Here	ic a	liet o	ıfallı	madu	اموا

FPGA board control	7
Socket communication objects	8
HPTDC chip control	9

2 **Module Index** 

# **Chapter 2**

# **Hierarchical Index**

# 2.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

Exception	20
le_header_t	23
ileReader	23
Message	32
HTTPMessage	. 29
SocketMessage	47
Socket	41
Client	15
FPGAHandler	25
Messenger	34
DC	54
DCEvent	68
DCRegister	71
TDCBoundaryScan	. 58
TDCControl	61
TDCSetup	. 75
TDCStatus	. 125
JSBHandler	127
EPGAHandler	25

**Hierarchical Index** 

# **Chapter 3**

# **Data Structure Index**

# 3.1 Data Structures

Here are the data structures with brief descriptions:

Client	
Base client object for the socket	15
Exception	
A simple exception handler	20
file_header_t	
Header to the output files	23
FileReader	23
FPGAHandler	
· · · · · · · · · · · · · · · · · · ·	25
HTTPMessage	
Message to be transmitted through a WebSocket protocol	26
Message	
	32
Messenger	
Base master object for the socket	34
Socket	
Base socket object from which clients/master from a socket inherit	Į1
SocketMessage	
1 5 71	17
TDC	
,	54
	58
TDCControl	
Control word to be sent to the HPTDC chip	31
TDCEvent	
HPTDC event parser	jξ
TDCRegister	
General register object to interact with a HPTDC chip	′
TDCSetup	,,
Setup word to be sent to the HPTDC chip	
TDCStatus	۲:
USBHandler Canaria USB communication handler	٠-
Generic USB communication handler	1

6 **Data Structure Index** 

# **Chapter 4**

# **Module Documentation**

# 4.1 FPGA board control

## **Data Structures**

• class FPGAHandler

Driver for timing detectors' FPGA readout.

• class USBHandler

Generic USB communication handler.

## 4.1.1 Detailed Description

8 Module Documentation

# 4.2 Socket communication objects

#### **Data Structures**

· class Client

Base client object for the socket.

class HTTPMessage

Message to be transmitted through a WebSocket protocol.

class Messenger

Base master object for the socket.

class Socket

Base socket object from which clients/master from a socket inherit.

class SocketMessage

Socket-passed message type.

#### **Enumerations**

enum Socket::SocketType {
 Socket::INVALID =-1, Socket::MASTER =0, Socket::WEBSOCKET\_CLIENT, Socket::DETECTOR }

Type of actor playing a role on the socket.

- 4.2.1 Detailed Description
- 4.2.2 Enumeration Type Documentation
- 4.2.2.1 enum Socket::SocketType

Type of actor playing a role on the socket.

#### Enumerator

INVALID
MASTER
WEBSOCKET\_CLIENT
CLIENT
DETECTOR

### 4.3 HPTDC chip control

#### **Data Structures**

· class TDC

HPTDC object.

- · class TDCBoundaryScan
- class TDCControl

Control word to be sent to the HPTDC chip.

class TDCEvent

HPTDC event parser.

class TDCRegister

General register object to interact with a HPTDC chip.

class TDCSetup

Setup word to be sent to the HPTDC chip.

· class TDCStatus

#### **Enumerations**

- enum TDCControl::EnablePattern
- enum TDCControl::RegisterName { TDCControl::R\_EnablePattern, TDCControl::R\_GlobalReset, TDC
   — Control::R DLLReset, TDCControl::R PLLReset }
- enum TDCEvent::EventType {

TDCEvent::Invalid =-1, TDCEvent::GroupHeader =0, TDCEvent::GroupTrailer, TDCEvent::TDCHeader,

 $TDCE vent:: TDCT railer, \ TDCE vent:: Leading Edge, \ TDCE vent:: Trailing Edge, \ TDCE vent:: Error,$ 

TDCEvent::Debug }

enum TDCSetup::EdgeResolution {

TDCSetup::E\_100ps =0, TDCSetup::E\_200ps, TDCSetup::E\_400ps, TDCSetup::E\_800ps,

TDCSetup::E\_1p6ns, TDCSetup::E\_3p12ns, TDCSetup::E\_6p25ns, TDCSetup::E\_12p5ns }

- enum TDCSetup::DeadTime { TDCSetup::DT\_5ns =0, TDCSetup::DT\_10ns, TDCSetup::DT\_30ns, TDC
   Setup::DT\_100ns }
- enum TDCSetup::WidthResolution {

TDCSetup::W\_100ps =0, TDCSetup::W\_200ps, TDCSetup::W\_400ps, TDCSetup::W\_800ps,

TDCSetup::W\_1p6ns, TDCSetup::W\_3p2ns, TDCSetup::W\_6p25ns, TDCSetup::W\_12p5ns,

TDCSetup::W 25ns, TDCSetup::W 50ns, TDCSetup::W 100ns, TDCSetup::W 200ns,

TDCSetup::W\_400ns, TDCSetup::W\_800ns }

enum TDCSetup::EnabledError {

TDCSetup::VernierError =0x1, TDCSetup::CoarseError =0x2, TDCSetup::ChannelSelectError =0x4, TDC ← Setup::L1BufferParityError =0x8,

TDCSetup::TriggerFIFOParityError =0x10, TDCSetup::TriggerMatchingError =0x20, TDCSetup::ReadoutF↔ IFOParityError =0x40, TDCSetup::ReadoutStateError =0x80,

TDCSetup::SetupParityError =0x100, TDCSetup::ControlParityError =0x200, TDCSetup::JTAGInstruction← ParityError =0x400 }

- enum TDCSetup::SerialClockSource { TDCSetup::Serial\_pll\_clock\_80 =0x0, TDCSetup::Serial\_pll\_clock\_
   —
   160 =0x1, TDCSetup::Serial\_pll\_clock\_40 =0x2, TDCSetup::Serial\_aux\_clock =0x3 }
- enum TDCSetup::IOClockSource { TDCSetup::IO\_clock\_40 =0x0, TDCSetup::IO\_pll\_clock\_80 =0x1, TDC
   Setup::IO\_pll\_clock\_160 =0x2, TDCSetup::IO\_aux\_clock =0x3 }
- enum TDCSetup::CoreClockSource { TDCSetup::Core\_clock\_40 =0x0, TDCSetup::Core\_pll\_clock\_80 =0x1, TDCSetup::Core\_pll\_clock\_160 =0x2, TDCSetup::Core\_aux\_clock =0x3 }
- enum TDCSetup::DLLClockSource {

TDCSetup::DLL\_clock\_40 =0x0, TDCSetup::DLL\_pll\_clock\_40 =0x1, TDCSetup::DLL\_pll\_clock\_160 =0x2, TDCSetup::DLL pll clock 320 =0x3,

TDCSetup::DLL\_aux\_clock =0x4 }

10 Module Documentation

```
    enum TDCSetup::ReadoutSpeed { TDCSetup::RO_Fixed =0x0, TDCSetup::RO_pll_80Mbits_s =0x1 }

    • enum TDCSetup::SerialStrobeType { TDCSetup::SS_NoStrobe =0x0, TDCSetup::SS_DSStrobe =0x1, TD←
      CSetup::SS_LeadingTrailingStrobe =0x2, TDCSetup::SS_LeadingEdge =0x3 }

    enum TDCSetup::ReadoutSingleCycleSpeed {

      TDCSetup::RSC_40Mbits_s =0x0, TDCSetup::RSC_20Mbits_s =0x1, TDCSetup::RSC_10Mbits_s =0x2, T \in \text{T}
      DCSetup::RSC 5Mbits s =0x3,
      TDCSetup::RSC_2p5Mbits_s =0x4, TDCSetup::RSC_1p25Mbits_s =0x5, TDCSetup::RSC_625kbits_s =0x6,
      TDCSetup::RSC_312p5kbits_s =0x7 }
4.3.1
       Detailed Description
      Enumeration Type Documentation
4.3.2
4.3.2.1 enum TDCSetup::CoreClockSource
Enumerator
     Core clock 40
     Core_pll_clock_80
     Core_pll_clock_160
     Core_aux_clock
4.3.2.2 enum TDCSetup::DeadTime
Enumerator
    DT_5ns
    DT_10ns
    DT_30ns
    DT_100ns
4.3.2.3 enum TDCSetup::DLLClockSource
Enumerator
    DLL_clock_40
    DLL_pll_clock_40
    DLL pll clock 160
    DLL_pll_clock_320
    DLL_aux_clock
4.3.2.4 enum TDCSetup::DLLSpeedMode
Enumerator
    DLL 40MHz
    DLL_160MHz
    DLL 320MHz
    DLL_Illegal
```

#### 4.3.2.5 enum TDCSetup::EdgeResolution

#### Enumerator

- E\_100ps
- E\_200ps
- E\_400ps
- E\_800ps
- E\_1p6ns
- E\_3p12ns
- E\_6p25ns
- E\_12p5ns

### 4.3.2.6 enum TDCSetup::EnabledError

#### Enumerator

**VernierError** 

CoarseError

ChannelSelectError

L1BufferParityError

**TriggerFIFOParityError** 

TriggerMatchingError

ReadoutFIFOParityError

ReadoutStateError

SetupParityError

ControlParityError

JTAGInstructionParityError

4.3.2.7 enum TDCControl::EnablePattern

4.3.2.8 enum TDCEvent::EventType

### **Enumerator**

Invalid

GroupHeader

GroupTrailer

**TDCHeader** 

**TDCTrailer** 

LeadingEdge

TrailingEdge

**Error** 

Debug

12 Module Documentation

#### 4.3.2.9 enum TDCSetup::IOClockSource

```
Enumerator
```

IO\_clock\_40

IO\_pll\_clock\_80

IO\_pll\_clock\_160

IO\_aux\_clock

#### 4.3.2.10 enum TDCSetup::ReadoutSingleCycleSpeed

#### Enumerator

RSC\_40Mbits\_s

RSC\_20Mbits\_s

RSC\_10Mbits\_s

RSC\_5Mbits\_s

RSC\_2p5Mbits\_s

RSC\_1p25Mbits\_s

RSC\_625kbits\_s

RSC\_312p5kbits\_s

### 4.3.2.11 enum TDCSetup::ReadoutSpeed

### **Enumerator**

RO\_Fixed

RO\_pll\_80Mbits\_s

#### 4.3.2.12 enum TDCControl::RegisterName

### Enumerator

R\_EnablePattern

R\_GlobalReset

R\_DLLReset

R\_PLLReset

### 4.3.2.13 enum TDCSetup::SerialClockSource

### Enumerator

Serial\_pll\_clock\_80

Serial\_pll\_clock\_160

Serial\_pll\_clock\_40

Serial\_aux\_clock

## 4.3.2.14 enum TDCSetup::SerialStrobeType

#### Enumerator

- SS\_NoStrobe
- SS\_DSStrobe
- $SS\_LeadingTrailingStrobe$
- SS\_LeadingEdge

## 4.3.2.15 enum TDCSetup::WidthResolution

#### Enumerator

- W\_100ps
- W\_200ps
- W\_400ps
- W\_800ps
- W\_1p6ns
- W\_3p2ns
- W\_6p25ns
- W\_12p5ns
- W\_25ns
- W\_50ns
- W\_100ns
- W\_200ns
- W\_400ns
- W\_800ns

14 **Module Documentation** 

# **Chapter 5**


# **Data Structure Documentation**

# 5.1 Client Class Reference


Base client object for the socket.

#include <Client.h>

Inheritance diagram for Client:



#### Collaboration diagram for Client:



#### **Public Member Functions**

· Client ()

General void client constructor.

· Client (int port)

Bind a socket client to a given port.

- virtual ∼Client ()
- bool Connect ()

Bind this client to the socket.

• void Disconnect ()

Unbind this client from the socket.

• void Send (const Message &m) const

Send a message to the master through the socket.

- SocketMessage SendAndReceive (const SocketMessage &m, const MessageKey &a) const
- void Receive ()

Receive a socket message from the master.

virtual void ParseMessage (const SocketMessage &m)

Parse a SocketMessage received from the master.

• virtual SocketType GetType () const

Socket actor type retrieval method.

#### **Private Member Functions**

• void Announce ()

Announce our entry on the socket to its master.

### **Private Attributes**

- int fClientId
- · bool flsConnected

5.1 Client Class Reference 17

#### **Additional Inherited Members**

### 5.1.1 Detailed Description

Base client object for the socket.

Client object used by the server to send/receive commands from the messenger/broadcaster.

**Author** 

Laurent Forthomme laurent.forthomme@cern.ch

Date

24 Mar 2015

#### 5.1.2 Constructor & Destructor Documentation

```
5.1.2.1 Client::Client() [inline]
```


General void client constructor.

5.1.2.2 Client::Client ( int port )

Bind a socket client to a given port.

5.1.2.3 Client::~Client() [virtual]

Here is the call graph for this function:




#### 5.1.3 Member Function Documentation

5.1.3.1 void Client::Announce( ) [private]

Announce our entry on the socket to its master.


Here is the call graph for this function:



#### 5.1.3.2 bool Client::Connect ( )

Bind this client to the socket.

Here is the call graph for this function:




### 5.1.3.3 void Client::Disconnect ( )

Unbind this client from the socket.

5.1 Client Class Reference 19

Here is the call graph for this function:



**5.1.3.4 virtual SocketType Client::GetType ( ) const** [inline], [virtual]

Socket actor type retrieval method.


Reimplemented in FPGAHandler.

5.1.3.5 virtual void Client::ParseMessage ( const SocketMessage & m ) [inline], [virtual]

Parse a SocketMessage received from the master.

5.1.3.6 void Client::Receive ( )

Receive a socket message from the master.



5.1.3.7 void Client::Send (const Message & m) const [inline]


Send a message to the master through the socket.

Here is the call graph for this function:



# 5.1.3.8 SocketMessage Client::SendAndReceive ( const SocketMessage & m, const MessageKey & a ) const [inline]

Here is the call graph for this function:



# 5.1.4 Field Documentation

- **5.1.4.1** int Client::fClientId [private]
- **5.1.4.2 bool Client::flsConnected** [private]

The documentation for this class was generated from the following files:

- · include/Client.h
- · src/Client.cpp

# 5.2 Exception Class Reference

A simple exception handler.

#include <Exception.h>

### **Public Member Functions**

Exception (const char \*from, std::string desc, ExceptionType type=Undefined, const int id=0)

- Exception (const char \*from, const char \*desc, ExceptionType type=Undefined, const int id=0)
- ∼Exception ()
- std::string From () const
- int ErrorNumber () const
- std::string Description () const
- ExceptionType Type () const
- std::string TypeString () const
- void Dump (std::ostream &os=std::cerr) const

### **Private Attributes**

- std::string fFrom
- std::string fDescription
- ExceptionType fType
- int fErrorNumber

# 5.2.1 Detailed Description

A simple exception handler.

**Author** 

Laurent Forthomme laurent.forthomme@cern.ch

Date

24 Mar 2015

#### 5.2.2 Constructor & Destructor Documentation


- **5.2.2.1** Exception::Exception (const char \* from, std::string desc, ExceptionType type = Undefined, const int id = 0) [inline]
- 5.2.2.2 Exception::Exception ( const char \* from, const char \* desc, ExceptionType type = Undefined, const int id = 0 ) [inline]
- **5.2.2.3 Exception::**~Exception() [inline]



### 5.2.3 Member Function Documentation

- 5.2.3.1 std::string Exception::Description ( ) const [inline]
- 5.2.3.2 void Exception::Dump ( std::ostream & os = std::cerr ) const [inline]

Here is the call graph for this function:



- **5.2.3.3** int Exception::ErrorNumber() const [inline]
- 5.2.3.4 std::string Exception::From ( ) const [inline]
- 5.2.3.5 ExceptionType Exception::Type ( ) const [inline]
- **5.2.3.6** std::string Exception::TypeString( ) const [inline]



- 5.2.4 Field Documentation
- **5.2.4.1 std::string Exception::fDescription** [private]
- **5.2.4.2** int Exception::fErrorNumber [private]
- **5.2.4.3 std::string Exception::fFrom** [private]

#### 5.2.4.4 ExceptionType Exception::fType [private]

The documentation for this class was generated from the following file:

· include/Exception.h

# 5.3 file\_header\_t Struct Reference

Header to the output files.

```
#include <FileConstants.h>
```

#### **Data Fields**

- uint32\_t magic
- · uint32\_t run\_id
- · uint32\_t spill\_id
- uint8\_t num\_hptdc

### 5.3.1 Detailed Description

Header to the output files.

General header to store in each collected data file for offline readout. It enable any reader to retrieve the run/spill number, as well as the HPTDC configuration during data collection.

**Author** 

```
Laurent Forthomme laurent.forthomme@cern.ch
```

Date

14 Apr 2015

# 5.3.2 Field Documentation

- 5.3.2.1 uint32\_t file\_header\_t::magic
- 5.3.2.2 uint8\_t file\_header\_t::num\_hptdc
- 5.3.2.3 uint32\_t file\_header\_t::run\_id
- 5.3.2.4 uint32\_t file\_header\_t::spill\_id


The documentation for this struct was generated from the following file:

• include/FileConstants.h

# 5.4 FileReader Class Reference

#include <FileReader.h>

# Collaboration diagram for FileReader:



### **Public Member Functions**

- FileReader (std::string name)
- ∼FileReader ()
- unsigned int GetNumTDCs () const
- TDCEvent GetNextEvent ()


# **Private Attributes**

- std::ifstream fFile
- file\_header\_t fHeader
- std::vector< TDCSetup > fSetupCollection

# 5.4.1 Constructor & Destructor Documentation

#### 5.4.1.1 FileReader::FileReader ( std::string name )

Here is the call graph for this function:



- 5.4.1.2 FileReader:: $\sim$ FileReader ( )
- 5.4.2 Member Function Documentation
- **5.4.2.1 TDCEvent FileReader::GetNextEvent ( )** [inline]
- **5.4.2.2 unsigned int FileReader::GetNumTDCs ( ) const** [inline]
- 5.4.3 Field Documentation
- **5.4.3.1** std::ifstream FileReader::fFile [private]
- 5.4.3.2 file\_header\_t FileReader::fHeader [private]
- **5.4.3.3 std::vector**<**TDCSetup**> **FileReader::fSetupCollection** [private]

The documentation for this class was generated from the following files:


- include/FileReader.h
- · src/FileReader.cpp

# 5.5 FPGAHandler Class Reference


Driver for timing detectors' FPGA readout.

#include <FPGAHandler.h>

Inheritance diagram for FPGAHandler:



### Collaboration diagram for FPGAHandler:



### **Public Member Functions**

- FPGAHandler (int port, const char \*dev)
  - Bind to a FPGA through the USB protocol, and to the socket.
- ∼FPGAHandler ()
- void Stop ()
- void OpenFile ()

Open an output file to store header/HPTDC events.

• void CloseFile ()

Close a previously opened output file used to store header/HPTDC events.

• std::string GetFilename () const

Retrieve the file name used to store data collected from the FPGA.

- TDC \* GetTDC (unsigned int i=0)
- void SetTDCSetup (const TDCSetup &s)

- bool ErrorState ()
- int ReadBuffer ()
- SocketType GetType () const

Socket actor type retrieval method.

# **Private Attributes**

- · std::string fFilename
- std::ofstream fOutput
- bool flsFileOpen
- TDC \* fTDC [NUM\_HPTDC]
- · bool flsTDCInReadout

#### **Additional Inherited Members**

# 5.5.1 Detailed Description

Driver for timing detectors' FPGA readout.

Main driver for a homebrew FPGA designed for the timing detectors' HPTDC chip readout.

**Author** 

Laurent Forthomme laurent.forthomme@cern.ch


Date

14 Apr 2015

### 5.5.2 Constructor & Destructor Documentation

5.5.2.1 FPGAHandler::FPGAHandler (int port, const char \* dev )

Bind to a FPGA through the USB protocol, and to the socket.



```
5.5.2.2 FPGAHandler::~FPGAHandler()
```

Here is the call graph for this function:



#### 5.5.3 Member Function Documentation

```
5.5.3.1 void FPGAHandler::CloseFile ( )
```

Close a previously opened output file used to store header/HPTDC events.

```
5.5.3.2 bool FPGAHandler::ErrorState ( )
```

5.5.3.3 std::string FPGAHandler::GetFilename() const [inline]

Retrieve the file name used to store data collected from the FPGA.

```
5.5.3.4 TDC* FPGAHandler::GetTDC ( unsigned int i = 0 ) [inline]
```

5.5.3.5 SocketType FPGAHandler::GetType() const [inline], [virtual]

Socket actor type retrieval method.

Reimplemented from Client.


```
5.5.3.6 void FPGAHandler::OpenFile ( )
```

Open an output file to store header/HPTDC events.



#### 5.5.3.7 int FPGAHandler::ReadBuffer ( )

Here is the call graph for this function:



#### 5.5.3.8 void FPGAHandler::SetTDCSetup (const TDCSetup & s) [inline]

Here is the call graph for this function:



- 5.5.3.9 void FPGAHandler::Stop() [inline]
- 5.5.4 Field Documentation
- **5.5.4.1** std::string FPGAHandler::fFilename [private]
- **5.5.4.2 bool FPGAHandler::flsFileOpen** [private]
- **5.5.4.3 bool FPGAHandler::flsTDClnReadout** [private]
- **5.5.4.4 std::ofstream FPGAHandler::fOutput** [private]
- **5.5.4.5 TDC\* FPGAHandler::fTDC[NUM\_HPTDC]** [private]

The documentation for this class was generated from the following files:


- include/FPGAHandler.h
- · src/FPGAHandler.cpp

# 5.6 HTTPMessage Class Reference


Message to be transmitted through a WebSocket protocol.

```
#include <HTTPMessage.h>
```

Inheritance diagram for HTTPMessage:



### Collaboration diagram for HTTPMessage:



### **Public Member Functions**

- HTTPMessage (WebSocket \*ws, Message m, MessageAction a)
- HTTPMessage (WebSocket \*ws, const char \*msg, MessageAction a)
- void Decode ()
- void Encode ()
- MessageKey GetKey () const
- void Dump (std::ostream &os=std::cout) const

#### **Private Attributes**

- WebSocket \* fWS
- · std::string fOriginalString

#### **Additional Inherited Members**

# 5.6.1 Detailed Description

Message to be transmitted through a WebSocket protocol.

Type of message compatible to the transmission through a WebSocket protocol. It enables a direct conversion of standards from any socket message format used elsewhere in this code using the *MessageAction* statement.

Author

Laurent Forthomme laurent.forthomme@cern.ch


Date

1 Apr 2015

### 5.6.2 Constructor & Destructor Documentation


5.6.2.1 HTTPMessage::HTTPMessage ( WebSocket \* ws, Message m, MessageAction a ) [inline]

Here is the call graph for this function:



5.6.2.2 HTTPMessage::HTTPMessage ( WebSocket \* ws, const char \* msg, MessageAction a ) [inline]

Here is the call graph for this function:



#### 5.6.3 Member Function Documentation

**5.6.3.1 void HTTPMessage::Decode( )** [inline]

5.6.3.2 void HTTPMessage::Dump ( std::ostream & os = std::cout ) const [inline]

5.6.3.3 void HTTPMessage::Encode( ) [inline]

- 5.6.3.4 MessageKey HTTPMessage::GetKey ( ) const [inline]
- 5.6.4 Field Documentation
- **5.6.4.1 std::string HTTPMessage::fOriginalString** [private]
- **5.6.4.2** WebSocket\* HTTPMessage::fWS [private]

The documentation for this class was generated from the following file:


• include/HTTPMessage.h

# 5.7 Message Class Reference

Base socket message type.

#include <Message.h>

Inheritance diagram for Message:



#### **Public Member Functions**

- Message ()
  - Void message constructor.
- Message (const char \*msg)
  - Construct a message from a string.
- Message (std::string msg)
  - Construct a message from a string.
- virtual ∼Message ()
- MessageKey GetKey () const

Placeholder for the MessageKey retrieval method.

• std::string GetString () const

Retrieve the string carried by this message as a whole.

• bool IsFromWeb () const

Extract from any message its potential arrival from a WebSocket protocol.

void Dump (std::ostream &os=std::cout) const

### **Protected Attributes**

· std::string fString

### 5.7.1 Detailed Description

Base socket message type.

Base handler for messages to be transmitted through the socket

**Author** 

Laurent Forthomme laurent.forthomme@cern.ch

Date

6 Apr 2015

### 5.7.2 Constructor & Destructor Documentation

```
5.7.2.1 Message::Message() [inline]
```

Void message constructor.

```
5.7.2.2 Message::Message (const char * msg ) [inline]
```

Construct a message from a string.

```
5.7.2.3 Message::Message ( std::string msg ) [inline]
```

Construct a message from a string.

```
5.7.2.4 virtual Message::~Message() [inline], [virtual]
```

### 5.7.3 Member Function Documentation

```
5.7.3.1 void Message::Dump ( std::ostream & os = std::cout ) const [inline]
```

```
5.7.3.2 MessageKey Message::GetKey ( ) const [inline]
```

Placeholder for the MessageKey retrieval method.

```
5.7.3.3 std::string Message::GetString ( ) const [inline]
```

Retrieve the string carried by this message as a whole.

```
5.7.3.4 bool Message::lsFromWeb() const [inline]
```

Extract from any message its potential arrival from a WebSocket protocol.

### 5.7.4 Field Documentation

```
5.7.4.1 std::string Message::fString [protected]
```

The documentation for this class was generated from the following file:


· include/Message.h

# 5.8 Messenger Class Reference


Base master object for the socket.

#include <Messenger.h>

Inheritance diagram for Messenger:



Collaboration diagram for Messenger:



# **Public Member Functions**

• Messenger ()

Build a void master object or socket actor.

• Messenger (int port)

Build a master object to control the socket.

- ∼Messenger ()
- bool Connect ()

Connect the master to the socket.

• void Disconnect ()

Remove the master and destroy the socket.

void Send (const Message &m, int sid) const

Send any type of message to any client.

· void Receive ()

Handle a message reception from a client.

· void Broadcast (const Message &m) const

Emit a message to all clients connected through the socket.

• void StartAcquisition ()

Start the data acquisition.

- void StopAcquisition ()
- SocketType GetType () const

Socket actor type retrieval method.

#### **Private Member Functions**

• void AddClient ()

Add a client to listen to.

void DisconnectClient (int sid, MessageKey key, bool force=false)

Disconnect a client.

- void SwitchClientType (int sid, Socket::SocketType type)
- void ProcessMessage (SocketMessage m, int sid)

Process a message received from the socket.

#### **Private Attributes**

- WebSocket \* fWS
- · int fNumAttempts

#### **Additional Inherited Members**

# 5.8.1 Detailed Description

Base master object for the socket.

Messenger/broadcaster object used by the server to send/receive commands from the clients/listeners.

**Author** 

Laurent Forthomme laurent.forthomme@cern.ch

Date

23 Mar 2015

### 5.8.2 Constructor & Destructor Documentation

5.8.2.1 Messenger::Messenger()

Build a void master object or socket actor.

5.8.2.2 Messenger::Messenger ( int port )


Build a master object to control the socket.

Here is the call graph for this function:



# 5.8.2.3 Messenger:: $\sim$ Messenger ( )

Here is the call graph for this function:




### 5.8.3 Member Function Documentation

# 5.8.3.1 void Messenger::AddClient( ) [private]

Add a client to listen to.

Add one client to the list of socket actors to monitor for message retrieval/submission.




#### 5.8.3.2 void Messenger::Broadcast ( const Message & m ) const

Emit a message to all clients connected through the socket.

#### **Parameters**

in	т	Message to transmit
----	---	---------------------

Here is the call graph for this function:




# 5.8.3.3 bool Messenger::Connect ( )

Connect the master to the socket.

Connect this master to the socket for clients to be able to bind.

Here is the call graph for this function:




#### 5.8.3.4 void Messenger::Disconnect ( )

Remove the master and destroy the socket.

Remove this master from the socket, thus disconnecting automatically the clients connected.

Here is the call graph for this function:



5.8.3.5 void Messenger::DisconnectClient ( int sid, MessageKey key, bool force = false ) [private]


Disconnect a client.

Ask to a client to disconnect from this socket.

#### **Parameters**

	in	sid	Unique identifier of the client to disconnect
	in	key	Key to the message to transmit for disconnection
Ì	in	force	Do we need to force the client out of this socket ?

Here is the call graph for this function:



5.8.3.6 SocketType Messenger::GetType ( ) const [inline]

Socket actor type retrieval method.


**5.8.3.7 void Messenger::ProcessMessage ( SocketMessage m, int sid )** [private]

Process a message received from the socket.

**Parameters** 

in	Unique	identifier of the client sending the message


Here is the call graph for this function:



# 5.8.3.8 void Messenger::Receive ( )

Handle a message reception from a client.

Here is the call graph for this function:




5.8.3.9 void Messenger::Send ( const Message & m, int sid ) const [inline]

Send any type of message to any client.

#### **Parameters**

in	m	Message to transmit
in	sid	Unique identifier of the client on this socket


Here is the call graph for this function:



# 5.8.3.10 void Messenger::StartAcquisition ( )

Start the data acquisition.

Here is the call graph for this function:




# 5.8.3.11 void Messenger::StopAcquisition ( )

5.9 Socket Class Reference 41

5.8.3.12 void Messenger::SwitchClientType ( int sid, Socket::SocketType type ) [private]

Here is the call graph for this function:



#### 5.8.4 Field Documentation

**5.8.4.1** int Messenger::fNumAttempts [private]

**5.8.4.2** WebSocket\* Messenger::fWS [private]

The documentation for this class was generated from the following files:


- · include/Messenger.h
- · src/Messenger.cpp

# 5.9 Socket Class Reference

Base socket object from which clients/master from a socket inherit.

#include <Socket.h>

Inheritance diagram for Socket:



# **Public Types**

```
    enum SocketType {
        INVALID =-1, MASTER =0, WEBSOCKET_CLIENT, CLIENT,
        DETECTOR }
```

Type of actor playing a role on the socket.

typedef std::set< std::pair< int, SocketType > > SocketCollection

#### **Public Member Functions**

- Socket ()
- · Socket (int port)
- virtual ∼Socket ()
- void Stop ()

Terminates the socket and all attached communications.

- void SetPort (int port)
- · int GetPort () const

Retrieve the port used for this socket.

void AcceptConnections (Socket &socket)

Accept connection from a client.

- void SelectConnections ()
- void SetSocketId (int sid)
- int GetSocketId () const
- SocketType GetSocketType (int sid) const
- · bool IsWebSocket (int sid) const
- void DumpConnected () const

#### **Protected Member Functions**

· bool Start ()

Start the socket.

• void Bind ()

Bind a name to a socket.

- void PrepareConnection ()
- void Listen (int maxconn)

Listen to incoming messages.

• void SendMessage (Message message, int id=-1) const

Send a message on a socket.

• Message FetchMessage (int id=-1) const

Receive a message from a socket.

### **Protected Attributes**

- int fPort
- char fBuffer [MAX\_WORD\_LENGTH]
- · SocketCollection fSocketsConnected
- · fd set fMaster

Master file descriptor list.

• fd\_set fReadFds

Temp file descriptor list for select()

5.9 Socket Class Reference 43

### **Private Member Functions**

• void Create ()

Create an endpoint for communication.

• void Configure ()

Configure the socket object for communication.

#### **Private Attributes**

- · int fSocketId
- · struct sockaddr\_in fAddress

#### 5.9.1 Detailed Description

Base socket object from which clients/master from a socket inherit.

General object providing all useful method to connect/bind/send/receive information through system sockets.

**Author** 

Laurent Forthomme laurent.forthomme@cern.ch

Date

23 Mar 2015

### 5.9.2 Member Typedef Documentation

5.9.2.1 typedef std::set< std::pair<int,SocketType> > Socket::SocketCollection

# 5.9.3 Constructor & Destructor Documentation

```
\textbf{5.9.3.1} \quad \textbf{Socket::Socket()} \quad [\texttt{inline}]
```

5.9.3.2 Socket::Socket (int port)

**5.9.3.3 Socket::∼Socket()** [virtual]

# 5.9.4 Member Function Documentation

5.9.4.1 void Socket::AcceptConnections ( Socket & socket )


Accept connection from a client.

Set the socket to accept connections any client transmitting through the socket

#### **Parameters**

in,out	socket	Master/client object to enable on the socket
--------	--------	--

Here is the call graph for this function:



5.9.4.2 void Socket::Bind( ) [protected]

Bind a name to a socket.

Returns

Success of the operation

Here is the call graph for this function:



5.9.4.3 void Socket::Configure( ) [private]

Configure the socket object for communication.

5.9.4.4 void Socket::Create( ) [private]

Create an endpoint for communication.

5.9.4.5 void Socket::DumpConnected ( ) const

5.9.4.6 Message Socket::FetchMessage (int id = -1) const [protected]

Receive a message from a socket.

Returns

Received message as a std::string

5.9 Socket Class Reference 45

5.9.4.7 int Socket::GetPort() const [inline]

Retrieve the port used for this socket.

**5.9.4.8** int Socket::GetSocketId ( ) const [inline]

5.9.4.9 SocketType Socket::GetSocketType ( int sid ) const [inline]

5.9.4.10 bool Socket::IsWebSocket (int sid ) const [inline]

Here is the call graph for this function:



**5.9.4.11 void Socket::Listen (int maxconn)** [protected]

Listen to incoming messages.

Set the socket to listen to any message coming from outside

Here is the call graph for this function:



**5.9.4.12 void Socket::PrepareConnection()** [protected]



5.9.4.13 void Socket::SelectConnections ( )

Register all open file descriptors to read their communication through the socket

5.9.4.14 void Socket::SendMessage ( Message message, int id = -1 ) const [protected]

Send a message on a socket.

Here is the call graph for this function:



```
5.9.4.15 void Socket::SetPort (int port) [inline]
```

5.9.4.16 void Socket::SetSocketId (int sid ) [inline]

5.9.4.17 bool Socket::Start() [protected]


Start the socket.

Launch all mandatory operations to set the socket to be used

Returns

Success of the operation

Here is the call graph for this function:



5.9.4.18 void Socket::Stop ( )

Terminates the socket and all attached communications.

### 5.9.5 Field Documentation

5.9.5.1 struct sockaddr\_in Socket::fAddress [private]

**5.9.5.2 char Socket::fBuffer[MAX\_WORD\_LENGTH]** [protected]

**5.9.5.3 fd\_set Socket::fMaster** [protected]

Master file descriptor list.

**5.9.5.4** int Socket::fPort [protected]

**5.9.5.5 fd\_set Socket::fReadFds** [protected]

Temp file descriptor list for select()

**5.9.5.6** int Socket::fSocketId [private]

A file descriptor for this socket, if *Create* was performed beforehand.

**5.9.5.7 SocketCollection Socket::fSocketsConnected** [protected]

The documentation for this class was generated from the following files:


- · include/Socket.h
- · src/Socket.cpp

# 5.10 SocketMessage Class Reference


Socket-passed message type.

#include <SocketMessage.h>

Inheritance diagram for SocketMessage:



Collaboration diagram for SocketMessage:



#### **Public Member Functions**

- · SocketMessage ()
- SocketMessage (const Message &msg)
- SocketMessage (const char \*msg\_s)
- SocketMessage (std::string msg\_s)
- SocketMessage (const MessageKey &key)

Construct a socket message out of a key.

SocketMessage (const MessageKey &key, const char \*value)

Construct a socket message out of a key and a string-type value.

• SocketMessage (const MessageKey &key, std::string value)

Construct a socket message out of a key and a string-type value.

SocketMessage (const MessageKey &key, const int value)

Construct a socket message out of a key and an integer-type value.

• SocketMessage (const MessageKey &key, const float value)

Construct a socket message out of a key and a float-type value.

• SocketMessage (const MessageKey &key, const double value)

Construct a socket message out of a key and a double precision-type value.

SocketMessage (MessageMap msg\_m)

Construct a socket message out of a map of key/string-type value.

- ∼SocketMessage ()
- void SetKeyValue (const MessageKey &key, const char \*value)

String-valued message.

void SetKeyValue (const MessageKey &key, int int\_value)

Send an integer-valued message.

• void SetKeyValue (const MessageKey &key, float float value)

Float-valued message.

• void SetKeyValue (const MessageKey &key, double double\_value)

Double-valued message.

• std::string GetString () const

Extract the whole key:value message.

MessageKey GetKey () const

Extract the message's key.

· std::string GetValue () const

Extract the message's string value.

• int GetIntValue () const

Extract the message's integer value.

• VectorValue GetVectorValue () const

Extract the message's vector of string value.

void Dump (std::ostream &os=std::cout) const

### **Private Member Functions**

- MessageMap Object () const
- std::string String () const

# **Private Attributes**

• MessageMap fMessage

#### **Additional Inherited Members**

# 5.10.1 Detailed Description

Socket-passed message type.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

26 Mar 2015

# 5.10.2 Constructor & Destructor Documentation

5.10.2.1 SocketMessage::SocketMessage( ) [inline]


5.10.2.2 SocketMessage::SocketMessage ( const Message & msg ) [inline]

Here is the call graph for this function:

SocketMessage::Object

5.10.2.3 SocketMessage::SocketMessage ( const char \* msg\_s ) [inline]

Here is the call graph for this function:



5.10.2.4 SocketMessage::SocketMessage ( std::string msg\_s ) [inline]

Here is the call graph for this function:



5.10.2.5 SocketMessage::SocketMessage ( const MessageKey & key ) [inline]

Construct a socket message out of a key.

Here is the call graph for this function:



5.10.2.6 SocketMessage::SocketMessage ( const MessageKey & key, const char \* value ) [inline]

Construct a socket message out of a key and a string-type value.



5.10.2.7 SocketMessage::SocketMessage(const MessageKey & key, std::string value) [inline]

Construct a socket message out of a key and a string-type value.


Here is the call graph for this function:



5.10.2.8 SocketMessage::SocketMessage ( const MessageKey & key, const int value ) [inline]

Construct a socket message out of a key and an integer-type value.


Here is the call graph for this function:



5.10.2.9 SocketMessage::SocketMessage ( const MessageKey & key, const float value ) [inline]

Construct a socket message out of a key and a float-type value.

Here is the call graph for this function:



5.10.2.10 SocketMessage::SocketMessage (const MessageKey & key, const double value) [inline]

Construct a socket message out of a key and a double precision-type value.



5.10.2.11 SocketMessage::SocketMessage ( MessageMap msg\_m ) [inline]


Construct a socket message out of a map of key/string-type value.

5.10.2.12 SocketMessage::~SocketMessage() [inline]

5.10.3 Member Function Documentation

5.10.3.1 void SocketMessage::Dump ( std::ostream & os = std::cout ) const [inline]

Here is the call graph for this function:



5.10.3.2 int SocketMessage::GetIntValue() const [inline]

Extract the message's integer value.

5.10.3.3 MessageKey SocketMessage::GetKey()const [inline]

Extract the message's key.

**5.10.3.4** std::string SocketMessage::GetString ( ) const [inline]

Extract the whole key:value message.

**5.10.3.5** std::string SocketMessage::GetValue( )const [inline]

Extract the message's string value.

5.10.3.6 VectorValue SocketMessage::GetVectorValue ( ) const [inline]

Extract the message's vector of string value.

Here is the call graph for this function:



**5.10.3.7** MessageMap SocketMessage::Object( )const [inline],[private]

5.10.3.8 void SocketMessage::SetKeyValue ( const MessageKey & key, const char \* value ) [inline]

String-valued message.

Here is the call graph for this function:



5.10.3.9 void SocketMessage::SetKeyValue ( const MessageKey & key, int int\_value ) [inline]

Send an integer-valued message.

Here is the call graph for this function:



5.10.3.10 void SocketMessage::SetKeyValue ( const MessageKey & key, float float\_value ) [inline]

Float-valued message.



5.10.3.11 void SocketMessage::SetKeyValue ( const MessageKey & key, double double\_value ) [inline]

Double-valued message.

Here is the call graph for this function:



**5.10.3.12** std::string SocketMessage::String ( ) const [inline], [private]

### 5.10.4 Field Documentation

**5.10.4.1** MessageMap SocketMessage::fMessage [private]

The documentation for this class was generated from the following file:


• include/SocketMessage.h

# 5.11 TDC Class Reference

HPTDC object.

#include <TDC.h>

Collaboration diagram for TDC:



# **Public Member Functions**

- TDC (unsigned int id, USBHandler \*h)
- ∼TDC ()
- void SetSetupRegister (const TDCSetup &c)

Submit the HPTDC setup word as a TDCSetup object.

TDCSetup GetSetupRegister ()

Retrieve the HPTDC setup word as a TDCSetup object.

• bool CheckFirmwareVersion () const

5.11 TDC Class Reference 55

- · void SoftReset ()
- TDCEventCollection FetchEvents ()
- void ReadStatus ()

## **Private Member Functions**

· void SendConfiguration ()

Set the setup word to the HPTDC internal setup register.

void ReadConfiguration ()

Read the setup word from the HPTDC internal setup register.

template < class T >

void WriteRegister (unsigned int r, const T &v)

Write one register content on the HPTDC inner memory.

• template<class T >

T ReadRegister (unsigned int r)

Retrieve one register content from the HPTDC inner memory.

## **Private Attributes**

- · unsigned int fld
- USBHandler \* fUSB
- TDCSetup fSetup
- TDCControl fControl
- TDCBoundaryScan fBS
- · TDCStatus fStatus

## 5.11.1 Detailed Description

HPTDC object.

**Author** 

Laurent Forthomme laurent.forthomme@cern.ch

Date

27 Apr 2015

## 5.11.2 Constructor & Destructor Documentation

5.11.2.1 TDC::TDC ( unsigned int id, USBHandler \*h )




5.11.2.2 TDC:: $\sim$ TDC( ) [inline]

## 5.11.3 Member Function Documentation


## 5.11.3.1 bool TDC::CheckFirmwareVersion ( ) const

Here is the call graph for this function:



## 5.11.3.2 TDCEventCollection TDC::FetchEvents ( )

Here is the call graph for this function:



# 5.11.3.3 TDCSetup TDC::GetSetupRegister() [inline]

Retrieve the HPTDC setup word as a TDCSetup object.

**5.11.3.4 void TDC::ReadConfiguration ( )** [private]


Read the setup word from the HPTDC internal setup register.

**5.11.3.5** template < class T > T TDC::ReadRegister (unsigned int r) [private]

Retrieve one register content from the HPTDC inner memory.

5.11 TDC Class Reference 57

Here is the call graph for this function:



```
5.11.3.6 void TDC::ReadStatus() [inline]
```

**5.11.3.7 void TDC::SendConfiguration()** [private]


Set the setup word to the HPTDC internal setup register.

5.11.3.8 void TDC::SetSetupRegister ( const TDCSetup & c ) [inline]

Submit the HPTDC setup word as a TDCSetup object.

5.11.3.9 void TDC::SoftReset ( )


Here is the call graph for this function:



5.11.3.10 template < class T > void TDC::WriteRegister ( unsigned int r, const T & v ) [private]

Write one register content on the HPTDC inner memory.

Here is the call graph for this function:



## 5.11.4 Field Documentation

- **5.11.4.1 TDCBoundaryScan TDC::fBS** [private]
- **5.11.4.2 TDCControl TDC::fControl** [private]
- **5.11.4.3 unsigned int TDC::fld** [private]
- **5.11.4.4 TDCSetup TDC::fSetup** [private]
- **5.11.4.5 TDCStatus TDC::fStatus** [private]
- **5.11.4.6 USBHandler\* TDC::fUSB** [private]


The documentation for this class was generated from the following files:

- · include/TDC.h
- · src/TDC.cpp


# 5.12 TDCBoundaryScan Class Reference

#include <TDCBoundaryScan.h>

Inheritance diagram for TDCBoundaryScan:



Collaboration diagram for TDCBoundaryScan:



#### **Public Member Functions**

- TDCBoundaryScan ()
- TDCBoundaryScan (const TDCBoundaryScan &bs)
- void SetConstantValues ()

# **Static Private Attributes**

- static const bit kTokenOut = 0
- static const bit kStrobeOut = 1
- static const bit kSerialOut = 2
- static const bit kTest = 3
- static const bit kError = 4
- static const bit kDataReady = 5
- static const bit kParallelEnable = 6
- static const bit kParallelDataOut = 7
- static const bit kEncodedControl = 39
- static const bit kTrigger = 40
- static const bit kEventReset = 41
- static const bit kBunchReset = 42
- static const bit kGetData = 43
- static const bit kSerialBypassIn = 44
- static const bit kSerialIn = 45
- static const bit kTokenBypassIn = 46
- static const bit kTokenIn = 47
- static const bit kReset = 48
- static const bit kAuxClock = 49
- static const bit kClk = 50
- static const bit kHit = 51

## **Additional Inherited Members**

# 5.12.1 Detailed Description

#### **Author**

Laurent Forthomme laurent.forthomme@cern.ch

Date

24 Apr 2015

## 5.12.2 Constructor & Destructor Documentation

## **5.12.2.1 TDCBoundaryScan::TDCBoundaryScan()** [inline]

Here is the call graph for this function:



## 5.12.2.2 TDCBoundaryScan::TDCBoundaryScan ( const TDCBoundaryScan & bs ) [inline]

Here is the call graph for this function:



## 5.12.3 Member Function Documentation

**5.12.3.1** void TDCBoundaryScan::SetConstantValues() [inline], [virtual]

Ensure that the critical constant values are properly set in the register word Implements TDCRegister.

## 5.12.4 Field Documentation

- **5.12.4.1 const bit TDCBoundaryScan::kAuxClock = 49** [static], [private]
- **5.12.4.2** const bit TDCBoundaryScan::kBunchReset = 42 [static], [private]
- 5.12.4.3 const bit TDCBoundaryScan::kClk = 50 [static], [private]
- **5.12.4.4 const bit TDCBoundaryScan::kDataReady = 5** [static], [private]
- **5.12.4.5** const bit TDCBoundaryScan::kEncodedControl = 39 [static], [private]
- 5.12.4.6 const bit TDCBoundaryScan::kError = 4 [static], [private]

```
5.12.4.7 const bit TDCBoundaryScan::kEventReset = 41  [static], [private]
5.12.4.8 const bit TDCBoundaryScan::kGetData = 43  [static], [private]
5.12.4.9 const bit TDCBoundaryScan::kParallelDataOut = 7  [static], [private]
5.12.4.10 const bit TDCBoundaryScan::kParallelDataOut = 7  [static], [private]
5.12.4.11 const bit TDCBoundaryScan::kParallelEnable = 6  [static], [private]
5.12.4.12 const bit TDCBoundaryScan::kReset = 48  [static], [private]
5.12.4.13 const bit TDCBoundaryScan::kSerialBypassIn = 44  [static], [private]
5.12.4.14 const bit TDCBoundaryScan::kSerialOut = 2  [static], [private]
5.12.4.15 const bit TDCBoundaryScan::kSerialOut = 2  [static], [private]
5.12.4.16 const bit TDCBoundaryScan::kStrobeOut = 1  [static], [private]
5.12.4.17 const bit TDCBoundaryScan::kTokenBypassIn = 46  [static], [private]
5.12.4.19 const bit TDCBoundaryScan::kTokenBypassIn = 47  [static], [private]
5.12.4.20 const bit TDCBoundaryScan::kTokenOut = 0  [static], [private]
5.12.4.21 const bit TDCBoundaryScan::kTokenOut = 0  [static], [private]
5.12.4.22 const bit TDCBoundaryScan::kTokenOut = 0  [static], [private]
5.12.4.21 const bit TDCBoundaryScan::kTokenOut = 0  [static], [private]
```

The documentation for this class was generated from the following file:


• include/TDCBoundaryScan.h

# 5.13 TDCControl Class Reference


Control word to be sent to the HPTDC chip.

#include <TDCControl.h>

Inheritance diagram for TDCControl:



## Collaboration diagram for TDCControl:



# **Public Types**

- enum EnablePattern
- enum RegisterName { R\_EnablePattern, R\_GlobalReset, R\_DLLReset, R\_PLLReset }

## **Public Member Functions**

- TDCControl ()
- TDCControl (const TDCControl &c)
- void SetEnablePattern (const EnablePattern &ep)
- EnablePattern GetEnablePattern () const
- void SetGlobalReset (const bool gr=true)
- bool GetGlobalReset () const
- void SetDLLReset (const bool dr=true)
- bool GetDLLReset () const
- void SetPLLReset (const bool pr=true)
- bool GetPLLReset () const
- · void EnableChannel (unsigned int id)
- · void EnableAllChannels ()
- void DisableChannel (unsigned int id)
- void DisableAllChannels ()
- void Dump (int verb=1, std::ostream &os=std::cout) const
- void SetConstantValues ()

## **Private Member Functions**

• void SetControlParity (const bool cp=true)

## **Static Private Attributes**

- static const bit kEnablePattern = 0
- static const bit kGlobalReset = 4
- static const bit kEnableChannel = 5
- static const bit kDLLReset = 37
- static const bit kPLLReset = 38
- static const bit kControlParity = 39

## **Additional Inherited Members**

# 5.13.1 Detailed Description

Control word to be sent to the HPTDC chip.

Object handling the control word provided by/to the HPTDC chip

**Author** 

Laurent Forthomme laurent.forthomme@cern.ch


Date

24 Apr 2015

## 5.13.2 Constructor & Destructor Documentation

```
5.13.2.1 TDCControl::TDCControl() [inline]
```

Here is the call graph for this function:



## **5.13.2.2 TDCControl::TDCControl (const TDCControl & c)** [inline]

Here is the call graph for this function:



## 5.13.3 Member Function Documentation

5.13.3.1 void TDCControl::DisableAllChannels() [inline]



5.13.3.2 void TDCControl::DisableChannel (unsigned int id) [inline]

Here is the call graph for this function:




5.13.3.3 void TDCControl::Dump ( int verb = 1, std::ostream & os = std::cout ) const [inline]

Here is the call graph for this function:



5.13.3.4 void TDCControl::EnableAllChannels() [inline]

Here is the call graph for this function:



5.13.3.5 void TDCControl::EnableChannel (unsigned int id) [inline]




5.13.3.6 bool TDCControl::GetDLLReset ( ) const [inline]

Here is the call graph for this function:



5.13.3.7 EnablePattern TDCControl::GetEnablePattern ( ) const [inline]

Here is the call graph for this function:



5.13.3.8 bool TDCControl::GetGlobalReset() const [inline]



5.13.3.9 bool TDCControl::GetPLLReset ( ) const [inline]

Here is the call graph for this function:



5.13.3.10 void TDCControl::SetConstantValues() [inline], [virtual]


Ensure that the critical constant values are properly set in the register word Implements TDCRegister.

Here is the call graph for this function:



5.13.3.11 void TDCControl::SetControlParity (const bool cp = true) [inline], [private]

Here is the call graph for this function:



**5.13.3.12** void TDCControl::SetDLLReset ( const bool *dr* = true ) [inline]



5.13.3.13 void TDCControl::SetEnablePattern ( const EnablePattern & ep ) [inline]

Here is the call graph for this function:



5.13.3.14 void TDCControl::SetGlobalReset ( const bool gr = true ) [inline]

Here is the call graph for this function:



5.13.3.15 void TDCControl::SetPLLReset (const bool pr = true) [inline]

Here is the call graph for this function:



## 5.13.4 Field Documentation

**5.13.4.1 const bit TDCControl::kControlParity = 39** [static], [private]

5.13.4.2 const bit TDCControl::kDLLReset = 37 [static], [private]

**5.13.4.3** const bit TDCControl::kEnableChannel = 5 [static], [private]

**5.13.4.4 const bit TDCControl::kEnablePattern = 0** [static], [private]

5.13.4.5 const bit TDCControl::kGlobalReset = 4 [static], [private]

```
5.13.4.6 const bit TDCControl::kPLLReset = 38 [static], [private]
```

The documentation for this class was generated from the following file:

· include/TDCControl.h

# 5.14 TDCEvent Class Reference

# HPTDC event parser.

```
#include <TDCEvent.h>
```

## **Public Types**

```
    enum EventType {
        Invalid =-1, GroupHeader =0, GroupTrailer, TDCHeader,
        TDCTrailer, LeadingEdge, TrailingEdge, Error,
        Debug }
```

#### **Public Member Functions**

- TDCEvent ()
- TDCEvent (const uint32\_t &word)
- virtual ∼TDCEvent ()
- void SetWord (const uint32\_t &word)
- EventType GetType () const

Type of packet read out from the TDC.

• unsigned int GetTDCld () const

Programmed identifier of master TDC.

• uint16\_t GetEventId () const

Event identifier from event counter.

• uint16\_t GetWordCount () const

Total number of words in event (including headers and trailers)

• uint16\_t GetBunchld () const

Bunch identifier of trigger (or trigger time tag)

• uint32\_t GetLeadingTime (bool pair=false) const

Leading edge measurement in programmed time resolution.

• uint8\_t GetWidth () const

Width of pulse in programmed time resolution.

• uint32\_t GetTrailingTime () const

Trailing edge measurement in programmed time resolution.

• uint16\_t GetErrorFlags () const

Return error flags if an error condition has been detected.

## **Private Attributes**

• uint32\_t fWord

# 5.14.1 Detailed Description

HPTDC event parser.

Object enabling to decipher any measurement/error/debug event returned by the HPTDC chip

**Author** 

Laurent Forthomme laurent.forthomme@cern.ch

Date

20 Apr 2015

## 5.14.2 Constructor & Destructor Documentation

```
5.14.2.1 TDCEvent::TDCEvent() [inline]
```

5.14.2.2 TDCEvent::TDCEvent ( const uint32\_t & word ) [inline]

5.14.2.3 virtual TDCEvent::~TDCEvent() [inline], [virtual]

## 5.14.3 Member Function Documentation

5.14.3.1 uint16\_t TDCEvent::GetBunchld() const [inline]

Bunch identifier of trigger (or trigger time tag)

Here is the call graph for this function:



```
5.14.3.2 uint16_t TDCEvent::GetErrorFlags ( ) const [inline]
```

Return error flags if an error condition has been detected.



5.14.3.3 uint16\_t TDCEvent::GetEventId() const [inline]

Event identifier from event counter.

Here is the call graph for this function:



5.14.3.4 uint32\_t TDCEvent::GetLeadingTime ( bool pair = false ) const [inline]

Leading edge measurement in programmed time resolution.

Here is the call graph for this function:




**5.14.3.5** unsigned int TDCEvent::GetTDCld ( ) const [inline]

Programmed identifier of master TDC.

5.14.3.6 uint32\_t TDCEvent::GetTrailingTime() const [inline]

Trailing edge measurement in programmed time resolution.



5.14.3.7 EventType TDCEvent::GetType()const [inline]

Type of packet read out from the TDC.

5.14.3.8 uint8\_t TDCEvent::GetWidth() const [inline]

Width of pulse in programmed time resolution.

Here is the call graph for this function:



5.14.3.9 uint16\_t TDCEvent::GetWordCount() const [inline]

Total number of words in event (including headers and trailers)

Here is the call graph for this function:



 $\textbf{5.14.3.10} \quad \textbf{void TDCEvent::SetWord ( const uint32\_t \& \textit{word} )} \quad \texttt{[inline]}$ 

## 5.14.4 Field Documentation

**5.14.4.1 uint32\_t TDCEvent::fWord** [private]

The documentation for this class was generated from the following file:


· include/TDCEvent.h

# 5.15 TDCRegister Class Reference

General register object to interact with a HPTDC chip.

#include <TDCRegister.h>

Inheritance diagram for TDCRegister:



## **Public Types**

• typedef uint16\_t bit

LSB index.

• typedef uint32 t word t

Unit of the TDC register word to be successfully contained on any machine.

## **Public Member Functions**

- TDCRegister (const unsigned int size)
- TDCRegister (const unsigned int size, const TDCRegister &r)
- virtual ∼TDCRegister ()
- TDCRegister & operator= (const TDCRegister &r)
- void SetWord (const unsigned int i, const word t word)

Set one bit(s) subset in the register word.

word\_t GetWord (const unsigned int i) const

Retrieve one subset from the register word.

• uint8\_t GetNumWords () const

Number of words in the register.

- void DumpRegister (std::ostream &os=std::cout, const bit max\_bits=-1) const
- virtual void SetConstantValues ()=0

## **Protected Member Functions**

void SetBits (uint16\_t lsb, uint16\_t word, uint8\_t size)

Set bits in the register word.

uint16\_t GetBits (uint16\_t lsb, uint8\_t size) const

Extract bits from the register word.

• void Clear ()

Set all bits in this register to '0'.

# **Protected Attributes**

• word\_t \* fWord

Pointer to this register's word.

- · unsigned int fNumWords
- unsigned int fWordSize

Number of bits in this register.

# 5.15.1 Detailed Description

General register object to interact with a HPTDC chip.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

24 Apr 2015

# 5.15.2 Member Typedef Documentation

5.15.2.1 typedef uint16\_t TDCRegister::bit

LSB index.

5.15.2.2 typedef uint32\_t TDCRegister::word\_t

Unit of the TDC register word to be successfully contained on any machine.

## 5.15.3 Constructor & Destructor Documentation

5.15.3.1 TDCRegister::TDCRegister ( const unsigned int size ) [inline]

Here is the call graph for this function:



5.15.3.2 TDCRegister::TDCRegister ( const unsigned int size, const TDCRegister & r ) [inline]



```
5.15.3.3 virtual TDCRegister::~TDCRegister() [inline], [virtual]
```

## 5.15.4 Member Function Documentation

```
5.15.4.1 void TDCRegister::Clear() [inline], [protected]
```

Set all bits in this register to '0'.

```
5.15.4.2 void TDCRegister::DumpRegister ( std::ostream & os = std::cout, const bit max\_bits = -1 ) const [inline]
```

```
5.15.4.3 uint16_t TDCRegister::GetBits ( uint16_t lsb, uint8_t size ) const [inline], [protected]
```

Extract bits from the register word.

Extract a fixed amount of bits from the full register word

#### **Parameters**

in	Isb	Least significant bit of the word to retrieve
in	size	Size of the word to retrieve

```
5.15.4.4 uint8_t TDCRegister::GetNumWords() const [inline]
```

Number of words in the register.

Return the number of words making up the full register word.

```
5.15.4.5 word_t TDCRegister::GetWord ( const unsigned int i ) const [inline]
```

Retrieve one subset from the register word.

```
5.15.4.6 TDCRegister& TDCRegister::operator=(const TDCRegister & r) [inline]
```

Set bits in the register word.

Set a fixed amount of bits in the full register word

#### **Parameters**

in	Isb	Least significant bit of the word to set
in	word	Word to set
in	size	Size of the word to set

**5.15.4.8 virtual void TDCRegister::SetConstantValues ( )** [pure virtual]

Ensure that the critical constant values are properly set in the register word Implemented in TDCSetup, TDCControl, TDCBoundaryScan, and TDCStatus.

5.15.4.9 void TDCRegister::SetWord ( const unsigned int i, const word t word ) [inline]

Set one bit(s) subset in the register word.

## 5.15.5 Field Documentation

**5.15.5.1 unsigned int TDCRegister::fNumWords** [protected]

Number of words to fit the fWordSize bits of this register to this object

**5.15.5.2** word t\* TDCRegister::fWord [protected]

Pointer to this register's word.

**5.15.5.3** unsigned int TDCRegister::fWordSize [protected]

Number of bits in this register.

The documentation for this class was generated from the following file:


· include/TDCRegister.h

# 5.16 TDCSetup Class Reference


Setup word to be sent to the HPTDC chip.

#include <TDCSetup.h>

Inheritance diagram for TDCSetup:



Collaboration diagram for TDCSetup:



## **Public Types**

```
    enum EdgeResolution {

 E_100ps =0, E_200ps, E_400ps, E_800ps,
 E_1p6ns, E_3p12ns, E_6p25ns, E_12p5ns }

    enum DeadTime { DT 5ns =0, DT 10ns, DT 30ns, DT 100ns }

enum WidthResolution {
 W 100ps = 0, W 200ps, W 400ps, W 800ps,
 W_1p6ns, W_3p2ns, W_6p25ns, W_12p5ns,
 W 25ns, W 50ns, W 100ns, W 200ns,
 W 400ns, W 800ns }
enum EnabledError {
 VernierError =0x1, CoarseError =0x2, ChannelSelectError =0x4, L1BufferParityError =0x8,
 TriggerFIFOParityError =0x10, TriggerMatchingError =0x20, ReadoutFIFOParityError =0x40, ReadoutState ←
 Error =0x80.
 SetupParityError =0x100, ControlParityError =0x200, JTAGInstructionParityError =0x400 }
enum DLLSpeedMode { DLL 40MHz =0x0, DLL 160MHz =0x1, DLL 320MHz =0x2, DLL Illegal =0x3 }
• enum SerialClockSource { Serial_pll_clock_80 =0x0, Serial_pll_clock_160 =0x1, Serial_pll_clock_40 =0x2,
 Serial_aux_clock =0x3 }

    enum IOClockSource { IO_clock_40 =0x0, IO_pll_clock_80 =0x1, IO_pll_clock_160 =0x2, IO_aux_clock =0x3

aux clock =0x3 }

    enum DLLClockSource {

 DLL_clock_40 =0x0, DLL_pll_clock_40 =0x1, DLL_pll_clock_160 =0x2, DLL_pll_clock_320 =0x3,
 DLL_aux_clock =0x4 }

    enum ReadoutSpeed { RO_Fixed =0x0, RO_pll_80Mbits_s =0x1 }

    enum SerialStrobeType { SS NoStrobe =0x0, SS DSStrobe =0x1, SS LeadingTrailingStrobe =0x2, SS ←

 LeadingEdge =0x3 }

    enum ReadoutSingleCycleSpeed {

 RSC 40Mbits s =0x0, RSC 20Mbits s =0x1, RSC 10Mbits s =0x2, RSC 5Mbits s =0x3,
 RSC 2p5Mbits s = 0x4, RSC 1p25Mbits s = 0x5, RSC 625kbits s = 0x6, RSC 312p5kbits s = 0x7}
```

## **Public Member Functions**

- TDCSetup ()
- TDCSetup (const TDCSetup &c)
- void SetEnableErrorMark (const bool em)

Mark events with error if global error signal is set.

- bool GetEnableErrorMark () const
- void SetEnableErrorBypass (const bool eb)

Bypass TDC chip if global error signal is set.

- · bool GetEnableErrorBypass () const
- void SetEnableError (const uint16 t &err)

Enable internal error types for generation of global error signals.

- uint16\_t GetEnableError () const
- void SetEnableSerial (const bool es)

Enable of serial read-out (otherwise parallel read-out)

- bool GetEnableSerial () const
- void SetEnableJTAGReadout (const bool jr)

Enable of read-out via JTAG.

- · bool GetEnableJTAGReadout () const
- void SetReadoutFIFOSize (int rfs)

Effective size of readout FIFO.

- int GetReadoutFIFOSize () const
- void SetRejectCountOffset (uint16\_t rco)

Set the offset in reject counter (defines reject latency together with coarse count offset)

uint16\_t GetRejectCountOffset () const

Extract the offset in reject counter.

void SetSearchWindow (uint16\_t sw)

Set the search window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

• uint16 t GetSearchWindow () const

Extract the search window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

void SetMatchWindow (uint16\_t mw)

Set the matching window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

uint16 t GetMatchWindow () const

Extract the matching window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

- void SetEdgeResolution (const EdgeResolution r)
- EdgeResolution GetEdgeResolution () const
- void SetMaxEventSize (int sz=-1)

Set the maximum number of hits per event.

• uint8\_t GetMaxEventSize () const

Extract the maximum number of hits per event.

void SetRejectFIFOFull (const bool rej=true)

Reject hits when readout FIFO full.

· bool GetRejectFIFOFull () const

Are hits rejected when readout FIFO is full?

void SetEnableReadoutOccupancy (const bool ro=true)

Enable the readout of buffer occupancies for each event (for debugging purposes)

- · bool GetEnableReadoutOccupancy () const
- void SetEnableReadoutSeparator (const bool ro=true)

Enable the readout of separators for each event (for debugging purposes, valid if readout of occupancies is enabled)

- bool GetEnableReadoutSeparator () const
- void SetEventCountOffset (uint16\_t eco)

Set offset for the event counter.

void SetTriggerCountOffset (uint16\_t tco)

Set offset for the trigger time tag counter to set effective trigger latency.

uint16\_t GetTriggerCountOffset () const

Extract trigger time tag count offset.

• void SetChannelOffset (int channel, uint16\_t offset)

Set the time offset for one single channel.

uint16\_t GetChannelOffset (int channel) const

Return the offset for one single channel.

· void SetAllChannelsOffset (uint16 t offset)

Set the time offset for all channels.

void SetCoarseCountOffset (uint16\_t cco)

Set offset for the coarse time counter.

uint16\_t GetCoarseCountOffset () const

Extract offset for the coarse time counter.

void SetDLLAdjustment (int tap, uint8\_t adj)

Set the DLL taps adjustments with a resolution of  $\sim$ 10 ps.

uint8\_t GetDLLAdjustment (int tap) const

Set the adjustment of DLL taps.

void SetAllTapsDLLAdjustment (uint8\_t adj)

Extract the adjustment of DLL taps.

· void SetRCAdjustment (int tap, uint8\_t adj)

Set the adjustment of the RC delay line.

uint8\_t GetRCAdjustment (int tap)

Extract the adjustment of the RC delay line.

void SetWidthResolution (const WidthResolution r)

Set the pulse width resolution when paired measurements are performed.

· WidthResolution GetWidthResolution () const

Extract the pulse width resolution when paired measurements are performed.

void SetVernierOffset (const uint8\_t vo)

Set the offset in vernier decoding.

• uint8\_t GetVernierOffset () const

Extract the offset in vernier decoding.

void SetDeadTime (const DeadTime dt)

Channel dead time between hits.

- DeadTime GetDeadTime () const
- void SetTestInvert (const bool ti=true)

Automatic inversion of test pattern. Only used during production testing.

- · bool GetTestInvert () const
- void SetTestMode (const bool tm=true)

Test mode where hit data are taken from coretest. Only used during production testing.

- bool GetTestMode () const
- void SetTrailingMode (const bool trail=true)

Enable/disable the detection of trailing edges.

• bool GetTrailingMode () const

Extract the status for the detection of trailing edges.

void SetLeadingMode (const bool lead=true)

Enable the detection of leading edges.

• bool GetLeadingMode () const

Extract the status for the detection of leading edges.

void SetTriggerMatchingMode (const bool trig=true)

Set the enable status of trigger matching mode.

bool GetTriggerMatchingMode () const

Extract the enable status of trigger matching mode.

void SetEdgesPairing (const bool pair=true)

Enable the pairing of leading and trailing edges (overrides individual enable of leading/trailing edges)

- bool GetEdgesPairing () const
- void SetSetupParity (const bool sp=true)

Set the parity of setup data (should be an even parity)

bool GetSetupParity () const

Extract the parity of setup data (should be an even parity)

• void SetConstantValues ()

Ensure that the critical constant values are properly set in the setup word.

uint16\_t GetTriggerLatency () const

Effective trigger latency in number of clock cycles (when no counter roll-over is used)

• void Dump (int verb=1, std::ostream &os=std::cout) const

#### **Private Member Functions**

void SetReadoutSingleCycleSpeed (const ReadoutSingleCycleSpeed rscs=RSC 40Mbits s)

Serial transmission speed in single cycle mode.

void SetSerialDelay (const uint8 t sd=0x0)

Programmable delay of serial input, in time unit  $\sim$  1 ns.

- void SetStrobeSelect (const SerialStrobeType ss=SS\_NoStrobe)
- void SetReadoutSpeedSelect (const ReadoutSpeed rss=RO\_Fixed)

Selection of serial read-out speed.

void SetTokenDelay (const uint8\_t td=0x0)

Programmable delay of token input, in time unit  $\sim$  1 ns.

void SetEnableLocalTrailer (const bool elt=true)

Enable of local trailers in read-out.

void SetEnableLocalHeader (const bool elh=true)

Enable of local headers in read-out.

void SetEnableGlobalTrailer (const bool egt=true)

Enable of global trailers in read-out (only valid for master TDC)

void SetEnableGlobalHeader (const bool egh=true)

Enable of global headers in read-out (only valid for master TDC)

- void SetKeepToken (const bool kt=true)
- void SetMaster (const bool m=true)
- void SetEnableBytewise (const bool seb=true)
- void SetBypassInputs (const bool sbi=true)

Select serial in and token in from bypass inputs.

void SetEnableOverflowDetect (const bool eod=true)

Enable overflow detection of L1 buffers (should always be enabled!)

- void SetEnableRelative (const bool er=true)
- void SetEnableAutomaticReject (const bool ear=true)

Enable of automatic rejection (should always be enabled if trigger matching mode!)

void SetEnableSetCountersOnBunchReset (const bool escobr=true)

Enable all counters to be set on bunch count reset.

void SetEnableMasterResetCode (const bool emrc=true)

Enable master reset code on encoded\_control.

void SetEnableMasterResetOnEventReset (const bool emroer=true)

Enable master reset of whole TDC on event reset.

void SetEnableResetChannelBufferWhenSeparator (const bool ercbws=true)

Enable reset channel buffers when separator.

void SetEnableSeparatorOnEventReset (const bool esoer=true)

Enable generation of separator on event reset.

void SetEnableSeparatorOnBunchReset (const bool esobr=true)

Enable generation of separator on bunch reset.

void SetEnableDirectEventReset (const bool eder=true)

Enable of direct event reset input pin (1), otherwise taken from encoded control.

void SetEnableDirectBunchReset (const bool edbr=true)

Enable of direct bunch reset input pin (1), otherwise taken from encoded control.

void SetEnableDirectTrigger (const bool edt=true)

Enable of direct trigger input pin.

void SetLowPowerMode (const bool lpm=true)

Low power mode of channel buffers.

· void SetDLLControl (const uint8 t dc)

Control of DLL (DLL charge pump levels)

void SetModeRCCompression (const bool mrc=true)

Perform RC interpolation on-chip (only valid in very high resolution mode)

void SetModeRC (const bool mr=true)

Enable of RR delay lines mode (in very high resolution mode); only for channels 0-4-8-12-16-20-24-28 active.

void SetDLLMode (const DLLSpeedMode dsm)

Selection of DLL speed mode.

• void SetPLLControl (const uint8\_t charge\_pump\_current=0x4, const bool power\_down\_mode=false, const bool enable test outputs=false, const bool invert connection to status=false)

Control of PLL.

void SetSerialClockDelay (const bool delay\_clock, const uint8\_t delay)

Delay of internal serial clock.

void SetIOClockDelay (const bool delay\_clock, const uint8\_t delay)

Delay of internal I/O clock.

void SetCoreClockDelay (const bool delay\_clock, const uint8\_t delay)

Delay of internal core clock.

void SetDLLClockDelay (const bool delay\_clock, const uint8\_t delay)

Delay of internal DLL clock.

void SetSerialClockSource (const SerialClockSource scs)

Selection of source for serial clock.

void SetIOClockSource (const IOClockSource ics)

Selection of clock source for I/O signals.

void SetCoreClockSource (const CoreClockSource ccs)

Selection of clock source for internal logic.

• void SetDLLClockSource (const DLLClockSource dcs)

Selection of clock source for DLL.

• void SetRollOver (const uint16 t ro=0xFFF)

Counter roll over value, defining maximal count value from where counters will be reset to 0.

• void SetEnableTTLSerial (const bool ts=true)

Enable LV TTL inputs on serial registers, and disable their drivers.

• void SetEnableTTLControl (const bool tc=true)

Enable LV TTL inputs on control registers.

void SetEnableTTLReset (const bool tr=true)

Enable LV TTL input on reset, otherwise uses LVDS input levels.

void SetEnableTTLClock (const bool tc=true)

Enable LV TTL inputs on: clk, aux\_clock, otherwise uses LVDS input levels.

void SetEnableTTLHit (const bool th=true)

Enable LV TTL input on hit[31:0], otherwise uses LVDS input levels.

## **Static Private Attributes**

- static const bit kTestSelect = 0
- static const bit kEnableErrorMark = 4
- static const bit kEnableErrorBypass = 5
- static const bit kEnableError = 6
- static const bit kReadoutSingleCycleSpeed = 17
- static const bit kSerialDelay = 20
- static const bit kStrobeSelect = 24
- static const bit kReadoutSpeedSelect = 26
- static const bit kTokenDelay = 27
- static const bit kEnableLocalTrailer = 31
- static const bit kEnableLocalHeader = 32

- static const bit kEnableGlobalTrailer = 33
- static const bit kEnableGlobalHeader = 34
- static const bit kKeepToken = 35
- static const bit kMaster = 36
- static const bit kEnableBytewise = 37
- static const bit kEnableSerial = 38
- static const bit kEnableJTAGReadout = 39
- static const bit kTDCld = 40
- static const bit kSelectBypassInputs = 44
- static const bit kReadoutFIFOSize = 45
- static const bit kRejectCountOffset = 48
- static const bit kSearchWindow = 60
- static const bit kMatchWindow = 72
- static const bit kLeadingResolution = 84
- static const bit kMaxEventSize = 116
- static const bit kRejectFIFOFull = 120
- static const bit kEnableReadoutOccupancy = 121
- static const bit kEnableReadoutSeparator = 122
- static const bit kEnableOverflowDetect = 123
- static const bit kEnableRelative = 124
- static const bit kEnableAutomaticReject = 125
- static const bit kEventCountOffset = 126
- static const bit kTriggerCountOffset = 138
- static const bit kEnableSetCountersOnBunchReset = 150
- static const bit kEnableMasterResetCode = 151
- static const bit kEnableMasterResetOnEventReset = 152
- static const bit kEnableResetChannelBufferWhenSeparator = 153
- static const bit kEnableSeparatorOnEventReset = 154
- static const bit kEnableSeparatorOnBunchReset = 155
- static const bit kEnableDirectEventReset = 156
- static const bit kEnableDirectBunchReset = 157
- static const bit kEnableDirectTrigger = 158
- static const bit kOffset0 = 438
- static const bit kCoarseCountOffset = 447
- static const bit kDLLTapAdjust0 = 459
- static const bit kRCAdjust0 = 555
- static const bit kLowPowerMode = 570
- static const bit kWidthSelect = 571
- static const bit kVernierOffset = 575
- static const bit kDLLControl = 580
- static const bit kDeadTime = 584
- static const bit kTestInvert = 586
- static const bit kTestMode = 587
- static const bit kTrailing = 588
- static const bit kLeading = 589
- static const bit kModeRCCompression = 590
- static const bit kModeRC = 591
- static const bit kDLLMode = 592
- static const bit kPLLControl = 594
- static const bit kSerialClockDelay = 602
- static const bit kIOClockDelay = 606
- static const bit kCoreClockDelay = 610
- static const bit kDLLClockDelay = 614
- static const bit kSerialClockSource = 618
- static const bit kIOClockSource = 620

- static const bit kCoreClockSource = 622
- static const bit kDLLClockSource = 624
- static const bit kRollOver = 627
- static const bit kEnableMatching = 639
- static const bit kEnablePair = 640
- static const bit kEnableTTLSerial = 641
- static const bit kEnableTTLControl = 642
- static const bit kEnableTTLReset = 643
- static const bit kEnableTTLClock = 644
- static const bit kEnableTTLHit = 645
- static const bit kSetupParity = 646

# **Additional Inherited Members**

# 5.16.1 Detailed Description

Setup word to be sent to the HPTDC chip.

Object handling the setup word provided by/to the HPTDC chip

#### **Author**


Laurent Forthomme laurent.forthomme@cern.ch

# Date

16 Apr 2015


## 5.16.2 Constructor & Destructor Documentation

5.16.2.1 TDCSetup::TDCSetup( ) [inline]



# 5.16.2.2 TDCSetup::TDCSetup ( const TDCSetup & c ) [inline]


Here is the call graph for this function:



## 5.16.3 Member Function Documentation

5.16.3.1 void TDCSetup::Dump (int verb = 1, std::ostream & os = std::cout) const

Here is the call graph for this function:



5.16.3.2 uint16\_t TDCSetup::GetChannelOffset(int channel)const [inline]

Return the offset for one single channel.

Here is the call graph for this function:



5.16.3.3 uint16\_t TDCSetup::GetCoarseCountOffset() const [inline]

Extract offset for the coarse time counter.

Here is the call graph for this function:



5.16.3.4 DeadTime TDCSetup::GetDeadTime ( ) const [inline]

Here is the call graph for this function:



5.16.3.5 uint8\_t TDCSetup::GetDLLAdjustment (int tap ) const [inline]

Set the adjustment of DLL taps.



5.16.3.6 EdgeResolution TDCSetup::GetEdgeResolution ( ) const [inline]

Here is the call graph for this function:



5.16.3.7 bool TDCSetup::GetEdgesPairing ( ) const [inline]

Here is the call graph for this function:




5.16.3.8 uint16\_t TDCSetup::GetEnableError( ) const [inline]



**5.16.3.9 bool TDCSetup::GetEnableErrorBypass ( ) const** [inline]

Here is the call graph for this function:




5.16.3.10 bool TDCSetup::GetEnableErrorMark() const [inline]

Here is the call graph for this function:




**5.16.3.11** bool TDCSetup::GetEnableJTAGReadout ( ) const [inline]



5.16.3.12 bool TDCSetup::GetEnableReadoutOccupancy() const [inline]

Here is the call graph for this function:




5.16.3.13 bool TDCSetup::GetEnableReadoutSeparator() const [inline]

Here is the call graph for this function:



**5.16.3.14** bool TDCSetup::GetEnableSerial ( ) const [inline]

Here is the call graph for this function:



5.16.3.15 bool TDCSetup::GetLeadingMode() const [inline]

Extract the status for the detection of leading edges.

Here is the call graph for this function:



5.16.3.16 uint16\_t TDCSetup::GetMatchWindow() const [inline]

Extract the matching window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

Here is the call graph for this function:



5.16.3.17 uint8\_t TDCSetup::GetMaxEventSize( ) const [inline]

Extract the maximum number of hits per event.

Here is the call graph for this function:



5.16.3.18 uint8\_t TDCSetup::GetRCAdjustment (int tap ) [inline]

Extract the adjustment of the RC delay line.



5.16.3.19 int TDCSetup::GetReadoutFIFOSize ( ) const [inline]

Here is the call graph for this function:



5.16.3.20 uint16\_t TDCSetup::GetRejectCountOffset() const [inline]

Extract the offset in reject counter.

Here is the call graph for this function:



5.16.3.21 bool TDCSetup::GetRejectFIFOFull ( ) const [inline]

Are hits rejected when readout FIFO is full?

Extract whether or not hits are rejected once FIFO is full.



5.16.3.22 uint16\_t TDCSetup::GetSearchWindow( )const [inline]

Extract the search window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

Here is the call graph for this function:



5.16.3.23 bool TDCSetup::GetSetupParity ( ) const [inline]

Extract the parity of setup data (should be an even parity)

Here is the call graph for this function:



5.16.3.24 bool TDCSetup::GetTestInvert() const [inline]

Here is the call graph for this function:



5.16.3.25 bool TDCSetup::GetTestMode() const [inline]

Here is the call graph for this function:



**5.16.3.26** bool TDCSetup::GetTrailingMode( )const [inline]

Extract the status for the detection of trailing edges.

Here is the call graph for this function:



5.16.3.27 uint16\_t TDCSetup::GetTriggerCountOffset( ) const [inline]


Extract trigger time tag count offset.



**5.16.3.28** uint16\_t TDCSetup::GetTriggerLatency( )const [inline]

Effective trigger latency in number of clock cycles (when no counter roll-over is used)


Here is the call graph for this function:



**5.16.3.29** bool TDCSetup::GetTriggerMatchingMode() const [inline]

Extract the enable status of trigger matching mode.

Here is the call graph for this function:



5.16.3.30 uint8\_t TDCSetup::GetVernierOffset( ) const [inline]

Extract the offset in vernier decoding.



5.16.3.31 WidthResolution TDCSetup::GetWidthResolution ( ) const [inline]

Extract the pulse width resolution when paired measurements are performed.

Here is the call graph for this function:



5.16.3.32 void TDCSetup::SetAllChannelsOffset ( uint16\_t offset ) [inline]

Set the time offset for all channels.


Here is the call graph for this function:



5.16.3.33 void TDCSetup::SetAllTapsDLLAdjustment ( uint8\_t adj ) [inline]

Extract the adjustment of DLL taps.

Here is the call graph for this function:



5.16.3.34 void TDCSetup::SetBypassInputs (const bool sbi = true ) [inline], [private]

Select serial in and token in from bypass inputs.

Here is the call graph for this function:



5.16.3.35 void TDCSetup::SetChannelOffset (int channel, uint16\_t offset) [inline]

Set the time offset for one single channel.

Here is the call graph for this function:



5.16.3.36 void TDCSetup::SetCoarseCountOffset ( uint16\_t cco ) [inline]

Set offset for the coarse time counter.


Here is the call graph for this function:



**5.16.3.37 void TDCSetup::SetConstantValues()** [virtual]

Ensure that the critical constant values are properly set in the setup word.

Implements TDCRegister.



5.16.3.38 void TDCSetup::SetCoreClockDelay ( const bool delay\_clock, const uint8\_t delay ) [inline], [private]

Delay of internal core clock.

#### **Parameters**

in	delay_clock	Use of direct clock (0) or delayed clock (1)
in	delay	Delay in steps of (typically) 0.13 ns

Here is the call graph for this function:



**5.16.3.39** void TDCSetup::SetCoreClockSource ( const CoreClockSource ccs ) [inline], [private]

Selection of clock source for internal logic.

Here is the call graph for this function:



5.16.3.40 void TDCSetup::SetDeadTime ( const DeadTime dt ) [inline]

Channel dead time between hits.

Here is the call graph for this function:



5.16.3.41 void TDCSetup::SetDLLAdjustment (int tap, uint8\_t adj) [inline]

Set the DLL taps adjustments with a resolution of  $\sim\!\!10$  ps.



5.16.3.42 void TDCSetup::SetDLLClockDelay ( const bool delay\_clock, const uint8\_t delay ) [inline], [private]

Delay of internal DLL clock.

### **Parameters**

in	delay_clock	Use of direct clock (0) or delayed clock (1)
in	delay	Delay in steps of (typically) 0.13 ns


Here is the call graph for this function:



5.16.3.43 void TDCSetup::SetDLLClockSource (const DLLClockSource dcs) [inline], [private]

Selection of clock source for DLL.

Here is the call graph for this function:



**5.16.3.44** void TDCSetup::SetDLLControl(const uint8\_t dc) [inline], [private]

Control of DLL (DLL charge pump levels)



5.16.3.45 void TDCSetup::SetDLLMode ( const DLLSpeedMode dsm ) [inline], [private]

Selection of DLL speed mode.

Here is the call graph for this function:



**5.16.3.46** void TDCSetup::SetEdgeResolution (const EdgeResolution r) [inline]

Here is the call graph for this function:




5.16.3.47 void TDCSetup::SetEdgesPairing (const bool pair = true) [inline]

Enable the pairing of leading and trailing edges (overrides individual enable of leading/trailing edges)



5.16.3.48 void TDCSetup::SetEnableAutomaticReject (const bool ear = true) [inline], [private]

Enable of automatic rejection (should always be enabled if trigger matching mode!) Here is the call graph for this function:



5.16.3.49 void TDCSetup::SetEnableBytewise ( const bool seb = true ) [inline], [private]

Here is the call graph for this function:



5.16.3.50 void TDCSetup::SetEnableDirectBunchReset (const bool edbr = true ) [inline], [private]

Enable of direct bunch reset input pin (1), otherwise taken from encoded control.



5.16.3.51 void TDCSetup::SetEnableDirectEventReset ( const bool eder = true ) [inline], [private]

Enable of direct event reset input pin (1), otherwise taken from encoded control.

Here is the call graph for this function:



5.16.3.52 void TDCSetup::SetEnableDirectTrigger ( const bool edt = true ) [inline], [private]

Enable of direct trigger input pin.

Here is the call graph for this function:



5.16.3.53 void TDCSetup::SetEnableError ( const uint16\_t & err ) [inline]

Enable internal error types for generation of global error signals.



**5.16.3.54 void TDCSetup::SetEnableErrorBypass (const bool** *eb***)** [inline]

Bypass TDC chip if global error signal is set.

Here is the call graph for this function:



5.16.3.55 void TDCSetup::SetEnableErrorMark ( const bool em ) [inline]


Mark events with error if global error signal is set.

Here is the call graph for this function:



5.16.3.56 void TDCSetup::SetEnableGlobalHeader(const bool egh = true) [inline], [private]


Enable of global headers in read-out (only valid for master TDC)



5.16.3.57 void TDCSetup::SetEnableGlobalTrailer (const bool egt = true) [inline], [private]

Enable of global trailers in read-out (only valid for master TDC)

Here is the call graph for this function:



5.16.3.58 void TDCSetup::SetEnableJTAGReadout (const bool jr) [inline]


Enable of read-out via JTAG.

Here is the call graph for this function:



5.16.3.59 void TDCSetup::SetEnableLocalHeader(const bool elh = true) [inline], [private]

Enable of local headers in read-out.



5.16.3.60 void TDCSetup::SetEnableLocalTrailer (const bool elt = true) [inline], [private]

Enable of local trailers in read-out.


Here is the call graph for this function:



5.16.3.61 void TDCSetup::SetEnableMasterResetCode( const bool emrc = true ) [inline], [private]


Enable master reset code on encoded control.

Here is the call graph for this function:



5.16.3.62 void TDCSetup::SetEnableMasterResetOnEventReset ( const bool *emroer* = true ) [inline], [private]


Enable master reset of whole TDC on event reset.



5.16.3.63 void TDCSetup::SetEnableOverflowDetect ( const bool eod = true ) [inline], [private]


Enable overflow detection of L1 buffers (should always be enabled!)

Here is the call graph for this function:




5.16.3.64 void TDCSetup::SetEnableReadoutOccupancy ( const bool ro = true ) [inline]

Enable the readout of buffer occupancies for each event (for debugging purposes) Here is the call graph for this function:



5.16.3.65 void TDCSetup::SetEnableReadoutSeparator (const bool ro = true) [inline]

Enable the readout of separators for each event (for debugging purposes, valid if readout of occupancies is enabled)



**5.16.3.66** void TDCSetup::SetEnableRelative (const bool *er* = true) [inline], [private]

Enable read-out of relative time to trigger time tag. Only valid when using trigger matching mode.


Here is the call graph for this function:



5.16.3.67 void TDCSetup::SetEnableResetChannelBufferWhenSeparator (const bool ercbws = true ) [inline], [private]

Enable reset channel buffers when separator.

Here is the call graph for this function:



5.16.3.68 void TDCSetup::SetEnableSeparatorOnBunchReset (const bool esobr = true) [inline], [private]

Enable generation of separator on bunch reset.



5.16.3.69 void TDCSetup::SetEnableSeparatorOnEventReset (const bool esoer = true ) [inline], [private]

Enable generation of separator on event reset.


Here is the call graph for this function:



**5.16.3.70** void TDCSetup::SetEnableSerial ( const bool es ) [inline]


Enable of serial read-out (otherwise parallel read-out)

Here is the call graph for this function:



5.16.3.71 void TDCSetup::SetEnableSetCountersOnBunchReset (const bool escobr = true ) [inline], [private]

Enable all counters to be set on bunch count reset.



5.16.3.72 void TDCSetup::SetEnableTTLClock ( const bool tc = true ) [inline], [private]

Enable LV TTL inputs on: clk, aux\_clock, otherwise uses LVDS input levels.

Here is the call graph for this function:



5.16.3.73 void TDCSetup::SetEnableTTLControl(const bool tc = true) [inline], [private]

Enable LV TTL inputs on control registers.

Enable LV TTL input on:

- trigger,
- · bunch\_reset,
- · event reset,
- encoded\_control, otherwise uses LVDS input levels.

Here is the call graph for this function:



5.16.3.74 void TDCSetup::SetEnableTTLHit (const bool th = true ) [inline], [private]

Enable LV TTL input on hit[31:0], otherwise uses LVDS input levels.

Here is the call graph for this function:



5.16.3.75 void TDCSetup::SetEnableTTLReset ( const bool tr = true ) [inline], [private]

Enable LV TTL input on reset, otherwise uses LVDS input levels.

Here is the call graph for this function:



5.16.3.76 void TDCSetup::SetEnableTTLSerial (const bool ts = true ) [inline], [private]

Enable LV TTL inputs on serial registers, and disable their drivers.

Enable LV TTL input on:

- · serial\_in,
- serial\_bypass\_in,
- · token\_in,
- token\_bypass\_in, otherwise uses LVDS input levels. Disable LVDS drivers on:
- · serial\_out,
- · strobe\_out,
- token\_out.



5.16.3.77 void TDCSetup::SetEventCountOffset ( uint16\_t eco ) [inline]

Set offset for the event counter.

Here is the call graph for this function:



5.16.3.78 void TDCSetup::SetlOClockDelay ( const bool delay\_clock, const uint8\_t delay ) [inline], [private]

Delay of internal I/O clock.

### **Parameters**


in	delay_clock	Use of direct clock (0) or delayed clock (1)
in	delay	Delay in steps of (typically) 0.13 ns

Here is the call graph for this function:



5.16.3.79 void TDCSetup::SetlOClockSource (const IOClockSource ics) [inline], [private]

Selection of clock source for I/O signals.



5.16.3.80 void TDCSetup::SetKeepToken (const bool kt = true ) [inline], [private]

Keep token until end of event or no more data, otherwise pass token after each word read. Must be enabled when using trigger matching.

Here is the call graph for this function:



5.16.3.81 void TDCSetup::SetLeadingMode ( const bool lead = true ) [inline]

Enable the detection of leading edges.

Here is the call graph for this function:



5.16.3.82 void TDCSetup::SetLowPowerMode ( const bool lpm = true ) [inline], [private]

Low power mode of channel buffers.



5.16.3.83 void TDCSetup::SetMaster(const bool m = true) [inline], [private]

Here is the call graph for this function:



5.16.3.84 void TDCSetup::SetMatchWindow ( uint16\_t mw ) [inline]

Set the matching window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

Here is the call graph for this function:



5.16.3.85 void TDCSetup::SetMaxEventSize ( int sz = -1 ) [inline]

Set the maximum number of hits per event.

Set the maximum number of hits that can be recorded for each event. It is always rounded to the next power of 2 (in the range 0-128), and if lower than 0 or bigger than 128 then set to unimited.



5.16.3.86 void TDCSetup::SetModeRC ( const bool mr = true ) [inline], [private]

Enable of RR delay lines mode (in very high resolution mode); only for channels 0-4-8-12-16-20-24-28 active. Here is the call graph for this function:



5.16.3.87 void TDCSetup::SetModeRCCompression (const bool mrc = true ) [inline], [private]

Perform RC interpolation on-chip (only valid in very high resolution mode) Here is the call graph for this function:



5.16.3.88 void TDCSetup::SetPLLControl ( const uint8\_t charge\_pump\_current =  $0 \times 4$ , const bool power\_down\_mode = false, const bool enable\_test\_outputs = false, const bool invert\_connection\_to\_status = false ) [inline], [private]

Control of PLL.



5.16.3.89 void TDCSetup::SetRCAdjustment(int tap, uint8\_t adj) [inline]

Set the adjustment of the RC delay line.

Here is the call graph for this function:



5.16.3.90 void TDCSetup::SetReadoutFIFOSize (int rfs ) [inline]

Effective size of readout FIFO.

Here is the call graph for this function:



5.16.3.91 void TDCSetup::SetReadoutSingleCycleSpeed ( const ReadoutSingleCycleSpeed rscs = RSC\_40Mbits\_s )
[inline], [private]

Serial transmission speed in single cycle mode.



5.16.3.92 void TDCSetup::SetReadoutSpeedSelect ( const ReadoutSpeed rss = RO\_Fixed ) [inline], [private]

Selection of serial read-out speed.

#### **Parameters**

in	rss	
		<ul> <li>0: Selection of serial read-out speed (as defined by setup[19:17], Set</li></ul>
		• 1: 80 Mbits/s (PLL lock required)

Here is the call graph for this function:



5.16.3.93 void TDCSetup::SetRejectCountOffset ( uint16\_t rco ) [inline]

Set the offset in reject counter (defines reject latency together with coarse count offset) Here is the call graph for this function:



5.16.3.94 void TDCSetup::SetRejectFIFOFull (const bool rej = true) [inline]

Reject hits when readout FIFO full.

Set whether or not hits are rejected once FIFO is full.

Here is the call graph for this function:



5.16.3.95 void TDCSetup::SetRollOver(const uint16\_t ro = 0xFFF) [inline], [private]

Counter roll over value, defining maximal count value from where counters will be reset to 0. Here is the call graph for this function:



5.16.3.96 void TDCSetup::SetSearchWindow(uint16\_t sw) [inline]

Set the search window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

Here is the call graph for this function:




5.16.3.97 void TDCSetup::SetSerialClockDelay (const bool delay\_clock, const uint8\_t delay) [inline], [private]

Delay of internal serial clock.

#### **Parameters**

in	delay_clock	Use of direct clock (0) or delayed clock (1)
in	delay	Delay in steps of (typically) 0.13 ns


Here is the call graph for this function:



5.16.3.98 void TDCSetup::SetSerialClockSource (const SerialClockSource scs) [inline], [private]

Selection of source for serial clock.


Here is the call graph for this function:



5.16.3.99 void TDCSetup::SetSerialDelay (const uint8\_t sd = 0x0) [inline], [private]

Programmable delay of serial input, in time unit  $\sim$  1 ns.

Here is the call graph for this function:




5.16.3.100 void TDCSetup::SetSetupParity (const bool sp = true) [inline]

Set the parity of setup data (should be an even parity)



5.16.3.101 void TDCSetup::SetStrobeSelect ( const SerialStrobeType  $ss = SS_NoStrobe$  ) [inline], [private]

Here is the call graph for this function:



5.16.3.102 void TDCSetup::SetTestInvert ( const bool ti = true ) [inline]

Automatic inversion of test pattern. Only used during production testing.

Here is the call graph for this function:



5.16.3.103 void TDCSetup::SetTestMode ( const bool tm = true ) [inline]

Test mode where hit data are taken from coretest. Only used during production testing.



5.16.3.104 void TDCSetup::SetTokenDelay (const uint8\_t  $td = 0 \times 0$ ) [inline], [private]

Programmable delay of token input, in time unit  $\sim 1\ \text{ns}.$ 


Here is the call graph for this function:



5.16.3.105 void TDCSetup::SetTrailingMode ( const bool trail = true ) [inline]

Enable/disable the detection of trailing edges.

Here is the call graph for this function:



5.16.3.106 void TDCSetup::SetTriggerCountOffset(uint16\_t tco) [inline]

Set offset for the trigger time tag counter to set effective trigger latency.



5.16.3.107 void TDCSetup::SetTriggerMatchingMode ( const bool trig = true ) [inline]

Set the enable status of trigger matching mode.

Here is the call graph for this function:



5.16.3.108 void TDCSetup::SetVernierOffset ( const uint8\_t vo ) [inline]

Set the offset in vernier decoding.

Here is the call graph for this function:



5.16.3.109 void TDCSetup::SetWidthResolution ( const WidthResolution r ) [inline]

Set the pulse width resolution when paired measurements are performed.



```
5.16.4 Field Documentation
5.16.4.1 const bit TDCSetup::kCoarseCountOffset = 447 [static], [private]
5.16.4.2 const bit TDCSetup::kCoreClockDelay = 610 [static], [private]
5.16.4.3 const bit TDCSetup::kCoreClockSource = 622 [static], [private]
5.16.4.4 const bit TDCSetup::kDeadTime = 584 [static], [private]
5.16.4.5 const bit TDCSetup::kDLLClockDelay = 614 [static], [private]
5.16.4.6 const bit TDCSetup::kDLLClockSource = 624 [static], [private]
5.16.4.7 const bit TDCSetup::kDLLControl = 580 [static], [private]
5.16.4.8 const bit TDCSetup::kDLLMode = 592 [static], [private]
5.16.4.9 const bit TDCSetup::kDLLTapAdjust0 = 459 [static], [private]
5.16.4.10 const bit TDCSetup::kEnableAutomaticReject = 125 [static], [private]
5.16.4.11 const bit TDCSetup::kEnableBytewise = 37 [static], [private]
5.16.4.12 const bit TDCSetup::kEnableDirectBunchReset = 157 [static], [private]
5.16.4.13 const bit TDCSetup::kEnableDirectEventReset = 156 [static], [private]
5.16.4.14 const bit TDCSetup::kEnableDirectTrigger = 158 [static], [private]
5.16.4.15 const bit TDCSetup::kEnableError = 6 [static], [private]
5.16.4.16 const bit TDCSetup::kEnableErrorBypass = 5 [static], [private]
5.16.4.17 const bit TDCSetup::kEnableErrorMark = 4 [static], [private]
5.16.4.18 const bit TDCSetup::kEnableGlobalHeader = 34 [static], [private]
5.16.4.19 const bit TDCSetup::kEnableGlobalTrailer = 33 [static], [private]
5.16.4.20 const bit TDCSetup::kEnableJTAGReadout = 39 [static], [private]
5.16.4.21 const bit TDCSetup::kEnableLocalHeader = 32 [static], [private]
```

```
5.16.4.22 const bit TDCSetup::kEnableLocalTrailer = 31 [static], [private]
5.16.4.23 const bit TDCSetup::kEnableMasterResetCode = 151 [static], [private]
5.16.4.24 const bit TDCSetup::kEnableMasterResetOnEventReset = 152 [static], [private]
5.16.4.25 const bit TDCSetup::kEnableMatching = 639 [static], [private]
5.16.4.26 const bit TDCSetup::kEnableOverflowDetect = 123 [static], [private]
5.16.4.27 const bit TDCSetup::kEnablePair = 640 [static], [private]
5.16.4.28 const bit TDCSetup::kEnableReadoutOccupancy = 121 [static], [private]
5.16.4.29 const bit TDCSetup::kEnableReadoutSeparator = 122 [static], [private]
5.16.4.30 const bit TDCSetup::kEnableRelative = 124 [static], [private]
5.16.4.31 const bit TDCSetup::kEnableResetChannelBufferWhenSeparator = 153 [static], [private]
5.16.4.32 const bit TDCSetup::kEnableSeparatorOnBunchReset = 155 [static], [private]
5.16.4.33 const bit TDCSetup::kEnableSeparatorOnEventReset = 154 [static], [private]
5.16.4.34 const bit TDCSetup::kEnableSerial = 38 [static], [private]
5.16.4.35 const bit TDCSetup::kEnableSetCountersOnBunchReset = 150 [static], [private]
5.16.4.36 const bit TDCSetup::kEnableTTLClock = 644 [static], [private]
5.16.4.37 const bit TDCSetup::kEnableTTLControl = 642 [static], [private]
5.16.4.38 const bit TDCSetup::kEnableTTLHit = 645 [static], [private]
5.16.4.39 const bit TDCSetup::kEnableTTLReset = 643 [static], [private]
5.16.4.40 const bit TDCSetup::kEnableTTLSerial = 641 [static], [private]
5.16.4.41 const bit TDCSetup::kEventCountOffset = 126 [static], [private]
5.16.4.42 const bit TDCSetup::klOClockDelay = 606 [static], [private]
5.16.4.43 const bit TDCSetup::klOClockSource = 620 [static], [private]
5.16.4.44 const bit TDCSetup::kKeepToken = 35 [static], [private]
5.16.4.45 const bit TDCSetup::kLeading = 589 [static], [private]
5.16.4.46 const bit TDCSetup::kLeadingResolution = 84 [static], [private]
5.16.4.47 const bit TDCSetup::kLowPowerMode = 570 [static], [private]
5.16.4.48 const bit TDCSetup::kMaster = 36 [static], [private]
5.16.4.49 const bit TDCSetup::kMatchWindow = 72 [static], [private]
```

```
5.16.4.50 const bit TDCSetup::kMaxEventSize = 116 [static], [private]
5.16.4.51 const bit TDCSetup::kModeRC = 591 [static], [private]
5.16.4.52 const bit TDCSetup::kModeRCCompression = 590 [static], [private]
5.16.4.53 const bit TDCSetup::kOffset0 = 438 [static], [private]
5.16.4.54 const bit TDCSetup::kPLLControl = 594 [static], [private]
5.16.4.55 const bit TDCSetup::kRCAdjust0 = 555 [static], [private]
5.16.4.56 const bit TDCSetup::kReadoutFIFOSize = 45 [static], [private]
5.16.4.57 const bit TDCSetup::kReadoutSingleCycleSpeed = 17 [static], [private]
5.16.4.58 const bit TDCSetup::kReadoutSpeedSelect = 26 [static], [private]
5.16.4.59 const bit TDCSetup::kRejectCountOffset = 48 [static], [private]
5.16.4.60 const bit TDCSetup::kRejectFlFOFull = 120 [static], [private]
5.16.4.61 const bit TDCSetup::kRollOver = 627 [static], [private]
5.16.4.62 const bit TDCSetup::kSearchWindow = 60 [static], [private]
5.16.4.63 const bit TDCSetup::kSelectBypassInputs = 44 [static], [private]
5.16.4.64 const bit TDCSetup::kSerialClockDelay = 602 [static], [private]
5.16.4.65 const bit TDCSetup::kSerialClockSource = 618 [static], [private]
5.16.4.66 const bit TDCSetup::kSerialDelay = 20 [static], [private]
5.16.4.67 const bit TDCSetup::kSetupParity = 646 [static], [private]
5.16.4.68 const bit TDCSetup::kStrobeSelect = 24 [static], [private]
5.16.4.69 const bit TDCSetup::kTDCld = 40 [static], [private]
5.16.4.70 const bit TDCSetup::kTestInvert = 586 [static], [private]
5.16.4.71 const bit TDCSetup::kTestMode = 587 [static], [private]
5.16.4.72 const bit TDCSetup::kTestSelect = 0 [static], [private]
5.16.4.73 const bit TDCSetup::kTokenDelay = 27 [static], [private]
5.16.4.74 const bit TDCSetup::kTrailing = 588 [static], [private]
5.16.4.75 const bit TDCSetup::kTriggerCountOffset = 138 [static], [private]
5.16.4.76 const bit TDCSetup::kVernierOffset = 575 [static], [private]
```

5.16.4.77 const bit TDCSetup::kWidthSelect = 571 [static], [private]


The documentation for this class was generated from the following files:

- · include/TDCSetup.h
- src/TDCSetup.cpp


# 5.17 TDCStatus Class Reference

#include <TDCStatus.h>

Inheritance diagram for TDCStatus:



Collaboration diagram for TDCStatus:



### **Public Member Functions**

- TDCStatus ()
- TDCStatus (const TDCStatus &s)
- void SetConstantValues ()

# **Static Private Attributes**

- static const bit kError = 0
- static const bit kHaveToken = 11

- static const bit kReadoutFIFOOccupancy = 12
- static const bit kReadoutFIFOFull = 20
- static const bit kReadoutFIFOEmpty = 21
- static const bit kL1Occupancy = 22
- static const bit kTriggerFIFOOccupancy = 54
- static const bit kTriggerFIFOFull = 58
- static const bit kTriggerFIFOEmpty = 59
- static const bit kDLLLock = 60

## **Additional Inherited Members**

# 5.17.1 Detailed Description

**Author** 

Laurent Forthomme laurent.forthomme@cern.ch

Date

27 Apr 2015

### 5.17.2 Constructor & Destructor Documentation


5.17.2.1 TDCStatus::TDCStatus() [inline]

Here is the call graph for this function:



# **5.17.2.2 TDCStatus::TDCStatus (const TDCStatus & s)** [inline]

Here is the call graph for this function:



## 5.17.3 Member Function Documentation

```
5.17.3.1 void TDCStatus::SetConstantValues() [inline], [virtual]
```

Ensure that the critical constant values are properly set in the register word Implements TDCRegister.

#### 5.17.4 Field Documentation

```
5.17.4.1 const bit TDCStatus::kDLLLock = 60 [static], [private]
5.17.4.2 const bit TDCStatus::kError = 0 [static], [private]
5.17.4.3 const bit TDCStatus::kHaveToken = 11 [static], [private]
5.17.4.4 const bit TDCStatus::kL1Occupancy = 22 [static], [private]
5.17.4.5 const bit TDCStatus::kReadoutFIFOEmpty = 21 [static], [private]
5.17.4.6 const bit TDCStatus::kReadoutFIFOFull = 20 [static], [private]
5.17.4.7 const bit TDCStatus::kReadoutFIFOOccupancy = 12 [static], [private]
5.17.4.8 const bit TDCStatus::kTriggerFIFOEmpty = 59 [static], [private]
5.17.4.9 const bit TDCStatus::kTriggerFIFOFull = 58 [static], [private]
5.17.4.10 const bit TDCStatus::kTriggerFIFOOccupancy = 54 [static], [private]
```

The documentation for this class was generated from the following file:

· include/TDCStatus.h

## 5.18 USBHandler Class Reference

Generic USB communication handler.

#include <USBHandler.h>

Inheritance diagram for USBHandler:



## **Public Member Functions**

- USBHandler (const char \*dev)
- USBHandler (const unsigned int vendor\_id, const unsigned int product\_id)
- virtual ∼USBHandler ()
- void Init ()
- · void Reset () const
- void DumpDevice (libusb device \*dev, int verb=1, std::ostream &out=std::cout)
- void Write (uint32\_t word, uint8\_t size) const

Write a word to the USB device.

• uint32\_t Fetch (uint8\_t size) const

Receive a word from the USB device.

## **Protected Attributes**

bool flsStopping

## **Private Attributes**

- std::string fDevice
- · unsigned int fVendorld

Device's vendor identifier.

· unsigned int fProductId

Device's product number.

libusb\_device\_handle \* fHandle

## 5.18.1 Detailed Description

Generic USB communication handler.

Date

21 Apr 2015

**Author** 

Laurent Forthomme laurent.forthomme@cern.ch

## 5.18.2 Constructor & Destructor Documentation

```
5.18.2.1 USBHandler::USBHandler (const char * dev)
```

5.18.2.2 USBHandler::USBHandler ( const unsigned int vendor\_id, const unsigned int product\_id )

**5.18.2.3 USBHandler::**~**USBHandler()** [virtual]

## 5.18.3 Member Function Documentation

5.18.3.1 void USBHandler::DumpDevice ( libusb\_device \* dev, int verb = 1, std::ostream & out = std::cout )

5.18.3.2 uint32\_t USBHandler::Fetch ( uint8\_t size ) const

Receive a word from the USB device.

```
5.18.3.3 void USBHandler::Init ( )
```

Pointer to a pointer of devices used to retrieve a list of them

A libusb session

Here is the call graph for this function:



```
5.18.3.4 void USBHandler::Reset ( ) const
```

5.18.3.5 void USBHandler::Write ( uint32\_t word, uint8\_t size ) const

Write a word to the USB device.

## 5.18.4 Field Documentation

```
5.18.4.1 std::string USBHandler::fDevice [private]
```

**5.18.4.2 libusb\_device\_handle\* USBHandler::fHandle** [private]

**5.18.4.3 bool USBHandler::flsStopping** [protected]

**5.18.4.4 unsigned int USBHandler::fProductId** [private]

Device's product number.

**5.18.4.5** unsigned int USBHandler::fVendorld [private]

Device's vendor identifier.

The documentation for this class was generated from the following files:

- · include/USBHandler.h
- · src/USBHandler.cpp



# Index

~Client	Client, 17
Client, 17	Connect, 18
~Exception	Disconnect, 18
Exception, 21	fClientId, 20
~FPGAHandler	flsConnected, 20
FPGAHandler, 27	GetType, 19
~FileReader	ParseMessage, 19
FileReader, 25	Receive, 19
~Message	Send, 19
Message, 33	SendAndReceive, 20
~Messenger	CloseFile
Messenger, 36	FPGAHandler, 28
~Socket	CoarseError
Socket, 43	HPTDC chip control, 11
~SocketMessage	Configure
SocketMessage, 52	Socket, 44
~TDC	Connect
TDC, 55	Client, 18
~TDCEvent	Messenger, 37
TDCEvent, 69	ControlParityError
~TDCRegister	HPTDC chip control, 11
TDCRegister, 73	Core aux clock
~USBHandler	HPTDC chip control, 10
USBHandler, 128	Core_clock_40
	HPTDC chip control, 10
AcceptConnections	Core_pll_clock_160
Socket, 43	HPTDC chip control, 10
AddClient	Core_pll_clock_80
Messenger, 36	HPTDC chip control, 10
Announce	CoreClockSource
Client, 17	HPTDC chip control, 10
	Create
Bind	Socket, 44
Socket, 44	
bit	DETECTOR
TDCRegister, 73	Socket communication objects, 8
Broadcast	DLL_160MHz
Messenger, 36	HPTDC chip control, 10
	DLL_320MHz
CLIENT	HPTDC chip control, 10
Socket communication objects, 8	DLL_40MHz
ChannelSelectError	HPTDC chip control, 10
HPTDC chip control, 11	DLL_Illegal
CheckFirmwareVersion	HPTDC chip control, 10
TDC, 56	DLL_aux_clock
Clear	HPTDC chip control, 10
TDCRegister, 74	DLL_clock_40
Client, 15	HPTDC chip control, 10
$\sim$ Client, 17	DLL_pll_clock_160
Announce, 17	HPTDC chip control, 10

DLL_pll_clock_320	E_6p25ns
HPTDC chip control, 10	HPTDC chip control, 11
DLL_pll_clock_40	E_800ps
HPTDC chip control, 10	HPTDC chip control, 11
DLLClockSource	EdgeResolution
HPTDC chip control, 10	HPTDC chip control, 10
DLLSpeedMode	EnableAllChannels
HPTDC chip control, 10	
•	TDCControl, 64
DT_100ns	EnableChannel
HPTDC chip control, 10	TDCControl, 64
DT_10ns	EnablePattern
HPTDC chip control, 10	HPTDC chip control, 11
DT_30ns	EnabledError
HPTDC chip control, 10	HPTDC chip control, 11
DT_5ns	Encode
HPTDC chip control, 10	HTTPMessage, 31
DeadTime	Error
HPTDC chip control, 10	HPTDC chip control, 11
Debug	ErrorNumber
HPTDC chip control, 11	
	Exception, 22
Decode	ErrorState
HTTPMessage, 31	FPGAHandler, 28
Description	EventType
Exception, 22	HPTDC chip control, 11
DisableAllChannels	Exception, 20
TDCControl, 63	$\sim$ Exception, 21
DisableChannel	Description, 22
TDCControl, 63	Dump, 22
Disconnect	ErrorNumber, 22
Client, 18	Exception, 21
Messenger, 37	fDescription, 22
DisconnectClient	fErrorNumber, 22
Messenger, 38	fFrom, 22
Dump	fType, 22
Exception, 22	From, 22
HTTPMessage, 31	Type, 22
Message, 33	TypeString, 22
SocketMessage, 52	fAddress
TDCControl, 64	
TDCSetup, 84	Socket, 47
DumpConnected	fBS
Socket, 44	TDC, 58
DumpDevice	fBuffer
USBHandler, 128	Socket, 47
DumpRegister	fClientId
TDCRegister, 74	Client, 20
120110g.oto1, 71	fControl
E_100ps	TDC, 58
HPTDC chip control, 11	fDescription
E_12p5ns	Exception, 22
HPTDC chip control, 11	fDevice
•	USBHandler, 129
E_1p6ns	
HPTDC chip control, 11	fErrorNumber
E_200ps	Exception, 22
HPTDC chip control, 11	fFile
E_3p12ns	FileReader, 25
HPTDC chip control, 11	fFilename
E_400ps	FPGAHandler, 29
HPTDC chip control, 11	fFrom

Exception, 22	Socket, 47
fHandle	fStatus
USBHandler, 129	TDC, 58
fHeader	fString
FileReader, 25	Message, 33
fld	fTDC
TDC, 58	FPGAHandler, 29
flsConnected	fType
Client, 20	Exception, 22
flsFileOpen	fUSB
FPGAHandler, 29	TDC, 58
flsStopping	fVendorld
USBHandler, 129	USBHandler, 129 fWS
flsTDCInReadout	HTTPMessage, 32
FPGAHandler, 29	Messenger, 41
fMaster	fWord
Socket, 47	TDCEvent, 71
fMessage	TDCRegister, 75
SocketMessage, 54	fWordSize
fNumAttempts	TDCRegister, 75
Messenger, 41 fNumWords	Fetch
	USBHandler, 128
TDCRegister, 75	FetchEvents
fOriginalString HTTPMessage, 32	TDC, 56
_	FetchMessage
fOutput FPGAHandler, 29	Socket, 44
FPGA board control, 7	file_header_t, 23
FPGAHandler, 25	magic, 23
~FPGAHandler, 27	num_hptdc, 23
CloseFile, 28	run_id, <mark>23</mark>
ErrorState, 28	spill_id, 23
fFilename, 29	FileReader, 23
flsFileOpen, 29	$\sim$ FileReader, 25
flsTDCInReadout, 29	fFile, 25
fOutput, 29	fHeader, 25
FPGAHandler, 27	fSetupCollection, 25
fTDC, 29	FileReader, 24
GetFilename, 28	GetNextEvent, 25
GetTDC, 28	GetNumTDCs, 25
GetType, 28	From
OpenFile, 28	Exception, 22
ReadBuffer, 28	GetBits
SetTDCSetup, 29	TDCRegister, 74
Stop, 29	GetBunchld
fPort	TDCEvent, 69
Socket, 47	GetChannelOffset
fProductId	TDCSetup, 85
USBHandler, 129	GetCoarseCountOffset
fReadFds	TDCSetup, 85
Socket, 47	GetDLLAdjustment
fSetup	TDCSetup, 86
TDC, 58	GetDLLReset
fSetupCollection	TDCControl, 64
FileReader, 25	GetDeadTime
fSocketId	TDCSetup, 86
Socket, 47	GetEdgeResolution
fSocketsConnected	TDCSetup, 86

GetEdgesPairing	GetSearchWindow
TDCSetup, 87	TDCSetup, 92
GetEnableError	GetSetupParity
TDCSetup, 87	TDCSetup, 92
GetEnableErrorBypass	GetSetupRegister
TDCSetup, 87	TDC, 56
GetEnableErrorMark	GetSocketId
	Socket, 45
TDCSetup, 88	
GetEnableJTAGReadout	GetSocketType
TDCSetup, 88	Socket, 45
GetEnablePattern	GetString
TDCControl, 65	Message, 33
GetEnableReadoutOccupancy	SocketMessage, 52
TDCSetup, 88	GetTDC
GetEnableReadoutSeparator	FPGAHandler, 28
TDCSetup, 89	GetTDCld
GetEnableSerial	TDCEvent, 70
TDCSetup, 89	GetTestInvert
GetErrorFlags	TDCSetup, 92
TDCEvent, 69	GetTestMode
GetEventId	TDCSetup, 93
TDCEvent, 69	GetTrailingMode
GetFilename	TDCSetup, 93
FPGAHandler, 28	GetTrailingTime
GetGlobalReset	TDCEvent, 70
TDCControl, 65	GetTriggerCountOffset
GetIntValue	TDCSetup, 93
SocketMessage, 52	GetTriggerLatency
GetKey	TDCSetup, 94
HTTPMessage, 31	GetTriggerMatchingMode
Message, 33	TDCSetup, 94
	GetType
SocketMessage, 52	Client, 19
GetLeadingMode	FPGAHandler, 28
TDCSetup, 89	Messenger, 38
GetLeadingTime	TDCEvent, 70
TDCEvent, 70	GetValue
GetMatchWindow	SocketMessage, 52
TDCSetup, 90	GetVectorValue
GetMaxEventSize	SocketMessage, 52
TDCSetup, 90	GetVernierOffset
GetNextEvent	TDCSetup, 94
FileReader, 25	GetWidth
GetNumTDCs	TDCEvent, 71
FileReader, 25	GetWidthResolution
GetNumWords	TDCSetup, 95
TDCRegister, 74	GetWord
GetPLLReset	TDCRegister, 74
TDCControl, 65	GetWordCount
GetPort	TDCEvent, 71
Socket, 44	GroupHeader
GetRCAdjustment	HPTDC chip control, 11
TDCSetup, 90	GroupTrailer
GetReadoutFIFOSize	HPTDC chip control, 11
TDCSetup, 91	The TDO chilp control, TT
GetRejectCountOffset	HPTDC chip control, 9
TDCSetup, 91	ChannelSelectError, 11
GetRejectFIFOFull	CoarseError, 11
TDCSetup, 91	ControlParityError, 11
. = 00010p, 01	control any Ellor, 11

Core_aux_clock, 10	RSC_5Mbits_s, 12
Core clock 40, 10	RSC 625kbits s, 12
Core_pll_clock_160, 10	ReadoutFIFOParityError, 11
Core_pll_clock_80, 10	ReadoutSingleCycleSpeed, 12
CoreClockSource, 10	ReadoutSpeed, 12
DLL_160MHz, 10	ReadoutStateError, 11
DLL_320MHz, 10	RegisterName, 12
DLL 40MHz, 10	SS DSStrobe, 13
DLL_Illegal, 10	SS LeadingEdge, 13
DLL_aux_clock, 10	SS_LeadingTrailingStrobe, 13
DLL_clock_40, 10	SS_NoStrobe, 13
DLL_pll_clock_160, 10	Serial_aux_clock, 12
DLL_pll_clock_320, 10	Serial_pll_clock_160, 12
DLL_pll_clock_40, 10	Serial_pll_clock_40, 12
DLLClockSource, 10	Serial_pll_clock_80, 12
DLLSpeedMode, 10	SerialClockSource, 12
DT_100ns, 10	SerialStrobeType, 12
DT_10ns, 10	SetupParityError, 11
	TDCHeader, 11
DT_30ns, 10	TDCTrailer, 11
DT_5ns, 10	TrailingEdge, 11
DeadTime, 10	<b>5 5</b> •
Debug, 11	TriggerFIFOParityError, 11
E_100ps, 11	TriggerMatchingError, 11
E_12p5ns, 11	VernierError, 11
E_1p6ns, 11	W_100ns, 13
E_200ps, 11	W_100ps, 13
E_3p12ns, 11	W_12p5ns, 13
E_400ps, 11	W_1p6ns, 13
	W_200ns, 13
E_6p25ns, 11	W_200ps, 13
E_800ps, 11	W_25ns, 13
EdgeResolution, 10	W_3p2ns, 13
EnablePattern, 11	_ ·
EnabledError, 11	W_400ns, 13
Error, 11	W_400ps, 13
EventType, 11	W_50ns, 13
GroupHeader, 11	W_6p25ns, 13
GroupTrailer, 11	W_800ns, 13
IO aux clock, 12	W_800ps, 13
	WidthResolution, 13
IO_clock_40, 12	HTTPMessage, 29
IO_pll_clock_160, 12	Decode, 31
IO_pll_clock_80, 12	Dump, 31
IOClockSource, 11	Encode, 31
Invalid, 11	fOriginalString, 32
JTAGInstructionParityError, 11	•
L1BufferParityError, 11	fWS, 32
LeadingEdge, 11	GetKey, 31
R DLLReset, 12	HTTPMessage, 31
<del>-</del>	IND /AL ID
R_EnablePattern, 12	INVALID
R_GlobalReset, 12	Socket communication objects, 8
R_PLLReset, 12	IO_aux_clock
RO_Fixed, 12	HPTDC chip control, 12
RO_pll_80Mbits_s, 12	IO_clock_40
RSC_10Mbits_s, 12	HPTDC chip control, 12
RSC_1p25Mbits_s, 12	IO_pll_clock_160
RSC_20Mbits_s, 12	HPTDC chip control, 12
RSC_2p5Mbits_s, 12	IO_pll_clock_80
RSC_312p5kbits_s, 12	HPTDC chip control, 12
	·
RSC_40Mbits_s, 12	IOClockSource

HPTDC abin control 11	k Enghlo Error Dynasa
HPTDC chip control, 11 Init	kEnableErrorBypass
-	TDCSetup, 122
USBHandler, 128	kEnableErrorMark
Invalid	TDCSetup, 122
HPTDC chip control, 11	kEnableGlobalHeader
IsFromWeb	TDCSetup, 122
Message, 33	kEnableGlobalTrailer
IsWebSocket	TDCSetup, 122
Socket, 45	kEnableJTAGReadout
	TDCSetup, 122
JTAGInstructionParityError	kEnableLocalHeader
HPTDC chip control, 11	TDCSetup, 122
	kEnableLocalTrailer
kAuxClock	TDCSetup, 122
TDCBoundaryScan, 60	kEnableMasterResetCode
kBunchReset	TDCSetup, 123
TDCBoundaryScan, 60	kEnableMasterResetOnEventReset
kClk	TDCSetup, 123
TDCBoundaryScan, 60	kEnableMatching
kCoarseCountOffset	•
TDCSetup, 122	TDCSetup, 123
kControlParity	kEnableOverflowDetect
TDCControl, 67	TDCSetup, 123
kCoreClockDelay	kEnablePair
TDCSetup, 122	TDCSetup, 123
kCoreClockSource	kEnablePattern
TDCSetup, 122	TDCControl, 67
kDLLClockDelay	kEnableReadoutOccupancy
TDCSetup, 122	TDCSetup, 123
kDLLClockSource	kEnableReadoutSeparator
TDCSetup, 122	TDCSetup, 123
•	kEnableRelative
kDLLControl	TDCSetup, 123
TDCSetup, 122	kEnableResetChannelBufferWhenSeparator
kDLLLock	TDCSetup, 123
TDCStatus, 127	kEnableSeparatorOnBunchReset
kDLLMode	TDCSetup, 123
TDCSetup, 122	
kDLLReset	kEnableSeparatorOnEventReset
TDCControl, 67	TDCSetup, 123
kDLLTapAdjust0	kEnableSerial
TDCSetup, 122	TDCSetup, 123
kDataReady	kEnableSetCountersOnBunchReset
TDCBoundaryScan, 60	TDCSetup, 123
kDeadTime	kEnableTTLClock
TDCSetup, 122	TDCSetup, 123
kEnableAutomaticReject	kEnableTTLControl
TDCSetup, 122	TDCSetup, 123
kEnableBytewise	kEnableTTLHit
TDCSetup, 122	TDCSetup, 123
kEnableChannel	kEnableTTLReset
TDCControl, 67	TDCSetup, 123
kEnableDirectBunchReset	kEnableTTLSerial
TDCSetup, 122	TDCSetup, 123
kEnableDirectEventReset	kEncodedControl
TDCSetup, 122	TDCBoundaryScan, 60
• •	kError
kEnableDirectTrigger	
TDCSetup, 122	TDCBoundaryScan, 60
kEnableError	TDCStatus, 127
TDCSetup, 122	kEventCountOffset

TDCSetup, 123	TDCSetup, 124
kEventReset	kRejectCountOffset
TDCBoundaryScan, 60	TDCSetup, 124
kGetData	kRejectFIFOFull
TDCBoundaryScan, 61	TDCSetup, 124
kGlobalReset	kReset
TDCControl, 67	TDCBoundaryScan, 61
kHaveToken	kRollOver
TDCStatus, 127	TDCSetup, 124
kHit	kSearchWindow
TDCBoundaryScan, 61	TDCSetup, 124
klOClockDelay	kSelectBypassInputs
TDCSetup, 123	TDCSetup, 124
klOClockSource	kSerialBypassIn
TDCSetup, 123	TDCBoundaryScan, 61
kKeepToken	kSerialClockDelay
TDCSetup, 123	TDCSetup, 124
kL1Occupancy	kSerialClockSource
TDCStatus, 127	TDCSetup, 124
kLeading	kSerialDelay
TDCSetup, 123	TDCSetup, 124
kLeadingResolution	kSerialIn
TDCSetup, 123	TDCBoundaryScan, 61
kLowPowerMode	kSerialOut
TDCSetup, 123	TDCBoundaryScan, 61
kMaster	kSetupParity
TDCSetup, 123	TDCSetup, 124
kMatchWindow	kStrobeOut
TDCSetup, 123	TDCBoundaryScan, 61
kMaxEventSize	kStrobeSelect
TDCSetup, 123	TDCSetup, 124
kModeRC	kTDCId
TDCSetup, 124	TDCSetup, 124
·	kTest
kModeRCCompression	
TDCSetup, 124 kOffset0	TDCBoundaryScan, 61
	kTestInvert
TDCSetup, 124	TDCSetup, 124
kPLLControl	kTestMode
TDCSetup, 124	TDCSetup, 124
kPLLReset	kTestSelect
TDCControl, 67	TDCSetup, 124
kParallelDataOut	kTokenBypassIn
TDCBoundaryScan, 61	TDCBoundaryScan, 61
kParallelEnable	kTokenDelay
TDCBoundaryScan, 61	TDCSetup, 124
kRCAdjust0	kTokenIn
TDCSetup, 124	TDCBoundaryScan, 61
kReadoutFIFOEmpty	kTokenOut
TDCStatus, 127	TDCBoundaryScan, 61
kReadoutFIFOFull	kTrailing
TDCStatus, 127	TDCSetup, 124
kReadoutFIFOOccupancy	kTrigger
TDCStatus, 127	TDCBoundaryScan, 61
kReadoutFIFOSize	kTriggerCountOffset
TDCSetup, 124	TDCSetup, 124
kReadoutSingleCycleSpeed	kTriggerFIFOEmpty
TDCSetup, 124	TDCStatus, 127
kReadoutSpeedSelect	kTriggerFIFOFull

TDCStatus, 127 kTriggerFIFOOccupancy	ProcessMessage Messenger, 38
TDCStatus, 127	
kVernierOffset	R_DLLReset
TDCSetup, 124	HPTDC chip control, 12
kWidthSelect	R_EnablePattern
TDCSetup, 124	HPTDC chip control, 12
	R_GlobalReset
L1BufferParityError	HPTDC chip control, 12
HPTDC chip control, 11	R_PLLReset
LeadingEdge	HPTDC chip control, 12
HPTDC chip control, 11	RO_Fixed
Listen	HPTDC chip control, 12
Socket, 45	RO_pll_80Mbits_s
Gooder, 10	HPTDC chip control, 12
MASTER	RSC_10Mbits_s
Socket communication objects, 8	HPTDC chip control, 12
magic	RSC_1p25Mbits_s
	HPTDC chip control, 12
file_header_t, 23	RSC_20Mbits_s
Message, 32	
~Message, 33	HPTDC chip control, 12
Dump, 33	RSC_2p5Mbits_s
fString, 33	HPTDC chip control, 12
GetKey, 33	RSC_312p5kbits_s
GetString, 33	HPTDC chip control, 12
IsFromWeb, 33	RSC_40Mbits_s
Message, 33	HPTDC chip control, 12
Messenger, 34	RSC_5Mbits_s
$\sim$ Messenger, 36	HPTDC chip control, 12
AddClient, 36	RSC_625kbits_s
Broadcast, 36	HPTDC chip control, 12
Connect, 37	ReadBuffer
Disconnect, 37	FPGAHandler, 28
DisconnectClient, 38	ReadConfiguration
fNumAttempts, 41	TDC, 56
fWS, 41	ReadRegister
GetType, 38	TDC, 56
Messenger, 35	ReadStatus
ProcessMessage, 38	TDC, 57
Receive, 39	ReadoutFIFOParityError
	HPTDC chip control, 11
Send, 39	ReadoutSingleCycleSpeed
StartAcquisition, 40	HPTDC chip control, 12
StopAcquisition, 40	
SwitchClientType, 40	ReadoutSpeed
	HPTDC chip control, 12
num_hptdc	ReadoutStateError
file_header_t, 23	HPTDC chip control, 11
	Receive
Object	Client, 19
SocketMessage, 53	Messenger, 39
OpenFile	RegisterName
FPGAHandler, 28	HPTDC chip control, 12
operator=	Reset
TDCRegister, 74	USBHandler, 129
	run_id
ParseMessage	file_header_t, 23
Client, 19	
PrepareConnection	SS_DSStrobe
Socket, 45	HPTDC chip control, 13

SS_LeadingEdge	TDCSetup, 99
HPTDC chip control, 13	SetDLLControl
SS_LeadingTrailingStrobe	TDCSetup, 99
HPTDC chip control, 13	SetDLLMode
SS_NoStrobe	TDCSetup, 100
HPTDC chip control, 13	SetDLLReset
SelectConnections	TDCControl, 66
Socket, 45	SetDeadTime
Send	TDCSetup, 98
Client, 19	SetEdgeResolution
•	•
Messenger, 39	TDCSetup, 100
SendAndReceive	SetEdgesPairing
Client, 20	TDCSetup, 100
SendConfiguration	SetEnableAutomaticReject
TDC, 57	TDCSetup, 101
SendMessage	SetEnableBytewise
Socket, 46	TDCSetup, 101
Serial_aux_clock	SetEnableDirectBunchReset
HPTDC chip control, 12	TDCSetup, 101
Serial_pll_clock_160	SetEnableDirectEventReset
HPTDC chip control, 12	TDCSetup, 102
Serial_pll_clock_40	SetEnableDirectTrigger
HPTDC chip control, 12	TDCSetup, 102
	• •
Serial_pll_clock_80	SetEnableError
HPTDC chip control, 12	TDCSetup, 102
SerialClockSource	SetEnableErrorBypass
HPTDC chip control, 12	TDCSetup, 103
SerialStrobeType	SetEnableErrorMark
HPTDC chip control, 12	TDCSetup, 103
SetAllChannelsOffset	SetEnableGlobalHeader
TDCSetup, 95	TDCSetup, 103
SetAllTapsDLLAdjustment	SetEnableGlobalTrailer
TDCSetup, 95	TDCSetup, 104
SetBits	SetEnableJTAGReadout
TDCRegister, 74	TDCSetup, 104
SetBypassInputs	SetEnableLocalHeader
	TDCSetup, 104
TDCSetup, 95 SetChannelOffset	SetEnableLocalTrailer
TDCSetup, 96	TDCSetup, 105
SetCoarseCountOffset	SetEnableMasterResetCode
TDCSetup, 96	TDCSetup, 105
SetConstantValues	SetEnableMasterResetOnEventReset
TDCBoundaryScan, 60	TDCSetup, 105
TDCControl, 66	SetEnableOverflowDetect
TDCRegister, 74	TDCSetup, 106
TDCSetup, 96	SetEnablePattern
TDCStatus, 126	TDCControl, 67
SetControlParity	SetEnableReadoutOccupancy
TDCControl, 66	TDCSetup, 106
SetCoreClockDelay	SetEnableReadoutSeparator
TDCSetup, 97	TDCSetup, 106
•	·
SetCoreClockSource	SetEnableRelative
TDCSetup, 98	TDCSetup, 107
SetDLLAdjustment	SetEnableResetChannelBufferWhenSeparator
TDCSetup, 98	TDCSetup, 107
SetDLLClockDelay	SetEnableSeparatorOnBunchReset
TDCSetup, 99	TDCSetup, 107
SetDLLClockSource	SetEnableSeparatorOnEventReset

TDCSetup, 108	TDCSetup, 116
SetEnableSerial	SetRollOver
TDCSetup, 108	TDCSetup, 117
SetEnableSetCountersOnBunchReset	SetSearchWindow
TDCSetup, 108	TDCSetup, 117
SetEnableTTLClock	SetSerialClockDelay
TDCSetup, 109	TDCSetup, 117
SetEnableTTLControl	SetSerialClockSource
TDCSetup, 109	TDCSetup, 118
SetEnableTTLHit	SetSerialDelay
TDCSetup, 109	TDCSetup, 118
SetEnableTTLReset	SetSetupParity
TDCSetup, 110	TDCSetup, 118
SetEnableTTLSerial	SetSetupRegister
TDCSetup, 110	TDC, 57
SetEventCountOffset	· ·
	SetSocketId
TDCSetup, 111	Socket, 46
SetGlobalReset	SetStrobeSelect
TDCControl, 67	TDCSetup, 119
SetIOClockDelay	SetTDCSetup
TDCSetup, 111	FPGAHandler, 29
SetIOClockSource	SetTestInvert
TDCSetup, 111	TDCSetup, 119
SetKeepToken	SetTestMode
TDCSetup, 112	TDCSetup, 119
SetKeyValue	SetTokenDelay
SocketMessage, 53, 54	TDCSetup, 120
SetLeadingMode	SetTrailingMode
TDCSetup, 112	TDCSetup, 120
SetLowPowerMode	SetTriggerCountOffset
TDCSetup, 112	TDCSetup, 120
SetMaster	SetTriggerMatchingMode
TDCSetup, 113	TDCSetup, 121
SetMatchWindow	SetVernierOffset
TDCSetup, 113	TDCSetup, 121
SetMaxEventSize	SetWidthResolution
TDCSetup, 113	TDCSetup, 121
SetModeRC	SetWord
TDCSetup, 114	TDCEvent, 71
SetModeRCCompression	TDCRegister, 74
TDCSetup, 114	SetupParityError
SetPLLControl	HPTDC chip control, 11
TDCSetup, 114	Socket, 41
SetPLLReset	$\sim$ Socket, 43
TDCControl, 67	AcceptConnections, 43
SetPort	Bind, 44
Socket, 46	Configure, 44
SetRCAdjustment	Create, 44
TDCSetup, 115	DumpConnected, 44
SetReadoutFIFOSize	fAddress, 47
TDCSetup, 115	fBuffer, 47
SetReadoutSingleCycleSpeed	fMaster, 47
	fPort, 47
TDCSetup, 115	
SetReadoutSpeedSelect	fReadFds, 47
TDCSetup, 116	fSocketId, 47
SetRejectCountOffset	fSocketsConnected, 47
TDCSetup, 116	FetchMessage, 44
SetRejectFIFOFull	GetPort, 44

GetSocketId, 45	fControl, 58
GetSocketType, 45	fld, 58
IsWebSocket, 45	fSetup, 58
Listen, 45	fStatus, 58
PrepareConnection, 45	fUSB, 58
SelectConnections, 45	FetchEvents, 56
SendMessage, 46	GetSetupRegister, 56
SetPort, 46	ReadConfiguration, 56
SetSocketId, 46	ReadRegister, 56
Socket, 43	ReadStatus, 57
SocketCollection, 43	SendConfiguration, 57
Start, 46	SetSetupRegister, 57
Stop, 46	SoftReset, 57
Socket communication objects, 8	TDC, 55
CLIENT, 8	WriteRegister, 57
DETECTOR, 8	TDCBoundaryScan, 58
INVALID, 8	kAuxClock, 60
MASTER, 8	kBunchReset, 60
SocketType, 8	kClk, 60
WEBSOCKET_CLIENT, 8	kDataReady, 60
SocketCollection	kEncodedControl, 60
Socket, 43	kError, 60
SocketMessage, 47	kEventReset, 60
~SocketMessage, 52	kGetData, 61
Dump, 52	kHit, 61
fMessage, 54	kParallelDataOut, 61
GetIntValue, 52	
GetKey, 52	kParallelEnable, 61
GetString, 52	kReset, 61
GetValue, 52	kSerialBypassIn, 61
GetVectorValue, 52	kSerialIn, 61
Object, 53	kSerialOut, 61
SetKeyValue, 53, 54	kStrobeOut, 61
SocketMessage, 49–51	kTest, 61
String, 54	kTokenBypassIn, 61
SocketType	kTokenIn, 61
Socket communication objects, 8	kTokenOut, 61
SoftReset	kTrigger, 61
TDC, 57	SetConstantValues, 60
spill_id	TDCBoundaryScan, 60
file_header_t, 23	TDCControl, 61
Start	DisableAllChannels, 63
Socket, 46	DisableChannel, 63
StartAcquisition	Dump, 64
Messenger, 40	EnableAllChannels, 64
Stop	EnableChannel, 64
FPGAHandler, 29	GetDLLReset, 64
Socket, 46	GetEnablePattern, 65
StopAcquisition	GetGlobalReset, 65
Messenger, 40	GetPLLReset, 65
String	kControlParity, 67
SocketMessage, 54	kDLLReset, 67
SwitchClientType	kEnableChannel, 67
Messenger, 40	kEnablePattern, 67
<b>3</b> ,	kGlobalReset, 67
TDC, 54	kPLLReset, 67
$\sim$ TDC, 55	SetConstantValues, 66
CheckFirmwareVersion, 56	SetControlParity, 66
fBS, 58	SetDLLReset, 66

Cat Final la Dattavia C7	Cat Dais at EIECE VIII 01
SetEnablePattern, 67	GetRejectFIFOFull, 91
SetGlobalReset, 67	GetSearchWindow, 92
SetPLLReset, 67	GetSetupParity, 92
TDCControl, 63	GetTestNede 02
TDCEvent, 68	GetTestMode, 93
~TDCEvent, 69	GetTrailingMode, 93
fWord, 71	GetTriggerCountOffset, 93
GetBunchId, 69	GetTriggerLatency, 94
GetErrorFlags, 69	GetTriggerMatchingMode, 94
GetEventId, 69	GetVernierOffset, 94
GetLeadingTime, 70	GetWidthResolution, 95
GetTDCld, 70	kCoarseCountOffset, 122
GetTrailingTime, 70	kCoreClockDelay, 122
GetType, 70	kCoreClockSource, 122
GetWidth, 71	kDLLClockDelay, 122
GetWordCount, 71	kDLLClockSource, 122
SetWord, 71	kDLLControl, 122
TDCEvent, 69	kDLLMode, 122
TDCHeader	kDLLTapAdjust0, 122
HPTDC chip control, 11	kDeadTime, 122
TDCRegister, 71	kEnableAutomaticReject, 122
$\sim$ TDCRegister, 73	kEnableBytewise, 122
bit, 73	kEnableDirectBunchReset, 122
Clear, 74	kEnableDirectEventReset, 122
DumpRegister, 74	kEnableDirectTrigger, 122
fNumWords, 75	kEnableError, 122
fWord, 75	kEnableErrorBypass, 122
fWordSize, 75	kEnableErrorMark, 122
GetBits, 74	kEnableGlobalHeader, 122
GetNumWords, 74	kEnableGlobalTrailer, 122
GetWord, 74	kEnableJTAGReadout, 122
operator=, 74	kEnableLocalHeader, 122
SetBits, 74	kEnableLocalTrailer, 122
SetConstantValues, 74	kEnableMasterResetCode, 123
SetWord, 74	kEnableMasterResetOnEventReset, 123
TDCRegister, 73	kEnableMatching, 123
word_t, 73	kEnableOverflowDetect, 123
TDCSetup, 75	kEnablePair, 123
Dump, 84	kEnableReadoutOccupancy, 123
GetChannelOffset, 85	kEnableReadoutSeparator, 123
GetCoarseCountOffset, 85	kEnableRelative, 123
GetDLLAdjustment, 86	kEnableResetChannelBufferWhenSeparator, 123
GetDeadTime, 86	kEnableSeparatorOnBunchReset, 123
GetEdgeResolution, 86	kEnableSeparatorOnEventReset, 123
GetEdgesPairing, 87	kEnableSerial, 123
GetEnableError, 87	kEnableSetCountersOnBunchReset, 123
GetEnableErrorBypass, 87	kEnableTTLClock, 123
• •	
GetEnableErrorMark, 88	kEnableTTLControl, 123
GetEnableJTAGReadout, 88	kEnableTTLHit, 123
GetEnableReadoutOccupancy, 88	kEnableTTLReset, 123
GetEnableReadoutSeparator, 89	kEnableTTLSerial, 123
GetEnableSerial, 89	kEventCountOffset, 123
GetLeadingMode, 89	klOClockDelay, 123
GetMatchWindow, 90	kIOClockSource, 123
GetMaxEventSize, 90	kKeepToken, 123
GetRCAdjustment, 90	kLeading, 123
GetReadoutFIFOSize, 91	kLeadingResolution, 123
GetRejectCountOffset, 91	kLowPowerMode, 123

kMaster, 123	SetEnableLocalTrailer, 105
kMatchWindow, 123	SetEnableMasterResetCode, 105
kMaxEventSize, 123	SetEnableMasterResetOnEventReset, 105
kModeRC, 124	SetEnableOverflowDetect, 106
kModeRCCompression, 124	SetEnableReadoutOccupancy, 106
kOffset0, 124	SetEnableReadoutSeparator, 106
kPLLControl, 124	SetEnableRelative, 107
kRCAdjust0, 124	SetEnableResetChannelBufferWhenSeparator
kReadoutFIFOSize, 124	107
kReadoutSingleCycleSpeed, 124	SetEnableSeparatorOnBunchReset, 107
kReadoutSpeedSelect, 124	SetEnableSeparatorOnEventReset, 108
kRejectCountOffset, 124	SetEnableSerial, 108
kRejectFIFOFull, 124	SetEnableSetCountersOnBunchReset, 108
kRollOver, 124	SetEnableTTLClock, 109
kSearchWindow, 124	SetEnableTTLControl, 109
kSelectBypassInputs, 124	SetEnableTTLHit, 109
kSerialClockDelay, 124	SetEnableTTLReset, 110
kSerialClockSource, 124	SetEnableTTLSerial, 110
kSerialDelay, 124	SetEventCountOffset, 111
kSetupParity, 124	SetIOClockDelay, 111
kStrobeSelect, 124	SetIOClockSource, 111
kTDCld, 124	SetKeepToken, 112
kTestInvert, 124	SetLeadingMode, 112
kTestMode, 124	SetLowPowerMode, 112
kTestSelect, 124	SetMaster, 113
kTokenDelay, 124	SetMatchWindow, 113
kTrailing, 124	SetMaxEventSize, 113
kTriggerCountOffset, 124	SetModeRC, 114
kVernierOffset, 124	SetModeRCCompression, 114
kWidthSelect, 124	SetPLLControl, 114
SetAllChannelsOffset, 95	SetRCAdjustment, 115
SetAllTapsDLLAdjustment, 95	SetReadoutFIFOSize, 115
SetBypassInputs, 95	SetReadoutSingleCycleSpeed, 115
SetChannelOffset, 96	SetReadoutSpeedSelect, 116
SetCoarseCountOffset, 96	SetRejectCountOffset, 116
SetConstantValues, 96	SetRejectFIFOFull, 116
SetCoreClockDelay, 97	SetRollOver, 117
SetCoreClockSource, 98	SetSearchWindow, 117
SetDLLAdjustment, 98	SetSerialClockDelay, 117
SetDLLClockDelay, 99	SetSerialClockSource, 118
SetDLLClockSource, 99	SetSerialDelay, 118
SetDLLControl, 99	SetSetupParity, 118
SetDLLMode, 100	SetStrobeSelect, 119
SetDeadTime, 98	SetTestInvert, 119
SetEdgeResolution, 100	SetTestMode, 119
SetEdgesPairing, 100	SetTokenDelay, 120
SetEnableAutomaticReject, 101	SetTrailingMode, 120
SetEnableBytewise, 101	SetTriggerCountOffset, 120
SetEnableDirectBunchReset, 101	SetTriggerMatchingMode, 121
SetEnableDirectEventReset, 102	SetVernierOffset, 121
SetEnableDirectTrigger, 102	SetWidthResolution, 121
SetEnableError, 102	TDCSetup, 82, 83
SetEnableErrorBypass, 103	TDCStatus, 125
SetEnableErrorMark, 103	kDLLLock, 127
SetEnableGlobalHeader, 103	kError, 127
SetEnableGlobalTrailer, 104	kHaveToken, 127
SetEnableJTAGReadout, 104	kL1Occupancy, 127
SetEnableLocalHeader, 104	kReadoutFIFOEmpty, 127

kReadoutFIFOFull, 127 kReadoutFIFOOccupancy, 127 kTriggerFIFOEmpty, 127 kTriggerFIFOFull, 127 kTriggerFIFOOccupancy, 127 SetConstantValues, 126 TDCStatus, 126 TDCTrailer HPTDC chip control, 11 TrailingEdge HPTDC chip control, 11 TriggerFIFOParityError HPTDC chip control, 11 TriggerMatchingError HPTDC chip control, 11 TriggerMatchingError HPTDC chip control, 11 Type Exception, 22 TypeString	W_6p25ns     HPTDC chip control, 13 W_800ns     HPTDC chip control, 13 W_800ps     HPTDC chip control, 13 WEBSOCKET_CLIENT     Socket communication objects, 8 WidthResolution     HPTDC chip control, 13 word_t     TDCRegister, 73 Write     USBHandler, 129 WriteRegister     TDC, 57
Exception, 22	
USBHandler, 127  ~USBHandler, 128  DumpDevice, 128  fDevice, 129  fHandle, 129  fIsStopping, 129  fProductId, 129  fVendorId, 129  Fetch, 128  Init, 128  Reset, 129  USBHandler, 128  Write, 129	
VernierError HPTDC chip control, 11	
W_100ns HPTDC chip control, 13 W_100ps HPTDC chip control, 13 W_12p5ns HPTDC chip control, 13 W_1p6ns HPTDC chip control, 13 W_200ns HPTDC chip control, 13 W_200ps HPTDC chip control, 13 W_25ns HPTDC chip control, 13 W_25ns HPTDC chip control, 13 W_3p2ns HPTDC chip control, 13 W_400ns HPTDC chip control, 13 W_400ns HPTDC chip control, 13 W_400ps HPTDC chip control, 13	
W 50ne	

HPTDC chip control, 13