NetXPTO - LinkPlanner

12 de Julho de 2017

# Conteúdo

| T | Introduction                      | 2        |
|---|-----------------------------------|----------|
| 2 | Simulator Structure 2.1 System    | <b>3</b> |
| 3 | Library                           | 4        |
| 4 | Visualizer                        | 5        |
| 5 | Case Studies 5.1 QPSK Transmitter | <b>6</b> |
| 6 | Development Cycle                 | 11       |

# Introduction

## **Simulator Structure**

LinkPlanner is a signals open-source simulator.

The major entity is the system.

A system comprises a set of blocks.

The blocks interact with each other through signals.

## 2.1 System

The System is

Library

Visualizer

### **Case Studies**

### 5.1 QPSK Transmitter

This system simulates a QPSK transmitter. A schematic representation of this system is shown in figure 5.1.



Figura 5.1: QPSK transmitter block diagram.

#### **System Input Parameters**

Parameter: sourceMode

**Description:** Specifies the operation mode of the binary source.

Accepted Values: PseudoRandom, Random, DeterministicAppendZeros, DeterministicCyclic.

**Parameter:** patternLength

**Description:** Specifies the pattern length used my the source in the PseudoRandom mode.

Accepted Values: Integer between 1 and 32.

Parameter: bitStream

Description: Specifies the bit stream generated by the source in the DeterministicCyclic and

DeterministicAppendZeros mode.

**Accepted Values:** "XXX..", where X is 0 or 1.

**Parameter:** bitPeriod

**Description:** Specifies the bit period, i.e. the inverse of the bit-rate.

**Accepted Values:** Any positive real value.

**Parameter:** *iqAmplitudes* 

**Description:** Specifies the IQ amplitudes.

**Accepted Values:** Any four par of real values, for instance  $\{\{1,1\},\{-1,1\},\{-1,-1\},\{1,-1\}\}\$ , the first

value correspond to the "00", the second to the "01", the third to the "10" and

the forth to the "11".

Parameter: numberOfBits

**Description:** Specifies the number of bits generated by the binary source.

**Accepted Values:** Any positive integer value.

Parameter: numberOfSamplesPerSymbol

**Description:** Specifies the number of samples per symbol.

**Accepted Values:** Any positive integer value.

**Parameter:** rollOffFactor

**Description:** Specifies the roll off factor in the raised-cosine filter.

**Accepted Values:** A real value between 0 and 1.

Parameter: impulseResponseTimeLength

**Description:** Specifies the impulse response window time width in symbol periods.

Accepted Values: Any positive integer value.

#### **Functional description**

This block generates an optical signal (output signal 1 in figure ??). The binary signal generated in the internal block Binary Source (block B1 in figure ??) can be used to perform a Bit Error Rate (BER) measurement and in that sense it works as an extra output signal (output signal 2 in figure ??).

#### Input parameters

This block has a special set of functions that allow the user to change the basic configuration of the transmitter. The list of input parameters, functions used to change them and the values that each one can take are summarized in table 5.1.

| Input parameters             | Function                  | Туре   | Accepted values   |
|------------------------------|---------------------------|--|---|
| Mode                         | setMode()                 | string                                       | PseudoRandom Random DeterministicAppendZeros DeterministicCyclic            |
| Number of bits generated     | setNumberOfBits()         | int  | Any integer   |
| Pattern length               | setPatternLength()        | int  | Real number greater than zero   |
| Number of bits               | setNumberOfBits()         | long   | Integer number greater than zero  |
| Number of samples per symbol | setNumberOfSamplesPerSymb | o <b>l()</b> t                               | Integer number of the type $2^n$ with n also integer                        |
| Roll of factor               | setRollOfFactor()         | double                                       | ∈ [0,1]   |
| IQ amplitudes                | setIqAmplitudes()         | Vector of coordinate points in the I-Q plane | Example for a 4-qam mapping: { { 1.0, 1.0 }, { -1.0, 1.0 }, { -1.0, -1.0 }, |
| Output optical power         | setOutputOpticalPower()   | int  | Real number greater than zero   |
| Save internal signals        | setSaveInternalSignals()  | bool   | True or False   |

Tabela 5.1: List of input parameters of the block MQAM transmitter

#### Methods

```
MQamTransmitter(vector<Signal *> &inputSignal, vector<Signal *> &outputSignal);
(constructor)

void set(int opt);

void setMode(BinarySourceMode m)
```

BinarySourceMode const getMode(void)

 $void\ set Probability Of Zero (double\ pZero)$ 

 $double\ const\ getProbabilityOfZero (void)$ 

void setBitStream(string bStream)

string const getBitStream(void)

```
void setNumberOfBits(long int nOfBits)
long int const getNumberOfBits(void)
void setPatternLength(int pLength)
int const getPatternLength(void)
void setBitPeriod(double bPeriod)
double const getBitPeriod(void)
void setM(int mValue) int const getM(void)
void setIqAmplitudes(vector<t_iqValues> iqAmplitudesValues)
vector<t_iqValues> const getIqAmplitudes(void)
void setNumberOfSamplesPerSymbol(int n)
int const getNumberOfSamplesPerSymbol(void)
void setRollOffFactor(double rOffFactor)
double const getRollOffFactor(void)
void setSeeBeginningOfImpulseResponse(bool sBeginningOfImpulseResponse)
double const getSeeBeginningOfImpulseResponse(void)
void setOutputOpticalPower(t_real outOpticalPower)
t_real const getOutputOpticalPower(void)
void setOutputOpticalPower_dBm(t_real outOpticalPower_dBm)
t_real const getOutputOpticalPower_dBm(void)
```

### **Output Signals**

Number: 1 optical and 1 binary (optional)

Type: Optical signal

### Example

## Sugestions for future improvement

Add to the system another block similar to this one in order to generate two optical signals with perpendicular polarizations. This would allow to combine the two optical signals and generate an optical signal with any type of polarization.

## **Development Cycle**

The NetXPTO-LinkPlanner has been developed by several people using git as a version control system. The NetXPTO-LinkPlanner repository is located in the GitHub site http://github.com/netxpto/linkplanner. The more updated functional version of the software is in the branch master. Master should be considered a functional beta version of the software. Periodically new releases are delivered from the master branch under the branch name Release<a href="Year">Year</a><a href="Year">