

Sloeber Tutorial

This introduction is copied from: <http://eclipse.baeyens.it/learn.shtml>

The arduino IDE put the focus on "a low entry level". Honestly with decades of experience in software development I can tell you -hand on hart- that the Arduino IDE is very good designed ... for it's purpose.

But when you start growing and "the low entry level" is no longer your first concern. You start to want a "rich tool", not a "this way it will work always work tool". So a tool that allows you to control more things, and as such does not stop you from breaking things.

As it is nearly impossible to combine a "rich tool" with a "low entry level tool" many "requests for improvements" are rejected by the arduino core team as it may infringe the "low entry level" target.

So when you have a need that goes above "low entry level" you are out of the focus of the arduino IDE development team and you need to start banging another door/tool.

At that point in time, one of the doors/options is the arduino eclipse plugin. One of the strong points of the Arduino eclipse plugin compared to the other available tools is that it is multi platform. It has active users using Windows, Mac and linux.

The arduino eclipse plugin is easy to set-up (though harder than the Arduino IDE) and easy to use. It has the same icons for verifying upload and serial monitor as the arduino IDE. And to name the biggest plus: It supports you to serve your multiple projects with different configurations (of each project). And it supports you from writing your code up to hopping into code of included libraries – seamless.

Most people have uploaded their first sketch in Slouber in less than 30 minutes - there are some people who never succeeded in running the tool – with this introduction we firmly believe that you belong to the first group. Good luck and have fun with this impressive extension!

Table of contents

Sloeber Tutorial	1
Installation.....	4
Setting Paths.....	4
First start of Sloeber	4
Eclipse IDE with Sloeber extensions.....	5
First Project Blink on Arduino UNO	6
Create a new project: Blink-test for Arduino UNO.....	6
Suppress sloeber.ini.cpp.....	8
Add line numbers to the editor	9
Change Compile options and Compile summary format	10
Upload to Arduino UNO	12
Enable automatic build before upload.....	12
Changing the Com Port for uploading	12
Where are the compiled results?	13
Discovering the Arduino cores	15
Manage Debug and Release version in one project (Multiple configurations).....	16
Extend Menu with Active Build Configuration and Build Active Configuration buttons.	16
Set indexer settings for multiple configurations	19
Rename an existing configuration.....	20
Add Debug configuration for the project	21
Set up the Debug configuration	22
Two different sources in the same project	25
Add a new configuration for the new source.....	25
Assign the sources to the respective configurations.....	27
Choose which configuration to build.	28
Change platform to ESP32.....	29
Install ESP platform	29
Extend Third party index url's.....	29
Choose the ESP core version	30
Select the ESP32 board for my project.....	31
Useful Settings.....	32
Auto Format 132 character per line	32
Enable file history.....	35
Access the history of a file.....	36
Launch explorer for the current file	37
Create a launch configuration for external tool.....	37
Advanced features.....	41

Advanced Editing shortcuts.....	41
Name completion with Ctrl + Space.....	41
Creating code blocks with Ctrl + Space	41
Search definition of a variable/function with F3.....	42
Search Usage of variable/function with Ctrl + Shift + G.....	42
Rename variable/function/macro at all occurrences with Alt + Shift + R.....	42
Format source with Ctrl + Shift + F.....	42
Comment/Outcomment with Ctrl + Shift + /	42
Search (and replace) in Project or complete Workspace with Search > File	42
Explore the history of your code	42
Generating Assembler output of your program.....	43
Synchronize editor window with left tree view	44
Add user libraries	45
Create a function from multiple lines of code	46
Convert an ino file to a cpp file	46
Working sets.....	47
Tips and Tricks	48
Detach an editor perspective (e.g. Console) window	48
Full screen Editing	48
Errors and Problems.....	49
A Window (e.g. Console) was accidentally deleted, the window arrangement is broken.....	49
Errors in unknown libraries	49
Strange errors indicated, F3 does not work, index not complete.....	50
No build.opt.....	50
Keyboard layout changed to English/US	50
Error message: <code>invalid argument to --format: avr</code>	50
Software updates	51


Installation

Setting Paths

In windows environment, choose an install path with a short name e.g. **C:\Sloeber**. Otherwise, while installation, some path names will be longer than accepted under Windows.


Create empty directory as workspace C:\sloeber-workspace

Start **sloeber-ide.exe**, select the new workspace and check "Use this..."




First start of Sloeber


Since you do not have secure data, you may allow for public sites.



Close the welcome tab.




Wait while sloeber is loading the current core and libraries





Eclipse IDE with Sloeber extensions

This is the Eclipse window with the Sloeber extensions as well as *two extra buttons* you will add in a few seconds!




First Project Blink on Arduino UNO

Create a new project: Blink-test for Arduino UNO



Here we choose a sample sketch as start for our project.




This is the Sloeber/Eclipse window for the Source file **Blink.uno**.

On the right, you see the **Outline window**, with all variables and functions listed for quick access.

In the middle, there are the **edit windows**.

Left is the **Project Explorer** with the tree view of your projects and files.

On the Bottom, there are some **Views** like the **Console** and **Serial monitor view**.




Suppress sloeber.ini.cpp

We think that the presence of the file "sloeber.ini.cpp" is a crutch. How to get rid of it? Just rename "Blink.ino" into "Blink.cpp" and the sloeber.ini.cpp file will vanish.

Note: If you do so, you must add the line `#include <Arduino.h>` in your source.

Add line numbers to the editor

Open **Window > Preferences**




Search for line and check **Insert spaces for tabs** and **Show line numbers**

A screenshot of the Eclipse IDE's 'Text Editors' preferences page. The search bar at the top left contains the text 'line'. On the left, there is a tree view with nodes like 'General', 'Compare/Patch', 'Editors' (which is expanded to show 'Text Editors' and 'Workspace'), 'C/C++', and 'Editor' (which is expanded to show 'Scalability' and 'Syntax Coloring'). The 'Text Editors' node is selected. In the main pane, under the heading 'Text Editors', there is a note: 'Some editors may not honor all of these settings.' Below this, there are several checkboxes: 'Insert spaces for tabs' (checked), 'Highlight current line' (checked), 'Show print margin' (unchecked), 'Show line numbers' (checked), 'Show cursor position in the status line' (checked), 'Show selection size in the status line' (checked), 'Show range indicator' (checked), 'Show whitespace characters' (unchecked), 'Show affordance in hover on how to make it sticky' (checked), 'Enable drag and drop of text' (checked), 'Warn before editing a derived file' (checked), and 'Smart caret positioning at line start and end' (checked). At the bottom, there is a section for 'Appearance color options' with a list of items: Line number foreground (selected), Current line highlight, Print margin, Find scope, Selection foreground color, Selection background color, Background color, Foreground color, and Hyperlink. A color swatch is shown next to 'Line number foreground'. At the very bottom, there are buttons for 'Restore Defaults', 'Apply', 'Apply and Close', and 'Cancel'.


Change Compile options and Compile summary format

Open Project properties with **Alt + Enter**



Check use alternative size command? (AVR only)


Do not check it for any non AVR platform!






Enable automatic build before upload


To be sure, that your upload includes all your recent changes, you should enable **Save automatically before manual build** option in **Window > Preferences > General > Workspace > Build**.




Changing the Com Port for uploading

You must set the Com Port in the **Arduino properties** of your project to the port number of your Arduino board, which is displayed in the **Windows Device Manager**. You **must likely have to attach the Board**, before selecting the port, because only Com-Ports currently attached can be selected.






Where are the compiled results?



The **Blink_test.hex** file is the file used by uploading with avrdude.exe



The screenshot shows the Sloeber IDE interface with the "Console" tab selected. The console output is as follows:

```
upload console [Blink_test]
Starting upload
Uploading project "Blink_test" with "AVRDUDE"
Starting reset using DTR toggle process
Continuing to use "COM6"
Ending reset

Launching: C:\Sloeber\arduinoPlugin\packages\arduino\tools\avrdude\6.3.0-arduino17/bin/avrdude -CC:C:\Sloeber\arduinoPlugin\packages\arduino\tools\avrdude\6.3.0-arduino17/etc/avrdude.conf -patmega328p -carduino -PCOM6 -b115200 -D -Uflash:w:C:\sloeber-workspace\Blink_test\Release/Blink_test.hex:i
Output:

avrduke: AVR device initialized and ready to accept instructions
Reading | ##### | 100% 0.00s

avrduke: Device signature = 0x1e950f (probably m328p)
avrduke: reading input file "C:\sloeber-workspace\Blink_test\Release/Blink_test.hex"
avrduke: writing flash (924 bytes)

Writing | ##### | 100% 0.16s

avrduke: 924 bytes of flash written
avrduke: verifying flash memory against C:\sloeber-workspace\Blink_test\Release/Blink_test.hex:
avrduke: load data flash data from inntut file C:\sloeber-worksnace\Blink test\Release/Blink test.hex:
```

You can remove the Release folder and other build folders anytime. Sloeber will restore them at the next build.

Discovering the Arduino cores


If you place the cursor over an Arduino (or library) function, it shows you the sourcecode.

```
void loop() {
#ifndef DEBUG
    Serial.println("Activate LED");
#endif
    digitalWrite(LED_BUILTIN, HIGH); // turn the LED on (HIGH is the
// port that supports PWM output)
    void digitalWrite(uint8_t pin, uint8_t val)
    {
        uint8_t timer = digitalPinToTimer(pin);
        uint8_t bit = digitalPinToBitMask(pin);
        uint8_t port = digitalPinToPort(pin);
        volatile uint8_t *out;
    }
    if (port == NOT_A_PIN) return;

    // If the pin that support PWM output, we need to turn it off
    // before doing a digital write.
    if (timer != NOT_ON_TIMER) turnOffPWM(timer);
}
```

If you press **F3**, the function definition will open in a new editor window. If you activate the **Link with Editor** button, the **Project Explorer** window shows you all core files.

You can even modify the core sources, but be careful!



Manage Debug and Release version in one project (Multiple configurations)


Each project has individual settings, like Board/CPU (type/clock), libraries, clock speed, Com Port, or Sources used for compile.


To have 2 different settings, you can of course create 2 projects, but then you have to take care to keep the sources synchronized 😞.

With configurations, you can have different sets of settings for one source. Each configuration is available at one mouse click.


Extend Menu with Active Build Configuration and Build Active Configuration buttons.

First, we extend the menu to have **two useful buttons** available for configuration management.






Check **Build Configuration** on the **Action Set Availability** tab to enable the **Active Build Configuration** and **Build Active Configuration** buttons.




Save the changes to the current perspective in order to have it persistent even after a reset perspective. We simply overwrite the existent Arduino perspective.





Set indexer settings for multiple configurations




The index for **active build configuration** should be enabled. This allows for more advanced usage of configuration, like binding different libraries etc.




Rename an existing configuration




Add Debug configuration for the project






We can now change easily to the Debug configuration



Set up the Debug configuration

Now we change the Debug configuration to have the **DEBUG** macro defined. This is equivalent to including the line **#define DEBUG** in your code. To have it specified in our configuration allows fast switching between using or not using the define without changing the code.



```

25 #include <Arduino.h>
26
27 // the setup function runs once when you press reset or power the board
28 void setup() {
29     // initialize digital pin LED_BUILTIN as an output.
30     pinMode(LED_BUILTIN, OUTPUT);
31     // Just to know which program is running on my Arduino
32 #ifdef DEBUG
33     Serial.println(F("START " __FILE__ " from " __DATE__));
34 #endif
35 }
36
37 // the loop function runs over and over again forever
38 void loop() {
39 #ifdef DEBUG
40     Serial.println("Activate LED");
41 #endif
42     digitalWrite(LED_BUILTIN, HIGH);    // turn the LED on (HIGH is the voltage level)
43     delay(1000);                      // wait for a second
44 #ifdef DEBUG
45     Serial.println("Deactivate LED");
46 #endif
47     digitalWrite(LED_BUILTIN, LOW);    // turn the LED off by making the voltage LOW
48     delay(1000);                      // wait for a second
49 }
50

```

Switching back to the Release configuration shows that the **DEBUG** guarded statements are inactive now.

```

25 #include <Arduino.h>
26
27 // the setup function runs once when you press reset or power the board
28 void setup() {
29     // initialize digital pin LED_BUILTIN as an output.
30     pinMode(LED_BUILTIN, OUTPUT);
31     // Just to know which program is running on my Arduino
32 #ifdef DEBUG
33     Serial.println(F("START " __FILE__ " from " __DATE__));
34 #endif
35 }
36
37 // the loop function runs over and over again forever
38 void loop() {
39 #ifdef DEBUG
40     Serial.println("Activate LED");
41 #endif
42     digitalWrite(LED_BUILTIN, HIGH);    // turn the LED on (HIGH is the voltage level)
43     delay(1000);                      // wait for a second
44 #ifdef DEBUG
45     Serial.println("Deactivate LED");
46 #endif
47     digitalWrite(LED_BUILTIN, LOW);    // turn the LED off by making the voltage LOW
48     delay(1000);                      // wait for a second
49 }
50

```

The code for the example:

```

void setup() {
    // initialize digital pin LED_BUILTIN as an output.
    pinMode(LED_BUILTIN, OUTPUT);
    // Just to know which program is running on my Arduino
    #ifdef DEBUG
        Serial.println(F("START " __FILE__ " from " __DATE__));
    #endif
}

```


```
}

// the loop function runs over and over again forever
void loop() {
#define DEBUG
    Serial.println("Activate LED");
#endif
    digitalWrite(LED_BUILTIN, HIGH); // turn the LED on (HIGH is the voltage level)
    delay(1000); // wait for a second
#define DEBUG
    Serial.println("Deactivate LED");
#endif
    digitalWrite(LED_BUILTIN, LOW); // turn the LED off by making the voltage LOW
    delay(1000); // wait for a second
}
```


Two different sources in the same project

Next, we add an additional source file with an extended version of our blink example.

Without a new configuration, we get the multiple definition of `setup' Error on compile.




Add a new configuration for the new source



And yet another for the **Debug variant for the new source**.


Here we just copy the settings from the existent Debug configuration, so the **-DDEBUG** is already set on creation




Assign the sources to the respective configurations

In Eclipse, all project sources (and libraries) are assigned to all configurations by default.


For each source, you must therefore specify all the configurations where this source should be excluded. Here we exclude the old file **Blink.cpp** from the new configurations.





The "same" must be done for the new source file.


Choose which configuration to build.



Change platform to ESP32


Install ESP platform

Open Arduino > Preferences





Extend Third party index url's

Add https://raw.githubusercontent.com/espressif/arduino-esp32/gh-pages/package_esp32_index.json



Choose the ESP core version

Open **Arduino > Preferences** again and choose the desired version in Platform and Boards. You can choose multiple versions, which can be used for different configurations or projects.



Here you find the unofficial list of all known core / board URL's


<https://github.com/arduino/Arduino/wiki/Unofficial-list-of-3rd-party-boards-support-urls>

A few more common URL's:


- http://arduino.esp8266.com/stable/package_esp8266com_index.json
- https://raw.githubusercontent.com/espressif/arduino-esp32/pages/package_esp32_index.json
- https://github.com/stm32duino/BoardManagerFiles/raw/master/STM32/package_stm_index.json
- http://dan.drown.org/stm32duino/package_STM32duino_index.json
- https://raw.githubusercontent.com/sparkfun/Arduino_Apollo3/master/package_sparkfun_apollo3_index.json
- https://files.pololu.com/arduino/package_pololu_index.json
- http://drazzy.com/package_drazzy.com_index.json

- https://raw.githubusercontent.com/ArminJo/DigistumpArduino/master/package_digistump_index.json
- http://raw.githubusercontent.com/MHEtLive/arduino-boards-index/master/package_mhetlive_index.json
- https://sandeepmistry.github.io/arduino-nRF5/package_nRF5_boards_index.json
- https://mcudude.github.io/MiniCore/package_MCUDude_MiniCore_index.json
- https://raw.githubusercontent.com/xukangmin/TinyCore/master/avr/package/package_tinycore_index.json
- https://mcudude.github.io/MegaCore/package_MCUDude_MegaCore_index.json

Select the ESP32 board for my project



One **drawback of Sloeber** is, that the default settings are not filled in. But they can easily be determined, if you select the same board in the **Arduino IDE**.




Useful Settings


Auto Format 132 character per line

The standard auto format settings are the **Kernighan & Ritchie style** with a **maximum line length of 80** characters. If you feel that this is too short for your HD Monitor (like I do), set maximum line length to e.g. 132.


Open Window > Preferences



Navigate to the **C++ Formatter**, click on **New....** and give it a sensible name.




Then change Maximum line width on the Line Wrapping tab to 132.




Enable file history

By default, the file history is limited to 7 days.




I personally prefer an unlimited history, it does not take too much space on your disk (2.6 GB for 136 projects and 5 years).



Access the history of a file

The local history (stored on your computer) can be accessed by selecting a file and then **Team > Show Local History**



This is an example history.


A screenshot of the Arduino IDE showing the 'History' tab. The tab bar includes 'History', 'Properties', 'Problems', and 'Serial monitor'. Below the tab, the file name 'DigisparkBlink.cpp' is shown. A table titled 'Revision Time' lists several commits:

Time	Commit
21.03.21, 12:10	Initial commit
09.02.21, 14:38	Minor update
05.12.20, 22:46	Major update (highlighted)
24.08.20, 22:3	Minor update
24.08.20, 22:3	Minor update

An open context menu is displayed over the third revision ('05.12.20, 22:46'), with options: 'Open', 'Open With', 'Compare Current with Local', and 'Get Contents'.


Launch explorer for the current file

This opens a Windows explorer window located at the file currently selected in the edit window. It is very handy if you want to modify or copy the file outside of Sloeber.




Create a launch configuration for external tool


You can also create a launch configuration for external tool, to have this function available at one click.




Add the path C:\Windows\explorer.exe and add Arguments "/select,\${resource_loc}"




On the Build tab, uncheck the **Build before launch** checkbox



On the Common tab, check External Tools



Run it from the menu




Advanced features


Advanced Editing shortcuts

Name completion with Ctrl + Space

Here the completion for "Serial".




It handles also available functions of an object if pressed after the dot.




Creating code blocks with Ctrl + Space

Type "sw", press Ctrl + Space and select **switch case statement**. A complete switch template will be generated for you.



Type "for", press Ctrl + Space and you get:




This results in:

```
for (int var = 0; var < max; ++var) {  
}
```


Search definition of a variable/function with F3
Search Usage of variable/function with Ctrl + Shift + G
Rename variable/function/macro at all occurrences with Alt + Shift + R
Format source with Ctrl + Shift + F
Comment/Outcomment with Ctrl + Shift + /
Search (and replace) in Project or complete Workspace with Search > File ...

Explore the history of your code

In the History view you can not only display historical file contents, but also compare them with current content.




If you select two dates / lines in the history view, you can compare them with each other.



Generating Assembler output of your program

Open **Project > Properties > C/C++ Build > Settings > Build Steps** and add "avr-objdump -h -S \${BuildArtifactFileName}.elf > \${BuildArtifactFileName}.lss" in the field **Post-build steps > Command**




The assembler output is located in Blink/Blink_test.lss and looks like:

```
✓ Blink_test Arduino Uno :C0I      658     *out |= bit;
                                SREG = oldSREG;
659
660 } else {
661     uint8_t oldSREG = SREG;
662 36a: 8f b7      in r24, 0x3f ; 63
663     cli();
664 36c: f8 94      cli
665     *reg |= bit;
666 36e: ec 91      ld r30, X
667 370: e2 2b      or r30, r18
668 372: ec 93      st X, r30
669     SREG = oldSREG;
670 374: 8f bf      out 0x3f, r24 ; 63
671
672     setup();
673
674     for (;;) {
675         loop();
676         if (serialEventRun) serialEventRun();
677 376: c0 e0      ldi r28, 0x00 ; 0
678 378: d0 e0      ldi r29, 0x00 ; 0
679 // the loop function runs over and over again forever
680 void loop() {
681 #ifdef DEBUG
682     Serial.println("Activate LED");
683 #endif
684     digitalWrite(LED_BUILTIN, HIGH); // turn the LED on (HIGH is the voltage level)
685 37a: 81 e0      ldi r24, 0x01 ; 1
686 37c: 0e 94 70 00 call 0xe0      ; 0xe0 <digitalWrite.constprop.0>
687     delay(1000);
688 380: 0e 94 dd 00 call 0x1ba    ; 0x1ba <delay.constprop.1>
689 #ifdef DEBUG
690     Serial.println("Deactivate LED");
691 #endif
692     digitalWrite(LED_BUILTIN, LOW); // turn the LED off by making the voltage LOW
693 384: 80 e0      ldi r24, 0x00 ; 0
694 386: 0e 94 70 00 call 0xe0      ; 0xe0 <digitalWrite.constprop.0>
695     delay(1000);
696 38a: 0e 94 dd 00 call 0x1ba    ; 0x1ba <delay.constprop.1>
697 38c: 20 97      sbiw r28, 0x00 ; 0
698 390: a1 f3      breq .-24      ; 0x37a <main+0xc0>
699 392: 0e 94 00 00 call 0          ; 0x0 <_vectors>
700 396: f1 cf      rjmp .-30      ; 0x37a <main+0xc0>
701
702 .....
```


Synchronize editor window with left tree view

If you activate the "Link with Editor" button. The tree view will position at the file in the Editor window (which is not always desirable).




Add user libraries

You can specify the location where your manually managed libraries are located.




Create a function from multiple lines of code

First, select the lines of code you want to have as a function, then use **Refactor > Extract Function** and specify name of the function as well as other parameters. The function will then be created and inserted before the current function.



Convert an ino file to a cpp file

If you create a project from an Arduino example or download Arduino examples, you always have an *.ino file as main program.



If you just rename your *.ino file to *.cpp, you will get compiler errors. You must **first** include the lines



```
#include "Arduino.h"

void setup() ;
void loop() ;
void calibrate() ;
```

from the file *sloeber.ino.cpp* into the *.ino file before any #defines or declarations. After renaming your file, the file *sloeber.ino.cpp* will be deleted (and if you rename it back, it is created again ☺).

Working sets

If after a while you have many projects in your workspace, you can group them with working sets. Here I grouped all projects with the same core into a working set and used the project configuration for the different source files/examples



Tips and Tricks

[Detach an editor perspective \(e.g. Console\) window](#)

You can detach every window by just dragging it elsewhere.

Dragging back can be done by simply **clicking on the tab (not on the title of the detached tab window)**. Then you will see mouse cursor change showing you where you can drop it to attach the tab back to Eclipse. Alternatively, you can close the window and use **Window > Perspective > Reset Perspective**.

[Full screen Editing](#)

By double clicking on the tab of every window, this window changes to full screen / full window. The next double click reverts this change.

Errors and Problems


Before you chase a strange error, it is always recommended to try **Sloeber > Reattach Libraries**, **right mouse button > Clean Project** and **Index > Rebuild** and to close and open the project or even restart Sloeber.

Also look to the list of libraries with **Sloeber > Add a library to the selected project** and check, if it corresponds to your requirements.

[A Window \(e.g. Console\) was accidentally deleted, the window arrangement is broken](#)

Reset window arrangement with **Window > Perspective > Reset Perspective**.

Do NEVER check the box Also discard perspective's customization.




[Errors in unknown libraries](#)

If you get errors like

```
make: *** [libraries\FreeRTOS\src\croutine.c.o] Error 1
```

then check libraries, sometimes there are more libraries than required. In this case, Sloeber thinks you might need the FreeRTOS library for the project.




Simply delete it in the Project Explorer or exclude it from your configuration with **Sloeber > Add a library to the selected project**.

Strange errors indicated, F3 does not work, index not complete

This happens sometimes after changing configuration.

Run **Index > Rebuild** or **Index > Freshen All Files** and the strange behavior will vanish.



No build.opt

If you get errors like

```
ESP8266/core/build.opt: No such file or directory
```

then just removing the line `build.opt.flags="@{build.opt.fqfn}"` in the files `platform.txt` and `platform.sloeber.txt` and restarting Sloeber will fix it. "Build options" can be specified in the **Compile Options** tab in the Sloeber project settings.

The files can be found at e.g. `Sloeber\arduinoPlugin\packages\esp8266\hardware\esp8266\3.1.1\`.


Keyboard layout changed to English/US

Keyboard layout can be (accidentally) changed by **Alt + Shift** to English and back.

Error message: `invalid argument to --format: avr`


You accidentally selected **AVR_ALTERNATIVE** for use alternative size command?

Do not select it for any non AVR platform!




Software updates


Check for updates with **Help > Check for Updates**




You see a list of available updates



Then you will be asked to **accept the terms of the license agreements**



And because the package is of course not signed, you must choose **Install anyway**



At last restart Sloeber

