


WeAct Studio

NANO&XAVIER TX2 NX CB

Tutorial



Catalog

Rev	vision History	.3
1.	Build a Flash environment	.4
	Update device tree for nano / nx o	
3.	System Backup and recovery	14
4.	Installing NVIDIA SDK	16
5.	Communication using can	18
6.	GPIO using on shell	20
7.	System migration to nvme SSD 2	21
8.	system migration to SD Card	25
Cor	ntact with us	28

WeAct Studio


REVISION HISTORY

Draft Date	Revision	Description
2021.9.20	V1.0	1. Init Version.
2021.12.26	V1.1	1. Add system backup and migra tion to NVME SSD
2022.1.22	V1.2	Add system migration to SD Card
2023.4.09	V1.3	1. Update device-tree by Jetpack5.x



1. BUILD A FLASH ENVIRONMENT

- a) First, you need a computer with Ubuntu 16.04 or above as the host to burn nano / NX, or you can install VMware on windows.
- b) Download the latest SDK manager from NVIDIA and install it in Ubuntu 18.04 (You need to register an NVIDIA account, which will also be used later)
 - > SDK-Manager Download: https://developer.nvidia.com/nvidia-sdk-manager
- c) Select the target hardware and jetpack version required, uncheck the host machine, take tx2nx as an example, and click continue.








Orin Nano/NX Please download the latest Orin NX Jetpack system.

d) Check I accept the terms and conditions of the license agreements, uncheck the Jetson SDK components, and click continue to proceed to the next step.



P. S: please download and install in a smooth network environment. When the download or installation fails, click Retry to continue until all the status is installed and green is displayed. During the installation process, a network burning message will pop up and select skip.





e) After the installation is successful, the required files will be burned with the corresponding version under ~ / NVIDIA / nvidia sdk /



f) Install Python support through sudo apt get install Python on the terminal for subsequent environment burning.

2. UPDATE DEVICE TREE FOR NANO / NX OR FLASH SYSTEM

P.S: the Weact device tree is different from the official device tree (Other functions are the same). If there is no need, the device tree can not be updated.

!!! Note that updating the device tree does not affect any system files. Please be assured to update

NVIDIA and WeAct device tree diff

	NVIDIA	WeAct Studio	
Nano-SD	Same	Same	
Nano-EMMC	Cant use SD	Can use SD	
TX2NX	Cant use SD&UART1	Can use SD &UART1	
XavierNX	Cant use SD	Can use SD	
Orin Nano/NX	Same	Same	

- a) Here, take tx2nx as an example, download the corresponding device tree file on the GitHub of Weact studio.
 - Github: https://github.com/WeActTC/Nano_TX2-Xavier_NX-CB

Update path and equipment tree name of each equipment tree


	Linux_for_Tegra/kernel/dtb	Linux_for_Tegra/bootloader/t186ref(t210f)
Nano-EMMC	tegra210-p3448-0002-p3449- 0000-b00	None


TX2NX	tegra186-p3636-0001-p3509- 0000-a01	tegra186-bpmp-p3636-0001-a00-00
XavierNX	tegra194-p3668-all-p3509-0000	None

- b) Find the corresponding version of the device tree
 - Enter ~/nvidia/nvidia_sdk/JetPack_4.6_Linux_JETSON_TX2_TARGETS/Linux_for_Tegra/kernel/dtb, copy device-tree tegra186-p3636-0001-p3509-000 0-a01.dtb to this dir.
 - Enter ~/nvidia/nvidia_sdk/JetPack_4.6_Linux_JETSON_TX2_TARGETS/Linux_for_Tegra/bootloader/t186ref, Copy device-tree tegra186-bpmp-p3636-0001-a00-00.dtb to this dir [Only TX2NX]


P.S: For Orin Serial, please modify: Linux_for_Tegra/bootloader/t186ref/BCT/tegra23 4-mb2-bct-misc-p3767-0000.dts

```
cvb_eeprom_read_size = <0x100>
cvb_eeprom_read_size = <0x0>
```






3. Use the USB type-C cable to connect the USB OTG interface on the carrier board.



4. Turn the power on key to MP (Manual power on), press the rec key, then press the PWR key to power on, release the rec key to enter the recovery mode, at this time, NVIDIA USB drive sign will appear in the lower right corner of VMware, or open the terminal and enter Isusb command, NVIDIA Corp will be found.



- 5. Enter ~/nvidia/nvidia_sdk/JetPack_4.6_Linux_JETSON_TX2_TARGETS/Linux_for_Tegra, open command
 - a) If you have a system, run **sudo** ./flash.sh -r -k kernel-dtb jetson-xavier-nx-devkit-tx2-nx mmcblk0p1, and updated the device-tree.
 - b) Or you don't have a system, run sudo ./flash.sh jetson-xavier-nx-devk it-tx2-nx mmcblk0p1, and flash the system

Device tree updated command

Device	Command
Nano-SD	sudo ./flash.sh -r -k DTB jetson-nano- qspi-sd mmcblk0p1
Nano-EMMC	sudo ./flash.sh -r -k DTB jetson-nano- emmc mmcblk0p1
TX2-NX	sudo ./flash.sh -r -k kernel-dtb jetson- xavier-nx-devkit-tx2-nx mmcblk0p1
Xavier-SD	sudo ./flash.sh -r -k kernel-dtb jetson- xavier-nx-devkit-qspi mmcblk0p1
Xavier-EMMC	sudo ./flash.sh -r -k kernel-dtb jetson- xavier-nx-devkit-emmc mmcblk0p1

System flash command

Device	Command		
Nano-SD	sudo ./flash.sh jetson-nano-qspi-sd mmcblk0p1		
Nano-EMMC	sudo ./flash.sh jetson-nano-emmc mmcblk0p1		
TX2-NX	sudo ./flash.sh jetson-xavier-nx-devkit-tx2-nx mmcblk0p1		
Xavier-SD	sudo ./flash.sh jetson-xavier-nx-devkit-qspi mmcblk0p1		
Xavier-EMMC	sudo ./flash.sh jetson-xavier-nx-devkit-emmc mmcblk0p1		
Orin Nano 4GB	 sudo BOARDID=3767 BOARDSKU=0004 ./tools/kernel_flash/l4t_initrd_flash.shno-flashexternal-device nvme0n1p1 -p "-c bootloader/t186ref/cfg/flash_t234_qspi.xmlno- systemimg" - c ./tools/kernel_flash/flash_l4t_external.xmlmassflash 5showlogsnetwork usb0 p3768-0000+p3767-0000 nvme0n1p1 sudo ./tools/kernel_flash/l4t_initrd_flash.shflash-onlynetwork usb0massflash 5showlogs 		
Orin Nano 8GB	1. sudo BOARDID=3767 BOARDSKU=0003 ./tools/kernel_flash/l4t_initrd_flash.shno-flashexternal-device nvme0n1p1 -p "-c bootloader/t186ref/cfg/flash_t234_qspi.xmlno- systemimg" - c ./tools/kernel_flash/flash_l4t_external.xmlmassflash 5showlogsnetwork usb0 p3768-0000+p3767-0000 nvme0n1p1		

	2. sudo ./tools/kernel_flash/l4t_initrd_flash.shflash-onlynetwork usb0massflash 5showlogs	
Orin NX 8GB	1. sudo BOARDID=3767 BOARDSKU=0001 ./tools/kernel_flash/l4t_initrd_flash.shno-flashexternal-device nvme0n1p1 -p "-c bootloader/t186ref/cfg/flash_t234_qspi.xmlno- systemimg" - c ./tools/kernel_flash/flash_l4t_external.xmlmassflash 5showlogsnetwork usb0 p3768-0000+p3767-0000 nvme0n1p1	
	2. sudo ./tools/kernel_flash/l4t_initrd_flash.shflash-onlynetwork usb0massflash 5showlogs	
Orin NX 16GB	I. sudo BOARDID=3767 BOARDSKU=0000 ./tools/kernel_flash/l4t_initrd_flash.shno-flashexternal-device nvme0n1p1 -p "-c bootloader/t186ref/cfg/flash_t234_qspi.xmlno- systemimg" - c ./tools/kernel_flash/flash_l4t_external.xmlmassflash 5showlogsnetwork usb0 p3768-0000+p3767-0000 nvme0n1p1	
	2. sudo ./tools/kernel_flash/l4t_initrd_flash.shflash-onlynetwork usb0massflash 5showlogs	

After updating the device tree, it will be successful! Display, as shown in the following figure.

Note: For jetpack5.x, please copy the relative device tree to your jetson device and replace it in the /boot/dtb directory.

3. SYSTEM BACKUP AND RECOVERY

- a) Refer to Chapter 2. No matter backup or image burning, enter the recovery mode. Note that the image is large. Please ensure that Ubuntu has sufficient space (> 40g).
- b) Backup: take TX2NX as an example (for other devices, please refer to the previou s chapter to modify the Jetson name) to backup the existing environment of the core board. Enter ~/nvidia/nvidia_sdk/JetPack_4.6_Linux_JETSON_TX2_TARGE TS/Linux for Tegra, open the terminal.

Use system backup command: **sudo** ./**flash.sh** -**r** -**k APP** -**G backup.img jetson- xavier-nx-devkit-tx2-nx mmcblk0p1.** Wait for the backup to complete, and there will be backup.img in the directory(it is recommended to copy a copy to another location for backup). At this time, the backup has been successful.

```
greetrix@greetrix-virtual-machine:~/nvidia/nvidia_sdk/JetPack_4.6_Linux_JETSON_
X2_TARGETS/Linux_for_Tegra$ sudo ./flash.sh -r -k APP -G backup.img jetson-xavie
r-nx-devkit-tx2-nx mmcblk0p1
    9.1920 ] tegrarcm_v2 --boot recovery
    9.1966 ] Applet version 01.00.0000
   9.3692
  10.3763
               tegrarcm v2 --isapplet
             USB communication failed.Check if device is in recovery
  10.3793
  10.5068
  10.8536 ] tegradevflash_v2 --iscpubl
10.8565 ] Cannot Open USB
  11.3572
  12.3617 ] tegrarcm_v2 --isapplet
12.5109 ]
  12.5142 ] tegradevflash_v2 --iscpubl
12.5163 ] Bootloader version 01.00.0000
  12.6843 ] Bootloader version 01.00.0000
  12.7463 ]
 12.7464 ] Reading partition
12.7464 ] tegradevflash_v2 --read APP /home/greetrix/nvidia/nvidia_sdk/JetPac
4.6_Linux_JETSON_TX2_TARGETS/Linux_for_Tegra/backup.img
12.7511 ] Bootloader version 01.00.0000
  12.9183 ] [......
[ 2216.5426 ]
 ** The [APP] has been read successfully. ***
         Converting RAW image to Sparse image... greetrix@greetrix-virtual-machin
2 TARGETS/Linux for TegraS 🖟 4.6_Linux_JETSON_TX
```


c) Recovery: Enter ~/nvidia/nvidia_sdk/JetPack_4.6_Linux_JETSON_TX2_TAR GETS/Linux_for_Tegra, copy the backup.img to Liunx_for_Tegra/bootloade r/ and rename with "system.img", goto Linux_for_Tegra and open termin al: sudo ./flash.sh -r jetson-xavier-nx-devkit-tx2-nx mmcblk0p1, wait finif shing.

```
18.0000 ] Writing partition spe-fw_b with spe_sigheader.bin.encrypt
 18.0790 ] Writing partition mb2 with nvtboot_sigheader.bin.encrypt
 18.1596 ] Writing partition mb2_b with nvtboot_sigheader.bin.encrypt
 18.2416 ] Writing partition mts-preboot with preboot_d15_prod_cr_sigheader.bi
n.encrypt
 18.2710 ] [......
 18.6760 ] Writing partition mts-preboot_b with preboot_d15_prod_cr_sigheader.
bin.encrypt
 18.7467
      ] Writing partition SMD with slot_metadata.bin
 18.9037
      ] Writing partition SMD_b with slot_metadata.bin
 18.9302
       [.....] 100%
 18.9658 ] Writing partition VER_b with emmc_bootblob_ver.txt
 18.9922
       19.0322 ] Writing partition VER with emmc_bootblob_ver.txt
 19.0592 ] [.....] 100%
 19.0966 ] Writing partition master_boot_record with mbr_1_3.bin
 19.1525 ] Writing partition APP with system.img
 19.1800 ] [......
                                   ] 016%
```


```
ct.encrypt
1888.6372 ] Bootloader version 01.00.0000
 1888.8013 ] Writing partition MB1_BCT with mb1_cold_boot_bct_MB1_sigheader.bd
encrypt
1888.8706
 1888.8837 ] tegradevflash_v2 --write MB1_BCT_b mb1_cold_boot_bct_MB1_sighead
bct.encrypt
1888.8849 ] Bootloader version 01.00.0000
1889.0452 ] Writing partition MB1_BCT_b with mb1_cold_boot_bct_MB1_sigheader
t.encrypt
1889.0468 ] [......] 100%
 1889.1180
 1889.1181 ] Flashing completed
 1889.1181 ] Coldbooting the device
 1889.1436 | tegradevflash v2 --reboot coldboot
 1889.1449 ] Bootloader version 01.00.0000
 1889.3379 ]
** The target t186ref has been flashed successfully. ***
Reset the board to boot from internal eMMC.
```

4. INSTALLING NVIDIA SDK


d) Select the target hardware and jetpack version required, uncheck the host machine, take tx2nx as an example, and click continue.



e) Check the required SDK components, check I accept the terms and conditions of the license agreements, and click continue to proceed to the next step.




f) Use the USB type-C cable to connect the USB OTG interface on the carrier board.



g) Turn the power on key to MP (manual power on) and press PWR key to power on. At this time, NVIDIA USB drive sign will appear in the lower right corner of VMware, or open the terminal and enter Isusb command to find NVIDIA Corp.

h) Enter the tx2nx account and password. Please keep the tx2nx terminal connected



i) Wait for the installation to complete.

5. COMMUNICATION USING CAN

- j) Two CAN controllers (CAN 0 / CAN 1) are integrated on TX2 NX / xaviernx. In addition, a CAN transceiver (CAN 0) is designed on the carrier board of Weact studio, which can be directly attached to the CAN physical bus.
- k) TX2 NX / xaviernx has its own CANbus driver and is integrated into the image. It already supports CANbus without further processing. We need to install CANbus module. (enter the following command in the terminal or put it into rc.local to start the self startup)

```
modprobe can
modprobe can-raw
modprobe can-bcm
modprobe can-gw
modprobe can_dev
modprobe mttcan
```

l) Check whether the installation is successful through Ismod.

```
nvidia@localhost:~$ lsmod
Module
                                Used by
                          Size
fuse
                        103841
                                2
mttcan
                         66251
                                0
can dev
                         13306
                                1 mttcan
can_gw
                         10919
                                0
                         16471
can bcm
can_raw
                         10388
can
                         46600
                                3 can_raw,can_bcm,can_gw
zram
overlay
                         48691
bcmdhd
                       934274
                                0
                        589351
cfg80211
                                1 bcmdhd
spidev
                                0
                         13282
nvgpu
                       1575721
                                20
bluedroid pm
                         13912
                                0
ip tables
                         19441
                                0
x tables
                         28951
                                1 ip_tables
```

m) Configure CANbus attribute, which is similar to the baud rate setting of serial port

sudo ip link set can0 type can bitrate 500000 sudo ip link set up can0

n) Check whether the configuration is successful through ifconfig.

```
nvidia@localhost:~$ ifconfig
can0: flags=193<UP,RUNNING,NOARP> mtu 16
    unspec 00-00-00-00-00-00-00-00-00-00-00-00-00 txqueuelen 10 (UNSPEC)
    RX packets 0 bytes 0 (0.0 B)
    RX errors 0 dropped 0 overruns 0 frame 0
    TX packets 0 bytes 0 (0.0 B)
    TX errors 0 dropped 0 overruns 0 carrier 0 collisions 0
    device interrupt 131
```

o) Can0 (Can1) via cansend at a terminal ××× Command to send data, and the other terminal completes the actual signal transceiver test through candump Can1 (can0).

```
nvidia@localhost:~$ cansend can0 555#112233445566
```

6. GPIO USING ON SHELL

a) Nano / TX2 NX / Xavier NX can directly control GPIO input and output through shell commands.

	GPIO1	GPIO2
Nano	194	38
TX2-NX	338	269
Xavier-NX	196	105

b) Take tx2-nx gpio1 as an example

> Activate IO first : sudo echo 338 > /sys/class/gpio/export

> Set IO direction: echo out > /sys/class/gpio/gpio338/direction

> Set output level : echo 1 > /sys/class/gpio/gpio338/value

7. SYSTEM MIGRATION TO NVME SSD

WeAct-Nano&Xavier-TX2_NX-Cb with WeAct-MiniPCIE2M, support 2242/2230 NVME SSD, speed up 300M/s.

```
tx2nx@tx2nx:/mnt/ssd$ dd if=/dev/zero of=./largefile bs=1M count=1024
dd: failed to open './largefile': Permission denied
tx2nx@tx2nx:/mnt/ssd$ sudo dd if=/dev/zero of=./largefile bs=1M count=1024
l024+0 records in
l024+0 records out
l073741824 bytes (1.1 GB, 1.0 GiB) copied, 3.14822 s, 341 MB/s
tx2nx@tx2nx:/mnt/ssd$ sudo sh -c "sync && echo 3 > /proc/sys/vm/drop_caches"
tx2nx@tx2nx:/mnt/ssd$ dd if=./largefile of=/dev/null bs=4k
l02144+0 records in
l02144+0 records out
l073741824 bytes (1.1 GB, 1.0 GiB) copied, 3.08641 s, 348 MB/s
tx2nx@tx2nx:/mnt/ssd$
```

- NVME SSD Configuration:
- > 1. Before configuration, ensure that the system can recognize the nvme SSD.

 The terminal command is **sudo fdisk lu**

```
Disk /dev/nvme0n1: 119.2 GiB, 128035676160 bytes, 250069680 sectors
Units: sectors of 1 * 512 = 512 bytes
Sector size (logical/physical): 512 bytes / 512 bytes
I/O size (minimum/optimal): 512 bytes / 512 bytes
Disklabel type: gpt
```

- 2. Set the NVME with GPT format:
 - i. Command: sudo parted /dev/nvme0n1, enter the parted

```
tx2nx@tx2nx:~$ sudo parted /dev/nvme0n1
[sudo] password for tx2nx:
GNU Parted 3.2
Using /dev/nvme0n1
Welcome to GNU Parted! Type 'help' to view a list of commands.
(parted)
```

ii. Command: mklabel gpt, make the label with GPT

```
(parted) mklabel gpt
Warning: The existing disk label on /dev/nvme0n1 will be destroyed and all data on this disk will be lost. Do you want to
Yes/No? Yes□
```

iii. Command: mkpart logical 0 -1, make the part with GPT

iv. Command: print, see the result

```
(parted) print
Model: KBG40ZNS128G NVMe TOSHIBA 128GB (nvme)
Disk /dev/nvme0n1: 128GB
Sector size (logical/physical): 512B/512B
Partition Table: gpt
Disk Flags:

Number Start End Size File system Name Flags
1 17.4kB 128GB 128GB logic
```

- v. Command: quit
- vi. Command: sudo fdisk /dev/nvme0n1

```
(parted) quit
Information: You may need to update /etc/fstab.

tx2nx@tx2nx:~$ sudo fdisk /dev/nvme0n1

Welcome to fdisk (util-linux 2.31.1).
Changes will remain in memory only, until you decide to write them.
Be careful before using the write command.

Command (m for help): □
```

vii. Command: N, add new part

```
Command (m for help): n
Partition number (2-128, default 2): 2
First sector (250067728-250069646, default 250068992):
Last sector, +sectors or +size{K,M,G,T,P} (250068992-250069646, default 250069646):
Created a new partition 2 of type 'Linux filesystem' and of size 327.5 KiB.
```

viii. Command: **P**, see the result

```
        Device
        Start
        End
        Sectors
        Size
        Type

        /dev/nvme0n1p1
        34 250067727 250067694 119.2G Linux filesystem

        /dev/nvme0n1p2 250068992 250069646
        655 327.5K Linux filesystem
```

- ix. Command: quit
- x. Command: sudo mke2fs -t ext4 /dev/nvme0n1p1, format the part

xi. Command: **sudo mount /dev/nvme0n1p1/mnt**, if success, configurate NVME ok.

```
tx2nx@tx2nx:~$ sudo mount /dev/nvme0n1p1 /mnt
tx2nx@tx2nx:~$ [
```

- NVIDIA Jetson system migration (!!! Please refer to chapter 3 for system backup before migration):
- ✓ Taking tx2nx as an example, other devices can replace the device name in the middle of the command, and the device name can refer to the above command
- > 1. Command: **git clone** https://github.com/jetsonhacks/rootOnNVMe, download the script
- 2. Enter the rootOnNVME document, Command: ./copy-rootfs-ssd.sh, copy the system file to NVME.

```
tx2nx@tx2nx:/home/script/root0nNVMe-master$ ./copy-rootfs-ssd.sh mount: /mnt: /dev/nvme0n1p1 already mounted on /mnt. 17,380,838 0% 2.40MB/s 0:00:06 (xfr#39, ir-chk=1015/44887)
```

> 3. Command: ./setup-service.sh, and configurate the booting

```
tx2nx@tx2nx:/home/script/rootOnNVMe-master$ ./setup-service.sh
==== AUTHENTICATING FOR org.freedesktop.systemd1.reload-daemon ===
Authentication is required to reload the systemd state.
Authenticating as: tx2nx,,, (tx2nx)
Password: Failed to reload daemon: Method call timed out
polkit-agent-helper-1: pam_authenticate failed: Authentication failure
Created symlink /etc/systemd/system/default.target.wants/setssdroot.service → /etc/systemd/system/setssdroot.service.
Service to set the rootfs to the SSD installed.
Make sure that you have copied the rootfs to SSD.
Reboot for changes to take effect.
```

- > 4. Refer to chapter 2, make the device in recovery mode.
- 5. (In Ubuntu, refer to chapter 2): Enter the ~/nvidia/nvidia_sdk/JetPack_4.6 _Linux_JETSON_TX2_TARGETS/Linux_for_Tegra, command: sudo ./flash.sh jetson-xavier-nx-devkit-tx2-nx nvme0n1p1 and updated the EMMC boot

```
greetrix@greetrix-virtual-machine:~/nvidia/nvidia_sdk/JetPack_4.6_Linux_JETSON_T
X2_TARGETS/Linux_for_Tegra$ sudo ./flash.sh jetson-xavier-nx-devkit-tx2-nx nvme0
n1p1
```

```
[ 37.3739 ] Coldbooting the device
[ 37.3775 ] tegradevflash_v2 --reboot coldboot
[ 37.3788 ] Bootloader version 01.00.0000
[ 37.5711 ]
*** The target t186ref has been flashed successfully. ***
Make the target filesystem available to the device and reset the board to boot f
rom external nvme0n1p1.
```

6. Reboot TX2NX, command: df -I, now the system is in NVME SSD and migra tion successful.

```
tx2nx@tx2nx:~$ df -l
                1K-blocks
Filesystem
                              Used Available Use% Mounted on
/dev/nvme0n1p1 122547172 11949920 104329176
                                               11% /
                  1578060
                                 0
                                      1578060
                                                0% /dev
tmpfs
                  1962748
                                52
                                      1962696
                                                1% /dev/shm
tmpfs
                  1962748
                             20764
                                      1941984
                                                2% /run
                                         5116
                                                1% /run/lock
tmpfs
                     5120
                                 4
                  1962748
                                 0
tmpfs
                                      1962748
                                                0% /sys/fs/cgroup
tmpfs
                   392548
                                 12
                                       392536
                                                1% /run/user/120
                   392548
                                 0
                                       392548
tmpfs
                                                0% /run/user/1000
```

8. SYSTEM MIGRATION TO SD CARD

- a) SD configuration:
 - 1. Make sure the system can recognize the SD card, command: **sudo fdisk -lu**
 - 2. Set the SD with GPT format:
 - i. Command: **sudo fdisk /dev/mmcblk1**, enter the SD configuration.

```
tx2nx@tx2nx:~/Desktop$ sudo fdisk /dev/mmcblk1
Welcome to fdisk (util-linux 2.31.1).
Changes will remain in memory only, until you decide to write them.
Be careful before using the write command.
```

ii. Command: **g**, new a GPT disklabel

```
Command (m for help): g
Created a new GPT disklabel (GUID: E39DF30E-48FE-B041-A6FA-5EFAEC223CEA).
```

iii. Command: **n**, new partition

```
Command (m for help): n
Partition number (1-128, default 1):
First sector (2048-124735454, default 2048):
Last sector, +sectors or +size{K,M,G,T,P} (2048-124735454, default 124735454):
```

iv. Command: w, save the configuration

```
Command (m for help): w
The partition table has been altered.
Calling ioctl() to re-read partition table.
Syncing disks.
```

v. Command: **sudo mke2fs -t ext4 /dev/mmcblk1p1**, format the partition

vi. Command: **sudo mount /dev/mmcblk1p1/mnt**, if success,

configurate the SD Card successfully.

tx2nx@tx2nx:~/Desktop\$ sudo mount /dev/mmcblk1p1 /mnt

- b) NVIDIA Jetson system migration (!!! Please refer to chapter 3 for system backup before migration):
 - Taking tx2nx as an example, other devices can replace the device name in the middle of the command, and the device name can refer to the above command
 - i. Command: **git clone** https://github.com/jetsonhacks/rootOnNVMe , download the script
 - ii. Modify copy-rootfs-ssd.sh, notes the mount

```
#!/bin/bash
# Mount the SSD as /mnt
# Sudo mount /dev/nvmeOnlp1 /mnt
# Copy over the rootfs from the SD card to the SSD
sudo rsync -axHAWX --numeric-ids --info=progress2 --exclude={"/dev/","/proc/","/sys/","/tmp/"
,"/run/","/mnt/","/media/*","/lost+found") / /mnt
# We want to keep the SSD mounted for further operations
# So we do not unmount the SSD
```

iii. Enter the **rootOnNVMe**, Command: **./copy-rootfs-ssd.sh**, copy the syste m file to SD Card

- iv. Refer to chapter 2, make the device in recovery mode.
- v. (In Ubuntu, refer to chapter 2): Enter the ~/nvidia/nvidia_sdk/JetPack_
 4.6_Linux_JETSON_TX2_TARGETS/Linux_for_Tegra, command: sudo ./fl
 ash.sh jetson-xavier-nx-devkit-tx2-nx mmcblk1p1 and updated the EM
 MC boot

```
greetrix@greetrix-virtual-machine:~/nvidia/nvidia_sdk/JetPack_4.6_Linux_JETSON_T
X2_TARGETS/Linux_for_Tegra$ sudo ./flash.sh jetson-xavier-nx-devkit-tx2-nx mmcbl
k1p1
```

```
[ 30.4511 ] Coldbooting the device
[ 30.4521 ] tegradevflash_v2 --reboot coldboot
[ 30.4531 ] Bootloader version 01.00.0000
[ 30.6253 ]
*** The target t186ref has been flashed successfully. ***
Make the target filesystem available to the device and reset the board to boot f
rom external mmcblk1p1.
```

vi. Reboot TX2NX, command: df -l, the system in SD Card

tx2nx@tx2nx:~\$	df -h				
Filesystem	Size	Used	Avail	Use%	Mounted on
/dev/mmcblk1p1	59G	12G	44G	21%	/
devtmpfs	1.6G	0	1.6G	0 %	/dev
tmpfs	1.9G	52K	1.9G	1%	/dev/shm
tmpfs	1.9G	21M	1.9G	2 %	/run
tmpfs	5.0M	4.0K	5.0M	1%	/run/lock
tmpfs	1.9G	0	1.9G	0 %	/sys/fs/cgroup
tmpfs	384M	12K	384M	1%	/run/user/120
tmpfs	384M	0	384M	0%	/run/user/1000

CONTACT WITH US

3. Github: https://github.com/WeActTC

4. Gitee: https://gitee.com/WeAct-TC

5. Site: https://www.weact-tc.cn/

6. Aliexpress:

 $\frac{https://www.aliexpress.com/item/1005003334440054.html?spm=5261.ProductManageOnline.0.0.48104edfJwGktm$