
Device: BMD SmartScope



Introduction

The Device Core "BMD SmartScope" can be used to control


- SmartView Duo
- SmartScope Duo 4K
- SmartView 4k

A number of parameters on the Blackmagic Design monitor series can be controlled from a SKAARHOJ control panel. The Device Core "BMD SmartScope" is used to both control the SmartView and the SmartScope. The SmartView does not have the scope features so the Scope actions will not work on this model

The implementation is done on SmartView V. 4.0.4


Number of Clients

Please notice. The SmartView/SmartScope will only accept a single client connection. If a SKAARHOJ controller is already connected to the SmartView/SmartScope the BMD Software will present this message:




SKAARHOJ DEVICE CORES

If the BMD Software *is* connected to the SmartView/SmartScope the feedback from the Serial Monitor (provided IP settings are correct) will state:




A succesful connection to the SmartView/SmartScope will look like this:



SKAARHOJ DEVICE CORES

This is a table of actions for Blackmagic Design SmartScope/SmartView monitors.

Please notice when controlling a SmartView 4K action on either A or B will adjust the monitor. If using Memory parametres to select monitor (A or B) memory A=0 equals Monitor A, A=1 equals Monitor B.



SKAARHOJ DEVICE CORES

