

Avantis TCP/IP Protocol

Firmware V1.10

This protocol is for use with Avantis systems loaded with firmware version V1.10 and later.

TCP/IP control is available via the **Network** port on the Avantis mixer. Messages are sent using the MIDI format, as described in this document.

All MIDI message numbers shown in this specification are hexadecimal. Refer to the end of this document for a table of values for each of the parameters listed here.

Clients should be configured to use TCP port 51325.

MIDI Controllable Functions and Parameters:

 Fader levels 	NRPN	Input, Mix master, FX send, FX return, DCA
----------------------------------	------	--

Mutes
 Note On
 Input, Mix master, FX send, FX return, DCA, Mute Groups

• Send levels SysEx Aux, FX and Matrix sends

DCA assign
 NRPN

• Input to Main assign NRPN

• Name & Colour SysEx

• Scene Recall Program Change

MIDI transport
 MIDI Machine Control (MMC)

MIDI Strips
 Custom Messages DAW and remote equipment control

SoftKeys
 Custom Messages Press and release messages

MIDI Running Status

Avantis uses MIDI running status. This maximises MIDI transmission efficiency by allowing a MIDI message to be sent without its Status byte if the previous transmitted message had the same Status.

For example, turning Mute on for Inputs 1, 2 and 3 on MIDI channel 12:

Without running status – Full message string 9B, 00, 7F, 9B, 01, 7F, 9B, 02, 7F

With running status – Shorter message string 9B, 00, 7F, 01, 7F, 02, 7F

MIDI Channel Number

MIDI channel 1 to 16 = 0 to F

To extend the range of audio channels that can be controlled by MIDI messages the Avantis MIDI protocol uses a range of five MIDI channels to select between audio channel types.

The base MIDI channel N is the lowest channel of the range selected in Utility / Control / MIDI and cannot exceed 12 (B). The default is MIDI Channel 12 to 16.

The audio channel type is selected by offsetting the MIDI channel used in the message and the audio channel number is selected using the note number, as detailed in 'Channel Selection' below.

Scene Recall and MIDI transport use the base MIDI channel N.

Channel Selection

N = Base MIDI channel

CH = Channel Note number (refer to table)

Channels are selected using the MIDI channel number and Note number as follows:

Inputs 1 to 64:	N	=	N,	CH =	00 to 3F
Mono Groups 1 to 40:	N	=	N + 1,	CH =	00 to 27
Stereo Groups 1 to 20:	N	=	N + 1,	CH =	40 to 53
Mono Aux 1 to 40:	N	=	N + 2,	CH =	00 to 27
Stereo Aux 1 to 20:	N	=	N + 2,	CH =	40 to 53
Mono Matrix 1 to 40:	N	=	N + 3,	CH =	00 to 27
Stereo Matrix 1 to 20:	N	=	N + 3,	CH =	40 to 53
Mono FX Send 1 to 12:	N	=	N + 4,	CH =	00 to 0B
Stereo FX Send 1 to 12:	N	=	N + 4,	CH =	10 to 1B
FX Return 1 to 12:	N	=	N + 4,	CH =	20 to 2B
Mains 1 to 3:	N	=	N + 4,	CH =	30 to 32
DCA 1 to 16:	N	=	N + 4,	CH =	36 to 45
Mute Group 1 to 8:	N	=	N + 4,	CH =	46 to 4D

SysEx Header

SvsEx Header

This applies to all SysEx messages described later in this specification.

```
F0, 00, 00, 1A, 50, 10, 01, 00
```

Mute ON

NOTE ON with velocity > 40 followed by NOTE OFF 9N, CH, 7F, 9N, CH, 00

Mute OFF

NOTE ON with velocity < 40 followed by NOTE OFF 9N, CH, 3F, 9N, CH, 00

Received Mute Messages

Velocity 00 and NOTE OFF messages are ignored

Velocity 01 to 3F = Mute OFF Velocity 40 to 7F = Mute ON

Fader Level

NRPN with parameter ID 17

Fader value LV –inf to +10dB = 00 to 7F (refer to table)

Select channel Parameter Set fader value
BN, 63, CH, BN, 62, 17, BN, 06, LV

Channel Assignment to Main Mix ON

NRPN with parameter ID 18

ON value = 40 to 7F

 Select channel
 Parameter
 Set ON

 BN, 63, CH,
 BN, 62, 18,
 BN, 06, 7F

Channel Assignment to Main Mix OFF

NRPN with parameter ID 18

OFF value = 00 to 3F

Select channel Parameter Set OFF
BN, 63, CH, BN, 62, 18, BN, 06, 3F

AUX / FX / Matrix Send Level

SysEx message

Where SndN and SndCH are the MIDI channel and Note number for the Mix to be sent to.

Send value LV –inf to +10dB = 00 to 7F (refer to table)

Message:

SysEx Header, ON, OD, CH, SndN, SndCH, LV, F7

DCA Assignment ON

NRPN with parameter ID 40

ON value **DB** for DCA 1 to 16 = 40 to 4F (refer to table)

 Select channel
 Parameter
 Set ON

 BN, 63, CH,
 BN, 62, 40,
 BN, 06, DB

DCA Assignment OFF

NRPN with parameter ID 40

OFF value **DA** for DCA 1 to 16 = 00 to 0F (refer to table)

Select channel Parameter Set OFF BN, 63, CH, BN, 62, 40, BN, 06, DA

Mute Group Assignment ON

NRPN with parameter ID 40

ON value **DB** for Mute Group 1 to 8 = 50 to 57 (refer to table)

Select channel Parameter Set ON
BN, 63, CH, BN, 62, 40, BN, 06, DB

Mute Group Assignment OFF

NRPN with parameter ID 40

OFF value **DA** for Mute Group 1 to 8 = 10 to 17 (refer to table)

 Select channel
 Parameter
 Set OFF

 BN, 63, CH,
 BN, 62, 40,
 BN, 06, DA

Channel Name

SysEx message

Gets or sets the Name with up to 8 characters (up to 8 can be displayed on the Avantis strip LCD)

To get Name from Avantis

```
Send... SysEx Header, 0N, 01, CH, F7

Reply... SysEx Header, 0N, 02, CH, Name, F7 where Name = Hex ASCII String

To set Name (refer to table)

SysEx Header, 0N, 03, CH, Name, F7 where Name = Hex ASCII String
```

Channel Colour

SysEx message

Gets or sets the Colour with a choice of 7 colours or no colour

To get Colour from Avantis

```
Send... SysEx Header, 0N, 04, CH, F7

Reply... SysEx Header, 0N, 05, CH, Col, F7 where Col = 00 to 07 (refer to table)

To set Colour

SysEx Header, 0N, 06, CH, Col, F7 where Col = 00 to 07 (refer to table)
```

Scene Recall

Bank and Program Change message

BN. 00. Bank.

To recall one of the 500 Scenes using 4 banks

Also transmits this message when a Scene is recalled from the Avantis screen

```
SS = Scene number within bank = 00 to 7F (refer to table)

Bank = Bank of scenes

Bank 1 - Scene 1 to 128

Bank = 00

Bank 2 - Scene 129 to 256

Bank = 01

Bank 3 - Scene 257 to 384

Bank = 02

Bank 4 - Scene 385 to 500

Bank = 03

Select bank

Becall Scene
```

CN. SS

MIDI Strips

Custom MIDI messages

Fader strips can be assigned as MIDI Strips. There are 32 MIDI Strips available.

Each fader strip control can be assigned to transmit a custom MIDI message. This is used for controlling audio within a Digital Audio Workstation (DAW), a slave mixer, or parameters on external equipment such as effects devices. MIDI Strips can be named and coloured. They are stored within Scenes and can be made Safe from Scene recall.

The Template Shows load the following factory default messages for the MIDI Strip controls. These can be edited to suit your application. If required, they can be restored to default from within Scene 1 'Reset Settings' in the Template Show.

```
    Fader

                            B1, 00, <VAR> to B1, 1F, <VAR>
                                                                  DAW track Level

    Gain Rotary

                            B2, 00, <VAR> to B2, 1F, <VAR>

    Pan Rotary

                            B2. 20. <VAR> to B2. 3F. <VAR>

    Sends Rotary

                            B2, 40, <VAR> to B2, 5F, <VAR>

    Rotary Custom 1

                            B2, 60, <VAR> to B2, 7F, <VAR>
• Rotary Custom 2
                            B2, 60, <VAR> to B2, 7F, <VAR>
• Rotary Custom 3
                            B2. 60. <VAR> to B2. 7F. <VAR>
Mute switch =
                            91, 00, <VAR> to 91, 1F, <VAR>
                                                                  DAW track Mute
• Mix switch =
                            91, 20, <VAR> to 91, 3F, <VAR>
                                                                  DAW track Select
• PAFL switch =
                            91, 40, <VAR> to 91, 5F, <VAR>
                                                                  DAW track Solo
```

Where <VAR> is the value determined by the position of the control.

- (i) Sel is not included as this is required to select the Processing screen for configuring the MIDI Strip.
- i By default, Rotary Custom 2 and 3 use the same values as Rotary Custom 1.

MMC (Transport Control)

```
SysEx message

F0, 7F, 7F 06, TC, F7

Where TC transport control is:

01 = Stop

02 = Play

04 = Fast Forward

05 = Rewind

06 = Record

09 = Pause
```

ALLEN&HEATH

Avantis MIDI TCP/IP Reference Table - V1.1

Scene Number 0 01 02 03 SS	Scene Number 0 01 02 03 SS	Inputs N	Mono Group N+1	Mono Aux N+2	Mono Matrix N+3	FX Return N+4	DCA DCA As N+4 Off	On Name
Bank 1 Bank 2 Bank 3 Bank 4 Hex 1 129 257 385 00	Bank 1 Bank 2 Bank 3 Bank 4 Hex 65 193 321 449 40	1 00	CH Hex	1 00	1 00	1 20	CH Hex DA 1 36 1 00	
2 130 258 386 01	66 194 322 450 41	2 01	2 01	2 01	2 01	2 21	2 37 2 01	41 0 30 B 42 b 62 " 22
3 131 259 387 02	67 195 323 451 42	3 02	3 02	3 02	3 02	3 22	3 38 3 02	
4 132 260 388 03	68 196 324 452 43	4 03	4 03	4 03	4 03	4 23	4 39 4 03	43 2 32 D 44 d 64 % 25
5 133 261 389 04 6 134 262 390 05	69 197 325 453 44 70 198 326 454 45	5 04 6 05	5 04 6 05	5 04 6 05	5 04 6 05	5 24 6 25	5 3A 5 04 6 3B 6 05	44 3 33 E 45 e 65 & 26 45 4 34 F 46 f 66 ' 27
7 135 263 391 06	71 199 327 455 46	7 06	7 06	7 06	7 06	7 26	7 3C 7 06	46 5 35 G 47 g 67 (28
8 136 264 392 07	72 200 328 456 47	8 07	8 07	8 07	8 07	8 27	8 3D 8 07	47 6 36 H 48 h 68) 29
9 137 265 393 08	73 201 329 457 48	9 08	9 08	9 08	9 08	9 28	9 3E 9 08	48 7 37 I 49 i 69 * 2A
10 138 266 394 09 11 139 267 395 0A	74 202 330 458 49 75 203 331 459 4A	10 09	10 09 11 0A	10 09 11 0A	10 09	10 29 11 2A	10 3F 10 09 11 40 11 0A	49 8 38 J 4A j 6A + 2B 4A 9 39 K 4B k 6B . 2C
12 140 268 396 0B	76 204 332 460 4B	12 OB	12 OB	12 OB	12 OB	12 2B	12 41 12 0B	
13 141 269 397 OC	77 205 333 461 4C	13 OC	13 OC	13 OC	13 OC		13 42 13 OC	
14 142 270 398 0D	78 206 334 462 4D	14 OD	14 OD	14 OD	14 OD	Mono FX Send		4D N 4E n 6E / 2F
15 143 271 399 OE	79 207 335 463 4E	15 OE	15 0E	15 OE	15 OE	N+4	15 44 15 0E	
16 144 272 400 0F 17 145 273 401 10	80 208 336 464 4F 81 209 337 465 50	16 OF 17 10	16 OF 17 10	16 0F	16 0F 17 10	CH Hex	16 45 16 OF	4F P 50 p 70 ; 3B Q 51 q 71 < 3C
18 146 274 402 11	82 210 338 466 51	18 11	18 11	18 11	18 11	2 01	MUTE Group Assig	
19 147 275 403 12	83 211 339 467 52	19 12	19 12	19 12	19 12	3 02	N+4 Off	
20 148 276 404 13	84 212 340 468 53	20 13	20 13	20 13	20 13	4 03	CH Hex DA	
21 149 277 405 14	85 213 341 469 54	21 14	21 14	21 14	21 14	5 04	1 46 1 10	
22 150 278 406 15 23 151 279 407 16	86 214 342 470 55 87 215 343 471 56	22 15 23 16	22 15 23 16	22 15 23 16	22 15 23 16	6 05 7 06	2 47 2 11 3 48 3 12	
24 152 280 408 17	88 216 344 472 57	24 17	24 17	24 17	24 17	8 07	4 49 4 13	
25 153 281 409 18	89 217 345 473 58	25 18	25 18	25 18	25 18	9 08	5 4A 5 14	
26 154 282 410 19	90 218 346 474 59	26 19	26 19	26 19	26 19	10 09	6 4B 6 15	
27 155 283 411 1A	91 219 347 475 5A	27 1A	27 1A	27 1A	27 1A	11 OA	7 4C 7 16	
28 156 284 412 1B 29 157 285 413 1C	92 220 348 476 5B 93 221 349 477 5C	28 1B 29 1C	28 1B 29 1C	28 1B 29 1C	28 1B 29 1C	12 0B	8 4D 8 17	57
30 158 286 414 1D	94 222 350 478 5D	30 1D	30 1D	30 1D	30 1D	Stereo FX Sen	id MIDI Cha	'
31 159 287 415 1E	95 223 351 479 5E	31 1E	31 1E	31 1E	31 1E	N+4	Base Chai	-
32 160 288 416 1F	96 224 352 480 5F	32 1F	32 1F	32 1F	32 1F	CH Hex	N Hex	
33 161 289 417 20 34 162 290 418 21	97 225 353 481 60 98 226 354 482 61	33 20 34 21	33 20 34 21	33 20 34 21	33 20 34 21	1 10	1 00 2 01	+10 7F 127 Colour +5 74 117 Col
35 163 291 419 22	99 227 355 483 62	35 22	34 21 35 22	35 22	35 22	2 11 3 12	3 02	+5 74 117 Col 0 6B 107 Colour Hex
36 164 292 420 23	100 228 356 484 63	36 23	36 23	36 23	36 23	4 13	4 03	-5 61 97 Off 00
37 165 293 421 24	101 229 357 485 64	37 24	37 24	37 24	37 24	5 14	5 04	-10 57 87 Red 01
38 166 294 422 25	102 230 358 486 65	38 25	38 25	38 25	38 25	6 15	6 05	-15 4D 77 Green 02
39 167 295 423 26 40 168 296 424 27	103 231 359 487 66	39 26 40 27	39 26 40 27	39 26 40 27	39 26 40 27	7 16 8 17	7 06 8 07	-20 43 67 Yellow 03 -25 39 58 Blue 04
41 169 297 425 28	105 233 361 489 68	41 28	40 27	40 21	40 21	9 18	9 08	-30 2F 48 Purple 05
42 170 298 426 29	106 234 362 490 69	42 29	Stereo Group	Stereo Aux	Stereo Matrix	10 19	10 09	-35 25 38 Lt Blue 06
43 171 299 427 2A	107 235 363 491 6A	43 2A	N+1	N+2	N+3	11 1A	11 0A	-40 1B 28 White 07
44 172 300 428 2B	108 236 364 492 6B	44 2B	CH Hex	CH Hex	CH Hex	12 1B	12 0B	-
45 173 301 429 2C 46 174 302 430 2D	109 237 365 493 6C 110 238 366 494 6D	45 2C 46 2D	1 40 2 41	1 40 2 41	1 40 2 41	Mains	13 OC 14 OD	-inf 00 0
47 175 303 431 2E	111 239 367 495 6E	47 2E	3 42	3 42	3 42	N+4	15 OE	
48 176 304 432 2F	112 240 368 496 6F	48 2F	4 43	4 43	4 43	CH Hex	16 OF	
49 177 305 433 30	113 241 369 497 70	49 30	5 44	5 44	5 44	1 30		
50 178 306 434 31 51 179 307 435 32	114 242 370 498 71 115 243 371 499 72	50 31 51 32	6 45 7 46	6 45 7 46	6 45 7 46	2 31	SysEx Header	F0, 00, 00, 1A, 50, 10, 01, 00
51 179 307 435 32	115 243 371 499 72 116 244 372 500 73	51 32 52 33	8 47	8 47	8 47	3 32	Mutes On(Off)	9N, CH, 7F(3F), 9N, CH, 00
53 181 309 437 34	117 245 373 74	53 34	9 48	9 48	9 48		Fader Levels	BN, 63, CH, BN, 62, 17, BN, 06, LV
54 182 310 438 35	118 246 374 75	54 35	10 49	10 49	10 49		Aux/FX/Mtx Sends	SysEx Header, 0N, 0D, CH, SndN, SndCH, LV, F7
55 183 311 439 36	119 247 375 76	55 36	11 4A	11 4A	11 4A		Ch>Main Assign	BN, 63, CH, BN, 62, 18, BN, 06, 7F(3F)
56 184 312 440 37 57 185 313 441 38	120 248 376 77 121 249 377 78	56 37 57 38	12 4B 13 4C	12 4B 13 4C	12 4B 13 4C		DCA Assign On(Off) Mute Grp Assign) BN, 63, CH, BN, 62, 40, BN, 06, DB(DA) BN, 63, CH, BN, 62, 40, BN, 06, DB(DA)
58 186 314 442 39	122 250 378 79	58 39	14 4D	13 4C	14 4D		Ch Name Request	
59 187 315 443 3A	123 251 379 7A	59 3A	15 4E	15 4E	15 4E		Ch Name Reply	SysEx Header, 0N, 02, CH, Name, F7
60 188 316 444 3B	124 252 380 7B	60 3B	16 4F	16 4F	16 4F		Ch Name Set	SysEx Header, 0N, 03, CH, Name, F7
61 189 317 445 3C 62 190 318 446 3D	125 253 381 7C	61 3C	17 50	17 50	17 50			SysEx Header, 0N, 04, CH, F7
62 190 318 446 3D 63 191 319 447 3E	126 254 382 7D 127 255 383 7E	62 3D 63 3E	18 51 19 52	18 51 19 52	18 51 19 52		Ch Colour Reply Ch Colour Set	SysEx Header, 0N, 05, CH, Col, F7 SysEx Header, 0N, 06, CH, Col, F7
64 192 320 448 3F	128 256 384 7F	64 3F	20 53	20 53	20 53		Scene Recall	BN, 00, Bank, CN, SS