# WiFi Setup

Connect to your computer (use the Left Connector near Henderson Station)



Open a browser (e.g. Chrome)



Go to keastudios.co.nz/wt



Press Connect
Device and follow
the instructions on
the page...

# **Train Lines**

Eastern

Southern

Western

Onehunga

Out of Service

#### **LEDs and Buttons**

Power Internet WiFi



Turn On/Off Brightness Up Brightness Down



## Care

### **Looking after Your Map**

Avoid exposure to temperature extremes, moisture, sand, and dust.

If the product has been in contact with water do not dry it in rice. Do not power the device and place it in a warm place (less than 80°C) for at least a few days before powering it on.

You can clean the Train map using >95% Isopropyl alcohol and a clean lint free cloth (only while the device is unpowered).

## **Extra Stuff**





github.com/CDFER/Auckland-LED-Train-Map

Made by Kea Studios in Auckland, New Zealand

### **Specifications**

5V ≥1A via USB Type C Supports WiFi 4 (802.11b/g/n) RoHS (Lead Free)

Feedback → KeaStudios.co.nz/fb

SN: AKL-LTM-100-





