Remote Control



Power ON	Press	Hold
0.0	Prepare for Time Travel - or - Previous Song*	Play/Stop
RESET	Next Song	Toggle Shuffle
CALIBRATION	Reset speed	Display IP address, battery state**

Power OFF	Press	Hold	
0.0	Volume up	Brightness up	
RESET	Volume down	Brightness down	
CALIBRATION	Calibrate neutral	Start calibration for up and down	

^{*} Depending on device setup

^{**} If battery monitoring is available; State-of-Charge and Time-To-Empty (minutes) shown alternately

Remote Control



Special key sequences	TCD
Toggle Movie-mode/linear acceleration	7060
Toggle TCD speed display while off	7061
Toggle Auto-Throttle	7062
Select volume level (00 - 19)	73xx
Enable acceleration click sound	7350
Disable acceleration click sound	7351
Select brightness level (00 - 15)	74xx
Music Player : Play / Stop	7005
Music Player : Previous Song	7002
Music Player : Next Song	7008
Music Player : Set folder number	705x
Music Player : Shuffle off	7222
Music Player : Shuffle on	7555
Music Player : Go to song 000	7888
Music Player : Go to song xxx	7888xxx
Play "keyX.mp3" on SD card (X = 1, 3, 4, 6, 7, 9)	700x
Display current IP address	7090
Battery: Display State-of-Charge (percent)*	7091
Battery: Display Time-To-Empty (minutes)*	7092
Battery: Display voltage*	7093
Restart	7064738
Delete static IP address	7123456

Control through TCD requires BTTFN connection.

_

^{*} If battery monitoring is available