Arduino	MT8808	Connection
2	4	DATA
3	C64-3	RESTORE
4	2	STROBE
5	1	AY2
6	28	AY1
7	27	AY0
8	26	AX2
9	25	AX1
10	24	AX0
11	N/A	N/A
12	10	RESET

MT8808	Connection
15	PB3-Y3
12	PB6-Y6
13	PB5-Y5
14	PB4-Y4
11	PB7-Y7
16	PB2-Y2
17	PB1-Y1
18	PBO-YO
6	PA0-X0
9	PA6-X6
21	PA5-X5
8	PA4-X4
22	PA3-X3
7	PA2-X2
23	PA1-X1
20	PA7-X7
	15 12 13 14 11 16 17 18 6 9 21 8 22 7

POWER	PIN	LABEL
GND	3 & 5	VEE & VSS
+ 5 VDC	19	VDD