

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected [Class \[general description\]](#).
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

To query the value of a *read-only attribute*, you might, for example, type:

```
print MySankeyDiagram.UUID
```

Attributes of the SankeyDiagram

_Attributes of the SankeyDiagram

The *SankeyDiagram* provides:

- The *attributes* listed in the table of contents to the left.
- The [Attributes of All Objects](#).

To view all of the *methods*, *read-only attributes*, and *attributes* of the object, open the window [Show Attributes and Methods](#). The figure below illustrates the information using the example of the object *Station*.

Name	Value	Inherited	Watchable	Signature
MoveToFolderCtrl	VOID	✓		method
MTTR	0.0000			time
Name	"Station"	✓	*	string

Name of the attribute Current value of the attribute Data type of the assignment value

- Select **Show Attributes and Methods** on the context menu of the **Class Library** to show the *methods*, *read-only attributes*, and *attributes* of the selected [Class \[general description\]](#).
- Press the **F8** key or click **Show Attributes and Methods** on the **Home** ribbon tab of the *Frame* into which you inserted an instance to show the *methods*, *read-only attributes*, and *attributes* of the selected [Instance \[general description\]](#).

You can set the value of an attribute and you can get its value, either with the check boxes, the text boxes and drop-down lists in the dialog windows or by assigning values to the respective attributes.

- To **set the value** of an attribute, you might, for example, type:

```
MySankeyDiagram.IsShown := true
```

- To **get the value** of an attribute, you might, for example, type:

```
print MySankeyDiagram.IsShown  
posit := Station.Cont.XPos
```

CollectData [SimTalk] - SankeyDiagram

Sets if the *SankeyDiagram* designated by <Path> collects data (`true`) or does not collect data (`false`).

Type

Attribute

Syntax

```
<Path>.CollectData: boolean
```

Assignment Value

You can assign a value of data type *boolean*.

Example

```
MySankeyDiagram.CollectData := true
```

See also

[Collect Data \[check box\] - SankeyDiagram](#)

Color [SimTalk] - SankeyDiagram

Sets the color which *Plant Simulation* uses for displaying the *Sankey flows* of the *parts* and *Workers* of the *SankeyDiagram* designated by <Path> in the *Frame*.

Remarks

Set the RGB values of the color with the method *makeRGBValue*.

Type

Attribute

Syntax

```
<Path>.Color:integer
```

Assignment Value

You can assign a value of data type *integer*.

Example

```
MySankeyDiagram.Color := makeRGBValue(255,0,0)
```

SimTalk

[makeRGBValue \[SimTalk\]](#)

See also

[Color \[SankeyDiagram\]](#)

IsShown [SimTalk] - SankeyDiagram

Activates (`true`) or deactivates (`false`) the display of the *SankeyDiagram* designated by `<Path>`.

Type

Attribute

Syntax

```
<Path>.IsShown: boolean
```

Assignment Value

You can assign a value of data type *boolean*.

Example

```
MySankeyDiagram.IsShown := false
```

See also

[Show Diagram](#)

MaximumWidth [SimTalk]

Sets the maximum width with which *Plant Simulation* visualizes the *Sankey* flows of the *parts* and *Workers* of the *SankeyDiagram* designated by <Path> in the *Frame*.

Type

Attribute

Syntax

```
<Path>.MaximumWidth:length
```

Assignment Value

You can assign a value of data type *length*.

Example

```
MySankeyDiagram.MaximumWidth := 1.0 -- meters
```

See also

[Maximum Width \[SankeyDiagram\]](#)

Objects [SimTalk] - SankeyDiagram

Sets the objects, i.e., the *Parts* or *Workers* whose *Sankey* flows which the *SankeyDiagram* designated by `<Path>` visualizes in the *Frame*.

Type

Attribute

Syntax

```
<Path>.Objects:array
```

Assignment Value

You can assign a value of data type *array*.

Example

```
MySankeyDiagram.Objects := [.Resources.Worker]           // all Workers of
this class
MySankeyDiagram.Objects := [.Resources.WorkerPool]       // all WorkerPool
classes
MySankeyDiagram.Objects := [.Models.Model.WorkerPool]    // all Workers of
the WorkerPool in the Frame named Frame
MySankeyDiagram.Objects := [.Resources.Worker:1]         // the Worker with
the number 1
```

See also

[Objects](#), tab

CostAnalyzer

CostAnalyzer

Use the object *CostAnalyzer* for analyzing costs that the individual *machines* and the *Worker* cause. The *CostAnalyzer* computes the costs that accrue for the material flow objects while processing the parts in the facility.

Image

