


1. How to modify the time zone.

We need to enter the command shown below at the command terminal to open the raspbian system settings interface:


sudo raspi-config

1.1 As shown below, move to the 4th step "localisation Options" via the keyboard up and down keys and press Enter.

!Note: Each system version is different, the choice is different, my is in item 4, it is possible that you are in 5 items and 6 items, you have to choose carefully after careful observation.




1.2 Then, we need to select "change Timezone"




1.3 Next, it will prompt us to choose a region. I choose Asia here (because China is in Asia, users need to choose according to their current region)





1.4 Select region: Shanghai.(for example) (!!Note: Choose a city closest to you)


Then press Enter and it will be OK.



1.5 We need to select "Change Wi-fi Country" and select "China".

!!Note: Choose your own country





```
File Edit Tabs Help

Select the country in which the Pi is to be used

CD Congo (Dem. Rep.)

CF Central African Rep.

CG Congo (Rep.)

CH Switzerland

CI Côte d'Ivoire

CK Cook Islands

CL Chile

CM Cameroon


CN China

CO Colombia

CO Colombia
```

1.6 Click "ok".





6. Finally, you can connect your WIFI.

