
# LGF\_StringToInt

### **Short description**

This block converts a variable of data type "String" into a variable of system data type "DInt".

#### **Block**



## Input parameters

Parameters	Data type	Description
value	STRING	Value to be converted as string. Example: '+16927'

### **Output parameters**

Parameters	Data type	Description
Ret_Val	DINT	Converted integer value

#### **Further information on libraries in TIA Portal:**

- Topic page libraries
   https://support.industry.siemens.com/cs/ww/en/view/109738702
- Guideline on Library Handling <a href="https://support.industry.siemens.com/cs/ww/en/view/109747503">https://support.industry.siemens.com/cs/ww/en/view/109747503</a>
- Programming Guideline for S7-1200/1500 in chapter "Libraries" <a href="https://support.industry.siemens.com/cs/ww/en/view/81318674">https://support.industry.siemens.com/cs/ww/en/view/81318674</a>
- Programming Styleguide https://support.industry.siemens.com/cs/ww/en/view/81318674