

## **Implementing a Simple Serial Mouse Controller**

## INTRODUCTION

The mouse is becoming increasingly popular as a standard pointing data entry device. There is no doubt that the demand for the mouse is increasing. Various kinds of mice can be found in the market, including optical mice, opto-mechanical mice, and their close relative, trackballs. The mouse interfaces to the host via a dedicated interface card or an RS-232 port. Their mechanisms are very similar. The major electrical components of a mouse are:

- Microcontroller
- · Photo-transistors
- · Infrared emitting diode
- · Voltage conversion circuit

The intelligence of the mouse is provided by the microcontroller, therefore the features and performance of a mouse is greatly related to the microcontroller used.

This application note describes the implementation of a serial mouse using the PIC16C54. The PIC16C54 is a high speed 8-bit CMOS microcontroller offered by Microchip Technology Inc. It is an ideal candidate for a mouse controller.

## THEORY OF OPERATION


A mouse can be divided into several functional blocks:

- Microcontroller
- · Button detection
- · Motion detection
- RS-232 signal generation
- 5V DC power supply unit

A typical functional block diagram is shown in Figure 1.

In Figure 2, three pushbuttons are connected to the input ports of the PIC16C54. When a switch opening or closure is detected, a message is formatted and sent to the host. The X and Y movements are measured by counting the pulses generated by the photo-couplers. In the case of an opto-mechanical mouse, the infrared light emitted by the infrared diode is blocked by the rotating wheel, so that the pulses are generated on the photo-transistor side. In case of an optical mouse, the infrared light emitted by the infrared diode is reflected off the reflective pad patterned with vertical and horizontal grid lines. It is then received by the photo-transistor in the mouse. When any X or Y movement is detected, a message is formatted and sent to the host.

FIGURE 1: FUNCTIONAL BLOCKS OF A SERIAL MOUSE



The Microsoft® Mouse System and the Mouse Systems® device both use serial input techniques. The Mouse System protocol format contains five bytes of data. One byte describes the status of three push buttons, two bytes for the relative X movements and two bytes for the relative Y movements. The Microsoft protocol format contains three bytes of data describing the status of two push buttons and the relative X and Y movements. The details of these protocols are given in Table 1.

Three lines are connected to the host via the RS-232 port:

- · Signal Ground
- Received Data
- · Request to Send

"Received Data" carries the message sent by the mouse. While "Request to Send" provides a -10 VDC for voltage conversion circuitry. A voltage of +5 VDC is required for electronic components inside the mouse, however, +5 VDC is not part of an RS-232 port, so voltage conversion circuitry is required. This circuit is typically composed of a 555 timer, Zener diodes, and capacitors.

An example circuit is shown in Figure 3. Since the current supplied through the RS-232 port is limited to 10 mA, the mouse cannot be designed to consume more than 10 mA current unless an external power supply is provided. The PIC16C54, running at 4 MHz (1  $\mu s$  instruction cycle) can provide a very high tracking speed. An 8 MHz version of PIC16C54 is also available if higher performance is desired.

FIGURE 2: PIC16C54 PIN ASSIGNMENTS





FIGURE 3: VOLTAGE CONVERSION CIRCUITRY



## **ABOUT THE SOFTWARE**

The major tasks performed by the software are button scanning, X and Y motion scanning, formatting and sending serial data to the host. These tasks need to be performed in parallel in order to gain better tracking speed. The pulses generated by the photo-couplers are counted while transmitting the serial signals to the RS-232 port. The number of pulses reflects the speed of the movement. The more pulses, the faster the movement.

The directions of movement are determined by the last states and the present states of the outputs of the photo-transistors. In Figure 4, XCLOCK and XDATA are outputs from the photo-transistors corresponding to the X-axis movement. XDATA is read when a rising or a fall-

ing edge of XCLOCK is detected. For right movement, XDATA is either LOW at the rising edge of XCLOCK or HIGH at the falling edge of XCLOCK. The up and down movement detections follow the same logic. In Table 1, X7:X0 are data for relative movement. If X is positive, it implies that the mouse is moving to the right. If X is negative, it implies a movement to the left. Similarly, if Y is positive, it indicates that the mouse is moving down and if Y is negative, it indicates that the mouse is moving up. The pulses generated by the photo-couplers are checked before every bit is sent. A bit takes 1/1200 second to send, if the distance between the grid lines is 1 mm, the tracking speed will be up to 1200 mm/second.






TABLE 1: MOUSE SYSTEM AND MICROSOFT PROTOCOLS

	Mou			se System Format*				Microsoft Format*								
Bit Position	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
Byte 1	1	0	0	0	0	L	М	R	1	1	L	R	Y7	Y6	X7	X6
Byte 2	X7	X6	X5	X4	ХЗ	X2	X1	X0	0	0	X5	X4	ХЗ	X2	X1	X0
Byte 3	Y7	Y6	Y5	Y4	Y3	Y2	Y1	Y0	0	0	Y5	Y4	Y3	Y2	Y1	Y0
Byte 4	X7	X6	X5	X4	Х3	X2	X1	X0								
Byte 5	Y7	Y6	Y5	Y4	Y3	Y2	Y1	Y0								
M = Mid	Key Status 1 = Pressed dle Key Status 0 = Released t Key Status				-X0 = X-Axis Movement Data -Y0 = Y-Axis Movement Data											

The buttons are scanned after a message is sent and the time used to send the message is used as the debouncing time. The message is in an RS-232 format with 1200 baud, eight data bits, no parity, and two stop bits.

The flowcharts of the main program, subroutine BYTE and subroutine BIT are shown in Figure 5, Figure 6, and Figure 7. Figure 5 shows that the trigger flag is set when any change in button status or X/Y movement is detected. Subroutine BYTE is called in the main program five times to send five bytes of information. Subroutine BYTE controls the status of the "Received Data" (RD) pin. If Trigger Flag is clear, RD will always be HIGH. Hence, no message will be sent even when subroutine BYTE is called. Figure 7 shows that subroutine BIT counts the number of pulses from the outputs of the photo-transistors, determines the directions, and generates a 1/1200 second delay to get 1200 baud timing.

The mouse has been tested in Mouse System Mode and functions properly. The setup and software have been tested and function within the given guidlines. A listing of the source program is given in Appendix A.

## **SUMMARY**

The PIC16C54 from Microchip Technology Inc. provides a very cost-effective, high performance mouse implementation. Its low power consumption (typically< 2 mA at 1  $\mu s$  instruction cycle), small package (18-pin) and high reliability (on-chip watchdog timer to prevent software hang-ups) are some of the many reasons why the PIC16C54 is uniquely suitable for mouse applications.

**Note:** This application note provides the user with a simple, fully functional serial mouse implementation. The user may use this as a starting point for a more comprehensive design.

FIGURE 5: FLOWCHART OF THE MAIN PROGRAM




FIGURE 6: FLOWCHART OF ROUTINE BYTE





FIGURE 7: FLOWCHART OF ROUTINE BIT



Please check the Microchip BBS for the latest version of the source code. Microchip's Worldwide Web Address: www.microchip.com; Bulletin Board Support: MCHIPBBS using CompuServe® (CompuServe membership not required).

## APPENDIX A: MOUSE.ASM

```
MPASM 01.40 Released
                              MOUSE.ASM 1-16-1997 12:44:22
                                                                    PAGE 1
LOC OBJECT CODE
                   LINE SOURCE TEXT
 VALUE
                  00001 TITLE " MOUSE "
                   00002 LIST P=16C54,R=0
                   00003;
                   00004;
                   00006;
                   00007 ;
                           MOUSE CONTROLLER
                   00008; PIC MODE = PIC16C54XT CLK=4.0MHZ
                  00009;
                  00010 ;
                                                MOUSE.ASM
                              Program:
                   00011 ;
                               Revision Date: 25 APRIL, 1990
                   00012 ;
                                                1-13-97
                                                           Compatibility with MPASMWIN 1.40
                   00013 ;
                   00014 ;**********************************
                  00015 ;
                   00016 ;-----
                   00017; FILES ASSIGNMENT
                  00018 ;-----
                  00019 ;
                                               ;STATUS REGISTER;I/O PORT A
 00000003
                  00020 STATUS EQU 3
 00000005
                  00021 RA EQU 5
               00022 RB EQU 5
00022 RB EQU 6
00023 TIMER1 EQU 10
00024 CSTAT EQU 14
00025 BSTAT EQU 15
00026 DATA0 EQU 16
00027 DATA1 EQU 17
00028 DATA2 EQU 20
00029 DATA3 EQU 21
00030 DATA4 EQU 22
00031 FLAGA EQU 23
 00000006
                                                ;I/O PORT B
;COUNTER FOR DELAY
;CO-ORDINATE STATUS
;BUTTON STATUS
                                                  ;I/O PORT B
 80000008
 000000C
 0000000D
 000000E
 000000F
                                               ;5 BYTE RS232 DATA
 00000010
 00000011
                                                 ;
 00000012
                                                  ;
 00000013
                                                  GENERAL PURPOSE FLAG
                  00032 XCOUNT
 00000014
                                  EQU 24
                                                   ;X-MOVEMENT COUNTER
                 00032 XCOUNT EQU 24
00033 YCOUNT EQU 25
00034 FLAGB EQU 26
00035 COUNT EQU 30
 00000015
                                                   ; Y-MOVEMENT COUNTER
 00000016
                                                  GENERAL PURPOSE FLAG
 00000018
                                                  GENERAL PURPOSE COUNTER
 00000019
                  00036 DATA_AREA EQU 31
                                                  ; FOR TEMP. STORAGE
                  00037 ;
                  00038 ;-----
                  00039 ;
                           BIT ASSIGNMENT
                  00040 ;-----
                  00041 ;
 00000000
                                EQU 0
EQU 1
                  00042 YC
                                                      ;Y-CLOCK PIN
 00000001
                  00043 YD
                                                      ;Y-DATA PIN
                               EQU 1
EQU 2
EQU 3
EQU 3
EQU 0
EQU 2
                00044 UP
                                                     ;MOVING UP FLAG
 00000001
                00045 XC
00046 XD
 00000002
                                                     ;X-CLOCK PIN
 0000003
                                                     ;X-DATA PIN
 0000003
                00047 RI
                                                     ; MOVING RIGHT FLAG
                00048 BU1
                                                     ;BUTTON #1 PIN
 00000000
                  00049 BU2
 00000002
                                                      ;BUTTON #2 PIN
 00000000
                  00050 CA
                                  EQU 0
                                                      ; CARRY FLAG
 00000007
                  00051 RD
                                  EQU 7
                                                      ; RECEIVED DATA PIN TO RS232
 00000002
                  00052 ZERO_AREA EQU 2
                                                      ;ZERO FLAG
 00000002
                  00053 TR
                                  EQU 2
                                                      ;TIGGER FLAG
                   00054 ;
```

## **AN519**

00000001	00055		EQU 1	
	00056			=======================================
	00057	-	SUBROUTINES	
				=======================================
	00060			
			*****	******
0000	00062	ORG 0		
	00063	; * * * * * * *	*****	******
	00064	;		
	00065	;======		=======================================
	00066	; DELAY A	A BIT TIME A	ND CHECK XC & YC STATUS
	00067	;======		=======================================
0000	00068	BIT		
0000 0745	00069	BTFSS	RA,XC	XC = 1?
0001 0A0A	00070	GOTO	BIT0	
0002 064C	00071	BTFSC	CSTAT,XC	; (XC=1)
0003 0A11	00072	GOTO	BITY	;(XC ALWAYS = 1)
0004 02B4	00073	INCF	XCOUNT, F	; (XC  )
0005 0476	00074	BCF	FLAGB,RI	;DEFAULT LEFT
0006 0765	00075	BTFSS	RA,XD	;LEFT / RIGHT ?
0007 0A11	00076	GOTO	BITY	
0008 0576	00077	BSF	FLAGB,RI	
0009 0A11	00078	GOTO	BITY	
A000	00079	BIT0		
000A 074C	08000	BTFSS	CSTAT,XC	; (XC=0)
000B 0A11	00081	GOTO	BITY	;(XC ALWAYS = 0)
000C 02B4	00082	INCF	XCOUNT, F	; (XC )
000D 0476	00083	BCF	FLAGB,RI	;DEFAULT LEFT
000E 0665		BTFSC	RA,XD	;LEFT / RIGHT ?
000F 0A11		GOTO	BITY	
0010 0576	00086	BSF	FLAGB,RI	
0011	00087			
0011 0705	00088	BTFSS	RA,YC	;YC = 1 ?
0012 0A1B		GOTO	BITY0	
0013 060C	00090	BTFSC	CSTAT, YC	; (YC=1)
0014 0A22	00091	GOTO	BITDY	; (YC ALWAYS = 1)
0015 02B5	00092	INCF	YCOUNT, F	; (YC   )
0016 0436	00093	BCF	FLAGB, UP	; DEFAULT DOWN
0017 0725		BTFSS	RA, YD	;DOWN / UP ?
0018 0A22 0019 0536		GOTO	BITDY	
0019 0336 001A 0A22	00096 00097	BSF	FLAGB,UP BITDY	
001B 0A22	00097		BIIDI	
001B 070C	00099	BTFSS	CSTAT, YC	; (YC=0)
001C 0A22	00100		BITDY	; (YC ALWAYS = 0)
001D 02B5	00101	INCF	YCOUNT, F	; (YC )
001E 0436	00102		FLAGB, UP	;DEFAULT DOWN
001F 0625	00103		RA,YD	;DOWN / UP ?
0020 0A22		GOTO	BITDY	
0021 0536	00105		FLAGB, UP	
0022	00106		, ,	
0022 0205	00107	MOVF	RA,W	;SAVE COOR. STATUS
0023 002C	00108	MOVWF	CSTAT	
0024 0CC1	00109	MOVLW	193D	;0.833 MS DELAY
0025 0028	00110	MOVWF	TIMER1	
0026	00111	BITD0		
0026 0000	00112	NOP		
0027 02E8	00113	DECFSZ	TIMER1, F	
0028 0A26	00114	GOTO	BITD0	
0029 0800	00115	RETLW 0		
	00116	;		
	00118			
				********
	00120	;* 5	SUBROUTINE T	O SEND A BYTE *

	00121 :*	AS RS232C FORMAT	* * N 1
			******
	00123 ;		
002A	00124 BYTE		
002A 0078	00125 CLRF	COUNT	RESET 8 BIT COUNT
002B 0753	00126 BTFSS	FLAGA,TR	;ANY TRIGGER
002C 0A2E	00127 GOTO		
002D 04E6	00128 BCF	RB,RD	;LOW RD FOR START BIT
002E	00129 BYTE0		
002E 0900 002F	00130 CALL 00131 BYTE1	BIT	
002F 002F 0753	00131 BYTE1 00132 BTFSS	FLAGA,TR	;ANY TRIGGER ?
002F 0733	00132 B1F33		/ANI IRIGGER :
0031 0339	00133 GGTG	DATA_AREA, F	;SHIFT DATA TO CARRY
0032 0703	00135 BTFSS		;0 / 1 ?
0033 0A36	00136 GOTO		
0034 05E6	00137 BSF	RB,RD	;SEND A 1
0035 0A37	00138 GOTO	BYTE3	
0036	00139 BYTE2		
0036 04E6	00140 BCF	RB,RD	;SEND A 0
0037	00141 BYTE3		
0037 0900	00142 CALL		
0038 02B8	00143 INCF	,	· COINE 0 2
0039 0778 003A 0A2F	00144 BTFSS 00145 GOTO		;COUNT = 8 ?
003B 0753	00145 GOTO		;ANY TRIGGER ?
003C 0A42	00110 BIFS	- ,	/ANI IRIGOER .
003D 04E6	00117 GGTG	RB,RD	;SEND SENT BIT
003E 0900	00149 CALL	BIT	
003F 05E6	00150 BSF	RB,RD	
0040 0900	00151 CALL	BIT	
0041 0A44	00152 GOTO	BYTE5	
0042	00153 BYTE4		
0042 0900	00154 CALL	BIT	
0043 0900	00155 CALL		
0044	00156 BYTE5		
	00156 BYTE5 00157 RETLW		
0044	00156 BYTE5 00157 RETLW 00158 ;	1 0	
0044	00156 BYTE5 00157 RETLW 00158; 00159;=====	v 0	:======
0044	00156 BYTE5 00157 RETLW 00158 ; 00159 ;===== 00160 ;	V 0  RESET ENTRY	
0044	00156 BYTE5 00157 RETLW 00158 ; 00159 ;===== 00160 ;	V 0  RESET ENTRY	
0044	00156 BYTE5 00157 RETLW 00158 ; 00159 ;===== 00160 ; 00161 ;=====	V 0  RESET ENTRY	
0044 0044 0800	00156 BYTE5 00157 RETLW 00158; 00159;===== 00160; 00161;===== 00162; 00163 INIT	V 0  RESET ENTRY	
0044 0044 0800 0045	00156 BYTE5 00157 RETLW 00158; 00159;===== 00160; 00161;===== 00162; 00163 INIT	N 0  RESET ENTRY  B'11000001'	
0044 0044 0800 0045 0045 0CC1 0046 0002 0047 0COF	00156 BYTE5 00157 RETLW 00158; 00159;===== 00160; 00161;===== 00162; 00163 INIT 00164 MOVLW	N 0  RESET ENTRY  B'11000001'	
0044 0044 0800 0045 0045 0CC1 0046 0002 0047 0C0F 0048 0006	00156 BYTE5 00157 RETLW 00158; 00159;===== 00160; 00161;===== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS	N 0  RESET ENTRY  B'11000001'  N B'00001111'  RB	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS ;RB4~7 BE OUTPUTS
0044 0044 0800 0045 0045 0CC1 0046 0002 0047 0C0F 0048 0006 0049 0CFF	00156 BYTE5 00157 RETLW 00158; 00159;===== 00160; 00161;===== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS 00168 MOVLW	TO 0  RESET ENTRY  B'11000001'  B'00001111'  RB  B'11111111'	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS
0044 0044 0800 0045 0045 0CC1 0046 0002 0047 0C0F 0048 0006 0049 0CFF 004A 0005	00156 BYTE5 00157 RETLW 00158; 00159;===== 00160; 00161;===== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS 00168 MOVLW 00169 TRIS	RESET ENTRY  B'11000001'  B'00001111'  RB B'11111111'  RA	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS ;RB4~7 BE OUTPUTS ;INIT RA0~3 BE INPUTS
0044 0044 0800 0045 0045 0CC1 0046 0002 0047 0C0F 0048 0006 0049 0CFF 004A 0005 004B 05E6	00156 BYTE5 00157 RETLW 00158; 00159;====== 00160; 00161;====== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS 00168 MOVLW 00169 TRIS 00170 BSF	RESET ENTRY  B'11000001'  B'00001111'  RB B'11111111'  RA RB,RD	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS ;RB4~7 BE OUTPUTS ;INIT RA0~3 BE INPUTS ;HIGH RD PIN
0044 0044 0800 0045 0045 0CC1 0046 0002 0047 0C0F 0048 0006 0049 0CFF 004A 0005 004B 05E6 004C 0246	00156 BYTE5 00157 RETLW 00158; 00159;====== 00160; 00161;====== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS 00168 MOVLW 00169 TRIS 00170 BSF 00171 COMF	RESET ENTRY  B'11000001'  B'00001111'  RB B'11111111'  RA  RB,RD  RB,W	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS ;RB4~7 BE OUTPUTS ;INIT RA0~3 BE INPUTS
0044 0044 0800 0045 0CC1 0046 0002 0047 0C0F 0048 0006 0049 0CFF 004A 0005 004B 05E6 004C 0246 004D 0E05	00156 BYTE5 00157 RETLW 00158; 00159;====== 00160; 00161;====== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS 00168 MOVLW 00169 TRIS 00170 BSF 00171 COMF 00172 ANDLW	RESET ENTRY  B'11000001'  B'00001111'  RB B'11111111'  RA  RB,RD  RB,W B'00000101'	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS ;RB4~7 BE OUTPUTS ;INIT RA0~3 BE INPUTS ;HIGH RD PIN
0044 0044 0800 0045 0CC1 0046 0002 0047 0C0F 0048 0006 0049 0CFF 004A 0005 004B 05E6 004C 0246 004D 0E05 004E 0D80	00156 BYTE5 00157 RETLW 00158; 00159;====== 00160; 00161;====== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS 00168 MOVLW 00169 TRIS 00170 BSF 00171 COMF 00172 ANDLW 00173 IORLW	RESET ENTRY  B'11000001'  B'00001111'  RB  B'11111111'  RA  RB,RD  RB,W  B'00000101'  B'10000000'	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS ;RB4~7 BE OUTPUTS ;INIT RA0~3 BE INPUTS ;HIGH RD PIN
0044 0044 0800 0045 0CC1 0046 0002 0047 0C0F 0048 0006 0049 0CFF 004A 0005 004B 05E6 004C 0246 004D 0E05	00156 BYTE5 00157 RETLW 00158; 00159;====== 00160; 00161;====== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS 00168 MOVLW 00169 TRIS 00170 BSF 00171 COMF 00172 ANDLW	RESET ENTRY  B'11000001'  RB B'00001111'  RB B'11111111'  RA  RB,RD  RB,W B'00000101'  B'10000000'  BSTAT	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS ;RB4~7 BE OUTPUTS ;INIT RA0~3 BE INPUTS ;HIGH RD PIN
0044 0044 0800 0045 0CC1 0046 0002 0047 0C0F 0048 0006 0049 0CFF 004A 0005 004B 05E6 004C 0246 004D 0E05 004E 0D80 004F 002D	00156 BYTE5 00157 RETLW 00158; 00159;====== 00160; 00161;====== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS 00168 MOVLW 00169 TRIS 00170 BSF 00171 COMF 00172 ANDLW 00173 IORLW 00174 MOVWE	RESET ENTRY  B'11000001'  RB B'00001111'  RB B'11111111'  RA  RB,RD  RB,W B'00000101'  B'10000000'  BSTAT	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS ;RB4~7 BE OUTPUTS ;INIT RA0~3 BE INPUTS ;HIGH RD PIN
0044 0044 0800 0045 0CC1 0046 0002 0047 0C0F 0048 0006 0049 0CFF 004A 0005 004B 05E6 004C 0246 004D 0E05 004E 0D80 004F 002D 0050 002E	00156 BYTE5 00157 RETLW 00158; 00159;====== 00160; 00161;====== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS 00168 MOVLW 00169 TRIS 00170 BSF 00171 COMF 00172 ANDLW 00173 IORLW 00174 MOVWM 00175 MOVWM	RESET ENTRY  B'11000001'  RB B'00001111'  RB B'11111111'  RA RB,RD RB,W B'00000101' B'10000000' F BSTAT F DATAO RA,W	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS ;RB4~7 BE OUTPUTS ;INIT RA0~3 BE INPUTS ;HIGH RD PIN
0044 0044 0800 0045 0CC1 0046 0002 0047 0C0F 0048 0006 0049 0CFF 004A 0005 004B 05E6 004C 0246 004D 0E05 004E 0D80 004F 002D 0050 002E 0051 0205	00156 BYTE5 00157 RETLW 00158; 00159;====== 00160; 00161;====== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS 00168 MOVLW 00169 TRIS 00170 BSF 00171 COMF 00172 ANDLW 00173 IORLW 00174 MOVWE 00175 MOVWE	RESET ENTRY  B'11000001'  RB B'00001111'  RB B'11111111'  RA RB,RD RB,W B'00000101' B'10000000' F BSTAT F DATAO RA,W	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS ;RB4~7 BE OUTPUTS ;INIT RA0~3 BE INPUTS ;HIGH RD PIN
0044 0044 0800 0045 0001 0046 0002 0047 000F 0048 0006 0049 00FF 004A 0005 004B 05E6 004C 0246 004D 0E05 004E 0D80 004F 002D 0050 002E 0051 0205 0052 002C	00156 BYTE5 00157 RETLW 00158; 00159;====== 00160; 00161;====== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS 00168 MOVLW 00169 TRIS 00170 BSF 00171 COMF 00172 ANDLW 00173 IORLW 00174 MOVWE 00175 MOVWE	RESET ENTRY  B'11000001'  RB B'00001111'  RB B'11111111'  RA RB,RD RB,W B'00000101' B'10000000' F BSTAT F DATAO RA,W F CSTAT	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS ;RB4~7 BE OUTPUTS ;INIT RA0~3 BE INPUTS ;HIGH RD PIN ;GET INIT BUTTON INPUTS
0044 0044 0800 0045 0CC1 0046 0002 0047 0C0F 0048 0006 0049 0CFF 004A 0005 004B 05E6 004C 0246 004D 0E05 004E 0D80 004F 002D 0050 002E 0051 0205 0052 002C 0053 0073 0054 0074 0055 0075	00156 BYTE5 00157 RETLW 00158; 00159;====== 00160; 00161;====== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS 00168 MOVLW 00169 TRIS 00170 BSF 00171 COMF 00172 ANDLW 00173 IORLW 00174 MOVWH 00175 MOVWH 00175 MOVWH 00176 MOVF 00177 MOVWH 00177 MOVWH 00178 CLRF 00179 CLRF	RESET ENTRY  B'11000001'  RB B'00001111'  RB B'11111111'  RA RB,RD RB,W B'00000101' B'10000000' F BSTAT F DATAO RA,W F CSTAT FLAGA	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS ;RB4~7 BE OUTPUTS ;INIT RA0~3 BE INPUTS ;HIGH RD PIN ;GET INIT BUTTON INPUTS
0044 0044 0800 0045 0CC1 0046 0002 0047 0C0F 0048 0006 0049 0CFF 004A 0005 004B 05E6 004C 0246 004D 0E05 004E 0D80 004F 002D 0050 002E 0051 0205 0052 002C 0053 0073 0054 0074 0055 0075 0056	00156 BYTE5 00157 RETLW 00158; 00159;====== 00160; 00161;====== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS 00168 MOVLW 00169 TRIS 00170 BSF 00171 COMF 00172 ANDLW 00173 IORLW 00174 MOVWH 00175 MOVWH 00175 MOVWH 00176 MOVF 00177 MOVWH 00177 MOVWH 00178 CLRF 00180 CLRF 00181 SCAN	RESET ENTRY  B'11000001'  N B'00001111'  RB N B'11111111'  RA RB,RD RB,W N B'00000101' N B'10000000' F BSTAT F DATAO RA,W F CSTAT FLAGA XCOUNT YCOUNT	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS ;RB4~7 BE OUTPUTS ;INIT RA0~3 BE INPUTS ;HIGH RD PIN ;GET INIT BUTTON INPUTS ;CLEAR TR FLAG ;RESET XCOUNT & YCOUNT
0044 0044 0800  0045 0045 0CC1 0046 0002 0047 0C0F 0048 0006 0049 0CFF 004A 0005 004B 05E6 004C 0246 004D 0E05 004E 0D80 004F 002D 0050 002E 0051 0205 0052 002C 0053 0073 0054 0074 0055 0075 0056 006F	00156 BYTE5 00157 RETLW 00158; 00159;====== 00160; 00161;====== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS 00168 MOVLW 00169 TRIS 00170 BSF 00171 COMF 00172 ANDLW 00173 IORLW 00173 IORLW 00174 MOVWH 00175 MOVWH 00175 MOVWH 00176 MOVF 00177 MOVWH 00177 MOVWH 00178 CLRF 00180 CLRF 00181 SCAN 00182 CLRF	RESET ENTRY  B'11000001'  N B'00001111'  RB N B'11111111'  RA RB,RD RB,W N B'00000101' N B'10000000' F BSTAT F DATAO RA,W F CSTAT FLAGA XCOUNT YCOUNT DATA1	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS ;RB4~7 BE OUTPUTS ;INIT RA0~3 BE INPUTS ;HIGH RD PIN ;GET INIT BUTTON INPUTS
0044 0044 0800  0045 0045 0CC1 0046 0002 0047 0C0F 0048 0006 0049 0CFF 004A 0005 004B 05E6 004C 0246 004D 0E05 004E 0D80 004F 002D 0050 002E 0051 0205 0052 002C 0053 0073 0054 0074 0055 0075 0056 0056 006F 0057 0070	00156 BYTE5 00157 RETLW 00158; 00159;====== 00160; 00161;====== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS 00168 MOVLW 00169 TRIS 00170 BSF 00171 COMF 00172 ANDLW 00173 IORLW 00173 IORLW 00174 MOVWH 00175 MOVWH 00175 MOVWH 00176 MOVF 00177 MOVWH 00177 MOVWH 00178 CLRF 00180 CLRF 00181 SCAN 00182 CLRF	RESET ENTRY  B'11000001'  N B'00001111'  RB N B'11111111'  RA RB,RD RB,W N B'00000101' N B'10000000' F BSTAT F DATAO RA,W F CSTAT FLAGA XCOUNT YCOUNT  DATA1 DATA2	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS ;RB4~7 BE OUTPUTS ;INIT RA0~3 BE INPUTS ;HIGH RD PIN ;GET INIT BUTTON INPUTS ;CLEAR TR FLAG ;RESET XCOUNT & YCOUNT
0044 0044 0800 0045 0801 0045 0801 0046 0002 0047 0806 0048 0006 0049 086 0040 0805 004B 0586 004C 0246 004D 0805 004E 0080 004F 002D 0050 002E 0051 0205 0052 002C 0053 0073 0054 0074 0055 0075 0056 006F 0057 0070 0058 0071	00156 BYTE5 00157 RETLW 00158; 00159;====== 00160; 00161;====== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS 00168 MOVLW 00169 TRIS 00170 BSF 00171 COMF 00172 ANDLW 00173 IORLW 00174 MOVWH 00175 MOVWH 00175 MOVWH 00176 MOVF 00177 MOVWH 00177 MOVWH 00178 CLRF 00180 CLRF 00181 SCAN 00182 CLRF 00183 CLRF 00183 CLRF	RESET ENTRY  B'11000001'  N B'00001111'  RB N B'11111111'  RA RB,RD RB,W N B'00000101' N B'10000000' F BSTAT DATAO RA,W CSTAT FLAGA XCOUNT YCOUNT  DATA1 DATA2 DATA3	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS ;RB4~7 BE OUTPUTS ;INIT RA0~3 BE INPUTS ;HIGH RD PIN ;GET INIT BUTTON INPUTS ;CLEAR TR FLAG ;RESET XCOUNT & YCOUNT
0044 0044 0800  0045 0045 0CC1 0046 0002 0047 0C0F 0048 0006 0049 0CFF 004A 0005 004B 05E6 004C 0246 004D 0E05 004E 0D80 004F 002D 0050 002E 0051 0205 0052 002C 0053 0073 0054 0074 0055 0075 0056 0056 006F 0057 0070	00156 BYTE5 00157 RETLW 00158; 00159;====== 00160; 00161;====== 00162; 00163 INIT 00164 MOVLW 00165 OPTIC 00166 MOVLW 00167 TRIS 00168 MOVLW 00169 TRIS 00170 BSF 00171 COMF 00172 ANDLW 00173 IORLW 00173 IORLW 00174 MOVWH 00175 MOVWH 00175 MOVWH 00176 MOVF 00177 MOVWH 00177 MOVWH 00178 CLRF 00180 CLRF 00181 SCAN 00182 CLRF	RESET ENTRY  B'11000001'  N B'00001111'  RB N B'11111111'  RA RB,RD RB,W N B'00000101' N B'10000000' F BSTAT F DATAO RA,W F CSTAT FLAGA XCOUNT YCOUNT  DATA1 DATA2	;DISABLE WATCHDOG ;INIT RB0~3 BE INPUTS ;RB4~7 BE OUTPUTS ;INIT RA0~3 BE INPUTS ;HIGH RD PIN ;GET INIT BUTTON INPUTS ;CLEAR TR FLAG ;RESET XCOUNT & YCOUNT

# **AN519**

005B	0743	00187	BTFSS	STATUS, ZERO_AREA	
005C	08A0	00188	GOTO	WRITX	
005D		00189	SCANA		
005D	0215	00190	MOVF	YCOUNT, W	;YCOUNT = 0 ?
005E	0743	00191	BTFSS	STATUS, ZERO_AREA	
005F	0A92	00192	GOTO	WRITY	
0060		00193	SCANB		
0060	0246	00194	COMF	RB,W	;BUTTON STATUS CHANGE ?
0061	0E05	00195	ANDLW	B'00000101'	
0062	0D80	00196	IORLW	B'10000000'	
0063	00AD	00197	SUBWF	BSTAT, F	
0064	0643	00198	BTFSC	STATUS, ZERO_AREA	; IF CHANGE THEN TRIGGER
0065	0A6B	00199	GOTO	SCANC	; (NO CHANGE)
0066	0553	00200	BSF	FLAGA,TR	;(CHANGE) SET TRIGGER FLAG
0067	0246	00201	COMF	RB,W	FORMAT BUTTON STATUS DATA
0068	0E05	00202	ANDLW	B'00000101'	
0069	0D80	00203	IORLW	B'10000000'	
006A	002E	00204	MOVWF	DATA0	
006B		00205	SCANC		
006B	0246	00206	COMF	RB,W	
006C	0E05	00207	ANDLW	B'00000101'	
	0D80	00208		B'10000000'	
	002D	00209		BSTAT	
	020E	00210		DATA0,W	;SEND DATA0,1,2,3,4 TO HOST
	0039	00211		DATA AREA	7,5211,5 5111110 (1 ( 2 ( ) ) 1 10 11051
	092A	00212		BYTE	
	020F	00212		DATA1,W	
	0039	00213		DATA_AREA	
	092A	00215		BYTE	
0075		00216		DATA2,W	
0076		00217		DATA_AREA	
	092A	00218		BYTE	
	0211	00219		DATA3,W	
0079	0039	00220	MOVWF	DATA_AREA	
007A	092A	00221	CALL	BYTE	
007B	0212	00222	MOVF	DATA4,W	
007C	0039	00223	MOVWF	DATA_AREA	
007D	092A	00224	CALL	BYTE	
007E	0453	00225	BCF	FLAGA,TR	;CLEAR TRIGGER FLAG
007F	0A56	00226	GOTO	SCAN	
		00227	;		
0080		00228	WRITX		
0080	0553	00229	BSF	FLAGA,TR	;SET TRIGGER FLAG
0081	0C40	00230	MOVLW	40H	; IF XCOUNT > 64 THEN XCOUNT <-64
0082	0094	00231	SUBWF	XCOUNT, W	
0083	0603	00232	BTFSC	STATUS, CA	
0084	0A8D	00233	GOTO	WRITR	
0085		00234	WRITS		
0085	0776	00235	BTFSS	FLAGB,RI	;LEFT / RIGHT ?
0086	0A90	00236	GOTO	WRITL	
0087	0274	00237	COMF	XCOUNT, F	;(RIGHT) NEG XCOUNT
0088	0294	00238	INCF	XCOUNT, W	
0089		00239	WRITA		
0089	002F	00240	MOVWF	DATA1	
	0031	00241	MOVWF	DATA3	
	0074	00242		XCOUNT	; RESET XCOUNT
008C	0A5D		GOTO	SCANA	
		00244			
008D			WRITR		
	0C40		MOVLW	40H	;XCOUNT <- 64
	0034		MOVWF	XCOUNT	
008F	0A85		GOTO	WRITS	
		00249			
0090	0014		WRITL		()
	0214		MOVF	XCOUNT,W	;(LEFT)
0091	0A89	00252	GOTO	WRITA	

```
00253 ;
0092
              00254 WRITY
0092 0553
              00255 BSF
                        FLAGA, TR
                                    ;SET TRIGGER FLAG
0093 0C40
             00256 MOVLW 40H
                                     ; IF YCOUNT > 64 THEN YCOUNT <-64
0094 0095
              00257 SUBWF
                        YCOUNT, W
0095 0603
              00258 BTFSC
                        STATUS, CA
            00259 GOTO
0096 0A9F
                        WRITV
0097
             00260 WRITW
            00261 BTFSS FLAGB, UP
0097 0736
                                     ;DOWN / UP ?
            00262 GOTO
0098 0AA2
                        WRITD
            00263 COMF
00264 INCF
0099 0275
                        YCOUNT, F
                                    ;(UP) NEG YCOUNT
009A 0295
                        YCOUNT, W
             00265 WRITB
009B
          00266 MOVWF DATA2
00267 MOVWF DATA4
00268 CLRF YCOUNT
00269 GOTO SCANB
00270 ;
009B 0030
009C 0032
                                     ; RESET YCOUNT
009D 0075
                        YCOUNT
009E 0A60
                        SCANB
009F
             00271 WRITV
           00272 MOVLW 40H
00273 MOVWF YCOUNT
009F 0C40
                                     ;YCOUNT <- 64
00A0 0035
00A1 0A97
            00274 GOTO
                        WRITW
              00275 ;
00A2
              00276 WRITD
00A2 0215
              00277 MOVF
                        YCOUNT, W
                                     ; (DOWN)
              00278 GOTO
00A3 0A9B
                        WRITB
              00279 ;
              00281; RESET ENTRY
              00283 ;
01FF
              00284 ORG
                        777
01FF 0A45
              00285 GOTO
                       INIT
                              ;JUMP TO PROGRAM STARTING
              00286 ;
              00287 END
01C0 : -----X
All other memory blocks unused.
Program Memory Words Used:
                    347
Program Memory Words Free:
Errors :
Warnings :
         0 reported,
                      0 suppressed
          0 reported,
                     0 suppressed
Messages :
```

#### Note the following details of the code protection feature on PICmicro® MCUs.

- The PICmicro family meets the specifications contained in the Microchip Data Sheet.
- Microchip believes that its family of PICmicro microcontrollers is one of the most secure products of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the PICmicro microcontroller in a manner outside the operating specifications contained in the data sheet. The person doing so may be engaged in theft of intellectual property.
- · Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable".
- Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our product.

If you have any further questions about this matter, please contact the local sales office nearest to you.

Information contained in this publication regarding device applications and the like is intended through suggestion only and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. No representation or warranty is given and no liability is assumed by Microchip Technology Incorporated with respect to the accuracy or use of such information, or infringement of patents or other intellectual property rights arising from such use or otherwise. Use of Microchip's products as critical components in life support systems is not authorized except with express written approval by Microchip. No licenses are conveyed, implicitly or otherwise, under any intellectual property rights.

#### **Trademarks**

The Microchip name and logo, the Microchip logo, FilterLab, KEELOQ, microID, MPLAB, PIC, PICmicro, PICMASTER, PICSTART, PRO MATE, SEEVAL and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

dsPIC, ECONOMONITOR, FanSense, FlexROM, fuzzyLAB, In-Circuit Serial Programming, ICSP, ICEPIC, microPort, Migratable Memory, MPASM, MPLIB, MPLINK, MPSIM, MXDEV, PICC, PICDEM, PICDEM.net, rfPIC, Select Mode and Total Endurance are trademarks of Microchip Technology Incorporated in the U.S.A.

Serialized Quick Turn Programming (SQTP) is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.

© 2002, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.





Microchip received QS-9000 quality system certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona in July 1999. The Company's quality system processes and procedures are QS-9000 compliant for its PICmicro® 8-bit MCUs, KEELO© code hopping devices, Serial EEPROMs and microperipheral products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001 certified.



## WORLDWIDE SALES AND SERVICE

#### **AMERICAS**

#### **Corporate Office**

2355 West Chandler Blvd. Chandler, AZ 85224-6199 Tel: 480-792-7200 Fax: 480-792-7277 Technical Support: 480-792-7627 Web Address: http://www.microchip.com

#### **Rocky Mountain**

2355 West Chandler Blvd. Chandler, AZ 85224-6199
Tel: 480-792-7966 Fax: 480-792-7456

#### Atlanta

500 Sugar Mill Road, Suite 200B Atlanta, GA 30350
Tel: 770-640-0034 Fax: 770-640-0307

#### **Boston**

2 Lan Drive, Suite 120 Westford, MA 01886 Tel: 978-692-3848 Fax: 978-692-3821

## Chicago

333 Pierce Road, Suite 180 Itasca, IL 60143

Tel: 630-285-0071 Fax: 630-285-0075

#### **Dallas**

4570 Westgrove Drive, Suite 160 Addison, TX 75001 Tel: 972-818-7423 Fax: 972-818-2924

#### Detroit

Tri-Atria Office Building 32255 Northwestern Highway, Suite 190 Farmington Hills, MI 48334 Tel: 248-538-2250 Fax: 248-538-2260

## Kokomo

2767 S. Albright Road Kokomo, Indiana 46902 Tel: 765-864-8360 Fax: 765-864-8387

### Los Angeles

18201 Von Karman, Suite 1090 Irvine, CA 92612

Tel: 949-263-1888 Fax: 949-263-1338

## **New York**

150 Motor Parkway, Suite 202 Hauppauge, NY 11788 Tel: 631-273-5305 Fax: 631-273-5335

### San Jose

Microchip Technology Inc. 2107 North First Street, Suite 590 San Jose, CA 95131 Tel: 408-436-7950 Fax: 408-436-7955

#### **Toronto**

6285 Northam Drive, Suite 108 Mississauga, Ontario L4V 1X5, Canada Tel: 905-673-0699 Fax: 905-673-6509

## ASIA/PACIFIC

#### Australia

Microchip Technology Australia Pty Ltd Suite 22, 41 Rawson Street Epping 2121, NSW Australia

Tel: 61-2-9868-6733 Fax: 61-2-9868-6755

#### China - Beijing Microchip Technology Consulting (Shanghai)

Co., Ltd., Beijing Liaison Office Unit 915 Bei Hai Wan Tai Bldg.

No. 6 Chaoyangmen Beidajie Beijing, 100027, No. China Tel: 86-10-85282100 Fax: 86-10-85282104

## China - Chengdu

Microchip Technology Consulting (Shanghai)
Co., Ltd., Chengdu Liaison Office
Rm. 2401, 24th Floor, Ming Xing Financial Tower

No. 88 TIDU Street Chengdu 610016, China

Tel: 86-28-6766200 Fax: 86-28-6766599

#### China - Fuzhou

Microchip Technology Consulting (Shanghai) Co., Ltd., Fuzhou Liaison Office Unit 28F, World Trade Plaza No. 71 Wusi Road Fuzhou 350001, China Tel: 86-591-7503506 Fax: 86-591-7503521

### China - Shanghai

Microchip Technology Consulting (Shanghai)

Co., Ltd. Room 701, Bldg. B Far East International Plaza No. 317 Xian Xia Road Shanghai, 200051

Tel: 86-21-6275-5700 Fax: 86-21-6275-5060

## China - Shenzhen

Microchip Technology Consulting (Shanghai) Co., Ltd., Shenzhen Liaison Office Rm. 1315, 13/F, Shenzhen Kerry Centre, Renminnan Lu Shenzhen 518001, China Tel: 86-755-2350361 Fax: 86-755-2366086

## **Hong Kong**

Microchip Technology Hongkong Ltd. Unit 901-6, Tower 2, Metroplaza 223 Hing Fong Road Kwai Fong, N.T., Hong Kong Tel: 852-2401-1200 Fax: 852-2401-3431

#### India

Microchip Technology Inc. India Liaison Office Divvasree Chambers 1 Floor, Wing A (A3/A4) No. 11, O'Shaugnessey Road Bangalore, 560 025, India Tel: 91-80-2290061 Fax: 91-80-2290062

#### Japan

Microchip Technology Japan K.K. Benex S-1 6F 3-18-20, Shinyokohama Kohoku-Ku, Yokohama-shi Kanagawa, 222-0033, Japan Tel: 81-45-471- 6166 Fax: 81-45-471-6122

#### Korea

Microchip Technology Korea 168-1, Youngbo Bldg. 3 Floor Samsung-Dong, Kangnam-Ku Seoul, Korea 135-882

Tel: 82-2-554-7200 Fax: 82-2-558-5934

#### Singapore

Microchip Technology Singapore Pte Ltd. 200 Middle Road #07-02 Prime Centre Singapore, 188980

Tel: 65-6334-8870 Fax: 65-6334-8850

#### Taiwan

Microchip Technology Taiwan 11F-3, No. 207 Tung Hua North Road Taipei, 105, Taiwan Tel: 886-2-2717-7175 Fax: 886-2-2545-0139

## **EUROPE**

#### Denmark

Microchip Technology Nordic ApS Regus Business Centre Lautrup hoj 1-3 Ballerup DK-2750 Denmark Tel: 45 4420 9895 Fax: 45 4420 9910

#### France

Microchip Technology SARL Parc d'Activite du Moulin de Massy 43 Rue du Saule Trapu Batiment A - Ier Etage 91300 Massy, France Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

**Germany** Microchip Technology GmbH Gustav-Heinemann Ring 125 D-81739 Munich, Germany Tel: 49-89-627-144 0 Fax: 49-89-627-144-44

## Italy

Microchip Technology SRL Centro Direzionale Colleoni Palazzo Taurus 1 V. Le Colleoni 1 20041 Agrate Brianza Milan, Italy Tel: 39-039-65791-1 Fax: 39-039-6899883

## **United Kingdom**

Arizona Microchip Technology Ltd. 505 Eskdale Road Winnersh Triangle Wokingham Berkshire, England RG41 5TU Tel: 44 118 921 5869 Fax: 44-118 921-5820

03/01/02