# Common

Library version:RENAT 0.1.8Library scope:globalNamed arguments:supported

## Introduction

Common library for RENAT

It loads config files and create necessary varibles. The file should be the 1st library included from any test case.

#### **Table of Contents**

- Configuration file
- Variables
- Shortcuts
- Keywords

# Configuration file

# **Global configuration**

There are 2 kinds of configuration files. The global configuration files (aka master files) include device information, authentication etc that are used for all the test cases in the suite. The local configuration file local.yaml includes information about nodes, tester ports etc. that are used in a specific test case.

At the beginning, the module makes a local copy the master files and initialize necessary variables.

The RENAT framework utilized the YAML format for its configurations file.

The master files folder is defined by renat-master-folder in \$RENAT\_PATH/config/config.yaml. Usually, users do not need to modify the master files. The most common case is when new device is deployed, the device.yaml need to be update so that device could be used in the test cases.

#### 1. device.yaml: contains global device information

Each device information is store under device block and has the following format:

```
<node_name>
type: <device type>
description: <any useful description>
ip: <the IPv4 address of the device
```

Where <node\_name> is the name of the device. It could be the name of a switch, router or a web appliance box and should be uniq between the devices. <description> is any useful information and <ip> is the IP that RENAT uses to access the device.

<type> is important because it will be used as the ky of the access\_template in template file. Usually users do not need to invent a new type but should use the existed type. When a new platform need to be supported, a new type will be introduced with the correspon template and authentication information.

#### Samples:

```
device:
  apollo:
    type: ssh-host
    description: main server
    ip: 10.128.3.101
  artermis:
    type: ssh-host
    description: second server
    ip: 10.128.3.91
  vmx11:
    type: juniper
    description: r1
    ip: 10.128.64.11
  vmx12:
    type: juniper
    description: r2
    ip: 10.128.64.12
```

## 2. template.yaml: contains device template information

The template file contains information about how to access to the device and how it should polling information (SNMP only for now). Each template has the following format:

<type>: access: <ssh or telnet> auth: <plaint-text or public-key> profile: <authentication profile name> prompt: <a regular expression for the PROMPT of the CLI device> (optional) login\_prompt: <a login PROMPT for CLI device> (optional) password\_prompt:<a PROMPT for asking password of CLI device> (optional) append: <a pharase to append automatically for every CLI command that executes> on this device (optional> init: <an array of command that will be executed automatically after a sucessful login of CLI device> (optional)</a>

Note: Becareful about the prompt field. Usually RENAT will wait until it could see the prompt in its output. A wrong prompt will halt the system until it is timed out.

Samples:

```
access-template:
 ssh-host:
    access: ssh
    auth: public-key
    profile: default
    prompt: \$
    append:
    init: unalias -a
 iuniper:
    access: telnet
    auth: plain-text
    profile: default
    prompt: "(#|>) "
    append: ' | no-more'
    init:
 cisco:
    access: ssh
    auth: plain-text
    profile: default
    prompt: "\@.*(#|>) "
    append:
    init:
snmp-template:
   juniper:
      mib: ./mib-Juniper.json
      community: public
      poller: renat
   cisco:
      mib: ./mib-Cisco.json
      community: public
```

#### 3. auth.yaml: contains authentication information

The file contains authentication information that system uses when access to a device. Each authencation type has follwing format:

Where <profile> is the name of the authentication profile specificed in the access template of the device

Sample:

```
auth:
 plain-text:
    default:
      user: user
      pass: nttXXX
    flets:
      user: user
      pass: lpcoXXXX
    arbor:
      user: admin
      pass: nttXXX
 public-key: # for Public Key authentication
   default:
      user: robot
      key: /home/user/.ssh/robot_id_rsa
      user: jenkins
      key: /var/lib/jenkins/.ssh/id_rsa
```

## **Local Configuration**

Local configuration (aka local.yaml) was used by a test case of its sub test cases. Test cases could includes several test cases (the sub level is not limited). The local configuration is defined by local.yaml in the config folder of each test case. If a test case does not has the local.yaml in its config folder, it will use the local.yaml file in its parent test case and so on. This will help users to share the test information for related test case without having the same local.yaml for each test case (**Note:** this feature is enabled from RENAT 0.1.4). The local.yaml that is really used for the test is called active local.yaml.

When user used the wizard item.sh to create a new test case, they have the ability to crete new local.yaml or not. local.yaml could be edited and inserted new information later to hold more informations for the test case.

When a test is run, it will display its current active local.yaml

The local configuration file of each test item is stored in the config folder of the item as `local.yaml

Usually the local.yaml has following parts:

- CLI node information: started by node keyword
- WEB node information: started by webapp keyword
- Tester device information: started by tester keyword
- Default information: automatically created and started by default keyword
- And other neccessary information for the test by yaml format

#### Sample:

```
# CLI node
node:
  vmx11:
    device: vmx11
    snmp_polling: yes
  vmx12:
    device: vmx11
    snmp_polling: yes
  apollo:
    device: vmx11
    snmp polling: yes
# web application information
webapp:
  arbor-sp-a:
    device: arbor-sp-a
    proxy:
      http: 10.128.8.210:8080
      ssl: 10.128.8.210:8080
      socks: 10.128.8.210:8080
# Tester information
tester:
  tester01:
    type: ixnet
    ip: 10.128.32.70
    config: vmx_20161129.ixncfg
# Other user information|
port-mapping:
  uplink01:
    device: vmx11
    port: ae-0/0/0
  downlink01:
    device: vmx12
    port: ge-0/0/2
# Default information
default:
  ignore_dead_node: yes
  terminal:
    width: 80
    height: 32
  result_folder: result
```

#### **Variables**

The module automatically create GLOBAL & LOCAL variable for other libraries. It also creates global list variables *GLOBAL,LOCAL* and *NODE* that could be accessed from Robot Framework` test cases.

The GLOBAL variable holds all information defined by the master files and LOCAL variable holds all variables defined by active local.yaml. And NODE is a list that hold all active nodes defined in the local.yaml.

Users could access to the information of a key in local.yaml by \${LOCAL['key']}, information of a node by \${LOCAL['node'][vmx11']} or simply \$NODE['vmx']. When a keyword need a list of current node, @{NODE} could be used.

**Notes:** By default, RENAT will stop and raise an exception if connection to a node is failed. But if ignore\_dead\_node is defined as yes (default) is the current active local.yaml, RENAT will omit an warning but keep running the test and remove the node from its active node list.

### **Shortcuts**

Change Mod · Cleanup Result · Convert Html To Pdf · Count Keyword · Count Keyword Line · Count Match Regexp · Create Sequence · Csv Concat · Csv Merge · Csv Select · Diff File · Err · Error Line Should Not Be Bigger Than · Error Should Not Be Bigger Than · Explicit Run · File Md5 · Fold Str · Follow Syslog And Trap · Get Config Path · Get File Without Error · Get Item Config Path · Get Item Name · Get Renat Path · Get Result Folder · Get Result Path · Get Test Device · Is Stable · Keyword Line Should Not Be Bigger Than · Keyword Should Not Be Bigger Than · Load Plugin · Log · Log To Console · Loop For Node Tag · Md 5 · Merge Files · Mib For Node · Node With Attr · Node With Tag · Node Without Tag · Pause · Ping Until Ok · Random Name · Random Number · Renat Version · Set Multi Item Variable · Set Result Folder · Slack · Str 2 Seg · Version

### Keywords

Keyword	Arguments	Documentation

Change Mod	name, mod, relative=False	Changes file mod, likes Unix chmod
		mod is a string specifying the privilege mode relative is False or True
		Examples:
		Common. Change Mod tmp 0775
Cleanup Result	ignore=^(log.html output.xml report.html)\$	Cleans up the result folder
		Deletes all files in current active folder that does not match the ignore expression and are older than the time the test has started.
		Note: The keyword only removes files but not folders
Convert Html To Pdf	html_file, pdf_file	Converts html file to pdf file
Count Keyword	keyword, *pattern_list	Count the keyword in files. Keyword is not case-sensitive
Count Keyword	keyword, *pattern_list	Count the number of lines contains the keyword
Line		<b>Notes:</b> Keyword is matched partially. For example, error or errorXXX will be matched by error keyword.
Count Match	regexp, *pattern_list	Count the number of regex found in pattern_list
Regexp		Examples:
		\${err_num}= Count Match RegExp .*error.* result/*.csv result/*.txt
Create Sequence	start, end, interval, option=float	Creates a list with number from start to end with interval
		Example:
		@{list}= Create Sequence 10   15   0.5
		will create a list of [11.0, 11.5, 12.0, 12.5, 13.0, 13.5, 14.0, 14.5]
Csv Concat	src_pattern, dst_name, has_header=None	Concatinates CSV files vertically If the CSV files has header, set has_header to \${TRUE}
		Examples:
		Commmon. CSV config/data0[3,4].csv result/result2.csv
		Merge       Commmon. CSV     config/data0[3,4].csv     result/result2.csv     has_header=\${TRUE}       Merge
Csv Merge	src_pattern, dst_name, on_key=0,	Merges all CSV files horizontally by on_key key from src_pattern
	has_header=None	on_key is the order of key column that is used as key when merging the files.
		Default is zero.
		When has_header is not None (default value), it is the order of the row used to make the column name. Returns False if only one file was found, no merging happend
		Examples:
		Common. <u>CSV</u> config/data0[3,4].csv result/result2.csv
		Merge  Common.CSV config/data0[3,4].csv result/result2.csv has header=\${TRUE}
		Merge
Csv Select	<pre>src_file, dst_file, str_row=:, str_col=:, has_header=None</pre>	Select part of the CSV file and write it to other file str_row and str_col are used to specify necessary rows and columns. They are using the same format with slice f Python list.
		• : and : means all rows and columns
		<ul> <li>:2 and : means first 2 rows and all columns</li> <li>: and 1,2 means all rows and 2nd and 3rd columns</li> </ul>
		<ul> <li>0:3 and 1 means 3 rows from the 1st one(0,1,2) and second column</li> <li>0:5:2 and 1 means 3 rows(0,3,5) and second column</li> </ul>
		Notes:
		■ Rows and columns are indexed from zero
		When ':' is used, the string has format: <start>:<stop> or <start>:<stop>: <step> For convenience, ':' means all the data, ':x' means first 'x' data</step></stop></start></stop></start>
		Examples:
		CSV Select result/data05.csv result/result3.csv 0,1,2 0,1
		CSV Select result/data05.csv result/result4.csv : 0,1
		CSV Select result/data05.csv result/result5.csv :2 :
		CSV Select result/data05.csv result/result6.csv 0:3 :
Diff File	path1, path2, newline=True	

Err	msg	Prints error msg to console
Error Line Should Not Be Bigger Than	num, *pattern_list	Checks whether the number of lines that contains error be less than a number
Error Should Not Be Bigger Than	num, *pattern_list	Checks whether the number of error be less than a number
Explicit Run		skip the test case if global_variable RUN_ME is not defined
		Sample scenario:
		00. Cabling  Common. Explicit Run  Log To Console cabling
		run.sh will bypass 00. Cabling by default. In other to run this test case \${FORCE} needs declared globally run.sh -X -v FORCE
File Md5	path	Returns MD5 hash of a file
		path is an absolute path
Fold Str	str	Folds a string by adding Non-Width-Space char (0x200b) at 6th char
Follow Syslog And Trap	pattern, log_file_name=syslog-trap.log, delay_str=1s	Pauses the execution and wait for the pattern is matched if the file <i>log_file_name</i> located in the current result folder.
		By default the <i>log_file_name</i> is ./result/syslog-trap.log which is created by <u>Follow</u> <u>Syslog and Trap</u> keyword.
		The keyword should be in tests between Follow Syslog adn Trap Start and Follow Syslog and Trap Stop keywords.
Get Config Path		Returns absolute path of RENAT config folder path
Get File Without Error	file_path	Get content of the file and return null string if the file does not exist
Get Item Config Path		Returns absolute path of current item config folder
Get Item Name		Returns the name of the running item
Get Renat Path		Returns the absolute path of RENAT folder
Get Result Folder		Returns current result folder name. Default is result in current test case.
		Note: the keyword only returns the name of the result folder not its absolue path
Get Result Path		Returns absolute path of the current result folder
Get Test Device		Return a list of all test device that is used in this test
		Notes: Device number could less than node number
Is Stable	seq, threshold, percentile=90	Checks if the value sequence is stable or not
Keyword Line Should Not Be Bigger Than	num, keyword, *pattern_list	Checks whether the number of line containing the keyword be less than a number
Keyword Should Not Be Bigger Than	num, keyword, *pattern_list	Checks whether the number of keyword be less than a number
Load Plugin		Load plugin in renat/plugin folder
Log	msg, level=1	Logs msg to the current log file (not console)
		The msg will logged only if the level is bigger than the global level \${DEBUG} who could be defined at runtime. If \${DEBUG} is not defined, it will be considered as default level as 1.
		Examples:
		Common. <u>Log</u> XXX # this always be
		logged  Common.Log AAA level=2 # this will not be logged with common
		run.sh  Common. <u>Log</u> BBB level=2 # ./run.sh -v DEBUG:2 will log the
		Notes: For common use
		<ul> <li>level 1: is default</li> <li>level 2: is debug mode</li> <li>level 3: is very informative mode</li> </ul>
Log To Console	msg, level=1	Logs a message to console
Loop For Node Tag	var, tags, *keywords	See Common. Print for more details about debug level  Repeatly executes RF keyword for nodes that has tag tags
	LYGI. IGGS. NEV WOIGS	inecedity executes or nevword tolloces that has facilities

		Run Keywords of RobotFramework (keyword and its arguments are separated by AND with the others.	
		Example:	
		Loop For Node Tag \\${node} tag1	
		Switch \\${node} AND	
		Cmd show system user AND	
		Cmd show system uptime	
Md 5	str	Note: \$ in variable name must be escaped Returns MD5 hash of a string	
Merge Files	path_name, file_name	Merges all the text files defined by path_name to file_name	
		Example:	
		Merge Files /result/*.csv /result/test.csv	
Mib For Node	node	Returns the mib file name for this node mib file is define by mib keyword under the node in local.yaml	
		node: vmx11: device: vmx11 snmp_polling: yes mib: mib11.txt	
		Default value is defined by mib keyword from global config/snmp-template.yaml for the type of the node	
		Example:	
		\${mib}= Common.MIB For Node vmx11	
Node With Attr	attr_name, value	Returns a list of nodes which have attribute attr_name with value value	
Node With Tag	*tag_list	Returns list of node or webapp from local.yaml that has <b>ALL</b> tags defined by tag_list	
		Tag was defined like this in local.yaml  vmx11:  device: vmx11  snmp_polling: yes  tag:  - tag1	
		- tag2  Examples:	
		\${test3}= Common. Node With Tag tag1 tag3	
Node Without Tag	*tag_list	Returns list of node from local.yaml that does not has ANY tags defined by tag_list	
		Tag was defined like this in local.yaml	
		vmx11:     device: vmx11     snmp_polling: yes     tag:     - tag1     - tag2	
		Examples:	
		\${test3}= Common. Node Without Tag tag1 tag3	
Pausa	mag time out 2h	Displays the message msg and pauses the test execution and wait for user input	
Pause	msg=, time_out=3h, error_on_timeout=True, default_input=	In case of error_on_timeout is True(default), the keyword will raise an error when timeout occurs. Otherwise, it will continue the test.	
		Notes: If the variable \${RENAT_BATCH} was defined, the keyword will print out the message and keeps running without pausing.	
		Examples:	
		Common. Pause Waiting 10s error_on_timeout=\${TRUE} default input Common. Pause Waiting 10s	
Ping Until Ok	node, wait_str=5s, extra=-c 3	Ping a node until it gets response. Then wait for more wait_str Default extra option is -c 3	
Random Name	base, a=0, b=99	Returns a random name by a <i>base</i> and a random number between [a,b]	
		Example:  \${FOLDER}= Random Name capture %05d 0 99	

Random Number	a=0, b=99	Returns a random number between [a,b]
Renat Version		Returns RENAT version string
Set Multi Item Variable	*vars	Set multiple varibles to be <i>suite variable</i> at the same time  Suite variables (or item variable) could be access anywhere in all the item scenario.
Set Result Folder	folder	Sets the result folder to folder and return the old result folder. The result folder contains all output files from the test likes tester ouput, config file
		folder is a folder name that under current test case folder
		The system will create a new folder if it does not exist and set its mode to 0775
		<b>Note:</b> Result folder should be set at the begining of the test. Changing result folder only has effect on up comming connection
Slack	msg, channel=#automation_dev, user=renat, host=10.128.3.103:4713	Post a message to Slack
Str 2 Seq	str_index, size	Returns a sequence from string format
		Samples:
		<u>Str2Seq</u> :: 5 # (0,1,2,3,4)
		<u>Str2Seq</u> :2 5 # (0,1)
		<u>Str2Seq</u> 1:3 5 # (1,2)
		<u>Str2Seq</u> 0:5:2 5 # (0,2,4)
Version		Returns the current version of RENAT

Altogether 49 keywords.
Generated by <u>Libdoc</u> on 2018-06-17 21:39:19.

