

# **Gallagher Command Centre**

**OPC Data Server Interface Specification** 

#### Disclaimer

This document gives certain information about products and/or services provided by Gallagher Group Limited or its related companies (referred to as "Gallagher Group").

The information is indicative only and is subject to change without notice meaning it may be out of date at any given time. Although every commercially reasonable effort has been taken to ensure the quality and accuracy of the information, Gallagher Group makes no representation as to its accuracy or completeness and it should not be relied on as such. To the extent permitted by law, all express or implied, or other representations or warranties in relation to the information are expressly excluded.

Neither Gallagher Group nor any of its directors, employees or other representatives shall be responsible for any loss that you may incur, either directly or indirectly, arising from any use or decisions based on the information provided.

Except where stated otherwise, the information is subject to copyright owned by Gallagher Group and you may not sell it without permission. Gallagher Group is the owner of all trademarks reproduced in this information. All trademarks which are not the property of Gallagher Group, are acknowledged.

Copyright © Gallagher Group Ltd 2016. All rights reserved.

#### **Document history**

Edition	Date	Author	Comment	
1.0	05/10/2006	DWH	Initial revision.	
1.1	27/11/2006	DWH	Detailed reliance on Gallagher Command Centre service. Access rights changes. Detail DCOM security. Fixed status values. Added override cancel verbs.	
1.2	23/01/2007	DWH	itatus and overrides for Vel5.10 FENCE ITEMS.	
1.3	07/02/2007	DWH	Status and overrides for Interlock Groups, Services and Workstations, Logic Blocks, External Systems, DVRs, Intercoms. Note on status quality through OPC interfaces.	
1.4	10/05/2007	DWH	Status and overrides value and description fixes.	
1.5	19/08/2008	DWH	Added four new available fields to the Gallagher Command Centre Properties section.	
1.6	14/07/2011	MD	OPC Data Service has been merged into the Command Centre Service.	
1.7	27/02/2015	MD	Updated status for fence zones.	
2.0	26/03/2015	DWH	Server now supports OPC DA 2.0.	
2.1	20/08/2015	DWH	Various status and override updates for vEL7.40 including Z10 and Z20.	
2.2	30/09/2016	DWH	Class 5 ELM status & override. Status for F22, F3x, F4x fence controllers. HV/LF overrides for Fence Zone. Configuring an OPC Operator Group and OPC Operator added.	

# **Contents**


1	Over	view	4
	1.1	Architecture	4
	1.2	Component	4
	1.3	Licensing	5
	1.4	Security	5
	1.5	Localisation	
2	Appl	ication	8
	2.1	Gallagher Command Centre Address Spacing	8
	2.2	Gallagher Command Centre Properties	
	2.3	Gallagher Command Centre Status	11
	2.4	Gallagher Command Centre Overrides	15
	2.5	Inclusions and Exclusions	17

#### 1 Overview

#### 1.1 Architecture

The Gallagher Command Centre OPC Data Server is designed as an out-of-process COM executable implementing the OPC DA 3.0 and OPC DA 2.0 specifications. It *does not* contain legacy support for the OPC DA 1.0 specification.

The Gallagher Command Centre OPC Data Server integrates with the Gallagher Command Centre Server in order to provide OPC DA 3.0 and 2.0 compliant clients with access to the address space of a Gallagher Command Centre install.



#### 1.2 Component

The Gallagher Command Centre OPC Data Server has the following identity:

Version-independent ProgID: CCFTOPCData.CardaxOPCDataServer
CLSID: 751FF1AF-4A4C-47D6-BF82-7FF008890C70

An example connection string, such as can be used in the OPC Foundation's sample data client, is as follows:

opcda://localhost/CCFTOPCData.CardaxOPCDataServer

The following points should be noted when dealing with the server component:

- The OPC server is installed as part of a Gallagher Command Centre setup. The Command Centre setup will install a Windows service called "FT Command Centre Server" (CCNTSAD.exe) with a default start-up type of "automatic". The Gallagher OPC Data Server runs within the context of this Windows service. The complete Command Centre setup must succeed and then the service must be running on the target machine in order for OPC connection attempts to succeed.
- The OPC server must reside on the Gallagher Command Centre central server machine. OPC clients may be distributed and may access the server remotely via DCOM, assuming DCOM and firewall permissions have been setup appropriately.
- The OPC server implements the OPC DA 3.0 and 2.0 custom interfaces. It does not contain built-in support for the IDispatch automation interface.

#### 1.3 Licensing

The Gallagher Command Centre OPC Data Server is a licensable feature for Gallagher Command Centre installations. Every Gallagher Command Centre installation requires a Gallagher Command Centre license file, which is keyed to specific Controller hardware running on the site. The OPC Data feature must be listed as a licensed feature within the Gallagher Command Centre license file in order for the OPC Data Server to operate.

#### 1.4 Security

#### 1.4.1 Logon

As with Gallagher Command Centre clients, OPC clients are required to logon to the server before access is granted to the server's address space or to read or write data in that space. The logon establishes the OPC client's identity and permissions within the Gallagher Command Centre system. See 1.4.1.1 Configuring an OPC Operator Group and OPC Operator next for further detail. The OPC-visible address space and the OPC read/write permissions within the address space will all be adjusted according to the Gallagher Command Centre configured "operator privileges" associated with the logon.

The Gallagher Command Centre OPC Data Server supports two logon techniques: manual logon and automatic logon. Manual logon is achieved via IOPCSecurityPrivate, which the server implements. Pass the same operator username and password credentials to IOPCSecurityPrivate::Logon as would be used to logon to a Gallagher Command Centre client workstation. The client and its associated OPC server component will then operate with the same operator privilege level as would be obtained by the operator at the Gallagher Command Centre workstation (subject, of course, to the more limited feature set available through the OPC interface).

The Gallagher Command Centre OPC Data Server does not support IOPCSecurityNT.

To enable use by OPC clients that do not support the OPC security specification, the Gallagher Command Centre server also supports a second logon technique: automatic logon. Whenever the Gallagher Command Centre OPC server processes a method call on the IOPCServer interface, it checks the logon status of the client. If it finds the client has not explicitly logged on via IOPCSecurityPrivate it will attempt to perform an automatic internal logon. The credentials it uses are determined in the following order:

1. Registry – The server looks up the following values within the host machine's registry:

Key name (32 bit OS): HKEY\_LOCAL\_MACHINE\SOFTWARE\Cardax\Command Centre FT

Key name (64 bit OS): HKEY\_LOCAL\_MACHINE\SOFTWARE\Wow6432Node\Cardax\

Command Centre FT

Username Value: OPCUserName (REG\_SZ)
Password Value: OPCPassword (REG\_SZ)

Default – If the registry values are not found, the Gallagher OPC server uses the default username as follows, with a blank password:

Username: opc

#### Notes:

 For all of the logon scenarios listed, it is essential that the corresponding operator (with matching username/password) has first been created and configured and enabled as an operator on the Gallagher Command Centre system. It follows, therefore, that if the system installer wants to disable the automatic logon feature for the OPC server then they should simply ensure that there is no default OPC operator configured in the system who has the credentials specified above.

• The default OPC logon with blank password is intended for testing purposes only. Use of this method on production sites is strongly discouraged.

#### 1.4.1.1 Configuring an OPC Operator Group and OPC Operator

OPC clients require an OPC operator. The OPC operator must be configured using the Command Centre Configuration Client, as follows:

- 1. In Gallagher Command Centre, create a cardholder with first and last names as required, (e.g. "OPC Operator").
- 2. Create an Operator Group called 'OPC Operators'.
- On the Operator Privileges tab of this group, select the appropriate privileges from the following list depending on what functionality the OPC client requires:
   Note: At a minimum the OPC operator requires "View Site" privilege in order for site

browse and item status to function, and "Launch Configuration Client" privilege to access the Command Centre Configuration Client.

- View Site
- Launch Configuration Client
- View Events and Alarms
- Run Macros
- Override Open Door
- Maintenance Override
- Override
- Edit Alarms
- 4. Once you have configured the Operator Group, drag the cardholder into that group.
- 5. Apply the changes to the cardholder and then close and reopen the cardholder.
- 6. On the **Operator Configuration** tab of the cardholder, enter the logon name as "opc" (lower case), check the **Force password change at next logon** checkbox and click **OK**.
- 7. Log out and log in as the 'opc' operator. The Password has expired dialog displays.
- 8. Create a secure password and click **OK**.
  - **Note:** This is the password that will be used by OPC clients when logging in via IOPCSecurityPrivate, or when the server logs on using the registry-sourced password as detailed in section 1.4.1 earlier.
- 9. Ensure everything is configured correctly in the Command Centre Configuration Client.

# 1.4.2 Access Rights

Section 6.7.6 of the OPC DA 3.0 specification contains the following paragraph about data item access rights:

The OPC\_READABLE and OPC\_WRITABLE bits are intended to indicate whether the Item is inherently readable or writable. For example, a value representing a physical input would generally be readable but not writable. A value representing a physical output or an adjustable parameter such as a setpoint or alarm limit would generally be readable and writable. It is possible that a value representing a physical output with no readback capability might be marked writable but not readable. It is recommended that Client applications use this information only as something to be viewed by the user. Attempts by the user to read or write a value should always be passed by the client program to the

server regardless of the access rights that were returned when the item was added. The Server can return E\_BADRIGHTS if needed.

Gallagher Command Centre **overrides** exposed through OPC will have an inherent access of OPC\_WRITABLE *without* OPC\_READABLE (i.e. they will be write-only). Therefore, OPC clients connecting to the Gallagher Command Centre server must support write-only data items.

Gallagher Command Centre **status** values available through OPC will have an inherent access of OPC\_READABLE *without* OPC\_WRITABLE (i.e. they will be read-only).

The Gallagher Command Centre OPC Data Server does not currently expose any read/write fields through the interface. Also, any fields that are denied to the logged-on operator due to Gallagher Command Centre configured privilege restrictions will not be included in the returned set of OPC items **via IOPCServer::Browse** – i.e. they will simply not be exposed through the OPC interface.

#### 1.4.3 DCOM and Firewall

The Gallagher Command Centre OPC Data Server installer performs the following DCOM and firewall security configurations at install time:

- Automatically adds the server component (CCNTSad.exe) to the standard Windows XP SP2 firewall, if present.
- Sets the server component to run under the Local System account.
- Gives DCOM activation and access permissions (both local and remote) for the server component to the "Cardax Users" group. This group was created at Gallagher Command Centre install time and by default includes "Everyone".

The Gallagher Command Centre OPC Data Server does not do any of the following:

- Install the OPCEnum service or any of the other OPC core components other than what is required to run OPC DA 3.0. This may mean that a remote client needs to use a CLSID to access the server. If the client wants to use a ProgID or server browsing then the OPC core components should be installed separately.
- Add the server component to any other firewall (non-XP standard) that may be running on the server machine.
- Make configuration changes on client machines. A clean client machine, in order to access the remote server will need to:
  - 1. Add the client application to the firewall on the client machine.
  - 2. Open port 135 in the client firewall to enable DCOM.
  - 3. Enable machine-wide DCOM remote *access* permissions for "Anonymous" in order to allow the server to perform DCOM callbacks to the client application.

It is the responsibility of the system installer to adjust DCOM config permissions for the server component and client machines as well as manage any relevant firewall restrictions to allow clients to access the server from across a network, according to the security policies of the installing site. A useful resource of note here is:

OPC & DCOM Troubleshooting: Quick Start Guide – available from the OPC Training Institute, download here:

http://www.opcti.com/ResourceDetails.aspx?id=2&AspxAutoDetectCookieSupport=1


#### 1.5 Localisation

The Gallagher Command Centre OPC Data Server supports localisation of strings, including translations of error codes, via the standard methods of the IOPCCommon interface. Gallagher-specific HRESULTS may be submitted to IOPCCommon::GetErrorString to retrieve a locale-specific description of the code. Note, however, that locales are limited to those supported in the Gallagher Command Centre installation.

# 2 Application

#### 2.1 Gallagher Command Centre Address Spacing

The client may use either the OPC DA 3.0 **IOPCBrowse** interface or the DA 2.0 **IOPCBrowseServerAddressSpace** to browse the address space of the Gallagher server. The Gallagher **IOPCBrowse::Browse** implementation supports *continuation points* and exposes an address space structured in the following way:



Note: The above is an example only and does not represent the final collection of properties and overrides exposed through the Gallagher Command Centre OPC interface. Also, the specific address space returned via **IOPCBrowse** is dependent on the access privileges of the operator currently logged on to the OPC server.

The features of the address space are as follows:

#### 2.1.1 Top-level Folders

These folders act as storage containers for logically grouped items within the Gallagher Command Centre address space. They are equivalent, having the same names and contents, to the Gallagher Command Centre configuration windows (also known as "master list windows") within the Gallagher Command Centre workstation client. For example, the "Door" top-level folder within the OPC address space is equivalent to the "Door" configuration window within the Gallagher Command Centre workstation client – It will contain the same Gallagher Command

Centre items in the same relationship to each other as would be found in the Gallagher Command Centre client under the same logon.

Note that the top-level folders are not OPC items – they cannot be added to OPC groups – but instead are marked as "containing children" while being "not an item". (Refer to the discussion of OPC\_BROWSE\_HASCHILDREN and OPC\_BROWSE\_ISITEM in section 4.3.6.1 of the OPC DA 3.0 specification).

#### 2.1.2 Gallagher Command Centre Items

Gallagher Command Centre items – such as Doors, Controllers, Access Zones, Macros – are presented in the OPC Browse hierarchy beneath their related top-level folder. Gallagher Command Centre items may exist in a hierarchical relationship to each other, such as IO boards below the Controller they are connected to. Gallagher Command Centre items are marked as OPC items and therefore support the list of basic properties defined by the OPC specification, as well as a small set of standard Gallagher Command Centre properties, such as item type, and modification date etc.

#### 2.1.3 Properties

Some Gallagher Command Centre properties, especially item status, are exposed as OPC items in their own right; sitting as child items below the Gallagher Command Centre item they apply to. This allows them to be added to OPC groups and allows the client to be notified of changes in those properties. This is intended to facilitate the addition of status properties to site plans or other dynamically updated UI feature.

Properties that are OPC items are grouped together under a container folder called "Properties", as shown above. The container folder is not an OPC item.

#### 2.1.4 Overrides

Gallagher Command Centre overrides are exposed as OPC items in their own right; sitting as child items below the Gallagher Command Centre item they apply to. This allows them to be easily identified and also allows their value to be written by the OPC client. Note that Gallagher Command Centre overrides are exposed as OPC items having inherent write only access.

Overrides are grouped together under a container folder called "Overrides", as shown above. The container folder is not an OPC item.

The following points should be noted when dealing with the OPC browse functionality provided by the Gallagher Command Centre OPC Data Server:

- There is no support in the OPC DA 3.0 specification for server notifications to connected clients regarding changes in the server's address space structure. The OPC specification assumes an address space that is static (in population, not in item values) over the execution lifetime of the server.
  - However, Gallagher Command Centre workstation clients running at the same time as the OPC clients may update the Gallagher Command Centre address space. This implies that OPC items determined via **IOPCBrowse** are not guaranteed to remain present over the lifetime of the OPC client's connection to the server. (For example, a Gallagher Command Centre operator may delete a Door after an OPC client has browsed it). OPC clients should be designed to cope with these scenarios.
- Currently the "vendor filter" feature of the browse function is unsupported. It merely reproduces the behaviour of the OPC standard "name filter" when browsing for items.
- The Gallagher Command Centre scheme for generating OPC ITEMIDs has been designed to be as static as possible, allowing clients to store item Ids or OPC group definitions without

fear of the Ids becoming disconnected from the items due to changes in the server configuration. To this end, Gallagher Command Centre generated OPC item Ids *do not* make use of concatenated item names such as is demonstrated in the OPC specification. (Item names may easily be changed via the Gallagher Command Centre client and would then expire any client-stored Ids for those items).

While it is highly unlikely that Gallagher Command Centre generated item Ids will ever "unlink" from their items, there is a slight possibility that this could happen *over an upgrade from one version of Gallagher Command Centre to an upgraded version*. This is the only vulnerable scenario, and it would happen if the upgraded version changed field identifiers internally. Thus, an upgrade of Command Centre needs to be accompanied with a test of OPC data clients to make sure any client-stored item or group definitions are still valid.

### 2.2 Gallagher Command Centre Properties

The following Gallagher Command Centre specific properties are available through IOPCBrowse::Browse and IOPCBrowse::GetProperties for Gallagher Command Centre items in the address space:

Name	Property ID	Туре	OPC item	Description
Name	5000	VT_BSTR	No	The item name, as displayed in the Gallagher command Centre client property pages for the item.
Description	5001	VT_BSTR	No	The item description
Notes	5035	VT_BSTR	No	The short notes for the item, as found on the item's Gallagher Command Centre property page.
Short name	5031	VT_BSTR	No	The item's short name.
Created	5002	VT_DATE	No	The date and time at which the item was created.
Modified	5004	VT_DATE	No	The date and time at which the item was last modified.
Database ID	5008	VT_14	No	An integer identifier that uniquely identifies each Gallagher Command Centre item.
Class ID	5027	VT_BSTR	No	A globally unique identifier (GUID) that identifies the item's type.
Type name	5012	VT_BSTR	No	A description of the item's type, in the Language of the Gallagher Command Centre server's locale.
Status	5013	VT_14	Yes	An integer representation of the item's status.
Status text	5029	VT_BSTR	Yes	A string representation of the item's status.
IP Address	6012	VT_BSTR	No	The Gallagher's Controller's IP address. This field is only available on Gallagher Controller item types.
Alarm Dialling "CCC" setting	8900	VT_BSTR	No	The Contact ID alarm dialling "CCC" setting for the item. This field is only available on item types that support the CCC setting.

# 2.3 Gallagher Command Centre Status

As well as status text delivered as an OPC property on Gallagher Command Centre items, a raw 32-bit integer representation of status is also available. This is vendor-specific property 5013 in the table above. For each item type it is formed as the "ORing" of flags according to the following table:

Item Type	Status	Flag
All Items		
	Normal	0x0
	Unsaved	0x1
	Unconfigured	0x2
	Deleted	0x4
	Unknown	0x8
	Process Offline	0x10
	Controller Offline	0x20
	Awaiting status from Controller	0x10000000
All Hardware		
	Unit Offline	0x100
	Not Polled	0x200
	Bad Power	0x400
	Front Tamper	0x800
	Back Tamper	0x1000
	Tamper	0x2000
Input		
	Shunt	0x200
	Closed. (Open = flag not set)	0x4000
	Parent alert (Which means: "Also note the status of the device that this item is attached to")	0x8000
	Isolated	0x20000
Output		
	On. (Off = flag not set)	0x4000
	Overridden	0x100000
	Pulsed	0x40000000
Door		
	Closed (Open = flag not set)	0x4000
	Secure (Free = flag not set)	0x40000
	Locked (Unlocked = flag not set)	0x2000000
	Forced	0x4000000
	Open Too Long	0x8000000
Access Zone		
	Secure (Free = flag not set)	0x40000
	Code only	0x10000
	Dual authorisation	0x20000
	Overridden	0x100000
	Zone count too high	0x200000
	Zone count too low	0x400000

Armed (Disarmed = flag not set)	Item Type	Status	Flag
The zone count part of status integer is valid		PIN	0x800000
The access part of the status integer is valid   0x80000000		Locked down	0x2000000
Armed (Disarmed = flag not set)		The zone count part of status integer is valid	0x40000000
Armed (Disarmed = flag not set)		The access part of the status integer is valid	0x80000000
User 1 state	Alarm Zone		
User 2 state		Armed (Disarmed = flag not set)	0x10000
Exit Delay   0x80000		User 1 state	0x20000
Shunt		User 2 state	0x40000
Shunt		Exit Delay	0x80000
On. (Off = flag not set)  Parent alert (Which means: "Also note the status of the device that this item is attached to")  Fence Zone overridden  Pre-arm  Ox20000  Deterrent unknown  In alarm  Ox80000  In warning  Low feel  On HBUS fence controller  Low voltage warning  Locked out  Zone's controller in service mode  HV plus mode  Temperature outside HV plus range  Go slow  Stop  Ox80000  Ox40000  Ox400000  Ox400000  Ox4000000  Ox2000000  Ox2000000  Ox2000000  Ox2000000  Ox2000000  Ox2000000  Ox2000000	Fence Zone		
Parent alert (Which means: "Also note the status of the device that this item is attached to")  Fence Zone overridden  Pre-arm  Ox20000  Deterrent unknown  In alarm  Ox80000  In warning  Low feel  On HBUS fence controller  Low voltage warning  High voltage warning  Locked out  Zone's controller in service mode  HV plus mode  Temperature outside HV plus range  Go slow  Stop  Ox10000  Ox200000  Ox200000  Ox200000  Ox2000000  Ox2000000  Ox2000000  Ox2000000  Ox2000000  Ox2000000  Ox2000000  Ox2000000  Ox2000000		Shunt	0x200
Deterrent unknown   Dete		On. (Off = flag not set)	0x4000
Pre-arm         0x20000           Deterrent unknown         0x40000           In alarm         0x80000           In warning         0x100000           Low feel         0x200000           On HBUS fence controller         0x400000           Low voltage warning         0x800000           High voltage warning         0x1000000           Locked out         0x2000000           Zone's controller in service mode         0x4000000           HV plus mode         0x8000000           Temperature outside HV plus range         0x20000000           Fence Controller           Go slow         0x10000           Stop         0x200000		· ·	0x8000
Deterrent unknown   0x40000     In alarm   0x80000     In warning   0x100000     Low feel   0x200000     On HBUS fence controller   0x400000     Low voltage warning   0x800000     High voltage warning   0x1000000     Locked out   0x2000000     Zone's controller in service mode   0x4000000     HV plus mode   0x8000000     Temperature outside HV plus range   0x20000000     Stop   0x200000     Ox10000   0x200000     Ox200000   0x2000000     Ox200000   0x200000     Ox2000000   0x2000000     Ox2000000   0x2000000     Ox2000000   0x2000000     Ox2000000   0x20000000     Ox20000000   0x2000000     Ox20000000   0x20000000     Ox20000000   0x20000000     Ox20000000   0x20000000     Ox20000000   0x20000000     Ox200000000   0x20000000     Ox20000000   0x2000000     Ox20000000   0x20000000     Ox200000000   0x20000000     Ox20000000   0x20000000     Ox20000000   0x2000000     Ox20000000   0x20000000     Ox2000000   0x2000000   0x2000000     Ox2000000   0x2000000   0x2000000     Ox2000000   0x2000000   0x2000000     Ox2000000   0x2000000   0x20000000   0x2000000   0x20000000   0x20000000   0x20000000   0x20000000   0x20000000   0x20000000   0x2000000000   0x20000000   0x20000000   0x20000000   0x20000000   0x20000000   0		Fence Zone overridden	0x10000
In alarm		Pre-arm	0x20000
In warning		Deterrent unknown	0x40000
Low feel		In alarm	0x80000
On HBUS fence controller  Low voltage warning  High voltage warning  Locked out  Zone's controller in service mode  HV plus mode  Temperature outside HV plus range  Go slow  Stop  Ox400000  Ox2000000  Ox20000000  Ox20000000  Ox20000000  Ox20000000  Ox10000  Ox2000000		In warning	0x100000
Low voltage warning		Low feel	0x200000
High voltage warning		On HBUS fence controller	0x400000
Locked out		Low voltage warning	0x800000
Zone's controller in service mode		High voltage warning	0x1000000
HV plus mode		Locked out	0x2000000
Temperature outside HV plus range		Zone's controller in service mode	0x4000000
Go slow		HV plus mode	0x8000000
Go slow         0x10000           Stop         0x20000		Temperature outside HV plus range	0x2000000
Stop 0x20000	Fence Controlle	r	
		Go slow	0x10000
Low battery 0x40000		Stop	0x20000
Low battery		Low battery	0x40000
Earth unknown 0x80000		Earth unknown	0x80000
Earth alarm 0x100000		Earth alarm	0x100000
No battery 0x200000		No battery	0x200000
Competing sync 0x800000		Competing sync	0x800000
Sync lost 0x400000		Sync lost	0x400000
Very high temperature 0x1000000		Very high temperature	0x1000000
Critical temperature 0x2000000		Critical temperature	0x2000000
Service mode 0x8000000		Service mode	0x8000000
HV Plus mode 0x20000000		HV Plus mode	0x2000000
Temperature outside HV Plus range 0x40000000		Temperature outside HV Plus range	0x4000000

All doors secure	Item Type	Status	Flag
Interlocking disabled by override Interlocking rules breached. (Interlocking rules active = 0x400000 Interlocking rules breached. (Interlocking rules active = 0x4000000 Interlocking rules breached. (Interlocking rules active = 0x4000000 Interlocking rules breached. (Interlocking rules active = 0x4000000 Interlocking rules active = 0x40000000000000000000000000000000000	Interlock Grou	ip	
Interlocking rules breached. (Interlocking rules active = flag not set).  Logic Block  On. (Off = flag not set)		All doors secure	0x40000
Intercom System  Intercom System offline (Online = flag not set).  Intercom System offline  Intercom call active  Intercom call active  Intercom call and ovalououo  Intercom call and ovalououo  Intercom call and out and ovalououououououououououououououououououou		Interlocking disabled by override	0x100000
On. (Off = flag not set)			0x4000000
Overridden	Logic Block		
Logic block input in unknown state   0x200000		On. (Off = flag not set)	0x4000
Services and Workstations    Process Offline. (Online = flag not set).   0x10		Overridden	0x100000
Process Offline. (Online = flag not set).   0x10		Logic block input in unknown state	0x200000
External System   External System Offline. (Online = flag not set).   0x100	Services and V	Vorkstations	
External System Item    Closed. (Open = flag not set).   0x4000     Tamper		Process Offline. (Online = flag not set).	0x10
External System Item    Closed. (Open = flag not set)   0x4000     Tamper   0x2000     External System Item offline. (Online = flag not set).   0x10000     Parent alert (Which means: "Also note the status of the device that this item is attached to")    DVR System   DVR System Offline. (Online = flag not set).   0x100     DVR Camera   Closed. (Open = flag not set)   0x4000     Tamper   0x2000     DVR Camera offline. (Online = flag not set).   0x1000     Parent alert (Which means: "Also note the status of the device that this item is attached to")     Intercom System   Intercom System offline   0x200     Intercom System   Intercom System offline   0x200     Intercom Intercom Gystem offline   0x400     Intercom Intercom offline   0x400     Intercom call active   0x00800000     Intercom call active   0x00800000     Intercom call ended   0x020000000     Intercom call ended   0x020000000     Intercom call on hold   0x04000000     Sturbance Sensor   Tilt alarm   0x000000     Disturbance alarm   0x2000     Disturbance alarm   0x2000     Disturbance Sensor   Ox20000000     Disturbance Sensor   Ox200000000     Disturbance Sensor   Ox20000000     Disturbance Sensor   Ox20000000     Disturbance Sensor   Ox20000000     Description of Sensor   Ox20000000     Description	External Syste	m	
Closed. (Open = flag not set)   0x4000     Tamper		External System Offline. (Online = flag not set).	0x100
Closed. (Open = flag not set)   0x4000     Tamper	External Syste	m Item	
Tamper External System Item offline. (Online = flag not set).  Parent alert (Which means: "Also note the status of the device that this item is attached to")  DVR System  DVR System Offline. (Online = flag not set).  DVR Camera  Closed. (Open = flag not set).  DVR Camera  Closed. (Open = flag not set).  DVR Camera offline. (Online = flag not set).  DVR Camera offline. (Online = flag not set).  Parent alert (Which means: "Also note the status of the device that this item is attached to")  Intercom System  Intercom System offline  Intercom System offline  Intercom System offline  Intercom System offline  Intercom isolated  Intercom isolated  Intercom call active  Intercom call ringing  Intercom call ringing  Intercom call on hold  Z20 Disturbance Sensor  Tilt alarm  Dynamic alarm  Disturbance alarm  Ox2000  Ox200	·	Closed. (Open = flag not set)	0x4000
Parent alert (Which means: "Also note the status of the device that this item is attached to")  DVR System  DVR System Offline. (Online = flag not set).  DVR Camera  Closed. (Open = flag not set)  Tamper  DVR Camera offline. (Online = flag not set).  Parent alert (Which means: "Also note the status of the device that this item is attached to")  Intercom System  Intercom System offline  Intercom System offline  Intercom System offline  Intercom System offline  Intercom offline  Intercom isolated  Intercom remoted  Intercom remoted  Intercom call active  Intercom call ringing  Intercom call ended  Intercom call on hold  Z20 Disturbance  Tit alarm  Dynamic alarm  Disturbance alarm  Ox2000  Ox1000  Ox2000  Ox2000		Tamper	0x2000
DVR System   DVR System Offline. (Online = flag not set).   0x100		External System Item offline. (Online = flag not set).	0x10000
DVR System Offline. (Online = flag not set).  DVR Camera  Closed. (Open = flag not set)		· ·	0x8000
DVR System Offline. (Online = flag not set).  DVR Camera  Closed. (Open = flag not set)	DVR System		
Closed. (Open = flag not set)   0x4000     Tamper		DVR System Offline. (Online = flag not set).	0x100
Tamper  DVR Camera offline. (Online = flag not set).  Parent alert (Which means: "Also note the status of the device that this item is attached to")  Intercom System  Intercom System offline  Intercom System offline  Intercom System offline  Intercom offline  Intercom offline  Intercom isolated  Intercom remoted  Intercom call active  Intercom call ringing  Intercom call ended  Intercom call on hold  Z20 Disturbance Sensor  Tilt alarm  Dynamic alarm  Disturbance alarm  Ox2000  Ox200	DVR Camera		
DVR Camera offline. (Online = flag not set).  Parent alert (Which means: "Also note the status of the device that this item is attached to")  Intercom System  Intercom System offline  Intercom System offline  Intercom System offline  Intercom offline  Intercom offline  Intercom isolated  Intercom remoted  Intercom call active  Intercom call ringing  Intercom call on hold  Z20 Disturbance Sensor  Tilt alarm  Dynamic alarm  Disturbance alarm  Disturbance alarm  Dx8000  0x10000  0x2000  0x100000  0x2000  0x10000  0x04000000  0x04000000  0x1000		Closed. (Open = flag not set)	0x4000
Parent alert (Which means: "Also note the status of the device that this item is attached to")  Intercom System  Intercom System offline  Intercom System offline  Intercom System offline  Intercom offline  Intercom isolated  Intercom remoted  Intercom call active  Intercom call ringing  Intercom call ended  Intercom call on hold  Z20 Disturbance Sensor  Tilt alarm  Dynamic alarm  Disturbance alarm  Ox200  Ox2000  Ox2000		Tamper	0x2000
Intercom System offline   0x200		DVR Camera offline. (Online = flag not set).	0x10000
Intercom System offline		· ·	0x8000
Intercom	Intercom Syste	em	
Intercom System offline		Intercom System offline	0x200
Intercom offline	Intercom		
Intercom isolated		Intercom System offline	0x200
Intercom remoted		Intercom offline	0x400
Intercom call active		Intercom isolated	0x800
Intercom call ringing		Intercom remoted	0x1000
Intercom call ended		Intercom call active	0x00800000
Intercom call ended		Intercom call ringing	0x01000000
Z20 Disturbance Sensor           Tilt alarm         0x0800           Dynamic alarm         0x1000           Disturbance alarm         0x2000			0x02000000
Tilt alarm $0 \times 0800$ Dynamic alarm $0 \times 1000$ Disturbance alarm $0 \times 2000$		Intercom call on hold	0x04000000
Dynamic alarm0x1000Disturbance alarm0x2000	Z20 Disturban	ce Sensor	
Disturbance alarm 0x2000			0x0800
Disturbance alarm 0x2000		Dynamic alarm	0x1000
			0x2000
			0x04000000

Item Type	Status	Flag		
Z10 Tension Sen	Z10 Tension Sensor Group			
	Maintenance mode	0x00010000		
	Walk test mode	0x00020000		
	Low tension	0x00040000		
	High tension	0x00080000		
	Voltage error	0x00100000		
	Sensor offline	0x00200000		
Class 5 End-of-Li	ne Module			
	Closed (Open = flag not set)	0x00004000		
	Isolated	0x00002000		
	Masked	0x00040000		

Note on Gallagher Command Centre Status Updates Through OPC

In Gallagher Command Centre an item's status is maintained at the server only when that item is being "watched" in a Gallagher Command Centre workstation. This is an efficiency feature that prevents massive amounts of unneeded item status being delivered to the Gallagher Command Centre server.

This feature has the following implications for reading status through the OPC server:

- Adding a Gallagher Command Centre item to an OPC group, where the item and the group
  is set to active, has the effect of putting a "watch" on the item in exactly the same way as
  watching it through the Gallagher Command Centre workstation. Thus the item's status will
  be maintained at the Gallagher Command Centre server and available through the OPC
  interface.
- 2. Therefore, reading status through one of the OPC group-based IO interfaces (e.g. IOPCSyncIO, IOPCAsyncIO etc.) is guaranteed to return up-to-date status for the items, providing the OPC group and item are set as active.
- 3. However, reading status through one of the OPC synchronous, non-group, read interfaces (i.e. IOPCItemIO or IOPCBrowse) is not guaranteed to return up-to-date status data. This is because there is no guarantee the item is part of an active OPC group or on display in a Gallagher Command Centre workstation and so there is no guarantee that Gallagher Command Centre has a "watch" on the item and is collecting up-to-date status data.
- 4. In order for OPC clients to determine the validity of status data *when reading it through a synchronous, non-group, IO interface,* the following OPC VQT scheme is implemented:
  - The timestamp (T) of the status value will indicate the time of collection of that status value (V) from the item hardware.
  - The quality (Q) of the status value will be marked as BAD if Gallagher Command Centre
    has never received status data from the item hardware i.e. the item has never been
    "watched" via an OPC group or via Gallagher Command Centre workstation.
  - The quality (Q) of the status value will be marked as UNCERTAIN if the status value is a real, timestamped status value from Gallagher Command Centre, but where the item's lack of inclusion in a group (i.e. the lack of a "watch" on the item's status) means the OPC server can't be certain if the value it holds is the *latest* status for the device.
  - For all active items that are included in an active group, the status value (V) will be marked as GOOD quality (Q) because there is a current "watch" associated with the item.

Note that the scheme detailed here only applies when reading through the OPC non-group interfaces. When reading status through an IO interface on an active OPC group, the quality (Q) will always be GOOD and the data up-to-date.

#### 2.4 Gallagher Command Centre Overrides

As described earlier, Gallagher Command Centre overrides are exposed through OPC as OPC items existing as child items below the Gallagher Command Centre item they apply to. For example, the "Open Door" override is an OPC item existing as a child of the "East Door" item. Where a Gallagher Command Centre item has several override options, each option is exposed as separate child OPC item of the Gallagher Command Centre item.

All overrides have a data type of VT\_I4. The override is engaged by writing an integer value into the appropriate OPC item. The value has different meanings depending on the override. For most overrides it is the length of time (in minutes, with a maximum of 1440) that the override is to be active for. In the case of the "Open Door" override, for example, the value is meaningless – just the act of writing to the item value will cause the door to be unlocked. Refer to the following table for details:

Item Type	Override	Value
Input		
	Shunt	Ignored. Override persists until manually reversed.
	Unshunt	Ignored. Override persists until manually reversed.
Output		
	On	Specifies the duration (in minutes) of the override. Value of 0 specifies override until next schedule update.
	Off	Specifies the duration (in minutes) of the override. Value of 0 specifies override until next schedule update.
	Cancel Override	Ignored. Writing to the value invokes the cancel.
Door		
	Open Door	Ignored. Write any value to open the door.
Access Zone		
	Free – No PIN	Specifies the duration (in minutes) of the override. Value of 0 specifies override until next schedule update.
	Free – PIN	As above
	Secure – No PIN	As above
	Secure – PIN	As above
	Code only – Card and No PIN	As above
	Dual auth – No PIN	As above
	Dual auth – PIN	As above
	Cancel Override	Ignored. Writing to the value invokes the cancel.
Alarm Zone		
	Armed	Specifies the duration (in minutes) of the override. Value of 0 specifies override until next schedule update.
	Disarmed	As above
	User 1 State	As above
	User 2 State	As above
	Cancel Override	Ignored. Writing to the value invokes the cancel.

Item Type	Override	Value
Macro		
	Run	Ignored. Writing to the value invokes the override.
Fence Zone		
	On	Ignored. Override persists until manually reversed.
	Off	Ignored. Override persists until manually reversed.
	Shunt	Ignored. Override persists until manually reversed.
	Unshunt	Ignored. Override persists until manually reversed.
	High Voltage	Ignored. Override persists until manually reversed.
	Low Feel	Ignored. Override persists until manually reversed.
	Cancel Override	Ignored. Writing to the value invokes the cancel.
Fence Controll	er	
	Shunt	Ignored. Override persists until manually reversed.
	Unshunt	Ignored. Override persists until manually reversed.
Interlock Grou	p	
	Enable	Ignored. Override persists until manually reversed.
	Disable	Ignored. Override persists until manually reversed.
Logic Block		
	On	Ignored. Override persists until manually reversed.
	Off	Ignored. Override persists until manually reversed.
	Reset Logic	Ignored. Writing to the value invokes the reset.
	Cancel Override	Ignored. Writing to the value invokes the cancel.
Z10 Tension Se	ensor Group	
	Shunt	Ignored. Override persists until manually reversed.
	Unshunt	As above
	Maintenance Mode	As above
	Cancel Maintenance Mode	As above
	Walk Test Mode	As above
	Cancel Walk Test Mode	As above
Z20 Disturbance Sensor		
_	Shunt	Ignored. Override persists until manually reversed.
	Unshunt	As above
Class 5 End-of-	Line Module	
_	Reset	Writing to the value invokes the reset.
	Isolate	Ignored. Override persists until manually reversed.
	Deisolate	Ignored. Override persists until manually reversed.
	Shunt	Ignored. Override persists until manually reversed.
	Unshunt	Ignored. Override persists until manually reversed.

#### 2.5 Inclusions and Exclusions

The following points should be noted about Gallagher Command Centre support for optional OPC features:

#### 2.5.1 Legacy OPC Data Interfaces

The Gallagher implementation supports OPC DA 3.0 and DA 2.05a specifications, without legacy support for OPC DA 1.0 interfaces or techniques.

#### 2.5.2 Limited VQT Support

The Gallagher Command Centre implementation supports appropriate setting of item values by the client (V) but does not support *client setting* of quality (Q) or timestamp (T) information. On an item read, the server will set the timestamp parameter to the time of reading.

### 2.5.3 CACHE/DEVICE Support

Because of the architecture of Gallagher Command Centre and the close positioning of the OPC Data Server component with respect to the Gallagher Command Centre data store, the Gallagher Command Centre OPC Data implementation includes no differentiation between the OPC CACHE and DEVICE contexts. Thus, the Gallagher Command Centre OPC Data Server does not implement its own data cache and so CACHE = DEVICE and writing to one is the same as writing to the other.

A synchronous write to DEVICE is equated to a committed write to a Gallagher Command Centre item in memory and database. Note, however, that transmission of changes to Gallagher hardware occurs according to the standard Gallagher Command Centre schemes, which is not guaranteed to be complete before the return from the OPC synchronous DEVICE write call.

Thus, the scheme described here equates the OPC abstract concept of DEVICE with the Gallagher Command Centre server, and not with Gallagher hardware.

#### 2.5.4 Deadband Support

The Gallagher Command Centre implementation does not support the OPC DA *deadband* features. Deadbands are an OPC feature designed to suppress noisy signallers by only triggering OPC callbacks when an item's value transitions more than a specified percentage from the previous callback value.

#### 2.5.5 Access Paths

Specification of *access paths* are optional within OPC. The Gallagher Command Centre implementation does not support them; items are referenced by their fully-qualified ITEMID only.

#### 2.5.6 Blob Support

OPC DA 3.0 contains provision for server-specified and client-stored *blobs* used for aiding server address resolution. The Gallagher Command Centre server does not make use of the blobs.

# 2.5.7 Optional Interfaces

The Gallagher server supports all required interfaces for the OPC DA 3.0 specification. The Gallagher server supports none of the interfaces marked optional for OPC DA 3.0.

The Gallagher server supports all required interfaces for the OPC DA 2.0 specification. The Gallagher server supports one interface marked as optional for OPC DA 2.0 -- IOPCBrowseServerAddressSpace.