# **Arduino MIDI**

Pieter P, 08-03-2017

This is a guide that covers the basics of the Musical Instrument Digital Interface (MIDI) protocol and its implementation on the Arduino platform.

The format of the protocol is explained in the first chapter. Chapter two goes over the hardware. In chapter three, example code for sending MIDI is presented. Chapter four contains everything needed to build a working MIDI controller. MIDI input is covered in chapter five, and chapter six extends this by adding support for System Exclusive (SysEx) messages.

## The MIDI protocol

The MIDI specification can be found here: https://www.midi.org/specifications/item/the-midi-1-0-specification

The MIDI protocol describes a set of MIDI events. For example, a note is played, or a note is turned off, a controller is moved and set to a new value, a new instrument is selected, etc. These events correspond to MIDI messages that can be sent over the MIDI hardware connection.

There are two main types of messages: channel messages and system messages. Most performance information will be sent as channel messages, while system messages are used for things like proprietary handshakes, manufacturer-specific settings, sending long packets of data, real-time messages for syncronization and tuning, and other things that are not really of interest to someone who just wants to make an Arduino MIDI instrument or controller. That's why this guide will mainly focus on channel messages.

## **Channel messages**

There are 16 MIDI channels. Each MIDI instrument can play notes on one of these channels, and they can apply different voices or patches to different channels, as well as setting some controllers like volume, pan, balance, sustain pedal, pitch bend, etc.

MIDI messages that target a specific channel are called channel messages.

A MIDI channel message consist of a header byte, referred to as the status byte, followed by one or two data bytes:

Each byte consists of 8 binary digits. To distinguish between status and data bytes, and to prevent framing errors, status bytes have the most significant bit (msb) set to one (1), and data bytes have the msb set to zero (0).

			St	atu	s by	/te					Da	ta I	oyte	e 1				ata	by	te 2	2 (o	ptio	ona	I)
Bit	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
Value	1	х	х	х	х	х	х	х	0	х	х	х	х	х	х	х	0	х	х	х	х	х	х	х

#### Status bytes

The status byte of channel messages is divided into two 4-bit nibbles. The high nibble (bits 4-7) specifies the message type, and the low nibble (bits 0-3) specifies the MIDI channel. Because the most significant bit has to be one, there are 8 different message types (0b1000 - 0b1111 or 0x8 - 0xF), and 16 different channels (0x0 - 0xF). Message type 0xF is used for system messages, so it won't be covered in this section on channel messages.

			St	atu	s by	/te		
Bit	7	6	5	4	3	2	1	0
Value	m	m	m	m	n	n	n	n

Where mmmm is the message type (0x8 - 0xE) and nnnn is the channel nibble. Note that the channels start from nnnn = 0 for MIDI channel 1. (nnnn = channel - 1)

#### **Data bytes**

Each data byte contains a 7-bit value, a number between 0 and 127 (0b011111111 or 0x7F). The meaning of this value depends on the message type. For example, it can tell the receiver what note is played, how hard the key was struck, what instrument to select, what value a controller is set to, etc.

## **Channel Messages: message types**

The following section will go over the different channel messages and their status and data bytes. Keep in mind that nnnn = channel - 1.

#### Note Off (0x8)

A note off event is used to stop a playing note. For example, when a key is released.

Data 1 (0b0kkkkkk): Note number (key). See MIDI note names.

Data 2 (0b0vvvvvvv): Velocity (how fast the key is released).

- A velocity of 0 is not defined, and some software or devices may not register the note off event if the velocity is zero.
- Most software or devices will ignore the note off velocity.
- Instead of a note off event, a note on event with a velocity of zero may be used. This is especially useful when using a <u>running status</u>.

			St	atu:	s by	/te					Not	e n	um	ber					١	/elc	city	/		
Bit	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
Value	1	0	0	0	n	n	n	n	0	k	k	k	k	k	k	k	0	٧	٧	٧	٧	٧	٧	V

#### Note On (0x9)

A note on event is used to play a note. For example, when a key is pressed.

**Data 1** (0b0kkkkkkk): Note number (key). See <u>MIDI note names</u>. **Data 2** (0b0vvvvvvv): Velocity (how fast/hard the key is pressed).

• If the velocity is zero, the note on event is interpreted as a note off event. This is especially useful when using a <u>running status</u>.

			St	atu	s by	/te					Not	e n	um	ber					١	/elc	city	/		
Bit	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
Value	1	0	0	1	n	n	n	n	0	k	k	k	k	k	k	k	0	٧	٧	v	٧	٧	٧	V

#### Polyphonic key pressure (0xA)

A polyphonic key pressure event is used when the pressure on a key or a pressure sensitive pad changes after the note on event.

Data 1 (0b0kkkkkkk): Note number (key). See MIDI note names.

Data 2 (0b0vvvvvvv): Pressure on the key.

- Most normal MIDI keyboards do not implement this event.
- Key pressure is sometimes referred to as after-touch or after-pressure.

			St	atu:	s by	/te					Not	e n	um	ber					P	res	sur	e		
Bit	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
Value	1	0	1	0	n	n	n	n	0	k	k	k	k	k	k	k	0	V	V	٧	٧	٧	٧	v

### Control change (0xB)

A control change event is used when the value of a controller changes.

Data 1 (0b0ccccccc): Controller number. See Controller numbers.

**Data 2** (0b0vvvvvvv): The value of the controller.

• Controller numbers 120-127 are reserved as "Channel Mode Messages".

			St	atu	s by	/te				Со	ntr	olle	r nı	umb	er					Val	ue			
Bit	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
Value	1	0	1	1	n	n	n	n	0	С	С	С	С	С	С	С	0	٧	٧	V	٧	V	٧	V

#### **Program change** (0xC)

A program change event is used to change the program (i.e. sound, voice, tone, preset or patch) of a given channel is changed.

**Data 1** (0b0ppppppp): Program number. See <u>Program numbers</u>.

Controller numbers 120-127 are reserved as "Channel Mode Messages".

			St	atu	s by	/te				Pr	ogr	am	nu	mb	er	
Bit	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
Value	1	1	0	0	n	n	n	n	0	С	С	С	С	С	С	С

### Channel pressure (0xD)

A channel pressure event is used when the pressure on a key or a pressure sensitive pad changes after the note on event. Unlike polyphonic key pressure, channel pressure affects all notes playing on the channel.

Data 1 (0b0vvvvvvv): Pressure value.

- Most normal MIDI keyboards do not implement this event.
- Channel pressure is sometimes referred to as after-touch or after-pressure.

			St	atu	s by	/te					F	res	sur	e		
Bit	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
Value	1	1	0	1	n	n	n	n	0	٧	٧	v	٧	v	٧	٧

#### Pitch bend change (0xE)

A pitch bend change event is used to alter the pitch of the notes played on a given channel.

**Data 1** (0b01111111): Least significant byte (bits 0-7) of the pitch bend value. **Data 2** (0b0mmmmmmm): Most significant byte (bits 8-13) of the pitch bend value.

• The center position (no pitch change) is represented by LSB = 0x0, MSB = 0x40

			St	atu	s by	/te						LS	SB							MS	SB			
Bit	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0
Value	1	1	1	0	n	n	n	n	0	1	Ι	ı	ı	ı	ı	ı	0	m	m	m	m	m	m	m

#### **Running status**

There are a lot of circumstances where you have to send many messages of the same type. For example, if you have a digital keyboard, pretty much all messages will be note on and note off events, or when you turn a knob on a MIDI controller, a lot of control change messages will be sent to update the controller value. To save bandwidth in these kinds of situations, you only have to send the status byte once, followed by only data bytes. This technique is called "running status".

Because note on events are most likely to be followed by note off events (or more note on events), the MIDI standard allows you to use a note on event with a velocity of zero instead of a note off event. This means that you only need one status byte for all note events, drastically reducing the data throughput, thus minimizing the delay between events.

#### **System Messages**

System messages are MIDI messages that do not carry data for a specific MIDI channel. There are three types of system messages:

#### **System Common Messages**

System Common messages are intended for all receivers in the system.

These messages are beyond the scope of this guide. If you want more information, refer to page 27 of the MIDI 1.0 Detailed Specification 4.2.

- MIDI Time Code Quarter Frame (0xF1)
- Song Position Pointer (0xF2)
- Song Select (0xF3)
- Tune Request (0xF6)
- EOX (End of Exclusive) (0xF7)

#### **System Real Time Messages**

System Real Time messages are used for synchronization between clock-based MIDI components. These messages are beyond the scope of this guide. If you want more information, refer to page 30 of the MIDI 1.0 Detailed Specification 4.2.

- Timing Clock (0xF8)
- Start (0xFA)
- Continue (0xFB)
- Stop (0xFC)
- Active Sensing (0xFE)

• System Reset (0xFF)

#### **System Exclusive Messages**

System Exclusive (SysEx) messages are used for things like setting synthesizer or patch settings, sending sampler data, memory dumps, etc.

Most SysEx messages are manufacturer-specific, so it is best to consult the MIDI implementation in the manual. If you want more information on the topic, you can find it on page 34 of the MIDI 1.0 Detailed Specification 4.2.

A system exclusive message starts with a status byte 0xF0, followed by an arbitrary number of data bytes, and ends with another status byte 0xF7.

			Sy	sEx	sta	art						Da	ata						Sy	/sE	x er	nd		
Bit	7	6	5	4	3	2	1	0	7	6	5	4	3	2	1	0	 7	6	5	4	3	2	1	0
Value	1	1	1	1	0	0	0	0	0	d	d	d	d	d	d	d	 1	1	1	1	0	1	1	1

## **Appendices**

All numbers are in hexadecimal representation, unless otherwise specified.

#### **MIDI** note names

Middle C or C4 is defined as MIDI note 0x3C.

The lowest note on a standard 88-key piano is A0 (0x15) and the highest note is C8 (0x6c).

						No	ote					
Octave	С	C#	D	D#	Е	F	F#	G	G#	Α	A#	В
-1	00	01	02	03	04	05	06	07	08	09	0A	ОВ
0	0C	0D	0E	0F	10	11	12	13	14	15	16	17
1	18	19	1A	1B	1C	1D	1E	1F	20	21	22	23
2	24	25	26	27	28	29	2A	2B	2C	2D	2E	2F
3	30	31	32	33	34	35	36	37	38	39	3A	3B
4	3C	3D	3E	3F	40	41	42	43	44	45	46	47
5	48	49	4A	4B	4C	4D	4E	4F	50	51	52	53
6	54	55	56	57	58	59	5A	5B	5C	5D	5E	5F
7	60	61	62	63	64	65	66	67	68	69	6A	6B
8	6C	6D	6E	6F	70	71	72	73	74	75	76	77
9	78	79	7A	7B	7C	7D	7E	7F				

#### **Controller numbers**

This is an overview of the MIDI controller numbers that can be used as the first data byte of a control change event.

The second data byte is the value for the controller. This value is 7 bits wide, so has a range of [0, 127]. Controller numbers 0x00-0x1F can be combined with numbers 0x20-0x3F for 14-bit resolution. In this case, numbers 0x00-0x1F set the MSB, and numbers 0x20-0x3F the LSB.

Controller numbers 120-127 are reserved for Channel Mode Messages, which rather than controlling sound parameters, affect the channel's operating mode.

Cont	roller	Function	Value	Used
Dec	Hex	Function	value	as
0	00	Bank Select	00-7F	MSB
1	01	Modulation Wheel or Lever	00-7F	MSB
2	02	Breath Controller	00-7F	MSB
3	03	Undefined	00-7F	MSB
4	04	Foot Controller	00-7F	MSB
5	05	Portamento Time	00-7F	MSB
6	06	Data Entry MSB	00-7F	MSB
7	07	Channel Volume (formerly Main Volume)	00-7F	MSB
8	08	Balance	00-7F	MSB
9	09	Undefined	00-7F	MSB

10	0A	Pan	00-7F	MSB
11	0B	Expression Controller	00-7F	MSB
12	0C	Effect Control 1	00-7F	MSB
13	0D	Effect Control 2	00-7F	MSB
14	0E	Undefined	00-7F	MSB
15	0F	Undefined	00-7F	MSB
16	10	General Purpose Controller 1	00-7F	MSB
17	11	General Purpose Controller 2	00-7F	MSB
18	12	General Purpose Controller 3	00-7F	MSB
19	13	General Purpose Controller 4	00-7F	MSB
20	14	Undefined	00-7F	MSB
21	15	Undefined	00-7F	MSB
22	16	Undefined	00-7F	MSB
23	17	Undefined	00-7F	MSB
24	18	Undefined	00-7F	MSB
25	19	Undefined	00-7F	MSB
26	19 1A	Undefined	00-7F 00-7F	MSB
27	1B	Undefined	00-7F	MSB
28	1C	Undefined	00-7F	MSB
29	1D	Undefined	00-7F	MSB
30	1E	Undefined	00-7F	MSB
31	1F	Undefined	00-7F	MSB
32	20	LSB for Control 0 (Bank Select)	00-7F	LSB
33	21	LSB for Control 1 (Modulation Wheel or Lever)	00-7F	LSB
34	22	LSB for Control 2 (Breath Controller)	00-7F	LSB
35	23	LSB for Control 3 (Undefined)	00-7F	LSB
36	24	LSB for Control 4 (Foot Controller)	00-7F	LSB
37	25	LSB for Control 5 (Portamento Time)	00-7F	LSB
38	26	LSB for Control 6 (Data Entry)	00-7F	LSB
39	27	LSB for Control 7 (Channel Volume, formerly Main Volume)	00-7F	LSB
40	28	LSB for Control 8 (Balance)	00-7F	LSB
41	29	LSB for Control 9 (Undefined)	00-7F	LSB
42	2A	LSB for Control 10 (Pan)	00-7F	LSB
43	2B	LSB for Control 11 (Expression Controller)	00-7F	LSB
44	2C	LSB for Control 12 (Effect control 1)	00-7F	LSB
45	2D	LSB for Control 13 (Effect control 2)	00-7F	LSB
46	2E	LSB for Control 14 (Undefined)	00-7F	LSB
47	2F	LSB for Control 15 (Undefined)	00-7F	LSB
48	30	LSB for Control 16 (General Purpose Controller 1)	00-7F	LSB
49	31	LSB for Control 17 (General Purpose Controller 2)	00-7F	LSB
50	32	LSB for Control 18 (General Purpose Controller 3)	00-7F	LSB
51	33	LSB for Control 19 (General Purpose Controller 4)	00-7F	LSB
52	34	LSB for Control 20 (Undefined)	00-7F	LSB
53	35	LSB for Control 21 (Undefined)	00-7F	LSB
54	36	LSB for Control 22 (Undefined)	00-7F	LSB
55	37	LSB for Control 23 (Undefined)	00-7F	LSB
56	38	LSB for Control 24 (Undefined)	00-7F	LSB
57	39	LSB for Control 25 (Undefined)	00-7F 00-7F	LSB
			00-7F 00-7F	
58	3A	LSB for Control 26 (Undefined)		LSB
59	3B	LSB for Control 27 (Undefined)	00-7F	LSB
60	3C	LSB for Control 28 (Undefined)	00-7F	LSB
61	3D	LSB for Control 29 (Undefined)	00-7F	LSB
62	3E	LSB for Control 30 (Undefined)	00-7F	LSB
63	3F	LSB for Control 31 (Undefined)	00-7F	LSB

64	40	Damper Pedal on/off (Sustain)	≤3F off, ≥40 on	
65	41	Portamento On/Off	≤3F off, ≥40 on	
66	42	Sostenuto On/Off	≤3F off, ≥40 on	
67	43	Soft Pedal On/Off	≤3F off, ≥40 on	
68	44	Legato Footswitch	≤3F Normal, ≥40 Legato	
69	45	Hold 2	≤3F off, ≥40 on	
70	46	Sound Controller 1 (default: Sound Variation)	00-7F	LSB
71	47	Sound Controller 2 (default: Timbre/Harmonic Intens.)	00-7F	LSB
72	48	Sound Controller 3 (default: Release Time)	00-7F	LSB
73	49	Sound Controller 4 (default: Attack Time)	00-7F	LSB
74	4A	Sound Controller 5 (default: Brightness)	00-7F	LSB
75	4B	Sound Controller 6 (default: Decay Time - see MMA RP-021)	00-7F	LSB
76	4C	Sound Controller 7 (default: Vibrato Rate - see MMA RP-021)	00-7F	LSB
77	4D	Sound Controller 8 (default: Vibrato Depth - see MMA RP-021)	00-7F	LSB
78	4E	Sound Controller 9 (default: Vibrato Delay - see MMA RP-021)	00-7F	LSB
79	4F	Sound Controller 10 (default undefined - see MMA RP-021)	00-7F	LSB
80	50	General Purpose Controller 5	00-7F	LSB
81	51	General Purpose Controller 6	00-7F	LSB
82	52	General Purpose Controller 7	00-7F	LSB
83	53	General Purpose Controller 8	00-7F	LSB
84	54	Portamento Control	00-7F	LSB
85	55	Undefined		
86	56	Undefined		
87	57	Undefined		
88	58	High Resolution Velocity Prefix	00-7F	LSB
89	59	Undefined		
90	5A	Undefined		
91	5B	Effects 1 Depth (default: Reverb Send Level - see MMA RP-023) (formerly ExternalEffects Depth)	00-7F	
92	5C	Effects 2 Depth (formerly Tremolo Depth)	00-7F	
93	5D	Effects 3 Depth (default: Chorus Send Level - see MMA RP-023) (formerly Chorus Depth)	00-7F	
94	5E	Effects 4 Depth (formerly Celeste [Detune] Depth)	00-7F	
95	5F	Effects 5 Depth (formerly Phaser Depth)	00-7F	
96	60	Data Increment (Data Entry +1) (see MMA RP-018)	N/A	
97	61	Data Decrement (Data Entry -1) (see MMA RP-018)	N/A	
98	62	Non-Registered Parameter Number (NRPN) - LSB	00-7F	LSB
99	63	Non-Registered Parameter Number (NRPN) - MSB	00-7F	MSB
100	64	Registered Parameter Number (RPN) - LSB*	00-7F	LSB
101	65	Registered Parameter Number (RPN) - MSB*	00-7F	MSB
102	66	Undefined		
103	67	Undefined		
104	68	Undefined		
105	69	Undefined		
106	6A	Undefined		
107	6B	Undefined		
	6C	Undefined		
108		Undefined		
108 109	6D			1
	6D 6E	Undefined		
109				
109 110 111	6E 6F	Undefined		
109 110 111 112	6E 6F 70	Undefined Undefined		
109 110 111 112 113	6E 6F 70 71	Undefined Undefined Undefined		
109 110 111 112	6E 6F 70	Undefined Undefined		

117	75	Undefined	 
118	76	Undefined	 
119	77	Undefined	 

Channel mode		Function	Value
Dec	Hex		
120	78	All Sound Off	00
121	79	Reset All Controllers	00
122	7A	Local Control On/Off	00 off, 7F on
123	7B	All Notes Off	00
124	7C	Omni Mode Off (+ all notes off)	00
125	7D	Omni Mode On (+ all notes off)	00
126	7E	Mono Mode On (+ poly off, + all notes off)	Note: This equals the number of channels, or zero if the number of channels equals the number of voices in the receiver.
127	7F	Poly Mode On (+ mono off, + all notes off)	0

### **Source**

## **Program numbers**

The MIDI specification doesn't specify instruments or voices for program numbers. The General MIDI 1 sound set does define a list of sounds and families of sounds.

Program	Family Name
1-8	Piano
9-16	Chromatic Percussion
17-24	Organ
25-32	Guitar
33-40	Bass
41-48	Strings
49-56	Ensemble
57-64	Brass
65-72	Reed
73-80	Pipe
81-88	Synth Lead
89-96	Synth Pad
97-104	Synth Effects
105-112	Ethnic
113-120	Percussive
121-128	Sound Effects

Program	Instrument Name
1	Acoustic Grand Piano
2	Bright Acoustic Piano
3	Electric Grand Piano
4	Honky-tonk Piano
5	Electric Piano 1
6	Electric Piano 2
7	Harpsichord
8	Clavi
9	Celesta
10	Glockenspiel
11	Music Box
12	Vibraphone
13	Marimba
14	Xylophone

16 Dulcimer 17 Drawbar Organ 18 Percussive Organ 19 Rock Organ 20 Church Organ 21 Reed Organ 22 Accordion 23 Harmonica 24 Tango Accordion 25 Acoustic Guitar (nylon 26 Acoustic Guitar (jazz) 27 Electric Guitar (clean) 29 Electric Guitar (muted 30 Overdriven Guitar 31 Distortion Guitar 32 Guitar harmonics 33 Acoustic Bass 34 Electric Bass (finger) 35 Electric Bass (pick) 36 Fretless Bass 37 Slap Bass 1 38 Slap Bass 2 39 Synth Bass 1 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax 66 Alto Sax	15	Tubular Bells
18 Percussive Organ 19 Rock Organ 20 Church Organ 21 Reed Organ 22 Accordion 23 Harmonica 24 Tango Accordion 25 Acoustic Guitar (nylon 26 Acoustic Guitar (steel) 27 Electric Guitar (clean) 29 Electric Guitar (muted 30 Overdriven Guitar 31 Distortion Guitar 32 Guitar harmonics 33 Acoustic Bass 34 Electric Bass (finger) 35 Electric Bass (pick) 36 Fretless Bass 37 Slap Bass 1 38 Slap Bass 2 39 Synth Bass 1 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	16	Dulcimer
18 Percussive Organ 19 Rock Organ 20 Church Organ 21 Reed Organ 22 Accordion 23 Harmonica 24 Tango Accordion 25 Acoustic Guitar (nylon 26 Acoustic Guitar (steel) 27 Electric Guitar (clean) 29 Electric Guitar (muted 30 Overdriven Guitar 31 Distortion Guitar 32 Guitar harmonics 33 Acoustic Bass 34 Electric Bass (finger) 35 Electric Bass (pick) 36 Fretless Bass 37 Slap Bass 1 38 Slap Bass 2 39 Synth Bass 1 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	17	Drawbar Organ
19 Rock Organ 20 Church Organ 21 Reed Organ 22 Accordion 23 Harmonica 24 Tango Accordion 25 Acoustic Guitar (nylon 26 Acoustic Guitar (steel) 27 Electric Guitar (clean) 29 Electric Guitar (muted 30 Overdriven Guitar 31 Distortion Guitar 32 Guitar harmonics 33 Acoustic Bass 34 Electric Bass (finger) 35 Electric Bass (pick) 36 Fretless Bass 37 Slap Bass 1 38 Slap Bass 2 39 Synth Bass 1 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	18	
20 Church Organ 21 Reed Organ 22 Accordion 23 Harmonica 24 Tango Accordion 25 Acoustic Guitar (nylon 26 Acoustic Guitar (jazz) 28 Electric Guitar (clean) 29 Electric Guitar (muted 30 Overdriven Guitar 31 Distortion Guitar 32 Guitar harmonics 33 Acoustic Bass 34 Electric Bass (finger) 35 Electric Bass (pick) 36 Fretless Bass 37 Slap Bass 1 38 Slap Bass 2 39 Synth Bass 1 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	19	
21 Reed Organ 22 Accordion 23 Harmonica 24 Tango Accordion 25 Acoustic Guitar (nylon 26 Acoustic Guitar (jazz) 28 Electric Guitar (clean) 29 Electric Guitar (muted 30 Overdriven Guitar 31 Distortion Guitar 32 Guitar harmonics 33 Acoustic Bass 34 Electric Bass (finger) 35 Electric Bass (pick) 36 Fretless Bass 37 Slap Bass 1 38 Slap Bass 2 39 Synth Bass 1 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax		
Accordion  Accordion  Accordion  Accordion  Accoustic Guitar (nylon  Accoustic Guitar (steel)  Electric Guitar (clean)  Electric Guitar (muted  Coverdriven Guitar  Electric Bass  Electric Bass (finger)  Electric Bass (pick)  Fretless Bass  Slap Bass 1  Slap Bass 1  Slap Bass 1  Synth Bass 2  Violin  Cello  Contrabass  Fremolo Strings  Firemolo Strings	-	
Harmonica  Harmonica  Harmonica  Acoustic Guitar (nylon  Acoustic Guitar (steel)  Electric Guitar (clean)  Electric Guitar (muted  Overdriven Guitar  Electric Bass (finger)  Electric Bass (finger)  Electric Bass (pick)  Fretless Bass  Felectric Bass (pick)  Fretless Bass  Filap Bass 1  Synth Bass 2  Synth Bass 2  Violin  Cello  Contrabass  Fremolo Strings  Firemolo Strings  Firmpani  Firmpani  String Ensemble 1  SynthStrings 1  SynthStrings 1  SynthStrings 2  Synth Voice  Choir Aahs  Corchestra Hit  Trumpet  Trumpet  Trumpet  Trumpet  Trumpet  Trumpet  Trumpet  French Horn  Muted Trumpet  French Horn  Electric Bass (pick)  Fretless Bass  Acoustic Bass  Fretless Bass  Fretless Bass  Fretless Bass  Choir Aahs  Cello  Muted Trumpet  French Horn  Electric Bass (pick)  Fretless Bass  Choir Aahs  French Horn  French Horn  French Horn  SynthBrass 1  SynthBrass 2		3
Tango Accordion  Tango Accordion  Acoustic Guitar (nylon  Acoustic Guitar (steel)  Electric Guitar (clean)  Electric Guitar (muted  Overdriven Guitar  I Distortion Guitar  Guitar harmonics  Acoustic Bass  Electric Bass (finger)  Electric Bass (pick)  Fretless Bass  Slap Bass 1  Slap Bass 2  Synth Bass 1  Violin  Cello  Contrabass  Tremolo Strings  Fizzicato Strings  Cello  Contrabass  Timpani  String Ensemble 1  SynthStrings 1  SynthStrings 1  SynthStrings 2  Synth Voice  Orchestra Hit  Trumpet  Trumpet  Trumpet  Trumpet  Trumpet  Trumpet  Trumpet  Trumpet  Trumpet  Brass Section  Muted Trumpet  French Horn  Electric Bass (pick)  Tremolo Strings  Tremolo Strings  Tremolo Strings  Timpani  Timpani  Cello  Contrabass  Tremolo Strings  Timpani		
Acoustic Guitar (nylon Acoustic Guitar (steel) Electric Guitar (jazz) Electric Guitar (clean) Electric Guitar (clean) Guitar Guitar Distortion Guitar  Guitar harmonics Acoustic Bass Electric Bass (finger) Electric Bass (finger) Electric Bass (pick) Fretless Bass Fretless Bass Slap Bass 1 Slap Bass 2 Synth Bass 1 Cello Contrabass Firemolo Strings Fizzicato Strings Fizzicato Strings Fizzicato Strings Fizzicato Strings Fixing Ensemble 1 SynthStrings 1 SynthStrings 2 SynthStrings 2 Synth Voice Cochestra Hit Trumpet Firemolo Muted Trumpet Firench Horn Express Soprano Sax Soprano Sax		
26 Acoustic Guitar (steel) 27 Electric Guitar (jazz) 28 Electric Guitar (clean) 29 Electric Guitar (muted) 30 Overdriven Guitar 31 Distortion Guitar 32 Guitar harmonics 33 Acoustic Bass 34 Electric Bass (finger) 35 Electric Bass (pick) 36 Fretless Bass 37 Slap Bass 1 38 Slap Bass 2 39 Synth Bass 1 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2		_
Electric Guitar (jazz) Electric Guitar (clean) Electric Guitar (clean) Distortion Guitar  Distortion Guitar  Guitar harmonics  Acoustic Bass Electric Bass (finger) Electric Bass (pick) Electric Bass		-
Electric Guitar (clean) Electric Guitar (muted) Coverdriven Guitar Electric Guitar (muted) Cuitar harmonics Electric Bass Electric Bass (finger) Electric Bass (finger) Electric Bass (pick) Electric		
29 Electric Guitar (muted 30 Overdriven Guitar 31 Distortion Guitar 32 Guitar harmonics 33 Acoustic Bass 34 Electric Bass (finger) 35 Electric Bass (pick) 36 Fretless Bass 37 Slap Bass 1 38 Slap Bass 2 39 Synth Bass 1 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 55 Soprano Sax		
30 Overdriven Guitar 31 Distortion Guitar 32 Guitar harmonics 33 Acoustic Bass 34 Electric Bass (finger) 35 Electric Bass (pick) 36 Fretless Bass 37 Slap Bass 1 38 Slap Bass 2 39 Synth Bass 1 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	28	
31 Distortion Guitar 32 Guitar harmonics 33 Acoustic Bass 34 Electric Bass (finger) 35 Electric Bass (pick) 36 Fretless Bass 37 Slap Bass 1 38 Slap Bass 2 39 Synth Bass 2 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	29	Electric Guitar (muted)
Guitar harmonics  Guitar harmonics  Guitar harmonics  Acoustic Bass  Electric Bass (finger)  Electric Bass (pick)  Electric Bass (pick)  Fretless Bass  Slap Bass 1  Slap Bass 2  Synth Bass 1  Synth Bass 2  Violin  Cello  Contrabass  Fremolo Strings  Fremolo Strings  Cello  Contrabass  Fremolo Strings  Corchestral Harp  String Ensemble 1  Suring Ensemble 2  SynthStrings 1  SynthStrings 2  SynthStrings 2  Synth Voice  Choir Aahs  Voice Oohs  Synth Voice  Corchestra Hit  Trumpet  Trumpet  Trumpet  Rombone  Tuba  Muted Trumpet  French Horn  Muted Trumpet  French Horn  Electric Bass (finger)  Suph Bass 1  Acoustic Bass (pick)  French Horn  Electric Bass (finger)  Suph Bass 1  Acoustic Bass (pick)  French Horn  Electric Bass (finger)  French Horn  Electric Bass (pick)  French Horn  El	30	Overdriven Guitar
33 Acoustic Bass 34 Electric Bass (finger) 35 Electric Bass (pick) 36 Fretless Bass 37 Slap Bass 1 38 Slap Bass 2 39 Synth Bass 1 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2	31	Distortion Guitar
34 Electric Bass (finger) 35 Electric Bass (pick) 36 Fretless Bass 37 Slap Bass 1 38 Slap Bass 2 39 Synth Bass 1 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	32	Guitar harmonics
35 Electric Bass (pick) 36 Fretless Bass 37 Slap Bass 1 38 Slap Bass 2 39 Synth Bass 1 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	33	Acoustic Bass
36 Fretless Bass 37 Slap Bass 1 38 Slap Bass 2 39 Synth Bass 1 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	34	Electric Bass (finger)
37 Slap Bass 1 38 Slap Bass 2 39 Synth Bass 1 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	35	Electric Bass (pick)
38 Slap Bass 2 39 Synth Bass 1 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	36	Fretless Bass
39 Synth Bass 1 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	37	Slap Bass 1
39 Synth Bass 1 40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	38	Slap Bass 2
40 Synth Bass 2 41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	39	
41 Violin 42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax		-
42 Viola 43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	-	•
43 Cello 44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax		- 1 - 1 - 1
44 Contrabass 45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax		
45 Tremolo Strings 46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax		
46 Pizzicato Strings 47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax		
47 Orchestral Harp 48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax		
48 Timpani 49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	-	5
49 String Ensemble 1 50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax		
50 String Ensemble 2 51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	48	Timpani
51 SynthStrings 1 52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	49	String Ensemble 1
52 SynthStrings 2 53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	50	String Ensemble 2
53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	51	SynthStrings 1
53 Choir Aahs 54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	52	SynthStrings 2
54 Voice Oohs 55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax	53	
55 Synth Voice 56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax		Voice Oohs
56 Orchestra Hit 57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax		
57 Trumpet 58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax		-
58 Trombone 59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax		
59 Tuba 60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax		
60 Muted Trumpet 61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax		
61 French Horn 62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax		
62 Brass Section 63 SynthBrass 1 64 SynthBrass 2 65 Soprano Sax		·
<ul><li>SynthBrass 1</li><li>SynthBrass 2</li><li>Soprano Sax</li></ul>		
64 SynthBrass 2 65 Soprano Sax	-	
65 Soprano Sax		-
	-	-
66 Alto Sax	65	Soprano Sax
	66	Alto Sax
67 Tenor Sax	67	Tenor Sax
68 Baritone Sax	68	Baritone Sax
		I

69	Oboe
70	English Horn
71	Bassoon
72	Clarinet
73	Piccolo
74	Flute
75	Recorder
76	Pan Flute
77	Blown Bottle
	Shakuhachi
78	
79	Whistle
80	Ocarina
81	Lead 1 (square)
82	Lead 2 (sawtooth)
83	Lead 3 (calliope)
84	Lead 4 (chiff)
85	Lead 5 (charang)
86	Lead 6 (voice)
87	Lead 7 (fifths)
88	Lead 8 (bass + lead)
89	Pad 1 (new age)
90	Pad 2 (warm)
91	Pad 3 (polysynth)
92	Pad 4 (choir)
93	Pad 5 (bowed)
94	Pad 6 (metallic)
95	Pad 7 (halo)
96	Pad 8 (sweep)
97	FX 1 (rain)
98	FX 2 (soundtrack)
99	FX 3 (crystal)
100	FX 4 (atmosphere)
101	FX 5 (brightness)
102	FX 6 (goblins)
103	FX 7 (echoes)
104	FX 8 (sci-fi)
105	Sitar
106	Banjo
107	Shamisen
108	Koto
109	Kalimba
110	Bag pipe
111	Fiddle
112	Shanai
113	Tinkle Bell
114	Agogo
115	Steel Drums
116	Woodblock
117	Taiko Drum
118	Melodic Tom
119	Synth Drum
120	Reverse Cymbal
121	Guitar Fret Noise
122	Breath Noise

124	Bird Tweet
125	Telephone Ring
126	Helicopter
127	Applause
128	Gunshot

## <u>Source</u>

## **MIDI** hardware

## **Sending MIDI over Serial**

The easiest way to send out MIDI packets is to use the Serial.write(uint8\_t data); function. This function writes out one 8-bit byte over the Serial connection (either hardware UARTO or the virtual COM port over USB).

To send out a MIDI packet, we just have to write out the three bytes that make up the packet: first the status byte, then the two data bytes.

```
void sendMIDI(uint8_t statusByte, uint8_t dataByte1, uint8_t dataByte2) {
   Serial.write(statusByte);
   Serial.write(dataByte1);
   Serial.write(dataByte2);
}
```

In order to support MIDI packets with only one data byte as well, we can just overload the sendMIDI function. This means that we create two functions with the same name, but with different parameters.

```
void sendMIDI(uint8_t statusByte, uint8_t dataByte) {
   Serial.write(statusByte);
   Serial.write(dataByte);
}
```

In its current form, the sendMIDI function is quite silly. Although it sends out MIDI packets, it doesn't automatically create these packets for us, we still have to put together the status and data bytes ourselves, and we have to make sure that it is a valid MIDI packet before calling sendMIDI. Let's create a more useful function that takes a message type, channel number and data as inputs, creates a MIDI packet, and sends it over the Serial port.

We now have a working function that sends MIDI packets, and takes a somewhat sensible input, not just the bytes of the packet. But there's still no guarantee that it is a valid MIDI message. Remember that the status byte should have a most significant bit equal to 1, and the data bytes a most significant bit equal to 0. We'll use some bitwise math to make sure that this is always the case, no matter what data the user enters.

```
void sendMIDI(uint8 t messageType, uint8 t channel, uint8 t data1, uint8 t data2) {
                                               // Decrement the channel, because MIDI channel 1 \,
  channel - - ;
                                               // corresponds to binary channel 0
 uint8 t statusByte = messageType | channel; // Combine the messageType (high nibble)
                                               // with the channel (low nibble)
                                               // Both the message type and the channel
                                               // should be 4 bits wide
  statusByte |= 0b10000000;
                                               // Set the most significant bit of the status byte
 data1 &= 0b01111111;
                                              // Clear the most significant bit of the data bytes
 data2
            &= 0b01111111;
 Serial.write(statusByte);
                                              // Send over Serial
  Serial.write(data1);
  Serial.write(data2);
}
```

```
void sendMIDI(uint8 t messageType, uint8 t channel, uint8 t data) {
                                               // Decrement the channel, because MIDI channel 1
  channel - - ;
                                               // corresponds to binary channel 0
  uint8 t statusByte = messageType | channel; // Combine the messageType (high nibble)
                                               // with the channel (low nibble)
                                               // Both the message type and the channel
                                               // should be 4 bits wide
                                              // Set the most significant bit of the status byte
  statusByte |= 0b10000000;
           &= 0b01111111;
                                               // Clear the most significant bit of the data byte
 Serial.write(statusByte);
                                               // Send over Serial
  Serial.write(data);
}
```

Before sending the packet, we set the most significant bit of the status byte by performing a bitwise OR operation:

```
0bxss sss
0b1000 0000
------|
0b1ss ssss
```

Where 0bsss ssss is the status, and x is either 1 or 0. As you can see, no matter the value of x, the result will always be 0blsss ssss.

We also clear the most significant bits of the data bytes by performing a bitwise AND operation:

```
0b×ddd dddd
0b0111 1111
----- &
0b0ddd dddd
```

Where 0bddd dddd is the data, and x is either 1 or 0. No matter what the value of x is, the result will always be 0b0ddd dddd

You could go even further by making sure that the message type and the channel don't interfere with each other. However, that might be overly defensive.

```
// corresponds to binary channel 0
 messageType \&= 0b11110000;
                                           // Make sure that only the high nibble
                                           // of the message type is set
                                          // Make sure that only the low nibble
// of the channel is set
 channel
            &= 0b00001111;
 uint8_t statusByte = messageType | channel; // Combine the messageType (high nibble)
                                           // with the channel (low nibble)
                                          // Both the message type and the channel
                                          // should be 4 bits wide
  statusByte |= 0b10000000;
                                           // Set the most significant bit of the status byte
         &= 0b01111111;
                                          // Clear the most significant bit of the data bytes
 data1
 data2
            \&= 0b01111111;
 Serial.write(statusByte);
                                          // Send over Serial
 Serial.write(data1);
  Serial.write(data2);
}
```

## Improving readibility

To send a Control Change (0xB0) message on channel 3 for controller 80 with a value of 64, you would call sendMIDI(0xB0, 3, 80, 64);

To make it a little more obvious what's going on, we could declare some constants for the different message types:

```
const uint8_t NOTE_OFF = 0x80;
const uint8_t NOTE_ON = 0x90;
const uint8_t KEY_PRESSURE = 0xA0;
const uint8_t CC = 0xB0;
const uint8_t PROGRAM_CHANGE = 0xC0;
const uint8_t CHANNEL_PRESSURE = 0xD0;
const uint8_t PITCH_BEND = 0xE0;
```

You can now use sendMIDI(CC, 3, 80, 64); which will make the code much easier to read. When writing code, it's always a good idea to keep so-called *magic numbers* to a minimum. These are seemingly arbitrary numeric literals in your code that don't have a clear meaning. For example, this code snippet plays a chromatic glissando (all keys, one after the other) on an honkytonk piano:

```
sendMIDI(0xC0, 1, 4);
for (uint8 t i = 21; i <= 108; i++) {
    sendMIDI(0x90, 1, i, 64);
    delay(100);
    sendMIDI(0x80, 1, i, 64);
}</pre>
```

To someone who has never seen the code, or someone who doesn't know all MIDI message type codes by heart, it's not clear what all these numbers mean. A much better sketch would be:

```
const uint8_t honkyTonkPiano = 4; // GM defines the Honky-tonk Piano as instrument #4

const uint8_t note_A1 = 21; // lowest note on an 88-key piano
const uint8_t note_C9 = 108; // highest note on an 88-key piano
```

This snippet does exactly the same thing as the previous example, but it's much easier to read and understand.

## **Using structs**

Another approach would be to compose the MIDI message in a buffer, and then just write out that buffer. We can define a struct with the different fields of a MIDI event. Take a look at this struct:

```
typedef struct MIDI message 3B {
  unsigned int channel : 4; // second nibble : MIDI channel (0-15)
unsigned int status : 3; // first nibble : status message
  unsigned int _msb0 : 1;
                               // most significant bit of status byte : should be 1 according to MIDI
specification
  unsigned int data1 : 7;
                               // second byte
                                                 : first value
  unsigned int _msb1 : 1;
                               // most significant bit of first data byte : should be 0 according to MIDI
specification
  unsigned int data2 : 7;
                               // third byte : second value
  unsigned int msb2 : 1;
                                // most significant bit of second data byte : should be 0 according to
MIDI specification
  MIDI message 3B(): msb0(1), msb1(0), msb2(0) {} // set the correct msb's for MIDI
```

You might have noticed that the bit fields are in the wrong order: for example, the normal order of the status byte would be 1.mmm.cccc with mmm the message type and cccc the channel. However, the order in our struct is cccc.mmm.1. To understand what's going on, you have to know that Arduinos are Little Endian. This means that the first bit field takes up the least significant bits in each byte. In other words, the bit fields within each byte are in reversed order, compared to the conventional Big Endian notation (that is used in the MIDI specification).

You can now fill up all fields of the struct, to create a valid MIDI packet. You don't have to worry about the most significant bits of each byte, bitmasking is done automatically, because of the bit fields. These bits are set to the correct value when a message is created, in the initializer list of the constructor. The only thing you need to keep in mind is that the channels are zero-based. Also note that the message types are no longer 0x80, 0x90 etc., but 0x8, 0x9 ...

```
const uint8_t NOTE_ON = 0x9;

MIDI_message_3B msg; // Create a variable called 'msg' of the 'MIDI_message_3B' type we just defined msg.status = NOTE_ON;
msg.channel = channel - 1; // MIDI channels start from 0, so subtract 1
msg.data1 = note_A1;
msg.data2 = velocity;
```

Finally, you can just write out the message over the Serial port. We'll create another overload of the sendMIDI function:

```
void sendMIDI(MIDI_message_3B msg) {
   Serial.write((uint8_t *)&msg, 3);
}
```

We're using the write(uint8\_t\* buffer, size\_t numberOfBytes) function. The first argument is a pointer to a buffer (or array) of data bytes to write out. The pointer points to the first element of this array. The second argument is the number of bytes to send, starting from that first element. There's one minor problem: msg is not an array, it's an object of type MIDI\_message\_3B. The write function expects a pointer to an array of bytes (uint8\_t). To get around this, we can just take the address of msg, using the address-of operator (&) and cast it to a pointer to an array of uint8\_t's using (uint8\_t\*). We need to write out the entire MIDI packet, which is 3 bytes long, so the second argument is just 3. To use the function, just use:

```
sendMIDI(msg);
```

In fact, we could do even better. Now every time the sendMIDI function is called, the msg object is copied. This takes time and memory. To prevent it from being copied, we can pass only a reference to msg to the function. Here's what that looks like:

```
void sendMIDI(MIDI_message_3B &msg) {
    Serial.write((uint8_t *)&msg, 3);
}
sendMIDI(msg);
```

You can do the same thing for two-byte MIDI packets:

## **Running status**

As discussed in <u>chapter 1</u>, you can use running statusses to save bandwidth. The implementation is relatively easy: remember the last status byte (header) that was sent, and then compare every following status byte to this header. If it's the same status, send the data bytes only, otherwise, send the new status byte, and remember this header.

To remember the previous header, a static variable is used. Static variables are not destroyed when they go out of scope, so the value is retained the next time the sendMIDI function is executed.

```
void sendMIDI(uint8_t messageType, uint8_t channel, uint8_t data1, uint8_t data2) {
  channel - -;
                                                 // Decrement the channel, because MIDI channel 1
                                                 // corresponds to binary channel 0
  uint8_t statusByte = messageType | channel; // Combine the messageType (high nibble)
                                                 // with the channel (low nibble)
                                                 // Both the message type and the channel
                                                // should be 4 bits wide
  statusByte |= 0b10000000;
                                                 // Set the most significant bit of the status byte
  data1 &= 0b01111111;
                                                // Clear the most significant bit of the data bytes
  data2
           &= 0b01111111;
  static uint8 t runningHeader;
  if (statusByte != runningHeader) {
                                                // If the new header is different from the previous
// Send the status byte over Serial
    Serial.write(statusByte);
    runningHeader = statusByte;
                                                // Remember the new header
  Serial.write(data1);
                                                // Send the data bytes over Serial
  Serial.write(data2);
}
```

```
void sendMIDI(uint8_t messageType, uint8_t channel, uint8_t data) {
  channel - - ;
                                                // Decrement the channel, because MIDI channel 1
                                                // corresponds to binary channel 0
 uint8_t statusByte = messageType | channel; // Combine the messageType (high nibble)
                                                // with the channel (low nibble)
                                                // Both the message type and the channel
                                                // should be 4 bits wide
 statusByte |= 0b10000000;
                                                // Set the most significant bit of the status byte
            &= 0b01111111;
 data
                                                // Clear the most significant bit of the data byte
 static uint8 t runningHeader;
                                               // If the new header is different from the previous
// Send over Serial
 if (statusByte != runningHeader) {
   Serial.write(statusByte);
                                                // Remember the new header
    runningHeader = statusByte;
  Serial.write(data);
                                                // Send the data byte over Serial
}
```

Going even further, we can replace note off events by note on events with a velocity of zero:

```
void sendMIDI(uint8 t messageType, uint8 t channel, uint8 t data1, uint8 t data2) {
 messageType = NOTE ON;
                                             // with a note on message
   data2 = 0;
                                             // with a velocity of zero.
 channel - - :
                                             // Decrement the channel, because MIDI channel 1
                                             // corresponds to binary channel 0
 uint8 t statusByte = messageType | channel;
                                            // Combine the messageType (high nibble)
                                             // with the channel (low nibble)
                                             // Both the message type and the channel
                                             // should be 4 bits wide
 statusByte |= 0b10000000;
                                             // Set the most significant bit of the status byte
 data1 &= 0b01111111;
data2 &= 0b01111111;
                                             // Clear the most significant bit of the data bytes
 data2
 static uint8 t runningHeader;
 if (statusByte != runningHeader) {
                                         // If the new header is different from the previous
                                            // Send the status byte over Serial
// Remember the new header
   Serial.write(statusByte);
   runningHeader = statusByte;
 Serial.write(data1);
                                             // Send the data bytes over Serial
 Serial.write(data2);
```

To ensure that the receiver will know what to do with the data, even if it missed the first header byte, is to send a new header byte regularly. This can be done by remembering the time the last header was sent:

```
if (messageType == NOTE_OFF) {
   messageType = NOTE_ON;
                                             // with a note on message
   data2 = 0;
                                             // with a velocity of zero.
                                             // Decrement the channel, because MIDI channel 1 // corresponds to binary channel \boldsymbol{\theta}
  channel - - ;
  uint8_t statusByte = messageType | channel;
                                            // Combine the messageType (high nibble)
                                              // with the channel (low nibble)
                                             // Both the message type and the channel
                                             // should be 4 bits wide
  statusByte |= 0b10000000;
                                              // Set the most significant bit of the status byte
  data1 &= 0b01111111;
                                             // Clear the most significant bit of the data bytes
           &= 0b01111111;
  data2
  static unsigned long lastHeaderTime = millis();
  static uint8_t runningHeader;
  if (statusByte != runningHeader
                                             // If the new header is different from the previous
    || (millis() - lastHeaderTime) > 1000) { // Or if the last header was sent more than 1 s ago
    Serial.write(statusByte);
                                             // Send the status byte over Serial
                                             // Remember the new header
    runningHeader = statusByte;
    lastHeaderTime = millis();
  Serial.write(data1);
                                             // Send the data bytes over Serial
  Serial.write(data2);
}
```