# TireGround

Generated by Doxygen 1.8.13

# Contents

1	Tire	Groun	d		1
2	Nan	nespace	e Index		5
	2.1	Name	space Lis	t	5
3	Hier	rarchica	al Index		7
	3.1	Class	Hierarchy	y	7
4	Clas	s Inde	x		9
	4.1	Class	List		9
5	Nan	nespace	e Docume	entation	11
	5.1	TireG	round Na	mespace Reference	11
		5.1.1		Description	13
	5.2	TireG	round::alg	gorithms Namespace Reference	13
		5.2.1	Detailed	l Description	13
		5.2.2	Function	n Documentation	13
			5.2.2.1	intersectPointSegment()	13
			5.2.2.2	intersectRayPlane()	14
			5.2.2.3	minmax_XY() [1/2]	14
			5.2.2.4	minmax_XY() [2/2]	14
			5.2.2.5	trapezoidArea()	15
			5.2.2.6	weightedMean() [1/2]	15
			5.2.2.7	weightedMean() [2/2]	15
	5.3	TireG	round::RI	OF Namespace Reference	15
		5.3.1	Detailed	d Description	16
	5.4	TireG	round::RI	DF::algorithms Namespace Reference	16
		5.4.1	Detailed	d Description	16
		5.4.2	Function	n Documentation	16
			5.4.2.1	firstToken()	16
			5.4.2.2	getElement()	17
			5.4.2.3	split()	17
			E 4 2 4	to:1/)	17

ii CONTENTS

5	Clas	es Doct	imentation	19
,	6.1		round::RDF::BBox2D Class Reference	19
	0.1	6.1.1	Detailed Description	20
		6.1.2	Constructor & Destructor Documentation	20
		0.1.2	6.1.2.1 BBox2D()	20
		6.1.3	Member Function Documentation	20
		0.1.0	6.1.3.1 print()	20
			6.1.3.2 updateBBox2D()	20
	6.2	TireG	round::Disk Class Reference	20
	0.2	6.2.1	Detailed Description	21
		6.2.2	Constructor & Destructor Documentation	21
		0.2.2	6.2.2.1 Disk()	22
		6.2.3	Member Function Documentation	22
		0.2.5	6.2.3.1 contactPlane()	22
			6.2.3.2 contactTriangles()	22
			6.2.3.3 getLineArea()	23
			6.2.3.4 intersectPlane()	23
			6.2.3.5 intersectSegment()	23
			<u> </u>	23
			V	24
			· ·	
			6.2.3.8 segmentLength()	24
			6.2.3.9 set()	24
			6.2.3.10 setOriginXZ()	25
	<i>c</i> 2	TT: - C	6.2.3.11 y()	25
	6.3		round::ETRTO Class Reference	25
		6.3.1	Detailed Description	26
		6.3.2	Constructor & Destructor Documentation	26
			6.3.2.1 ETRTO()	26
		6.3.3	Member Function Documentation	26
		<b></b>	6.3.3.1 print()	26
	6.4		round::MagicFormula Class Reference	26
		6.4.1	Detailed Description	29
		6.4.2	Constructor & Destructor Documentation	29
			6.4.2.1 MagicFormula()	29
		6.4.3	Member Function Documentation	30
			6.4.3.1 evaluateContact()	30
			6.4.3.2 fourPointsSampling()	30
			6.4.3.3 getArea() [1/2]	30
			6.4.3.4 getArea() [2/2]	31
			6.4.3.5 getEulerAngleX()	31
			6.4.3.6 getEulerAngleY()	31
			6.4.3.7 getEulerAngleZ()	31

CONTENTS

		6.4.3.8	getFriction() [1/2]	31
		6.4.3.9	getFriction() [2/2]	31
		6.4.3.10	getMFpoint() [1/2]	32
		6.4.3.11	getMFpoint() [2/2]	32
		6.4.3.12	getMFpointRF() [1/2]	32
		6.4.3.13	getMFpointRF() [2/2]	32
		6.4.3.14	getNormal() [1/2]	33
		6.4.3.15	getNormal() [2/2]	33
		6.4.3.16	getRelativeCamber()	33
		6.4.3.17	getRho() [1/2]	33
		6.4.3.18	getRho() [2/2]	34
		6.4.3.19	getRhoDot() [1/2]	34
		6.4.3.20	getRhoDot() [2/2]	34
		6.4.3.21	getVolume() [1/2]	35
		6.4.3.22	getVolume() [2/2]	35
		6.4.3.23	pointSampling()	35
		6.4.3.24	print()	36
		6.4.3.25	printETRTOGeometry()	36
		6.4.3.26	setOrigin()	36
		6.4.3.27	setReferenceFrame()	36
		6.4.3.28	setRotationMatrix()	36
		6.4.3.29	setTotalTransformationMatrix()	37
		6.4.3.30	setup()	37
6.5	TireG	round::RI	DF::MeshSurface Class Reference	37
	6.5.1	Detailed	Description	38
	6.5.2	Constru	ctor & Destructor Documentation	38
		6.5.2.1	MeshSurface() [1/2]	38
		6.5.2.2	MeshSurface() [2/2]	38
	6.5.3	Member	Function Documentation	39
		6.5.3.1	intersectAABBtree()	39
		6.5.3.2	intersectBBox()	39
		6.5.3.3	LoadFile()	39
		6.5.3.4	printData()	39
		6.5.3.5	set()	40
6.6	TireG	round::M	ultiDisk Class Reference	40
	6.6.1	Detailed	Description	43
	6.6.2	Constru	ctor & Destructor Documentation	43
		6.6.2.1	MultiDisk() [1/3]	43
		6.6.2.2	MultiDisk() [2/3]	43
		6.6.2.3	MultiDisk() [3/3]	44
	6.6.3	Member	Function Documentation	44
		6.6.3.1	getArea() [1/2]	44

iv

	6.6.3.2	getArea() [2/2]	45
	6.6.3.3	getDiskFriction()	45
	6.6.3.4	getDiskMFpoint()	45
	6.6.3.5	getDiskMFpointRF()	45
	6.6.3.6	getDiskNormal()	46
	6.6.3.7	getDiskOriginXYZ() [1/2]	46
	6.6.3.8	getDiskOriginXYZ() [2/2]	46
	6.6.3.9	getDiskRho()	46
	6.6.3.10	getDiskRhoDot()	47
	6.6.3.11	getEulerAngleX()	47
	6.6.3.12	getEulerAngleY()	47
	6.6.3.13	getEulerAngleZ()	47
	6.6.3.14	getFriction() [1/2]	48
	6.6.3.15	getFriction() [2/2]	49
	6.6.3.16	getMFpoint() [1/2]	49
	6.6.3.17	getMFpoint() [2/2]	49
	6.6.3.18	getMFpointRF() [1/2]	49
	6.6.3.19	getMFpointRF() [2/2]	50
	6.6.3.20	getNormal() [1/2]	50
	6.6.3.21	getNormal() [2/2]	50
	6.6.3.22	getRelativeCamber()	50
	6.6.3.23	getRho() [1/2]	51
	6.6.3.24	getRho() [2/2]	51
	6.6.3.25	getRhoDot() [1/2]	51
	6.6.3.26	getRhoDot() [2/2]	52
	6.6.3.27	getVolume() [1/2]	52
	6.6.3.28	getVolume() [2/2]	52
	6.6.3.29	pointSampling()	52
	6.6.3.30	print()	53
	6.6.3.31	printETRTOGeometry()	53
	6.6.3.32	setDiskOriginXZ() [1/2]	53
	6.6.3.33	setDiskOriginXZ() [2/2]	54
	6.6.3.34	setOrigin()	54
	6.6.3.35	setReferenceFrame()	54
	6.6.3.36	setRotationMatrix()	54
	6.6.3.37	setTotalTransformationMatrix()	55
	6.6.3.38	setup()	55
TireGr	ound::Re	ferenceFrame Class Reference	55
6.7.1	Detailed	Description	56
6.7.2	Construc	ctor & Destructor Documentation	56
	6.7.2.1	ReferenceFrame()	56
6.7.3	Member	Function Documentation	56
	6.7.1 6.7.2	6.6.3.3 6.6.3.4 6.6.3.5 6.6.3.6 6.6.3.7 6.6.3.8 6.6.3.9 6.6.3.10 6.6.3.11 6.6.3.12 6.6.3.13 6.6.3.14 6.6.3.15 6.6.3.16 6.6.3.17 6.6.3.18 6.6.3.19 6.6.3.20 6.6.3.21 6.6.3.21 6.6.3.22 6.6.3.23 6.6.3.24 6.6.3.25 6.6.3.25 6.6.3.26 6.6.3.27 6.6.3.28 6.6.3.29 6.6.3.30 6.6.3.31 6.6.3.32 6.6.3.31 6.6.3.32 6.6.3.33 6.6.3.34 6.6.3.35 6.6.3.35 6.6.3.36 6.6.3.37 6.6.3.38  TireGround::Re 6.7.2 Construction of the control	6.6.3.3 getDiskFriction() 6.6.3.4 getDiskMFpoint() 6.6.3.5 getDiskMFpoint() 6.6.3.5 getDiskNormal() 6.6.3.7 getDiskNormal() 6.6.3.8 getDiskNormal() 6.6.3.9 getDiskNormal() 6.6.3.10 getDiskNormal() 6.6.3.11 getEulerAngleX() 6.6.3.12 getEulerAngleX() 6.6.3.13 getEulerAngleY() 6.6.3.13 getEulerAngleZ() 6.6.3.14 getFriction() [1/2] 6.6.3.15 getMFpoint() [1/2] 6.6.3.16 getMFpoint() [1/2] 6.6.3.17 getMFpoint() [1/2] 6.6.3.18 getWFpointRF() [1/2] 6.6.3.19 getMFpointRF() [1/2] 6.6.3.20 getNormal() [1/2] 6.6.3.21 getWFpointRF() [2/2] 6.6.3.22 getRelativeCamber() 6.6.3.23 getRhoD() [1/2] 6.6.3.24 getRhoD() [1/2] 6.6.3.25 getRhoD() [1/2] 6.6.3.26 getRhoDot() [1/2] 6.6.3.27 getVolume() [1/2] 6.6.3.28 getVolume() [1/2] 6.6.3.29 pointSampling() 6.6.3.30 print() 6.6.3.31 printETRTOGeometry() 6.6.3.32 setDiskOriginXZ() [1/2] 6.6.3.33 setDiskOriginXZ() [1/2] 6.6.3.34 setOrigin() 6.6.3.35 setReferenceFrame() 6.6.3.37 setTotalTransformationMatrix() 6.6.3.37 setTotalTransformationMatrix() 6.6.3.38 setup() TireGround::ReferenceFrame() 6.7.1 Detailed Description 6.7.2.1 ReferenceFrame()

CONTENTS

		6.7.3.1	getEulerAngleX()
		6.7.3.2	getEulerAngleY()
		6.7.3.3	getEulerAngleZ()
		6.7.3.4	set()
		6.7.3.5	setOrigin()
		6.7.3.6	setRotationMatrix()
		6.7.3.7	setTotalTransformationMatrix()
6.8	TireGr	ound::Sar	mplingGrid Class Reference
	6.8.1	Detailed	Description
	6.8.2	Construc	ctor & Destructor Documentation
		6.8.2.1	SamplingGrid() [1/2]
		6.8.2.2	SamplingGrid() [2/2]
	6.8.3	Member	Function Documentation
		6.8.3.1	set() [1/2]
		6.8.3.2	set() [2/2]
		6.8.3.3	setSwitchNumber()
6.9	TireGr	ound::Sha	adow Class Reference
	6.9.1	Detailed	Description
	6.9.2	Construc	ctor & Destructor Documentation
		6.9.2.1	Shadow()
	6.9.3	Member	Function Documentation
		6.9.3.1	update()
6.10	TicToc	Class Ref	ference
6.11	TireGr	ound::Tir	e Class Reference
	6.11.1	Detailed	Description
	6.11.2	Construc	ctor & Destructor Documentation
		6.11.2.1	Tire()
	6.11.3	Member	Function Documentation
		6.11.3.1	evaluateContact()
		6.11.3.2	getArea() [1/2]
		6.11.3.3	getArea() [2/2]
		6.11.3.4	getEulerAngleX()
		6.11.3.5	getEulerAngleY()
		6.11.3.6	getEulerAngleZ()
		6.11.3.7	getFriction() [1/2]
		6.11.3.8	getFriction() [2/2]
		6.11.3.9	getMFpoint() [1/2]
		6.11.3.10	getMFpoint() [2/2]
		6.11.3.11	getMFpointRF() [1/2]
		6.11.3.12	getMFpointRF() [2/2]
		6.11.3.13	getNormal() [1/2]
		6.11.3.14	getNormal() [2/2] 68

vi CONTENTS

	6.11.3.15 getRelativeCamber()	68
	6.11.3.16 getRho() [1/2]	69
	6.11.3.17 getRho() [2/2]	69
	6.11.3.18 getRhoDot() [1/2]	69
	6.11.3.19 getRhoDot() [2/2]	70
	6.11.3.20 getVolume() [1/2]	70
	6.11.3.21 getVolume() [2/2]	70
	6.11.3.22 pointSampling()	70
	6.11.3.23 print()	71
	6.11.3.24 printETRTOGeometry()	71
	6.11.3.25 setOrigin()	71
	6.11.3.26 setReferenceFrame()	72
	6.11.3.27 setRotationMatrix()	72
	6.11.3.28 setTotalTransformationMatrix()	72
	6.11.3.29 setup()	72
6.12 TireG	round::RDF::Triangle3D Class Reference	73
6.12.1	Detailed Description	74
6.12.2	Constructor & Destructor Documentation	74
	6.12.2.1 Triangle3D()	74
6.12.3	Member Function Documentation	74
	6.12.3.1 intersectEdgePlane()	75
	6.12.3.2 intersectPlane()	75
	6.12.3.3 intersectRay()	75
	6.12.3.4 print()	76
	6.12.3.5 setVertices() [1/2]	76
	6.12.3.6 setVertices() [2/2]	76
6.13 TireG	round::RDF::TriangleRoad Class Reference	76
6.13.1	Detailed Description	78
6.13.2	Constructor & Destructor Documentation	78
	6.13.2.1 TriangleRoad()	78
6.13.3	Member Function Documentation	78
	6.13.3.1 intersectEdgePlane()	78
	6.13.3.2 intersectPlane()	79
	6.13.3.3 intersectRay()	79
	6.13.3.4 print()	79
	6.13.3.5 setFriction()	80
	6.13.3.6 setVertices() [1/2]	80
	6.13.3.7 setVertices() [2/2]	80
Index		81

# Chapter 1

# **TireGround**

A repository for the code developed by Davide Stocco for his thesis.

Department of Industrial Engineering

Master Degree in Mechatronics Engineering

EN: Real-Time Computation of Tire/Road Contact using Tailored Algorithms IT: Valutazione Real-Time del Contatto Pneumatico/Strada con Algoritmi Dedicati

Academic Year 2019 · 2020

Author: Davide Stocco

Supervisor & Co-supervisor: Prof. Enrico Bertolazzi & Dr.Eng. Matteo Ragni

# MagicFormula tire model usage

1. Load .rdf file.

```
TireGround::RDF::MeshSurface Road(
  "./file.rdf" // Path to the *.rdf file
);
```

2. Initialize the MagicFormula tire model.

```
TireGround::Tire* TireSD = new TireGround::MagicFormula(
   SectionWidth, // [mm]
   AspectRatio, // [%]
   RimDiameter, // [in]
   SwitchNumber // Maximum RoadTriangles in the Tire Shadow (switch to sampling)
);
```

3. Contact evaluation.

```
bool Out = TireSD->setup( Road, // Road mesh TransfMat // 4x4 total transformation matrix );
```

4. Data extraction.

```
// Variable initialization (for real numbers)
TireGround::vec3 N;
TireGround::vec3 P;
TireGround::real_type Friction;
TireGround::real_type Rho;
TireGround::real_type RhoDot;
TireGround::real_type RelativeCamber;
TireGround::real_type Area;
TireGround::real_type Volume;
// Data extraction (for real numbers)
TireSD->getNormal(N);
```

2 TireGround

```
TireSD->getMFpoint(P);
TireSD->getFriction(Friction);
TireSD->getRho(Rho);
TireSD->getRhoDot(PreviousRho,TimeStep,RhoDot);
TireSD->getRelativeCamber (RelativeCamber);
TireSD->getArea(Area);
TireSD->getVolume(Volume);
// Extract data stucture size
TireGround::int_type size = TireSD->getDisksNumber();
// Variable initialization (for vectors)
TireGround::row vec3 NVec(size);
TireGround::row_vec3 PVec(size);
TireGround::row_vecN FrictionVec(size);
TireGround::row_vecN RhoVec(size);
TireGround::row_vecN RhoDotVec(size);
TireGround::row_vecN RelativeCamberVec(size);
TireGround::row_vecN AreaVec(size);
TireGround::row_vecN VolumeVec(size);
// Data extraction (for vectors)
TireSD->getNormal(NVec);
TireSD->getMFpoint(PVec);
TireSD->getFriction(FrictionVec);
TireSD->getRho(RhoVec);
TireSD->getRhoDot(PreviousRho, TimeStep, RhoDotVec);
TireSD->getRelativeCamber(RelativeCamberVec);
TireSD->getArea(AreaVec);
TireSD->getVolume(VolumeVec);
```

# MultiDisk tire model usage

1. Load .rdf file.

```
TireGround::RDF::MeshSurface Road(
   "./file.rdf" // Path to the *.rdf file
);
```

- 2. Initialize the MultiDisk tire model:
  - (a) MultiDisk tire without sidewall radius (uniform cylinder).

```
TireGround::Tire* TireMD = new TireGround::MultiDisk(
   SectionWidth, // [mm]
   AspectRatio, // [%]
   RimDiameter, // [in]
   PointsNumber, // Sampling points for each disk
   DisksNumber, // Disks number
   SwitchNumber // Maximum RoadTriangles in the Tire Shadow (switch to sampling)
);
```

(b) MultiDisk tire with sidewall radius (uniform cylinder with filleted sidewall edge).

```
TireGround::Tire* TireMD = new TireGround::MultiDisk(
   SectionWidth, // [mm]
   AspectRatio, // [%]
   RimDiameter, // [in]
   SideRadius, // Sidewall radius [mm]
   PointsNumber, // Sampling points for each disk
   DisksNumber, // Disks number
   SwitchNumber // Maximum RoadTriangles in the Tire Shadow (switch to sampling)
);
```

(c) MultiDisk tire with custom disks radius.

```
TireGround::Tire* TireMD = new TireGround::MultiDisk(
   SectionWidth, // [mm]
   AspectRatio, // [%]
   RimDiameter, // [in]
   RadiusVec, // Disks radius vector [m]
   PointsNumber, // Sampling points for each disk
   SwitchNumber // Maximum RoadTriangles in the Tire Shadow (switch to sampling)
);
```

3. Contact evaluation.

#### 4. Data extraction for contact point(s).

```
// Variable initialization (for real numbers)
TireGround::vec3 N;
TireGround::vec3 P;
TireGround::real_type Friction;
TireGround::real_type Rho;
TireGround::real_type RhoDot;
TireGround::real_type RelativeCamber;
TireGround::real_type Area;
TireGround::real_type Volume;
// Data extraction (for real numbers)
TireMD->getNormal(N);
TireMD->getMFpoint(P);
TireMD->getFriction(Friction);
TireMD->getRho(Rho);
TireMD->getRhoDot(PreviousRho, TimeStep, RhoDot);
TireMD->getRelativeCamber(RelativeCamber);
TireMD->getArea(Area);
TireMD->getVolume(Volume);
// Extract data stucture size
TireGround::int_type size = TireSD->getDisksNumber();
// Variable initialization (for vectors)
TireGround::row_vec3 NVec(size);
TireGround::row_vec3 PVec(size);
TireGround::row_vecN FrictionVec(size);
TireGround::row_vecN RhoVec(size);
TireGround::row_vecN RhoDotVec(size);
TireGround::row_vecN RelativeCamberVec(size);
TireGround::row_vecN AreaVec(size);
TireGround::row_vecN VolumeVec(size);
// Data extraction (for vectors)
TireMD->getNormal(NVec);
TireMD->getMFpoint(PVec);
TireMD->getFriction(FrictionVec);
TireMD->getRho(RhoVec);
TireMD->getRhoDot(PreviousRho,TimeStep,RhoDotVec);
TireMD->getRelativeCamber(RelativeCamberVec);
TireMD->getArea(AreaVec);
TireMD->getVolume(VolumeVec);
```

4 TireGround

# Chapter 2

# Namespace Index

2.1	Namespace 1	List
<b>-</b> • •	1 valification acc	

Here is a list of all documented namespaces with brief descriptions:

TireGround	
Tire computations routines	11
TireGround::algorithms	
Algorithms for tire computations routine	13
TireGround::RDF	
RDF mesh computations routines	15
TireGround::RDF::algorithms	
Algorithms for RDF mesh computations routine	16

6 Namespace Index

# Chapter 3

# Hierarchical Index

# 3.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:	
TireGround::RDF::BBox2D	19
TireGround::Disk	20
TireGround::ETRTO	25
TireGround::RDF::MeshSurface	37
TireGround::ReferenceFrame	55
TireGround::SamplingGrid	58
TireGround::Shadow	61
TicToc	62
TireGround::Tire	62
TireGround::MagicFormula	26
e	40
TireGround::RDF::Triangle3D	73
TireGround::RDF::TriangleRoad	

8 Hierarchical Index

# Chapter 4

# Class Index

# 4.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:	
TireGround::RDF::BBox2D	
2D Bounding Box class	19
TireGround::Disk	
Tire disk	20
TireGround::ETRTO	
Tire ETRTO denomination	25
TireGround::MagicFormula	
Pacejka MagicFormula contact model	26
TireGround::RDF::MeshSurface	
Mesh surface	37
TireGround::MultiDisk	
Multi-disk tire contact model	40
TireGround::ReferenceFrame	
Reference frame	55
TireGround::SamplingGrid	
Patch evaluation precision	58
TireGround::Shadow	
2D shadow (2D bounding box enhacement)	
TicToc	62
TireGround::Tire	
Base class for Tire models	62
TireGround::RDF::Triangle3D	
3D triangle (pure geometrical description)	73
TireGround::RDF::TriangleRoad	
3D triangles for road representation	76

10 Class Index

# Chapter 5

# Namespace Documentation

# 5.1 TireGround Namespace Reference

Tire computations routines.

# Namespaces

• algorithms

Algorithms for tire computations routine.

• RDF

RDF mesh computations routines.

### Classes

• class Disk

Tire disk.

• class ETRTO

Tire ETRTO denomination.

• class MagicFormula

Pacejka MagicFormula contact model.

• class MultiDisk

Multi-disk tire contact model.

• class ReferenceFrame

Reference frame.

• class SamplingGrid

Patch evaluation precision.

• class Shadow

2D shadow (2D bounding box enhacement)

• class Tire

Base class for Tire models.

# **Typedefs**

- typedef double real\_type

  Real number type.
- typedef int int\_type *Integer number type.*
- typedef Eigen::Vector2i vec2\_int

  2D vector type of real integer type
- typedef Eigen::Vector2d vec2
   2D vector type of real number type
- typedef Eigen::Vector3d vec3

  3D vector type of real number type
- typedef Eigen::Vector4d vec4

  4D vector type of real number type
- typedef Eigen::Matrix3d mat3

  3x3 matrix type of real number type
- typedef Eigen::Matrix4d mat4

  4x4 matrix type of real number type
- typedef Eigen::Matrix < real\_type, 1, Eigen::Dynamic > row\_vecN
   Row vector type real number type.
- typedef Eigen::Matrix< real\_type, Eigen::Dynamic, 1 > col\_vecN Column vector type real number type.
- typedef Eigen::Matrix < real\_type, Eigen::Dynamic, Eigen::Dynamic > matN
   Matrix type of real number type.
- typedef Eigen::Matrix < vec2, 1, Eigen::Dynamic > row\_vec2

  \*Row vector type of 2D vector.
- typedef Eigen::Matrix< vec2, Eigen::Dynamic, 1 > col\_vec2

  Column vector type of 2D vector.
- typedef Eigen::Matrix < vec2, Eigen::Dynamic, Eigen::Dynamic > mat\_vec2

  Matrix type of 2D vector.
- typedef Eigen::Matrix < vec3, 1, Eigen::Dynamic > row\_vec3

  \*Row vector type of 3D vector.\*
- typedef Eigen::Matrix < vec3, Eigen::Dynamic, 1 > col\_vec3

  \*Column vector type of 3D vector.
- typedef Eigen::Matrix < vec3, Eigen::Dynamic, Eigen::Dynamic > matN\_vec3
   Matrix type of 3D vector.
- typedef Eigen::Matrix < mat4, 1, Eigen::Dynamic > row\_mat4
   Matrix type of 4x4 matrix.
- typedef std::basic\_ostream< char > ostream\_type
   Output stream type.

#### Variables

real\_type const epsilon = std::numeric\_limits<real\_type>::epsilon()
 Epsilon type.

## 5.1.1 Detailed Description

Tire computations routines.

Typedefs for tire computations routine.

file: PatchTire.hh file: TireGround.hh

# 5.2 TireGround::algorithms Namespace Reference

Algorithms for tire computations routine.

#### **Functions**

- real\_type weightedMean (row\_vecN const &Values, row\_vecN const &Weights)

  Calculate arithmetic weighted mean for real numbers.
- vec3 weightedMean (row\_vec3 const &Values, row\_vecN const &Weights)

Calculate arithmetic weighted mean for 3D vectors.

- bool intersectPointSegment (vec2 const &Point1, vec2 const &Point2, vec2 const &PointQ)
- bool intersectRayPlane (vec3 const &planeN, vec3 const &planeP, vec3 const &RayPoint, vec3 const &RayDirection, vec3 &IntersectionPt)

Check if a segment hits a plane and find the intersection point.

- void minmax\_XY (row\_vec3 const &Points, vec2 &XYmin, vec2 &XYmax)
  - Calculate minumum and maximum in XY plane for 3D vectors.
- void minmax\_XY (row\_vec2 const &Points, vec2 &XYmin, vec2 &XYmax)

Calculate minumum and maximum in XY plane for 2D vectors.

• real\_type trapezoidArea (real\_type const Base2, real\_type const Base1, real\_type const Height)

Calculate area of a trapeziod [  $m^2$ ].

# 5.2.1 Detailed Description

Algorithms for tire computations routine.

#### 5.2.2 Function Documentation

#### 5.2.2.1 intersectPointSegment()

```
bool TireGround::algorithms::intersectPointSegment (
    vec2 const & Point1,
    vec2 const & Point2,
    vec2 const & PointQ )
```

Check if a point lays inside or outside a line segment

Warning: The point query point must be on the same rect of the line segment!

#### Parameters

Point1	Line segment point 1
Point2	Line segment point 2
PointQ	Query point

### 5.2.2.2 intersectRayPlane()

```
bool TireGround::algorithms::intersectRayPlane (
    vec3 const & planeN,
    vec3 const & planeP,
    vec3 const & RayPoint,
    vec3 const & RayDirection,
    vec3 & IntersectionPt )
```

Check if a segment hits a plane and find the intersection point.

#### Parameters

planeN	Plane normal vector
planeP	Plane known point
RayPoint	Ray point
RayDirection	Ray direction
IntersectionPt	Intersection point

#### 5.2.2.3 minmax\_XY() [1/2]

```
void TireGround::algorithms::minmax_XY (
    row_vec3 const & Points,
    vec2 & XYmin,
    vec2 & XYmax )
```

Calculate minumum and maximum in XY plane for 3D vectors.

## Parameters

Points	3D points vector
XYmin	Minimum ( $X, Y$ ) values
XYmax	Maximum ( $X, Y$ ) values

## 5.2.2.4 minmax\_XY() [2/2]

```
void TireGround::algorithms::minmax_XY (
    row_vec2 const & Points,
    vec2 & XYmin,
    vec2 & XYmax )
```

Calculate minumum and maximum in XY plane for 2D vectors.

#### **Parameters**

Points	2D points vector
XYmin	Minimum ( $X, Y$ ) values
XYmax	Maximum $(X, Y)$ values

### 5.2.2.5 trapezoidArea()

```
real_type TireGround::algorithms::trapezoidArea (
    real_type const Base2,
    real_type const Base1,
    real_type const Height ) [inline]
```

Calculate area of a trapeziod [ $m^2$ ].

#### **Parameters**

Base2	Base 1
Base1	Base 2
Height	Heigth

### 5.2.2.6 weightedMean() [1/2]

```
real_type TireGround::algorithms::weightedMean (
    row_vecN const & Values,
    row_vecN const & Weights )
```

Calculate arithmetic weighted mean for real numbers.

#### **Parameters**

Values	Values (real numbers)
Weights	Weights (real numbers)

#### 5.2.2.7 weightedMean() [2/2]

```
vec3 TireGround::algorithms::weightedMean (
    row_vec3 const & Values,
    row_vecN const & Weights)
```

Calculate arithmetic weighted mean for 3D vectors.

# Parameters

Values	Values (3D vectors)
Weights	Weights (real numbers)

# 5.3 TireGround::RDF Namespace Reference

RDF mesh computations routines.

# Namespaces

• algorithms

Algorithms for RDF mesh computations routine.

#### Classes

• class BBox2D

2D Bounding Box class

• class MeshSurface

Mesh surface.

• class Triangle3D

3D triangle (pure geometrical description)

• class TriangleRoad

3D triangles for road representation

# **Typedefs**

- typedef std::shared\_ptr < TriangleRoad > TriangleRoad\_ptr
   Shared pointer to TriangleRoad object.
- typedef std::vector < TriangleRoad\_ptr > TriangleRoad\_list
   Vector of shared pointers to TriangleRoad objects.

# 5.3.1 Detailed Description

RDF mesh computations routines.

# 5.4 TireGround::RDF::algorithms Namespace Reference

Algorithms for RDF mesh computations routine.

### **Functions**

- void split (std::string const &in, std::vector< std::string > &out, std::string const &token) Split a string into a string array at a given token.
- std::string tail (std::string const &in)

Get tail of string after first token and possibly following spaces.

• std::string firstToken (std::string const &in)

Get first token of string.

• template<typename T >

T const & getElement (std::vector< T > const & elements, std::string const & index)

Get element at given index position.

## 5.4.1 Detailed Description

Algorithms for RDF mesh computations routine.

#### 5.4.2 Function Documentation

#### 5.4.2.1 firstToken()

#### Get first token of string.

#### Parameters

```
in Input string
```

# 5.4.2.2 getElement()

```
template<typename T >
T const& TireGround::RDF::algorithms::getElement (
    std::vector< T > const & elements,
    std::string const & index )
```

Get element at given index position.

#### **Parameters**

elements	Elements vector
index	Index position

# 5.4.2.3 split()

```
void TireGround::RDF::algorithms::split (
    std::string const & in,
    std::vector< std::string > & out,
    std::string const & token )
```

Split a string into a string array at a given token.

#### **Parameters**


in	Input string
out	Output string vector
token	Token

### 5.4.2.4 tail()

```
std::string TireGround::RDF::algorithms::tail (
    std::string const & in )
```

Get tail of string after first token and possibly following spaces.

#### Parameters



# Chapter 6

# Class Documentation

# 6.1 TireGround::RDF::BBox2D Class Reference

## 2D Bounding Box class

#include <RoadRDF.hh>

#### **Public Member Functions**

• BBox2D ()

Default constructor.

• BBox2D (vec3 const Vertices[3])

Variable set constructor.

• void setXmin (real\_type const \_Xmin)

Set  $X_{min}$  shadow domain.

• void setYmin (real\_type const \_Ymin)

Set  $Y_{min}$  shadow domain.

void setXmax (real\_type const \_Xmax)

Set  $X_{max}$  shadow domain.

void setYmax (real\_type const \_Ymax)

Set  $Y_{max}$  shadow domain.

real\_type getXmin (void) const

Get  $X_{min}$  shadow domain.

real\_type getYmin (void) const

Get  $Y_{min}$  shadow domain.

• real\_type getXmax (void) const

Get  $X_{max}$  shadow domain.

real\_type getYmax (void) const

Get  $Y_{max}$  shadow domain.

• void clear (void)

Clear the bounding box domain.

• void print (ostream\_type &stream) const

Print bounding box domain.

• void updateBBox2D (vec3 const Vertices[3])

Update the bounding box domain with three input vertices.

20 Class Documentation

# 6.1.1 Detailed Description

2D Bounding Box class

#### 6.1.2 Constructor & Destructor Documentation

#### 6.1.2.1 BBox2D()

```
TireGround::RDF::BBox2D::BBox2D (
    vec3 const Vertices[3] ) [inline]
```

Variable set constructor.

Parameters

```
Vertices | Vertices reference vector
```

### 6.1.3 Member Function Documentation

# 6.1.3.1 print()

Print bounding box domain.

**Parameters** 

```
stream Output stream type
```

## 6.1.3.2 updateBBox2D()

```
void TireGround::RDF::BBox2D::updateBBox2D (
    vec3 const Vertices[3] )
```

Update the bounding box domain with three input vertices.

Parameters

```
Vertices Vertices reference vector
```

The documentation for this class was generated from the following file:

• include/RoadRDF.hh

# 6.2 TireGround::Disk Class Reference

#### Tire disk.

```
#include <PatchTire.hh>
```

#### **Public Member Functions**

• Disk (Disk &&)=default

Enable && operator.

• Disk ()

Default constructor.

• Disk (vec2 const &\_OriginXZ, real\_type \_OffsetY, real\_type \_Radius)

Variable set constructor.

• void set (Disk const &in)

Copy the Disk object.

void setOriginXZ (vec2 const &\_OriginXZ)

Set origin on XZ plane.

vec2 const & getOriginXZ (void) const

Get origin vector XZ-axes coordinates.

vec3 getOriginXYZ (void) const

Get origin vector XYZ-axes coordinates.

real\_type getOffsetY (void) const

Get origin Y-axis coordinate.

• real\_type getRadius (void) const

Get Disk radius.

- void contactTriangles (RDF::TriangleRoad\_list const &TriList, ReferenceFrame const &RF, vec3 &Normal, real\_type &Friction, real\_type &Area) const
- void contactPlane (vec3 const &Normal, vec3 const &Point, ReferenceFrame const &RF, real\_type &Area) const
- void pointOnDisk (vec3 const &Normal, ReferenceFrame const &RF, vec3 &DiskPoint, vec3 &NormalOnDisk) const

Get the points on Disk the circumference and on a given plane.

- real\_type segmentArea (real\_type const Length) const
- bool isPointInside (vec2 const &Point) const

Check if a point in Disk reference frame is inside or outside the Disk.

• real\_type y (real\_type const x) const

Evaluate Y at a query X value on the lower side Disk circumfererence.

• real\_type segmentLength (vec2 const Point1, vec2 const Point2) const

Evaluate a generic segment length given 2 points on the Disk circumfererence.

- int\_type intersectSegment (vec2 const &Point1, vec2 const &Point2, vec2 &Intersect1, vec2 &Intersect2) const
- bool intersectPlane (vec3 const &Plane\_Normal, vec3 const &Plane\_Point, vec3 &Line\_← Direction, vec3 &Line\_Point) const
- real\_type getLineArea (vec2 const &Point1\_XZ, vec2 const &Point2\_XZ) const Get a two points line segment area [ m²] (as ouput) inside the Disk.

## 6.2.1 Detailed Description

Tire disk.

#### 6.2.2 Constructor & Destructor Documentation

22 Class Documentation

#### 6.2.2.1 Disk()

```
TireGround::Disk::Disk (
    vec2 const & _OriginXZ,
    real_type _OffsetY,
    real_type _Radius ) [inline]
```

Variable set constructor.

#### **Parameters**

_OriginXZ	$(X_0,Z_0)$ origin coordinate
_OffsetY	$Y_0$ origin coordinate (offset from center)
_Radius	Radius

### 6.2.3 Member Function Documentation

### 6.2.3.1 contactPlane()

```
void TireGround::Disk::contactPlane (
    vec3 const & Normal,
    vec3 const & Point,
    ReferenceFrame const & RF,
    real_type & Area ) const
```

Get the contact area [ $m^2$ ] inside the single Disk given a plane in absolute reference frame

## Parameters

Normal	Plane normal in absolute reference frame
Point	Plane point in absolute reference frame
RF	Tire ReferenceFrame
Area	Contact area [ $m^2$ ]

# 6.2.3.2 contactTriangles()

```
void TireGround::Disk::contactTriangles (
   RDF::TriangleRoad_list const & TriList,
   ReferenceFrame const & RF,
   vec3 & Normal,
   real_type & Friction,
   real_type & Area ) const
```

Get area weighted mean road normal versor, area weighted mean friction and contact area [  $m^2$ ] inside the single Disk of segments described by the intersection of triangles on XZ-plane

#### **Parameters**

TriList	Shadow / MeshSurface intersected triangles
RF	Tire ReferenceFrame
Normal	Area weighted mean road normal versor

#### Parameters

Friction	Area weighted mean contact friction
Area	Contact area [ $m^2$ ]

### 6.2.3.3 getLineArea()

```
real_type TireGround::Disk::getLineArea (
    vec2 const & Point1_XZ,
    vec2 const & Point2_XZ ) const
```

Get a two points line segment area [ $m^2$ ] (as ouput) inside the Disk.

#### Parameters

Point1_XZ	Point 1 in Disk reference frame
Point2_XZ	Point 2 in Disk reference frame

### 6.2.3.4 intersectPlane()

```
bool TireGround::Disk::intersectPlane (
    vec3 const & Plane_Normal,
    vec3 const & Plane_Point,
    vec3 & Line_Direction,
    vec3 & Line_Point ) const
```

Check if two plane intersects and find the intersecting rect given two points in Disk reference frame

#### Parameters

Plane_Normal	Plane normal vector in Disk reference frame	
Plane_Point	Plane known point in Disk reference frame	
Line_Direction	Direction   Rect direction vector in Disk reference frame	
Line_Point	Plane known point in Disk reference frame	

# 6.2.3.5 intersectSegment()

```
int_type TireGround::Disk::intersectSegment (
    vec2 const & Point1,
    vec2 const & Point2,
    vec2 & Intersect1,
    vec2 & Intersect2 ) const
```

Find the intersection points between the Disk and a two points line segment in Disk reference frame (output integer gives number of intersection points)

#### Parameters

Point1	Line segment point 1 in Disk reference frame

24 Class Documentation

#### Parameters

Point2	Line segment point 2 in Disk reference frame	
Intersect1	Intersection point 1 in Disk reference frame	
Intersect2	Intersection point 2 in Disk reference frame	

### 6.2.3.6 isPointInside()

Check if a point in Disk reference frame is inside or outside the Disk.

#### Parameters

Point	Query point in Disk reference frame
-------	-------------------------------------

# 6.2.3.7 segmentArea()

```
real_type TireGround::Disk::segmentArea (
    real_type const Length ) const [inline]
```

Get the contact patch area under the intersection plane in absolute reference frame [  $m^2$ ]

#### Parameters

```
Length Chord length
```

# 6.2.3.8 segmentLength()

Evaluate a generic segment length given 2 points on the Disk circumfererence.

### Parameters

Point1	Point 1
Point2	Point 2

# 6.2.3.9 set()

```
void TireGround::Disk::set (
    Disk const & in ) [inline]
```

Copy the Disk object.

#### Parameters

*in* Disk object to be copied

#### 6.2.3.10 setOriginXZ()

```
void TireGround::Disk::setOriginXZ (
    vec2 const & _OriginXZ ) [inline]
```

Set origin on XZ plane.

#### **Parameters**

_OriginXZ	New origin on $XZ$ plane
-----------	--------------------------

### 6.2.3.11 y()

```
real_type TireGround::Disk::y (
    real_type const x ) const [inline]
```

Evaluate Y at a query X value on the lower side Disk circumfererence.

#### Parameters

```
x Query X value
```

The documentation for this class was generated from the following file:

• include/PatchTire.hh

# 6.3 TireGround::ETRTO Class Reference

# Tire ETRTO denomination.

```
#include <PatchTire.hh>
```

### **Public Member Functions**

• ETRTO ()

Default constructor.

- ETRTO (real\_type \_SectionWidth, real\_type \_AspectRatio, real\_type \_RimDiameter) Variable set constructor.
- real\_type getSidewallHeight (void) const

*Get sidewall height* [ *m*].

• real\_type getTireDiameter (void) const

Get external tire diameter [m].

real\_type getTireRadius (void) const

Get external tire radius [m].

• real\_type getSectionWidth (void) const

26 Class Documentation

Get section width [m].

• void print (ostream\_type &stream) const Display tire data.

# 6.3.1 Detailed Description

Tire ETRTO denomination.

### 6.3.2 Constructor & Destructor Documentation

#### 6.3.2.1 ETRTO()

```
TireGround::ETRTO::ETRTO (
    real_type _SectionWidth,
    real_type _AspectRatio,
    real_type _RimDiameter ) [inline]
```

Variable set constructor.

#### **Parameters**

_SectionWidth	Tire section width [ m]
_AspectRatio	Tire aspect ratio [ %]
_RimDiameter	Rim diameter [ in]

### 6.3.3 Member Function Documentation

### 6.3.3.1 print()

Display tire data.

#### Parameters

```
stream Output stream type
```

The documentation for this class was generated from the following file:


• include/PatchTire.hh

# 6.4 TireGround::MagicFormula Class Reference


Pacejka MagicFormula contact model.

```
#include <PatchTire.hh>
```

Inheritance diagram for TireGround::MagicFormula:



Collaboration diagram for TireGround::MagicFormula:



## **Public Member Functions**

• ~MagicFormula ()

Default destructor.

 MagicFormula (real\_type const SectionWidth, real\_type const AspectRatio, real\_type const RimDiameter, int\_type const SwitchN)

Variable set constructor.

• void getNormal (vec3 &\_Normal) const override

Get contact normal versor.

• void getNormal (row\_vec3 &\_Normal) const override

Get contact normal versors vector.

• void getMFpoint (vec3 &\_DiskPoint) const override

Get Magic Formula contact point.

• void getMFpoint (row\_vec3 &\_DiskPoint) const override

Get Magic Formula contact point vector.

• void getFriction (real\_type &\_Friction) const override

Get contact point friction.

• void getFriction (row\_vecN &\_Friction) const override

Get contact point friction vector.

• void getMFpointRF (mat4 &PointRF) const override

 $Get\ Magic\ Formula\ contact\ point\ reference\ frame\ with\ 4x4\ transformation\ matrix.$ 

28 Class Documentation

• void getMFpointRF (row\_mat4 &\_MFpointRF) const override

Get Magic Formula contact point reference frame vector with 4x4 transformation matrix.

- void getRho (real\_type &Rho) const override
- void getRho (row\_vecN &Rho) const override
- void getRhoDot (real\_type const &Rho, real\_type const &Time, real\_type &RhoDot) const override

Get contact depth time derivative [m/s].

 void getRhoDot (row\_vecN const &Rho, real\_type const &Time, row\_vecN &RhoDot) const override

Get contact depth time derivative vector [m/s].

• void getArea (real\_type &\_Area) const override

Get approximated contact area on Disk plane [  $m^2$ ].

• void getArea (row\_vecN &\_Area) const override

Get approximated contact area vector on Disk plane [  $m^2$ ].

• void getVolume (real\_type &\_Volume) const override

Get approximated contact volume [ $m^3$ ].

• void getVolume (row\_vecN &Volume) const override

Get approximated contact volume vector  $[m^3]$ .

• bool setup (RDF::MeshSurface &Mesh, mat4 const &TM) override

*Update current tire position and find contact parameters.* 

• void print (ostream\_type &stream) const override

Print contact parameters.

void printETRTOGeometry (ostream\_type &stream) const

Display Tire ETRTO geometry data.

• G2lib::AABBtree::PtrAABB const getAABBtree (void) const

Get total Tire Shadow G2Lib::AABBtree (3D projection on ground)

• G2lib::AABBtree::PtrAABB const getUpperSideAABBtree (void) const

Get upper side Tire Shadow G2Lib:AABBtree (3D projection on ground)

G2lib::AABBtree::PtrAABB const getLowerSideAABBtree (void) const

Get lower side Tire Shadow G2Lib:AABBtree (3D projection on ground)

- void setReferenceFrame (ReferenceFrame const &\_RF)
- ReferenceFrame const & getReferenceFrame (void) const

Get tire ReferenceFrame object.

• void setOrigin (vec3 const &Origin)

Set a new tire origin.

- void setRotationMatrix (mat3 const &RotationMatrix)
- void setTotalTransformationMatrix (mat4 const &TM)
- real\_type getEulerAngleX (void) const
- real\_type getEulerAngleY (void) const
- real\_type getEulerAngleZ (void) const
- void getRelativeCamber (real\_type &RelativeCamber) const

Get relative camber angle [rad].

int\_type getDisksNumber (void) const

Dimension of the contact points data structure (disks number)

### **Protected Member Functions**

• MagicFormula (MagicFormula const &)=delete

Deleted copy constructor.

- MagicFormula const & operator= (MagicFormula const &)=delete
   Deleted copy operator.
- void evaluateContact (RDF::TriangleRoad\_list const &TriList) override

Evaluate contact with RoadTriangles.

- void fourPointsSampling (RDF::TriangleRoad\_list const &TriList, vec3 &P\_star)

  Perform triangles sampling on 4 points at ±0.1\*R along X and ±0.3\*W along Y.
- bool pointSampling (RDF::TriangleRoad\_list const &TriList, vec3 const &RayOrigin, vec3 const &RayDirection, vec3 &SampledPt, real\_type &TriFriction=quietNaN, vec3 &Tri← Normal=vec3\_NaN) const

Perform one point sampling (ray-triangle intersection)

## **Protected Attributes**

• Disk SingleDisk

Single Disk.

vec3 Normal

Contact normal versor.

vec3 MeshPoint

Contact point on Mesh (not for Magic Formula)

vec3 DiskPoint

Contact point on undeformed Disk circumference (for Magic Formula)

real\_type Friction

Contact friction.

• real\_type Area

Contact area  $[m^2]$ .

SamplingGrid Precision

Contacth patch evaluating precision.

ETRTO TireGeometry

Tire ETRTO denomination.

ReferenceFrame RF

ReferenceFrame.

Shadow TireShadow

Tire shadow.

# 6.4.1 Detailed Description

Pacejka MagicFormula contact model.

## 6.4.2 Constructor & Destructor Documentation

### 6.4.2.1 MagicFormula()

```
TireGround::MagicFormula::MagicFormula (
    real_type const SectionWidth,
    real_type const AspectRatio,
    real_type const RimDiameter,
    int_type const SwitchN ) [inline]
```

Variable set constructor.

#### Parameters

SectionWidth	Tire section width [ m]
AspectRatio	Tire aspect ratio [ %]
RimDiameter	Rim diameter [ in]
SwitchN	Maximum RoadTriangles in the Tire Shadow (switch to sampling)

## 6.4.3 Member Function Documentation

## 6.4.3.1 evaluateContact()

Evaluate contact with RoadTriangles.

## Parameters

TriList	Shadow/MeshSurface intersected triangles
---------	--

Implements TireGround::Tire.

## 6.4.3.2 fourPointsSampling()

Perform triangles sampling on 4 points at  $\pm 0.1*R$  along X and  $\pm 0.3*W$  along Y.

#### Parameters

## 6.4.3.3 getArea() [1/2]

```
void TireGround::MagicFormula::getArea (
    real_type & _Area ) const [inline], [override], [virtual]
```

Get approximated contact area on Disk plane [  $m^2$ ].

## Parameters

```
_Area | Contact area [ m^2]
```

Implements TireGround::Tire.

```
6.4.3.4 getArea() [2/2]
void TireGround::MagicFormula::getArea (
       row_vecN & _Area ) const [inline], [override], [virtual]
Get approximated contact area vector on Disk plane [m^2].
Parameters
         Contact area vector [m^2]
  Area
Implements TireGround::Tire.
6.4.3.5 getEulerAngleX()
real_type TireGround::Tire::getEulerAngleX (
       void ) const [inline], [inherited]
Get current Euler angles [ rad] for X-axis
Warning: Factor as [R_z][R_x][R_y]!
6.4.3.6 getEulerAngleY()
real_type TireGround::Tire::getEulerAngleY (
       void ) const [inline], [inherited]
Get current Euler angles [ rad] for Y-axis
Warning: Factor as [R_z][R_x][R_y]!
6.4.3.7 getEulerAngleZ()
real_type TireGround::Tire::getEulerAngleZ (
       void ) const [inline], [inherited]
Get current Euler angles [ rad] for Z-axis
Warning: Factor as [R_z][R_x][R_y]!
6.4.3.8 getFriction() [1/2]
void TireGround::MagicFormula::getFriction (
       real_type & _Friction ) const [inline], [override], [virtual]
Get contact point friction.
Parameters
            Contact point friction
  _Friction
Implements TireGround::Tire.
6.4.3.9 getFriction() [2/2]
```

void TireGround::MagicFormula::getFriction (

Get contact point friction vector.

row\_vecN & \_Friction ) const [inline], [override], [virtual]

#### Parameters

_ <i>Friction</i>   Contact point friction vector
---

Implements TireGround::Tire.

```
6.4.3.10 getMFpoint() [1/2]
void TireGround::MagicFormula::getMFpoint (
    vec3 & _DiskPoint ) const [inline], [override], [virtual]
```

Get Magic Formula contact point.

#### **Parameters**

_DiskPoint   Magic Formula contact point
--

Implements TireGround::Tire.

```
6.4.3.11 getMFpoint() [2/2]
```

```
void TireGround::MagicFormula::getMFpoint (
    row_vec3 & _DiskPoint ) const [inline], [override], [virtual]
```

Get Magic Formula contact point vector.

**Parameters** 

```
_DiskPoint | Contact point vector on Disk
```

Implements TireGround::Tire.

```
6.4.3.12 getMFpointRF() [1/2]
```

```
void TireGround::MagicFormula::getMFpointRF (
    mat4 & PointRF ) const [override], [virtual]
```

Get Magic Formula contact point reference frame with 4x4 transformation matrix.

Parameters

```
PointRF | Magic Formula contact point reference frame
```

Implements TireGround::Tire.

```
6.4.3.13 getMFpointRF() [2/2]
```

```
void TireGround::MagicFormula::getMFpointRF (
    row_mat4 & _MFpointRF ) const [inline], [override], [virtual]
```

Get Magic Formula contact point reference frame vector with 4x4 transformation matrix.

#### Parameters

_MFpointRF   Magic Formula ontact point reference frames vector	r
---	---

Implements TireGround::Tire.

```
6.4.3.14 getNormal() [1/2]
```

```
void TireGround::MagicFormula::getNormal (
    vec3 & _Normal ) const [inline], [override], [virtual]
```

Get contact normal versor.

Parameters

_Normal	Contact point normal versor
---------	-----------------------------

Implements TireGround::Tire.

```
6.4.3.15 getNormal() [2/2]
```

```
void TireGround::MagicFormula::getNormal (
    row_vec3 & _Normal ) const [inline], [override], [virtual]
```

Get contact normal versors vector.

Parameters

```
_Normal | Contact point normal direction vector
```

Implements TireGround::Tire.

## 6.4.3.16 getRelativeCamber()

```
void TireGround::Tire::getRelativeCamber (
    real_type & RelativeCamber ) const [inherited]
```

Get relative camber angle [rad].

**Parameters** 

```
RelativeCamber Relative camber angle
```

```
6.4.3.17 getRho() [1/2]
```

```
void TireGround::MagicFormula::getRho (
    real_type & Rho ) const [inline], [override], [virtual]
```

Get contact depth at center point [m]

Warning: (if negative the tire does not touch the ground)!

#### Parameters

Rho	Depth at center point
-----	-----------------------

Implements TireGround::Tire.

```
6.4.3.18 getRho() [2/2]

void TireGround::MagicFormula::getRho (
    row_vecN & Rho ) const [inline], [override], [virtual]
```

Get contact depth matrix [ m]

Warning: (if negative the tire does not touch the ground)!

#### Parameters

```
Rho Depth matrix
```

Implements TireGround::Tire.

## 6.4.3.19 getRhoDot() [1/2]

```
void TireGround::MagicFormula::getRhoDot (
    real_type const & Rho,
    real_type const & Time,
    real_type & RhoDot ) const [inline], [override], [virtual]
```

Get contact depth time derivative [ m/s].

#### **Parameters**

Rho	Previous time step Rho [ $m$ ]
Time	Time step [ s]
RhoDot	Penetration derivative [ $m/s$ ]

Implements TireGround::Tire.

# 6.4.3.20 getRhoDot() [2/2]

```
void TireGround::MagicFormula::getRhoDot (
    row_vecN const & Rho,
    real_type const & Time,
    row_vecN & RhoDot ) const [inline], [override], [virtual]
```

Get contact depth time derivative vector [ m/s].

## Parameters

Rho	Previous time step Rho [ $m$ ]
Time	Time step [ s]
RhoDot	Penetration derivative [ $m/s$ ]

Implements TireGround::Tire.

```
6.4.3.21 getVolume() [1/2]
```

Get approximated contact volume [ $m^3$ ].

### Parameters

```
_Volume | Contact volume [ m^3]
```

Implements TireGround::Tire.

## 6.4.3.22 getVolume() [2/2]

```
void TireGround::MagicFormula::getVolume (
    row_vecN & Volume ) const [inline], [override], [virtual]
```

Get approximated contact volume vector [ $m^3$ ].

#### **Parameters**

	Volume	Contact volume vector [ $m^3$ ]		l
--	--------	---------------------------------	--	---

Implements TireGround::Tire.

# 6.4.3.23 pointSampling()

```
bool TireGround::Tire::pointSampling (
    RDF::TriangleRoad_list const & TriList,
    vec3 const & RayOrigin,
    vec3 const & RayDirection,
    vec3 & SampledPt,
    real_type & TriFriction = quietNaN,
    vec3 & TriNormal = vec3_NaN ) const [protected], [inherited]
```

Perform one point sampling (ray-triangle intersection)

#### **Parameters**

TriList	Shadow/MeshSurface intersected triangles
RayOrigin	Ray origin
RayDirection	Ray direction
SampledPt	Intersection point
TriFriction	Intersected triangle friction
TriNormal	Intersected triangle normal

```
6.4.3.24 print()
```

Print contact parameters.

**Parameters** 

```
stream | Output stream type
```

Implements TireGround::Tire.

## 6.4.3.25 printETRTOGeometry()

Display Tire ETRTO geometry data.

Parameters

```
stream Output stream type
```

# 6.4.3.26 setOrigin()

```
void TireGround::Tire::setOrigin (
    vec3 const & Origin ) [inline], [inherited]
```

Set a new tire origin.

Parameters

```
Origin Tire origin
```

### 6.4.3.27 setReferenceFrame()

Copy the tire ReferenceFrame object

Warning: Rotation matrix must be orthonormal!

**Parameters** 

```
_RF | ReferenceFrame object to be copied
```

## 6.4.3.28 setRotationMatrix()

```
void TireGround::Tire::setRotationMatrix (
```

```
mat3 const & RotationMatrix ) [inline], [inherited]
```

Set a new 3x3 rotation matrix

Warning: Rotation matrix must be orthonormal!

#### **Parameters**

```
RotationMatrix | Rotation matrix
```

## 6.4.3.29 setTotalTransformationMatrix()

Set 4x4 total transformation matrix

Warning: Rotation matrix must be orthonormal!

#### **Parameters**

```
TM 4x4 total transformation matrix
```

# 6.4.3.30 setup()

Update current tire position and find contact parameters.

#### Parameters

Mesh	MeshSurface object (road)
TM	4x4 total transformation matrix

Implements TireGround::Tire.

The documentation for this class was generated from the following file:

• include/PatchTire.hh

# 6.5 TireGround::RDF::MeshSurface Class Reference

# Mesh surface.

```
#include <RoadRDF.hh>
```

## **Public Member Functions**

• MeshSurface ()

Default set constructor.

• MeshSurface (TriangleRoad\_list const &\_PtrTriangleVec)

Variable set constructor.

• MeshSurface (std::string const &Path)

Variable set constructor.

• TriangleRoad\_list const & getTrianglesList (void) const

Get all triangles inside the mesh as a vector.

TriangleRoad\_ptr const getTriangle (unsigned i) const

Get i-th TriangleRoad.

G2lib::AABBtree::PtrAABB const getAABBPtr (void) const

Get AABBtree object.

• void printData (std::string const &FileName) const

Print data in file.

• std::vector< G2lib::BBox::PtrBBox > const & getPtrBBoxList () const

Get the mesh G2lib bounding boxes pointers vector.

• void set (MeshSurface const &in)

Copy the MeshSurface object.

• bool LoadFile (std::string const &Path)

Load the RDF model and print information on a file.

bool intersectAABBtree (G2lib::AABBtree::PtrAABB const &AABBTreePtr, RDF::Triangle← Road\_list &TrianglesList) const

Intersect the mesh AABB tree with an external AABB tree.

• bool intersectBBox (std::vector< G2lib::BBox::PtrBBox > const &BBoxPtr, RDF::Triangle← Road\_list &TrianglesList) const

Update the mesh AABBtree with an external G2lib::BBox object pointer vector.

# 6.5.1 Detailed Description

Mesh surface.

#### 6.5.2 Constructor & Destructor Documentation

```
6.5.2.1 MeshSurface() [1/2]
```

Variable set constructor.

**Parameters** 

```
_PtrTriangleVec | Road triangles pointer vector list
```

```
6.5.2.2 MeshSurface() [2/2]
```

Variable set constructor.

**Parameters** 

```
Path Path to the RDF file
```

## 6.5.3 Member Function Documentation

### 6.5.3.1 intersectAABBtree()

Intersect the mesh AABB tree with an external AABB tree.

#### Parameters

AABBTreePtr	External AABBtree object pointer
TrianglesList	Intersected TriangleRoad vector list

## 6.5.3.2 intersectBBox()

Update the mesh AABBtree with an external G2lib::BBox object pointer vector.

#### **Parameters**

BBoxPtr	External G2lib::BBox object pointer vector
TrianglesList	Intersected TriangleRoad vector list

## 6.5.3.3 LoadFile()

```
bool TireGround::RDF::MeshSurface::LoadFile (
    std::string const & Path )
```

Load the RDF model and print information on a file.

### Parameters

```
Path Path to the RDF file
```

## 6.5.3.4 printData()

```
void TireGround::RDF::MeshSurface::printData (
    std::string const & FileName ) const
```

Print data in file.

#### **Parameters**

FileName	File name in which print data
----------	-------------------------------

## 6.5.3.5 set()

Copy the MeshSurface object.

#### **Parameters**

```
in MeshSurface object to be copied
```

The documentation for this class was generated from the following file:


• include/RoadRDF.hh

# 6.6 TireGround::MultiDisk Class Reference


Multi-disk tire contact model.

```
#include <PatchTire.hh>
```

Inheritance diagram for TireGround::MultiDisk:



Collaboration diagram for TireGround::MultiDisk:



#### **Public Member Functions**

• ∼MultiDisk ()

Default destructor.

• MultiDisk (real\_type const SectionWidth, real\_type const AspectRatio, real\_type const RimDiameter, int\_type const PointsN, int\_type const DisksN, int\_type const SwitchN)

Variable set constructor.

 MultiDisk (real\_type const SectionWidth, real\_type const AspectRatio, real\_type const RimDiameter, real\_type const SideRadius, int\_type const PointsN, int\_type const DisksN, int\_type const SwitchN)

Variable set constructor.

 MultiDisk (real\_type const SectionWidth, real\_type const AspectRatio, real\_type const RimDiameter, row\_vecN const DisksRadius, int\_type const PointsN, int\_type const SwitchN)

Variable set constructor.

real\_type getPointstep (void) const

Get grid step on X-axis between sampling points [m].

real\_type getDiskStep (void) const

Get step on Y-axis between disks [m].

• void getNormal (vec3 &\_Normal) const override

Get contact normal mean versor.

• void getDiskOriginXYZ (row\_vec3 &Origin) const

Get disks origin (X, Y, Z).

• void getDiskOriginXYZ (int\_type const i, vec3 &Origin) const

Get i-th Disk origin (X, Y, Z).

• void setDiskOriginXZ (row\_vec2 &Origin)

Set disks origin (X, Y, Z).

void setDiskOriginXZ (int\_type const i, vec2 &Origin)

Set i-th Disk origin (X, Y, Z).

• void getNormal (row\_vec3 &\_NormalVec) const override

Get contact normal versors vector.

• void getDiskNormal (int\_type const i, vec3 &\_Normal) const

Get i-th Disk contact normal versor.

• void getMFpoint (vec3 &\_DiskPoint) const override

Get Magic Formula contact point.

• void getMFpoint (row\_vec3 &\_DiskPointVec) const override

Get Magic Formula contact points vector.

• void getDiskMFpoint (int\_type const i, vec3 &\_DiskPoint) const

Get i-th Disk Magic Formula contact point.

void getFriction (real\_type &\_Friction) const override

Get area weighted mean contact friction.

• void getFriction (row\_vecN &\_Friction) const override

Get contact frictions vector.

void getDiskFriction (int\_type const i, real\_type &\_Friction) const

Get i-th Disk contact friction.

• void getMFpointRF (mat4 &PointRF) const override

Get Magic Formula contact point reference frame with 4x4 transformation matrix.

• void getMFpointRF (row\_mat4 &PointRF) const override

Get Magic Formula contact point reference frames vector with 4x4 transformation matrix.

void getDiskMFpointRF (int\_type const i, mat4 &PointRF) const

Get Disk Magic Formula contact point reference frame with 4x4 transformation matrix.

- void getRho (real\_type &Rho) const override
- void getRho (row\_vecN &Rho) const override
- void getDiskRho (int\_type const i, real\_type &Rho) const
- void getRhoDot (real\_type const &Rho, real\_type const &Time, real\_type &RhoDot) const override

Get contact depth time derivative [m/s].

 void getRhoDot (row\_vecN const &Rho, real\_type const &Time, row\_vecN &RhoDot) const override

Get contact depths derivative vector [m/s].

void getDiskRhoDot (int\_type const i, real\_type const &Rho, real\_type const &Time, real
 \_type &RhoDot) const

Get i-th Disk contact depth derivative [ m/s].

• void getArea (real\_type &\_Area) const override

Get approximated mean contact area on Disk plane [  $m^2$ ].

• void getArea (row\_vecN &\_AreaVec) const override

Get approximated contact areas vector on Disk plane [ $m^2$ ].

• void getVolume (real\_type &Volume) const override

Get approximated contact volume  $[m^3]$ .

• void getVolume (row\_vecN &Volume) const override

Get approximated contact volumes vector  $[m^3]$ .

• bool setup (RDF::MeshSurface &Mesh, mat4 const &TM) override

Update current tire position and find contact parameters.

• void print (ostream\_type &stream) const override

Print contact parameters.

• void printETRTOGeometry (ostream\_type &stream) const

Display Tire ETRTO geometry data.

• G2lib::AABBtree::PtrAABB const getAABBtree (void) const

Get total Tire Shadow G2Lib::AABBtree (3D projection on ground)

• G2lib::AABBtree::PtrAABB const getUpperSideAABBtree (void) const

Get upper side Tire Shadow G2Lib:AABBtree (3D projection on ground)

• G2lib::AABBtree::PtrAABB const getLowerSideAABBtree (void) const

Get lower side Tire Shadow G2Lib:AABBtree (3D projection on ground)

- void setReferenceFrame (ReferenceFrame const & RF)
- ReferenceFrame const & getReferenceFrame (void) const

Get tire ReferenceFrame object.

• void setOrigin (vec3 const &Origin)

Set a new tire origin.

- void setRotationMatrix (mat3 const &RotationMatrix)
- void setTotalTransformationMatrix (mat4 const &TM)
- real\_type getEulerAngleX (void) const
- real\_type getEulerAngleY (void) const
- real\_type getEulerAngleZ (void) const
- void getRelativeCamber (real\_type &RelativeCamber) const

Get relative camber angle [rad].

• int\_type getDisksNumber (void) const

Dimension of the contact points data structure (disks number)

## **Protected Member Functions**

• bool pointSampling (RDF::TriangleRoad\_list const &TriList, vec3 const &RayOrigin, vec3 const &RayDirection, vec3 &SampledPt, real\_type &TriFriction=quietNaN, vec3 &Tri← Normal=vec3\_NaN) const

Perform one point sampling (ray-triangle intersection)

#### **Protected Attributes**

• SamplingGrid Precision

Contacth patch evaluating precision.

• ETRTO TireGeometry

Tire ETRTO denomination.

ReferenceFrame RF

ReferenceFrame.

• Shadow TireShadow

Tire shadow.

# 6.6.1 Detailed Description

Multi-disk tire contact model.

# 6.6.2 Constructor & Destructor Documentation

### 6.6.2.1 MultiDisk() [1/3]

```
TireGround::MultiDisk::MultiDisk (
    real_type const SectionWidth,
    real_type const AspectRatio,
    real_type const RimDiameter,
    int_type const PointsN,
    int_type const DisksN,
    int_type const SwitchN ) [inline]
```

## Variable set constructor.

#### **Parameters**

SectionWidth	Tire section width [ m]
AspectRatio	Tire aspect ratio [ %]
RimDiameter	Rim diameter [ in]
PointsN	Sampling points for each Disk (divisions on <i>X</i> -axis)
DisksN	Number of Disks (divisions on $Y$ -axis $-1$ )
SwitchN	Maximum RoadTriangles in the Tire Shadow (switch to sampling)

### 6.6.2.2 MultiDisk() [2/3]

```
real_type const RimDiameter,
real_type const SideRadius,
int_type const PointsN,
int_type const DisksN,
int_type const SwitchN ) [inline]
```

### Variable set constructor.

#### Parameters

SectionWidth	Tire section width [ m]
AspectRatio	Tire aspect ratio [ %]
RimDiameter	Rim diameter [ in]
SideRadius	Sidewall radius [ m]
PointsN	Sampling points for each Disk (divisions on <i>X</i> -axis)
DisksN	Number of Disks (divisions on $Y$ -axis $-1$ )
SwitchN	Maximum RoadTriangles in the Tire Shadow (switch to sampling)

## 6.6.2.3 MultiDisk() [3/3]

```
TireGround::MultiDisk::MultiDisk (
    real_type const SectionWidth,
    real_type const AspectRatio,
    real_type const RimDiameter,
    row_vecN const DisksRadius,
    int_type const PointsN,
    int_type const SwitchN ) [inline]
```

## Variable set constructor.

#### Parameters

SectionWidth	Tire section width [ m]
AspectRatio	Tire aspect ratio [ %]
RimDiameter	Rim diameter [ in]
DisksRadius	Disks radius vector [ m]
PointsN	Sampling points for each Disk (divisions on <i>X</i> -axis)
SwitchN	Maximum RoadTriangles in the Tire Shadow (switch to sampling)

## 6.6.3 Member Function Documentation

```
6.6.3.1 getArea() [1/2]

void TireGround::MultiDisk::getArea (
    real_type & _Area ) const [inline], [override], [virtual]
```

Get approximated mean contact area on Disk plane [  $m^2$ ].

#### Parameters

Implements TireGround::Tire.

```
6.6.3.2 getArea() [2/2]
```

```
void TireGround::MultiDisk::getArea (
    row_vecN & _AreaVec ) const [inline], [override], [virtual]
```

Get approximated contact areas vector on Disk plane [ $m^2$ ].

#### **Parameters**

$[m^2]$	Contact areas vector	_AreaVec
---------	----------------------	----------

Implements TireGround::Tire.

# 6.6.3.3 getDiskFriction()

```
void TireGround::MultiDisk::getDiskFriction (
    int_type const i,
    real_type & _Friction ) const [inline]
```

Get *i*-th Disk contact friction.

#### **Parameters**

i	<i>i</i> -th Disk
_Friction	Disk contact friction

## 6.6.3.4 getDiskMFpoint()

```
void TireGround::MultiDisk::getDiskMFpoint (
    int_type const i,
    vec3 & _DiskPoint ) const [inline]
```

Get *i*-th Disk Magic Formula contact point.

### Parameters

i	i-th Disk
_DiskPoint	Disk Magic Formula contact point

## 6.6.3.5 getDiskMFpointRF()

```
void TireGround::MultiDisk::getDiskMFpointRF (
    int_type const i,
    mat4 & PointRF ) const [inline]
```

Get Disk Magic Formula contact point reference frame with 4x4 transformation matrix.

### Parameters

i	i-th Disk
PointRF	Magic Formula contact point reference frame

# 6.6.3.6 getDiskNormal()

```
void TireGround::MultiDisk::getDiskNormal (
    int_type const i,
    vec3 & _Normal ) const [inline]
```

Get *i*-th Disk contact normal versor.

#### **Parameters**

i		<i>i</i> -th Disk
_	Normal	Contact normal versor

## 6.6.3.7 getDiskOriginXYZ() [1/2]

```
void TireGround::MultiDisk::getDiskOriginXYZ (
    row_vec3 & Origin ) const [inline]
```

Get disks origin (X, Y, Z).

## Parameters

_		
	Origin	Disks origin

# 6.6.3.8 getDiskOriginXYZ() [2/2]

```
void TireGround::MultiDisk::getDiskOriginXYZ (
    int_type const i,
    vec3 & Origin ) const [inline]
```

Get *i*-th Disk origin (X, Y, Z).

#### Parameters

i	i-th Disk
Origin	Disks origin

## 6.6.3.9 getDiskRho()

```
void TireGround::MultiDisk::getDiskRho (
    int_type const i,
```

```
real_type & Rho ) const [inline]
```

Get *i*-th Disk contact depth [ *m*]

Warning: (if negative the tire does not touch the ground)!

#### **Parameters**

i	i-th Disk
Rho	Disk contact depth

## 6.6.3.10 getDiskRhoDot()

```
void TireGround::MultiDisk::getDiskRhoDot (
    int_type const i,
    real_type const & Rho,
    real_type const & Time,
    real_type & RhoDot ) const [inline]
```

Get *i*-th Disk contact depth derivative [ m/s].

#### **Parameters**

i	i-th Disk
Rho	Previous time step Rho [ $m$ ]
Time Time step [ s]	
RhoDot	Disk contact depth derivative [ $m/s$ ]

## 6.6.3.11 getEulerAngleX()

```
real_type TireGround::Tire::getEulerAngleX (
    void ) const [inline], [inherited]
```

Get current Euler angles [ rad] for X-axis Warning: Factor as  $[R_z][R_x][R_y]!$ 

# 6.6.3.12 getEulerAngleY()

```
real_type TireGround::Tire::getEulerAngleY (
    void ) const [inline], [inherited]
```

Get current Euler angles [rad] for Y-axis Warning: Factor as [ $R_z$ ][ $R_x$ ][ $R_y$ ]!

## 6.6.3.13 getEulerAngleZ()

```
real_type TireGround::Tire::getEulerAngleZ (
    void ) const [inline], [inherited]
```

Get current Euler angles [ rad] for Z-axis Warning: Factor as  $[R_z][R_x][R_y]!$ 

# 6.6.3.14 getFriction() [1/2]

```
void TireGround::MultiDisk::getFriction (
    real_type & _Friction ) const [inline], [override], [virtual]
```

Get area weighted mean contact friction.

## Parameters

_Friction	Area weighted mean contact friction
-----------	-------------------------------------

Implements TireGround::Tire.

```
6.6.3.15 getFriction() [2/2]

void TireGround::MultiDisk::getFriction (
    row_vecN & _Friction ) const [inline], [override], [virtual]
```

Get contact frictions vector.

#### Parameters

Friction	Contact frictions vector
_1 / / / / / / /	Contact intending vector

Implements TireGround::Tire.

```
6.6.3.16 getMFpoint() [1/2]
void TireGround::MultiDisk::getMFpoint (
    vec3 & _DiskPoint ) const [inline], [override], [virtual]
```

Get Magic Formula contact point.

#### Parameters

_DiskPoint	Magic Formula contact point
------------	-----------------------------

Implements TireGround::Tire.

```
6.6.3.17 getMFpoint() [2/2]
```

```
void TireGround::MultiDisk::getMFpoint (
    row_vec3 & _DiskPointVec ) const [inline], [override], [virtual]
```

Get Magic Formula contact points vector.

Parameters

```
_DiskPointVec | Magic Formula contact points vector
```

Implements TireGround::Tire.

```
6.6.3.18 getMFpointRF() [1/2]
```

```
void TireGround::MultiDisk::getMFpointRF (
    mat4 & PointRF ) const [inline], [override], [virtual]
```

Get Magic Formula contact point reference frame with 4x4 transformation matrix.

#### Parameters

 PointRF
 Magic Formula contact point reference frame

Implements TireGround::Tire.

```
6.6.3.19 getMFpointRF() [2/2]
void TireGround::MultiDisk::getMFpointRF (
    row_mat4 & PointRF ) const [inline], [override], [virtual]
```

Get Magic Formula contact point reference frames vector with 4x4 transformation matrix.

#### **Parameters**

```
PointRF | Magic Formula contact point reference frames vector
```

Implements TireGround::Tire.

```
6.6.3.20 getNormal() [1/2]
```

```
void TireGround::MultiDisk::getNormal (
    vec3 & _Normal ) const [inline], [override], [virtual]
```

Get contact normal mean versor.

#### **Parameters**

```
_Normal | Contact normal mean versor
```

Implements TireGround::Tire.

```
6.6.3.21 getNormal() [2/2]
```

```
void TireGround::MultiDisk::getNormal (
    row_vec3 & _NormalVec ) const [inline], [override], [virtual]
```

Get contact normal versors vector.

### Parameters

```
_NormalVec | Contact normal versors vector
```

Implements TireGround::Tire.

## 6.6.3.22 getRelativeCamber()

```
void TireGround::Tire::getRelativeCamber (
    real_type & RelativeCamber ) const [inherited]
```

Get relative camber angle [ rad].

#### Parameters

```
6.6.3.23 getRho() [1/2]
```

```
void TireGround::MultiDisk::getRho (
    real_type & Rho ) const [inline], [override], [virtual]
```

Get contact depth at center point [ m]

Warning: (if negative the tire does not touch the ground)!

#### Parameters

Implements TireGround::Tire.

```
6.6.3.24 getRho() [2/2]
```

```
void TireGround::MultiDisk::getRho (
    row_vecN & Rho ) const [inline], [override], [virtual]
```

Get contact depths vector [ m]

Warning: (if negative the tire does not touch the ground)!

#### Parameters

Rho	Contact depths vector

Implements TireGround::Tire.

## 6.6.3.25 getRhoDot() [1/2]

```
void TireGround::MultiDisk::getRhoDot (
    real_type const & Rho,
    real_type const & Time,
    real_type & RhoDot ) const [inline], [override], [virtual]
```

Get contact depth time derivative [ m/s].

#### Parameters

Rho	Previous time step Rho [ $m$ ]
Time	Time step $[s]$
RhoDot	Contact depth derivative [ $m/s$ ]

Implements TireGround::Tire.

## 6.6.3.26 getRhoDot() [2/2]

```
void TireGround::MultiDisk::getRhoDot (
    row_vecN const & Rho,
    real_type const & Time,
    row_vecN & RhoDot ) const [inline], [override], [virtual]
```

Get contact depths derivative vector [ m/s].

#### **Parameters**

Rho	Previous time step Rho [ m]
Time	Time step [ s]
RhoDot	Contact depths derivative vector [ $m/s$ ]

Implements TireGround::Tire.

```
6.6.3.27 getVolume() [1/2]
```

```
void TireGround::MultiDisk::getVolume (
    real_type & Volume ) const [inline], [override], [virtual]
```

Get approximated contact volume [ $m^3$ ].

#### Parameters

Implements TireGround::Tire.

```
6.6.3.28 getVolume() [2/2]
```

```
void TireGround::MultiDisk::getVolume (
    row_vecN & Volume ) const [inline], [override], [virtual]
```

Get approximated contact volumes vector [ $m^3$ ].

## Parameters

```
Volume | Contact volumes vector [ m^3]
```

Implements TireGround::Tire.

### 6.6.3.29 pointSampling()

```
bool TireGround::Tire::pointSampling (
    RDF::TriangleRoad_list const & TriList,
    vec3 const & RayOrigin,
    vec3 const & RayDirection,
    vec3 & SampledPt,
    real_type & TriFriction = quietNaN,
    vec3 & TriNormal = vec3_NaN ) const [protected], [inherited]
```

Perform one point sampling (ray-triangle intersection)

### Parameters

TriList	Shadow/MeshSurface intersected triangles
RayOrigin	Ray origin
RayDirection	Ray direction
SampledPt	Intersection point
TriFriction	Intersected triangle friction
TriNormal	Intersected triangle normal

## 6.6.3.30 print()

Print contact parameters.

#### **Parameters**

stream	Output stream type
--------	--------------------

Implements TireGround::Tire.

# 6.6.3.31 printETRTOGeometry()

Display Tire ETRTO geometry data.

## Parameters

```
stream Output stream type
```

## 6.6.3.32 setDiskOriginXZ() [1/2]

```
void TireGround::MultiDisk::setDiskOriginXZ (
    row_vec2 & Origin ) [inline]
```

Set disks origin (X, Y, Z).

## Parameters

Orig	gin	New Disks origin vector

# 6.6.3.33 setDiskOriginXZ() [2/2]

```
void TireGround::MultiDisk::setDiskOriginXZ (
    int_type const i,
    vec2 & Origin ) [inline]
```

Set *i*-th Disk origin (X, Y, Z).

#### **Parameters**

i	<i>i</i> -th Disk
Origin	New Disks origin vector

# 6.6.3.34 setOrigin()

```
void TireGround::Tire::setOrigin (
    vec3 const & Origin ) [inline], [inherited]
```

Set a new tire origin.

#### **Parameters**

Origin	Tire origin
--------	-------------

## 6.6.3.35 setReferenceFrame()

Copy the tire ReferenceFrame object

Warning: Rotation matrix must be orthonormal!

#### Parameters

\_RF | ReferenceFrame object to be copied

## 6.6.3.36 setRotationMatrix()

```
void TireGround::Tire::setRotationMatrix (
    mat3 const & RotationMatrix ) [inline], [inherited]
```

Set a new 3x3 rotation matrix

Warning: Rotation matrix must be orthonormal!

## Parameters

RotationMatrix	Rotation matrix

### 6.6.3.37 setTotalTransformationMatrix()

```
void TireGround::Tire::setTotalTransformationMatrix (
    mat4 const & TM ) [inline], [inherited]
```

Set 4x4 total transformation matrix

Warning: Rotation matrix must be orthonormal!

#### Parameters

```
TM 4x4 total transformation matrix
```

## 6.6.3.38 setup()

Update current tire position and find contact parameters.

#### **Parameters**

Mesh	MeshSurface object (road)
TM	4x4 total transformation matrix

Implements TireGround::Tire.

The documentation for this class was generated from the following file:

• include/PatchTire.hh

# 6.7 TireGround::ReferenceFrame Class Reference

#### Reference frame.

```
#include <PatchTire.hh>
```

## **Public Member Functions**

• ReferenceFrame ()

Default constructor.

• ReferenceFrame (vec3 const &\_Origin, mat3 const &\_RotationMatrix)

Variable set constructor.

• bool isEmpty (void)

Check if ReferenceFrame object is empty.

• mat3 const & getRotationMatrix (void) const

Get current 3x3 rotation matrix.

• mat3 getRotationMatrixInverse (void) const

Get current 3x3 rotation matrix inverse.

vec3 getX (void) const

*Get current X-axis versor.* 

• vec3 getY (void) const

*Get current Y-axis versor.* 

• vec3 getZ (void) const

Get current Z-axis versor.

• vec3 const & getOrigin (void) const

Get origin position.

• void setOrigin (vec3 const &\_Origin)

Set origin position.

• void setRotationMatrix (mat3 const &\_RotationMatrix)

Set 3x3 rotation matrix.

• void setTotalTransformationMatrix (mat4 const &TM)

Set 4x4 total transformation matrix.

mat4 getTotalTransformationMatrix (void)

Get 4x4 total transformation matrix.

- void set (ReferenceFrame const &in)
- real\_type getEulerAngleX (void) const
- real\_type getEulerAngleY (void) const
- real\_type getEulerAngleZ (void) const

# 6.7.1 Detailed Description

Reference frame.

### 6.7.2 Constructor & Destructor Documentation

#### 6.7.2.1 ReferenceFrame()

```
TireGround::ReferenceFrame::ReferenceFrame (
    vec3 const & _Origin,
    mat3 const & _RotationMatrix ) [inline]
```

Variable set constructor.

#### **Parameters**

_Origin	Origin position	
_RotationMatrix	3x3 rotation matrix	

## 6.7.3 Member Function Documentation

### 6.7.3.1 getEulerAngleX()

```
real_type TireGround::ReferenceFrame::getEulerAngleX ( void ) const  
Get current Euler angles [ rad] for X-axis  
Warning: Factor as [R_z][R_x][R_y]!
```

# 6.7.3.2 getEulerAngleY()

```
Get current Euler angles [ rad] for Y-axis Warning: Factor as [R_x][R_x][R_y]!
```

## 6.7.3.3 getEulerAngleZ()

```
real_type TireGround::ReferenceFrame::getEulerAngleZ (
    void ) const
```

Get current Euler angles [ rad] for Z-axis Warning: Factor as  $[R_z][R_x][R_y]!$ 

### 6.7.3.4 set()

```
void TireGround::ReferenceFrame::set (
          ReferenceFrame const & in ) [inline]
```

Copy the tire ReferenceFrame object

Warning: Rotation matrix must be orthonormal!

#### Parameters

*in* ReferenceFrame object to be copied

## 6.7.3.5 setOrigin()

```
void TireGround::ReferenceFrame::setOrigin (
    vec3 const & _Origin ) [inline]
```

Set origin position.

#### Parameters

```
_Origin | Origin position
```

# 6.7.3.6 setRotationMatrix()

Set 3x3 rotation matrix.

### Parameters

```
_RotationMatrix | 3x3 rotation matrix
```

## 6.7.3.7 setTotalTransformationMatrix()

```
void TireGround::ReferenceFrame::setTotalTransformationMatrix (
    mat4 const & TM ) [inline]
```

Set 4x4 total transformation matrix.

#### Parameters

TM 4x4 total transformation	matrix
-----------------------------	--------

The documentation for this class was generated from the following file:

• include/PatchTire.hh

# 6.8 TireGround::SamplingGrid Class Reference

Patch evaluation precision.

```
#include <PatchTire.hh>
```

#### **Public Member Functions**

• SamplingGrid ()

Default constructor.

• SamplingGrid (int\_type \_PointsN, int\_type \_DisksN)

Variable set constructor.

• SamplingGrid (int\_type \_PointsN, int\_type \_DisksN, int\_type \_Switch)

Variable set constructor.

int\_type getPointsNumber (void) const

Get number of sampling points for each Disk (divisions on X-axis)

• int\_type getDisksNumber (void) const

Get number of Disks (divisions on Y-axis -1)

unsigned getSwitchNumber (void) const

Get number of maximum RoadTriangles in the Tire Shadow (switch to sampling)

void setSwitchNumber (int\_type const \_Switch)

Set number of maximum RoadTriangles in the Tire Shadow (switch to sampling)

- void set (int\_type \_PointsN, int\_type \_DisksN, int\_type \_Switch) Set number of divisions.
- void set (SamplingGrid const &in)

Copy the SamplingGrid object.

## 6.8.1 Detailed Description

Patch evaluation precision.

# 6.8.2 Constructor & Destructor Documentation

### 6.8.2.1 SamplingGrid() [1/2]

```
TireGround::SamplingGrid::SamplingGrid (
    int_type _PointsN,
    int_type _DisksN ) [inline]
```

Variable set constructor.

#### **Parameters**

_PointsN	Sampling points for each Disk (divisions on <i>X</i> -axis)
_DisksN	Number of Disks (divisions on $Y$ -axis $-1$ )

## 6.8.2.2 SamplingGrid() [2/2]

```
TireGround::SamplingGrid::SamplingGrid (
    int_type _PointsN,
    int_type _DisksN,
    int_type _Switch ) [inline]
```

### Variable set constructor.

#### **Parameters**

_PointsN	Sampling points for each Disk (divisions on <i>X</i> -axis)
_DisksN	Number of Disks (divisions on $Y$ -axis $-1$ )
_Switch	Maximum RoadTriangles in the Tire Shadow (switch to sampling)

## 6.8.3 Member Function Documentation

```
6.8.3.1 set() [1/2]

void TireGround::SamplingGrid::set (
    int_type _PointsN,
    int_type _DisksN,
    int_type _Switch ) [inline]
```

Set number of divisions.

## Parameters

_Pa	ointsN	Sampling points for each Disk (divisions on <i>X</i> -axis)
_D	isksN	Number of Disks (divisions on $Y$ -axis $-1$ )
_St	witch	Maximum RoadTriangles in the Tire Shadow (switch to sampling)

## Copy the SamplingGrid object.

#### Parameters

```
in SamplingGrid object to be copied
```

## 6.8.3.3 setSwitchNumber()

```
void TireGround::SamplingGrid::setSwitchNumber (
    int_type const _Switch ) [inline]
```

Set number of maximum RoadTriangles in the Tire Shadow (switch to sampling)

#### Parameters

|--|

The documentation for this class was generated from the following file:

• include/PatchTire.hh

# 6.9 TireGround::Shadow Class Reference

2D shadow (2D bounding box enhacement)

```
#include <PatchTire.hh>
```

### **Public Member Functions**

• Shadow ()

Default constructor.

- Shadow (ETRTO const &TireGeometry, ReferenceFrame const &RF)
- void update (ETRTO const &TireGeometry, ReferenceFrame const &RF)
- G2lib::AABBtree::PtrAABB const getAABBtree (void) const Get total Tire G2Lib::AABBtree (3D projection on ground)
- G2lib::AABBtree::PtrAABB const getUpperSideAABBtree (void) const Get upper side Tire G2Lib:AABBtree (3D projection on ground)
- G2lib::AABBtree::PtrAABB const getLowerSideAABBtree (void) const Get lower side Tire G2Lib:AABBtree (3D projection on ground)

## 6.9.1 Detailed Description

2D shadow (2D bounding box enhacement)

# 6.9.2 Constructor & Destructor Documentation

## 6.9.2.1 Shadow()

Variable set constructor

Warning: Rotation matrix must be orthonormal!

#### Parameters

TireGeometry	Tire ETRTO denomination
RF	Tire ReferenceFrame

## 6.9.3 Member Function Documentation

### 6.9.3.1 update()

Update the 2D tire shadow domain

Warning: Rotation matrix must be orthonormal!

#### **Parameters**

TireGeometry	Tire ETRTO denomination
RF	Tire ReferenceFrame

The documentation for this class was generated from the following file:

• include/PatchTire.hh

# 6.10 TicToc Class Reference

**Public Member Functions** 

- void tic ()
- void **toc** ()
- real\_type elapsed\_s () const
- real\_type **elapsed\_ms** () const

The documentation for this class was generated from the following file:


• include/TicToc.hh

# 6.11 TireGround::Tire Class Reference


Base class for Tire models.

```
#include <PatchTire.hh>
```

Inheritance diagram for TireGround::Tire:



Collaboration diagram for TireGround::Tire:



#### **Public Member Functions**

• ~Tire ()

Default destructor.

Tire (real\_type const SectionWidth, real\_type const AspectRatio, real\_type const Rim
 — Diameter, int\_type const PointsN, int\_type const DisksN)

Variable set constructor.

void printETRTOGeometry (ostream\_type &stream) const

Display Tire ETRTO geometry data.

• G2lib::AABBtree::PtrAABB const getAABBtree (void) const

Get total Tire Shadow G2Lib::AABBtree (3D projection on ground)

G2lib::AABBtree::PtrAABB const getUpperSideAABBtree (void) const

Get upper side Tire Shadow G2Lib:AABBtree (3D projection on ground)

• G2lib::AABBtree::PtrAABB const getLowerSideAABBtree (void) const

Get lower side Tire Shadow G2Lib:AABBtree (3D projection on ground)

- void setReferenceFrame (ReferenceFrame const &\_RF)
- ReferenceFrame const & getReferenceFrame (void) const

Get tire ReferenceFrame object.

• void setOrigin (vec3 const &Origin)

Set a new tire origin.

- void setRotationMatrix (mat3 const &RotationMatrix)
- void setTotalTransformationMatrix (mat4 const &TM)
- real\_type getEulerAngleX (void) const
- real\_type getEulerAngleY (void) const
- real\_type getEulerAngleZ (void) const
- void getRelativeCamber (real\_type &RelativeCamber) const

Get relative camber angle [rad].

• int\_type getDisksNumber (void) const

Dimension of the contact points data structure (disks number)

- virtual void getRho (real\_type &Rho) const =0
- virtual void getRho (row\_vecN &Rho) const =0
- virtual void getRhoDot (real\_type const &Rho, real\_type const &Time, real\_type &RhoDot)
   const =0

Get contact depth time derivative [ m/s].

virtual void getRhoDot (row\_vecN const &Rho, real\_type const &Time, row\_vecN &Rho
 —Dot) const =0

Get contact depth time derivative vector [m/s].

• virtual void getNormal (vec3 &Normal) const =0

Get contact normal versor.

• virtual void getNormal (row\_vec3 &Normal) const =0

Get contact normal versors vector.

• virtual void getMFpoint (vec3 &Point) const =0

Get Magic Formula contact point.

• virtual void getMFpoint (row\_vec3 &Point) const =0

Get Magic Formula contact point vector.

• virtual void getFriction (real\_type &Friction) const =0

Get contact point friction.

• virtual void getFriction (row\_vecN &Friction) const =0

Get contact frictions vector.

• virtual void getMFpointRF (mat4 &PointRF) const =0

Get Magic Formula contact point reference frame with 4x4 transformation matrix.

• virtual void getMFpointRF (row\_mat4 &PointRF) const =0

Get Magic Formula contact point reference frame vector with 4x4 transformation matrix.

• virtual void getArea (real\_type &\_Area) const =0

Get approximated contact area on Disk plane [  $m^2$ ].

• virtual void getArea (row\_vecN &Area) const =0

Get approximated contact areas vector on Disk plane [  $m^2$ ].

• virtual void getVolume (real\_type &Volume) const =0

Get approximated contact volume  $[m^3]$ .

• virtual void getVolume (row\_vecN &\_Volume) const =0

Get approximated contact volume [ $m^3$ ].

• virtual void evaluateContact (RDF::TriangleRoad\_list const &TriList)=0

Evaluate contact with RoadTriangles.

• virtual bool setup (RDF::MeshSurface &Mesh, mat4 const &TM)=0

*Update current tire position and find contact parameters.* 

• virtual void print (ostream\_type &stream) const =0

Print contact parameters.

## **Protected Member Functions**

• Tire (Tire const &)=delete

Deleted copy constructor.

• Tire const & operator= (Tire const &)=delete

Deleted copy operator.

• bool pointSampling (RDF::TriangleRoad\_list const &TriList, vec3 const &RayOrigin, vec3 const &RayDirection, vec3 &SampledPt, real\_type &TriFriction=quietNaN, vec3 &Tri← Normal=vec3\_NaN) const

Perform one point sampling (ray-triangle intersection)

# **Protected Attributes**

• SamplingGrid Precision

Contacth patch evaluating precision.

• ETRTO TireGeometry

Tire ETRTO denomination.

ReferenceFrame RF

ReferenceFrame.

Shadow TireShadow

Tire shadow.

# 6.11.1 Detailed Description

Base class for Tire models.

# 6.11.2 Constructor & Destructor Documentation

#### 6.11.2.1 Tire()

```
TireGround::Tire::Tire (
    real_type const SectionWidth,
    real_type const AspectRatio,
    real_type const RimDiameter,
    int_type const PointsN,
    int_type const DisksN ) [inline]
```

Variable set constructor.

# Parameters

SectionWidth	Tire section width [ m]
AspectRatio	Tire aspect ratio [ %]
RimDiameter	Rim diameter [ in]
PointsN	Sampling points for each Disk (divisions on <i>X</i> -axis)
DisksN	Number of Disks (divisions on $Y$ -axis $-1$ )

# 6.11.3 Member Function Documentation

# 6.11.3.1 evaluateContact()

Evaluate contact with RoadTriangles.

#### **Parameters**

TriList	Shadow/MeshSurface intersected triangles
---------	--

Implemented in TireGround::MagicFormula.

```
6.11.3.2 getArea() [1/2]
virtual void TireGround::Tire::getArea (
    real_type & _Area ) const [pure virtual]
```

Get approximated contact area on Disk plane [  $m^2$ ].

**Parameters** 

```
_Area | Contact area [ m^2]
```

Implemented in TireGround::MultiDisk, and TireGround::MagicFormula.

Get approximated contact areas vector on Disk plane [ $m^2$ ].

**Parameters** 

```
Area Contact areas vector [m^2]
```

Implemented in TireGround::MultiDisk, and TireGround::MagicFormula.

```
6.11.3.4 getEulerAngleX()

real_type TireGround::Tire::getEulerAngleX (
	void ) const [inline]

Get current Euler angles [rad] for X-axis

Warning: Factor as [R_z][R_x][R_y]!

6.11.3.5 getEulerAngleY()

real_type TireGround::Tire::getEulerAngleY (
	void ) const [inline]

Get current Euler angles [rad] for Y-axis

Warning: Factor as [R_z][R_x][R_y]!

6.11.3.6 getEulerAngleZ()
```

real\_type TireGround::Tire::getEulerAngleZ (

```
void ) const [inline] 
Get current Euler angles [rad] for Z-axis 
Warning: Factor as [R_z][R_x][R_y]! 
6.11.3.7 getFriction() [1/2] 
virtual void TireGround::Tire::getFriction (
```

real\_type & Friction ) const [pure virtual]

Get contact point friction.

#### Parameters

Implemented in TireGround::MultiDisk, and TireGround::MagicFormula.

```
6.11.3.8 getFriction() [2/2]
virtual void TireGround::Tire::getFriction (
    row_vecN & Friction ) const [pure virtual]
```

Get contact frictions vector.

#### Parameters

Friction	Contact frictions vector
----------	--------------------------

Implemented in TireGround::MultiDisk, and TireGround::MagicFormula.

```
6.11.3.9 getMFpoint() [1/2]
virtual void TireGround::Tire::getMFpoint (
    vec3 & Point ) const [pure virtual]
```

Get Magic Formula contact point.

## Parameters

D ' '	Magic Formula contact point
Point	Magic Formula contact point
1 01111	magic i crimaia comact point

Implemented in TireGround::MultiDisk, and TireGround::MagicFormula.

```
6.11.3.10 getMFpoint() [2/2]
virtual void TireGround::Tire::getMFpoint (
    row_vec3 & Point ) const [pure virtual]
```

Get Magic Formula contact point vector.

#### Parameters

```
Point | Magic Formula Contact point vector
```

Implemented in TireGround::MultiDisk, and TireGround::MagicFormula.

```
6.11.3.11 getMFpointRF() [1/2]
virtual void TireGround::Tire::getMFpointRF (
    mat4 & PointRF ) const [pure virtual]
```

Get Magic Formula contact point reference frame with 4x4 transformation matrix.

#### Parameters

PointRF   Magic Formula c	ontact point reference frame
---------------------------	------------------------------

Implemented in TireGround::MultiDisk, and TireGround::MagicFormula.

Get Magic Formula contact point reference frame vector with 4x4 transformation matrix.

#### **Parameters**

```
PointRF | Magic Formula ontact point reference frames vector
```

Implemented in TireGround::MultiDisk, and TireGround::MagicFormula.

```
6.11.3.13 getNormal() [1/2]
virtual void TireGround::Tire::getNormal (
    vec3 & Normal ) const [pure virtual]
```

Get contact normal versor.

#### Parameters

```
Normal Contact point normal direction
```

Implemented in TireGround::MultiDisk, and TireGround::MagicFormula.

```
6.11.3.14 getNormal() [2/2]
virtual void TireGround::Tire::getNormal (
    row_vec3 & Normal ) const [pure virtual]
```

Get contact normal versors vector.

#### Parameters

```
Normal | Contact point normal direction vector
```

Implemented in TireGround::MultiDisk, and TireGround::MagicFormula.

# 6.11.3.15 getRelativeCamber()

Get relative camber angle [rad].

#### Parameters

Relative Camber	Relative camber angle
-----------------	-----------------------

```
6.11.3.16 getRho() [1/2]
virtual void TireGround::Tire::getRho (
    real_type & Rho ) const [pure virtual]
```

Get contact depth at center point [m]

Warning: (if negative the tire does not touch the ground)!

#### Parameters

```
Rho Depth at center point
```

Implemented in TireGround::MultiDisk, and TireGround::MagicFormula.

```
6.11.3.17 getRho() [2/2]

virtual void TireGround::Tire::getRho (
    row_vecN & Rho ) const [pure virtual]
```

Get contact depth vector [m]

Warning: (if negative the tire does not touch the ground)!

#### Parameters

```
Rho Depth vector [m]
```

 $Implemented \ in \ Tire Ground:: Multi Disk, \ and \ Tire Ground:: Magic Formula.$ 

```
6.11.3.18 getRhoDot() [1/2]
```

```
virtual void TireGround::Tire::getRhoDot (
    real_type const & Rho,
    real_type const & Time,
    real_type & RhoDot ) const [pure virtual]
```

Get contact depth time derivative [ m/s].

#### Parameters

Rho	Previous time step Rho [ $m$ ]
Time	Time step [ $s$ ]
RhoDot	Penetration derivative [ $m/s$ ]

Implemented in TireGround::MultiDisk, and TireGround::MagicFormula.

#### 6.11.3.19 getRhoDot() [2/2]

```
virtual void TireGround::Tire::getRhoDot (
    row_vecN const & Rho,
    real_type const & Time,
    row_vecN & RhoDot ) const [pure virtual]
```

Get contact depth time derivative vector [ m/s].

#### **Parameters**

Rho	Previous time step Rho [ $m$ ]
Time	Time step [ s]
RhoDot	Penetration derivative [ $m/s$ ]

Implemented in TireGround::MultiDisk, and TireGround::MagicFormula.

```
6.11.3.20 getVolume() [1/2]
```

```
virtual void TireGround::Tire::getVolume (
    real_type & Volume ) const [pure virtual]
```

Get approximated contact volume [ $m^3$ ].

#### **Parameters**

<i>lume</i> Contact volume [ $m^3$ ]
--------------------------------------

Implemented in TireGround::MultiDisk, and TireGround::MagicFormula.

```
6.11.3.21 getVolume() [2/2]
```

```
virtual void TireGround::Tire::getVolume (
    row_vecN & _Volume ) const [pure virtual]
```

Get approximated contact volume [ $m^3$ ].

## Parameters

```
_Volume | Contact volume vector [ m^3]
```

Implemented in TireGround::MultiDisk, and TireGround::MagicFormula.

# 6.11.3.22 pointSampling()

```
bool TireGround::Tire::pointSampling (
    RDF::TriangleRoad_list const & TriList,
    vec3 const & RayOrigin,
    vec3 const & RayDirection,
    vec3 & SampledPt,
    real_type & TriFriction = quietNaN,
    vec3 & TriNormal = vec3_NaN ) const [protected]
```

Perform one point sampling (ray-triangle intersection)

#### Parameters

TriList	Shadow/MeshSurface intersected triangles
RayOrigin	Ray origin
RayDirection	Ray direction
SampledPt	Intersection point
TriFriction	Intersected triangle friction
TriNormal	Intersected triangle normal

# 6.11.3.23 print()

Print contact parameters.

#### **Parameters**

stream	Output stream type
--------	--------------------

 $Implemented\ in\ Tire Ground:: Multi Disk, and\ Tire Ground:: Magic Formula.$ 

# 6.11.3.24 printETRTOGeometry()

Display Tire ETRTO geometry data.

## Parameters

stream	Output stream type
--------	--------------------

# 6.11.3.25 setOrigin()

```
void TireGround::Tire::setOrigin (
    vec3 const & Origin ) [inline]
```

Set a new tire origin.

# Parameters

Origin	Tire origin

#### 6.11.3.26 setReferenceFrame()

Copy the tire ReferenceFrame object

Warning: Rotation matrix must be orthonormal!

#### Parameters

\_*RF* | ReferenceFrame object to be copied

# 6.11.3.27 setRotationMatrix()

Set a new 3x3 rotation matrix

Warning: Rotation matrix must be orthonormal!

#### **Parameters**

RotationMatrix	Rotation matrix
----------------	-----------------

# 6.11.3.28 setTotalTransformationMatrix()

Set 4x4 total transformation matrix

Warning: Rotation matrix must be orthonormal!

#### **Parameters**

```
TM | 4x4 total transformation matrix
```

# 6.11.3.29 setup()

Update current tire position and find contact parameters.

#### **Parameters**

Mesh	MeshSurface object (road)
TM	4x4 total transformation matrix

Implemented in TireGround::MultiDisk, and TireGround::MagicFormula.

The documentation for this class was generated from the following file:


• include/PatchTire.hh

# 6.12 TireGround::RDF::Triangle3D Class Reference


3D triangle (pure geometrical description)

#include <RoadRDF.hh>

Inheritance diagram for TireGround::RDF::Triangle3D:



Collaboration diagram for TireGround::RDF::Triangle3D:



# **Public Member Functions**

• Triangle3D ()

Variable set constructor.

• Triangle3D (vec3 const \_Vertices[3])

Variable set constructor.

• void setVertices (vec3 const \_Vertices[3])

Set new vertices and update bounding box domain.

• void setVertices (vec3 const &Vertex0, vec3 const &Vertex1, vec3 const &Vertex2)

Set new vertices then update bounding box domain and normal versor.

• vec3 const & getNormal (void) const

Get normal versor.

• vec3 const & getVertex (unsigned i) const

Get i-th vertex.

• BBox2D const & getBBox (void) const

Get Triangle3D bonding box BBox2D.

• void print (ostream\_type &stream) const

Print vertices data.

- bool intersectRay (vec3 const &RayOrigin, vec3 const &RayDirection, vec3 &IntPt) const
- int\_type intersectEdgePlane (vec3 const &PlaneN, vec3 const &PlaneP, int\_type const Edge, vec3 &IntPt1, vec3 &IntPt2) const
- bool intersectPlane (vec3 const &PlaneN, vec3 const &PlaneP, std::vector< vec3 > &IntPts)
  const

#### **Protected Member Functions**

• Triangle3D (Triangle3D const &)=delete

Deleted copy constructor.

• Triangle3D & operator= (Triangle3D const &)=delete

Deleted copy operator.

#### **Protected Attributes**

• vec3 Vertices [3]

Vertices reference vector.

vec3 Normal

Triangle normal versor.

• BBox2D TriangleBBox

Triangle 2D bounding box (XY plane)

# 6.12.1 Detailed Description

3D triangle (pure geometrical description)

# 6.12.2 Constructor & Destructor Documentation

# 6.12.2.1 Triangle3D()

```
TireGround::RDF::Triangle3D::Triangle3D (
    vec3 const _Vertices[3] ) [inline]
```

# Variable set constructor.

#### **Parameters**

_ <i>Vertices</i>   Vertices reference vector
---

# 6.12.3 Member Function Documentation

# 6.12.3.1 intersectEdgePlane()

```
int_type TireGround::RDF::Triangle3D::intersectEdgePlane (
    vec3 const & PlaneN,
    vec3 const & PlaneP,
    int_type const Edge,
    vec3 & IntPt1,
    vec3 & IntPt2 ) const
```

Check if an edge of the Triangle3D object hits a and find the intersection point

#### **Parameters**

PlaneN	Plane normal vector	
PlaneP	Plane known point	
Edge	Triangle edge number (0:2)	
IntPt1	Intersection point 1	
IntPt2	Intersection point 2	

# 6.12.3.2 intersectPlane()

```
bool TireGround::RDF::Triangle3D::intersectPlane (
    vec3 const & PlaneN,
    vec3 const & PlaneP,
    std::vector< vec3 > & IntPts ) const
```

Check if a plane intersects a Triangle3D object and find the intersection points

# Parameters

PlaneN	Plane normal vector
PlaneP	Plane known point
IntPts	Intersection points

# 6.12.3.3 intersectRay()

```
bool TireGround::RDF::Triangle3D::intersectRay (
    vec3 const & RayOrigin,
    vec3 const & RayDirection,
    vec3 & IntPt ) const
```

Check if a ray hits a Triangle3D object through Möller-Trumbore intersection algorithm

# Parameters

RayOrigin	Ray origin position
RayDirection	Ray direction vector
IntPt	Intersection point

# 6.12.3.4 print()

Print vertices data.

#### **Parameters**

```
stream Output stream type
```

# 6.12.3.5 setVertices() [1/2]

```
void TireGround::RDF::Triangle3D::setVertices (
    vec3 const _Vertices[3] ) [inline]
```

Set new vertices and update bounding box domain.

#### **Parameters**

_Vertices	Vertices reference vector
-----------	---------------------------

#### 6.12.3.6 setVertices() [2/2]

```
void TireGround::RDF::Triangle3D::setVertices (
    vec3 const & Vertex0,
    vec3 const & Vertex1,
    vec3 const & Vertex2 ) [inline]
```

Set new vertices then update bounding box domain and normal versor.

# Parameters

Vertex0	Vertex 1
Vertex1	Vertex 2
Vertex2	Vertex 3

The documentation for this class was generated from the following file:


• include/RoadRDF.hh

# 6.13 TireGround::RDF::TriangleRoad Class Reference


3D triangles for road representation

```
#include <RoadRDF.hh>
```

Inheritance diagram for TireGround::RDF::TriangleRoad:



Collaboration diagram for TireGround::RDF::TriangleRoad:



# **Public Member Functions**

• TriangleRoad ()

Default set constructor.

• TriangleRoad (vec3 const \_Vertices[3], real\_type \_Friction)

Variable set constructor.

• void setFriction (real\_type \_Friction)

Set friction coefficient.

• real\_type getFriction (void) const

Get friction coefficent on the face.

• void setVertices (vec3 const \_Vertices[3])

Set new vertices and update bounding box domain.

• void setVertices (vec3 const &Vertex0, vec3 const &Vertex1, vec3 const &Vertex2)

Set new vertices then update bounding box domain and normal versor.

• vec3 const & getNormal (void) const

Get normal versor.

• vec3 const & getVertex (unsigned i) const

Get i-th vertex.

• BBox2D const & getBBox (void) const

Get Triangle3D bonding box BBox2D.

• void print (ostream\_type &stream) const

Print vertices data.

- bool intersectRay (vec3 const &RayOrigin, vec3 const &RayDirection, vec3 &IntPt) const
- int\_type intersectEdgePlane (vec3 const &PlaneN, vec3 const &PlaneP, int\_type const Edge, vec3 &IntPt1, vec3 &IntPt2) const
- bool intersectPlane (vec3 const &PlaneN, vec3 const &PlaneP, std::vector < vec3 > &IntPts)
  const

#### Protected Attributes

• vec3 Vertices [3]

Vertices reference vector.

vec3 Normal

Triangle normal versor.

• BBox2D TriangleBBox

Triangle 2D bounding box (XY plane)

# 6.13.1 Detailed Description

3D triangles for road representation

# 6.13.2 Constructor & Destructor Documentation

# 6.13.2.1 TriangleRoad()

```
TireGround::RDF::TriangleRoad::TriangleRoad (
    vec3 const _Vertices[3],
    real_type _Friction ) [inline]
```

#### Variable set constructor.

#### Parameters

_Vertices	Vertices reference vector
_Friction	Friction coefficient

# 6.13.3 Member Function Documentation

#### 6.13.3.1 intersectEdgePlane()

```
int_type TireGround::RDF::Triangle3D::intersectEdgePlane (
    vec3 const & PlaneN,
    vec3 const & PlaneP,
```

```
int_type const Edge,
vec3 & IntPt1,
vec3 & IntPt2 ) const [inherited]
```

Check if an edge of the Triangle3D object hits a and find the intersection point

#### **Parameters**

PlaneN	Plane normal vector	
PlaneP	Plane known point	
Edge	Triangle edge number (0:2)	
IntPt1	Intersection point 1	
IntPt2	Intersection point 2	

# 6.13.3.2 intersectPlane()

```
bool TireGround::RDF::Triangle3D::intersectPlane (
    vec3 const & PlaneN,
    vec3 const & PlaneP,
    std::vector< vec3 > & IntPts ) const [inherited]
```

Check if a plane intersects a Triangle3D object and find the intersection points

#### **Parameters**

PlaneN	Plane normal vector
PlaneP	Plane known point
IntPts	Intersection points

# 6.13.3.3 intersectRay()

```
bool TireGround::RDF::Triangle3D::intersectRay (
    vec3 const & RayOrigin,
    vec3 const & RayDirection,
    vec3 & IntPt ) const [inherited]
```

Check if a ray hits a Triangle3D object through Möller-Trumbore intersection algorithm

#### **Parameters**

RayOrigin	Ray origin position
RayDirection	Ray direction vector
IntPt	Intersection point

# 6.13.3.4 print()

Print vertices data.

**Parameters** 

```
stream | Output stream type
```

# 6.13.3.5 setFriction()

```
void TireGround::RDF::TriangleRoad::setFriction (
    real_type _Friction ) [inline]
```

Set friction coefficient.

**Parameters** 

```
_Friction | New friction coefficient
```

```
6.13.3.6 setVertices() [1/2]
```

```
void TireGround::RDF::Triangle3D::setVertices (
    vec3 const _Vertices[3] ) [inline], [inherited]
```

Set new vertices and update bounding box domain.

**Parameters** 

```
_Vertices | Vertices reference vector
```

```
6.13.3.7 setVertices() [2/2]
```

```
void TireGround::RDF::Triangle3D::setVertices (
    vec3 const & Vertex0,
    vec3 const & Vertex1,
    vec3 const & Vertex2 ) [inline], [inherited]
```

Set new vertices then update bounding box domain and normal versor.

#### **Parameters**

Vertex0	Vertex 1
Vertex1	Vertex 2
Vertex2	Vertex 3

The documentation for this class was generated from the following file:

• include/RoadRDF.hh

# Index

BBox2D	TireGround::MagicFormula, 31
TireGround::RDF::BBox2D, 20	TireGround::MultiDisk, 47
	TireGround::ReferenceFrame, 56
contactPlane	TireGround::Tire, 66
TireGround::Disk, 22	getEulerAngleZ
contactTriangles	TireGround::MagicFormula, 31
TireGround::Disk, 22	TireGround::MultiDisk, 47
	TireGround::ReferenceFrame, 57
Disk	TireGround::Tire, 66
TireGround::Disk, 21	getFriction
	TireGround::MagicFormula, 31
ETRTO	TireGround::MultiDisk, 47, 49
TireGround::ETRTO, 26	TireGround::Tire, 66, 67
evaluateContact	getLineArea
TireGround::MagicFormula, 30	TireGround::Disk, 23
TireGround::Tire, 65	
	getMFpoint
firstToken	TireGround::MagicFormula, 32
TireGround::RDF::algorithms, 16	TireGround::MultiDisk, 49
fourPointsSampling	TireGround::Tire, 67
TireGround::MagicFormula, 30	getMFpointRF
	TireGround::MagicFormula, 32
getArea	TireGround::MultiDisk, 49, 50
TireGround::MagicFormula, 30	TireGround::Tire, 67, 68
TireGround::MultiDisk, 44, 45	getNormal
TireGround::Tire, 66	TireGround::MagicFormula, 33
getDiskFriction	TireGround::MultiDisk, 50
TireGround::MultiDisk, 45	TireGround::Tire, 68
getDiskMFpoint	getRelativeCamber
TireGround::MultiDisk, 45	TireGround::MagicFormula, 33
getDiskMFpointRF	TireGround::MultiDisk, 50
TireGround::MultiDisk, 45	TireGround::Tire, 68
getDiskNormal	getRho
TireGround::MultiDisk, 46	TireGround::MagicFormula, 33, 34
getDiskOriginXYZ	TireGround::MultiDisk, 51
TireGround::MultiDisk, 46	TireGround::Tire, 69
getDiskRho	getRhoDot
TireGround::MultiDisk, 46	TireGround::MagicFormula, 34
getDiskRhoDot	TireGround::MultiDisk, 51
TireGround::MultiDisk, 47	TireGround::Tire, 69
getElement	getVolume
TireGround::RDF::algorithms, 17	TireGround::MagicFormula, 35
getEulerAngleX	TireGround::MultiDisk, 52
TireGround::MagicFormula, 31	TireGround::Tire, 70
TireGround::MultiDisk, 47	•
TireGround::ReferenceFrame, 56	intersectAABBtree
TireGround::Tire, 66	TireGround::RDF::MeshSurface, 39
getEulerAngleY	intersectBBox

82 INDEX

TireGround::RDF::MeshSurface, 39	TireGround::Disk, 24
intersectEdgePlane	segmentLength
TireGround::RDF::Triangle3D, 74	TireGround::Disk, 24
TireGround::RDF::TriangleRoad, 78	set
intersectPlane	TireGround::Disk, 24
TireGround::Disk, 23	TireGround::RDF::MeshSurface, 40
TireGround::RDF::Triangle3D, 75	TireGround::ReferenceFrame, 57
TireGround::RDF::TriangleRoad, 79	TireGround::SamplingGrid, 59
intersectPointSegment	setDiskOriginXZ
TireGround::algorithms, 13	TireGround::MultiDisk, 53
intersectRay	setFriction
TireGround::RDF::Triangle3D, 75	TireGround::RDF::TriangleRoad, 80
TireGround::RDF::TriangleRoad, 79	setOrigin
intersectRayPlane	TireGround::MagicFormula, 36
TireGround::algorithms, 14	TireGround::MultiDisk, 54
intersectSegment	TireGround::ReferenceFrame, 57
TireGround::Disk, 23	TireGround::Tire, 71
isPointInside	setOriginXZ
TireGround::Disk, 24	TireGround::Disk, 25
	setReferenceFrame
LoadFile	TireGround::MagicFormula, 36
TireGround::RDF::MeshSurface, 39	TireGround::MultiDisk, 54
M · F 1	TireGround::Tire, 71
MagicFormula	setRotationMatrix
TireGround::MagicFormula, 29	TireGround::MagicFormula, 36
MeshSurface	TireGround::MultiDisk, 54
TireGround::RDF::MeshSurface, 38	TireGround::ReferenceFrame, 57
minmax_XY	TireGround::Tire, 72
TireGround::algorithms, 14	setSwitchNumber
MultiDisk	TireGround::SamplingGrid, 59
TireGround::MultiDisk, 43, 44	setTotalTransformationMatrix
nointCompline	TireGround::MagicFormula, 37
pointSampling TireCrounduMagicFormula 35	TireGround::MultiDisk, 54
TireGround::MagicFormula, 35	TireGround::ReferenceFrame, 57
TireGround::MultiDisk, 52	TireGround::Tire, 72
TireGround::Tire, 70	setVertices
print TireCrounduETETO 26	TireGround::RDF::Triangle3D, 76
TireGround::ETRTO, 26	TireGround::RDF::TriangleRoad, 80
TireGround::MagicFormula, 35 TireGround::MultiDisk, 53	setup
TireGround::RDF::BBox2D, 20	TireGround::MagicFormula, 37
	TireGround::MultiDisk, 55
TireGround::RDF::Triangle3D, 75	TireGround::Tire, 72
TireGround::RDF::TriangleRoad, 79	Shadow
TireGround::Tire, 71	TireGround::Shadow, 61
printData TireCrounduPDEvMochSurface 20	split
TireGround::RDF::MeshSurface, 39 printETRTOGeometry	TireGround::RDF::algorithms, 17
TireGround::MagicFormula, 36	0
TireGround::MultiDisk, 53	tail
TireGround::Tire, 71	TireGround::RDF::algorithms, 17
meGroundme, /1	TicToc, 62
ReferenceFrame	Tire
TireGround::ReferenceFrame, 56	TireGround::Tire, 65
	TireGround, 11
SamplingGrid	TireGround::Disk, 20
TireGround::SamplingGrid, 58, 59	contactPlane, 22
segmentArea	contactTriangles, 22

INDEX 83

Disk, 21	getVolume, 52
getLineArea, 23	MultiDisk, 43, 44
intersectPlane, 23	pointSampling, 52
intersectSegment, 23	print, 53
isPointInside, 24	printETRTOGeometry, 53
segmentArea, 24	setDiskOriginXZ, 53
segmentLength, 24	setOrigin, 54
set, 24	setReferenceFrame, 54
setOriginXZ, 25	setRotationMatrix, 54
y, 25	setTotalTransformationMatrix, 54
TireGround::ETRTO, 25	setup, 55
ETRTO, 26	TireGround::RDF::BBox2D, 19
print, 26	BBox2D, 20
TireGround::MagicFormula, 26	print, 20
evaluateContact, 30	updateBBox2D, 20
fourPointsSampling, 30	TireGround::RDF::MeshSurface, 37
getArea, 30	intersectAABBtree, 39
getEulerAngleX, 31	intersectBBox, 39
getEulerAngleY, 31	LoadFile, 39
getEulerAngleZ, 31	MeshSurface, 38
getFriction, 31	printData, 39
getMFpoint, 32	set, 40
getMFpointRF, 32	TireGround::RDF::Triangle3D, 73
getNormal, 33	intersectEdgePlane, 74
getRelativeCamber, 33	intersectPlane, 75
getRho, 33, 34	intersectRay, 75
getRhoDot, 34	print, 75
getVolume, 35	setVertices, 76
MagicFormula, 29	Triangle3D, 74
pointSampling, 35	TireGround::RDF::TriangleRoad, 76
print, 35	intersectEdgePlane, 78
printETRTOGeometry, 36	intersectPlane, 79
setOrigin, 36	intersectRay, 79
setReferenceFrame, 36	print, 79
setRotationMatrix, 36	setFriction, 80
setTotalTransformationMatrix, 37	setVertices, 80
setup, 37	TriangleRoad, 78
TireGround::MultiDisk, 40	TireGround::RDF::algorithms, 16
getArea, 44, 45	firstToken, 16
getDiskFriction, 45	getElement, 17
getDiskMFpoint, 45	split, 17
getDiskMFpointRF, 45	tail, 17
getDiskNormal, 46	TireGround::RDF, 15
getDiskOriginXYZ, 46	TireGround::ReferenceFrame, 55
getDiskRho, 46	getEulerAngleX, 56
getDiskRhoDot, 47	getEulerAngleY, 56
getEulerAngleX, 47	getEulerAngleZ, 57
getEulerAngleY, 47	ReferenceFrame, 56
getEulerAngleZ, 47	set, 57
getFriction, 47, 49	setOrigin, 57
getMFpoint, 49	setRotationMatrix, 57
getMFpointRF, 49, 50	setTotalTransformationMatrix, 57
getNormal, 50	TireGround::SamplingGrid, 58
getRelativeCamber, 50	SamplingGrid, 58, 59
getRho, 51	set, 59
getRhoDot, 51	setSwitchNumber, 59
0- ········· - · · · · -	

84 INDEX

```
TireGround::Shadow, 61
    Shadow, 61
    update, 61
TireGround::Tire, 62
    evaluateContact, 65
    getArea, 66
    getEulerAngleX, 66
    getEulerAngleY, 66
    getEulerAngleZ, 66
    getFriction, 66, 67
    getMFpoint, 67
    getMFpointRF, 67, 68
    getNormal, 68
    getRelativeCamber, 68
    getRho, 69
    getRhoDot, 69
    getVolume, 70
    pointSampling, 70
    print, 71
    printETRTOGeometry, 71
    setOrigin, 71
    setReferenceFrame, 71
    setRotationMatrix, 72
    setTotalTransformationMatrix, 72
    setup, 72
    Tire, 65
TireGround::algorithms, 13
    intersectPointSegment, 13
    intersectRayPlane, 14
    minmax_XY, 14
    trapezoidArea, 15
    weightedMean, 15
trapezoidArea
    TireGround::algorithms, 15
Triangle3D
    TireGround::RDF::Triangle3D, 74
TriangleRoad
    TireGround::RDF::TriangleRoad, 78
update
    TireGround::Shadow, 61
updateBBox2D
    TireGround::RDF::BBox2D, 20
weightedMean
    TireGround::algorithms, 15
y
```

TireGround::Disk, 25