Table of Contents

```
%Marat Purnyn and Leonard Knittle
%Section 61
%Group 9
%========= Accelerometer Vector Skeleton Code ==================================
This skeleton script does the following:
% 1. Specifies the COM port that the Arduino board is connected to
% 2. Initializes the Serial Port - setupSerial() (not to be altered)
% 3. Runs a calibration routine if needed - calibrate() (not to be altered)
4. Opens a new figure and customizes it by adding start/stop and close
  serial buttons
  - A different stop call
% 5. Runs a loop that continually reads the accelerometer values
  readAcc() - (not to be altered)
  The accelerometer data is placed in the variables [qx qy qz].
% 6. Displays the vectors using line() command
```

1. Specifies the COM port that the Arduino board is connected to

2. Initialize the Serial Port - setupSerial() (not to be altered)

%connect MATLAB to the accelerometer

3. Run a calibration routine if needed - calibrate() (not to be altered)

```
%if the accelerometer is not calibrated, calibrate now
if(~exist('calCo', 'var'))
    calCo = calibrate(accelerometer.s);
end
```

4. Open a new figure - add start/stop and close serial buttons

```
%initalize the figure that we will plot in if it does not exist
if(~exist('h', 'var') || ~ishandle(h))
   h = figure(1);
   ax = axes('box','on');
end
%add a start/stop and close serial button inside the figure
%Keep in mind the 'stop_call_wk3' function that this button calls everytime
%it is pressed
if(~exist('button','var'))
   button = uicontrol('Style','pushbutton','String','Stop',...
                    'pos',[0 0 50 25],'parent',h,...
                    'Callback', 'stop_call_vector', 'UserData', 1);
end
%Keep in mind the 'close_call' function that this button calls everytime
%it is pressed
if(~exist('button2','var'))
   button2 = uicontrol('Style', 'pushbutton', 'String', 'Close Serial Port',...
                    'pos',[250 0 150 25],'parent',h,...
                    'Callback','closeSerial','UserData',1);
end
```

5. Runs a loop that continually reads the accelerometer values

```
readAcc() - (not to be altered)
            The accelerometer data is placed in the variables [gx gy gz].
while (get(button, 'UserData'))
    %read accelerometer output
    [gx gy gz] = readAcc(accelerometer, calCo);
    cla;
                      %clear everything from the current axis
    %plot X and Y acceleration vectors and resultant acceleration vector
    line([0 gx], [0 0],[0 0], 'Color', 'r', 'LineWidth', 2, 'Marker', 'o');
    line([0 0], [0 gy],[0 0], 'Color', 'g', 'LineWidth', 2, 'Marker', 'o');
line([0 0], [0 0],[0 gz], 'Color', 'b', 'LineWidth', 2, 'Marker', 'o');
    line([0 gx], [0 gy],[0 gz], 'Color', 'black', 'LineWidth', 2, 'Marker', 'o');
    % limit plot to +/- 1.25 g in all directions and make axis square
    limits = 2.5;
    axis([-limits limits -limits limits -limits limits]);
    axis square;
    *calculate the angle of the resultant acceleration vector and print
    theta = atand(gy/gx);
    title(['Accelerometer tilt angle: ' num2str(theta, '%.0f')]);
    %force MATLAB to redraw the figure
    drawnow;
end
```

Published with MATLAB® R2013a