Back to search page

# Click to download printable version of this guide.

AWR Microwave Office Element Catalog > Sources > DC Voltage Source: DCVS

<u>Prev</u> <u>Next</u>

## **DC Voltage Source: DCVS**

## **Symbol**



#### **Parameters**

Name	Description	Unit Type	Default
ID	Voltage source ID	Text	V1
V	DC voltage	Voltage	1 V

#### **Implementation Details**

Produces a DC voltage.

## Layout

This element does not have an assigned layout cell. You can assign artwork cells to any element. See <u>"Assigning Artwork Cells to Layout of Schematic Elements"</u> for details.

<u>Prev</u> <u>Up</u> <u>Next</u>

<u>Home</u>

Please send email to <a href="mailto:awr.support@cadence.com">awr.support@cadence.com</a> if you would like to provide feedback on this article. Please make sure to include the article link in the email.

Legal and Trademark Notice