DHT22 library for Arduino 1.0.0

Generated by Doxygen 1.8.14

Contents

Index

| 1 | DHT | DHT22 - AM2303 temperature and humidity sensor library for Arduino | | | 1 | | |
|---|--------------------|--|------------|---------------------------------|------|--|--|
| 2 | Class Index | | | | | | |
| | 2.1 | Class I | List | | . 5 | | |
| 3 | File | Index | | | | | |
| | 3.1 | File Lis | st | | . 7 | | |
| 4 | Clas | s Docu | mentation | 1 | 9 | | |
| | 4.1 | DHT22 | 2 Class Re | eference | . 9 | | |
| | | 4.1.1 | Detailed | Description | . 9 | | |
| | | 4.1.2 | Construc | ctor & Destructor Documentation | . 9 | | |
| | | | 4.1.2.1 | DHT22() | . 9 | | |
| | | 4.1.3 | Member | Function Documentation | . 10 | | |
| | | | 4.1.3.1 | available() | . 10 | | |
| | | | 4.1.3.2 | begin() | . 10 | | |
| | | | 4.1.3.3 | readHumidity() | . 10 | | |
| | | | 4.1.3.4 | readTemperature() | . 11 | | |
| 5 | File Documentation | | | | 13 | | |
| | 5.1 | src/DH | T22.cpp F | File Reference | . 13 | | |
| | | 5.1.1 | Detailed | Description | . 13 | | |
| | 5.2 | src/DHT22.h File Reference | | Reference | . 13 | | |
| | | 5.2.1 | Detailed | Description | . 14 | | |
| | | 5.2.2 | Macro Do | efinition Documentation | . 14 | | |
| | | | 5.2.2.1 | DHT22_MIN_READ_INTERVAL | . 14 | | |
| | | | 5.2.2.2 | DHT22_NUM_DATA_BITS | . 14 | | |
| | | | | | | | |

15

DHT22 - AM2303 temperature and humidity sensor library for Arduino

This is a calibrated AM2303 digital temperature and relative humidity sensor on a DHT22 breakout PCB.

Library features

- Read 16-bit temperature (synchronous blocking)
- · Read 16-bit relative humidity (synchronous blocking)

AM2303 sensor specifications

- · Voltage: 3.3 .. 5V
- · Ultra-low power:
 - Typical 15uA dormancy
 - Typical 500uA measuring
- · Single wire digital serial interface
- · Calibrated digital signal
- · Outstanding long term stability
- · No additional electronic components needed
- · Humidity:
 - Range: 0 .. 99.9 RH (Relative Humidity)
 - Resolution: 0.1 RH
 - Accuracy: +/-2 RH (at 25 degree Celsius)
- · Temperature:
 - Range: -40 .. +125 degree Celsius
 - Resolution: 0.1 degree Celsius
 - Accuracy: +/- 0.4 degree Celsius
- · Minimum read interval: 2000 ms
- \bullet \sim 31ms to synchronous read humidity, temperature and parity data from sensor (5 Bytes)

Hardware

Connection DHT22 - Arduino

| DHT22 | Arduino UNO/Nano/Leonardo/Mega2560 |
|-------|------------------------------------|
| GND | GND |
| VCC | 5V (or 3.3V) |
| DAT | D2 |

Connection DHT22 - ESP8266

Some ESP8266 boards uses Arduino pin 2 -> GPIO4 which is D4 text on the board. Make sure you're using the right pin.

| DHT22 | ESP8266 / WeMos D1 R2 / ESP12E / NodeMCU |
|-------|--|
| GND | GND |
| VCC | 3.3V |
| DAT | Arduino pin 2 -> GPIO4 = D4 |

Connection DHT22 - Lolin32

| DHT22 | WeMos Lolin32 |
|-------|---------------|
| GND | GND |
| VCC | 3.3V |
| DAT | 2 |

Supported Arduino Boards

- All ATMega328P MCU's:
 - Arduino UNO
 - Arduino Nano
- All ATMega32U4 MCU's:
 - Arduino Leonardo
 - Pro Micro
- All ATMega2560 MCU's:
 - Arduino Mega2560
- · All ESP8266 boards:
 - WeMos D1 R2
 - NodeMCU
- · All Lolin32 boards:
 - WeMos Lolin32
- Other MCU's may work, but are not tested.

Library dependencies

None

Documentation

Doxygen PDF (Documentation source code)

AM2303 datasheet

DHT22 datasheet

Examples

Examples | Erriez DH22 | Example

Usage

Initialization

```
{c++}
#include <DHT22.h>

// Connect DTH22 data pin to Arduino DIGITAL pin
#define DHT22_PIN 2

DHT22 sensor = DHT22(DHT22_PIN);

void setup()
{
    // Initialize serial port
    Serial.begin(115200);
    Serial.println(F("DHT22 temperature and humidity sensor example\n"));
    // Initialize sensor
    sensor.begin();
}
```

Read temperature and humidity

```
{c++}
void loop()
    // Check minimum interval of 2000 ms between sensor reads
    if (sensor.available()) {
        // Read temperature from sensor
        int16_t temperature = sensor.readTemperature();
        // Read humidity from sensor
        int16_t humidity = sensor.readHumidity();
        if (temperature == \sim 0) {
            // Print error (Check hardware connection)
            Serial.print(F("Temperature: Error"));
        Serial.print(temperature / 10);
            Serial.print(F("."));
            Serial.print(temperature % 10);
Serial.println(F(" *C"));
        if (humidity == ~0) {
    // Print error (Check hardware connection)
            Serial.print(F("Humidity: Error"));
        } else {
    // Print humidity
            Serial.print(F("Humidity: "));
            Serial.print(humidity / 10);
            Serial.print(F("."));
            Serial.print(humidity % 10);
            Serial.println(F(" %"));
        Serial.println();
}
```

Serial output

DHT22 temperature and humidity sensor example

Temperature: 17.7 *C

Humidity: 41.0 %

Temperature: 17.8 *C

Humidity: 41.1 %

...

Class Index

| _ | | | |
|---|---|-------|-------|
| 2 | 1 | Clace | I iet |

| Here are the classes, structs, unions and interfaces with brief descriptions: | | | | | |
|---|--------------------|---|--|--|--|
| DHT22 | DHT22 sensor class | 9 | | | |

6 Class Index

File Index

3.1 File List

Here is a list of all documented files with brief descriptions:

| src/DHT22.cpp | |
|--|--------|
| DHT22 (AM2303) Humidity and Temperature sensor example for Arduino | 13 |
| src/DHT22.h | |
| DHT22 (AM2303) Humidity and Temperature sensor example for Arduino | 13 |

8 File Index

Class Documentation

4.1 DHT22 Class Reference

```
DHT22 sensor class.
```

```
#include <DHT22.h>
```

Public Member Functions

• DHT22 (uint8_t pin)

Constructor DHT22 sensor.

• void begin ()

Initialize sensor.

• bool available ()

Check if new temperature or humidity read is allowed.

• int16_t readTemperature ()

Read temperature from sensor.

• int16_t readHumidity ()

Read humidity from sensor.

4.1.1 Detailed Description

DHT22 sensor class.

Definition at line 58 of file DHT22.h.

4.1.2 Constructor & Destructor Documentation

4.1.2.1 DHT22()

Constructor DHT22 sensor.

10 Class Documentation

Parameters

```
pin Data pin sensor.
```

Definition at line 37 of file DHT22.cpp.

4.1.3 Member Function Documentation

4.1.3.1 available()

```
bool DHT22::available ()
```

Check if new temperature or humidity read is allowed.

The application should call this function and check if a new temperature and humidity can be read to prevent too fast sensor reads.

Returns

true: Available, interval between sensor reads \geq 2000 ms. false: Not available, interval between sensor reads too short.

Definition at line 79 of file DHT22.cpp.

4.1.3.2 begin()

```
void DHT22::begin ( )
```

Initialize sensor.

Call this function from setup().

Definition at line 59 of file DHT22.cpp.

4.1.3.3 readHumidity()

```
int16_t DHT22::readHumidity ( )
```

Read humidity from sensor.

Returns

Signed humidity with last digit after the point. \sim 0: An error occurred

Definition at line 121 of file DHT22.cpp.

4.1 DHT22 Class Reference

4.1.3.4 readTemperature()

```
int16_t DHT22::readTemperature ( )
```

Read temperature from sensor.

Returns the actual temperature, or a cached temperature when read interval is too short.

Returns

Signed temperature with last digit after the point \sim 0: An error occurred

Definition at line 99 of file DHT22.cpp.

The documentation for this class was generated from the following files:

- src/DHT22.h
- src/DHT22.cpp

12 Class Documentation

File Documentation

5.1 src/DHT22.cpp File Reference

DHT22 (AM2303) Humidity and Temperature sensor example for Arduino.

```
#include "DHT22.h"
```

5.1.1 Detailed Description

DHT22 (AM2303) Humidity and Temperature sensor example for Arduino.

```
Source: https://github.com/Erriez/ErriezDHT22
```

5.2 src/DHT22.h File Reference

DHT22 (AM2303) Humidity and Temperature sensor example for Arduino.

```
#include <Arduino.h>
```

Classes

• class DHT22

DHT22 sensor class.

Macros

- #define DHT22_MIN_READ_INTERVAL 2000

 Enable debug prints to Serial.
- #define DHT22_NUM_DATA_BITS (5 * 8)
- #define DEBUG_PRINTLN(...) {}

Debug print configuration.

14 File Documentation

5.2.1 Detailed Description

DHT22 (AM2303) Humidity and Temperature sensor example for Arduino.

Source: https://github.com/Erriez/ErriezDHT22

5.2.2 Macro Definition Documentation

5.2.2.1 DHT22_MIN_READ_INTERVAL

```
#define DHT22_MIN_READ_INTERVAL 2000
```

Enable debug prints to Serial.

Minimum interval between sensor reads in milli seconds

Definition at line 40 of file DHT22.h.

5.2.2.2 DHT22_NUM_DATA_BITS

```
#define DHT22_NUM_DATA_BITS (5 * 8)
```

Number of data bits is 5 Bytes * 8 bits: 1 Byte: Humidity high 1 Byte: Humidity low 1 Byte: Temperature high 1 Byte: Temperature low 1 Byte: Parity

Definition at line 48 of file DHT22.h.

Index

```
available
    DHT22, 10
begin
    DHT22, 10
DHT22, 9
    available, 10
    begin, 10
    DHT22, 9
    readHumidity, 10
    readTemperature, 10
DHT22.h
    DHT22_MIN_READ_INTERVAL, 14
    DHT22_NUM_DATA_BITS, 14
DHT22_MIN_READ_INTERVAL
    DHT22.h, 14
DHT22_NUM_DATA_BITS
    DHT22.h, 14
readHumidity
    DHT22, 10
readTemperature
    DHT22, 10
src/DHT22.cpp, 13
src/DHT22.h, 13
```