# Erriez Serial Terminal library for Arduino

1.1.1

Generated by Doxygen 1.8.11

## **Contents**

Index

1	Seri	ial Term	inal librar	ry for Arduino	1
2	Clas	ss Index	ī.		5
	2.1	Class	List		5
3	File	Index			7
	3.1	File Lis	st		7
4	Clas	ss Docu	mentatio	n	9
	4.1	Serial	Terminal C	lass Reference	9
		4.1.1	Detailed	Description	9
		4.1.2	Construc	ctor & Destructor Documentation	9
			4.1.2.1	SerialTerminal(char newlineChar='\n', char delimiterChar=' ')	9
		4.1.3	Member	Function Documentation	10
			4.1.3.1	addCommand(const char *command, void(*function)())	10
			4.1.3.2	getNext()	10
			4.1.3.3	getRemaining()	10
			4.1.3.4	readSerial()	11
			4.1.3.5	setDefaultHandler(void(*function)(const char *))	11
5	File	Docum	entation		13
	5.1	Erriez	SerialTerm	ninal.cpp File Reference	13
		5.1.1	Detailed	Description	13
	5.2	Erriez	SerialTerm	ninal.h File Reference	13
		5.2.1	Detailed	Description	13

15

# **Serial Terminal library for Arduino**

This is a universal Serial Terminal library for Arduino to parse ASCII commands and arguments.

### Hardware

Any Arduino hardware with a serial port.

### **Examples**

Arduino IDE | Examples | Erriez Serial Terminal |

• SerialTerminal

### **Documentation**

- Online HTML
- Download PDF

### Usage

### Initialization

Create a Serial Terminal object. This can be initialized with optional newline and delimiter characters.

Default newline character:  $\ensuremath{^{\mbox{\sc h}}}\ensuremath{^{\mbox{\sc h}}}\$ 

```
2 #include <ErriezSerialTerminal.h>
4 // Newline character '\r' or '\n' 5 char newlineChar = '\n';
6 // Separator character between commands and arguments 7 char delimiterChar = ' ';
9 // Create serial terminal object
10 SerialTerminal term(newlineChar, delimiterChar);
11
12
13 void setup()
14 {
15
       // Initialize serial port
16
       Serial.begin(115200);
17
18
       // Initialize the built-in LED
       pinMode(LED_BUILTIN, OUTPUT);
19
       digitalWrite(LED_BUILTIN, LOW);
```

### Register new commands

Commands must be registered at startup with a corresponding callback handler. This registers the command only, excluding arguments.

The callback handler will be called when the command has been received including the newline character.

An example of registering multiple commands:

```
2 void setup()
3 {
        // Add command callback handlers
        term.addCommand("?", cmdHelp);
        term.addCommand("help", cmdHelp);
term.addCommand("on", cmdLedOn);
term.addCommand("off", cmdLedOff);
8
9
10
11 }
12
13 void cmdHelp()
14 {
15
         // Print usage
        Serial.println(F("Serial terminal usage:"));
16
         Serial.println(F(" serial terminal usage: ));
Serial.println(F(" help or ? Print this usage"));
Serial.println(F(" on Turn LED on"));
Serial.println(F(" off Turn LED off"));
17
18
19
20 }
22 void cmdLedOn()
23 {
24
         // Turn LED on
25
         Serial.println(F("LED on"));
         digitalWrite(LED_BUILTIN, HIGH);
27 }
2.8
29 void cmdLedOff()
30 {
         // Turn LED off
31
         Serial.println(F("LED off"));
33
         digitalWrite(LED_BUILTIN, LOW);
34 }
```

### Set default handler

Optional: The default handler will be called when the command is not recognized.

```
1 {c++}
2 void setup()
3 {
4    ...
5    // Set default handler for unknown commands
```

```
7  term.setDefaultHandler(unknownCommand);
8 }
9
10 void unknownCommand(const char *command)
11 {
12   // Print unknown command
13   Serial.print(F("Unknown command: "));
14   Serial.println(command);
15 }
```

### Read from serial port

Read from the serial port in the main loop:

### Get next argument

Get pointer to next argument in serial receive buffer:

```
1 {c++}
2 char *arg;
3
4 // Get next argument
5 arg = term.getNext();
6 if (arg != NULL) {
7     Serial.print(F("Argument: "));
8     Serial.println(arg);
9 } else {
10     Serial.println(F("No argument"));
```

### Get remaining characters

Get pointer to remaining characters in serial receive buffer:

#### Clear buffer

Optional: The serial receive buffer can be cleared with the following call:

```
1 {c++}
2 term.clearBuffer();
```

### Library configuration

SerialTerminal.h contains the following configuration macro's:

- ST\_RX\_BUFFER\_SIZE: The default serial receive buffer size is 32 Bytes. This includes the command and arguments, excluding the '\0' character.
- ST\_NUM\_COMMAND\_CHARS: The default number of command characters is 8 Bytes, excluding the '\0' character.

### Library dependencies

• None.

### Library installation

Please refer to the Wiki page.

### Other Arduino Libraries and Sketches from Erriez

• Erriez Libraries and Sketches

# **Class Index**

2	4		۱.	22	1	
"	Т.	- (	เเล	ee		ICT

Here are the	classes, structs, union	s and interfa	ces with brief	descriptions:		
SerialTeri	minal					
	SerialTerminal class				 	9

6 Class Index

# File Index

### 3.1 File List

Here is a list of all documented files with brief descriptions:

ErriezSerialTerminal.cpp	
Serial terminal library for Arduino	13
ErriezSerialTerminal.h	
Serial terminal library for Arduino	13

8 File Index

### **Class Documentation**

### 4.1 SerialTerminal Class Reference

### SerialTerminal class.

```
#include <ErriezSerialTerminal.h>
```

### **Public Member Functions**

- SerialTerminal (char newlineChar='\n', char delimiterChar=' ')
  - SerialTerminal constructor.
- void addCommand (const char \*command, void(\*function)())
  - Add command with callback handler.
- void setDefaultHandler (void(\*function)(const char \*))
  - Set default callback handler for unknown commands.
- void readSerial ()
  - Read from serial port.
- void clearBuffer ()
  - Clear serial receive buffer.
- char \* getNext ()
  - Get next argument.
- char \* getRemaining ()

Get all remaining characters from serial buffer.

### 4.1.1 Detailed Description

### SerialTerminal class.

Definition at line 52 of file ErriezSerialTerminal.h.

### 4.1.2 Constructor & Destructor Documentation

```
4.1.2.1 SerialTerminal::SerialTerminal ( char newlineChar = '\n', char delimiterChar = ' ') [explicit]
```

SerialTerminal constructor.

10 Class Documentation

#### **Parameters**

newlineChar	Newline character '\r' or '\n'.  Default: '\n'.
delimiterChar	Delimiter separator character between commands and arguments.  Default: space.

Definition at line 44 of file ErriezSerialTerminal.cpp.

### 4.1.3 Member Function Documentation

4.1.3.1 void SerialTerminal::addCommand ( const char \* command, void(\*)() function )

Add command with callback handler.

#### **Parameters**

command	Register a null-terminated ASCII command.
function	The function to be called when receiving the command.

Definition at line 66 of file ErriezSerialTerminal.cpp.

4.1.3.2 char \* SerialTerminal::getNext ( )

Get next argument.

#### Returns

Address: Pointer to next argument NULL: No argument available

Definition at line 154 of file ErriezSerialTerminal.cpp.

4.1.3.3 char \* SerialTerminal::getRemaining ( )

Get all remaining characters from serial buffer.

### Returns

Address: Pointer to remaining characters in serial receive buffer.

NULL: No remaining data available.

Definition at line 165 of file ErriezSerialTerminal.cpp.

4.1.3.4 void SerialTerminal::readSerial ( )

Read from serial port.

Process command when newline character has been received.

Definition at line 98 of file ErriezSerialTerminal.cpp.

4.1.3.5 void SerialTerminal::setDefaultHandler ( void(\*)(const char \*) function )

Set default callback handler for unknown commands.

Store default callback handler which will be called when receiving an unknown command.

### **Parameters**

function	Address of the default handler. This function will be called when the command is not recognized.
	The parameter contains the first ASCII command.

Definition at line 88 of file ErriezSerialTerminal.cpp.

The documentation for this class was generated from the following files:

- ErriezSerialTerminal.h
- ErriezSerialTerminal.cpp

12 Class Documentation

## **File Documentation**

### 5.1 ErriezSerialTerminal.cpp File Reference

Serial terminal library for Arduino.

```
#include "ErriezSerialTerminal.h"
```

### 5.1.1 Detailed Description

Serial terminal library for Arduino.

```
Source: https://github.com/Erriez/ErriezSerialTerminal Documentation: https://erriez.github.io/ErriezSerialTerminal
```

### 5.2 ErriezSerialTerminal.h File Reference

Serial terminal library for Arduino.

```
#include <Arduino.h>
#include <string.h>
```

### Classes

class SerialTerminal
 SerialTerminal class.

#### **Macros**

- #define ST\_RX\_BUFFER\_SIZE 32
  - Size of the serial receive buffer in bytes (Maximum length of one command plus arguments)
- #define ST\_NUM\_COMMAND\_CHARS 8

Number of command characters.

### 5.2.1 Detailed Description

Serial terminal library for Arduino.

```
Source: https://github.com/Erriez/ErriezSerialTerminal Documentation: https←://erriez.github.io/ErriezSerialTerminal
```

14 File Documentation

## Index

```
addCommand
     SerialTerminal, 10
ErriezSerialTerminal.cpp, 13
ErriezSerialTerminal.h, 13
getNext
     SerialTerminal, 10
getRemaining
    SerialTerminal, 10
readSerial
    SerialTerminal, 10
SerialTerminal, 9
    addCommand, 10
    getNext, 10
    getRemaining, 10
    readSerial, 10
    SerialTerminal, 9
    setDefaultHandler, 11
setDefaultHandler
    SerialTerminal, 11
```