





B161	AC refrigerant pressure sensor
B138	
	Accelerator pedal position (APP) sensor
31	Battery -
30	Battery +
B132	Camshaft position (CMP) sensor
S258	Clutch pedal position (CPP) switch
CAN-H	Controller area network (data bus) high
CAN-L	Controller area network (data bus) low
B54	Crankshaft position (CKP) sensor
S101	Cruise control brake pedal switch
X1	Data link connector (DLC)
A35	Engine control module (ECM)
M6	Engine coolant blower motor
K12-I	Engine coolant blower motor relay 1
K12-II	Engine coolant blower motor relay 2
K12-III	Engine coolant blower motor relay 3
R46	Engine coolant blower motor resistor
R46-I	Engine coolant blower motor resistor 1
R46-II	Engine coolant blower motor resistor 2
R93	Engine coolant heater
K242-I	Engine coolant heater relay 1
K242-II	Engine coolant heater relay 2
B24	Engine coolant temperature (ECT) sensor
H63	Engine malfunction indicator lamp (MIL)
Y28	Exhaust gas recirculation (EGR) solenoid
R64	Fuel filter heater
Y194	Fuel flow control valve
B186	Fuel rail pressure (FRP) sensor
B31	Fuel temperature sensor
B82	Fuel/water separator sensor
F	Fuse
X28-IV	Fuse box/relay plate , fascia 2
X28-II	Fuse box/relay plate, engine bay 1
X28-III	Fuse box/relay plate, engine bay 1
X28-V	Fuse box/relay plate, engine bay 3
X28-I	Fuse box/relay plate, fascia 1
K93	Glow plug timer relay
H25	Glow plug warning lamp
R5	Glow plugs
15	Ignition switch - ignition ON
Y3	Injector
A5	Instrument panel
A75	Instrumentation control module
B25	Intake air temperature (IAT) sensor
B30	Mass air flow (MAF) sensor
A11-I	Multifunction control module 1
A11-II	Multifunction control module 2
X92-I	Shorting link connector 1
P7	Tachometer
VAN	Vehicle area network (data bus)
B33	Vehicle speed sensor (VSS)
P9	Vehicle speedometer